

## Systems supported by ECUREADER (up to V5.40)

### TRUCKS

Acerbi

**MODEL**

**SYSTEM TYPE**

**ENGINE / SYSTEM**

**ECU**

 Trailers



BRAKE SYS. MANAG Trailers

Wabco Trailer EBS

## Systems supported by ECUREADER (up to V5.40)

### TRUCKS





**ACM**

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Trailers	BRAKE SYS. MANAG	Trailers	Wabco Trailer EBS
 Trailers	BRAKE SYS. MANAG	Trailers	Wabco Trailer VCS II

## Systems supported by ECUREADER (up to V5.40)

### TRUCKS

Adamoli

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Trailers	BRAKE SYS. MANAG	Trailers	Wabco Trailer EBS
 Trailers	BRAKE SYS. MANAG	Trailers	Wabco Trailers EBS kw2000
 Trailers	BRAKE SYS. MANAG	Trailers Haldex	Haldex EBS EB+
 Trailers	BRAKE SYS. MANAG	Trailers Knorr	Knorr Trailer EBS

## Systems supported by ECUreader (up to V5.40)

### TRUCKS



Adige

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Trailers	ABS	Trailers Wabco	Wabco VARIO C1-C2-C plus
 Trailers	BRAKE SYS. MANAG	Trailers	Wabco Trailer EBS
 Trailers	BRAKE SYS. MANAG	Trailers	Wabco Trailers EBS kw2000
 Trailers	BRAKE SYS. MANAG	Trailers Haldex	Haldex EBS EB+
 Trailers	BRAKE SYS. MANAG	Trailers Knorr	Knorr Trailer EBS

## Systems supported by ECUreader (up to V5.40)

### TRUCKS
















### AGP Cisternas

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Trailers	BRAKE SYS. MANAG	Trailers	Wabco Trailer EBS
 Trailers	BRAKE SYS. MANAG	Trailers	Wabco Trailer VCS II

## Systems supported by ECUreader (up to V5.40)

### TRUCKS





Astra

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 HD7-C 42.36	ENGINE MANAGEME	Cursor 13 F3BE0681JB	BOSCH EDC MS 6.2
 HD7-C 42.40	ENGINE MANAGEME	Cursor 13 F3BE0681DB	BOSCH EDC MS 6.2
 HD7-C 42.45	ENGINE MANAGEME	Cursor 13 F3BE0681HB	BOSCH EDC MS 6.2
 HD7-C 64.36	ENGINE MANAGEME	Cursor 13 F3BE0681JB	BOSCH EDC MS 6.2
 HD7-C 64.40	ENGINE MANAGEME	Cursor 13 F3BE0681DB	BOSCH EDC MS 6.2
 HD7-C 64.45	ENGINE MANAGEME	Cursor 13 F3BE0681HB	BOSCH EDC MS 6.2
 HD7-C 64.50	ENGINE MANAGEME	Cursor 13 F3BE0681FB	BOSCH EDC MS 6.2
 HD7-C 66.36	ENGINE MANAGEME	Cursor 13 F3BE0681DB	BOSCH EDC MS 6.2
 HD7-C 66.36	ENGINE MANAGEME	Cursor 13 F3BE0681FB	BOSCH EDC MS 6.2
 HD7-C 66.36	ENGINE MANAGEME	Cursor 13 F3BE0681HB	BOSCH EDC MS 6.2
 HD7-C 66.36	ENGINE MANAGEME	Cursor 13 F3BE0681JB	BOSCH EDC MS 6.2
 HD7-C 84.36	ENGINE MANAGEME	Cursor 13 F3BE0681JB	BOSCH EDC MS 6.2
 HD7-C 84.40	ENGINE MANAGEME	Cursor 13 F3BE0681DB	BOSCH EDC MS 6.2
 HD7-C 84.45	ENGINE MANAGEME	Cursor 13 F3BE0681HB	BOSCH EDC MS 6.2
 HD7-C 84.50	ENGINE MANAGEME	Cursor 13 F3BE0681FB	BOSCH EDC MS 6.2
 HD7-C 86.40	ENGINE MANAGEME	Cursor 13 F3BE0681DB	BOSCH EDC MS 6.2
 HD7-C 86.45	ENGINE MANAGEME	Cursor 13 F3BE0681HB	BOSCH EDC MS 6.2
 HD7-C 86.50	ENGINE MANAGEME	Cursor 13 F3BE0681FB	BOSCH EDC MS 6.2

## Systems supported by ECUREADER (up to V5.40)

### TRUCKS





Atlas

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Trailers	BRAKE SYS. MANAG	Trailers	Wabco Trailers EBS
 Trailers	BRAKE SYS. MANAG	Trailers	Wabco Trailers EBS kw2000
 Trailers	BRAKE SYS. MANAG	Trailers Haldex	Haldex EBS EB+
 Trailers	BRAKE SYS. MANAG	Trailers Knorr	Knorr Trailer EBS

## Systems supported by ECUreader (up to V5.40)

### TRUCKS



**Bartoletti**

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Trailers	BRAKE SYS. MANAG	Trailers	Wabco Trailer EBS
 Trailers	BRAKE SYS. MANAG	Trailers	Wabco Trailers EBS kw2000
 Trailers	BRAKE SYS. MANAG	Trailers Haldex	Haldex EBS EB+
 Trailers	BRAKE SYS. MANAG	Trailers Knorr	Knorr Trailer EBS

## Systems supported by ECUreader (up to V5.40)

### TRUCKS



**Basben**

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Trailers	BRAKE SYS. MANAG	Trailers	Wabco Trailer EBS
 Trailers	BRAKE SYS. MANAG	Trailers	Wabco Trailer VCS II

## Systems supported by ECUreader (up to V5.40)

### TRUCKS





### Basculantes Martin

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Trailers	BRAKE SYS. MANAG	Trailers	Wabco Trailer EBS
 Trailers	BRAKE SYS. MANAG	Trailers	Wabco Trailer VCS II

## Systems supported by ECUreader (up to V5.40)

### TRUCKS





**Berger**

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Trailers	BRAKE SYS. MANAG	Trailers	Wabco Trailer EBS
 Trailers	BRAKE SYS. MANAG	Trailers	Wabco Trailers EBS kw2000
 Trailers	BRAKE SYS. MANAG	Trailers Haldex	Haldex EBS EB+
 Trailers	BRAKE SYS. MANAG	Trailers Knorr	Knorr Trailer EBS

## Systems supported by ECUreader (up to V5.40)

### TRUCKS






Bertoja

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Trailers	BRAKE SYS. MANAG	Trailers	Wabco Trailers EBS
 Trailers	BRAKE SYS. MANAG	Trailers	Wabco Trailers EBS kw2000
 Trailers	BRAKE SYS. MANAG	Trailers Haldex	Haldex EBS EB+
 Trailers	BRAKE SYS. MANAG	Trailers Knorr	Knorr Trailer EBS

## Systems supported by ECUreader (up to V5.40)

### TRUCKS



Broshuis

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Trailers	BRAKE SYS. MANAG	Trailers	Wabco Trailer EBS
 Trailers	BRAKE SYS. MANAG	Trailers	Wabco Trailer VCS II
 Trailers	BRAKE SYS. MANAG	Trailers	Wabco Trailers EBS kw2000
 Trailers	BRAKE SYS. MANAG	Trailers Haldex	Haldex EBS EB+
 Trailers	BRAKE SYS. MANAG	Trailers Knorr	Knorr Trailer EBS

## Systems supported by ECUreader (up to V5.40)

### TRUCKS



**Caldal**

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Trailers	BRAKE SYS. MANAG	Trailers	Wabco Trailer EBS
 Trailers	BRAKE SYS. MANAG	Trailers	Wabco Trailer VCS II

## Systems supported by ECUreader (up to V5.40)

### TRUCKS


Cametal

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Trailers	BRAKE SYS. MANAG	Trailers	Wabco Trailer EBS
 Trailers	BRAKE SYS. MANAG	Trailers	Wabco Trailer VCS II

## Systems supported by ECUreader (up to V5.40)

### TRUCKS






Cardi

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Trailers	ABS	Trailers Wabco	Wabco VARIO C1-C2-C plus
 Trailers	BRAKE SYS. MANAG	Trailers	Wabco Trailer EBS
 Trailers	BRAKE SYS. MANAG	Trailers	Wabco Trailers EBS kw2000
 Trailers	BRAKE SYS. MANAG	Trailers Haldex	Haldex EBS EB+
 Trailers	BRAKE SYS. MANAG	Trailers Knorr	Knorr Trailer EBS

## Systems supported by ECUreader (up to V5.40)

### TRUCKS



**Carmosino**

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Trailers	BRAKE SYS. MANAG	Trailers	Wabco Trailer EBS
 Trailers	BRAKE SYS. MANAG	Trailers	Wabco Trailer VCS II
 Trailers	BRAKE SYS. MANAG	Trailers	Wabco Trailers EBS kw2000
 Trailers	BRAKE SYS. MANAG	Trailers Haldex	Haldex EBS EB+
 Trailers	BRAKE SYS. MANAG	Trailers Knorr	Knorr Trailer EBS

## Systems supported by ECUREADER (up to V5.40)

### TRUCKS





### Chasis Levante

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Trailers	BRAKE SYS. MANAG	Trailers	Wabco Trailer EBS
 Trailers	BRAKE SYS. MANAG	Trailers	Wabco Trailer VCS II

## Systems supported by ECUreader (up to V5.40)

### TRUCKS



Chiavetta

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Trailers	BRAKE SYS. MANAG	Trailers	Wabco Trailers EBS
 Trailers	BRAKE SYS. MANAG	Trailers	Wabco Trailers EBS kw2000
 Trailers	BRAKE SYS. MANAG	Trailers Haldex	Haldex EBS EB+
 Trailers	BRAKE SYS. MANAG	Trailers Knorr	Knorr Trailer EBS

## Systems supported by ECUreader (up to V5.40)

### TRUCKS



Chizalosa

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Trailers	BRAKE SYS. MANAG	Trailers	Wabco Trailer EBS
 Trailers	BRAKE SYS. MANAG	Trailers	Wabco Trailer VCS II

## Systems supported by ECUREADER (up to V5.40)

### TRUCKS

























### Cisternas La Mancha

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Trailers	BRAKE SYS. MANAG	Trailers	Wabco Trailer EBS
 Trailers	BRAKE SYS. MANAG	Trailers	Wabco Trailer VCS II

## Systems supported by ECReader (up to V5.40)

### TRUCKS



Citroen

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Berlingo 2	ABS + TRACT. CONT	1.1 HFX	BOSCH ABS 8.0 no ESP AUTODETECT
 Berlingo 2	ABS + TRACT. CONT	1.1 HFX	BOSCH ABS 8.1 AUTODETECT
 Berlingo 2	ABS + TRACT. CONT	1.1 HFX	BOSCH ABS/ESP 5.7
 Berlingo 2	ABS + TRACT. CONT	1.1 HFX	BOSCH ESP 5.7 AUTODETECT
 Berlingo 2	ABS + TRACT. CONT	1.1 HFX	BOSCH ESP 8.0 AUTODETECT
 Berlingo 2	ABS + TRACT. CONT	1.1 HFX	BOSCH ESP 8.1 AUTODETECT
 Berlingo 2	ABS + TRACT. CONT	1.4 - GPL KfV	BOSCH ABS 8.0 no ESP AUTODETECT
 Berlingo 2	ABS + TRACT. CONT	1.4 - GPL KfV	BOSCH ABS 8.1 AUTODETECT
 Berlingo 2	ABS + TRACT. CONT	1.4 - GPL KfV	BOSCH ABS/ESP 5.7
 Berlingo 2	ABS + TRACT. CONT	1.4 - GPL KfV	BOSCH ESP 5.7 AUTODETECT
 Berlingo 2	ABS + TRACT. CONT	1.4 - GPL KfV	BOSCH ESP 8.0 AUTODETECT
 Berlingo 2	ABS + TRACT. CONT	1.4 - GPL KfV	BOSCH ESP 8.1 AUTODETECT
 Berlingo 2	ABS + TRACT. CONT	1.4 - GPL KfV	BOSCH ABS 8.1 AUTODETECT
 Berlingo 2	ABS + TRACT. CONT	1.4 - GPL KfV	BOSCH ABS/ESP 5.7
 Berlingo 2	ABS + TRACT. CONT	1.4 - GPL KfV	BOSCH ABS8.0 no ESP AUTODETECT
 Berlingo 2	ABS + TRACT. CONT	1.4 - GPL KfV	BOSCH ESP 5.7 AUTODETECT
 Berlingo 2	ABS + TRACT. CONT	1.4 - GPL KfV	BOSCH ESP 8.0 AUTODETECT
 Berlingo 2	ABS + TRACT. CONT	1.4 - GPL KfV	BOSCH ESP 8.1 AUTODETECT
 Berlingo 2	ABS + TRACT. CONT	1.4 KfV	BOSCH ABS 8.0 no ESP AUTODETECT
 Berlingo 2	ABS + TRACT. CONT	1.4 KfV	BOSCH ABS 8.1 AUTODETECT
 Berlingo 2	ABS + TRACT. CONT	1.4 KfV	BOSCH ESP 5.7 AUTODETECT
 Berlingo 2	ABS + TRACT. CONT	1.4 KfV	BOSCH ESP 8.0 AUTODETECT
 Berlingo 2	ABS + TRACT. CONT	1.4 KfV	BOSCH ESP 8.1 AUTODETECT
 Berlingo 2	ABS + TRACT. CONT	1.4 KfV	BOSCH ABS 8.0 no ESP AUTODETECT
 Berlingo 2	ABS + TRACT. CONT	1.4 KfV	BOSCH ABS 8.1 AUTODETECT
 Berlingo 2	ABS + TRACT. CONT	1.4 KfV	BOSCH ABS/ESP 5.7
 Berlingo 2	ABS + TRACT. CONT	1.4 KfV	BOSCH ESP 5.7 AUTODETECT

## Systems supported by ECUreader (up to V5.40)

### TRUCKS

Citroen

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Berlingo 2	ABS + TRACT. CONT	1.4 KFW	BOSCH ESP 8.0 AUTODETECT
 Berlingo 2	ABS + TRACT. CONT	1.4 KFW	BOSCH ESP 8.1 AUTODETECT
 Berlingo 2	ABS + TRACT. CONT	1.6 16v NFU	BOSCH ABS 8.0 no ESP AUTODETECT
 Berlingo 2	ABS + TRACT. CONT	1.6 16v NFU	BOSCH ABS 8.1 AUTODETECT
 Berlingo 2	ABS + TRACT. CONT	1.6 16v NFU	BOSCH ABS/ESP 5.7
 Berlingo 2	ABS + TRACT. CONT	1.6 16v NFU	BOSCH ESP 5.7 AUTODETECT
 Berlingo 2	ABS + TRACT. CONT	1.6 16v NFU	BOSCH ESP 8.0 AUTODETECT
 Berlingo 2	ABS + TRACT. CONT	1.6 16v NFU	BOSCH ESP 8.1 AUTODETECT
 Berlingo 2	ABS + TRACT. CONT	1.6 HDI 9HW	BOSCH ABS 8.0 no ESP AUTODETECT
 Berlingo 2	ABS + TRACT. CONT	1.6 HDI 9HW	BOSCH ABS 8.1 AUTODETECT
 Berlingo 2	ABS + TRACT. CONT	1.6 HDI 9HW	BOSCH ABS/ESP 5.7
 Berlingo 2	ABS + TRACT. CONT	1.6 HDI 9HW	BOSCH ESP 5.7 AUTODETECT
 Berlingo 2	ABS + TRACT. CONT	1.6 HDI 9HW	BOSCH ESP 8.0 AUTODETECT
 Berlingo 2	ABS + TRACT. CONT	1.6 HDI 9HW	BOSCH ESP 8.1 AUTODETECT
 Berlingo 2	ABS + TRACT. CONT	1.6 HDI 9HX	BOSCH ABS 8.0 no ESP AUTODETECT
 Berlingo 2	ABS + TRACT. CONT	1.6 HDI 9HX	BOSCH ABS 8.1 AUTODETECT
 Berlingo 2	ABS + TRACT. CONT	1.6 HDI 9HX	BOSCH ABS/ESP 5.7
 Berlingo 2	ABS + TRACT. CONT	1.6 HDI 9HX	BOSCH ESP 5.7 AUTODETECT
 Berlingo 2	ABS + TRACT. CONT	1.6 HDI 9HX	BOSCH ESP 8.0 AUTODETECT
 Berlingo 2	ABS + TRACT. CONT	1.6 HDI 9HX	BOSCH ESP 8.1 AUTODETECT
 Berlingo 2	ABS + TRACT. CONT	1.6 N6A	BOSCH ABS 8.0 no ESP AUTODETECT
 Berlingo 2	ABS + TRACT. CONT	1.6 N6A	BOSCH ABS 8.1 AUTODETECT
 Berlingo 2	ABS + TRACT. CONT	1.6 N6A	BOSCH ESP 5.7 AUTODETECT
 Berlingo 2	ABS + TRACT. CONT	1.6 N6A	BOSCH ESP 8.0 AUTODETECT
 Berlingo 2	ABS + TRACT. CONT	1.6 N6A	BOSCH ESP 8.1 AUTODETECT
 Berlingo 2	ABS + TRACT. CONT	1.9 D WJY	BOSCH ABS 8.0 AUTODETECT
 Berlingo 2	ABS + TRACT. CONT	1.9 D WJY	BOSCH ABS BOSCH 8.1 AUTODETECT

## Systems supported by ECReader (up to V5.40)

### TRUCKS


























Citroen

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Berlingo 2	ABS + TRACT. CONT	1.9 D WJY	BOSCH ABS/ESP 5.7
 Berlingo 2	ABS + TRACT. CONT	1.9 D WJY	BOSCH ESP 5.7 AUTODETECT
 Berlingo 2	ABS + TRACT. CONT	1.9 D WJY	BOSCH ESP 8.0 AUTODETECT
 Berlingo 2	ABS + TRACT. CONT	1.9 D WJY	BOSCH ESP 8.1 AUTODETECT
 Berlingo 2	ABS + TRACT. CONT	2.0 HDI RHT	BOSCH ABS 8.0 no ESP AUTODETECT
 Berlingo 2	ABS + TRACT. CONT	2.0 HDI RHT	BOSCH ABS 8.1 AUTODETECT
 Berlingo 2	ABS + TRACT. CONT	2.0 HDI RHT	BOSCH ABS/ESP 5.7
 Berlingo 2	ABS + TRACT. CONT	2.0 HDI RHT	BOSCH ESP 5.7 AUTODETECT
 Berlingo 2	ABS + TRACT. CONT	2.0 HDI RHT	BOSCH ESP 8.0 AUTODETECT
 Berlingo 2	ABS + TRACT. CONT	2.0 HDI RHT	BOSCH ESP 8.1 AUTODETECT
 Berlingo 2	ABS + TRACT. CONT	2.0 HDI RHY	BOSCH ABS 8.0 no ESP AUTODETECT
 Berlingo 2	ABS + TRACT. CONT	2.0 HDI RHY	BOSCH ABS 8.1 AUTODETECT
 Berlingo 2	ABS + TRACT. CONT	2.0 HDI RHY	BOSCH ABS/ESP 5.7
 Berlingo 2	ABS + TRACT. CONT	2.0 HDI RHY	BOSCH ESP 5.7 AUTODETECT
 Berlingo 2	ABS + TRACT. CONT	2.0 HDI RHY	BOSCH ESP 8.0 AUTODETECT
 Berlingo 2	ABS + TRACT. CONT	2.0 HDI RHY	BOSCH ESP 8.1 AUTODETECT
 Berlingo 2	AIRBAG	1.1 HFX	Temic AirBag CENTRAL AUTODETECT
 Berlingo 2	AIRBAG	1.4 - GPL KfV	Temic AirBag CENTRAL AUTODETECT
 Berlingo 2	AIRBAG	1.4 - GPL KfW	Temic AirBag CENTRAL AUTODETECT
 Berlingo 2	AIRBAG	1.4 KfV	Temic AirBag CENTRAL AUTODETECT
 Berlingo 2	AIRBAG	1.4 KfW	Temic AirBag CENTRAL AUTODETECT
 Berlingo 2	AIRBAG	1.6 16v NFU	Temic AirBag CENTRAL AUTODETECT
 Berlingo 2	AIRBAG	1.6 HDI 9HW	Temic AirBag CENTRAL AUTODETECT
 Berlingo 2	AIRBAG	1.6 HDI 9HX	Temic AirBag CENTRAL AUTODETECT
 Berlingo 2	AIRBAG	1.6 N6A	Temic AirBag CENTRAL AUTODETECT
 Berlingo 2	AIRBAG	1.9 D WJY	Temic AirBag CENTRAL AUTODETECT
 Berlingo 2	AIRBAG	2.0 HDI RHT	Temic AirBag CENTRAL AUTODETECT

## Systems supported by ECReader (up to V5.40)

### TRUCKS




























Citroen

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Berlingo 2	AIRBAG	2.0 HDI RHY	Temic AirBag CENTRAL AUTODETECT
 Berlingo 2	ANTITHEFT	1.1 HFX	Alarm PSA2 AUTODETECT
 Berlingo 2	ANTITHEFT	1.4 - GPL KFV	Alarm PSA2 AUTODETECT
 Berlingo 2	ANTITHEFT	1.4 - GPL KFW	Alarm PSA2 AUTODETECT
 Berlingo 2	ANTITHEFT	1.4 KFW	Alarm PSA2 AUTODETECT
 Berlingo 2	ANTITHEFT	1.4 KFW	Alarm PSA2 AUTODETECT
 Berlingo 2	ANTITHEFT	1.6 16v NFU	Alarm PSA2 AUTODETECT
 Berlingo 2	ANTITHEFT	1.6 HDI 9HW	Alarm PSA2 AUTODETECT
 Berlingo 2	ANTITHEFT	1.6 HDI 9HX	Alarm PSA2 AUTODETECT
 Berlingo 2	ANTITHEFT	1.6 N6A	Alarm PSA2 AUTODETECT
 Berlingo 2	ANTITHEFT	1.9 D WJY	Alarm PSA2 AUTODETECT
 Berlingo 2	ANTITHEFT	2.0 HDI RHT	Alarm PSA2 AUTODETECT
 Berlingo 2	ANTITHEFT	2.0 HDI RHY	Alarm PSA2 AUTODETECT
 Berlingo 2	CHASSIS NETWORK	1.1 HFX	Body Computer BSI AUTODETECT
 Berlingo 2	CHASSIS NETWORK	1.4 - GPL KFV	Body Computer BSI AUTODETECT
 Berlingo 2	CHASSIS NETWORK	1.4 - GPL KFW	Body Computer BSI AUTODETECT
 Berlingo 2	CHASSIS NETWORK	1.4 KFW	Body Computer BSI AUTODETECT
 Berlingo 2	CHASSIS NETWORK	1.4 KFW	Body Computer BSI AUTODETECT
 Berlingo 2	CHASSIS NETWORK	1.6 16v NFU	Body Computer BSI AUTODETECT
 Berlingo 2	CHASSIS NETWORK	1.6 HDI 9HW	Body Computer BSI AUTODETECT
 Berlingo 2	CHASSIS NETWORK	1.6 HDI 9HX	Body Computer BSI AUTODETECT
 Berlingo 2	CHASSIS NETWORK	1.6 N6A	Body Computer BSI AUTODETECT
 Berlingo 2	CHASSIS NETWORK	1.9 D WJY	Body Computer BSI AUTODETECT
 Berlingo 2	CHASSIS NETWORK	2.0 HDI RHT	Body Computer BSI AUTODETECT
 Berlingo 2	CHASSIS NETWORK	2.0 HDI RHY	Body Computer BSI AUTODETECT
 Berlingo 2	DASHBOARD	1.1 HFX	AUTODETECT
 Berlingo 2	DASHBOARD	1.4 - GPL KFW	AUTODETECT

## Systems supported by ECReader (up to V5.40)

### TRUCKS




























Citroen

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Berlingo 2	DASHBOARD	1.4 - GPL KFW	AUTODETECT
 Berlingo 2	DASHBOARD	1.4 KFV	AUTODETECT
 Berlingo 2	DASHBOARD	1.4 KFW	AUTODETECT
 Berlingo 2	DASHBOARD	1.6 16v NFU	AUTODETECT
 Berlingo 2	DASHBOARD	1.6 HDI 9HW	AUTODETECT
 Berlingo 2	DASHBOARD	1.6 HDI 9HX	AUTODETECT
 Berlingo 2	DASHBOARD	1.6 N6A	AUTODETECT
 Berlingo 2	DASHBOARD	1.9 D WJY	AUTODETECT
 Berlingo 2	DASHBOARD	2.0 HDI RHT	AUTODETECT
 Berlingo 2	DASHBOARD	2.0 HDI RHY	AUTODETECT
 Berlingo 2	DIESEL MANAGEMEN	1.9 D WJY	LUCAS DCN2 AUTODETECT
 Berlingo 2	ENGINE MANAGEME	1.1 HFX	JCAE SAX500 GNV AUTODETECT
 Berlingo 2	ENGINE MANAGEME	1.1 HFX	MARELLI MM48P AUTODETECT
 Berlingo 2	ENGINE MANAGEME	1.4 - GPL KFV	JCAE SAX500 GPL AUTODETECT
 Berlingo 2	ENGINE MANAGEME	1.4 - GPL KFW	JCAE SAX500 GPL AUTODETECT
 Berlingo 2	ENGINE MANAGEME	1.4 KFV	SAGEM J34P AUTODETECT
 Berlingo 2	ENGINE MANAGEME	1.4 KFV	SAGEM S2000 PM1 AUTODETECT
 Berlingo 2	ENGINE MANAGEME	1.4 KFV	SAGEM S2000 PM2 AUTODETECT
 Berlingo 2	ENGINE MANAGEME	1.4 KFW	SAGEM S2000
 Berlingo 2	ENGINE MANAGEME	1.4 KFW	SAGEM S2000 PM1 AUTODETECT
 Berlingo 2	ENGINE MANAGEME	1.4 KFW	SAGEM S2000 PM2 AUTODETECT
 Berlingo 2	ENGINE MANAGEME	1.6 16v NFU	BOSCH ME 7.4.4 AUTODETECT
 Berlingo 2	ENGINE MANAGEME	1.6 16v NFU	BOSCH ME 7.4.5 AUTODETECT
 Berlingo 2	ENGINE MANAGEME	1.6 16v NFU	BOSCH Motronic ME7.4.4
 Berlingo 2	ENGINE MANAGEME	1.6 HDI 9HW	BOSCH EDC16 C34 Common Rail AUTOD
 Berlingo 2	ENGINE MANAGEME	1.6 HDI 9HX	BOSCH EDC16 C34 Common Rail AUTOD
 Berlingo 2	ENGINE MANAGEME	1.6 N6A	BOSCH ME 7.4.5 AUTODETECT

## Systems supported by ECUREADER (up to V5.40)

### TRUCKS

Citroen

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Berlingo 2	ENGINE MANAGEME	2.0 HDI RHT	BOSCH EDC 15 C2 Common Rail
 Berlingo 2	ENGINE MANAGEME	2.0 HDI RHY	BOSCH EDC 15 C2 Common Rail
 Berlingo 2	ENGINE MANAGEME	2.0 HDI RHY	SIEMENS Diesel SID 801 Common Rail
 Berlingo 2	ENGINE MANAGEME	2.0 HDI RHY	SIEMENS SID 801 Common rail AUTODET
 Berlingo 2	KEY ENCODE	1.1 HFX	VALEO Body Siemens
 Berlingo 2	KEY ENCODE	1.4 - GPL KfV	VALEO Body Siemens
 Berlingo 2	KEY ENCODE	1.4 - GPL KfW	VALEO Body Siemens
 Berlingo 2	KEY ENCODE	1.4 KfW	VALEO Body Siemens
 Berlingo 2	KEY ENCODE	1.6 16v NFU	VALEO Body Siemens
 Berlingo 2	KEY ENCODE	1.6 HDI 9HW	VALEO Body Siemens
 Berlingo 2	KEY ENCODE	1.6 HDI 9HX	VALEO Body Siemens
 Berlingo 2	KEY ENCODE	1.9 D WJY	VALEO Body Siemens
 Berlingo 2	KEY ENCODE	2.0 HDI RHT	VALEO Body Siemens
 Berlingo 2	KEY ENCODE	2.0 HDI RHY	VALEO Body Siemens
 Berlingo 2	PARK.BRAKE	1.1 HFX	AUTODETECT
 Berlingo 2	PARK.BRAKE	1.4 - GPL KfV	AUTODETECT
 Berlingo 2	PARK.BRAKE	1.4 - GPL KfW	AUTODETECT
 Berlingo 2	PARK.BRAKE	1.4 KfV	AUTODETECT
 Berlingo 2	PARK.BRAKE	1.4 KfW	AUTODETECT
 Berlingo 2	PARK.BRAKE	1.6 16v NFU	AUTODETECT
 Berlingo 2	PARK.BRAKE	1.6 HDI 9HW	AUTODETECT
 Berlingo 2	PARK.BRAKE	1.6 HDI 9HX	AUTODETECT
 Berlingo 2	PARK.BRAKE	1.6 N6A	AUTODETECT
 Berlingo 2	PARK.BRAKE	1.9 D WJY	AUTODETECT
 Berlingo 2	PARK.BRAKE	2.0 HDI RHT	AUTODETECT
 Berlingo 2	PARK.BRAKE	2.0 HDI RHY	AUTODETECT
 Berlingo 2	RADIO / CD	1.1 HFX	AudioSystem AUTODETECT

## Systems supported by ECReader (up to V5.40)

### TRUCKS


Citroen

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Berlingo 2	RADIO / CD	1.1 HFX	CD Changer AUTODETECT
 Berlingo 2	RADIO / CD	1.1 HFX	CLARION AudioSystem
 Berlingo 2	RADIO / CD	1.1 HFX	PHILIPS AudioSystem
 Berlingo 2	RADIO / CD	1.1 HFX	VDO AudioSystem
 Berlingo 2	RADIO / CD	1.4 - GPL KFV	AudioSystem AUTODETECT
 Berlingo 2	RADIO / CD	1.4 - GPL KFV	CD Changer AUTODETECT
 Berlingo 2	RADIO / CD	1.4 - GPL KFV	CLARION AudioSystem
 Berlingo 2	RADIO / CD	1.4 - GPL KFV	PHILIPS AudioSystem
 Berlingo 2	RADIO / CD	1.4 - GPL KFV	VDO AudioSystem
 Berlingo 2	RADIO / CD	1.4 - GPL KFW	AudioSystem AUTODETECT
 Berlingo 2	RADIO / CD	1.4 - GPL KFW	CD Changer AUTODETECT
 Berlingo 2	RADIO / CD	1.4 - GPL KFW	CLARION AudioSystem
 Berlingo 2	RADIO / CD	1.4 - GPL KFW	PHILIPS AudioSystem
 Berlingo 2	RADIO / CD	1.4 - GPL KFW	VDO AudioSystem
 Berlingo 2	RADIO / CD	1.4 KFV	AudioSystem AUTODETECT
 Berlingo 2	RADIO / CD	1.4 KFV	CD Changer AUTODETECT
 Berlingo 2	RADIO / CD	1.4 KFW	AudioSystem AUTODETECT
 Berlingo 2	RADIO / CD	1.4 KFW	CD Changer AUTODETECT
 Berlingo 2	RADIO / CD	1.4 KFW	CLARION AudioSystem
 Berlingo 2	RADIO / CD	1.4 KFW	PHILIPS AudioSystem
 Berlingo 2	RADIO / CD	1.4 KFW	VDO AudioSystem
 Berlingo 2	RADIO / CD	1.6 16v NFU	AudioSystem AUTODETECT
 Berlingo 2	RADIO / CD	1.6 16v NFU	CD Changer AUTODETECT
 Berlingo 2	RADIO / CD	1.6 16v NFU	CLARION AudioSystem
 Berlingo 2	RADIO / CD	1.6 16v NFU	PHILIPS AudioSystem
 Berlingo 2	RADIO / CD	1.6 16v NFU	VDO AudioSystem
 Berlingo 2	RADIO / CD	1.6 HDI 9HW	AudioSystem AUTODETECT

## Systems supported by ECUREADER (up to V5.40)

### TRUCKS
























Citroen

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Berlingo 2	RADIO / CD	1.6 HDI 9HW	CD Changer AUTODETECT
 Berlingo 2	RADIO / CD	1.6 HDI 9HW	CLARION AudioSystem
 Berlingo 2	RADIO / CD	1.6 HDI 9HW	PHILIPS AudioSystem
 Berlingo 2	RADIO / CD	1.6 HDI 9HW	VDO AudioSystem
 Berlingo 2	RADIO / CD	1.6 HDI 9HX	AudioSystem AUTODETECT
 Berlingo 2	RADIO / CD	1.6 HDI 9HX	CD Changer AUTODETECT
 Berlingo 2	RADIO / CD	1.6 HDI 9HX	CLARION AudioSystem
 Berlingo 2	RADIO / CD	1.6 HDI 9HX	PHILIPS AudioSystem
 Berlingo 2	RADIO / CD	1.6 HDI 9HX	VDO AudioSystem
 Berlingo 2	RADIO / CD	1.6 N6A	AudioSystem AUTODETECT
 Berlingo 2	RADIO / CD	1.6 N6A	CD Changer AUTODETECT
 Berlingo 2	RADIO / CD	1.9 D WJY	AudioSystem AUTODETECT
 Berlingo 2	RADIO / CD	1.9 D WJY	CD Changer AUTODETECT
 Berlingo 2	RADIO / CD	1.9 D WJY	CLARION AudioSystem
 Berlingo 2	RADIO / CD	1.9 D WJY	PHILIPS AudioSystem
 Berlingo 2	RADIO / CD	1.9 D WJY	VDO AudioSystem
 Berlingo 2	RADIO / CD	2.0 HDI RHT	AudioSystem AUTODETECT
 Berlingo 2	RADIO / CD	2.0 HDI RHT	Cd Changer AUTODETECT
 Berlingo 2	RADIO / CD	2.0 HDI RHT	CLARION AudioSystem
 Berlingo 2	RADIO / CD	2.0 HDI RHT	PHILIPS AudioSystem
 Berlingo 2	RADIO / CD	2.0 HDI RHT	VDO AudioSystem
 Berlingo 2	RADIO / CD	2.0 HDI RHY	AudioSystem AUTODETECT
 Berlingo 2	RADIO / CD	2.0 HDI RHY	Cd Changer AUTODETECT
 Berlingo 2	RADIO / CD	2.0 HDI RHY	CLARION AudioSystem
 Berlingo 2	RADIO / CD	2.0 HDI RHY	PHILIPS AudioSystem
 Berlingo 2	RADIO / CD	2.0 HDI RHY	VDO AudioSystem
 Berlingo 2	RAIN-LUMINOSITY SE	1.1 HFX	AUTODETECT

## Systems supported by ECReader (up to V5.40)

### TRUCKS



Citroen

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Berlingo 2	RAIN-LUMINOSITY SE	1.4 - GPL KfV	AUTODETECT
 Berlingo 2	RAIN-LUMINOSITY SE	1.4 - GPL KfW	AUTODETECT
 Berlingo 2	RAIN-LUMINOSITY SE	1.4 KfV	AUTODETECT
 Berlingo 2	RAIN-LUMINOSITY SE	1.4 KfW	AUTODETECT
 Berlingo 2	RAIN-LUMINOSITY SE	1.6 16v NFU	AUTODETECT
 Berlingo 2	RAIN-LUMINOSITY SE	1.6 HDI 9HW	AUTODETECT
 Berlingo 2	RAIN-LUMINOSITY SE	1.6 HDI 9HX	AUTODETECT
 Berlingo 2	RAIN-LUMINOSITY SE	1.6 N6A	AUTODETECT
 Berlingo 2	RAIN-LUMINOSITY SE	1.9 D WJY	AUTODETECT
 Berlingo 2	RAIN-LUMINOSITY SE	2.0 HDI RHY	AUTODETECT
 Berlingo 2	STEERING COLUMN	1.1 HFX	AUTODETECT
 Berlingo 2	STEERING COLUMN	1.4 - GPL KfV	AUTODETECT
 Berlingo 2	STEERING COLUMN	1.4 - GPL KfW	AUTODETECT
 Berlingo 2	STEERING COLUMN	1.4 KfV	AUTODETECT
 Berlingo 2	STEERING COLUMN	1.4 KfW	AUTODETECT
 Berlingo 2	STEERING COLUMN	1.6 16v NFU	AUTODETECT
 Berlingo 2	STEERING COLUMN	1.6 HDI 9HW	AUTODETECT
 Berlingo 2	STEERING COLUMN	1.6 HDI 9HX	AUTODETECT
 Berlingo 2	STEERING COLUMN	1.6 N6A	AUTODETECT
 Berlingo 2	STEERING COLUMN	1.9 D WJY	AUTODETECT
 Berlingo 2	STEERING COLUMN	2.0 HDI RHT	AUTODETECT
 Berlingo 2	STEERING COLUMN	2.0 HDI RHY	AUTODETECT
 Berlingo 2	VISUAL./TELEMATICS	1.1 HFX	AUTODETECT
 Berlingo 2	VISUAL./TELEMATICS	1.1 HFX	Display AUTODETECT
 Berlingo 2	VISUAL./TELEMATICS	1.1 HFX	SAGEM JCAE
 Berlingo 2	VISUAL./TELEMATICS	1.4 - GPL KfV	AUTODETECT
 Berlingo 2	VISUAL./TELEMATICS	1.4 - GPL KfV	Display AUTODETECT

## Systems supported by ECUREADER (up to V5.40)

### TRUCKS



























Citroen

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Berlingo 2	VISUAL./TELEMATICS	1.4 - GPL KfV	SAGEM JCAE
 Berlingo 2	VISUAL./TELEMATICS	1.4 - GPL KfW	AUTODETECT
 Berlingo 2	VISUAL./TELEMATICS	1.4 - GPL KfW	Display AUTODETECT
 Berlingo 2	VISUAL./TELEMATICS	1.4 - GPL KfW	SAGEM JCAE
 Berlingo 2	VISUAL./TELEMATICS	1.4 KfV	AUTODETECT
 Berlingo 2	VISUAL./TELEMATICS	1.4 KfV	Display AUTODETECT
 Berlingo 2	VISUAL./TELEMATICS	1.4 KfW	AUTODETECT
 Berlingo 2	VISUAL./TELEMATICS	1.4 KfW	Display AUTODETECT
 Berlingo 2	VISUAL./TELEMATICS	1.4 KfW	SAGEM JCAE
 Berlingo 2	VISUAL./TELEMATICS	1.6 16v NFU	AUTODETECT
 Berlingo 2	VISUAL./TELEMATICS	1.6 16v NFU	Display AUTODETECT
 Berlingo 2	VISUAL./TELEMATICS	1.6 16v NFU	SAGEM JCAE
 Berlingo 2	VISUAL./TELEMATICS	1.6 HDI 9HW	AUTODETECT
 Berlingo 2	VISUAL./TELEMATICS	1.6 HDI 9HW	Display AUTODETECT
 Berlingo 2	VISUAL./TELEMATICS	1.6 HDI 9HW	SAGEM JCAE
 Berlingo 2	VISUAL./TELEMATICS	1.6 HDI 9HX	AUTODETECT
 Berlingo 2	VISUAL./TELEMATICS	1.6 HDI 9HX	Display AUTODETECT
 Berlingo 2	VISUAL./TELEMATICS	1.6 HDI 9HX	SAGEM JCAE
 Berlingo 2	VISUAL./TELEMATICS	1.6 N6A	AUTODETECT
 Berlingo 2	VISUAL./TELEMATICS	1.6 N6A	Display AUTODETECT
 Berlingo 2	VISUAL./TELEMATICS	1.9 D WJY	AUTODETECT
 Berlingo 2	VISUAL./TELEMATICS	1.9 D WJY	Display AUTODETECT
 Berlingo 2	VISUAL./TELEMATICS	1.9 D WJY	SAGEM JCAE
 Berlingo 2	VISUAL./TELEMATICS	2.0 HDI RHT	AUTODETECT
 Berlingo 2	VISUAL./TELEMATICS	2.0 HDI RHT	Display AUTODETECT
 Berlingo 2	VISUAL./TELEMATICS	2.0 HDI RHT	SAGEM JCAE
 Berlingo 2	VISUAL./TELEMATICS	2.0 HDI RHY	AUTODETECT

## Systems supported by ECReader (up to V5.40)

### TRUCKS

Citroen

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Berlingo 2	VISUAL./TELEMATICS	2.0 HDI RHY	Display AUTODETECT
 Berlingo 2	VISUAL./TELEMATICS	2.0 HDI RHY	SAGEM JCAE
 Berlingo B9	ABS	1.6 16v 110cv NFU	BOSCH ABS 8.1
 Berlingo B9	ABS	1.6 16v 90cv NFR	BOSCH ABS 8.1
 Berlingo B9	ABS	1.6 HDI 16v 110cv FAP 9HZ	BOSCH ABS 8.1
 Berlingo B9	ABS	1.6 HDI 16v 75cv 9HT	BOSCH ABS 8.1
 Berlingo B9	ABS	1.6 HDI 16v 90cv 9HX	BOSCH ABS 8.1
 Berlingo B9	ABS	1.6 HDI 16v 90cv FAP 9HS	BOSCH ABS 8.1
 Berlingo B9	ABS	1.6 HDI 16v 90cv FAP 9HV	BOSCH ABS 8.1
 Berlingo B9	ABS + TRACT. CONT	1.6 16v 110cv NFU	BOSCH ABS 8.1 AUTODETECT
 Berlingo B9	ABS + TRACT. CONT	1.6 16v 110cv NFU	BOSCH ESP 8.1 AUTODETECT
 Berlingo B9	ABS + TRACT. CONT	1.6 16v 90cv NFR	BOSCH ABS 8.1 AUTODETECT
 Berlingo B9	ABS + TRACT. CONT	1.6 16v 90cv NFR	BOSCH ESP 8.1 AUTODETECT
 Berlingo B9	ABS + TRACT. CONT	1.6 HDI 16v 110cv FAP 9HZ	BOSCH ABS 8.1 AUTODETECT
 Berlingo B9	ABS + TRACT. CONT	1.6 HDI 16v 110cv FAP 9HZ	BOSCH ESP 8.1 AUTODETECT
 Berlingo B9	ABS + TRACT. CONT	1.6 HDI 16v 75cv 9HT	BOSCH ABS 8.1 AUTODETECT
 Berlingo B9	ABS + TRACT. CONT	1.6 HDI 16v 75cv 9HT	BOSCH ESP 8.1 AUTODETECT
 Berlingo B9	ABS + TRACT. CONT	1.6 HDI 16v 90cv 9HX	BOSCH ABS 8.1 AUTODETECT
 Berlingo B9	ABS + TRACT. CONT	1.6 HDI 16v 90cv 9HX	BOSCH ESP 8.1 AUTODETECT
 Berlingo B9	ABS + TRACT. CONT	1.6 HDI 16v 90cv FAP 9HS	BOSCH ABS 8.1 AUTODETECT
 Berlingo B9	ABS + TRACT. CONT	1.6 HDI 16v 90cv FAP 9HS	BOSCH ESP 8.1 AUTODETECT
 Berlingo B9	ABS + TRACT. CONT	1.6 HDI 16v 90cv FAP 9HV	BOSCH ABS 8.1 AUTODETECT
 Berlingo B9	ABS + TRACT. CONT	1.6 HDI 16v 90cv FAP 9HV	BOSCH ESP 8.1 AUTODETECT
 Berlingo B9	AIRBAG	1.6 16v 110cv NFU	AirBag AUTODETECT
 Berlingo B9	AIRBAG	1.6 16v 110cv NFU	AirBag CENTRAL AUTODETECT
 Berlingo B9	AIRBAG	1.6 16v 110cv NFU	Autoliv AirBag

## Systems supported by ECUreader (up to V5.40)

### TRUCKS








Citroen

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Berlingo B9	AIRBAG	1.6 16v 90cv NFR	AirBag AUTODETECT
 Berlingo B9	AIRBAG	1.6 16v 90cv NFR	AirBag CENTRAL AUTODETECT
 Berlingo B9	AIRBAG	1.6 16v 90cv NFR	Autoliv AirBag
 Berlingo B9	AIRBAG	1.6 HDI 16v 110cv FAP 9HZ	AirBag AUTODETECT
 Berlingo B9	AIRBAG	1.6 HDI 16v 110cv FAP 9HZ	AirBag CENTRAL AUTODETECT
 Berlingo B9	AIRBAG	1.6 HDI 16v 110cv FAP 9HZ	Autoliv AirBag
 Berlingo B9	AIRBAG	1.6 HDI 16v 75cv 9HT	AirBag AUTODETECT
 Berlingo B9	AIRBAG	1.6 HDI 16v 75cv 9HT	AirBag CENTRAL AUTODETECT
 Berlingo B9	AIRBAG	1.6 HDI 16v 75cv 9HT	Autoliv AirBag
 Berlingo B9	AIRBAG	1.6 HDI 16v 90cv 9HX	AirBag AUTODETECT
 Berlingo B9	AIRBAG	1.6 HDI 16v 90cv 9HX	AirBag CENTRAL AUTODETECT
 Berlingo B9	AIRBAG	1.6 HDI 16v 90cv 9HX	Autoliv AirBag
 Berlingo B9	AIRBAG	1.6 HDI 16v 90cv FAP 9HS	AirBag AUTODETECT
 Berlingo B9	AIRBAG	1.6 HDI 16v 90cv FAP 9HS	AirBag CENTRAL AUTODETECT
 Berlingo B9	AIRBAG	1.6 HDI 16v 90cv FAP 9HS	Autoliv AirBag
 Berlingo B9	AIRBAG	1.6 HDI 16v 90cv FAP 9HV	AIRBAG AUTODETECT
 Berlingo B9	AIRBAG	1.6 HDI 16v 90cv FAP 9HV	AirBag CENTRAL AUTODETECT
 Berlingo B9	AIRBAG	1.6 HDI 16v 90cv FAP 9HV	Autoliv AirBag
 Berlingo B9	ANTITHEFT	1.6 16v 110cv NFU	Alarm PSA2 AUTODETECT
 Berlingo B9	ANTITHEFT	1.6 16v 90cv NFR	Alarm PSA2 AUTODETECT
 Berlingo B9	ANTITHEFT	1.6 HDI 16v 110cv FAP 9HZ	Alarm PSA2 AUTODETECT
 Berlingo B9	ANTITHEFT	1.6 HDI 16v 75cv 9HT	Alarm PSA2 AUTODETECT
 Berlingo B9	ANTITHEFT	1.6 HDI 16v 90cv 9HX	Alarm PSA2 AUTODETECT
 Berlingo B9	ANTITHEFT	1.6 HDI 16v 90cv FAP 9HS	Alarm PSA2 AUTODETECT
 Berlingo B9	ANTITHEFT	1.6 HDI 16v 90cv FAP 9HV	Alarm PSA2 AUTODETECT
 Berlingo B9	CHASSIS NETWORK	1.6 16v 110cv NFU	Body Computer BSI AUTODETECT
 Berlingo B9	CHASSIS NETWORK	1.6 16v 110cv NFU	Body Computer BSM AUTODETECT

## Systems supported by ECReader (up to V5.40)

### TRUCKS




Citroen

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Berlingo B9	CHASSIS NETWORK	1.6 16v 110cv NFU	Body Computer BSR AUTODETECT
 Berlingo B9	CHASSIS NETWORK	1.6 16v 110cv NFU	Body Computer chassis AUTODETECT
 Berlingo B9	CHASSIS NETWORK	1.6 16v 110cv NFU	Delphi BSM
 Berlingo B9	CHASSIS NETWORK	1.6 16v 110cv NFU	JCAE BSI 5.20
 Berlingo B9	CHASSIS NETWORK	1.6 16v 90cv NFR	Body Computer BSI AUTODETECT
 Berlingo B9	CHASSIS NETWORK	1.6 16v 90cv NFR	Body Computer BSM AUTODETECT
 Berlingo B9	CHASSIS NETWORK	1.6 16v 90cv NFR	Body Computer BSR AUTODETECT
 Berlingo B9	CHASSIS NETWORK	1.6 16v 90cv NFR	Body Computer Chassis AUTODETECT
 Berlingo B9	CHASSIS NETWORK	1.6 16v 90cv NFR	Delphi BSM
 Berlingo B9	CHASSIS NETWORK	1.6 16v 90cv NFR	JCAE BSI 5.20
 Berlingo B9	CHASSIS NETWORK	1.6 HDI 16v 110cv FAP 9HZ	Body Computer BSI AUTODETECT
 Berlingo B9	CHASSIS NETWORK	1.6 HDI 16v 110cv FAP 9HZ	Body Computer BSM AUTODETECT
 Berlingo B9	CHASSIS NETWORK	1.6 HDI 16v 110cv FAP 9HZ	Body Computer BSR AUTODETECT
 Berlingo B9	CHASSIS NETWORK	1.6 HDI 16v 110cv FAP 9HZ	Body Computer Chassis AUTODETECT
 Berlingo B9	CHASSIS NETWORK	1.6 HDI 16v 110cv FAP 9HZ	Delphi BSM
 Berlingo B9	CHASSIS NETWORK	1.6 HDI 16v 110cv FAP 9HZ	JCAE BSI 5.20
 Berlingo B9	CHASSIS NETWORK	1.6 HDI 16v 75cv 9HT	Body Computer BSI AUTODETECT
 Berlingo B9	CHASSIS NETWORK	1.6 HDI 16v 75cv 9HT	Body Computer BSM AUTODETECT
 Berlingo B9	CHASSIS NETWORK	1.6 HDI 16v 75cv 9HT	Body Computer BSR AUTODETECT
 Berlingo B9	CHASSIS NETWORK	1.6 HDI 16v 75cv 9HT	Body Computer Chassis AUTODETECT
 Berlingo B9	CHASSIS NETWORK	1.6 HDI 16v 75cv 9HT	Delphi BSM
 Berlingo B9	CHASSIS NETWORK	1.6 HDI 16v 75cv 9HT	JCAE BSI 5.20
 Berlingo B9	CHASSIS NETWORK	1.6 HDI 16v 90cv 9HX	Body Computer BSI AUTODETECT
 Berlingo B9	CHASSIS NETWORK	1.6 HDI 16v 90cv 9HX	Body Computer BSM AUTODETECT
 Berlingo B9	CHASSIS NETWORK	1.6 HDI 16v 90cv 9HX	Body Computer BSR AUTODETECT
 Berlingo B9	CHASSIS NETWORK	1.6 HDI 16v 90cv 9HX	Body Computer chassis AUTODETECT
 Berlingo B9	CHASSIS NETWORK	1.6 HDI 16v 90cv 9HX	Delphi BSM

## Systems supported by ECUREADER (up to V5.40)

### TRUCKS



























Citroen

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Berlingo B9	CHASSIS NETWORK	1.6 HDI 16v 90cv 9HX	JCAE BSI 5.20
 Berlingo B9	CHASSIS NETWORK	1.6 HDI 16v 90cv FAP 9HS	Body Computer BSI AUTODETECT
 Berlingo B9	CHASSIS NETWORK	1.6 HDI 16v 90cv FAP 9HS	Body Computer BSM AUTODETECT
 Berlingo B9	CHASSIS NETWORK	1.6 HDI 16v 90cv FAP 9HS	Body Computer BSR AUTODETECT
 Berlingo B9	CHASSIS NETWORK	1.6 HDI 16v 90cv FAP 9HS	Body Computer Chassis AUTODETECT
 Berlingo B9	CHASSIS NETWORK	1.6 HDI 16v 90cv FAP 9HS	Delphi BSM
 Berlingo B9	CHASSIS NETWORK	1.6 HDI 16v 90cv FAP 9HS	JCAE BSI 5.20
 Berlingo B9	CHASSIS NETWORK	1.6 HDI 16v 90cv FAP 9HV	Body Computer BSI AUTODETECT
 Berlingo B9	CHASSIS NETWORK	1.6 HDI 16v 90cv FAP 9HV	Body Computer BSM AUTODETECT
 Berlingo B9	CHASSIS NETWORK	1.6 HDI 16v 90cv FAP 9HV	Body Computer BSR AUTODETECT
 Berlingo B9	CHASSIS NETWORK	1.6 HDI 16v 90cv FAP 9HV	Body Computer Chassis AUTODETECT
 Berlingo B9	CHASSIS NETWORK	1.6 HDI 16v 90cv FAP 9HV	Delphi BSM
 Berlingo B9	CHASSIS NETWORK	1.6 HDI 16v 90cv FAP 9HV	JCAE BSI 5.20
 Berlingo B9	CLIMA	1.6 16v 110cv NFU	CLIMA AUTODETECT
 Berlingo B9	CLIMA	1.6 16v 90cv NFR	CLIMA AUTODETECT
 Berlingo B9	CLIMA	1.6 HDI 16v 110cv FAP 9HZ	CLIMA AUTODETECT
 Berlingo B9	CLIMA	1.6 HDI 16v 75cv 9HT	CLIMA AUTODETECT
 Berlingo B9	CLIMA	1.6 HDI 16v 90cv 9HX	CLIMA AUTODETECT
 Berlingo B9	CLIMA	1.6 HDI 16v 90cv FAP 9HS	CLIMA AUTODETECT
 Berlingo B9	CLIMA	1.6 HDI 16v 90cv FAP 9HV	CLIMA AUTODETECT
 Berlingo B9	DASHBOARD	1.6 16v 110cv NFU	AUTODETECT
 Berlingo B9	DASHBOARD	1.6 16v 110cv NFU	MARELLI
 Berlingo B9	DASHBOARD	1.6 16v 90cv NFR	AUTODETECT
 Berlingo B9	DASHBOARD	1.6 16v 90cv NFR	MARELLI
 Berlingo B9	DASHBOARD	1.6 HDI 16v 110cv FAP 9HZ	AUTODETECT
 Berlingo B9	DASHBOARD	1.6 HDI 16v 110cv FAP 9HZ	MARELLI
 Berlingo B9	DASHBOARD	1.6 HDI 16v 75cv 9HT	AUTODETECT

## Systems supported by ECReader (up to V5.40)

### TRUCKS

Citroen

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Berlingo B9	DASHBOARD	1.6 HDI 16v 75cv 9HT	MARELLI
 Berlingo B9	DASHBOARD	1.6 HDI 16v 90cv 9HX	AUTODETECT
 Berlingo B9	DASHBOARD	1.6 HDI 16v 90cv 9HX	MARELLI
 Berlingo B9	DASHBOARD	1.6 HDI 16v 90cv FAP 9HS	AUTODETECT
 Berlingo B9	DASHBOARD	1.6 HDI 16v 90cv FAP 9HS	MARELLI
 Berlingo B9	DASHBOARD	1.6 HDI 16v 90cv FAP 9HV	AUTODETECT
 Berlingo B9	DASHBOARD	1.6 HDI 16v 90cv FAP 9HV	MARELLI
 Berlingo B9	DIESEL ADDITION	1.6 HDI 16v 110cv FAP 9HZ	AUTODETECT
 Berlingo B9	DIESEL ADDITION	1.6 HDI 16v 90cv FAP 9HS	AUTODETECT
 Berlingo B9	DIESEL ADDITION	1.6 HDI 16v 90cv FAP 9HV	AUTODETECT
 Berlingo B9	ELECTRIC STEERING	1.6 16v 110cv NFU	AUTODETECT
 Berlingo B9	ELECTRIC STEERING	1.6 16v 90cv NFR	AUTODETECT
 Berlingo B9	ELECTRIC STEERING	1.6 HDI 16v 110cv FAP 9HZ	AUTODETECT
 Berlingo B9	ELECTRIC STEERING	1.6 HDI 16v 75cv 9HT	AUTODETECT
 Berlingo B9	ELECTRIC STEERING	1.6 HDI 16v 90cv 9HX	AUTODETECT
 Berlingo B9	ELECTRIC STEERING	1.6 HDI 16v 90cv FAP 9HS	AUTODETECT
 Berlingo B9	ELECTRIC STEERING	1.6 HDI 16v 90cv FAP 9HV	AUTODETECT
 Berlingo B9	ENGINE MANAGEME	1.6 16v 110cv NFU	BOSCH ME 7.4.5 AUTODETECT
 Berlingo B9	ENGINE MANAGEME	1.6 16v 90cv NFR	BOSCH ME 7.4.5 AUTODETECT
 Berlingo B9	ENGINE MANAGEME	1.6 16v 90cv NFR	BOSCH Motronic ME 7.4.5
 Berlingo B9	ENGINE MANAGEME	1.6 HDI 16v 110cv FAP 9HZ	BOSCH EDC16 C34 Common Rail AUTOD
 Berlingo B9	ENGINE MANAGEME	1.6 HDI 16v 75cv 9HT	BOSCH EDC16 C34 Common Rail AUTOD
 Berlingo B9	ENGINE MANAGEME	1.6 HDI 16v 90cv 9HX	BOSCH EDC16 C34 Common Rail AUTOD
 Berlingo B9	ENGINE MANAGEME	1.6 HDI 16v 90cv FAP 9HS	BOSCH EDC16 C34 Common Rail AUTOD
 Berlingo B9	ENGINE MANAGEME	1.6 HDI 16v 90cv FAP 9HV	BOSCH EDC16 C34 Common Rail AUTOD
 Berlingo B9	NAVIGATION	1.6 16v 110cv NFU	AUTODETECT
 Berlingo B9	NAVIGATION	1.6 16v 90cv NFR	AUTODETECT

## Systems supported by ECUREADER (up to V5.40)

### TRUCKS

Citroen

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Berlingo B9	NAVIGATION	1.6 HDI 16v 110cv FAP 9HZ	AUTODETECT
 Berlingo B9	NAVIGATION	1.6 HDI 16v 75cv 9HT	AUTODETECT
 Berlingo B9	NAVIGATION	1.6 HDI 16v 90cv 9HX	AUTODETECT
 Berlingo B9	NAVIGATION	1.6 HDI 16v 90cv FAP 9HS	AUTODETECT
 Berlingo B9	NAVIGATION	1.6 HDI 16v 90cv FAP 9HV	AUTODETECT
 Berlingo B9	PARK.BRAKE	1.6 16v 110cv NFU	AUTODETECT
 Berlingo B9	PARK.BRAKE	1.6 16v 90cv NFR	AUTODETECT
 Berlingo B9	PARK.BRAKE	1.6 HDI 16v 110cv FAP 9HZ	AUTODETECT
 Berlingo B9	PARK.BRAKE	1.6 HDI 16v 75cv 9HT	AUTODETECT
 Berlingo B9	PARK.BRAKE	1.6 HDI 16v 90cv 9HX	AUTODETECT
 Berlingo B9	PARK.BRAKE	1.6 HDI 16v 90cv FAP 9HS	AUTODETECT
 Berlingo B9	PARK.BRAKE	1.6 HDI 16v 90cv FAP 9HV	AUTODETECT
 Berlingo B9	PHONE	1.6 16v 110cv NFU	AUTODETECT
 Berlingo B9	PHONE	1.6 16v 90cv NFR	AUTODETECT
 Berlingo B9	PHONE	1.6 HDI 16v 110cv FAP 9HZ	AUTODETECT
 Berlingo B9	PHONE	1.6 HDI 16v 75cv 9HT	AUTODETECT
 Berlingo B9	PHONE	1.6 HDI 16v 90cv 9HX	AUTODETECT
 Berlingo B9	PHONE	1.6 HDI 16v 90cv FAP 9HS	AUTODETECT
 Berlingo B9	PHONE	1.6 HDI 16v 90cv FAP 9HV	AUTODETECT
 Berlingo B9	RADIO / CD	1.6 16v 110cv NFU	AudioSystem AUTODETECT
 Berlingo B9	RADIO / CD	1.6 16v 110cv NFU	CD Changer AUTODETECT
 Berlingo B9	RADIO / CD	1.6 16v 90cv NFR	AudioSystem AUTODETECT
 Berlingo B9	RADIO / CD	1.6 16v 90cv NFR	CD Changer AUTODETECT
 Berlingo B9	RADIO / CD	1.6 HDI 16v 110cv FAP 9HZ	AudioSystem AUTODETECT
 Berlingo B9	RADIO / CD	1.6 HDI 16v 110cv FAP 9HZ	CD Changer AUTODETECT
 Berlingo B9	RADIO / CD	1.6 HDI 16v 75cv 9HT	AudioSystem AUTODETECT
 Berlingo B9	RADIO / CD	1.6 HDI 16v 75cv 9HT	CD Changer AUTODETECT

## Systems supported by ECUREADER (up to V5.40)

### TRUCKS



Citroen

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Berlingo B9	RADIO / CD	1.6 HDI 16v 90cv 9HX	AudioSystem AUTODETECT
 Berlingo B9	RADIO / CD	1.6 HDI 16v 90cv 9HX	CD Changer AUTODETECT
 Berlingo B9	RADIO / CD	1.6 HDI 16v 90cv FAP 9HS	AudioSystem AUTODETECT
 Berlingo B9	RADIO / CD	1.6 HDI 16v 90cv FAP 9HS	CD Changer AUTODETECT
 Berlingo B9	RADIO / CD	1.6 HDI 16v 90cv FAP 9HV	AudioSystem AUTODETECT
 Berlingo B9	RADIO / CD	1.6 HDI 16v 90cv FAP 9HV	CD Changer AUTODETECT
 Berlingo B9	RAIN-LUMINOSITY SE	1.6 16v 110cv NFU	AUTODETECT
 Berlingo B9	RAIN-LUMINOSITY SE	1.6 16v 90cv NFR	AUTODETECT
 Berlingo B9	RAIN-LUMINOSITY SE	1.6 HDI 16v 110cv FAP 9HZ	AUTODETECT
 Berlingo B9	RAIN-LUMINOSITY SE	1.6 HDI 16v 75cv 9HT	AUTODETECT
 Berlingo B9	RAIN-LUMINOSITY SE	1.6 HDI 16v 90cv 9HX	AUTODETECT
 Berlingo B9	RAIN-LUMINOSITY SE	1.6 HDI 16v 90cv FAP 9HS	AUTODETECT
 Berlingo B9	RAIN-LUMINOSITY SE	1.6 HDI 16v 90cv FAP 9HV	AUTODETECT
 Berlingo B9	SERVICE LIGHT RES	1.6 16v 110cv NFU	MANUAL
 Berlingo B9	SERVICE LIGHT RES	1.6 16v 90cv NFR	MANUAL
 Berlingo B9	SERVICE LIGHT RES	1.6 HDI 16v 110cv FAP 9HZ	MANUAL
 Berlingo B9	SERVICE LIGHT RES	1.6 HDI 16v 75cv 9HT	MANUAL
 Berlingo B9	SERVICE LIGHT RES	1.6 HDI 16v 90cv 9HX	MANUAL
 Berlingo B9	SERVICE LIGHT RES	1.6 HDI 16v 90cv FAP 9HS	MANUAL
 Berlingo B9	SERVICE LIGHT RES	1.6 HDI 16v 90cv FAP 9HV	MANUAL
 Berlingo B9	STEERING COLUMN	1.6 16v 110cv NFU	AUTODETECT
 Berlingo B9	STEERING COLUMN	1.6 16v 90cv NFR	AUTODETECT
 Berlingo B9	STEERING COLUMN	1.6 HDI 16v 110cv FAP 9HZ	AUTODETECT
 Berlingo B9	STEERING COLUMN	1.6 HDI 16v 75cv 9HT	AUTODETECT
 Berlingo B9	STEERING COLUMN	1.6 HDI 16v 90cv 9HX	AUTODETECT
 Berlingo B9	STEERING COLUMN	1.6 HDI 16v 90cv FAP 9HS	AUTODETECT
 Berlingo B9	STEERING COLUMN	1.6 HDI 16v 90cv FAP 9HV	AUTODETECT

## Systems supported by ECUREADER (up to V5.40)

### TRUCKS




























Citroen

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Berlingo B9	SWITCHLIGHT MODU	1.6 16v 110cv NFU	Delphi
 Berlingo B9	SWITCHLIGHT MODU	1.6 16v 90cv NFR	Delphi
 Berlingo B9	SWITCHLIGHT MODU	1.6 HDI 16v 110cv FAP 9HZ	Delphi
 Berlingo B9	SWITCHLIGHT MODU	1.6 HDI 16v 75cv 9HT	Delphi
 Berlingo B9	SWITCHLIGHT MODU	1.6 HDI 16v 90cv 9HX	Delphi
 Berlingo B9	SWITCHLIGHT MODU	1.6 HDI 16v 90cv FAP 9HS	Delphi
 Berlingo B9	SWITCHLIGHT MODU	1.6 HDI 16v 90cv FAP 9HV	Delphi
 Berlingo B9	VISUAL./TELEMATICS	1.6 16v 110cv NFU	Display A+ AUTODETECT
 Berlingo B9	VISUAL./TELEMATICS	1.6 16v 110cv NFU	Display C- AUTODETECT
 Berlingo B9	VISUAL./TELEMATICS	1.6 16v 90cv NFR	Display A+ AUTODETECT
 Berlingo B9	VISUAL./TELEMATICS	1.6 16v 90cv NFR	Display C- AUTODETECT
 Berlingo B9	VISUAL./TELEMATICS	1.6 HDI 16v 110cv FAP 9HZ	Display A+ AUTODETECT
 Berlingo B9	VISUAL./TELEMATICS	1.6 HDI 16v 110cv FAP 9HZ	Display C- AUTODETECT
 Berlingo B9	VISUAL./TELEMATICS	1.6 HDI 16v 75cv 9HT	Display A+ AUTODETECT
 Berlingo B9	VISUAL./TELEMATICS	1.6 HDI 16v 75cv 9HT	Display C- AUTODETECT
 Berlingo B9	VISUAL./TELEMATICS	1.6 HDI 16v 90cv 9HX	Display A+ AUTODETECT
 Berlingo B9	VISUAL./TELEMATICS	1.6 HDI 16v 90cv 9HX	Display C- AUTODETECT
 Berlingo B9	VISUAL./TELEMATICS	1.6 HDI 16v 90cv FAP 9HS	Display A+ AUTODETECT
 Berlingo B9	VISUAL./TELEMATICS	1.6 HDI 16v 90cv FAP 9HS	Display C- AUTODETECT
 Berlingo B9	VISUAL./TELEMATICS	1.6 HDI 16v 90cv FAP 9HV	Display A+ AUTODETECT
 Berlingo B9	VISUAL./TELEMATICS	1.6 HDI 16v 90cv FAP 9HV	Display C- AUTODETECT
 Berlingo	ABS	1.1 HDY	BOSCH ABS ABR 5.3
 Berlingo	ABS	1.1 HDZ	BOSCH ABS ABR 5.3
 Berlingo	ABS	1.1 HFX	BOSCH ABS ABR 5.3
 Berlingo	ABS	1.4 - GPL KFX	BOSCH ABS ABR 5.3
 Berlingo	ABS	1.4 KFW	BOSCH ABS ABR 5.3

## Systems supported by ECUREADER (up to V5.40)

### TRUCKS




























Citroen

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Berlingo	ABS	1.4 KFX	BOSCH ABS ABR 5.3
 Berlingo	ABS	1.6 16v NFU	BOSCH ABS ABR 5.3
 Berlingo	ABS	1.6 N6A	BOSCH ABS ABR 5.3
 Berlingo	ABS	1.9 D WJY	BOSCH ABS ABR 5.3
 Berlingo	ABS	2.0 HDI RHY	BOSCH ABS ABR 5.3
 Berlingo	AIRBAG	1.1 HDY (97-00)	AKF- Autoliv AirBag no SIDE AB
 Berlingo	AIRBAG	1.1 HDZ (97-00)	AKF- Autoliv AirBag no SIDE AB
 Berlingo	AIRBAG	1.1 HFX (97-00)	AKF- Autoliv AirBag no SIDE AB
 Berlingo	AIRBAG	1.4 - GPL KFX (97-00)	AKF- Autoliv AirBag no SIDE AB
 Berlingo	AIRBAG	1.4 KFW (97-00)	AKF- Autoliv AirBag no SIDE AB
 Berlingo	AIRBAG	1.4 KFX (97-00)	AKF- Autoliv AirBag no SIDE AB
 Berlingo	AIRBAG	1.6 16v NFU (97-00)	AKF- Autoliv AirBag no SIDE AB
 Berlingo	AIRBAG	1.6 N6A (97-00)	AKF- Autoliv AirBag no SIDE AB
 Berlingo	AIRBAG	1.9 D WJY (97-00)	AKF- Autoliv AirBag no SIDE AB
 Berlingo	AIRBAG	2.0 HDI RHY (97-00)	AKF- Autoliv AirBag no SIDE AB
 Berlingo	AUX. HEATING	1.1 HDY	AUTODETECT
 Berlingo	AUX. HEATING	1.1 HDZ	AUTODETECT
 Berlingo	AUX. HEATING	1.1 HFX	AUTODETECT
 Berlingo	AUX. HEATING	1.4 - GPL KFX	AUTODETECT
 Berlingo	AUX. HEATING	1.4 KFW	AUTODETECT
 Berlingo	AUX. HEATING	1.4 KFX	AUTODETECT
 Berlingo	AUX. HEATING	1.6 16v NFU	AUTODETECT
 Berlingo	AUX. HEATING	1.6 N6A	AUTODETECT
 Berlingo	AUX. HEATING	1.9 D WJY	AUTODETECT
 Berlingo	AUX. HEATING	2.0 HDI RHY	AUTODETECT
 Berlingo	CHASSIS NETWORK	1.1 HDY	Body Computer BSI AUTODETECT
 Berlingo	CHASSIS NETWORK	1.1 HDY (...-01)	VALEO Body Computer

## Systems supported by ECUREADER (up to V5.40)

### TRUCKS

























Citroen

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Berlingo	CHASSIS NETWORK	1.1 HDZ	Body Computer BSI AUTODETECT
 Berlingo	CHASSIS NETWORK	1.1 HDZ (...01)	VALEO Body Computer
 Berlingo	CHASSIS NETWORK	1.1 HFX	Body Computer BSI AUTODETECT
 Berlingo	CHASSIS NETWORK	1.1 HFX (...01)	VALEO Body Computer
 Berlingo	CHASSIS NETWORK	1.4 - GPL KFX	Body Computer BSI AUTODETECT
 Berlingo	CHASSIS NETWORK	1.4 - GPL KFX	VALEO Body Computer BSI AUTODETECT
 Berlingo	CHASSIS NETWORK	1.4 KFW	Body Computer BSI AUTODETECT
 Berlingo	CHASSIS NETWORK	1.4 KFW (...01)	VALEO Body Computer
 Berlingo	CHASSIS NETWORK	1.4 KFX	Body Computer BSI AUTODETECT
 Berlingo	CHASSIS NETWORK	1.4 KFX (...01)	VALEO Body Computer
 Berlingo	CHASSIS NETWORK	1.6 16v NFU	Body Computer BSI AUTODETECT
 Berlingo	CHASSIS NETWORK	1.6 16v NFU (...01)	VALEO Body Computer
 Berlingo	CHASSIS NETWORK	1.6 N6A	Body Computer BSI AUTODETECT
 Berlingo	CHASSIS NETWORK	1.6 N6A (...01)	VALEO Body Computer
 Berlingo	CHASSIS NETWORK	1.9 D WJY	Body Computer BSI AUTODETECT
 Berlingo	CHASSIS NETWORK	1.9 D WJY (...01)	VALEO Body Computer
 Berlingo	CHASSIS NETWORK	2.0 HDI RHY	Body Computer BSI AUTODETECT
 Berlingo	CHASSIS NETWORK	2.0 HDI RHY (...01)	VALEO Body Computer
 Berlingo	DASHBOARD	1.1 HDY	AUTODETECT
 Berlingo	DASHBOARD	1.1 HDZ	AUTODETECT
 Berlingo	DASHBOARD	1.1 HFX	AUTODETECT
 Berlingo	DASHBOARD	1.4 - GPL KFX	AUTODETECT
 Berlingo	DASHBOARD	1.4 KFW	AUTODETECT
 Berlingo	DASHBOARD	1.4 KFX	AUTODETECT
 Berlingo	DASHBOARD	1.6 16v NFU	AUTODETECT
 Berlingo	DASHBOARD	1.6 N6A	AUTODETECT
 Berlingo	DASHBOARD	1.9 D WJY	AUTODETECT

## Systems supported by ECUreader (up to V5.40)

### TRUCKS


Citroen

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Berlingo	DASHBOARD	2.0 HDI RHY	AUTODETECT
 Berlingo	DIESEL MANAGEMEN	1.9 D WJY	LUCAS DCN2 AUTODETECT
 Berlingo	DIESEL MANAGEMEN	1.9 D WJY	LUCAS Diesel DCN2
 Berlingo	ENGINE MANAGEME	1.1 HDY	BOSCH MonoMotronic MA3.1
 Berlingo	ENGINE MANAGEME	1.1 HDZ	BOSCH MonoMotronic MA3.1
 Berlingo	ENGINE MANAGEME	1.1 HFX	BOSCH M7.4.4 AUTODETECT
 Berlingo	ENGINE MANAGEME	1.4 KFW	SAGEM S2000 AUTODETECT
 Berlingo	ENGINE MANAGEME	1.4 KFX	MARELLI MM 1AP.40
 Berlingo	ENGINE MANAGEME	1.4 KFX	SAGEM SL 96
 Berlingo	ENGINE MANAGEME	1.6 16v NFU	BOSCH ME 7.4.4 AUTODETECT
 Berlingo	ENGINE MANAGEME	1.6 N6A	BOSCH ME 7.4.4 AUTODETECT
 Berlingo	ENGINE MANAGEME	2.0 HDI RHY	BOSCH EDC15 C2 Common Rail AUTODE
 Berlingo	ENGINE MANAGEME	2.0 HDI RHY	SIEMENS Diesel SID 801 Common Rail
 Berlingo	ENGINE MANAGEME	2.0 HDI RHY	SIEMENS SID 801 Common Rail AUTODET
 Berlingo	ENGINE MANAGEME	2.0 HDI RHY (.-00)	BOSCH EDC 15 C2 Common Rail
 Berlingo	ENGINE MANAGEME	2.0 HDI RHY (01-03)	BOSCH EDC 15 C2 Common Rail
 Berlingo	KEY ENCODE	1.1 HDY	Valeo/Siemens
 Berlingo	KEY ENCODE	1.1 HDZ	Valeo/Siemens
 Berlingo	KEY ENCODE	1.1 HFX	Valeo/Siemens
 Berlingo	KEY ENCODE	1.4 KFW	Valeo/Siemens
 Berlingo	KEY ENCODE	1.4 KFX	Valeo/Siemens
 Berlingo	KEY ENCODE	1.6 16v NFU	Valeo/Siemens
 Berlingo	KEY ENCODE	1.6 N6A	Valeo/Siemens
 Berlingo	KEY ENCODE	1.9 D WJY	Valeo/Siemens
 Berlingo	KEY ENCODE	2.0 HDI RHY	Valeo/Siemens
 Berlingo	RADIO / CD	1.1 HDY	AudioSystem AUTODETECT
 Berlingo	RADIO / CD	1.1 HDY	CD Changer AUTODETECT

## Systems supported by ECReader (up to V5.40)

### TRUCKS

Citroen

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Berlingo	RADIO / CD	1.1 HDY	CLARION AudioSystem
 Berlingo	RADIO / CD	1.1 HDY	PHILIPS AudioSystem
 Berlingo	RADIO / CD	1.1 HDY	VDO AudioSystem
 Berlingo	RADIO / CD	1.1 HDZ	AudioSystem AUTODETECT
 Berlingo	RADIO / CD	1.1 HDZ	CD Changer AUTODETECT
 Berlingo	RADIO / CD	1.1 HDZ	CLARION AudioSystem
 Berlingo	RADIO / CD	1.1 HDZ	PHILIPS AudioSystem
 Berlingo	RADIO / CD	1.1 HDZ	VDO AudioSystem
 Berlingo	RADIO / CD	1.1 HFX	AudioSystem AUTODETECT
 Berlingo	RADIO / CD	1.1 HFX	Cd Changer AUTODETECT
 Berlingo	RADIO / CD	1.1 HFX	CLARION AudioSystem
 Berlingo	RADIO / CD	1.1 HFX	PHILIPS AudioSystem
 Berlingo	RADIO / CD	1.1 HFX	VDO AudioSystem
 Berlingo	RADIO / CD	1.4 - GPL KFX	AudioSystem AUTODETECT
 Berlingo	RADIO / CD	1.4 - GPL KFX	CD Changer AUTODETECT
 Berlingo	RADIO / CD	1.4 - GPL KFX	CLARION AudioSystem
 Berlingo	RADIO / CD	1.4 - GPL KFX	PHILIPS AudioSystem
 Berlingo	RADIO / CD	1.4 - GPL KFX	VDO AudioSystem
 Berlingo	RADIO / CD	1.4 KFW	AudioSystem AUTODETECT
 Berlingo	RADIO / CD	1.4 KFW	CD Changer AUTODETECT
 Berlingo	RADIO / CD	1.4 KFW	CLARION AudioSystem
 Berlingo	RADIO / CD	1.4 KFW	PHILIPS AudioSystem
 Berlingo	RADIO / CD	1.4 KFW	VDO AudioSystem
 Berlingo	RADIO / CD	1.4 KFX	AudioSystem AUTODETECT
 Berlingo	RADIO / CD	1.4 KFX	CD Changer AUTODETECT
 Berlingo	RADIO / CD	1.4 KFX	CLARION AudioSystem
 Berlingo	RADIO / CD	1.4 KFX	PHILIPS AudioSystem

## Systems supported by ECReader (up to V5.40)

### TRUCKS



























Citroen

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Berlingo	RADIO / CD	1.4 KFX	VDO AudioSystem
 Berlingo	RADIO / CD	1.6 16v NFU	AudioSystem AUTODETECT
 Berlingo	RADIO / CD	1.6 16v NFU	CD Changer AUTODETECT
 Berlingo	RADIO / CD	1.6 16v NFU	CLARION AudioSystem
 Berlingo	RADIO / CD	1.6 16v NFU	PHILIPS AudioSystem
 Berlingo	RADIO / CD	1.6 16v NFU	VDO AudioSystem
 Berlingo	RADIO / CD	1.6 N6A	AudioSystem AUTODETECT
 Berlingo	RADIO / CD	1.6 N6A	CD Changer AUTODETECT
 Berlingo	RADIO / CD	1.6 N6A	CLARION AudioSystem
 Berlingo	RADIO / CD	1.6 N6A	PHILIPS AudioSystem
 Berlingo	RADIO / CD	1.6 N6A	VDO AudioSystem
 Berlingo	RADIO / CD	1.9 D WJY	AudioSystem AUTODETECT
 Berlingo	RADIO / CD	1.9 D WJY	CD Changer AUTODETECT
 Berlingo	RADIO / CD	1.9 D WJY	CLARION AudioSystem
 Berlingo	RADIO / CD	1.9 D WJY	PHILIPS AudioSystem
 Berlingo	RADIO / CD	1.9 D WJY	VDO AudioSystem
 Berlingo	RADIO / CD	2.0 HDI RHY	AudioSystem AUTODETECT
 Berlingo	RADIO / CD	2.0 HDI RHY	CD Changer AUTODETECT
 Berlingo	RADIO / CD	2.0 HDI RHY	CLARION AudioSystem
 Berlingo	RADIO / CD	2.0 HDI RHY	PHILIPS AudioSystem
 Berlingo	RADIO / CD	2.0 HDI RHY	VDO AudioSystem
 Berlingo	SERVICE LIGHT RES	1.1 HDY (98-00)	Sagem Manual
 Berlingo	SERVICE LIGHT RES	1.1 HDZ (98-00)	Sagem Manual
 Berlingo	SERVICE LIGHT RES	1.1 HFX (98-00)	Sagem Manual
 Berlingo	SERVICE LIGHT RES	1.4 - GPL KFX (98-00)	Sagem Manual
 Berlingo	SERVICE LIGHT RES	1.4 KFW (98-00)	Sagem Manual
 Berlingo	SERVICE LIGHT RES	1.4 KFX (98-00)	Sagem Manual

## Systems supported by ECReader (up to V5.40)

### TRUCKS




























Citroen

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Berlingo	SERVICE LIGHT RES	1.9 D WJY (98-00)	Sagem Manual
 Berlingo	SERVICE LIGHT RES	2.0 HDI RHV (98-00)	Sagem Manual
 C15	DIESEL MANAGEMEN	1.9 D WJY	LUCAS DCN2 AUTODETECT
 C15	DIESEL MANAGEMEN	1.9 D WJY	LUCAS Diesel DCN2
 C15	ELECTRONIC INJECTI	1.1 HDZ	BOSCH MonoJetronic A2.2 [Slow]
 C15	ELECTRONIC INJECTI	1.4 KDY	BOSCH MonoJetronic A2.2 [Slow]
 Jumper 2	ABS	2.0 16v RFL	BOSCH ABS ABR 5.3
 Jumper 2	ABS	2.0 16v RFL (06-..)	BOSCH ABS 8
 Jumper 2	ABS	2.0 D DW10UTD	BOSCH ABS ABR 5.3
 Jumper 2	ABS	2.0 D DW10UTD (06-..)	BOSCH ABS 8
 Jumper 2	ABS	2.0 HDI RHV	BOSCH ABS ABR 5.3
 Jumper 2	ABS	2.0 HDI RHV (06-..)	BOSCH ABS 8
 Jumper 2	ABS	2.2 D DW12UTED	BOSCH ABS ABR 5.3
 Jumper 2	ABS	2.2 D DW12UTED (06-..)	BOSCH ABS 8
 Jumper 2	ABS	2.2 HDI 4HY	BOSCH ABS ABR 5.3
 Jumper 2	ABS	2.2 HDI 4HY (06-..)	BOSCH ABS 8
 Jumper 2	ABS	2.8 HDI SOFIM (06-..)	BOSCH ABS 8
 Jumper 2	ABS	2.8 HDI SOFIM (06-..)	BOSCH ABS ABR 5.3
 Jumper 2	AIRBAG	2.0 16v RFL	SIEMENS AirBag
 Jumper 2	AIRBAG	2.0 16v RFL (06-..)	TRW SRS 1
 Jumper 2	AIRBAG	2.0 D DW10UTD	SIEMENS AirBag
 Jumper 2	AIRBAG	2.0 D DW10UTD (06-..)	TRW SRS 1
 Jumper 2	AIRBAG	2.0 HDI RHV	SIEMENS AirBag
 Jumper 2	AIRBAG	2.0 HDI RHV (06-..)	TRW SRS 1
 Jumper 2	AIRBAG	2.2 D DW12UTED	SIEMENS AirBag
 Jumper 2	AIRBAG	2.2 D DW12UTED (06-..)	TRW SRS 1

## Systems supported by ECReader (up to V5.40)

### TRUCKS



























Citroen

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Jumper 2	AIRBAG	2.2 HDI 4HY	SIEMENS AirBag
 Jumper 2	AIRBAG	2.2 HDI 4HY (06-..)	TRW SRS 1
 Jumper 2	AIRBAG	2.8 HDI SOFIM	SIEMENS AirBag
 Jumper 2	AIRBAG	2.8 HDI SOFIM (06-..)	TRW SRS 1
 Jumper 2	AUTOM. TRANSMISSI	2.0 16v RFL	A/T 4HP20 AUTODETECT
 Jumper 2	AUTOM. TRANSMISSI	2.0 D DW10UTD	A/T 4HP20 AUTODETECT
 Jumper 2	AUTOM. TRANSMISSI	2.0 HDI RHV	A/T 4HP20 AUTODETECT
 Jumper 2	AUTOM. TRANSMISSI	2.2 D DW12UTED	A/T 4HP20 AUTODETECT
 Jumper 2	AUTOM. TRANSMISSI	2.2 HDI 4HY	A/T 4HP20 AUTODETECT
 Jumper 2	AUTOM. TRANSMISSI	2.8 HDI SOFIM	A/T 4HP20 AUTODETECT
 Jumper 2	AUX. HEATING	2.0 16v RFL	AUTODETECT
 Jumper 2	AUX. HEATING	2.0 D DW10UTD	AUTODETECT
 Jumper 2	AUX. HEATING	2.0 HDI RHV	AUTODETECT
 Jumper 2	AUX. HEATING	2.2 D DW12UTED	AUTODETECT
 Jumper 2	AUX. HEATING	2.2 HDI 4HY	AUTODETECT
 Jumper 2	AUX. HEATING	2.8 HDI SOFIM	AUTODETECT
 Jumper 2	CHASSIS NETWORK	2.0 16v RFL (06-..)	MARELLI Body Computer 6
 Jumper 2	CHASSIS NETWORK	2.0 D DW10UTD (06-..)	MARELLI Body Computer 6
 Jumper 2	CHASSIS NETWORK	2.0 HDI RHV (06-..)	MARELLI Body Computer 6
 Jumper 2	CHASSIS NETWORK	2.2 D DW12UTED (06-..)	MARELLI Body Computer 6
 Jumper 2	CHASSIS NETWORK	2.2 HDI 4HY (06-..)	MARELLI Body Computer 6
 Jumper 2	CHASSIS NETWORK	2.8 HDI SOFIM (06-..)	MARELLI Body Computer 6
 Jumper 2	DASHBOARD	2.0 16v RFL (06-..)	MARELLI Dashboard
 Jumper 2	DASHBOARD	2.0 D DW10UTD (06-..)	MARELLI Dashboard
 Jumper 2	DASHBOARD	2.0 HDI RHV (06-..)	MARELLI Dashboard
 Jumper 2	DASHBOARD	2.2 D DW12UTED (06-..)	MARELLI Dashboard
 Jumper 2	DASHBOARD	2.2 HDI 4HY (06-..)	MARELLI Dashboard

## Systems supported by ECUreader (up to V5.40)

### TRUCKS

Citroen

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Jumper 2	DASHBOARD	2.8 HDI SOFIM (06-..)	MARELLI Dashboard
 Jumper 2	ENGINE MANAGEME	2.0 16v RFL	MARELLI MM48P AUTODETECT
 Jumper 2	ENGINE MANAGEME	2.0 D DW10UTD	DIESEL AUTODETECT
 Jumper 2	ENGINE MANAGEME	2.0 HDI RHV (02-06)	BOSCH EDC 15 Common Rail (JTD '99)
 Jumper 2	ENGINE MANAGEME	2.2 D DW12UTED	DIESEL AUTODETECT
 Jumper 2	ENGINE MANAGEME	2.2 HDI 4HY (02-06)	BOSCH EDC 15 Common Rail (JTD '99)
 Jumper 2	ENGINE MANAGEME	2.2 HDI 4HY (06-..)	BOSCH EDC 16 Common Rail
 Jumper 2	ENGINE MANAGEME	2.8 HDI SOFIM	DIESEL AUTODETECT
 Jumper 2	ENGINE MANAGEME	2.8 HDI SOFIM (02-06)	BOSCH EDC 15 Common Rail (JTD '99)
 Jumper 2	SERVICE LIGHT RES	2.0 16v RFL (06-..)	MARELLI Dashboard
 Jumper 2	SERVICE LIGHT RES	2.0 D DW10UTD (06-..)	MARELLI Dashboard
 Jumper 2	SERVICE LIGHT RES	2.0 HDI RHV (06-..)	MARELLI Dashboard
 Jumper 2	SERVICE LIGHT RES	2.2 D DW12UTED (06-..)	MARELLI Dashboard
 Jumper 2	SERVICE LIGHT RES	2.2 HDI 4HY (06-..)	MARELLI Dashboard
 Jumper 2	SERVICE LIGHT RES	2.8 HDI SOFIM (06-..)	MARELLI Dashboard
 Jumper 3	ABS	2.2 HDI 4HU	BOSCH ABS 8.0 AUTODETECT
 Jumper 3	ABS	2.2 HDI 4HV	BOSCH ABS 8.0 AUTODETECT
 Jumper 3	ABS	3.0 HDI SOFIM	BOSCH ABS 8.0 AUTODETECT
 Jumper 3	ABS + TRACT. CONT	2.2 HDI 4HU	ABS+TC AUTODETECT
 Jumper 3	ABS + TRACT. CONT	2.2 HDI 4HU	BOSCH ESP AUTODETECT
 Jumper 3	ABS + TRACT. CONT	2.2 HDI 4HV	ABS+TC AUTODETECT
 Jumper 3	ABS + TRACT. CONT	2.2 HDI 4HV	ESP AUTODETECT
 Jumper 3	ABS + TRACT. CONT	3.0 HDI SOFIM	ABS+TC AUTODETECT
 Jumper 3	ABS + TRACT. CONT	3.0 HDI SOFIM	BOSCH ESP AUTODETECT
 Jumper 3	AIRBAG	2.2 HDI 4HU	AirBag CENTRAL AUTODETECT
 Jumper 3	AIRBAG	2.2 HDI 4HV	AirBag CENTRAL AUTODETECT

## Systems supported by ECUreader (up to V5.40)

### TRUCKS



























Citroen

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Jumper 3	AIRBAG	3.0 HDI SOFIM	AirBag CENTRAL AUTODETECT
 Jumper 3	AUX. HEATING	2.2 HDI 4HU	AUTODETECT
 Jumper 3	AUX. HEATING	2.2 HDI 4HV	AUTODETECT
 Jumper 3	AUX. HEATING	3.0 HDI SOFIM	AUTODETECT
 Jumper 3	CHASSIS NETWORK	2.2 HDI 4HU	Body Computer BSI AUTODETECT
 Jumper 3	CHASSIS NETWORK	2.2 HDI 4HV	Body Computer BSI AUTODETECT
 Jumper 3	CHASSIS NETWORK	3.0 HDI SOFIM	Body Computer BSI AUTODETECT
 Jumper 3	CHRONOTACHOGRA	2.2 HDI 4HU	AUTODETECT
 Jumper 3	CHRONOTACHOGRA	2.2 HDI 4HV	AUTODETECT
 Jumper 3	CHRONOTACHOGRA	3.0 HDI SOFIM	AUTODETECT
 Jumper 3	CLIMA	2.2 HDI 4HU	CLIMA AUTODETECT
 Jumper 3	CLIMA	2.2 HDI 4HV	CLIMA AUTODETECT
 Jumper 3	CLIMA	3.0 HDI SOFIM	CLIMA AUTODETECT
 Jumper 3	DASHBOARD	2.2 HDI 4HU	AUTODETECT
 Jumper 3	DASHBOARD	2.2 HDI 4HV	AUTODETECT
 Jumper 3	DASHBOARD	3.0 HDI SOFIM	AUTODETECT
 Jumper 3	ELECTRIC STEERING	2.2 HDI 4HU	AUTODETECT
 Jumper 3	ELECTRIC STEERING	2.2 HDI 4HV	AUTODETECT
 Jumper 3	ELECTRIC STEERING	3.0 HDI SOFIM	AUTODETECT
 Jumper 3	ENGINE MANAGEME	2.2 HDI 4HU	VISTEON PUMA AUTODETECT
 Jumper 3	ENGINE MANAGEME	2.2 HDI 4HV	VISTEON PUMA AUTODETECT
 Jumper 3	ENGINE MANAGEME	3.0 HDI SOFIM	BOSCH EDC16 C39 Common Rail AUTOD
 Jumper 3	NAVIGATION	2.2 HDI 4HU	AUTODETECT
 Jumper 3	NAVIGATION	2.2 HDI 4HV	AUTODETECT
 Jumper 3	NAVIGATION	3.0 HDI SOFIM	AUTODETECT
 Jumper 3	PARK.BRAKE	2.2 HDI 4HU	AUTODETECT
 Jumper 3	PARK.BRAKE	2.2 HDI 4HV	AUTODETECT

## Systems supported by ECUREADER (up to V5.40)

### TRUCKS




























Citroen

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Jumper 3	PARK.BRAKE	3.0 HDI SOFIM	AUTODETECT
 Jumper 3	SUSPENSION CONTR	2.2 HDI 4HU	AUTODETECT
 Jumper 3	SUSPENSION CONTR	2.2 HDI 4HV	AUTODETECT
 Jumper 3	SUSPENSION CONTR	3.0 HDI SOFIM	AUTODETECT
 Jumper	ABS	2.0 D DW10UTD	BOSCH ABS ABR 5.3
 Jumper	ABS	2.0 RFL	BOSCH ABS ABR 5.3
 Jumper	ABS	2.2 D DW12UTED	BOSCH ABS ABR 5.3
 Jumper	ABS	2.8 HDI SOFIM	BOSCH ABS ABR 5.3
 Jumper	ENGINE MANAGEME	2.0 D DW10UTD	DIESEL AUTODETECT
 Jumper	ENGINE MANAGEME	2.0 RFL	MARELLI MM48P AUTODETECT
 Jumper	ENGINE MANAGEME	2.2 D DW12UTED	DIESEL AUTODETECT
 Jumper	ENGINE MANAGEME	2.8 HDI SOFIM	DIESEL AUTODETECT
 Jumpy 2	ABS	1.6 HDI 9HU (07-..)	BOSCH ABS 8
 Jumpy 2	ABS	1.9 D WJY (07-..)	BOSCH ABS 8
 Jumpy 2	ABS	2.0 16v RFN (07-..)	BOSCH ABS 8
 Jumpy 2	ABS	2.0 HDI 16v FAP RHW (07-..)	BOSCH ABS 8
 Jumpy 2	ABS	2.0 HDI 16v RHX (07-..)	BOSCH ABS 8
 Jumpy 2	ABS	2.0 HDI 16v RHZ (07-..)	BOSCH ABS 8
 Jumpy 2	AIRBAG	1.6 HDI 9HU	AirBag CENTRAL AUTODETECT
 Jumpy 2	AIRBAG	1.6 HDI 9HU (07-..)	Temic SRS
 Jumpy 2	AIRBAG	1.9 D WJY	AirBag CENTRAL AUTODETECT
 Jumpy 2	AIRBAG	1.9 D WJY (07-..)	Temic SRS
 Jumpy 2	AIRBAG	2.0 16v RFN	AirBag CENTRAL AUTODETECT
 Jumpy 2	AIRBAG	2.0 16v RFN (07-..)	Temic SRS
 Jumpy 2	AIRBAG	2.0 HDI 16v FAP RHW	AirBag CENTRAL AUTODETECT
 Jumpy 2	AIRBAG	2.0 HDI 16v FAP RHW (07-..)	Temic SRS

## Systems supported by ECUREADER (up to V5.40)

### TRUCKS










Citroen

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Jumpy 2	AIRBAG	2.0 HDI 16v RHX	AirBag CENTRAL AUTODETECT
 Jumpy 2	AIRBAG	2.0 HDI 16v RHX (07-..)	Temic SRS
 Jumpy 2	AIRBAG	2.0 HDI 16v RHZ	AirBag CENTRAL AUTODETECT
 Jumpy 2	AIRBAG	2.0 HDI 16v RHZ (07-..)	Temic SRS
 Jumpy 2	AUTOM. TRANSMISSI	1.6 HDI 9HU	A/T AL4 AUTODETECT
 Jumpy 2	AUTOM. TRANSMISSI	1.9 D WJY	A/T AL4 AUTODETECT
 Jumpy 2	AUTOM. TRANSMISSI	2.0 16v RFN	A/T AL4 AUTODETECT
 Jumpy 2	AUTOM. TRANSMISSI	2.0 HDI 16v FAP RHW	A/T AL4 AUTODETECT
 Jumpy 2	AUTOM. TRANSMISSI	2.0 HDI 16v RHX	A/T AL4 AUTODETECT
 Jumpy 2	AUTOM. TRANSMISSI	2.0 HDI 16v RHZ	A/T AL4 AUTODETECT
 Jumpy 2	CHASSIS NETWORK	1.6 HDI 9HU (07-..)	Valeo 2 1/2
 Jumpy 2	CHASSIS NETWORK	1.6 HDI 9HU (07-..)	Valeo 2 2/2
 Jumpy 2	CHASSIS NETWORK	1.9 D WJY (07-..)	Valeo 2 1/2
 Jumpy 2	CHASSIS NETWORK	1.9 D WJY (07-..)	Valeo 2 2/2
 Jumpy 2	CHASSIS NETWORK	2.0 16v RFN (07-..)	Valeo 2 1/2
 Jumpy 2	CHASSIS NETWORK	2.0 16v RFN (07-..)	Valeo 2 2/2
 Jumpy 2	CHASSIS NETWORK	2.0 HDI 16v FAP RHW (07-..)	Valeo 2 1/2
 Jumpy 2	CHASSIS NETWORK	2.0 HDI 16v FAP RHW (07-..)	Valeo 2 2/2
 Jumpy 2	CHASSIS NETWORK	2.0 HDI 16v RHX (07-..)	Valeo 2 1/2
 Jumpy 2	CHASSIS NETWORK	2.0 HDI 16v RHX (07-..)	Valeo 2 2/2
 Jumpy 2	CHASSIS NETWORK	2.0 HDI 16v RHZ (07-..)	Valeo 2 1/2
 Jumpy 2	CHASSIS NETWORK	2.0 HDI 16v RHZ (07-..)	Valeo 2 2/2
 Jumpy 2	DASHBOARD	1.6 HDI 9HU (07-..)	Marelli Dashboard PSA
 Jumpy 2	DASHBOARD	1.9 D WJY (07-..)	Marelli Dashboard PSA
 Jumpy 2	DASHBOARD	2.0 16v RFN (07-..)	Marelli Dashboard PSA
 Jumpy 2	DASHBOARD	2.0 HDI 16v FAP RHW (07-..)	Marelli Dashboard PSA
 Jumpy 2	DASHBOARD	2.0 HDI 16v RHX (07-..)	Marelli Dashboard PSA

## Systems supported by ECReader (up to V5.40)

### TRUCKS



























Citroen

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Jumpy 2	DASHBOARD	2.0 HDI 16v RHZ (07-..)	Marelli Dashboard PSA
 Jumpy 2	DIESEL ADDITION	2.0 HDI 16v FAP RHW	MARVAL
 Jumpy 2	DIESEL MANAGEMEN	1.9 D WJY	LUCAS DCN2 AUTODETECT
 Jumpy 2	DIESEL MANAGEMEN	1.9 D WJY	LUCAS Diesel DCN2
 Jumpy 2	ENGINE MANAGEME	1.6 HDI 9HU (07-..)	BOSCH EDC 16 34 Common Rail
 Jumpy 2	ENGINE MANAGEME	1.9 D WJY (07-..)	BOSCH EDC 16 34 Common Rail
 Jumpy 2	ENGINE MANAGEME	2.0 16v RFN	MARELLI MM48P AUTODETECT
 Jumpy 2	ENGINE MANAGEME	2.0 HDI 16v FAP RHW	BOSCH EDC15 C2 Common Rail AUTODE
 Jumpy 2	ENGINE MANAGEME	2.0 HDI 16v RHX	BOSCH EDC15 C2 Common Rail AUTODE
 Jumpy 2	ENGINE MANAGEME	2.0 HDI 16v RHX (07-..)	BOSCH EDC 16 34 Common Rail
 Jumpy 2	ENGINE MANAGEME	2.0 HDI 16v RHZ	BOSCH EDC15 C2 Common Rail AUTODE
 Jumpy 2	ENGINE MANAGEME	2.0 HDI 16v RHZ (...00)	BOSCH EDC 15 C2 Common Rail
 Jumpy 2	ENGINE MANAGEME	2.0 HDI 16v RHZ (07-..)	BOSCH EDC 16 34 Common Rail
 Jumpy 2	RADIO / CD	1.6 HDI 9HU (07-..)	Blaupunkt AudioSystem
 Jumpy 2	RADIO / CD	1.9 D WJY (07-..)	Blaupunkt AudioSystem
 Jumpy 2	RADIO / CD	2.0 16v RFN (07-..)	Blaupunkt AudioSystem
 Jumpy 2	RADIO / CD	2.0 HDI 16v FAP RHW (07-..)	Blaupunkt AudioSystem
 Jumpy 2	RADIO / CD	2.0 HDI 16v RHZ (07-..)	Blaupunkt AudioSystem
 Jumpy 2	SERVICE LIGHT RES	1.6 HDI 9HU (07-..)	MANUAL
 Jumpy 2	SERVICE LIGHT RES	1.9 D WJY (07-..)	MANUAL
 Jumpy 2	SERVICE LIGHT RES	2.0 16v RFN (07-..)	MANUAL
 Jumpy 2	SERVICE LIGHT RES	2.0 HDI 16v FAP RHW (07-..)	MANUAL
 Jumpy 2	SERVICE LIGHT RES	2.0 HDI 16v RHX (07-..)	MANUAL
 Jumpy 2	SERVICE LIGHT RES	2.0 HDI 16v RHZ (07-..)	MANUAL
 Jumpy 2	SWITCHLIGHT MODU	1.6 HDI 9HU (07-..)	Delphi
 Jumpy 2	SWITCHLIGHT MODU	1.9 D WJY (07-..)	Delphi
 Jumpy 2	SWITCHLIGHT MODU	2.0 16v RFN (07-..)	Delphi

## Systems supported by ECUreader (up to V5.40)

### TRUCKS


Citroen

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Jumpy 2	SWITCHLIGHT MODU	2.0 HDI 16v FAP RHW (07-..)	Delphi
 Jumpy 2	SWITCHLIGHT MODU	2.0 HDI 16v RHX (07-..)	Delphi
 Jumpy 2	SWITCHLIGHT MODU	2.0 HDI 16v RHZ (07-..)	Delphi
 Jumpy 3	ABS + TRACT. CONT	1.6 HDI 9HU	BOSCH ABS 8.0 AUTODETECT
 Jumpy 3	ABS + TRACT. CONT	1.6 HDI 9HU	BOSCH ABS 8.1 AUTODETECT
 Jumpy 3	ABS + TRACT. CONT	1.6 HDI 9HU	BOSCH ESP 8.0 AUTODETECT
 Jumpy 3	ABS + TRACT. CONT	1.6 HDI 9HU	BOSCH ESP 8.1 AUTODETECT
 Jumpy 3	ABS + TRACT. CONT	2.0 16v RFH	BOSCH ABS 8.0 AUTODETECT
 Jumpy 3	ABS + TRACT. CONT	2.0 16v RFH	BOSCH ABS 8.1 AUTODETECT
 Jumpy 3	ABS + TRACT. CONT	2.0 16v RFH	BOSCH ESP 8.0 AUTODETECT
 Jumpy 3	ABS + TRACT. CONT	2.0 16v RFH	BOSCH ESP 8.1 AUTODETECT
 Jumpy 3	ABS + TRACT. CONT	2.0 HDI 16v RHG	BOSCH ABS 8.0 AUTODETECT
 Jumpy 3	ABS + TRACT. CONT	2.0 HDI 16v RHG	BOSCH ABS 8.1 AUTODETECT
 Jumpy 3	ABS + TRACT. CONT	2.0 HDI 16v RHG	BOSCH ESP 8.0 AUTODETECT
 Jumpy 3	ABS + TRACT. CONT	2.0 HDI 16v RHG	BOSCH ESP 8.1 AUTODETECT
 Jumpy 3	ABS + TRACT. CONT	2.0 HDI 16v RHK	BOSCH ABS 8.0 AUTODETECT
 Jumpy 3	ABS + TRACT. CONT	2.0 HDI 16v RHK	BOSCH ABS 8.1 AUTODETECT
 Jumpy 3	ABS + TRACT. CONT	2.0 HDI 16v RHK	BOSCH ESP 8.0 AUTODETECT
 Jumpy 3	ABS + TRACT. CONT	2.0 HDI 16v RHK	BOSCH ESP 8.1 AUTODETECT
 Jumpy 3	ABS + TRACT. CONT	2.0 HDI 16v RHR	BOSCH ABS 8.0 AUTODETECT
 Jumpy 3	ABS + TRACT. CONT	2.0 HDI 16v RHR	BOSCH ABS 8.1 AUTODETECT
 Jumpy 3	ABS + TRACT. CONT	2.0 HDI 16v RHR	BOSCH ESP 8.0 AUTODETECT
 Jumpy 3	ABS + TRACT. CONT	2.0 HDI 16v RHR	BOSCH ESP 8.1 AUTODETECT
 Jumpy 3	AIRBAG	1.6 HDI 9HU	AirBag CENTRAL AUTODETECT
 Jumpy 3	AIRBAG	2.0 16v RFH	AirBag CENTRAL AUTODETECT
 Jumpy 3	AIRBAG	2.0 HDI 16v RHG	AirBag CENTRAL AUTODETECT

## Systems supported by ECReader (up to V5.40)

### TRUCKS























Citroen

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Jumpy 3	AIRBAG	2.0 HDI 16v RHK	AirBag CENTRAL AUTODETECT
 Jumpy 3	AIRBAG	2.0 HDI 16v RHR	AirBag CENTRAL AUTODETECT
 Jumpy 3	ANTITHEFT	1.6 HDI 9HU	Alarm PSA2 AUTODETECT
 Jumpy 3	ANTITHEFT	2.0 16v RFH	Alarm PSA2 AUTODETECT
 Jumpy 3	ANTITHEFT	2.0 HDI 16v RHG	Alarm PSA2 AUTODETECT
 Jumpy 3	ANTITHEFT	2.0 HDI 16v RHK	Alarm PSA2 AUTODETECT
 Jumpy 3	ANTITHEFT	2.0 HDI 16v RHR	Alarm PSA2 AUTODETECT
 Jumpy 3	AUX. HEATING	1.6 HDI 9HU	AUTODETECT
 Jumpy 3	AUX. HEATING	2.0 16v RFH	AUTODETECT
 Jumpy 3	AUX. HEATING	2.0 HDI 16v RHG	AUTODETECT
 Jumpy 3	AUX. HEATING	2.0 HDI 16v RHK	AUTODETECT
 Jumpy 3	AUX. HEATING	2.0 HDI 16v RHR	AUTODETECT
 Jumpy 3	CHASSIS NETWORK	1.6 HDI 9HU	Body Computer BSI AUTODETECT
 Jumpy 3	CHASSIS NETWORK	1.6 HDI 9HU	Body Computer BSM AUTODETECT
 Jumpy 3	CHASSIS NETWORK	1.6 HDI 9HU	Body Computer BSR AUTODETECT
 Jumpy 3	CHASSIS NETWORK	1.6 HDI 9HU	Body Computer Chassis AUTODETECT
 Jumpy 3	CHASSIS NETWORK	2.0 16v RFH	Body Computer BSI AUTODETECT
 Jumpy 3	CHASSIS NETWORK	2.0 16v RFH	Body Computer BSM AUTODETECT
 Jumpy 3	CHASSIS NETWORK	2.0 16v RFH	Body Computer BSR AUTODETECT
 Jumpy 3	CHASSIS NETWORK	2.0 16v RFH	Body Computer Chassis AUTODETECT
 Jumpy 3	CHASSIS NETWORK	2.0 HDI 16v RHG	Body Computer BSI AUTODETECT
 Jumpy 3	CHASSIS NETWORK	2.0 HDI 16v RHG	Body Computer BSM AUTODETECT
 Jumpy 3	CHASSIS NETWORK	2.0 HDI 16v RHG	Body Computer BSR AUTODETECT
 Jumpy 3	CHASSIS NETWORK	2.0 HDI 16v RHG	Body Computer Chassis AUTODETECT
 Jumpy 3	CHASSIS NETWORK	2.0 HDI 16v RHK	Body Computer BSI AUTODETECT
 Jumpy 3	CHASSIS NETWORK	2.0 HDI 16v RHK	Body Computer BSM AUTODETECT
 Jumpy 3	CHASSIS NETWORK	2.0 HDI 16v RHK	Body Computer BSR AUTODETECT

## Systems supported by ECReader (up to V5.40)

### TRUCKS




























Citroen

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Jumpy 3	CHASSIS NETWORK	2.0 HDI 16v RHK	Body Computer Chassis AUTODETECT
 Jumpy 3	CHASSIS NETWORK	2.0 HDI 16v RHR	Body Computer BSI AUTODETECT
 Jumpy 3	CHASSIS NETWORK	2.0 HDI 16v RHR	Body Computer BSM AUTODETECT
 Jumpy 3	CHASSIS NETWORK	2.0 HDI 16v RHR	Body Computer BSR AUTODETECT
 Jumpy 3	CHASSIS NETWORK	2.0 HDI 16v RHR	Body Computer Chassis AUTODETECT
 Jumpy 3	CLIMA	1.6 HDI 9HU	CLIMA AUTODETECT
 Jumpy 3	CLIMA	2.0 16v RFH	CLIMA AUTODETECT
 Jumpy 3	CLIMA	2.0 HDI 16v RHG	CLIMA AUTODETECT
 Jumpy 3	CLIMA	2.0 HDI 16v RHK	CLIMA AUTODETECT
 Jumpy 3	CLIMA	2.0 HDI 16v RHR	CLIMA AUTODETECT
 Jumpy 3	DASHBOARD	1.6 HDI 9HU	AUTODETECT
 Jumpy 3	DASHBOARD	2.0 16v RFH	AUTODETECT
 Jumpy 3	DASHBOARD	2.0 HDI 16v RHG	AUTODETECT
 Jumpy 3	DASHBOARD	2.0 HDI 16v RHK	AUTODETECT
 Jumpy 3	DASHBOARD	2.0 HDI 16v RHR	AUTODETECT
 Jumpy 3	ELECTRIC STEERING	1.6 HDI 9HU	AUTODETECT
 Jumpy 3	ELECTRIC STEERING	2.0 16v RFH	AUTODETECT
 Jumpy 3	ELECTRIC STEERING	2.0 HDI 16v RHG	AUTODETECT
 Jumpy 3	ELECTRIC STEERING	2.0 HDI 16v RHK	AUTODETECT
 Jumpy 3	ELECTRIC STEERING	2.0 HDI 16v RHR	AUTODETECT
 Jumpy 3	ENGINE MANAGEME	1.6 HDI 9HU	BOSCH EDC16 C34 Common Rail AUTOD
 Jumpy 3	ENGINE MANAGEME	2.0 16v RFH	MARELLI MM6KP AUTODETECT
 Jumpy 3	ENGINE MANAGEME	2.0 HDI 16v RHG	SIEMENS SID 803A Common Rail AUTOD
 Jumpy 3	ENGINE MANAGEME	2.0 HDI 16v RHK	SIEMENS SID 803A Common Rail AUTOD
 Jumpy 3	ENGINE MANAGEME	2.0 HDI 16v RHR	SIEMENS SID 803A Common Rail AUTOD
 Jumpy 3	NAVIGATION	1.6 HDI 9HU	AUTODETECT
 Jumpy 3	NAVIGATION	2.0 16v RFH	AUTODETECT

## Systems supported by ECReader (up to V5.40)

### TRUCKS



























Citroen

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Jumpy 3	NAVIGATION	2.0 HDI 16v RHG	AUTODETECT
 Jumpy 3	NAVIGATION	2.0 HDI 16v RHK	AUTODETECT
 Jumpy 3	NAVIGATION	2.0 HDI 16v RHR	AUTODETECT
 Jumpy 3	PARK.BRAKE	1.6 HDI 9HU	AUTODETECT
 Jumpy 3	PARK.BRAKE	2.0 16v RFH	AUTODETECT
 Jumpy 3	PARK.BRAKE	2.0 HDI 16v RHG	AUTODETECT
 Jumpy 3	PARK.BRAKE	2.0 HDI 16v RHK	AUTODETECT
 Jumpy 3	PARK.BRAKE	2.0 HDI 16v RHR	AUTODETECT
 Jumpy 3	PHONE	1.6 HDI 9HU	AUTODETECT
 Jumpy 3	PHONE	2.0 16v RFH	AUTODETECT
 Jumpy 3	PHONE	2.0 HDI 16v RHG	AUTODETECT
 Jumpy 3	PHONE	2.0 HDI 16v RHK	AUTODETECT
 Jumpy 3	PHONE	2.0 HDI 16v RHR	AUTODETECT
 Jumpy 3	RADIO / CD	1.6 HDI 9HU	AudioSystem AUTODETECT
 Jumpy 3	RADIO / CD	1.6 HDI 9HU	CD Changer AUTODETECT
 Jumpy 3	RADIO / CD	2.0 16v RFH	AudioSystem AUTODETECT
 Jumpy 3	RADIO / CD	2.0 16v RFH	CD Changer AUTODETECT
 Jumpy 3	RADIO / CD	2.0 HDI 16v RHG	AudioSystem AUTODETECT
 Jumpy 3	RADIO / CD	2.0 HDI 16v RHG	CD Changer AUTODETECT
 Jumpy 3	RADIO / CD	2.0 HDI 16v RHK	AudioSystem AUTODETECT
 Jumpy 3	RADIO / CD	2.0 HDI 16v RHK	CD Changer AUTODETECT
 Jumpy 3	RADIO / CD	2.0 HDI 16v RHR	AudioSystem AUTODETECT
 Jumpy 3	RADIO / CD	2.0 HDI 16v RHR	CD Changer AUTODETECT
 Jumpy 3	RAIN-LUMINOSITY SE	1.6 HDI 9HU	AUTODETECT
 Jumpy 3	RAIN-LUMINOSITY SE	2.0 16v RFH	AUTODETECT
 Jumpy 3	RAIN-LUMINOSITY SE	2.0 HDI 16v RHG	AUTODETECT
 Jumpy 3	RAIN-LUMINOSITY SE	2.0 HDI 16v RHK	AUTODETECT

## Systems supported by ECUREADER (up to V5.40)

### TRUCKS




























Citroen

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Jumpy 3	RAIN-LUMINOSITY SE	2.0 HDI 16v RHR	AUTODETECT
 Jumpy 3	REAR CLIMA	1.6 HDI 9HU	AUTODETECT
 Jumpy 3	REAR CLIMA	2.0 16v RFH	AUTODETECT
 Jumpy 3	REAR CLIMA	2.0 HDI 16v RHG	AUTODETECT
 Jumpy 3	REAR CLIMA	2.0 HDI 16v RHK	AUTODETECT
 Jumpy 3	REAR CLIMA	2.0 HDI 16v RHR	AUTODETECT
 Jumpy 3	STEERING COLUMN	1.6 HDI 9HU	AUTODETECT
 Jumpy 3	STEERING COLUMN	2.0 16v RFH	AUTODETECT
 Jumpy 3	STEERING COLUMN	2.0 HDI 16v RHG	AUTODETECT
 Jumpy 3	STEERING COLUMN	2.0 HDI 16v RHK	AUTODETECT
 Jumpy 3	STEERING COLUMN	2.0 HDI 16v RHR	AUTODETECT
 Jumpy 3	SUSPENSION CONTR	1.6 HDI 9HU	AUTODETECT
 Jumpy 3	SUSPENSION CONTR	2.0 16v RFH	AUTODETECT
 Jumpy 3	SUSPENSION CONTR	2.0 HDI 16v RHG	AUTODETECT
 Jumpy 3	SUSPENSION CONTR	2.0 HDI 16v RHK	AUTODETECT
 Jumpy 3	SUSPENSION CONTR	2.0 HDI 16v RHR	AUTODETECT
 Jumpy 3	VISUAL./TELEMATICS	1.6 HDI 9HU	Display A+ AUTODETECT
 Jumpy 3	VISUAL./TELEMATICS	1.6 HDI 9HU	Display C- AUTODETECT
 Jumpy 3	VISUAL./TELEMATICS	2.0 16v RFH	Display A+ AUTODETECT
 Jumpy 3	VISUAL./TELEMATICS	2.0 16v RFH	Display C- AUTODETECT
 Jumpy 3	VISUAL./TELEMATICS	2.0 HDI 16v RHG	Display A+ AUTODETECT
 Jumpy 3	VISUAL./TELEMATICS	2.0 HDI 16v RHG	Display C- AUTODETECT
 Jumpy 3	VISUAL./TELEMATICS	2.0 HDI 16v RHK	Display A+ AUTODETECT
 Jumpy 3	VISUAL./TELEMATICS	2.0 HDI 16v RHK	Display C- AUTODETECT
 Jumpy 3	VISUAL./TELEMATICS	2.0 HDI 16v RHR	Display A+ AUTODETECT
 Jumpy 3	VISUAL./TELEMATICS	2.0 HDI 16v RHR	Display C- AUTODETECT

## Systems supported by ECUREADER (up to V5.40)

### TRUCKS

























Citroen

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Jumpy	ABS	1.9 D WJY	BOSCH ABS ABR 5.3
 Jumpy	ABS	1.9 TD DHX	BOSCH ABS ABR 5.3
 Jumpy	ABS	2.0 16v RFN	BOSCH ABS ABR 5.3
 Jumpy	ABS	2.0 HDI 16v RHW	BOSCH ABS ABR 5.3
 Jumpy	ABS	2.0 HDI RHT	BOSCH ABS ABR 5.3
 Jumpy	ABS	2.0 HDI RHY	BOSCH ABS ABR 5.3
 Jumpy	ABS	2.0 HDI RHZ	BOSCH ABS ABR 5.3
 Jumpy	AIRBAG	1.9 D WJY	AUTOLIV AirBag CENTRAL ACU AUTODE
 Jumpy	AIRBAG	1.9 TD DHX	AUTOLIV AirBag CENTRAL ACU AUTODE
 Jumpy	AIRBAG	2.0 16v RFN	AUTOLIV AirBag CENTRAL ACU AUTODE
 Jumpy	AIRBAG	2.0 HDI 16v RHW	AUTOLIV Airbag CENTRAL ACU AUTODET
 Jumpy	AIRBAG	2.0 HDI RHT	AUTOLIV AirBag CENTRAL ACU AUTODE
 Jumpy	AIRBAG	2.0 HDI RHX	AUTOLIV AirBag CENTRAL ACU AUTODE
 Jumpy	AIRBAG	2.0 HDI RHY	AUTOLIV AirBag CENTRAL ACU AUTODE
 Jumpy	AIRBAG	2.0 HDI RHZ	AUTOLIV AirBag CENTRAL ACU AUTODE
 Jumpy	AUTOM. TRANSMISSI	1.9 D WJY	A/T AL4 AUTODETECT
 Jumpy	AUTOM. TRANSMISSI	1.9 TD DHX	A/T AL4 AUTODETECT
 Jumpy	AUTOM. TRANSMISSI	2.0 16v RFN	A/T AL4 AUTODETECT
 Jumpy	AUTOM. TRANSMISSI	2.0 HDI 16v RHW	A/T AL4 AUTODETECT
 Jumpy	AUTOM. TRANSMISSI	2.0 HDI RHT	A/T AL4 AUTODETECT
 Jumpy	AUTOM. TRANSMISSI	2.0 HDI RHX	A/T AL4 AUTODETECT
 Jumpy	AUTOM. TRANSMISSI	2.0 HDI RHY	A/T AL4 AUTODETECT
 Jumpy	AUTOM. TRANSMISSI	2.0 HDI RHZ	A/T AL4 AUTODETECT
 Jumpy	DIESEL MANAGEMEN	1.9 D WJY	LUCAS DCN2 AUTODETECT
 Jumpy	DIESEL MANAGEMEN	1.9 D WJY	LUCAS Diesel DCN2
 Jumpy	DIESEL MANAGEMEN	1.9 TD DHX	BOSCH AS3 VP20
 Jumpy	ENGINE MANAGEME	2.0 16v RFN	MARELLI MM48P AUTODETECT

## Systems supported by ECReader (up to V5.40)

### TRUCKS

Citroen

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Jumpy	ENGINE MANAGEME	2.0 HDI 16v RHW	BOSCH EDC15 C2 Common Rail AUTODE
 Jumpy	ENGINE MANAGEME	2.0 HDI RHT	BOSCH EDC 15 C2 Common Rail
 Jumpy	ENGINE MANAGEME	2.0 HDI RHX	BOSCH EDC15 C2 Common Rail AUTODE
 Jumpy	ENGINE MANAGEME	2.0 HDI RHY (...00)	BOSCH EDC 15 C2 Common Rail
 Jumpy	ENGINE MANAGEME	2.0 HDI RHZ	BOSCH EDC15 C2 Common Rail AUTODE
 Nemo	ABS + TRACT. CONT	1.3 Multijet 75cv 8HS	ABS BOSCH 8.1 AUTODETECT
 Nemo	ABS + TRACT. CONT	1.3 Multijet 75cv 8HS	BOSCH ESP 8
 Nemo	ABS + TRACT. CONT	1.4 8v KFV	BOSCH ABS 8.1 AUTODETECT
 Nemo	ABS + TRACT. CONT	1.4 8v KFV	BOSCH ESP 8
 Nemo	ABS + TRACT. CONT	1.4 HDI 8HS	ABS BOSCH 8.1 AUTODETECT
 Nemo	ABS + TRACT. CONT	1.4 HDI 8HS	BOSCH ESP 8
 Nemo	AIRBAG	1.3 Multijet 75cv 8HS	AUTOLIV AirBag CENTRAL AUTODETECT
 Nemo	AIRBAG	1.3 Multijet 75cv 8HS	TRW SRS EP
 Nemo	AIRBAG	1.4 8v KFV	AUTOLIV AirBag CENTRAL AUTODETECT
 Nemo	AIRBAG	1.4 8v KFV	TRW SRS EP
 Nemo	AIRBAG	1.4 HDI 8HS	AUTOLIV AirBag CENTRAL AUTODETECT
 Nemo	AIRBAG	1.4 HDI 8HS	TRW SRS EP
 Nemo	AUTOM. TRANSMISSI	1.3 Multijet 75cv 8HS	A/T MAP AUTODETECT
 Nemo	AUTOM. TRANSMISSI	1.4 8v KFV	A/T MAP AUTODETECT
 Nemo	AUTOM. TRANSMISSI	1.4 HDI 8HS	A/T MAP AUTODETECT
 Nemo	CHASSIS NETWORK	1.3 Multijet 75cv 8HS	Body Computer BSI AUTODETECT
 Nemo	CHASSIS NETWORK	1.3 Multijet 75cv 8HS	DELPHI Body Computer
 Nemo	CHASSIS NETWORK	1.3 Multijet 75cv 8HS	DELPHI Body Computer CAN Info
 Nemo	CHASSIS NETWORK	1.3 Multijet 75cv 8HS	DELPHI EP
 Nemo	CHASSIS NETWORK	1.4 8v KFV	Body Computer BSI AUTODETECT
 Nemo	CHASSIS NETWORK	1.4 8v KFV	DELPHI Body Computer

## Systems supported by ECUREADER (up to V5.40)

### TRUCKS



Citroen

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Nemo	CHASSIS NETWORK	1.4 8v KFV	DELPHI Body Computer CAN Info
 Nemo	CHASSIS NETWORK	1.4 8v KFV	DELPHI EP
 Nemo	CHASSIS NETWORK	1.4 HDI 8HS	Body Computer BSI AUTODETECT
 Nemo	CHASSIS NETWORK	1.4 HDI 8HS	DELPHI Body Computer
 Nemo	CHASSIS NETWORK	1.4 HDI 8HS	DELPHI Body Computer CAN Info
 Nemo	CHASSIS NETWORK	1.4 HDI 8HS	DELPHI EP
 Nemo	DASHBOARD	1.3 Multijet 75cv 8HS	AUTODETECT
 Nemo	DASHBOARD	1.3 Multijet 75cv 8HS	MARELLI Dashboard Modale
 Nemo	DASHBOARD	1.4 8v KFV	AUTODETECT
 Nemo	DASHBOARD	1.4 8v KFV	MARELLI Dashboard Modale
 Nemo	DASHBOARD	1.4 HDI 8HS	AUTODETECT
 Nemo	DASHBOARD	1.4 HDI 8HS	MARELLI Dashboard Modale
 Nemo	ENGINE MANAGEME	1.3 Multijet 75cv 8HS	BOSCH EDC16 C34 Common Rail AUTOD
 Nemo	ENGINE MANAGEME	1.3 Multijet 75cv 8HS	MARELLI IAW 6F3
 Nemo	ENGINE MANAGEME	1.4 8v KFV	V34P AUTODETECT
 Nemo	ENGINE MANAGEME	1.4 HDI 8HS	BOSCH EDC16 C34 Common Rail AUTOD
 Nemo	ENGINE MANAGEME	1.4 HDI 8HS	MARELLI IAW 6F3
 Nemo	PARK.BRAKE	1.3 Multijet 75cv 8HS	AUTODETECT
 Nemo	PARK.BRAKE	1.4 8v KFV	AUTODETECT
 Nemo	PARK.BRAKE	1.4 HDI 8HS	AUTODETECT

## Systems supported by ECUREADER (up to V5.40)

### TRUCKS





**Cobo Hermanos**

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Trailers	BRAKE SYS. MANAG	Trailers	Wabco Trailer EBS
 Trailers	BRAKE SYS. MANAG	Trailers	Wabco Trailer VCS II

## Systems supported by ECUreader (up to V5.40)

### TRUCKS




























**CTC**

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Trailers	BRAKE SYS. MANAG	Trailers	Wabco Trailers EBS
 Trailers	BRAKE SYS. MANAG	Trailers	Wabco Trailers EBS kw2000
 Trailers	BRAKE SYS. MANAG	Trailers Haldex	Haldex EBS EB+
 Trailers	BRAKE SYS. MANAG	Trailers Knorr	Knorr Trailer EBS

## Systems supported by ECUreader (up to V5.40)

### TRUCKS



























**DAF**

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 CF 65	AUTOM. TRANSMISSI	XE 340 (02-05)	ZF ASTRONIC
 CF 65	AUTOM. TRANSMISSI	XE 380 (02-05)	ZF ASTRONIC
 CF 65	AUTOM. TRANSMISSI	XE 430 (02-05)	ZF ASTRONIC
 CF 65	AUTOM. TRANSMISSI	XE 480 (02-05)	ZF ASTRONIC
 CF 65	BRAKE SYS. MANAG	280 (07-..)	WABCO EBS 2
 CF 65	BRAKE SYS. MANAG	CF 65.180 (02-..)	WABCO EBS EURO
 CF 65	BRAKE SYS. MANAG	CF 65.220 (02-..)	WABCO EBS EURO
 CF 65	BRAKE SYS. MANAG	CF 65.250 (02-..)	WABCO EBS EURO
 CF 65	DASHBOARD	280 (07-..)	DIP 4
 CF 65	DASHBOARD	XE 340 (02-05)	
 CF 65	DASHBOARD	XE 380 (02-05)	
 CF 65	DASHBOARD	XE 430 (02-05)	
 CF 65	DASHBOARD	XE 480 (02-05)	
 CF 65	ENGINE MANAGEME	XE 340 (02-05)	DAF UPEC
 CF 65	ENGINE MANAGEME	XE 380 (02-05)	DAF UPEC
 CF 65	ENGINE MANAGEME	XE 430 (02-05)	DAF UPEC
 CF 65	ENGINE MANAGEME	XE 480 (02-05)	DAF UPEC
 CF 65	SUSPENSION CONTR	CF 65.180 (02-..)	WABCO ECAS 3
 CF 65	SUSPENSION CONTR	CF 65.180 (02-..)	WABCO ECAS JED
 CF 65	SUSPENSION CONTR	CF 65.220 (02-..)	WABCO ECAS 3
 CF 65	SUSPENSION CONTR	CF 65.220 (02-..)	WABCO ECAS JED
 CF 65	SUSPENSION CONTR	CF 65.250 (02-..)	WABCO ECAS 3
 CF 65	SUSPENSION CONTR	CF 65.250 (02-..)	WABCO ECAS JED
 CF 65	SUSPENSION CONTR	XE 340 (02-05)	WABCO ECAS 3
 CF 65	SUSPENSION CONTR	XE 380 (02-05)	WABCO ECAS 3
 CF 65	SUSPENSION CONTR	XE 430 (02-05)	WABCO ECAS 3
 CF 65	SUSPENSION CONTR	XE 480 (02-05)	WABCO ECAS 3

## Systems supported by ECUreader (up to V5.40)

### TRUCKS



























**DAF**

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 CF 75	AUTOM. TRANSMISSI	XE 340 (02-05)	ZF ASTRONIC
 CF 75	AUTOM. TRANSMISSI	XE 380 (02-05)	ZF ASTRONIC
 CF 75	AUTOM. TRANSMISSI	XE 430 (02-05)	ZF ASTRONIC
 CF 75	AUTOM. TRANSMISSI	XE 480 (02-05)	ZF ASTRONIC
 CF 75	BRAKE SYS. MANAG	310 (07-..)	WABCO EBS 2
 CF 75	BRAKE SYS. MANAG	360 (07-..)	WABCO EBS 2
 CF 75	BRAKE SYS. MANAG	CF 75.250 (02-..)	WABCO EBS EURO
 CF 75	BRAKE SYS. MANAG	CF 75.310 (02-..)	WABCO EBS EURO
 CF 75	BRAKE SYS. MANAG	CF 75.360 (02-..)	WABCO EBS EURO
 CF 75	DASHBOARD	310 (07-..)	DIP 4
 CF 75	DASHBOARD	360 (07-..)	DIP 4
 CF 75	DASHBOARD	XE 340 (02-05)	
 CF 75	DASHBOARD	XE 380 (02-05)	
 CF 75	DASHBOARD	XE 430 (02-05)	
 CF 75	DASHBOARD	XE 480 (02-05)	
 CF 75	ENGINE MANAGEME	XE 340 (02-05)	DAF UPEC
 CF 75	ENGINE MANAGEME	XE 380 (02-05)	DAF UPEC
 CF 75	ENGINE MANAGEME	XE 430 (02-05)	DAF UPEC
 CF 75	ENGINE MANAGEME	XE 480 (02-05)	DAF UPEC
 CF 75	SUSPENSION CONTR	CF 75.250 (02-..)	WABCO ECAS 3
 CF 75	SUSPENSION CONTR	CF 75.250 (02-..)	WABCO ECAS JED
 CF 75	SUSPENSION CONTR	CF 75.310 (02-..)	WABCO ECAS 3
 CF 75	SUSPENSION CONTR	CF 75.310 (02-..)	WABCO ECAS JED
 CF 75	SUSPENSION CONTR	CF 75.360 (02-..)	WABCO ECAS 3
 CF 75	SUSPENSION CONTR	CF 75.360 (02-..)	WABCO ECAS JED
 CF 75	SUSPENSION CONTR	XE 340 (02-05)	WABCO ECAS 3

## Systems supported by ECUreader (up to V5.40)

### TRUCKS



























**DAF**

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 CF 75	SUSPENSION CONTR	XE 380 (02-05)	WABCO ECAS 3
 CF 75	SUSPENSION CONTR	XE 430 (02-05)	WABCO ECAS 3
 CF 75	SUSPENSION CONTR	XE 480 (02-05)	WABCO ECAS 3
 CF 85	AUTOM. TRANSMISSI	XE 340 (02-05)	ZF ASTRONIC
 CF 85	AUTOM. TRANSMISSI	XE 380 (02-05)	ZF ASTRONIC
 CF 85	AUTOM. TRANSMISSI	XE 430 (02-05)	ZF ASTRONIC
 CF 85	AUTOM. TRANSMISSI	XE 480 (02-05)	ZF ASTRONIC
 CF 85	BRAKE SYS. MANAG	410 (07-..)	WABCO EBS 2
 CF 85	BRAKE SYS. MANAG	460 (07-..)	WABCO EBS 2
 CF 85	BRAKE SYS. MANAG	CF 85.340 (02-..)	WABCO EBS EURO
 CF 85	BRAKE SYS. MANAG	CF 85.380 (02-..)	WABCO EBS EURO
 CF 85	BRAKE SYS. MANAG	CF 85.430 (02-..)	WABCO EBS EURO
 CF 85	BRAKE SYS. MANAG	CF 85.480 (02-..)	WABCO EBS EURO
 CF 85	DASHBOARD	410 (07-..)	DIP 4
 CF 85	DASHBOARD	460 (07-..)	DIP 4
 CF 85	DASHBOARD	XE 340 (02-05)	
 CF 85	DASHBOARD	XE 380 (02-05)	
 CF 85	DASHBOARD	XE 430 (02-05)	
 CF 85	DASHBOARD	XE 480 (02-05)	
 CF 85	ENGINE MANAGEME	XE 340 (02-05)	DAF UPEC
 CF 85	ENGINE MANAGEME	XE 380 (02-05)	DAF UPEC
 CF 85	ENGINE MANAGEME	XE 430 (02-05)	DAF UPEC
 CF 85	ENGINE MANAGEME	XE 480 (02-05)	DAF UPEC
 CF 85	SUSPENSION CONTR	CF 85.340 (02-..)	WABCO ECAS 3
 CF 85	SUSPENSION CONTR	CF 85.340 (02-..)	WABCO ECAS JED
 CF 85	SUSPENSION CONTR	CF 85.380 (02-..)	WABCO ECAS 3

## Systems supported by ECUREADER (up to V5.40)

### TRUCKS




















**DAF**

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 CF 85	SUSPENSION CONTR	CF 85.380 (02-..)	WABCO ECAS JED
 CF 85	SUSPENSION CONTR	CF 85.430 (02-..)	WABCO ECAS 3
 CF 85	SUSPENSION CONTR	CF 85.430 (02-..)	WABCO ECAS JED
 CF 85	SUSPENSION CONTR	CF 85.480 (02-..)	WABCO ECAS 3
 CF 85	SUSPENSION CONTR	CF 85.480 (02-..)	WABCO ECAS JED
 CF 85	SUSPENSION CONTR	XE 340 (02-05)	WABCO ECAS 3
 CF 85	SUSPENSION CONTR	XE 380 (02-05)	WABCO ECAS 3
 CF 85	SUSPENSION CONTR	XE 430 (02-05)	WABCO ECAS 3
 CF 85	SUSPENSION CONTR	XE 480 (02-05)	WABCO ECAS 3
 XF 105	BRAKE SYS. MANAG	410 (07-..)	WABCO EBS 2
 XF 105	BRAKE SYS. MANAG	460 (07-..)	WABCO EBS 2
 XF 105	BRAKE SYS. MANAG	510 (07-..)	WABCO EBS 2
 XF 105	BRAKE SYS. MANAG	560 (07-..)	WABCO EBS 2
 XF 105	DASHBOARD	410 (07-..)	DIP 4
 XF 105	DASHBOARD	460 (07-..)	DIP 4
 XF 105	DASHBOARD	510 (07-..)	DIP 4
 XF 105	DASHBOARD	560 (07-..)	DIP 4
 XF 95	AUTOM. TRANSMISSI	XE 380 C (02-05)	ZF ASTRONIC
 XF 95	AUTOM. TRANSMISSI	XE 430 C (02-05)	ZF ASTRONIC
 XF 95	AUTOM. TRANSMISSI	XE 480 C (02-05)	ZF ASTRONIC
 XF 95	AUTOM. TRANSMISSI	XE 530 C (02-05)	ZF ASTRONIC
 XF 95	BRAKE SYS. MANAG	XE 280 C (02-..)	WABCO EBS EURO
 XF 95	BRAKE SYS. MANAG	XE 315 C (02-..)	WABCO EBS EURO
 XF 95	BRAKE SYS. MANAG	XE 355 C (02-..)	WABCO EBS EURO
 XF 95	BRAKE SYS. MANAG	XE 390 C (02-..)	WABCO EBS EURO
 XF 95	DASHBOARD	XE 380 C (02-05)	

## Systems supported by ECUreader (up to V5.40)

### TRUCKS





**DAF**

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 XF 95	DASHBOARD	XE 430 C (02-05)	
 XF 95	DASHBOARD	XE 480 C (02-05)	
 XF 95	DASHBOARD	XE 530 C (02-05)	
 XF 95	ENGINE MANAGEME	XE 380 C (02-05)	DAF UPEC
 XF 95	ENGINE MANAGEME	XE 430 C (02-05)	DAF UPEC
 XF 95	ENGINE MANAGEME	XE 480 C (02-05)	DAF UPEC
 XF 95	ENGINE MANAGEME	XE 530 C (02-05)	DAF UPEC
 XF 95	SUSPENSION CONTR	XE 280 C (02-..)	WABCO ECAS 3
 XF 95	SUSPENSION CONTR	XE 280 C (02-..)	WABCO ECAS JED
 XF 95	SUSPENSION CONTR	XE 315 C (02-..)	WABCO ECAS 3
 XF 95	SUSPENSION CONTR	XE 315 C (02-..)	WABCO ECAS JED
 XF 95	SUSPENSION CONTR	XE 355 C (02-..)	WABCO ECAS 3
 XF 95	SUSPENSION CONTR	XE 355 C (02-..)	WABCO ECAS JED
 XF 95	SUSPENSION CONTR	XE 380 C (02-05)	WABCO ECAS 3
 XF 95	SUSPENSION CONTR	XE 390 C (02-..)	WABCO ECAS 3
 XF 95	SUSPENSION CONTR	XE 390 C (02-..)	WABCO ECAS JED
 XF 95	SUSPENSION CONTR	XE 430 C (02-05)	WABCO ECAS 3
 XF 95	SUSPENSION CONTR	XE 480 C (02-05)	WABCO ECAS 3
 XF 95	SUSPENSION CONTR	XE 530 C (02-05)	WABCO ECAS 3

## Systems supported by ECUreader (up to V5.40)

### TRUCKS






De Angelis

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Trailers	BRAKE SYS. MANAG	Trailers	Wabco Trailers EBS
 Trailers	BRAKE SYS. MANAG	Trailers	Wabco Trailers EBS kw2000
 Trailers	BRAKE SYS. MANAG	Trailers Haldex	Haldex EBS EB+
 Trailers	BRAKE SYS. MANAG	Trailers Knorr	Knorr Trailer EBS

## Systems supported by ECUreader (up to V5.40)

### TRUCKS





**Doll**

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Trailers	BRAKE SYS. MANAG	Trailers	Wabco Trailer EBS
 Trailers	BRAKE SYS. MANAG	Trailers	Wabco Trailer VCS II
 Trailers	BRAKE SYS. MANAG	Trailers	Wabco Trailers EBS kw2000
 Trailers	BRAKE SYS. MANAG	Trailers Haldex	Haldex EBS EB+
 Trailers	BRAKE SYS. MANAG	Trailers Knorr	Knorr Trailer EBS

## Systems supported by ECUREADER (up to V5.40)

### TRUCKS










### D-TEC

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Trailers	BRAKE SYS. MANAG	Trailers	Wabco Trailers EBS
 Trailers	BRAKE SYS. MANAG	Trailers	Wabco Trailers EBS kw2000
 Trailers	BRAKE SYS. MANAG	Trailers Haldex	Haldex EBS EB+
 Trailers	BRAKE SYS. MANAG	Trailers Knorr	Knorr Trailer EBS

## Systems supported by ECUREADER (up to V5.40)

### TRUCKS



**EvoBus**

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 TRAVEGO	BRAKE SYS. MANAG	O 580 15 RH	BS EBS ZF
 TRAVEGO	BRAKE SYS. MANAG	O 580 15 RHD	BS EBS ZF
 TRAVEGO	BRAKE SYS. MANAG	O 580 17 RHD	BS EBS ZF
 TRAVEGO	CRUISE CONTROL	O 580 15 RH	FR FMR
 TRAVEGO	CRUISE CONTROL	O 580 15 RHD	FR FMR
 TRAVEGO	CRUISE CONTROL	O 580 17 RHD	FR FMR
 TRAVEGO	ENGINE MANAGEME	O 580 15 RH	MR PLD
 TRAVEGO	ENGINE MANAGEME	O 580 15 RHD	MR PLD
 TRAVEGO	ENGINE MANAGEME	O 580 17 RHD	MR PLD

## Systems supported by ECUreader (up to V5.40)

### TRUCKS



**Fabrisem**

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Trailers	BRAKE SYS. MANAG	Trailers	Wabco Trailer EBS
 Trailers	BRAKE SYS. MANAG	Trailers	Wabco Trailer VCS II

## Systems supported by ECUREADER (up to V5.40)

### TRUCKS





**Farcinox**

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Trailers	BRAKE SYS. MANAG	Trailers	Wabco Trailer EBS
 Trailers	BRAKE SYS. MANAG	Trailers	Wabco Trailer VCS II

## Systems supported by ECUREADER (up to V5.40)

### TRUCKS




























Feldbinder

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Trailers	BRAKE SYS. MANAG	Trailers	Wabco Trailers EBS
 Trailers	BRAKE SYS. MANAG	Trailers	Wabco Trailers EBS kw2000
 Trailers	BRAKE SYS. MANAG	Trailers Haldex	Haldex EBS EB+
 Trailers	BRAKE SYS. MANAG	Trailers Knorr	Knorr Trailer EBS

## Systems supported by ECUREADER (up to V5.40)

### TRUCKS




























Fiat

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Doblo' 03	ABS	1.2 8v	ATE TEVES ABS Mk20
 Doblo' 03	ABS	1.3 Multijet	ATE TEVES ABS Mk20
 Doblo' 03	ABS	1.3 Multijet FAP	ATE TEVES ABS Mk20
 Doblo' 03	ABS	1.6 16v Bipower	ATE TEVES ABS Mk20
 Doblo' 03	ABS	1.9 D	ATE TEVES ABS Mk20
 Doblo' 03	ABS	1.9 DS	ATE TEVES ABS Mk20
 Doblo' 03	ABS	1.9 JTD	ATE TEVES ABS Mk20
 Doblo' 03	ABS	120 1.9 JTD	ATE TEVES ABS Mk20
 Doblo' 03	AIRBAG	1.2 8v	Autoliv AirBag MY 99 (1F-2P)
 Doblo' 03	AIRBAG	1.2 8v	Autoliv AirBag MY 99 (2F-2P-2L-I)
 Doblo' 03	AIRBAG	1.2 8v	Autoliv AirBag MY 99 (2F-2P-I)
 Doblo' 03	AIRBAG	1.2 8v	SIEMENS AirBag MY 99 (2F-2P-2L-2T-2I-S)
 Doblo' 03	AIRBAG	1.2 8v	SIEMENS AirBag MY 99 (2F-2P-I-S)
 Doblo' 03	AIRBAG	1.2 8v	SIEMENS AirBag MY 99 (2F-4P-4L-2T-2I-S)
 Doblo' 03	AIRBAG	1.3 Multijet	Autoliv AirBag MY 99 (1F-2P)
 Doblo' 03	AIRBAG	1.3 Multijet	Autoliv AirBag MY 99 (2F-2P-2L-I)
 Doblo' 03	AIRBAG	1.3 Multijet	Autoliv AirBag MY 99 (2F-2P-I)
 Doblo' 03	AIRBAG	1.3 Multijet	SIEMENS AirBag MY 99 (2F-2P-2L-2T-2I-S)
 Doblo' 03	AIRBAG	1.3 Multijet	SIEMENS AirBag MY 99 (2F-2P-I-S)
 Doblo' 03	AIRBAG	1.3 Multijet	SIEMENS AirBag MY 99 (2F-4P-4L-2T-2I-S)
 Doblo' 03	AIRBAG	1.3 Multijet FAP	Autoliv AirBag MY 99 (1F-2P)
 Doblo' 03	AIRBAG	1.3 Multijet FAP	Autoliv AirBag MY 99 (2F-2P-2L-I)
 Doblo' 03	AIRBAG	1.3 Multijet FAP	Autoliv AirBag MY 99 (2F-2P-I)
 Doblo' 03	AIRBAG	1.3 Multijet FAP	SIEMENS AirBag MY 99 (2F-2P-2L-2T-2I-S)
 Doblo' 03	AIRBAG	1.3 Multijet FAP	SIEMENS AirBag MY 99 (2F-2P-I-S)
 Doblo' 03	AIRBAG	1.3 Multijet FAP	SIEMENS AirBag MY 99 (2F-4P-4L-2T-2I-S)
 Doblo' 03	AIRBAG	1.6 16v Bipower	Autoliv AirBag MY 99 (1F-2P)

## Systems supported by ECReader (up to V5.40)

### TRUCKS




























**Fiat**

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Doblo' 03	AIRBAG	1.6 16v Bipower	Autoliv AirBag MY 99 (2F-2P-2L-I)
 Doblo' 03	AIRBAG	1.6 16v Bipower	Autoliv AirBag MY 99 (2F-2P-I)
 Doblo' 03	AIRBAG	1.6 16v Bipower	SIEMENS AirBag MY 99 (2F-2P-2L-2T-2I-S)
 Doblo' 03	AIRBAG	1.6 16v Bipower	SIEMENS AirBag MY 99 (2F-2P-I-S)
 Doblo' 03	AIRBAG	1.6 16v Bipower	SIEMENS AirBag MY 99 (2F-4P-4L-2T-2I-S)
 Doblo' 03	AIRBAG	1.9 D	Autoliv AirBag MY 99 (1F-2P)
 Doblo' 03	AIRBAG	1.9 D	Autoliv AirBag MY 99 (2F-2P-2L-I)
 Doblo' 03	AIRBAG	1.9 D	Autoliv AirBag MY 99 (2F-2P-I)
 Doblo' 03	AIRBAG	1.9 D	SIEMENS AirBag MY 99 (2F-2P-2L-2T-2I-S)
 Doblo' 03	AIRBAG	1.9 D	SIEMENS AirBag MY 99 (2F-2P-I-S)
 Doblo' 03	AIRBAG	1.9 D	SIEMENS AirBag MY 99 (2F-4P-4L-2T-2I-S)
 Doblo' 03	AIRBAG	1.9 DS	Autoliv AirBag MY 99 (1F-2P)
 Doblo' 03	AIRBAG	1.9 DS	Autoliv AirBag MY 99 (2F-2P-2L-I)
 Doblo' 03	AIRBAG	1.9 DS	Autoliv AirBag MY 99 (2F-2P-I)
 Doblo' 03	AIRBAG	1.9 DS	SIEMENS AirBag MY 99 (2F-2P-2L-2T-2I-S)
 Doblo' 03	AIRBAG	1.9 DS	SIEMENS AirBag MY 99 (2F-2P-I-S)
 Doblo' 03	AIRBAG	1.9 DS	SIEMENS AirBag MY 99 (2F-4P-4L-2T-2I-S)
 Doblo' 03	AIRBAG	1.9 JTD	Autoliv AirBag MY 99 (1F-2P)
 Doblo' 03	AIRBAG	1.9 JTD	Autoliv AirBag MY 99 (2F-2P-2L-I)
 Doblo' 03	AIRBAG	1.9 JTD	Autoliv AirBag MY 99 (2F-2P-I)
 Doblo' 03	AIRBAG	1.9 JTD	SIEMENS AirBag MY 99 (2F-2P-2L-2T-2I-S)
 Doblo' 03	AIRBAG	1.9 JTD	SIEMENS AirBag MY 99 (2F-2P-I-S)
 Doblo' 03	AIRBAG	1.9 JTD	SIEMENS AirBag MY 99 (2F-4P-4L-2T-2I-S)
 Doblo' 03	AIRBAG	120 1.9 JTD	Autoliv AirBag MY 99 (1F-2P)
 Doblo' 03	AIRBAG	120 1.9 JTD	Autoliv AirBag MY 99 (2F-2P-2L-I)
 Doblo' 03	AIRBAG	120 1.9 JTD	Autoliv AirBag MY 99 (2F-2P-I)
 Doblo' 03	AIRBAG	120 1.9 JTD	SIEMENS AirBag MY 99 (2F-2P-2L-2T-2I-S)

## Systems supported by ECReader (up to V5.40)

### TRUCKS



























**Fiat**

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Doblo' 03	AIRBAG	120 1.9 JTD	SIEMENS AirBag MY 99 (2F-2P-I-S)
 Doblo' 03	AIRBAG	120 1.9 JTD	SIEMENS AirBag MY 99 (2F-4P-4L-2T-2I-S)
 Doblo' 03	CHASSIS NETWORK	1.2 8v (03-..)	DELPHI/MARELLI Body Computer
 Doblo' 03	CHASSIS NETWORK	1.3 Multijet (03-..)	DELPHI/MARELLI Body Computer
 Doblo' 03	CHASSIS NETWORK	1.3 Multijet FAP (03-..)	DELPHI/MARELLI Body Computer
 Doblo' 03	CHASSIS NETWORK	1.6 16v Bipower (03-..)	DELPHI/MARELLI Body Computer
 Doblo' 03	CHASSIS NETWORK	1.9 D (03-..)	DELPHI/MARELLI Body Computer
 Doblo' 03	CHASSIS NETWORK	1.9 DS (03-..)	DELPHI/MARELLI Body Computer
 Doblo' 03	CHASSIS NETWORK	1.9 JTD (03-..)	DELPHI/MARELLI Body Computer
 Doblo' 03	CHASSIS NETWORK	120 1.9 JTD (03-..)	DELPHI/MARELLI Body Computer
 Doblo' 03	DASHBOARD	1.2 8v	MARELLI Dashboard Comfort
 Doblo' 03	DASHBOARD	1.2 8v	MARELLI Dashboard Strip/Modale
 Doblo' 03	DASHBOARD	1.3 Multijet	MARELLI Dashboard Comfort
 Doblo' 03	DASHBOARD	1.3 Multijet	MARELLI Dashboard Strip/Modale
 Doblo' 03	DASHBOARD	1.3 Multijet FAP	MARELLI Dashboard Comfort
 Doblo' 03	DASHBOARD	1.3 Multijet FAP	MARELLI Dashboard Strip/Modale
 Doblo' 03	DASHBOARD	1.6 16v Bipower	MARELLI Dashboard Comfort
 Doblo' 03	DASHBOARD	1.6 16v Bipower	MARELLI Dashboard Strip/Modale
 Doblo' 03	DASHBOARD	1.9 D	MARELLI Dashboard Comfort
 Doblo' 03	DASHBOARD	1.9 D	MARELLI Dashboard Strip/Modale
 Doblo' 03	DASHBOARD	1.9 DS	MARELLI Dashboard Comfort
 Doblo' 03	DASHBOARD	1.9 DS	MARELLI Dashboard Strip/Modale
 Doblo' 03	DASHBOARD	1.9 JTD	MARELLI Dashboard Comfort
 Doblo' 03	DASHBOARD	1.9 JTD	MARELLI Dashboard Strip/Modale
 Doblo' 03	DASHBOARD	120 1.9 JTD	MARELLI Dashboard Comfort
 Doblo' 03	DASHBOARD	120 1.9 JTD	MARELLI Dashboard Strip/Modale
 Doblo' 03	DIESEL MANAGEMEN	1.9 D	LUCAS EPIC DCU3F

## Systems supported by ECReader (up to V5.40)

### TRUCKS




























**Fiat**

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Doblo' 03	ENGINE MANAGEME	1.3 Multijet	MARELLI 6JF CF3 Common Rail
 Doblo' 03	ENGINE MANAGEME	1.3 Multijet FAP	MARELLI 6F3 CF3 Common Rail
 Doblo' 03	ENGINE MANAGEME	1.3 Multijet FAP	MARELLI 6JF CF3 Common Rail
 Doblo' 03	ENGINE MANAGEME	1.6 16v Bipower	MARELLI IAW 49F/59F EOBD
 Doblo' 03	ENGINE MANAGEME	1.9 JTD	BOSCH EDC 15 Common Rail (JTD '99)
 Doblo' 03	ENGINE MANAGEME	120 1.9 JTD	BOSCH EDC 16 Common Rail
 Doblo' 03	ENGINE MANAGEME	1.6 16v Bipower (03-..)	METATRON 6A0 EOBD
 Doblo' 03	KEY ENCODE	1.2 8v	DELPHI/MARELLI CODE Body Computer
 Doblo' 03	KEY ENCODE	1.3 Multijet	DELPHI/MARELLI CODE Body Computer
 Doblo' 03	KEY ENCODE	1.3 Multijet FAP	DELPHI/MARELLI CODE Body Computer
 Doblo' 03	KEY ENCODE	1.6 16v Bipower	DELPHI/MARELLI CODE Body Computer
 Doblo' 03	KEY ENCODE	1.9 D	DELPHI/MARELLI CODE Body Computer
 Doblo' 03	KEY ENCODE	1.9 DS	DELPHI/MARELLI CODE Body Computer
 Doblo' 03	KEY ENCODE	1.9 JTD	DELPHI/MARELLI CODE Body Computer
 Doblo' 03	KEY ENCODE	120 1.9 JTD	DELPHI/MARELLI CODE Body Computer
 Doblo'	ABS	1.2 16v	ATE TEVES ABS Mk20
 Doblo'	ABS	1.2 8v	ATE TEVES ABS Mk20
 Doblo'	ABS	1.2 8v Bipower	ATE TEVES ABS Mk20
 Doblo'	ABS	1.3 Multijet	ATE TEVES ABS Mk20
 Doblo'	ABS	1.6 16v	ATE TEVES ABS Mk20
 Doblo'	ABS	1.9 D	ATE TEVES ABS Mk20
 Doblo'	ABS	1.9 DS	ATE TEVES ABS Mk20
 Doblo'	ABS	1.9 JTD	ATE TEVES ABS Mk20
 Doblo'	ABS	100 1.9 JTD	ATE TEVES ABS Mk20
 Doblo'	ABS	80 1.9 JTD	ATE TEVES ABS Mk20
 Doblo'	AIRBAG	1.2 16v	AUTOLIV AirBag MY 99 (1F-2P)

## Systems supported by ECReader (up to V5.40)

### TRUCKS

























Fiat

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Doblo'	AIRBAG	1.2 16v	AUTOLIV AirBag MY 99 (2F-2P-2L-I)
 Doblo'	AIRBAG	1.2 16v	Autoliv AirBag MY 99 (2F-2P-I)
 Doblo'	AIRBAG	1.2 16v	SIEMENS AirBag MY 99 (2F-2P-2L-2T-2I-S)
 Doblo'	AIRBAG	1.2 16v	SIEMENS AirBag MY 99 (2F-2P-I-S)
 Doblo'	AIRBAG	1.2 16v	SIEMENS AirBag MY 99 (2F-4P-4L-2T-2I-S)
 Doblo'	AIRBAG	1.2 8v	AUTOLIV AirBag MY 99 (1F-2P)
 Doblo'	AIRBAG	1.2 8v	AUTOLIV AirBag MY 99 (2F-2P-2L-I)
 Doblo'	AIRBAG	1.2 8v	Autoliv AirBag MY 99 (2F-2P-I)
 Doblo'	AIRBAG	1.2 8v	SIEMENS AirBag MY 99 (2F-2P-2L-2T-2I-S)
 Doblo'	AIRBAG	1.2 8v	SIEMENS AirBag MY 99 (2F-2P-I-S)
 Doblo'	AIRBAG	1.2 8v	SIEMENS AirBag MY 99 (2F-4P-4L-2T-2I-S)
 Doblo'	AIRBAG	1.2 8v Bipower	AUTOLIV AirBag MY 99 (1F-2P)
 Doblo'	AIRBAG	1.2 8v Bipower	AUTOLIV AirBag MY 99 (2F-2P-2L-I)
 Doblo'	AIRBAG	1.2 8v Bipower	Autoliv AirBag MY 99 (2F-2P-I)
 Doblo'	AIRBAG	1.2 8v Bipower	SIEMENS AirBag MY 99 (2F-2P-2L-2T-2I-S)
 Doblo'	AIRBAG	1.2 8v Bipower	SIEMENS AirBag MY 99 (2F-2P-I-S)
 Doblo'	AIRBAG	1.2 8v Bipower	SIEMENS AirBag MY 99 (2F-4P-4L-2T-2I-S)
 Doblo'	AIRBAG	1.3 Multijet	AUTOLIV AirBag MY 99 (1F-2P)
 Doblo'	AIRBAG	1.3 Multijet	AUTOLIV AirBag MY 99 (2F-2P-2L-I)
 Doblo'	AIRBAG	1.3 Multijet	Autoliv AirBag MY 99 (2F-2P-I)
 Doblo'	AIRBAG	1.3 Multijet	SIEMENS AirBag MY 99 (2F-2P-2L-2T-2I-S)
 Doblo'	AIRBAG	1.3 Multijet	SIEMENS AirBag MY 99 (2F-2P-I-S)
 Doblo'	AIRBAG	1.3 Multijet	SIEMENS AirBag MY 99 (2F-4P-4L-2T-2I-S)
 Doblo'	AIRBAG	1.6 16v	AUTOLIV AirBag MY 99 (1F-2P)
 Doblo'	AIRBAG	1.6 16v	AUTOLIV AirBag MY 99 (2F-2P-2L-I)
 Doblo'	AIRBAG	1.6 16v	Autoliv AirBag MY 99 (2F-2P-I)
 Doblo'	AIRBAG	1.6 16v	SIEMENS AirBag MY 99 (2F-2P-2L-2T-2I-S)

## Systems supported by ECReader (up to V5.40)

### TRUCKS




























**Fiat**

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Doblo'	AIRBAG	1.6 16v	SIEMENS AirBag MY 99 (2F-2P-I-S)
 Doblo'	AIRBAG	1.6 16v	SIEMENS AirBag MY 99 (2F-4P-4L-2T-2I-S)
 Doblo'	AIRBAG	1.9 D	AUTOLIV AirBag MY 99 (1F-2P)
 Doblo'	AIRBAG	1.9 D	AUTOLIV AirBag MY 99 (2F-2P-2L-I)
 Doblo'	AIRBAG	1.9 D	Autoliv AirBag MY 99 (2F-2P-I)
 Doblo'	AIRBAG	1.9 D	SIEMENS AirBag MY 99 (2F-2P-2L-2T-2I-S)
 Doblo'	AIRBAG	1.9 D	SIEMENS AirBag MY 99 (2F-2P-I-S)
 Doblo'	AIRBAG	1.9 D	SIEMENS AirBag MY 99 (2F-4P-4L-2T-2I-S)
 Doblo'	AIRBAG	1.9 DS	AUTOLIV AirBag MY 99 (1F-2P)
 Doblo'	AIRBAG	1.9 DS	AUTOLIV AirBag MY 99 (2F-2P-2L-I)
 Doblo'	AIRBAG	1.9 DS	Autoliv AirBag MY 99 (2F-2P-I)
 Doblo'	AIRBAG	1.9 DS	SIEMENS AirBag MY 99 (2F-2P-2L-2T-2I-S)
 Doblo'	AIRBAG	1.9 DS	SIEMENS AirBag MY 99 (2F-2P-I-S)
 Doblo'	AIRBAG	1.9 DS	SIEMENS AirBag MY 99 (2F-4P-4L-2T-2I-S)
 Doblo'	AIRBAG	1.9 JTD	AUTOLIV AirBag MY 99 (1F-2P)
 Doblo'	AIRBAG	1.9 JTD	AUTOLIV AirBag MY 99 (2F-2P-2L-I)
 Doblo'	AIRBAG	1.9 JTD	Autoliv AirBag MY 99 (2F-2P-I)
 Doblo'	AIRBAG	1.9 JTD	SIEMENS AirBag MY 99 (2F-2P-2L-2T-2I-S)
 Doblo'	AIRBAG	1.9 JTD	SIEMENS AirBag MY 99 (2F-2P-I-S)
 Doblo'	AIRBAG	1.9 JTD	SIEMENS AirBag MY 99 (2F-4P-4L-2T-2I-S)
 Doblo'	AIRBAG	100 1.9 JTD	AUTOLIV AirBag MY 99 (1F-2P)
 Doblo'	AIRBAG	100 1.9 JTD	AUTOLIV AirBag MY 99 (2F-2P-2L-I)
 Doblo'	AIRBAG	100 1.9 JTD	Autoliv AirBag MY 99 (2F-2P-I)
 Doblo'	AIRBAG	100 1.9 JTD	SIEMENS AirBag MY 99 (2F-2P-2L-2T-2I-S)
 Doblo'	AIRBAG	100 1.9 JTD	SIEMENS AirBag MY 99 (2F-2P-I-S)
 Doblo'	AIRBAG	100 1.9 JTD	SIEMENS AirBag MY 99 (2F-4P-4L-2T-2I-S)
 Doblo'	AIRBAG	80 1.9 JTD	AUTOLIV AirBag MY 99 (1F-2P)

## Systems supported by ECReader (up to V5.40)

### TRUCKS




























**Fiat**

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Doblo'	AIRBAG	80 1.9 JTD	AUTOLIV AirBag MY 99 (2F-2P-2L-I)
 Doblo'	AIRBAG	80 1.9 JTD	Autoliv AirBag MY 99 (2F-2P-I)
 Doblo'	AIRBAG	80 1.9 JTD	SIEMENS AirBag MY 99 (2F-2P-2L-2T-2I-S)
 Doblo'	AIRBAG	80 1.9 JTD	SIEMENS AirBag MY 99 (2F-2P-I-S)
 Doblo'	AIRBAG	80 1.9 JTD	SIEMENS AirBag MY 99 (2F-4P-4L-2T-2I-S)
 Doblo'	CHASSIS NETWORK	1.2 16v	DELPHI/MARELLI Body Computer
 Doblo'	CHASSIS NETWORK	1.2 16v	Fiat CAN Info
 Doblo'	CHASSIS NETWORK	1.2 16v	Fiat Proxi Alignement
 Doblo'	CHASSIS NETWORK	1.2 8v	DELPHI/MARELLI Body Computer
 Doblo'	CHASSIS NETWORK	1.2 8v	Fiat CAN Info
 Doblo'	CHASSIS NETWORK	1.2 8v	Fiat Proxi Alignement
 Doblo'	CHASSIS NETWORK	1.2 8v (03-..)	DELPHI/MARELLI Body Computer
 Doblo'	CHASSIS NETWORK	1.2 8v Bipower	Fiat CAN Info
 Doblo'	CHASSIS NETWORK	1.2 8v Bipower (03-..)	DELPHI/MARELLI Body Computer
 Doblo'	CHASSIS NETWORK	1.2 8v Bipower (03-..)	Fiat Proxi Alignement
 Doblo'	CHASSIS NETWORK	1.3 Multijet	Fiat CAN Info
 Doblo'	CHASSIS NETWORK	1.3 Multijet (03-..)	DELPHI/MARELLI Body Computer
 Doblo'	CHASSIS NETWORK	1.3 Multijet (03-..)	Fiat Proxi Alignement
 Doblo'	CHASSIS NETWORK	1.6 16v	Fiat CAN Info
 Doblo'	CHASSIS NETWORK	1.6 16v (03-..)	DELPHI/MARELLI Body Computer
 Doblo'	CHASSIS NETWORK	1.6 16v (03-..)	Fiat Proxi Alignement
 Doblo'	CHASSIS NETWORK	1.9 D	DELPHI/MARELLI Body Computer
 Doblo'	CHASSIS NETWORK	1.9 D	Fiat CAN Info
 Doblo'	CHASSIS NETWORK	1.9 D	Fiat Proxi Alignement
 Doblo'	CHASSIS NETWORK	1.9 DS	Fiat CAN Info
 Doblo'	CHASSIS NETWORK	1.9 DS (03-..)	DELPHI/MARELLI Body Computer
 Doblo'	CHASSIS NETWORK	1.9 DS (03-..)	Fiat Proxi Alignement

## Systems supported by ECUREADER (up to V5.40)

### TRUCKS



























**Fiat**

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Doblo'	CHASSIS NETWORK	1.9 JTD	DELPHI/MARELLI Body Computer
 Doblo'	CHASSIS NETWORK	1.9 JTD	Fiat CAN Info
 Doblo'	CHASSIS NETWORK	1.9 JTD	Fiat Proxi Alignement
 Doblo'	CHASSIS NETWORK	1.9 JTD (03-..)	DELPHI/MARELLI Body Computer
 Doblo'	CHASSIS NETWORK	1.9 JTD (03-..)	Fiat Proxi Alignement
 Doblo'	CHASSIS NETWORK	100 1.9 JTD	DELPHI/MARELLI Body Computer
 Doblo'	CHASSIS NETWORK	100 1.9 JTD	Fiat CAN Info
 Doblo'	CHASSIS NETWORK	100 1.9 JTD	Fiat Proxi Alignement
 Doblo'	CHASSIS NETWORK	80 1.9 JTD	DELPHI/MARELLI Body Computer
 Doblo'	CHASSIS NETWORK	80 1.9 JTD	Fiat CAN Info
 Doblo'	CHASSIS NETWORK	80 1.9 JTD	Fiat Proxi Alignement
 Doblo'	DASHBOARD	1.2 16v	VEGLIA/MARELLI Dashboard
 Doblo'	DASHBOARD	1.2 8v	VEGLIA/MARELLI Dashboard
 Doblo'	DASHBOARD	1.2 8v Bipower	VEGLIA/MARELLI Dashboard
 Doblo'	DASHBOARD	1.3 Multijet	VEGLIA/MARELLI Dashboard
 Doblo'	DASHBOARD	1.6 16v	VEGLIA/MARELLI Dashboard
 Doblo'	DASHBOARD	1.9 D	VEGLIA/MARELLI Dashboard
 Doblo'	DASHBOARD	1.9 DS	VEGLIA/MARELLI Dashboard
 Doblo'	DASHBOARD	1.9 JTD	VEGLIA/MARELLI Dashboard
 Doblo'	DASHBOARD	100 1.9 JTD	VEGLIA/MARELLI Dashboard
 Doblo'	DASHBOARD	80 1.9 JTD	VEGLIA/MARELLI Dashboard
 Doblo'	DIESEL MANAGEMEN	1.9 D	LUCAS EPIC DCU3F
 Doblo'	ENGINE MANAGEME	1.2 8v	MARELLI IAW 49F/59F EOBD
 Doblo'	ENGINE MANAGEME	1.2 8v	MARELLI IAW 59F
 Doblo'	ENGINE MANAGEME	1.2 8v	MARELLI IAW 5AF
 Doblo'	ENGINE MANAGEME	1.2 8v (01-..)	EOBD
 Doblo'	ENGINE MANAGEME	1.3 Multijet	MARELLI 6JF CF3 Common Rail

## Systems supported by ECReader (up to V5.40)

### TRUCKS



























**Fiat**

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Doblo'	ENGINE MANAGEME	100 1.9 JTD (02-..)	BOSCH EDC 15 Common Rail (JTD '99)
 Doblo'	ENGINE MANAGEME	80 1.9 JTD	BOSCH EDC 15 Common Rail (JTD '99)
 Doblo'	KEY ENCODE	1.2 16v	DELPHI/MARELLI CODE Body Computer
 Doblo'	KEY ENCODE	1.2 8v	DELPHI/MARELLI CODE Body Computer
 Doblo'	KEY ENCODE	1.2 8v Bipower	DELPHI/MARELLI CODE Body Computer
 Doblo'	KEY ENCODE	1.3 Multijet	DELPHI/MARELLI CODE Body Computer
 Doblo'	KEY ENCODE	1.6 16v	DELPHI/MARELLI CODE Body Computer
 Doblo'	KEY ENCODE	1.9 D	DELPHI/MARELLI CODE Body Computer
 Doblo'	KEY ENCODE	1.9 DS	DELPHI/MARELLI CODE Body Computer
 Doblo'	KEY ENCODE	1.9 JTD	DELPHI/MARELLI CODE Body Computer
 Doblo'	KEY ENCODE	100 1.9 JTD	DELPHI/MARELLI CODE Body Computer
 Doblo'	KEY ENCODE	80 1.9 JTD	DELPHI/MARELLI CODE Body Computer
 Ducato 03	ABS	2.8 JTD	BOSCH ABS 5.3
 Ducato 03	ABS	2.8 JTD (03-..)	BOSCH ABS 5.3
 Ducato 03	AIRBAG	2.8 JTD	SIEMENS AirBag MY 99 (2F-2P-2L-I)
 Ducato 03	AIRBAG	2.8 JTD	SIEMENS AirBag MY 99 (2F-2P-I)
 Ducato 03	AIRBAG	2.8 JTD	SIEMENS AirBag MY 99 (2F-3P-I)
 Ducato 03	AIRBAG	2.8 JTD (03-..)	SIEMENS AirBag MY 99 (1F-2P)
 Ducato 03	AIRBAG	2.8 JTD (03-..)	SIEMENS AirBag MY 99 (1F-3P)
 Ducato 03	AIRBAG	2.8 JTD (03-..)	SIEMENS AirBag MY 99 (2F-2P-2L-I)
 Ducato 03	AIRBAG	2.8 JTD (03-..)	SIEMENS AirBag MY 99 (2F-2P-I)
 Ducato 03	AIRBAG	2.8 JTD (03-..)	SIEMENS AirBag MY 99 (2F-3P-I)
 Ducato 03	ENGINE MANAGEME	2.8 JTD (03-..)	BOSCH EDC 15 Common Rail (JTD '99)
 Ducato 03	IMMOBILIZER	2.8 JTD	DELPHI CODE 2
 Ducato 03	IMMOBILIZER	2.8 JTD (03-..)	DELPHI CODE 2
 Ducato 03	SERVICE LIGHT RES	2.8 JTD (03-..)	MANUAL

## Systems supported by ECUREADER (up to V5.40)

### TRUCKS




























**Fiat**

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Ducato 06	ABS	2.2 JTD	BOSCH ABS 8
 Ducato 06	ABS	2.3 JTD	BOSCH ABS 8
 Ducato 06	ABS	3.0 JTD	BOSCH ABS 8
 Ducato 06	AIRBAG	2.2 JTD	TRW SRS 1
 Ducato 06	AIRBAG	2.3 JTD	TRW SRS 1
 Ducato 06	AIRBAG	3.0 JTD	TRW SRS 1
 Ducato 06	CHASSIS NETWORK	2.2 JTD	MARELLI Body Computer 6
 Ducato 06	CHASSIS NETWORK	2.3 JTD	MARELLI Body Computer 6
 Ducato 06	CHASSIS NETWORK	3.0 JTD	MARELLI Body Computer 6
 Ducato 06	DASHBOARD	2.2 JTD	MARELLI Dashboard
 Ducato 06	DASHBOARD	2.3 JTD	MARELLI Dashboard
 Ducato 06	DASHBOARD	3.0 JTD	MARELLI Dashboard
 Ducato 06	ENGINE MANAGEME	2.2 JTD	VISTEON PUMA AUTODETECT
 Ducato 06	ENGINE MANAGEME	2.3 JTD	BOSCH EDC 16 Common Rail
 Ducato 06	ENGINE MANAGEME	3.0 JTD	BOSCH EDC 16 Common Rail
 Ducato 06	SERVICE LIGHT RES	2.2 JTD	MARELLI Dashboard
 Ducato 06	SERVICE LIGHT RES	2.3 JTD	MARELLI Dashboard
 Ducato 06	SERVICE LIGHT RES	3.0 JTD	MARELLI Dashboard
 Ducato 98	ABS	2.0 (98-..)	BOSCH ABS 5.3
 Ducato 98	ABS	2.0 JTD (98-..)	BOSCH ABS 5.3
 Ducato 98	ABS	2.3 JTD (98-..)	BOSCH ABS 5.3
 Ducato 98	ABS	2.8 JTD (98-..)	BOSCH ABS 5.3
 Ducato 98	ABS	Bipower-Gpower (98-..)	BOSCH ABS 5.3
 Ducato 98	AIRBAG	2.0	SIEMENS AirBag MY 99 (1F-2P)
 Ducato 98	AIRBAG	2.0	SIEMENS AirBag MY 99 (1F-3P)
 Ducato 98	AIRBAG	2.0	SIEMENS AirBag MY 99 (2F-2P-2L-I)

## Systems supported by ECReader (up to V5.40)

### TRUCKS



























**Fiat**

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Ducato 98	AIRBAG	2.0	SIEMENS AirBag MY 99 (2F-2P-I)
 Ducato 98	AIRBAG	2.0	SIEMENS AirBag MY 99 (2F-3P-I)
 Ducato 98	AIRBAG	2.0 JTD	SIEMENS AirBag MY 99 (1F-2P)
 Ducato 98	AIRBAG	2.0 JTD	SIEMENS AirBag MY 99 (1F-3P)
 Ducato 98	AIRBAG	2.0 JTD	SIEMENS AirBag MY 99 (2F-2P-2L-I)
 Ducato 98	AIRBAG	2.0 JTD	SIEMENS AirBag MY 99 (2F-2P-I)
 Ducato 98	AIRBAG	2.0 JTD	SIEMENS AirBag MY 99 (2F-3P-I)
 Ducato 98	AIRBAG	2.3 JTD	SIEMENS AirBag MY 99 (1F-2P)
 Ducato 98	AIRBAG	2.3 JTD	SIEMENS AirBag MY 99 (1F-3P)
 Ducato 98	AIRBAG	2.3 JTD	SIEMENS AirBag MY 99 (2F-2P-2L-I)
 Ducato 98	AIRBAG	2.3 JTD	SIEMENS AirBag MY 99 (2F-2P-I)
 Ducato 98	AIRBAG	2.3 JTD	SIEMENS AirBag MY 99 (2F-3P-I)
 Ducato 98	AIRBAG	2.8 JTD	SIEMENS AirBag MY 99 (1F-2P)
 Ducato 98	AIRBAG	2.8 JTD	SIEMENS AirBag MY 99 (1F-3P)
 Ducato 98	AIRBAG	2.8 JTD	SIEMENS AirBag MY 99 (2F-2P-2L-I)
 Ducato 98	AIRBAG	2.8 JTD	SIEMENS AirBag MY 99 (2F-2P-I)
 Ducato 98	AIRBAG	2.8 JTD	SIEMENS AirBag MY 99 (2F-3P-I)
 Ducato 98	AIRBAG	Bipower-Gpower	SIEMENS AirBag MY 99 (1F-2P)
 Ducato 98	AIRBAG	Bipower-Gpower	SIEMENS AirBag MY 99 (1F-3P)
 Ducato 98	AIRBAG	Bipower-Gpower	SIEMENS AirBag MY 99 (2F-2P-2L-I)
 Ducato 98	AIRBAG	Bipower-Gpower	SIEMENS AirBag MY 99 (2F-2P-I)
 Ducato 98	AIRBAG	Bipower-Gpower	SIEMENS AirBag MY 99 (2F-3P-I)
 Ducato 98	CENTRAL LOCKING	2.0	RF Bloccaporte/ricevitore VAS 97/3
 Ducato 98	CENTRAL LOCKING	2.0 JTD	RF Bloccaporte/ricevitore VAS 97/3
 Ducato 98	CENTRAL LOCKING	2.3 JTD	RF Bloccaporte/ricevitore VAS 97/3
 Ducato 98	CENTRAL LOCKING	2.8 JTD	RF Bloccaporte/ricevitore VAS 97/3
 Ducato 98	CENTRAL LOCKING	Bipower-Gpower	RF Bloccaporte/ricevitore VAS 97/3

## Systems supported by ECReader (up to V5.40)

### TRUCKS


























**Fiat**

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Ducato 98	ENGINE MANAGEME	2.0 JTD	BOSCH EDC 15 Common Rail (JTD '99)
 Ducato 98	ENGINE MANAGEME	2.3 JTD	BOSCH EDC 15 Common Rail (JTD '99)
 Ducato 98	ENGINE MANAGEME	2.8 JTD	BOSCH EDC 15 Common Rail (JTD '99)
 Ducato 98	IMMOBILIZER	2.0	DELPHI CODE 2
 Ducato 98	IMMOBILIZER	2.0 JTD	DELPHI CODE 2
 Ducato 98	IMMOBILIZER	2.3 JTD	DELPHI CODE 2
 Ducato 98	IMMOBILIZER	2.8 JTD	DELPHI CODE 2
 Ducato 98	IMMOBILIZER	Bipower-Gpower	DELPHI CODE 2
 Ducato 98	SERVICE LIGHT RES	2.0	MANUAL
 Ducato 98	SERVICE LIGHT RES	2.0 JTD	MANUAL
 Ducato 98	SERVICE LIGHT RES	2.3 JTD	MANUAL
 Ducato 98	SERVICE LIGHT RES	2.8 JTD	MANUAL
 Ducato 98	SERVICE LIGHT RES	Bipower-Gpower	MANUAL
 Ducato	ABS		BOSCH ABS 5.3
 Ducato	AIRBAG		BREED AirBag + Pret.
 Ducato	AIRBAG		BREED AirBag MY 97 (1F-2P)
 Fiorino 08	ABS + TRACT. CONT	1.3 Multijet 75cv	ABS BOSCH 8.1 AUTODETECT
 Fiorino 08	ABS + TRACT. CONT	1.3 Multijet 75cv (08-..)	BOSCH ESP 8
 Fiorino 08	ABS + TRACT. CONT	1.4 8v	ABS BOSCH 8.1 AUTODETECT
 Fiorino 08	ABS + TRACT. CONT	1.4 8v (08-..)	BOSCH ESP 8
 Fiorino 08	AIRBAG	1.3 Multijet 75cv	AUTOLIV AirBag CENTRAL AUTODETECT
 Fiorino 08	AIRBAG	1.3 Multijet 75cv (08-..)	TRW SRS EP
 Fiorino 08	AIRBAG	1.4 8v	AUTOLIV AirBag CENTRAL AUTODETECT
 Fiorino 08	AIRBAG	1.4 8v (08-..)	TRW SRS EP
 Fiorino 08	AUTOM. TRANSMISSI	1.3 Multijet 75cv	A/T MAP AUTODETECT
 Fiorino 08	AUTOM. TRANSMISSI	1.4 8v	A/T MAP AUTODETECT

## Systems supported by ECReader (up to V5.40)

### TRUCKS


























**Fiat**

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Fiorino 08	CHASSIS NETWORK	1.3 Multijet 75cv	Body Computer BSI AUTODETECT
 Fiorino 08	CHASSIS NETWORK	1.3 Multijet 75cv (08-..)	DELPHI Body Computer
 Fiorino 08	CHASSIS NETWORK	1.3 Multijet 75cv (08-..)	DELPHI Body Computer CAN Info
 Fiorino 08	CHASSIS NETWORK	1.3 Multijet 75cv (08-..)	DELPHI EP
 Fiorino 08	CHASSIS NETWORK	1.4 8v	Body Computer BSI AUTODETECT
 Fiorino 08	CHASSIS NETWORK	1.4 8v (08-..)	DELPHI Body Computer
 Fiorino 08	CHASSIS NETWORK	1.4 8v (08-..)	DELPHI Body Computer CAN Info
 Fiorino 08	CHASSIS NETWORK	1.4 8v (08-..)	DELPHI EP
 Fiorino 08	DASHBOARD	1.3 Multijet 75cv	AUTODETECT
 Fiorino 08	DASHBOARD	1.3 Multijet 75cv (08-..)	MARELLI Dashboard Comfort
 Fiorino 08	DASHBOARD	1.3 Multijet 75cv (08-..)	MARELLI Dashboard Modale
 Fiorino 08	DASHBOARD	1.4 8v	AUTODETECT
 Fiorino 08	DASHBOARD	1.4 8v (08-..)	MARELLI Dashboard Comfort
 Fiorino 08	DASHBOARD	1.4 8v (08-..)	MARELLI Dashboard Modale
 Fiorino 08	ENGINE MANAGEME	1.3 Multijet 75cv	BOSCH EDC16 C34 Common Rail AUTOD
 Fiorino 08	ENGINE MANAGEME	1.3 Multijet 75cv (08-..)	MARELLI IAW 6F3
 Fiorino 08	ENGINE MANAGEME	1.4 8v	BOSCH EDC16 C34 Common Rail AUTOD
 Fiorino 08	ENGINE MANAGEME	1.4 8v (08-..)	EOBD
 Fiorino 08	PARK.BRAKE	1.3 Multijet 75cv	AUTODETECT
 Fiorino 08	PARK.BRAKE	1.4 8v	AUTODETECT
 Fiorino	ELECTRONIC INJECTI	1.5 AT Kat	BOSCH MonoJetronic A2.2
 Fiorino	ELECTRONIC INJECTI	1.5 Kat	BOSCH MonoJetronic A2.2
 Fiorino	ENGINE MANAGEME	1.6 Kat	BOSCH MonoMotronic MA1.7
 Scudo 07	ABS + TRACT. CONT	1.6 JTD	BOSCH ABS 8.0 AUTODETECT
 Scudo 07	ABS + TRACT. CONT	1.6 JTD	BOSCH ABS 8.1 AUTODETECT
 Scudo 07	ABS + TRACT. CONT	1.6 JTD	BOSCH ESP 8.0 AUTODETECT

## Systems supported by ECUREADER (up to V5.40)

### TRUCKS




























**Fiat**

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Scudo 07	ABS + TRACT. CONT	1.6 JTD	BOSCH ESP 8.1 AUTODETECT
 Scudo 07	ABS + TRACT. CONT	2.0 16v	BOSCH ABS 8.0 AUTODETECT
 Scudo 07	ABS + TRACT. CONT	2.0 16v	BOSCH ABS 8.1 AUTODETECT
 Scudo 07	ABS + TRACT. CONT	2.0 16v	BOSCH ESP 8.0 AUTODETECT
 Scudo 07	ABS + TRACT. CONT	2.0 16v	BOSCH ESP 8.1 AUTODETECT
 Scudo 07	ABS + TRACT. CONT	2.0 JTD 16v	BOSCH ABS 8.0 AUTODETECT
 Scudo 07	ABS + TRACT. CONT	2.0 JTD 16v	BOSCH ABS 8.1 AUTODETECT
 Scudo 07	ABS + TRACT. CONT	2.0 JTD 16v	BOSCH ESP 8.0 AUTODETECT
 Scudo 07	ABS + TRACT. CONT	2.0 JTD 16v	BOSCH ESP 8.1 AUTODETECT
 Scudo 07	AIRBAG	1.6 JTD	AirBag CENTRAL AUTODETECT
 Scudo 07	AIRBAG	2.0 16v	AirBag CENTRAL AUTODETECT
 Scudo 07	AIRBAG	2.0 JTD 16v	AirBag CENTRAL AUTODETECT
 Scudo 07	ANTITHEFT	1.6 JTD	Alarm PSA2 AUTODETECT
 Scudo 07	ANTITHEFT	2.0 16v	Alarm PSA2 AUTODETECT
 Scudo 07	ANTITHEFT	2.0 JTD 16v	Alarm PSA2 AUTODETECT
 Scudo 07	AUX. HEATING	1.6 JTD	AUTODETECT
 Scudo 07	AUX. HEATING	2.0 16v	AUTODETECT
 Scudo 07	AUX. HEATING	2.0 JTD 16v	AUTODETECT
 Scudo 07	CHASSIS NETWORK	1.6 JTD	Body Computer BSI AUTODETECT
 Scudo 07	CHASSIS NETWORK	1.6 JTD	Body Computer BSM AUTODETECT
 Scudo 07	CHASSIS NETWORK	1.6 JTD	Body Computer BSR AUTODETECT
 Scudo 07	CHASSIS NETWORK	1.6 JTD	Body Computer Chassis AUTODETECT
 Scudo 07	CHASSIS NETWORK	2.0 16v	Body Computer BSI AUTODETECT
 Scudo 07	CHASSIS NETWORK	2.0 16v	Body Computer BSM AUTODETECT
 Scudo 07	CHASSIS NETWORK	2.0 16v	Body Computer BSR AUTODETECT
 Scudo 07	CHASSIS NETWORK	2.0 16v	Body Computer Chassis AUTODETECT
 Scudo 07	CHASSIS NETWORK	2.0 JTD 16v	Body Computer BSI AUTODETECT

## Systems supported by ECReader (up to V5.40)

### TRUCKS



























**Fiat**

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Scudo 07	CHASSIS NETWORK	2.0 JTD 16v	Body Computer BSM AUTODETECT
 Scudo 07	CHASSIS NETWORK	2.0 JTD 16v	Body Computer BSR AUTODETECT
 Scudo 07	CHASSIS NETWORK	2.0 JTD 16v	Body Computer Chassis AUTODETECT
 Scudo 07	CLIMA	1.6 JTD	CLIMA AUTODETECT
 Scudo 07	CLIMA	2.0 16v	CLIMA AUTODETECT
 Scudo 07	CLIMA	2.0 JTD 16v	CLIMA AUTODETECT
 Scudo 07	DASHBOARD	1.6 JTD	AUTODETECT
 Scudo 07	DASHBOARD	2.0 16v	AUTODETECT
 Scudo 07	DASHBOARD	2.0 JTD 16v	AUTODETECT
 Scudo 07	ELECTRIC STEERING	1.6 JTD	AUTODETECT
 Scudo 07	ELECTRIC STEERING	2.0 16v	AUTODETECT
 Scudo 07	ELECTRIC STEERING	2.0 JTD 16v	AUTODETECT
 Scudo 07	ENGINE MANAGEME	1.6 JTD	BOSCH EDC16 C34 Common Rail AUTOD
 Scudo 07	ENGINE MANAGEME	2.0 16v	MARELLI MM6KP AUTODETECT
 Scudo 07	ENGINE MANAGEME	2.0 JTD 16v	SIEMENS SID 803A Common Rail AUTOD
 Scudo 07	NAVIGATION	1.6 JTD	AUTODETECT
 Scudo 07	NAVIGATION	2.0 16v	AUTODETECT
 Scudo 07	NAVIGATION	2.0 JTD 16v	AUTODETECT
 Scudo 07	PARK.BRAKE	1.6 JTD	AUTODETECT
 Scudo 07	PARK.BRAKE	2.0 16v	AUTODETECT
 Scudo 07	PARK.BRAKE	2.0 JTD 16v	AUTODETECT
 Scudo 07	PHONE	1.6 JTD	AUTODETECT
 Scudo 07	PHONE	2.0 16v	AUTODETECT
 Scudo 07	PHONE	2.0 JTD 16v	AUTODETECT
 Scudo 07	RADIO / CD	1.6 JTD	AudioSystem AUTODETECT
 Scudo 07	RADIO / CD	1.6 JTD	CD Changer AUTODETECT
 Scudo 07	RADIO / CD	2.0 16v	AudioSystem AUTODETECT

## Systems supported by ECReader (up to V5.40)

### TRUCKS












Fiat

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Scudo 07	RADIO / CD	2.0 16v	CD Changer AUTODETECT
 Scudo 07	RADIO / CD	2.0 JTD 16v	AudioSystem AUTODETECT
 Scudo 07	RADIO / CD	2.0 JTD 16v	CD Changer AUTODETECT
 Scudo 07	RAIN-LUMINOSITY SE	1.6 JTD	AUTODETECT
 Scudo 07	RAIN-LUMINOSITY SE	2.0 16v	AUTODETECT
 Scudo 07	RAIN-LUMINOSITY SE	2.0 JTD 16v	AUTODETECT
 Scudo 07	REAR CLIMA	1.6 JTD	AUTODETECT
 Scudo 07	REAR CLIMA	2.0 16v	AUTODETECT
 Scudo 07	REAR CLIMA	2.0 JTD 16v	AUTODETECT
 Scudo 07	STEERING COLUMN	1.6 JTD	AUTODETECT
 Scudo 07	STEERING COLUMN	2.0 16v	AUTODETECT
 Scudo 07	STEERING COLUMN	2.0 JTD 16v	AUTODETECT
 Scudo 07	SUSPENSION CONTR	1.6 JTD	AUTODETECT
 Scudo 07	SUSPENSION CONTR	2.0 16v	AUTODETECT
 Scudo 07	SUSPENSION CONTR	2.0 JTD 16v	AUTODETECT
 Scudo 07	VISUAL./TELEMATICS	1.6 JTD	Display A+ AUTODETECT
 Scudo 07	VISUAL./TELEMATICS	1.6 JTD	Display C- AUTODETECT
 Scudo 07	VISUAL./TELEMATICS	2.0 16v	Display A+ AUTODETECT
 Scudo 07	VISUAL./TELEMATICS	2.0 16v	Display C- AUTODETECT
 Scudo 07	VISUAL./TELEMATICS	2.0 JTD 16v	Display A+ AUTODETECT
 Scudo 07	VISUAL./TELEMATICS	2.0 JTD 16v	Display C- AUTODETECT
 Scudo	ABS	1.6 Kat	BOSCH ABS ABR 5.3
 Scudo	ABS	1.9 D	BOSCH ABS ABR 5.3
 Scudo	ABS	1.9 TD	BOSCH ABS ABR 5.3
 Scudo	ABS	2.0 JTD	BOSCH ABS ABR 5.3
 Scudo	ABS	2.0 JTD FAP	BOSCH ABS ABR 5.3

## Systems supported by ECReader (up to V5.40)

### TRUCKS





Fiat

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Scudo	AIRBAG	1.9 D WJY	AUTOLIV AirBag CENTRAL ACU AUTODE
 Scudo	AUTOM. TRANSMISSI	1.9 TD DHX	A/T AL4 AUTODETECT
 Scudo	DIESEL MANAGEMEN	1.9 D WJY	LUCAS DCN2 AUTODETECT
 Scudo	DIESEL MANAGEMEN	1.9 D WJY (00-..)	LUCAS Diesel DCN2
 Scudo	DIESEL MANAGEMEN	1.9 TD	BOSCH AS3 VP20
 Scudo	ENGINE MANAGEME	1.6 Kat	BOSCH MonoMotronic MA1.7
 Scudo	ENGINE MANAGEME	2.0 JTD (.-99)	BOSCH EDC 15 C2 Common Rail
 Scudo	ENGINE MANAGEME	2.0 JTD 16v RHW	BOSCH EDC15 C2 Common Rail AUTODE
 Scudo	ENGINE MANAGEME	2.0 JTD RHT	BOSCH EDC 15 C2 Common Rail
 Scudo	ENGINE MANAGEME	2.0 JTD RHW	BOSCH EDC15 C2 Common Rail AUTODE
 Strada	DIESEL MANAGEMEN	1.9 D (99-..)	LUCAS EPIC DCU3F

## Systems supported by ECUreader (up to V5.40)

### TRUCKS



























Fliegl

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Trailers	BRAKE SYS. MANAG	Trailers	Wabco Trailer EBS
 Trailers	BRAKE SYS. MANAG	Trailers	Wabco Trailers EBS kw2000
 Trailers	BRAKE SYS. MANAG	Trailers Haldex	Haldex EBS EB+
 Trailers	BRAKE SYS. MANAG	Trailers Knorr	Knorr Trailer EBS

## Systems supported by ECReader (up to V5.40)

### TRUCKS




























Ford

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Courier	ENGINE MANAGEME	1.3 J4C (95-..)	FORD SEFI EEC-V
 Courier	ENGINE MANAGEME	1.3 J6B (...96)	FORD EFI EEC-IV
 Courier	ENGINE MANAGEME	1.4 FHA (95-..)	FORD SEFI EEC-V
 Tourneo	ENGINE MANAGEME	2.0 NGS (94-..)	FORD SEFI EEC-V
 Tourneo	ENGINE MANAGEME	2.0 NSF (94-..)	FORD SEFI EEC-V
 Transit	ABS	2.0	BOSCH ABS 5
 Transit	ABS	2.2 TDCi 110cv	BOSCH ABS 5
 Transit	ABS	2.2 TDCi 110cv (07-..)	ABS
 Transit	ABS	2.2 TDCi 140cv	BOSCH ABS 5
 Transit	ABS	2.2 TDCi 140cv (07-..)	ABS
 Transit	ABS	2.3	BOSCH ABS 5
 Transit	ABS	2.3 (07-..)	ABS
 Transit	ABS	2.4 TDCi 100cv	BOSCH ABS 5
 Transit	ABS	2.4 TDCi 100cv (07-..)	ABS
 Transit	ABS	2.4 TDCi 115cv	BOSCH ABS 5
 Transit	ABS	2.4 TDCi 115cv (07-..)	ABS
 Transit	ABS	2.4 TDCi 140cv	BOSCH ABS 5
 Transit	ABS	2.4 TDCi 140cv (07-..)	ABS
 Transit	ABS	2.4 TDDi	BOSCH ABS 5
 Transit	ABS	2.5 TD	BOSCH ABS 5
 Transit	ABS	3.2 TDCi 200cv	BOSCH ABS 5
 Transit	ABS	3.2 TDCi 200cv (07-..)	ABS
 Transit	AIRBAG	2.0 (...00)	FORD AirBag MANUAL
 Transit	AIRBAG	2.0 (...01)	FORD AirBag SRS
 Transit	AIRBAG	2.2 TDCi 110cv (...00)	FORD AirBag MANUAL
 Transit	AIRBAG	2.2 TDCi 110cv (...01)	FORD AirBag SRS

## Systems supported by ECReader (up to V5.40)

### TRUCKS




























Ford

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Transit	AIRBAG	2.2 TDCi 140cv (...00)	FORD AirBag MANUAL
 Transit	AIRBAG	2.2 TDCi 140cv (...01)	FORD AirBag SRS
 Transit	AIRBAG	2.3 (...00)	FORD AirBag MANUAL
 Transit	AIRBAG	2.3 (...01)	FORD AirBag SRS
 Transit	AIRBAG	2.4 TDCi 100cv (...00)	FORD AirBag MANUAL
 Transit	AIRBAG	2.4 TDCi 100cv (...01)	FORD AirBag SRS
 Transit	AIRBAG	2.4 TDCi 115cv (...00)	FORD AirBag MANUAL
 Transit	AIRBAG	2.4 TDCi 115cv (...01)	FORD AirBag SRS
 Transit	AIRBAG	2.4 TDCi 140cv (...00)	FORD AirBag MANUAL
 Transit	AIRBAG	2.4 TDCi 140cv (...01)	FORD AirBag SRS
 Transit	AIRBAG	2.4 TDDi (...00)	FORD AirBag MANUAL
 Transit	AIRBAG	2.4 TDDi (...01)	FORD AirBag SRS
 Transit	AIRBAG	2.5 TD (...00)	FORD AirBag MANUAL
 Transit	AIRBAG	2.5 TD (...01)	FORD AirBag SRS
 Transit	AIRBAG	3.2 TDCi 200cv (...00)	FORD AirBag MANUAL
 Transit	AIRBAG	3.2 TDCi 200cv (...01)	FORD AirBag SRS
 Transit	CHASSIS NETWORK	2.4 TDCi 100cv (07-..)	
 Transit	CHASSIS NETWORK	2.4 TDCi 115cv (07-..)	
 Transit	CHASSIS NETWORK	2.4 TDCi 140cv (07-..)	
 Transit	CHASSIS NETWORK	3.2 TDCi 200cv (07-..)	
 Transit	DASHBOARD	2.4 TDCi 100cv (07-..)	
 Transit	DASHBOARD	2.4 TDCi 115cv (07-..)	
 Transit	DASHBOARD	2.4 TDCi 140cv (07-..)	
 Transit	DASHBOARD	3.2 TDCi 200cv (07-..)	
 Transit	ENGINE MANAGEME	2.0 (97-..)	FORD SEFI EEC-V
 Transit	ENGINE MANAGEME	2.4 TDCi 100cv (07-..)	PCM
 Transit	ENGINE MANAGEME	2.4 TDCi 115cv (07-..)	PCM

## Systems supported by ECUREADER (up to V5.40)

### TRUCKS






**Ford**

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Transit	ENGINE MANAGEME	2.4 TDCi 140cv (07-..)	PCM
 Transit	ENGINE MANAGEME	2.4 TDDi DOFA (...01)	FORD Diesel - Duratorq-Di EEC-V
 Transit	ENGINE MANAGEME	2.5 TD (97-..)	FORD Diesel EEC-V
 Transit	KEY ENCODE	2.0 (...00)	FORD PATS MANUAL
 Transit	KEY ENCODE	2.0 (95-99)	FORD PATS MANUAL
 Transit	KEY ENCODE	2.2 TDCi 110cv (...00)	FORD PATS MANUAL
 Transit	KEY ENCODE	2.2 TDCi 110cv (95-99)	FORD PATS MANUAL
 Transit	KEY ENCODE	2.2 TDCi 140cv (...00)	FORD PATS MANUAL
 Transit	KEY ENCODE	2.2 TDCi 140cv (95-99)	FORD PATS MANUAL
 Transit	KEY ENCODE	2.3 (...00)	FORD PATS MANUAL
 Transit	KEY ENCODE	2.3 (95-99)	FORD PATS MANUAL
 Transit	KEY ENCODE	2.4 TDCi 100cv (...00)	FORD PATS MANUAL
 Transit	KEY ENCODE	2.4 TDCi 100cv (95-99)	FORD PATS MANUAL
 Transit	KEY ENCODE	2.4 TDCi 115cv (...00)	FORD PATS MANUAL
 Transit	KEY ENCODE	2.4 TDCi 115cv (95-99)	FORD PATS MANUAL
 Transit	KEY ENCODE	2.4 TDCi 140cv (...00)	FORD PATS MANUAL
 Transit	KEY ENCODE	2.4 TDCi 140cv (95-99)	FORD PATS MANUAL
 Transit	KEY ENCODE	2.4 TDDi (...00)	FORD PATS MANUAL
 Transit	KEY ENCODE	2.4 TDDi (95-99)	FORD PATS MANUAL
 Transit	KEY ENCODE	2.5 TD (...00)	FORD PATS MANUAL
 Transit	KEY ENCODE	2.5 TD (95-99)	FORD PATS MANUAL
 Transit	KEY ENCODE	3.2 TDCi 200cv (...00)	FORD PATS MANUAL
 Transit	KEY ENCODE	3.2 TDCi 200cv (95-99)	FORD PATS MANUAL
 Transit	SERVICE LIGHT RES	2.0 (00-..)	MANUAL
 Transit	SERVICE LIGHT RES	2.2 TDCi 110cv (00-..)	MANUAL
 Transit	SERVICE LIGHT RES	2.2 TDCi 140cv (00-..)	MANUAL
 Transit	SERVICE LIGHT RES	2.3 (00-..)	MANUAL

## Systems supported by ECUreader (up to V5.40)

### TRUCKS



Ford

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Transit	SERVICE LIGHT RES	2.4 TDCi 100cv (00-..)	MANUAL
 Transit	SERVICE LIGHT RES	2.4 TDCi 115cv (00-..)	MANUAL
 Transit	SERVICE LIGHT RES	2.4 TDCi 140cv (00-..)	MANUAL
 Transit	SERVICE LIGHT RES	2.4 TDDi (00-..)	MANUAL
 Transit	SERVICE LIGHT RES	2.5 TD (00-..)	MANUAL
 Transit	SERVICE LIGHT RES	3.2 TDCi 200cv (00-..)	MANUAL

## Systems supported by ECUREADER (up to V5.40)

### TRUCKS



### Frenos Camino

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Trailers	BRAKE SYS. MANAG	Trailers	Wabco Trailer EBS
 Trailers	BRAKE SYS. MANAG	Trailers	Wabco Trailer VCS II

## Systems supported by ECUREADER (up to V5.40)

### TRUCKS



Fruehauf

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Trailers	BRAKE SYS. MANAG	Trailers	Wabco Trailer EBS
 Trailers	BRAKE SYS. MANAG	Trailers	Wabco Trailer VCS II

## Systems supported by ECUREADER (up to V5.40)

### TRUCKS





**Galucho**

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Trailers	BRAKE SYS. MANAG	Trailers	Wabco Trailer EBS
 Trailers	BRAKE SYS. MANAG	Trailers	Wabco Trailer VCS II

## Systems supported by ECUreader (up to V5.40)

### TRUCKS





Goldhofer

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Trailers	BRAKE SYS. MANAG	Trailers	Wabco Trailers EBS
 Trailers	BRAKE SYS. MANAG	Trailers	Wabco Trailers EBS kw2000
 Trailers	BRAKE SYS. MANAG	Trailers Haldex	Haldex EBS EB+
 Trailers	BRAKE SYS. MANAG	Trailers Knorr	Knorr Trailer EBS

## Systems supported by ECUreader (up to V5.40)

### TRUCKS



### Gontrailer

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Trailers	BRAKE SYS. MANAG	Trailers	Wabco Trailers EBS
 Trailers	BRAKE SYS. MANAG	Trailers	Wabco Trailers EBS kw2000
 Trailers	BRAKE SYS. MANAG	Trailers Haldex	Haldex EBS EB+
 Trailers	BRAKE SYS. MANAG	Trailers Knorr	Knorr Trailer EBS

## Systems supported by ECUREADER (up to V5.40)

### TRUCKS

Guillen

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Trailers	BRAKE SYS. MANAG	Trailers	Wabco Trailer EBS
 Trailers	BRAKE SYS. MANAG	Trailers	Wabco Trailer VCS II

## Systems supported by ECUREADER (up to V5.40)

### TRUCKS

**Haldex**

**MODEL**

**SYSTEM TYPE**

**ENGINE / SYSTEM**

**ECU**



Trailers



BRAKE SYS. MANAG Trailers

Haldex EBS EB+

## Systems supported by ECUreader (up to V5.40)

### TRUCKS



**Hermanns**

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Trailers	BRAKE SYS. MANAG	Trailers	Wabco Trailer EBS
 Trailers	BRAKE SYS. MANAG	Trailers	Wabco Trailer VCS II

## Systems supported by ECUREADER (up to V5.40)

### TRUCKS






















Invepe

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Trailers	BRAKE SYS. MANAG	Trailers	Wabco Trailer EBS
 Trailers	BRAKE SYS. MANAG	Trailers	Wabco Trailer VCS II

## Systems supported by ECUreader (up to V5.40)

### TRUCKS

**IrisBus**

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 CityClass	ENGINE MANAGEME	Cursor	BOSCH EDC MS 6.2
 Domino	ENGINE MANAGEME	380	BOSCH EDC M7
 EuroClass HD	BRAKE SYS. MANAG	Cursor	Wabco EBS EURO
 EuroClass HD	ENGINE MANAGEME	Cursor	Bosch EDC MS 6.2
 EuroClass ND	BRAKE SYS. MANAG		Wabco EBS EURO
 Euroclass	ENGINE MANAGEME	380	BOSCH EDC M7
 Mini & Midi (Daily)	ABS + TRACT. CONT	8140 MiniBUS	Bosch ABS/ABD/EBD 5.3
 Mini & Midi (Daily)	ABS + TRACT. CONT	8140 ScuolaBUS	Bosch ABS/ABD/EBD 5.3
 Mini & Midi (Daily)	CLIMA	8140 MiniBUS	Marelli A/C Clima
 Mini & Midi (Daily)	CLIMA	8140 ScuolaBUS	Marelli A/C Clima
 Mini & Midi (Daily)	ENGINE MANAGEME	8140 MiniBUS	BOSCH EDC MS6.3
 Mini & Midi (Daily)	ENGINE MANAGEME	8140 ScuolaBUS	BOSCH EDC MS6.3
 Mini & Midi (Daily)	IMMOBILIZER	8140 MiniBUS	BOSCH
 Mini & Midi (Daily)	IMMOBILIZER	8140 ScuolaBUS	BOSCH
 My way	ENGINE MANAGEME	393	BOSCH EDC M7
 My way	ENGINE MANAGEME	393 E	BOSCH EDC M7
 My way	ENGINE MANAGEME	Cursor	BOSCH EDC MS 6.2
 Touring by ORLANDI (Daily)	ABS + TRACT. CONT	8140 MiniBUS	Bosch ABS/ABD/EBD 5.3
 Touring by ORLANDI (Daily)	CLIMA	8140 MiniBUS	Marelli A/C Clima
 Touring by ORLANDI (Daily)	ENGINE MANAGEME	8140 MiniBUS	BOSCH EDC MS6.3
 Touring by ORLANDI (Daily)	IMMOBILIZER	8140 MiniBUS	BOSCH

## Systems supported by ECReader (up to V5.40)

### TRUCKS




























Iveco

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Daily & TurboDaily	ABS + TRACT. CONT	29 L 10 FIAE0481A	BOSCH ABS/ABD/EBD 5.3
 Daily & TurboDaily	ABS + TRACT. CONT	29 L 11 8140	BOSCH ABS/ABD/EBD 5.3
 Daily & TurboDaily	ABS + TRACT. CONT	29 L 12 FIAE0481B	BOSCH ABS/ABD/EBD 5.3
 Daily & TurboDaily	ABS + TRACT. CONT	29 L 9 8140	BOSCH ABS/ABD/EBD 5.3
 Daily & TurboDaily	ABS + TRACT. CONT	35 C 10 FIAE0481A	BOSCH ABS/ABD/EBD 5.3
 Daily & TurboDaily	ABS + TRACT. CONT	35 C 11 8140	BOSCH ABS/ABD/EBD 5.3
 Daily & TurboDaily	ABS + TRACT. CONT	35 C 12 FIAE0481B	BOSCH ABS/ABD/EBD 5.3
 Daily & TurboDaily	ABS + TRACT. CONT	35 C 13 8140	BOSCH ABS/ABD/EBD 5.3
 Daily & TurboDaily	ABS + TRACT. CONT	35 C 9 8140	BOSCH ABS/ABD/EBD 5.3
 Daily & TurboDaily	ABS + TRACT. CONT	35 L 9 8140	BOSCH ABS/ABD/EBD 5.3
 Daily & TurboDaily	ABS + TRACT. CONT	35 S 11 8140	BOSCH ABS/ABD/EBD 5.3
 Daily & TurboDaily	ABS + TRACT. CONT	35 S 12 FIAE0481B	BOSCH ABS/ABD/EBD 5.3
 Daily & TurboDaily	ABS + TRACT. CONT	35 S 13 8140	BOSCH ABS/ABD/EBD 5.3
 Daily & TurboDaily	ABS + TRACT. CONT	40 C 10 FIAE0481A	BOSCH ABS/ABD/EBD 5.3
 Daily & TurboDaily	ABS + TRACT. CONT	40 C 11 8140	BOSCH ABS/ABD/EBD 5.3
 Daily & TurboDaily	ABS + TRACT. CONT	40 C 12 FIAE0481B	BOSCH ABS/ABD/EBD 5.3
 Daily & TurboDaily	ABS + TRACT. CONT	40 C 13 8140	BOSCH ABS/ABD/EBD 5.3
 Daily & TurboDaily	ABS + TRACT. CONT	40 C 9 8140	BOSCH ABS/ABD/EBD 5.3
 Daily & TurboDaily	ABS + TRACT. CONT	65 C 15 8140	BOSCH ABS/ABD/EBD 5.3
 Daily & TurboDaily	AIRBAG	2.3 HPI 16v	ALLIED AirBag MY 97 (2F-2P)
 Daily & TurboDaily	AIRBAG	2.3 Unijet	ALLIED AirBag MY 97 (2F-2P)
 Daily & TurboDaily	AIRBAG	2.8 Unijet	ALLIED AirBag MY 97 (2F-2P)
 Daily & TurboDaily	AIRBAG	29 L 10	ALLIED AirBag MY 97 (2F-2P)
 Daily & TurboDaily	AIRBAG	29 L 11	ALLIED AirBag MY 97 (2F-2P)
 Daily & TurboDaily	AIRBAG	29 L 12	ALLIED AirBag MY 97 (2F-2P)
 Daily & TurboDaily	AIRBAG	29 L 9	ALLIED AirBag MY 97 (2F-2P)
 Daily & TurboDaily	AIRBAG	35 C 10	ALLIED AirBag MY 97 (2F-2P)

## Systems supported by ECReader (up to V5.40)

### TRUCKS






Iveco

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Daily & TurboDaily	AIRBAG	35 C 11	ALLIED AirBag MY 97 (2F-2P)
 Daily & TurboDaily	AIRBAG	35 C 12	ALLIED AirBag MY 97 (2F-2P)
 Daily & TurboDaily	AIRBAG	35 C 13	ALLIED AirBag MY 97 (2F-2P)
 Daily & TurboDaily	AIRBAG	35 C 9	ALLIED AirBag MY 97 (2F-2P)
 Daily & TurboDaily	AIRBAG	35 L 9	ALLIED AirBag MY 97 (2F-2P)
 Daily & TurboDaily	AIRBAG	35 S 11	ALLIED AirBag MY 97 (2F-2P)
 Daily & TurboDaily	AIRBAG	35 S 12	ALLIED AirBag MY 97 (2F-2P)
 Daily & TurboDaily	AIRBAG	35 S 13	ALLIED AirBag MY 97 (2F-2P)
 Daily & TurboDaily	AIRBAG	40 C 10	ALLIED AirBag MY 97 (2F-2P)
 Daily & TurboDaily	AIRBAG	40 C 11	ALLIED AirBag MY 97 (2F-2P)
 Daily & TurboDaily	AIRBAG	40 C 12	ALLIED AirBag MY 97 (2F-2P)
 Daily & TurboDaily	AIRBAG	40 C 13	ALLIED AirBag MY 97 (2F-2P)
 Daily & TurboDaily	AIRBAG	40 C 9	ALLIED AirBag MY 97 (2F-2P)
 Daily & TurboDaily	AIRBAG	65 C 15	ALLIED AirBag MY 97 (2F-2P)
 Daily & TurboDaily	CLIMA	2.3 HPI 16v (...02)	Marelli A/C Clima
 Daily & TurboDaily	CLIMA	2.3 Unijet (...02)	Marelli A/C Clima
 Daily & TurboDaily	CLIMA	2.3 Unijet (02-05)	Marelli
 Daily & TurboDaily	CLIMA	2.8 Unijet (...02)	Marelli A/C Clima
 Daily & TurboDaily	CLIMA	2.8 Unijet (02-05)	Marelli
 Daily & TurboDaily	CLIMA	29 L 10 (...02)	Marelli A/C Clima
 Daily & TurboDaily	CLIMA	29 L 11 (...02)	Marelli A/C Clima
 Daily & TurboDaily	CLIMA	29 L 12 (...02)	Marelli A/C Clima
 Daily & TurboDaily	CLIMA	29 L 9 (...02)	Marelli A/C Clima
 Daily & TurboDaily	CLIMA	35 C 10 (...02)	Marelli A/C Clima
 Daily & TurboDaily	CLIMA	35 C 11 (...02)	Marelli A/C Clima
 Daily & TurboDaily	CLIMA	35 C 12 (...02)	Marelli A/C Clima
 Daily & TurboDaily	CLIMA	35 C 13 (...02)	Marelli A/C Clima

## Systems supported by ECUREADER (up to V5.40)

### TRUCKS




























Iveco

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Daily & TurboDaily	CLIMA	35 C 9 (...02)	Marelli A/C Clima
 Daily & TurboDaily	CLIMA	35 L 9 (...02)	Marelli A/C Clima
 Daily & TurboDaily	CLIMA	35 S 11 (...02)	Marelli A/C Clima
 Daily & TurboDaily	CLIMA	35 S 12 (...02)	Marelli A/C Clima
 Daily & TurboDaily	CLIMA	35 S 13 (...02)	Marelli A/C Clima
 Daily & TurboDaily	CLIMA	40 C 10 (...02)	Marelli A/C Clima
 Daily & TurboDaily	CLIMA	40 C 11 (...02)	Marelli A/C Clima
 Daily & TurboDaily	CLIMA	40 C 12 (...02)	Marelli A/C Clima
 Daily & TurboDaily	CLIMA	40 C 13 (...02)	Marelli A/C Clima
 Daily & TurboDaily	CLIMA	40 C 9 (...02)	Marelli A/C Clima
 Daily & TurboDaily	CLIMA	65 C 15 (...02)	Marelli A/C Clima
 Daily & TurboDaily	ENGINE MANAGEME	2.3 HPI 16v F1AE0481A	BOSCH EDC 16 Common Rail
 Daily & TurboDaily	ENGINE MANAGEME	2.3 HPI 16v F1AE0481B	BOSCH EDC 16 Common Rail
 Daily & TurboDaily	ENGINE MANAGEME	2.3 Unijet (02-06)	BOSCH EDC MS6.3
 Daily & TurboDaily	ENGINE MANAGEME	2.8 Unijet 8140 (00-04)	BOSCH EDC MS6.3
 Daily & TurboDaily	IMMOBILIZER	2.3 HPI 16v	BOSCH
 Daily & TurboDaily	IMMOBILIZER	2.3 Unijet	BOSCH
 Daily & TurboDaily	IMMOBILIZER	2.3 Unijet	BOSCH
 Daily & TurboDaily	IMMOBILIZER	2.8 Unijet	BOSCH
 Daily & TurboDaily	IMMOBILIZER	29 L 10	BOSCH
 Daily & TurboDaily	IMMOBILIZER	29 L 11	BOSCH
 Daily & TurboDaily	IMMOBILIZER	29 L 12	BOSCH
 Daily & TurboDaily	IMMOBILIZER	29 L 9	BOSCH
 Daily & TurboDaily	IMMOBILIZER	35 C 10	BOSCH
 Daily & TurboDaily	IMMOBILIZER	35 C 11	BOSCH
 Daily & TurboDaily	IMMOBILIZER	35 C 12	BOSCH
 Daily & TurboDaily	IMMOBILIZER	35 C 13	BOSCH

## Systems supported by ECReader (up to V5.40)

### TRUCKS



























Iveco

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Daily & TurboDaily	IMMOBILIZER	35 C 9	BOSCH
 Daily & TurboDaily	IMMOBILIZER	35 L 9	BOSCH
 Daily & TurboDaily	IMMOBILIZER	35 S 11	BOSCH
 Daily & TurboDaily	IMMOBILIZER	35 S 12	BOSCH
 Daily & TurboDaily	IMMOBILIZER	35 S 13	BOSCH
 Daily & TurboDaily	IMMOBILIZER	40 C 10	BOSCH
 Daily & TurboDaily	IMMOBILIZER	40 C 11	BOSCH
 Daily & TurboDaily	IMMOBILIZER	40 C 12	BOSCH
 Daily & TurboDaily	IMMOBILIZER	40 C 13	BOSCH
 Daily & TurboDaily	IMMOBILIZER	40 C 9	BOSCH
 Daily & TurboDaily	IMMOBILIZER	65 C 15	BOSCH
 Daily & TurboDaily	KEY ENCODE	2.3 HPI 16v	BOSCH CODE
 Daily & TurboDaily	KEY ENCODE	2.3 Unijet	BOSCH CODE
 Daily & TurboDaily	KEY ENCODE	2.8 Unijet	BOSCH CODE
 Daily & TurboDaily	KEY ENCODE	29 L 10	BOSCH CODE
 Daily & TurboDaily	KEY ENCODE	29 L 11	BOSCH CODE
 Daily & TurboDaily	KEY ENCODE	29 L 12	BOSCH CODE
 Daily & TurboDaily	KEY ENCODE	29 L 9	BOSCH CODE
 Daily & TurboDaily	KEY ENCODE	35 C 10	BOSCH CODE
 Daily & TurboDaily	KEY ENCODE	35 C 11	BOSCH CODE
 Daily & TurboDaily	KEY ENCODE	35 C 12	BOSCH CODE
 Daily & TurboDaily	KEY ENCODE	35 C 13	BOSCH CODE
 Daily & TurboDaily	KEY ENCODE	35 C 9	BOSCH CODE
 Daily & TurboDaily	KEY ENCODE	35 L 9	BOSCH CODE
 Daily & TurboDaily	KEY ENCODE	35 S 11	BOSCH CODE
 Daily & TurboDaily	KEY ENCODE	35 S 12	BOSCH CODE
 Daily & TurboDaily	KEY ENCODE	35 S 13	BOSCH CODE

## Systems supported by ECUreader (up to V5.40)

### TRUCKS



























Iveco

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Daily & TurboDaily	KEY ENCODE	40 C 10	BOSCH CODE
 Daily & TurboDaily	KEY ENCODE	40 C 11	BOSCH CODE
 Daily & TurboDaily	KEY ENCODE	40 C 12	BOSCH CODE
 Daily & TurboDaily	KEY ENCODE	40 C 13	BOSCH CODE
 Daily & TurboDaily	KEY ENCODE	40 C 9	BOSCH CODE
 Daily & TurboDaily	KEY ENCODE	65 C 15	BOSCH CODE
 EuroCargo	ABS	Euro 2/3	BOSCH/KNORR ABS 2X
 EuroCargo	ABS	Euro 4/5	BOSCH/KNORR ABS 2X
 EuroCargo	ABS + TRACT. CONT	Euro 2/3	BOSCH ABS/ASR/SL P4 Full Air
 EuroCargo	ABS + TRACT. CONT	Euro 2/3	WABCO ABS/ASR/EBS C3
 EuroCargo	AUX. HEATING	Euro 4/5	Webasto Airmatic
 EuroCargo	CAN LANES TEST	Euro 4/5	
 EuroCargo	CHASSIS MANAGEME	Euro 4/5	
 EuroCargo	CHASSIS NETWORK	Euro 4/5	Body Computer
 EuroCargo	CHASSIS NETWORK	Euro 4/5	VDO Body Controller
 EuroCargo	DASHBOARD	Euro 4/5	VDO Instrument Cluster
 EuroCargo	DASHBOARD	Euro 4/5	VDO Instrument Cluster Can
 EuroCargo	DIESEL ADDITION	Euro 4/5	DeNoxtronic 2
 EuroCargo	EMERGENCY START	Euro 2/3	
 EuroCargo	EMERGENCY START	Euro 4/5	
 EuroCargo	ENGINE MANAGEME	Euro 2/3	BOSCH EDC 7 Tector
 EuroCargo	ENGINE MANAGEME	Euro 4/5	BOSCH EDC 7 Tector
 EuroCargo	ENGINE MANAGEME	Euro 4/5	BOSCH EDC 7 UC-31
 EuroCargo	IMMOBILIZER	Euro 4/5	VCM Immobilizer
 EuroCargo	SUSPENSION CONTR	Euro 2/3	WABCO ECAS F. P. + CAN
 EuroCargo	SUSPENSION CONTR	Euro 4/5	WABCO ECAS CAN

## Systems supported by ECUreader (up to V5.40)

### TRUCKS



























Iveco

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 EuroFire	ABS + TRACT. CONT		BOSCH ABS/ASR/SL P4 Full Air
 EuroFire	ABS + TRACT. CONT		WABCO ABS/ASR/EBS C3
 EuroFire	ENGINE MANAGEME		BOSCH EDC 7
 EuroFire	SUSPENSION CONTR		WABCO ECAS Full Pneumatic
 EuroFire	SUSPENSION CONTR		WABCO ECAS Pneumatic
 EuroMover	ABS + TRACT. CONT	Cursor 10	WABCO ABS/ASR/EBS C3
 EuroMover	ENGINE MANAGEME	Cursor 10 F3AE0681A	BOSCH EDC MS 6.2
 EuroMover	ENGINE MANAGEME	Cursor 10 F3AE0681B	BOSCH EDC MS 6.2
 EuroMover	ENGINE MANAGEME	Cursor 10 F3AE0681D	BOSCH EDC MS 6.2
 EuroMover	ENGINE MANAGEME	Cursor 10 F3AE0681E	BOSCH EDC MS 6.2
 EuroMover	ENGINE MANAGEME	Cursor 10 F3AE0681H	BOSCH EDC MS 6.2
 EuroMover	GEARBOX MANAGEM	Cursor 10	Eurotronic 2
 EuroMover	SUSPENSION CONTR	Cursor 10	WABCO ECAS Full Pneumatic
 EuroMover	SUSPENSION CONTR	Cursor 10	WABCO ECAS Pneumatic
 EuroStar	ABS	180 E 38	WABCO ABS E
 EuroStar	ABS	190 E 38	WABCO ABS E
 EuroStar	ABS	240 E 38	WABCO ABS E
 EuroStar	ABS	260 E 38	WABCO ABS E
 EuroStar	ABS	360 E 38	WABCO ABS E
 EuroStar	ABS	400 E 38	WABCO ABS E
 EuroStar	ABS	470 E 38	WABCO ABS E
 EuroStar	ABS	Cursor 10	WABCO ABS E
 EuroStar	ABS + TRACT. CONT	180 E 38	BOSCH ABS/ASR/SL P4 Full Air
 EuroStar	ABS + TRACT. CONT	180 E 38	WABCO ABS/ASR/EBS C3
 EuroStar	ABS + TRACT. CONT	190 E 38	BOSCH ABS/ASR/SL P4 Full Air
 EuroStar	ABS + TRACT. CONT	190 E 38	WABCO ABS/ASR/EBS C3

## Systems supported by ECUREADER (up to V5.40)

### TRUCKS
















Iveco

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 EuroStar	ABS + TRACT. CONT	240 E 38	BOSCH ABS/ASR/SL P4 Full Air
 EuroStar	ABS + TRACT. CONT	240 E 38	WABCO ABS/ASR/EBS C3
 EuroStar	ABS + TRACT. CONT	260 E 38	BOSCH ABS/ASR/SL P4 Full Air
 EuroStar	ABS + TRACT. CONT	260 E 38	WABCO ABS/ASR/EBS C3
 EuroStar	ABS + TRACT. CONT	360 E 38	BOSCH ABS/ASR/SL P4 Full Air
 EuroStar	ABS + TRACT. CONT	360 E 38	WABCO ABS/ASR/EBS C3
 EuroStar	ABS + TRACT. CONT	400 E 38	BOSCH ABS/ASR/SL P4 Full Air
 EuroStar	ABS + TRACT. CONT	400 E 38	WABCO ABS/ASR/EBS C3
 EuroStar	ABS + TRACT. CONT	470 E 38	BOSCH ABS/ASR/SL P4 Full Air
 EuroStar	ABS + TRACT. CONT	470 E 38	WABCO ABS/ASR/EBS C3
 EuroStar	ABS + TRACT. CONT	Cursor 10	BOSCH ABS/ASR/SL P4 Full Air
 EuroStar	ABS + TRACT. CONT	Cursor 10	WABCO ABS/ASR/EBS C3
 EuroStar	BRAKE POWER SUP	180 E 38	ZF Intarder no CAN
 EuroStar	BRAKE POWER SUP	190 E 38	ZF Intarder no CAN
 EuroStar	BRAKE POWER SUP	240 E 38	ZF Intarder no CAN
 EuroStar	BRAKE POWER SUP	260 E 38	ZF Intarder no CAN
 EuroStar	BRAKE POWER SUP	360 E 38	ZF Intarder no CAN
 EuroStar	BRAKE POWER SUP	400 E 38	ZF Intarder no CAN
 EuroStar	BRAKE POWER SUP	470 E 38	ZF Intarder no CAN
 EuroStar	BRAKE POWER SUP	Cursor 10	ZF Intarder no CAN
 EuroStar	BRAKE SYS. MANAG	180 E 38	WABCO EBS EURO
 EuroStar	BRAKE SYS. MANAG	190 E 38	WABCO EBS EURO
 EuroStar	BRAKE SYS. MANAG	240 E 38	WABCO EBS EURO
 EuroStar	BRAKE SYS. MANAG	260 E 38	WABCO EBS EURO
 EuroStar	BRAKE SYS. MANAG	360 E 38	WABCO EBS EURO
 EuroStar	BRAKE SYS. MANAG	400 E 38	WABCO EBS EURO
 EuroStar	BRAKE SYS. MANAG	470 E 38	WABCO EBS EURO

## Systems supported by ECUreader (up to V5.40)

### TRUCKS



























Iveco

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 EuroStar	BRAKE SYS. MANAG	Cursor 10	WABCO EBS EURO
 EuroStar	EMERGENCY START	Cursor 10 F3AE0681A	BOSCH EDC MS 6.2
 EuroStar	EMERGENCY START	Cursor 10 F3AE0681B	BOSCH EDC MS 6.2
 EuroStar	EMERGENCY START	Cursor 10 F3AE0681D	BOSCH EDC MS 6.2
 EuroStar	EMERGENCY START	Cursor 10 F3AE0681E	BOSCH EDC MS 6.2
 EuroStar	EMERGENCY START	Cursor 10 F3AE0681H	BOSCH EDC MS 6.2
 EuroStar	ENGINE MANAGEME	180 E 38	BOSCH EDC M7
 EuroStar	ENGINE MANAGEME	190 E 38	BOSCH EDC M7
 EuroStar	ENGINE MANAGEME	240 E 38	BOSCH EDC M7
 EuroStar	ENGINE MANAGEME	260 E 38	BOSCH EDC M7
 EuroStar	ENGINE MANAGEME	360 E 38	BOSCH EDC M7
 EuroStar	ENGINE MANAGEME	400 E 38	BOSCH EDC M7
 EuroStar	ENGINE MANAGEME	470 E 38	BOSCH EDC M7
 EuroStar	ENGINE MANAGEME	Cursor 10 F3AE0681A	BOSCH EDC MS 6.2
 EuroStar	ENGINE MANAGEME	Cursor 10 F3AE0681B	BOSCH EDC MS 6.2
 EuroStar	ENGINE MANAGEME	Cursor 10 F3AE0681D	BOSCH EDC MS 6.2
 EuroStar	ENGINE MANAGEME	Cursor 10 F3AE0681E	BOSCH EDC MS 6.2
 EuroStar	ENGINE MANAGEME	Cursor 10 F3AE0681H	BOSCH EDC MS 6.2
 EuroStar	GEARBOX MANAGEM	180 E 38	Eurotronic 2
 EuroStar	GEARBOX MANAGEM	190 E 38	Eurotronic 2
 EuroStar	GEARBOX MANAGEM	240 E 38	Eurotronic 2
 EuroStar	GEARBOX MANAGEM	260 E 38	Eurotronic 2
 EuroStar	GEARBOX MANAGEM	360 E 38	Eurotronic 2
 EuroStar	GEARBOX MANAGEM	400 E 38	Eurotronic 2
 EuroStar	GEARBOX MANAGEM	470 E 38	Eurotronic 2
 EuroStar	GEARBOX MANAGEM	Cursor 10	Eurotronic 2
 EuroStar	IMMOBILIZER	180 E 38	MANUAL

## Systems supported by ECUreader (up to V5.40)

### TRUCKS




























Iveco

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 EuroStar	IMMOBILIZER	190 E 38	MANUAL
 EuroStar	IMMOBILIZER	240 E 38	MANUAL
 EuroStar	IMMOBILIZER	260 E 38	MANUAL
 EuroStar	IMMOBILIZER	360 E 38	MANUAL
 EuroStar	IMMOBILIZER	400 E 38	MANUAL
 EuroStar	IMMOBILIZER	470 E 38	MANUAL
 EuroStar	IMMOBILIZER	Cursor 10	MANUAL
 EuroStar	SUSPENSION CONTR	180 E 38	WABCO ECAS Pneumatic
 EuroStar	SUSPENSION CONTR	190 E 38	WABCO ECAS Pneumatic
 EuroStar	SUSPENSION CONTR	240 E 38	WABCO ECAS Pneumatic
 EuroStar	SUSPENSION CONTR	260 E 38	WABCO ECAS Pneumatic
 EuroStar	SUSPENSION CONTR	360 E 38	WABCO ECAS Pneumatic
 EuroStar	SUSPENSION CONTR	400 E 38	WABCO ECAS Pneumatic
 EuroStar	SUSPENSION CONTR	470 E 38	WABCO ECAS Pneumatic
 EuroStar	SUSPENSION CONTR	Cursor 10	WABCO ECAS Pneumatic
 EuroTech	ABS + TRACT. CONT	180 E 38	Bosch ABS/ASR/SL P4 Full Air
 EuroTech	ABS + TRACT. CONT	180 E 38	Knorr ABS
 EuroTech	ABS + TRACT. CONT	180 E 38	WABCO ABS/ASR/EBS C3
 EuroTech	ABS + TRACT. CONT	180 E 38	WABCO EBS EURO
 EuroTech	ABS + TRACT. CONT	190 E 38	Bosch ABS/ASR/SL P4 Full Air
 EuroTech	ABS + TRACT. CONT	190 E 38	Knorr ABS
 EuroTech	ABS + TRACT. CONT	190 E 38	WABCO ABS/ASR/EBS C3
 EuroTech	ABS + TRACT. CONT	190 E 38	WABCO EBS EURO
 EuroTech	ABS + TRACT. CONT	240 E 38	Bosch ABS/ASR/SL P4 Full Air
 EuroTech	ABS + TRACT. CONT	240 E 38	Knorr ABS
 EuroTech	ABS + TRACT. CONT	240 E 38	WABCO ABS/ASR/EBS C3

## Systems supported by ECUREADER (up to V5.40)

### TRUCKS




























Iveco

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 EuroTech	ABS + TRACT. CONT	240 E 38	WABCO EBS EURO
 EuroTech	ABS + TRACT. CONT	Cursor 10	Bosch ABS/ASR/SL P4 Full Air
 EuroTech	ABS + TRACT. CONT	Cursor 10	Knorr ABS
 EuroTech	ABS + TRACT. CONT	Cursor 10	WABCO ABS/ASR/EBS C3
 EuroTech	ABS + TRACT. CONT	Cursor 10	WABCO EBS EURO
 EuroTech	ABS + TRACT. CONT	Cursor 13	Bosch ABS/ASR/SL P4 Full Air
 EuroTech	ABS + TRACT. CONT	Cursor 13	Knorr ABS
 EuroTech	ABS + TRACT. CONT	Cursor 13	WABCO ABS/ASR/EBS C3
 EuroTech	ABS + TRACT. CONT	Cursor 13	WABCO EBS EURO
 EuroTech	ABS + TRACT. CONT	Cursor 8	Bosch ABS/ASR/SL P4 Full Air
 EuroTech	ABS + TRACT. CONT	Cursor 8	Knorr ABS
 EuroTech	ABS + TRACT. CONT	Cursor 8	WABCO ABS/ASR/EBS C3
 EuroTech	ABS + TRACT. CONT	Cursor 8	WABCO EBS EURO
 EuroTech	BRAKE POWER SUP	180 E 38	ZF Intarder no CAN
 EuroTech	BRAKE POWER SUP	190 E 38	ZF Intarder no CAN
 EuroTech	BRAKE POWER SUP	240 E 38	ZF Intarder no CAN
 EuroTech	BRAKE POWER SUP	Cursor 10	ZF Intarder no CAN
 EuroTech	BRAKE POWER SUP	Cursor 13	ZF Intarder no CAN
 EuroTech	BRAKE POWER SUP	Cursor 8	ZF Intarder no CAN
 EuroTech	EMERGENCY START	Cursor 10 F3AE0681A	BOSCH EDC MS 6.2
 EuroTech	EMERGENCY START	Cursor 10 F3AE0681B	BOSCH EDC MS 6.2
 EuroTech	EMERGENCY START	Cursor 10 F3AE0681D	BOSCH EDC MS 6.2
 EuroTech	EMERGENCY START	Cursor 10 F3AE0681E	BOSCH EDC MS 6.2
 EuroTech	EMERGENCY START	Cursor 10 F3AE0681H	BOSCH EDC MS 6.2
 EuroTech	EMERGENCY START	Cursor 13 F3BE0681C	BOSCH EDC MS 6.2
 EuroTech	EMERGENCY START	Cursor 13 F3BE0681D	BOSCH EDC MS 6.2
 EuroTech	EMERGENCY START	Cursor 13 F3BE0681E	BOSCH EDC MS 6.2

## Systems supported by ECReader (up to V5.40)

### TRUCKS



























Iveco

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 EuroTech	EMERGENCY START	Cursor 13 F3BE0681F	BOSCH EDC MS 6.2
 EuroTech	EMERGENCY START	Cursor 13 F3BE0681G	BOSCH EDC MS 6.2
 EuroTech	EMERGENCY START	Cursor 8 F2BE0681A	BOSCH EDC MS 6.2
 EuroTech	EMERGENCY START	Cursor 8 F2BE0681B	BOSCH EDC MS 6.2
 EuroTech	EMERGENCY START	Cursor 8 F2BE0681C	BOSCH EDC MS 6.2
 EuroTech	EMERGENCY START	Cursor 8 F2BE0681D	BOSCH EDC MS 6.2
 EuroTech	EMERGENCY START	Cursor 8 F2BE0681E	BOSCH EDC MS 6.2
 EuroTech	EMERGENCY START	Cursor 8 F2BE0681F	BOSCH EDC MS 6.2
 EuroTech	EMERGENCY START	Cursor 8 F2BE0681G	BOSCH EDC MS 6.2
 EuroTech	ENGINE MANAGEME	180 E 38	BOSCH EDC M7
 EuroTech	ENGINE MANAGEME	190 E 38	BOSCH EDC M7
 EuroTech	ENGINE MANAGEME	240 E 38	BOSCH EDC M7
 EuroTech	ENGINE MANAGEME	Cursor 10 F3AE0681A	BOSCH EDC MS 6.2
 EuroTech	ENGINE MANAGEME	Cursor 10 F3AE0681B	BOSCH EDC MS 6.2
 EuroTech	ENGINE MANAGEME	Cursor 10 F3AE0681D	BOSCH EDC MS 6.2
 EuroTech	ENGINE MANAGEME	Cursor 10 F3AE0681E	BOSCH EDC MS 6.2
 EuroTech	ENGINE MANAGEME	Cursor 10 F3AE0681H	BOSCH EDC MS 6.2
 EuroTech	ENGINE MANAGEME	Cursor 13 F3BE0681C	BOSCH EDC MS 6.2
 EuroTech	ENGINE MANAGEME	Cursor 13 F3BE0681D	BOSCH EDC MS 6.2
 EuroTech	ENGINE MANAGEME	Cursor 13 F3BE0681E	BOSCH EDC MS 6.2
 EuroTech	ENGINE MANAGEME	Cursor 13 F3BE0681F	BOSCH EDC MS 6.2
 EuroTech	ENGINE MANAGEME	Cursor 13 F3BE0681G	BOSCH EDC MS 6.2
 EuroTech	ENGINE MANAGEME	Cursor 8 F2BE0681A	BOSCH EDC MS 6.2
 EuroTech	ENGINE MANAGEME	Cursor 8 F2BE0681B	BOSCH EDC MS 6.2
 EuroTech	ENGINE MANAGEME	Cursor 8 F2BE0681C	BOSCH EDC MS 6.2
 EuroTech	ENGINE MANAGEME	Cursor 8 F2BE0681D	BOSCH EDC MS 6.2
 EuroTech	ENGINE MANAGEME	Cursor 8 F2BE0681E	BOSCH EDC MS 6.2

## Systems supported by ECUreader (up to V5.40)

### TRUCKS




























Iveco

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 EuroTech	ENGINE MANAGEME	Cursor 8 F2BE0681F	BOSCH EDC MS 6.2
 EuroTech	ENGINE MANAGEME	Cursor 8 F2BE0681G	BOSCH EDC MS 6.2
 EuroTech	GEARBOX MANAGEM	180 E 38	Eurotronic 2
 EuroTech	GEARBOX MANAGEM	190 E 38	Eurotronic 2
 EuroTech	GEARBOX MANAGEM	240 E 38	Eurotronic 2
 EuroTech	GEARBOX MANAGEM	Cursor 10	Eurotronic 2
 EuroTech	GEARBOX MANAGEM	Cursor 13	Eurotronic 2
 EuroTech	GEARBOX MANAGEM	Cursor 8	Eurotronic 2
 EuroTech	SUSPENSION CONTR	180 E 38	WABCO ECAS Full Pneumatic
 EuroTech	SUSPENSION CONTR	180 E 38	WABCO ECAS Pneumatic
 EuroTech	SUSPENSION CONTR	190 E 38	WABCO ECAS Full Pneumatic
 EuroTech	SUSPENSION CONTR	190 E 38	WABCO ECAS Pneumatic
 EuroTech	SUSPENSION CONTR	240 E 38	WABCO ECAS Full Pneumatic
 EuroTech	SUSPENSION CONTR	240 E 38	WABCO ECAS Pneumatic
 EuroTech	SUSPENSION CONTR	Cursor 10	WABCO ECAS Full Pneumatic
 EuroTech	SUSPENSION CONTR	Cursor 10	WABCO ECAS Pneumatic
 EuroTech	SUSPENSION CONTR	Cursor 13	WABCO ECAS Full Pneumatic
 EuroTech	SUSPENSION CONTR	Cursor 13	WABCO ECAS Pneumatic
 EuroTech	SUSPENSION CONTR	Cursor 8	WABCO ECAS Full Pneumatic
 EuroTech	SUSPENSION CONTR	Cursor 8	WABCO ECAS Pneumatic
 EuroTrakker	ABS + TRACT. CONT	190 E 47	Bosch ABS/ASR/SL P4 Full Air
 EuroTrakker	ABS + TRACT. CONT	190 E 47	WABCO ABS/ASR/EBS C3
 EuroTrakker	ABS + TRACT. CONT	260 E 47	Bosch ABS/ASR/SL P4 Full Air
 EuroTrakker	ABS + TRACT. CONT	260 E 47	WABCO ABS/ASR/EBS C3
 EuroTrakker	ABS + TRACT. CONT	340 E 47	Bosch ABS/ASR/SL P4 Full Air
 EuroTrakker	ABS + TRACT. CONT	340 E 47	WABCO ABS/ASR/EBS C3

## Systems supported by ECReader (up to V5.40)

### TRUCKS

Iveco

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 EuroTrakker	ABS + TRACT. CONT	380 E 47	Bosch ABS/ASR/SL P4 Full Air
 EuroTrakker	ABS + TRACT. CONT	380 E 47	WABCO ABS/ASR/EBS C3
 EuroTrakker	ABS + TRACT. CONT	410 E 47	Bosch ABS/ASR/SL P4 Full Air
 EuroTrakker	ABS + TRACT. CONT	410 E 47	WABCO ABS/ASR/EBS C3
 EuroTrakker	ABS + TRACT. CONT	440 E 47	Bosch ABS/ASR/SL P4 Full Air
 EuroTrakker	ABS + TRACT. CONT	440 E 47	WABCO ABS/ASR/EBS C3
 EuroTrakker	ABS + TRACT. CONT	720 E 47	Bosch ABS/ASR/SL P4 Full Air
 EuroTrakker	ABS + TRACT. CONT	720 E 47	WABCO ABS/ASR/EBS C3
 EuroTrakker	ABS + TRACT. CONT	Cursor 13	Bosch ABS/ASR/SL P4 Full Air
 EuroTrakker	ABS + TRACT. CONT	Cursor 13	WABCO ABS/ASR/EBS C3
 EuroTrakker	ABS + TRACT. CONT	Cursor 8	Bosch ABS/ASR/SL P4 Full Air
 EuroTrakker	ABS + TRACT. CONT	Cursor 8	WABCO ABS/ASR/EBS C3
 EuroTrakker	BRAKE POWER SUP	190 E 47	ZF Intarder no CAN
 EuroTrakker	BRAKE POWER SUP	260 E 47	ZF Intarder no CAN
 EuroTrakker	BRAKE POWER SUP	340 E 47	ZF Intarder no CAN
 EuroTrakker	BRAKE POWER SUP	380 E 47	ZF Intarder no CAN
 EuroTrakker	BRAKE POWER SUP	410 E 47	ZF Intarder no CAN
 EuroTrakker	BRAKE POWER SUP	440 E 47	ZF Intarder no CAN
 EuroTrakker	BRAKE POWER SUP	720 E 47	ZF Intarder no CAN
 EuroTrakker	BRAKE POWER SUP	Cursor 13	ZF Intarder no CAN
 EuroTrakker	BRAKE POWER SUP	Cursor 8	ZF Intarder no CAN
 EuroTrakker	BRAKE SYS. MANAG	Cursor 13 F3BE0681C	WABCO EBS EURO
 EuroTrakker	BRAKE SYS. MANAG	Cursor 13 F3BE0681D	WABCO EBS EURO
 EuroTrakker	BRAKE SYS. MANAG	Cursor 13 F3BE0681E	WABCO EBS EURO
 EuroTrakker	BRAKE SYS. MANAG	Cursor 13 F3BE0681F	WABCO EBS EURO
 EuroTrakker	BRAKE SYS. MANAG	Cursor 13 F3BE0681G	WABCO EBS EURO
 EuroTrakker	BRAKE SYS. MANAG	Cursor 8 F2BE0681A	WABCO EBS EURO

## Systems supported by ECUreader (up to V5.40)

### TRUCKS



























Iveco

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 EuroTrakker	BRAKE SYS. MANAG	Cursor 8 F2BE0681B	WABCO EBS EURO
 EuroTrakker	BRAKE SYS. MANAG	Cursor 8 F2BE0681C	WABCO EBS EURO
 EuroTrakker	BRAKE SYS. MANAG	Cursor 8 F2BE0681D	WABCO EBS EURO
 EuroTrakker	BRAKE SYS. MANAG	Cursor 8 F2BE0681E	WABCO EBS EURO
 EuroTrakker	BRAKE SYS. MANAG	Cursor 8 F2BE0681F	WABCO EBS EURO
 EuroTrakker	BRAKE SYS. MANAG	Cursor 8 F2BE0681G	WABCO EBS EURO
 EuroTrakker	ENGINE MANAGEME	190 E 47	BOSCH EDC M7
 EuroTrakker	ENGINE MANAGEME	260 E 47	BOSCH EDC M7
 EuroTrakker	ENGINE MANAGEME	340 E 47	BOSCH EDC M7
 EuroTrakker	ENGINE MANAGEME	380 E 47	BOSCH EDC M7
 EuroTrakker	ENGINE MANAGEME	410 E 47	BOSCH EDC M7
 EuroTrakker	ENGINE MANAGEME	440 E 47	BOSCH EDC M7
 EuroTrakker	ENGINE MANAGEME	720 E 47	BOSCH EDC M7
 EuroTrakker	ENGINE MANAGEME	Cursor 13 F3BE0681C	BOSCH EDC MS 6.2
 EuroTrakker	ENGINE MANAGEME	Cursor 13 F3BE0681D	BOSCH EDC MS 6.2
 EuroTrakker	ENGINE MANAGEME	Cursor 13 F3BE0681E	BOSCH EDC MS 6.2
 EuroTrakker	ENGINE MANAGEME	Cursor 13 F3BE0681F	BOSCH EDC MS 6.2
 EuroTrakker	ENGINE MANAGEME	Cursor 13 F3BE0681G	BOSCH EDC MS 6.2
 EuroTrakker	ENGINE MANAGEME	Cursor 8 F2BE0681A	BOSCH EDC MS 6.2
 EuroTrakker	ENGINE MANAGEME	Cursor 8 F2BE0681B	BOSCH EDC MS 6.2
 EuroTrakker	ENGINE MANAGEME	Cursor 8 F2BE0681C	BOSCH EDC MS 6.2
 EuroTrakker	ENGINE MANAGEME	Cursor 8 F2BE0681D	BOSCH EDC MS 6.2
 EuroTrakker	ENGINE MANAGEME	Cursor 8 F2BE0681E	BOSCH EDC MS 6.2
 EuroTrakker	ENGINE MANAGEME	Cursor 8 F2BE0681F	BOSCH EDC MS 6.2
 EuroTrakker	ENGINE MANAGEME	Cursor 8 F2BE0681G	BOSCH EDC MS 6.2
 EuroTrakker	GEARBOX MANAGEM	190 E 47	Eurotronic 2
 EuroTrakker	GEARBOX MANAGEM	260 E 47	Eurotronic 2

## Systems supported by ECUreader (up to V5.40)

### TRUCKS




























Iveco

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 EuroTrakker	GEARBOX MANAGEM	340 E 47	Eurotronic 2
 EuroTrakker	GEARBOX MANAGEM	380 E 47	Eurotronic 2
 EuroTrakker	GEARBOX MANAGEM	410 E 47	Eurotronic 2
 EuroTrakker	GEARBOX MANAGEM	440 E 47	Eurotronic 2
 EuroTrakker	GEARBOX MANAGEM	720 E 47	Eurotronic 2
 EuroTrakker	GEARBOX MANAGEM	Cursor 13	Eurotronic 2
 EuroTrakker	GEARBOX MANAGEM	Cursor 8	Eurotronic 2
 EuroTrakker	SUSPENSION CONTR	190 E 47	WABCO ECAS Full Pneumatic
 EuroTrakker	SUSPENSION CONTR	190 E 47	WABCO ECAS Pneumatic
 EuroTrakker	SUSPENSION CONTR	260 E 47	WABCO ECAS Full Pneumatic
 EuroTrakker	SUSPENSION CONTR	260 E 47	WABCO ECAS Pneumatic
 EuroTrakker	SUSPENSION CONTR	340 E 47	WABCO ECAS Full Pneumatic
 EuroTrakker	SUSPENSION CONTR	340 E 47	WABCO ECAS Pneumatic
 EuroTrakker	SUSPENSION CONTR	380 E 47	WABCO ECAS Full Pneumatic
 EuroTrakker	SUSPENSION CONTR	380 E 47	WABCO ECAS Pneumatic
 EuroTrakker	SUSPENSION CONTR	410 E 47	WABCO ECAS Full Pneumatic
 EuroTrakker	SUSPENSION CONTR	410 E 47	WABCO ECAS Pneumatic
 EuroTrakker	SUSPENSION CONTR	440 E 47	WABCO ECAS Full Pneumatic
 EuroTrakker	SUSPENSION CONTR	440 E 47	WABCO ECAS Pneumatic
 EuroTrakker	SUSPENSION CONTR	720 E 47	WABCO ECAS Full Pneumatic
 EuroTrakker	SUSPENSION CONTR	720 E 47	WABCO ECAS Pneumatic
 EuroTrakker	SUSPENSION CONTR	Cursor 13	WABCO ECAS Full Pneumatic
 EuroTrakker	SUSPENSION CONTR	Cursor 13	WABCO ECAS Pneumatic
 EuroTrakker	SUSPENSION CONTR	Cursor 8	WABCO ECAS Full Pneumatic
 EuroTrakker	SUSPENSION CONTR	Cursor 8	WABCO ECAS Pneumatic
 New Daily	ABS + TRACT. CONT	2.3 HPI 116cv	BOSCH ABS 8

## Systems supported by ECReader (up to V5.40)

### TRUCKS


























Iveco

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 New Daily	ABS + TRACT. CONT	2.3 HPI 96cv	BOSCH ABS 8
 New Daily	ABS + TRACT. CONT	2.3 HPT 136cv	BOSCH ABS 8
 New Daily	ABS + TRACT. CONT	3.0 CNG	BOSCH ABS 8
 New Daily	ABS + TRACT. CONT	3.0 HPI	BOSCH ABS 8
 New Daily	ABS + TRACT. CONT	3.0 HPT	BOSCH ABS 8
 New Daily	AIRBAG	2.3 HPI 116cv (07-..)	AB/SRS
 New Daily	AIRBAG	2.3 HPI 96cv (07-..)	AB/SRS
 New Daily	AIRBAG	2.3 HPT 136cv (07-..)	AB/SRS
 New Daily	AIRBAG	3.0 CNG (07-..)	AB/SRS
 New Daily	AIRBAG	3.0 HPI (07-..)	AB/SRS
 New Daily	AIRBAG	3.0 HPT (07-..)	AB/SRS
 New Daily	CHASSIS NETWORK	2.3 HPI 116cv	
 New Daily	CHASSIS NETWORK	2.3 HPI 96cv	
 New Daily	CHASSIS NETWORK	2.3 HPT 136cv	
 New Daily	CHASSIS NETWORK	3.0 CNG	
 New Daily	CHASSIS NETWORK	3.0 HPI	
 New Daily	CHASSIS NETWORK	3.0 HPT	
 New Daily	DASHBOARD	2.3 HPI 116cv	MARELLI
 New Daily	DASHBOARD	2.3 HPI 96cv	MARELLI
 New Daily	DASHBOARD	2.3 HPT 136cv	MARELLI
 New Daily	DASHBOARD	3.0 CNG	MARELLI
 New Daily	DASHBOARD	3.0 HPI	MARELLI
 New Daily	DASHBOARD	3.0 HPT	MARELLI
 New Daily	ENGINE MANAGEME	2.3 HPI 116cv	BOSCH EDC 16 Common Rail
 New Daily	ENGINE MANAGEME	2.3 HPI 96cv	BOSCH EDC 16 Common Rail
 New Daily	ENGINE MANAGEME	2.3 HPT 136cv	BOSCH EDC 16 Common Rail
 New Daily	ENGINE MANAGEME	3.0 HPI	BOSCH EDC 16 Common Rail

## Systems supported by ECReader (up to V5.40)

### TRUCKS




























Iveco

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 New Daily	ENGINE MANAGEME	3.0 HPT	BOSCH EDC 16 Common Rail
 Stralis	ABS	Cursor 10	WABCO ABS E
 Stralis	ABS	Cursor 13	WABCO ABS E
 Stralis	ABS	Cursor 8	WABCO ABS E
 Stralis	BRAKE SYS. MANAG	Cursor 10	WABCO EBS EURO
 Stralis	BRAKE SYS. MANAG	Cursor 10 (04-..)	WABCO EBS 2
 Stralis	BRAKE SYS. MANAG	Cursor 13	WABCO EBS EURO
 Stralis	BRAKE SYS. MANAG	Cursor 13 (04-..)	WABCO EBS 2
 Stralis	BRAKE SYS. MANAG	Cursor 8	WABCO EBS EURO
 Stralis	BRAKE SYS. MANAG	Cursor 8 (04-..)	WABCO EBS 2
 Stralis	CAN LANES TEST	Cursor 10	
 Stralis	CAN LANES TEST	Cursor 13	
 Stralis	CAN LANES TEST	Cursor 8	
 Stralis	CHASSIS NETWORK	Cursor 10 (...-05)	Body Computer 1
 Stralis	CHASSIS NETWORK	Cursor 10 (...-05)	Body Computer 2
 Stralis	CHASSIS NETWORK	Cursor 10 (...-05)	Cabin Module
 Stralis	CHASSIS NETWORK	Cursor 10 (...-05)	Driver Door Module
 Stralis	CHASSIS NETWORK	Cursor 10 (...-05)	Front Frame Computer
 Stralis	CHASSIS NETWORK	Cursor 10 (...-05)	Passenger Door Module
 Stralis	CHASSIS NETWORK	Cursor 10 (...-05)	Rear Frame Computer
 Stralis	CHASSIS NETWORK	Cursor 10 (06-..)	Body Computer 2
 Stralis	CHASSIS NETWORK	Cursor 13 (...-05)	Body Computer 1
 Stralis	CHASSIS NETWORK	Cursor 13 (...-05)	Body Computer 2
 Stralis	CHASSIS NETWORK	Cursor 13 (...-05)	Cabin Module
 Stralis	CHASSIS NETWORK	Cursor 13 (...-05)	Driver Door Module
 Stralis	CHASSIS NETWORK	Cursor 13 (...-05)	Front Frame Computer

## Systems supported by ECUREADER (up to V5.40)

### TRUCKS



























Iveco

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Stralis	CHASSIS NETWORK	Cursor 13 (...-05)	Passenger Door Module
 Stralis	CHASSIS NETWORK	Cursor 13 (...-05)	Rear Frame Computer
 Stralis	CHASSIS NETWORK	Cursor 13 (06-..)	Body Computer 2
 Stralis	CHASSIS NETWORK	Cursor 8 (...-05)	Body Computer 1
 Stralis	CHASSIS NETWORK	Cursor 8 (...-05)	Body Computer 2
 Stralis	CHASSIS NETWORK	Cursor 8 (...-05)	Cabin Module
 Stralis	CHASSIS NETWORK	Cursor 8 (...-05)	Driver Door Module
 Stralis	CHASSIS NETWORK	Cursor 8 (...-05)	Front Frame Computer
 Stralis	CHASSIS NETWORK	Cursor 8 (...-05)	Passenger Door Module
 Stralis	CHASSIS NETWORK	Cursor 8 (...-05)	Rear Frame Computer
 Stralis	CHASSIS NETWORK	Cursor 8 (06-..)	Body Computer 2
 Stralis	DASHBOARD	Cursor 10	Instrument Cluster 1
 Stralis	DASHBOARD	Cursor 10	Instrument Cluster 2
 Stralis	DASHBOARD	Cursor 13	Instrument Cluster 1
 Stralis	DASHBOARD	Cursor 13	Instrument Cluster 2
 Stralis	DASHBOARD	Cursor 8	Instrument Cluster 1
 Stralis	DASHBOARD	Cursor 8	Instrument Cluster 2
 Stralis	DIESEL ADDITION	Cursor 10 (06-..)	DeNoxtronic 2
 Stralis	DIESEL ADDITION	Cursor 13 (06-..)	DeNoxtronic 2
 Stralis	DIESEL ADDITION	Cursor 8 (06-..)	DeNoxtronic 2
 Stralis	EMERGENCY START	Cursor 10 F3AE0681B	BOSCH EDC MS 6.2
 Stralis	EMERGENCY START	Cursor 10 F3AE0681D	BOSCH EDC MS 6.2
 Stralis	EMERGENCY START	Cursor 13 F3BE0681F	BOSCH EDC MS 6.2
 Stralis	EMERGENCY START	Cursor 13 F3BE0681G	BOSCH EDC MS 6.2
 Stralis	EMERGENCY START	Cursor 8 F2BE0681A	BOSCH EDC MS 6.2
 Stralis	EMERGENCY START	Cursor 8 F2BE0681B	BOSCH EDC MS 6.2
 Stralis	EMERGENCY START	Cursor 8 F2BE0681E	BOSCH EDC MS 6.2

## Systems supported by ECUreader (up to V5.40)

### TRUCKS



























Iveco

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Stralis	EMERGENCY START	Cursor 8 F2BE0681F	BOSCH EDC MS 6.2
 Stralis	ENGINE MANAGEME	Cursor 10 F3AE0681B	BOSCH EDC MS 6.2
 Stralis	ENGINE MANAGEME	Cursor 10 F3AE0681D	BOSCH EDC MS 6.2
 Stralis	ENGINE MANAGEME	Cursor 10 F3AE0681DM	BOSCH EDC7 1
 Stralis	ENGINE MANAGEME	Cursor 10 F3AE0681DM	BOSCH EDC7 2
 Stralis	ENGINE MANAGEME	Cursor 10 F3AE3681A	BOSCH EDC7 1
 Stralis	ENGINE MANAGEME	Cursor 10 F3AE3681A	BOSCH EDC7 2
 Stralis	ENGINE MANAGEME	Cursor 10 F3AE3681D	BOSCH EDC7 1
 Stralis	ENGINE MANAGEME	Cursor 10 F3AE3681D	BOSCH EDC7 2
 Stralis	ENGINE MANAGEME	Cursor 13 F3BE0681F	BOSCH EDC MS 6.2
 Stralis	ENGINE MANAGEME	Cursor 13 F3BE0681G	BOSCH EDC MS 6.2
 Stralis	ENGINE MANAGEME	Cursor 13 F3BE3681A	BOSCH EDC7 1
 Stralis	ENGINE MANAGEME	Cursor 13 F3BE3681A	BOSCH EDC7 2
 Stralis	ENGINE MANAGEME	Cursor 13 F3BE3681B	BOSCH EDC7 1
 Stralis	ENGINE MANAGEME	Cursor 13 F3BE3681B	BOSCH EDC7 2
 Stralis	ENGINE MANAGEME	Cursor 8 F2BE03681A	BOSCH EDC7 1
 Stralis	ENGINE MANAGEME	Cursor 8 F2BE03681A	BOSCH EDC7 2
 Stralis	ENGINE MANAGEME	Cursor 8 F2BE03681C	BOSCH EDC7 1
 Stralis	ENGINE MANAGEME	Cursor 8 F2BE03681C	BOSCH EDC7 2
 Stralis	ENGINE MANAGEME	Cursor 8 F2BE0681A	BOSCH EDC MS 6.2
 Stralis	ENGINE MANAGEME	Cursor 8 F2BE0681B	BOSCH EDC MS 6.2
 Stralis	ENGINE MANAGEME	Cursor 8 F2BE0681E	BOSCH EDC MS 6.2
 Stralis	ENGINE MANAGEME	Cursor 8 F2BE0681F	BOSCH EDC MS 6.2
 Stralis	ENGINE MANAGEME	Cursor 8 F2BE3681A	BOSCH EDC7 1
 Stralis	ENGINE MANAGEME	Cursor 8 F2BE3681A	BOSCH EDC7 2
 Stralis	ENGINE MANAGEME	Cursor 8 F2BE3681B	BOSCH EDC7 1
 Stralis	ENGINE MANAGEME	Cursor 8 F2BE3681B	BOSCH EDC7 2

## Systems supported by ECUreader (up to V5.40)

### TRUCKS


























Iveco

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Stralis	ENGINE MANAGEME	Cursor 8 F2BE3681C	BOSCH EDC7 1
 Stralis	ENGINE MANAGEME	Cursor 8 F2BE3681C	BOSCH EDC7 2
 Stralis	GEARBOX MANAGEM	Cursor 10	Eurotronic 2
 Stralis	GEARBOX MANAGEM	Cursor 13	Eurotronic 2
 Stralis	GEARBOX MANAGEM	Cursor 8	Eurotronic 2
 Stralis	IMMOBILIZER	Cursor 10 (...05)	
 Stralis	IMMOBILIZER	Cursor 13 (...05)	
 Stralis	IMMOBILIZER	Cursor 8 (...05)	
 Stralis	SUSPENSION CONTR	Cursor 10	WABCO ECAS + CAN
 Stralis	SUSPENSION CONTR	Cursor 13	WABCO ECAS + CAN
 Stralis	SUSPENSION CONTR	Cursor 8	WABCO ECAS + CAN
 Trakker	CAN LANES TEST	Cursor 13	
 Trakker	CAN LANES TEST	Cursor 8	
 Trakker	CHASSIS NETWORK	Cursor 13	Body Computer
 Trakker	CHASSIS NETWORK	Cursor 13	Driver Door Module
 Trakker	CHASSIS NETWORK	Cursor 13	Front Frame Computer
 Trakker	CHASSIS NETWORK	Cursor 13	Passenger Door Module
 Trakker	CHASSIS NETWORK	Cursor 13	Rear Frame Computer
 Trakker	CHASSIS NETWORK	Cursor 8	Body Computer
 Trakker	CHASSIS NETWORK	Cursor 8	Driver Door Module
 Trakker	CHASSIS NETWORK	Cursor 8	Front Frame Computer
 Trakker	CHASSIS NETWORK	Cursor 8	Passenger Door Module
 Trakker	CHASSIS NETWORK	Cursor 8	Rear Frame Computer
 Trakker	DASHBOARD	Cursor 13	Instrument Cluster
 Trakker	DASHBOARD	Cursor 8	Instrument Cluster
 Trakker	DIESEL ADDITION	Cursor 13	DeNoxtronic 2

## Systems supported by ECUreader (up to V5.40)

### TRUCKS








Iveco

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Trakker	DIESEL ADDITION	Cursor 8	DeNoxtronic 2
 Trakker	EMERGENCY START	Cursor 13 F3BE0681F	BOSCH EDC MS 6.2
 Trakker	EMERGENCY START	Cursor 13 F3BE0681G	BOSCH EDC MS 6.2
 Trakker	EMERGENCY START	Cursor 8 F2BE0681A	BOSCH EDC MS 6.2
 Trakker	EMERGENCY START	Cursor 8 F2BE0681B	BOSCH EDC MS 6.2
 Trakker	EMERGENCY START	Cursor 8 F2BE0681E	BOSCH EDC MS 6.2
 Trakker	EMERGENCY START	Cursor 8 F2BE0681F	BOSCH EDC MS 6.2
 Trakker	ENGINE MANAGEME	Cursor 13 F3BE0681B	BOSCH EDC 7
 Trakker	ENGINE MANAGEME	Cursor 13 F3BE0681F	BOSCH EDC MS 6.2
 Trakker	ENGINE MANAGEME	Cursor 13 F3BE0681G	BOSCH EDC MS 6.2
 Trakker	ENGINE MANAGEME	Cursor 13 F3BE3681B	BOSCH EDC 7
 Trakker	ENGINE MANAGEME	Cursor 13 F3BE3681C	BOSCH EDC 7
 Trakker	ENGINE MANAGEME	Cursor 13 F3BE3681D	BOSCH EDC 7
 Trakker	ENGINE MANAGEME	Cursor 13 F3BE3681P	BOSCH EDC 7
 Trakker	ENGINE MANAGEME	Cursor 8 F2BE0681A	BOSCH EDC MS 6.2
 Trakker	ENGINE MANAGEME	Cursor 8 F2BE0681B	BOSCH EDC MS 6.2
 Trakker	ENGINE MANAGEME	Cursor 8 F2BE0681E	BOSCH EDC MS 6.2
 Trakker	ENGINE MANAGEME	Cursor 8 F2BE0681F	BOSCH EDC MS 6.2
 Trakker	ENGINE MANAGEME	Cursor 8 F2BE3681A	BOSCH EDC 7
 Trakker	GEARBOX MANAGEM	Cursor 13	Eurotronic 2
 Trakker	GEARBOX MANAGEM	Cursor 8	Eurotronic 2
 Trakker	IMMOBILIZER	Cursor 13	
 Trakker	IMMOBILIZER	Cursor 8	
 Trakker	SUSPENSION CONTR	Cursor 13	WABCO ECAS + CAN
 Trakker	SUSPENSION CONTR	Cursor 8	WABCO ECAS + CAN

## Systems supported by ECUreader (up to V5.40)

### TRUCKS






Iveco Bus

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 3 Series	ENGINE MANAGEME	315	BOSCH EDC M7
 3 Series	ENGINE MANAGEME	316	BOSCH EDC M7
 3 Series	ENGINE MANAGEME	370	BOSCH EDC M7
 3 Series	ENGINE MANAGEME	380	BOSCH EDC M7
 3 Series	ENGINE MANAGEME	391	BOSCH EDC M7
 3 Series	ENGINE MANAGEME	393	BOSCH EDC M7
 Euroreader	ENGINE MANAGEME	391	BOSCH EDC M7

## Systems supported by ECUreader (up to V5.40)

### TRUCKS

Kassbohrer

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Trailers	BRAKE SYS. MANAG	Trailers	Wabco Trailer EBS
 Trailers	BRAKE SYS. MANAG	Trailers	Wabco Trailer VCS II
 Trailers	BRAKE SYS. MANAG	Trailers	Wabco Trailers EBS kw2000
 Trailers	BRAKE SYS. MANAG	Trailers Haldex	Haldex EBS EB+
 Trailers	BRAKE SYS. MANAG	Trailers Knorr	Knorr Trailer EBS

## Systems supported by ECUREADER (up to V5.40)

### TRUCKS





**Knorr**

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Trailers	BRAKE SYS. MANAG	Trailers	Knorr Trailer EBS

## Systems supported by ECUREADER (up to V5.40)

### TRUCKS





**Kogel**

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Trailers	BRAKE SYS. MANAG	Trailers	Wabco Trailer EBS
 Trailers	BRAKE SYS. MANAG	Trailers	Wabco Trailers EBS kw2000
 Trailers	BRAKE SYS. MANAG	Trailers Haldex	Haldex EBS EB+
 Trailers	BRAKE SYS. MANAG	Trailers Knorr	Knorr Trailer EBS

## Systems supported by ECUreader (up to V5.40)

### TRUCKS

**Kraker**

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Trailers	BRAKE SYS. MANAG	Trailers	Wabco Trailer EBS
 Trailers	BRAKE SYS. MANAG	Trailers	Wabco Trailers EBS kw2000
 Trailers	BRAKE SYS. MANAG	Trailers Haldex	Haldex EBS EB+
 Trailers	BRAKE SYS. MANAG	Trailers Knorr	Knorr Trailer EBS

## Systems supported by ECUreader (up to V5.40)

### TRUCKS



Krone

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Trailers	ABS	Trailers Wabco	Wabco VARIO C1-C2-C plus
 Trailers	BRAKE SYS. MANAG	Trailers	Wabco Trailer EBS
 Trailers	BRAKE SYS. MANAG	Trailers	Wabco Trailers EBS kw2000
 Trailers	BRAKE SYS. MANAG	Trailers Haldex	Haldex EBS EB+
 Trailers	BRAKE SYS. MANAG	Trailers Knorr	Knorr Trailer EBS

## Systems supported by ECUREADER (up to V5.40)

### TRUCKS





Laneko

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Trailers	BRAKE SYS. MANAG	Trailers	Wabco Trailer EBS
 Trailers	BRAKE SYS. MANAG	Trailers	Wabco Trailer VCS II

## Systems supported by ECUREADER (up to V5.40)

### TRUCKS



Lecinena

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Trailers	BRAKE SYS. MANAG	Trailers	Wabco Trailers EBS
 Trailers	BRAKE SYS. MANAG	Trailers	Wabco Trailers EBS kw2000
 Trailers	BRAKE SYS. MANAG	Trailers Haldex	Haldex EBS EB+
 Trailers	BRAKE SYS. MANAG	Trailers Knorr	Knorr Trailer EBS

## Systems supported by ECUreader (up to V5.40)

### TRUCKS



























Lecitrailer

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Trailers	BRAKE SYS. MANAG	Trailers	Wabco Trailer EBS
 Trailers	BRAKE SYS. MANAG	Trailers	Wabco Trailer VCS II

## Systems supported by ECReader (up to V5.40)

### TRUCKS



























**MAN**

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 E2000	ABS		BOSCH ABS/ASR 2E
 E2000	ABS		BOSCH ABS/ASR 2M Stufe 1
 E2000	ABS		BOSCH ABS/ASR 3E
 E2000	ABS		BOSCH/KNORR ABS Ci 12
 E2000	ABS		KNORR ABS
 E2000	AUX. HEATING		ZH Webasto AT2000
 E2000	BRAKE POWER SUP		ZF Intarder est 32
 E2000	CLIMA		Konvekta MANUAL
 E2000	CLIMA		WABCO ATC MANUAL
 E2000	ENGINE MANAGEME		EDC MS5
 E2000	SUSPENSION CONTR		WABCO ECAS
 F2000	ABS	19.414	BOSCH ABS/ASR 2E
 F2000	ABS	19.414	BOSCH ABS/ASR 2M Stufe 1
 F2000	ABS	19.414	BOSCH ABS/ASR 3E
 F2000	ABS	19.414	KNORR ABS
 F2000	ABS	19.414 (99-00)	BOSCH/KNORR ABS Ci 12
 F2000	ABS	19.463	BOSCH ABS/ASR 2E
 F2000	ABS	19.463	BOSCH ABS/ASR 2M Stufe 1
 F2000	ABS	19.463	BOSCH ABS/ASR 3E
 F2000	ABS	19.463	KNORR ABS
 F2000	ABS	19.463 (99-00)	BOSCH/KNORR ABS Ci 12
 F2000	AUX. HEATING	19.414 (99-00)	ZH Webasto AT2000
 F2000	AUX. HEATING	19.463 (99-00)	ZH Webasto AT2000
 F2000	BRAKE POWER SUP	19.414 (99-00)	ZF Intarder est 32
 F2000	BRAKE POWER SUP	19.463 (99-00)	ZF Intarder est 32
 F2000	CLIMA	19.414	Konvekta MANUAL

## Systems supported by ECUreader (up to V5.40)

### TRUCKS



























**MAN**

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 F2000	CLIMA	19.414	WABCO ATC MANUAL
 F2000	CLIMA	19.414 (99-00)	WABCO ACT
 F2000	CLIMA	19.463	Konvekta MANUAL
 F2000	CLIMA	19.463	WABCO ATC MANUAL
 F2000	CLIMA	19.463 (99-00)	WABCO ACT
 F2000	ENGINE MANAGEME	19.414 (99-00)	EDC MS5
 F2000	ENGINE MANAGEME	19.463 (99-00)	EDC MS5
 F2000	SUSPENSION CONTR	19.414 (99-00)	WABCO ECAS 4x2 6x4
 F2000	SUSPENSION CONTR	19.463 (99-00)	WABCO ECAS 4x2 6x4
 F90	ABS	19.322 F-sm	BOSCH ABS/ASR 2E
 F90	ABS	19.322 F-sm	BOSCH ABS/ASR 2M Stufe 1
 F90	ABS	19.322 F-sm	BOSCH ABS/ASR 3E
 F90	ABS	19.322 F-sm	BOSCH ABS/ASR 3M
 F90	ABS	19.322 F-sm	BOSCH/KNORR ABS Ci 12
 F90	ABS	19.322 F-sm	KNORR ABS
 F90	ABS	19.372 F-cl	BOSCH ABS/ASR 2E
 F90	ABS	19.372 F-cl	BOSCH ABS/ASR 2M Stufe 1
 F90	ABS	19.372 F-cl	BOSCH ABS/ASR 3E
 F90	ABS	19.372 F-cl	BOSCH ABS/ASR 3M
 F90	ABS	19.372 F-cl	BOSCH/KNORR ABS Ci 12
 F90	ABS	19.372 F-cl	KNORR ABS
 F90	ABS	19.422 FL-cl	BOSCH ABS/ASR 2E
 F90	ABS	19.422 FL-cl	BOSCH ABS/ASR 2M Stufe 1
 F90	ABS	19.422 FL-cl	BOSCH ABS/ASR 3E
 F90	ABS	19.422 FL-cl	BOSCH ABS/ASR 3M
 F90	ABS	19.422 FL-cl	BOSCH/KNORR ABS Ci 12

## Systems supported by ECUreader (up to V5.40)

### TRUCKS



























**MAN**

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 F90	ABS	19.422 FL-cl	KNORR ABS
 F90	ABS	19.422 FLT-cl-SPP	BOSCH ABS/ASR 2E
 F90	ABS	19.422 FLT-cl-SPP	BOSCH ABS/ASR 2M Stufe 1
 F90	ABS	19.422 FLT-cl-SPP	BOSCH ABS/ASR 3E
 F90	ABS	19.422 FLT-cl-SPP	BOSCH ABS/ASR 3M
 F90	ABS	19.422 FLT-cl-SPP	BOSCH/KNORR ABS Ci 12
 F90	ABS	19.422 FLT-cl-SPP	KNORR ABS
 F90	CLIMA	19.322 F-sm	Konvekta MANUAL
 F90	CLIMA	19.322 F-sm	WABCO ATC MANUAL
 F90	CLIMA	19.372 F-cl	Konvekta MANUAL
 F90	CLIMA	19.372 F-cl	WABCO ATC MANUAL
 F90	CLIMA	19.422 FL-cl	Konvekta MANUAL
 F90	CLIMA	19.422 FL-cl	WABCO ATC MANUAL
 F90	CLIMA	19.422 FLT-cl-SPP	Konvekta MANUAL
 F90	CLIMA	19.422 FLT-cl-SPP	WABCO ATC MANUAL
 F90	DIESEL MANAGEMEN	19.322 F-sm	BOSCH EDC M7
 F90	DIESEL MANAGEMEN	19.372 F-cl	BOSCH ECD M7
 F90	DIESEL MANAGEMEN	19.422 FL-cl	BOSCH EDC M7
 F90	DIESEL MANAGEMEN	19.422 FLT-cl-SPP	BOSCH EDC M7
 F90	SUSPENSION CONTR	19.322 F-sm	ECAS
 F90	SUSPENSION CONTR	19.372 F-cl	ECAS
 F90	SUSPENSION CONTR	19.422 FL-cl	ECAS
 F90	SUSPENSION CONTR	19.422 FLT-cl-SPP	ECAS
 L2000	ABS		BOSCH ABS Ci 12 MANUAL
 L2000	ABS		BOSCH ABS/ASR 2E
 L2000	ABS		BOSCH ABS/ASR 2M MANUAL

## Systems supported by ECUREADER (up to V5.40)

### TRUCKS




























**MAN**

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 L2000	ABS		BOSCH ABS/ASR 2M Stufe 1
 L2000	ABS		BOSCH ABS/ASR 3E
 L2000	ABS		BOSCH/KNORR ABS Ci 12
 L2000	ABS		KNORR ABS
 L2000	ABS		KNORR ABS KB3AL MANUAL
 L2000	AUX. HEATING		ZH Webasto AT2000
 L2000	BRAKE POWER SUP		ZF Intarder est 32
 L2000	CLIMA		Konvekta MANUAL
 L2000	CLIMA		WABCO ATC MANUAL
 L2000	ENGINE MANAGEME		EDC MS5
 L2000	SUSPENSION CONTR		WABCO ECAS 4x2 6x4
 LE2000	ABS		BOSCH/KNORR ABS Ci 12
 LE2000	AUX. HEATING		ZH Webasto AT2000
 LE2000	SUSPENSION CONTR		WABCO ECAS
 M2000	ABS		BOSCH ABS/ASR 2E
 M2000	ABS		BOSCH ABS/ASR 2M Stufe 1
 M2000	ABS		BOSCH ABS/ASR 3E
 M2000	ABS		BOSCH/KNORR ABS Ci 12
 M2000	ABS		KNORR ABS
 M2000	AUX. HEATING		ZH Webasto AT2000
 M2000	BRAKE POWER SUP		ZF Intarder est 32
 M2000	CLIMA		Konvekta MANUAL
 M2000	CLIMA		WABCO ATC MANUAL
 M2000	ENGINE MANAGEME		EDC MS5
 M2000	SUSPENSION CONTR		WABCO ECAS 4x2 6x4
 M90	ABS	12.192 F-sm	BOSCH ABS/ASR 2E

## Systems supported by ECUREADER (up to V5.40)

### TRUCKS



























**MAN**

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 M90	ABS	12.192 F-sm	BOSCH ABS/ASR 2M Stufe 1
 M90	ABS	12.192 F-sm	BOSCH ABS/ASR 3E
 M90	ABS	12.192 F-sm	BOSCH ABS/ASR 3M
 M90	ABS	12.192 F-sm	BOSCH/KNORR ABS Ci 12
 M90	ABS	12.192 F-sm	KNORR ABS
 M90	ABS	12.232 FL-spp	BOSCH ABS/ASR 2E
 M90	ABS	12.232 FL-spp	BOSCH ABS/ASR 2M Stufe 1
 M90	ABS	12.232 FL-spp	BOSCH ABS/ASR 3E
 M90	ABS	12.232 FL-spp	BOSCH ABS/ASR 3M
 M90	ABS	12.232 FL-spp	BOSCH/KNORR ABS Ci 12
 M90	ABS	12.232 FL-spp	KNORR ABS
 M90	ABS	12.272 FL-spp	BOSCH ABS/ASR 2E
 M90	ABS	12.272 FL-spp	BOSCH ABS/ASR 2M Stufe 1
 M90	ABS	12.272 FL-spp	BOSCH ABS/ASR 3E
 M90	ABS	12.272 FL-spp	BOSCH ABS/ASR 3M
 M90	ABS	12.272 FL-spp	BOSCH/KNORR ABS Ci 12
 M90	ABS	12.272 FL-spp	KNORR ABS
 M90	CLIMA	12.192 F-sm	Konvekta MANUAL
 M90	CLIMA	12.192 F-sm	WABCO ATC MANUAL
 M90	CLIMA	12.232 FL-spp	Konvekta MANUAL
 M90	CLIMA	12.232 FL-spp	WABCO ATC MANUAL
 M90	CLIMA	12.272 FL-spp	Konvekta MANUAL
 M90	CLIMA	12.272 FL-spp	WABCO ATC MANUAL
 M90	DIESEL MANAGEMEN	12.192 F-sm	BOSCH EDC M7
 M90	DIESEL MANAGEMEN	12.232 FL-spp	BOSCH EDC M7
 M90	DIESEL MANAGEMEN	12.272 FL-spp	BOSCH EDC M7
 M90	SUSPENSION CONTR	12.192 F-sm	ECAS

## Systems supported by ECUreader (up to V5.40)

### TRUCKS




























**MAN**

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 M90	SUSPENSION CONTR	12.232 FL-spp	ECAS
 M90	SUSPENSION CONTR	12.272 FL-spp	ECAS
 TG-A	AIR BRAKE MANAGE	18.XXX (...05)	HALDEX ECAM
 TG-A	AIR BRAKE MANAGE	18.XXX (06-..)	HALDEX ECAM
 TG-A	AIR BRAKE MANAGE	24.XXX (06-..)	HALDEX ECAM
 TG-A	AIR BRAKE MANAGE	26.XXX (...05)	HALDEX ECAM
 TG-A	AIR BRAKE MANAGE	26.XXX (06-..)	HALDEX ECAM
 TG-A	AIR BRAKE MANAGE	28.XXX (06-..)	HALDEX ECAM
 TG-A	AIR BRAKE MANAGE	32.XXX (06-..)	HALDEX ECAM
 TG-A	AIR BRAKE MANAGE	33.XXX (...05)	HALDEX ECAM
 TG-A	AIR BRAKE MANAGE	33.XXX (06-..)	HALDEX ECAM
 TG-A	AIR BRAKE MANAGE	35.XXX (...05)	HALDEX ECAM
 TG-A	AIR BRAKE MANAGE	35.XXX (06-..)	HALDEX ECAM
 TG-A	AIR BRAKE MANAGE	39.XXX (06-..)	HALDEX ECAM
 TG-A	AIR BRAKE MANAGE	40.XXX (06-..)	HALDEX ECAM
 TG-A	AIR BRAKE MANAGE	41.XXX (...05)	HALDEX ECAM
 TG-A	AIR BRAKE MANAGE	41.XXX (06-..)	HALDEX ECAM
 TG-A	AUTOM. TRANSMISSI	18.XXX (...05)	ZF ASTRONIC 2
 TG-A	AUTOM. TRANSMISSI	18.XXX (06-..)	ZF ASTRONIC 2
 TG-A	AUTOM. TRANSMISSI	24.XXX (06-..)	ZF ASTRONIC 2
 TG-A	AUTOM. TRANSMISSI	26.XXX (...05)	ZF ASTRONIC 2
 TG-A	AUTOM. TRANSMISSI	26.XXX (06-..)	ZF ASTRONIC 2
 TG-A	AUTOM. TRANSMISSI	28.XXX (06-..)	ZF ASTRONIC 2
 TG-A	AUTOM. TRANSMISSI	32.XXX (06-..)	ZF ASTRONIC 2
 TG-A	AUTOM. TRANSMISSI	33.XXX (...05)	ZF ASTRONIC 2
 TG-A	AUTOM. TRANSMISSI	33.XXX (06-..)	ZF ASTRONIC 2

## Systems supported by ECReader (up to V5.40)

### TRUCKS




























**MAN**

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 TG-A	AUTOM. TRANSMISSI	35.XXX (...05)	ZF ASTRONIC 2
 TG-A	AUTOM. TRANSMISSI	35.XXX (06-..)	ZF ASTRONIC 2
 TG-A	AUTOM. TRANSMISSI	39.XXX (06-..)	ZF ASTRONIC 2
 TG-A	AUTOM. TRANSMISSI	40.XXX (06-..)	ZF ASTRONIC 2
 TG-A	AUTOM. TRANSMISSI	41.XXX (...05)	ZF ASTRONIC 2
 TG-A	AUTOM. TRANSMISSI	41.XXX (06-..)	ZF ASTRONIC 2
 TG-A	BRAKE POWER SUP	18.XXX (...05)	ZF Intarder
 TG-A	BRAKE POWER SUP	26.XXX (...05)	ZF Intarder
 TG-A	BRAKE POWER SUP	33.XXX (...05)	ZF Intarder
 TG-A	BRAKE POWER SUP	35.XXX (...05)	ZF Intarder
 TG-A	BRAKE POWER SUP	41.XXX (...05)	ZF Intarder
 TG-A	BRAKE SYS. MANAG	18.XXX (...05)	KNORR EBS 2.3 - 2 axle
 TG-A	BRAKE SYS. MANAG	18.XXX (...05)	KNORR EBS 2.3 - 3 axle
 TG-A	BRAKE SYS. MANAG	18.XXX (...05)	KNORR EBS 2.3 - 4 axle
 TG-A	BRAKE SYS. MANAG	18.XXX (...05)	KNORR EBS 2.3 - axle 3 trained
 TG-A	BRAKE SYS. MANAG	18.XXX (06-..)	KNORR EBS 2.3 - 2 axle
 TG-A	BRAKE SYS. MANAG	18.XXX (06-..)	KNORR EBS 2.3 - 3 axle
 TG-A	BRAKE SYS. MANAG	18.XXX (06-..)	KNORR EBS 2.3 - 4 axle
 TG-A	BRAKE SYS. MANAG	18.XXX (06-..)	KNORR EBS 2.3 - axle 3 trained
 TG-A	BRAKE SYS. MANAG	18.XXX (06-..)	KNORR EBS 5
 TG-A	BRAKE SYS. MANAG	24.XXX (06-..)	KNORR EBS 2.3 - 3 axle
 TG-A	BRAKE SYS. MANAG	24.XXX (06-..)	KNORR EBS 2.3 - 4 axle
 TG-A	BRAKE SYS. MANAG	24.XXX (06-..)	KNORR EBS 2.3 - axle 3 trained
 TG-A	BRAKE SYS. MANAG	24.XXX (06-..)	KNORR EBS 5
 TG-A	BRAKE SYS. MANAG	26.XXX (...05)	KNORR EBS 2.3 - 2 axle
 TG-A	BRAKE SYS. MANAG	26.XXX (...05)	KNORR EBS 2.3 - 3 axle
 TG-A	BRAKE SYS. MANAG	26.XXX (...05)	KNORR EBS 2.3 - 4 axle

## Systems supported by ECReader (up to V5.40)

### TRUCKS




























**MAN**

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 TG-A	BRAKE SYS. MANAG	26.XXX (...05)	KNORR EBS 2.3 - axle 3 trained
 TG-A	BRAKE SYS. MANAG	26.XXX (06-..)	KNORR EBS 2.3 - 2 axle
 TG-A	BRAKE SYS. MANAG	26.XXX (06-..)	KNORR EBS 2.3 - 3 axle
 TG-A	BRAKE SYS. MANAG	26.XXX (06-..)	KNORR EBS 2.3 - 4 axle
 TG-A	BRAKE SYS. MANAG	26.XXX (06-..)	KNORR EBS 2.3 - axle 3 trained
 TG-A	BRAKE SYS. MANAG	26.XXX (06-..)	KNORR EBS 5
 TG-A	BRAKE SYS. MANAG	28.XXX (06-..)	KNORR EBS 2.3 - 2 axle
 TG-A	BRAKE SYS. MANAG	28.XXX (06-..)	KNORR EBS 2.3 - 3 axle
 TG-A	BRAKE SYS. MANAG	28.XXX (06-..)	KNORR EBS 2.3 - 4 axle
 TG-A	BRAKE SYS. MANAG	28.XXX (06-..)	KNORR EBS 2.3 - axle 3 trained
 TG-A	BRAKE SYS. MANAG	28.XXX (06-..)	KNORR EBS 5
 TG-A	BRAKE SYS. MANAG	32.XXX (06-..)	KNORR EBS 2.3 - 2 axle
 TG-A	BRAKE SYS. MANAG	32.XXX (06-..)	KNORR EBS 2.3 - 3 axle
 TG-A	BRAKE SYS. MANAG	32.XXX (06-..)	KNORR EBS 2.3 - 4 axle
 TG-A	BRAKE SYS. MANAG	32.XXX (06-..)	KNORR EBS 2.3 - axle 3 trained
 TG-A	BRAKE SYS. MANAG	32.XXX (06-..)	KNORR EBS 5
 TG-A	BRAKE SYS. MANAG	33.XXX (...05)	KNORR EBS 2.3 - 2 axle
 TG-A	BRAKE SYS. MANAG	33.XXX (...05)	KNORR EBS 2.3 - 3 axle
 TG-A	BRAKE SYS. MANAG	33.XXX (...05)	KNORR EBS 2.3 - 4 axle
 TG-A	BRAKE SYS. MANAG	33.XXX (...05)	KNORR EBS 2.3 - axle 3 trained
 TG-A	BRAKE SYS. MANAG	33.XXX (06-..)	KNORR EBS 2.3 - 2 axle
 TG-A	BRAKE SYS. MANAG	33.XXX (06-..)	KNORR EBS 2.3 - 3 axle
 TG-A	BRAKE SYS. MANAG	33.XXX (06-..)	KNORR EBS 2.3 - 4 axle
 TG-A	BRAKE SYS. MANAG	33.XXX (06-..)	KNORR EBS 2.3 - axle 3 trained
 TG-A	BRAKE SYS. MANAG	33.XXX (06-..)	KNORR EBS 5
 TG-A	BRAKE SYS. MANAG	35.XXX (...05)	KNORR EBS 2.3 - 2 axle
 TG-A	BRAKE SYS. MANAG	35.XXX (...05)	KNORR EBS 2.3 - 3 axle

## Systems supported by ECReader (up to V5.40)

### TRUCKS

























**MAN**

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 TG-A	BRAKE SYS. MANAG	35.XXX (...05)	KNORR EBS 2.3 - 4 axle
 TG-A	BRAKE SYS. MANAG	35.XXX (...05)	KNORR EBS 2.3 - axle 3 trained
 TG-A	BRAKE SYS. MANAG	35.XXX (06-..)	KNORR EBS 2.3 - 2 axle
 TG-A	BRAKE SYS. MANAG	35.XXX (06-..)	KNORR EBS 2.3 - 3 axle
 TG-A	BRAKE SYS. MANAG	35.XXX (06-..)	KNORR EBS 2.3 - 4 axle
 TG-A	BRAKE SYS. MANAG	35.XXX (06-..)	KNORR EBS 2.3 - axle 3 trained
 TG-A	BRAKE SYS. MANAG	35.XXX (06-..)	KNORR EBS 5
 TG-A	BRAKE SYS. MANAG	39.XXX (06-..)	KNORR EBS 2.3 - 2 axle
 TG-A	BRAKE SYS. MANAG	39.XXX (06-..)	KNORR EBS 2.3 - 3 axle
 TG-A	BRAKE SYS. MANAG	39.XXX (06-..)	KNORR EBS 2.3 - 4 axle
 TG-A	BRAKE SYS. MANAG	39.XXX (06-..)	KNORR EBS 2.3 - axle 3 trained
 TG-A	BRAKE SYS. MANAG	39.XXX (06-..)	KNORR EBS 5
 TG-A	BRAKE SYS. MANAG	40.XXX (06-..)	KNORR EBS 2.3 - 2 axle
 TG-A	BRAKE SYS. MANAG	40.XXX (06-..)	KNORR EBS 2.3 - 3 axle
 TG-A	BRAKE SYS. MANAG	40.XXX (06-..)	KNORR EBS 2.3 - 4 axle
 TG-A	BRAKE SYS. MANAG	40.XXX (06-..)	KNORR EBS 2.3 - axle 3 trained
 TG-A	BRAKE SYS. MANAG	40.XXX (06-..)	KNORR EBS 5
 TG-A	BRAKE SYS. MANAG	41.XXX (...05)	KNORR EBS 2.3 - 2 axle
 TG-A	BRAKE SYS. MANAG	41.XXX (...05)	KNORR EBS 2.3 - 3 axle
 TG-A	BRAKE SYS. MANAG	41.XXX (...05)	KNORR EBS 2.3 - 4 axle
 TG-A	BRAKE SYS. MANAG	41.XXX (...05)	KNORR EBS 2.3 - axle 3 trained
 TG-A	BRAKE SYS. MANAG	41.XXX (06-..)	KNORR EBS 2.3 - 2 axle
 TG-A	BRAKE SYS. MANAG	41.XXX (06-..)	KNORR EBS 2.3 - 3 axle
 TG-A	BRAKE SYS. MANAG	41.XXX (06-..)	KNORR EBS 2.3 - 4 axle
 TG-A	BRAKE SYS. MANAG	41.XXX (06-..)	KNORR EBS 2.3 - axle 3 trained
 TG-A	BRAKE SYS. MANAG	41.XXX (06-..)	KNORR EBS 5
 TG-A	CHASSIS NETWORK	18.XXX (...05)	BERIFORS Door Module

## Systems supported by ECUREADER (up to V5.40)

### TRUCKS




























**MAN**

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 TG-A	CHASSIS NETWORK	18.XXX (...05)	VDO Client Module
 TG-A	CHASSIS NETWORK	18.XXX (...05)	VDO Clutch calibration FFR
 TG-A	CHASSIS NETWORK	18.XXX (...05)	WABCO Body Computer ZBR 2
 TG-A	CHASSIS NETWORK	18.XXX (06-..)	BERIFORS Door Module
 TG-A	CHASSIS NETWORK	18.XXX (06-..)	VDO Accelerator pedal calib. FFR STEP 11
 TG-A	CHASSIS NETWORK	18.XXX (06-..)	VDO Clutch calibration FFR
 TG-A	CHASSIS NETWORK	18.XXX (06-..)	WABCO Body Computer ZBR 2 06>
 TG-A	CHASSIS NETWORK	18.XXX (06-..)	WABCO Body Computer ZBR 2 07>
 TG-A	CHASSIS NETWORK	24.XXX (06-..)	VDO Accelerator pedal calib. FFR STEP 11
 TG-A	CHASSIS NETWORK	24.XXX (06-..)	VDO Clutch calibration FFR
 TG-A	CHASSIS NETWORK	24.XXX (06-..)	WABCO Body Computer ZBR 2 06>
 TG-A	CHASSIS NETWORK	24.XXX (06-..)	WABCO Body Computer ZBR 2 07>
 TG-A	CHASSIS NETWORK	26.XXX (...05)	BERIFORS Door Module
 TG-A	CHASSIS NETWORK	26.XXX (...05)	VDO Client Module
 TG-A	CHASSIS NETWORK	26.XXX (...05)	VDO Clutch calibration FFR
 TG-A	CHASSIS NETWORK	26.XXX (...05)	WABCO Body Computer ZBR 2
 TG-A	CHASSIS NETWORK	26.XXX (06-..)	BERIFORS Door Module
 TG-A	CHASSIS NETWORK	26.XXX (06-..)	VDO Accelerator pedal calib. FFR STEP 11
 TG-A	CHASSIS NETWORK	26.XXX (06-..)	VDO Clutch calibration FFR
 TG-A	CHASSIS NETWORK	26.XXX (06-..)	WABCO Body Computer ZBR 2
 TG-A	CHASSIS NETWORK	26.XXX (06-..)	WABCO Body Computer ZBR 2 07>
 TG-A	CHASSIS NETWORK	28.XXX (06-..)	VDO Accelerator pedal calib. FFR STEP 11
 TG-A	CHASSIS NETWORK	28.XXX (06-..)	VDO Clutch calibration FFR
 TG-A	CHASSIS NETWORK	28.XXX (06-..)	WABCO Body Computer ZBR 2
 TG-A	CHASSIS NETWORK	28.XXX (06-..)	WABCO Body Computer ZBR 2 07>
 TG-A	CHASSIS NETWORK	32.XXX (06-..)	VDO Accelerator pedal calib. FFR STEP 11
 TG-A	CHASSIS NETWORK	32.XXX (06-..)	VDO Clutch calibration FFR

## Systems supported by ECUREADER (up to V5.40)

### TRUCKS




























**MAN**

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 TG-A	CHASSIS NETWORK	32.XXX (06-..)	WABCO Body Computer ZBR 2
 TG-A	CHASSIS NETWORK	32.XXX (06-..)	WABCO Body Computer ZBR 2 07>
 TG-A	CHASSIS NETWORK	33.XXX (...05)	BERIFORS Door Module
 TG-A	CHASSIS NETWORK	33.XXX (...05)	VDO Client Module
 TG-A	CHASSIS NETWORK	33.XXX (...05)	VDO Clutch calibration FFR
 TG-A	CHASSIS NETWORK	33.XXX (...05)	WABCO Body Computer ZBR 2
 TG-A	CHASSIS NETWORK	33.XXX (06-..)	BERIFORS Door Module
 TG-A	CHASSIS NETWORK	33.XXX (06-..)	VDO Accelerator pedal calib. FFR STEP 11
 TG-A	CHASSIS NETWORK	33.XXX (06-..)	VDO Clutch calibration FFR
 TG-A	CHASSIS NETWORK	33.XXX (06-..)	WABCO Body Computer ZBR 2
 TG-A	CHASSIS NETWORK	33.XXX (06-..)	WABCO Body Computer ZBR 2 07>
 TG-A	CHASSIS NETWORK	35.XXX (...05)	BERIFORS Door Module
 TG-A	CHASSIS NETWORK	35.XXX (...05)	VDO Client Module
 TG-A	CHASSIS NETWORK	35.XXX (...05)	VDO Clutch calibration FFR
 TG-A	CHASSIS NETWORK	35.XXX (...05)	WABCO Body Computer ZBR 2
 TG-A	CHASSIS NETWORK	35.XXX (06-..)	BERIFORS Door Module
 TG-A	CHASSIS NETWORK	35.XXX (06-..)	VDO Accelerator pedal calib. FFR STEP 11
 TG-A	CHASSIS NETWORK	35.XXX (06-..)	VDO Clutch calibration FFR
 TG-A	CHASSIS NETWORK	35.XXX (06-..)	WABCO Body Computer ZBR 2
 TG-A	CHASSIS NETWORK	35.XXX (06-..)	WABCO Body Computer ZBR 2 07>
 TG-A	CHASSIS NETWORK	39.XXX (06-..)	VDO Accelerator pedal calib. FFR STEP 11
 TG-A	CHASSIS NETWORK	39.XXX (06-..)	VDO Clutch calibration FFR
 TG-A	CHASSIS NETWORK	39.XXX (06-..)	WABCO Body Computer ZBR 2
 TG-A	CHASSIS NETWORK	39.XXX (06-..)	WABCO Body Computer ZBR 2 07>
 TG-A	CHASSIS NETWORK	40.XXX (06-..)	VDO Accelerator pedal calib. FFR STEP 11
 TG-A	CHASSIS NETWORK	40.XXX (06-..)	VDO Clutch calibration FFR
 TG-A	CHASSIS NETWORK	40.XXX (06-..)	WABCO Body Computer ZBR 2

## Systems supported by ECReader (up to V5.40)

### TRUCKS




























**MAN**

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 TG-A	CHASSIS NETWORK	40.XXX (06-..)	WABCO Body Computer ZBR 2 07>
 TG-A	CHASSIS NETWORK	41.XXX (...05)	BERIFORS Door Module
 TG-A	CHASSIS NETWORK	41.XXX (...05)	VDO Client Module
 TG-A	CHASSIS NETWORK	41.XXX (...05)	VDO Clutch calibration FFR
 TG-A	CHASSIS NETWORK	41.XXX (...05)	WABCO Body Computer ZBR 2
 TG-A	CHASSIS NETWORK	41.XXX (06-..)	BERIFORS Door Module
 TG-A	CHASSIS NETWORK	41.XXX (06-..)	VDO Accelerator pedal calib. FFR STEP 11
 TG-A	CHASSIS NETWORK	41.XXX (06-..)	VDO Clutch calibration FFR
 TG-A	CHASSIS NETWORK	41.XXX (06-..)	WABCO Body Computer ZBR 2
 TG-A	CHASSIS NETWORK	41.XXX (06-..)	WABCO Body Computer ZBR 2 07>
 TG-A	CLIMA	18.XXX (...05)	BEHR/GKR Klima
 TG-A	CLIMA	18.XXX (06-..)	BEHR/GKR Klima
 TG-A	CLIMA	24.XXX (06-..)	BEHR/GKR Klima
 TG-A	CLIMA	26.XXX (...05)	BEHR/GKR Klima
 TG-A	CLIMA	26.XXX (06-..)	BEHR/GKR Klima
 TG-A	CLIMA	28.XXX (06-..)	BEHR/GKR Klima
 TG-A	CLIMA	32.XXX (06-..)	BEHR/GKR Klima
 TG-A	CLIMA	33.XXX (...05)	BEHR/GKR Klima
 TG-A	CLIMA	33.XXX (06-..)	BEHR/GKR Klima
 TG-A	CLIMA	35.XXX (...05)	BEHR/GKR Klima
 TG-A	CLIMA	35.XXX (06-..)	BEHR/GKR Klima
 TG-A	CLIMA	39.XXX (06-..)	BEHR/GKR Klima
 TG-A	CLIMA	40.XXX (06-..)	BEHR/GKR Klima
 TG-A	CLIMA	41.XXX (...05)	BEHR/GKR Klima
 TG-A	CLIMA	41.XXX (06-..)	BEHR/GKR Klima
 TG-A	CRUISE MANAGEME	18.XXX (...05)	VDO Navigator
 TG-A	CRUISE MANAGEME	18.XXX (06-..)	VDO FFR Step 9

## Systems supported by ECReader (up to V5.40)

### TRUCKS




























**MAN**

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 TG-A	CRUISE MANAGEME	18.XXX (06-..)	VDO Navigator
 TG-A	CRUISE MANAGEME	24.XXX (06-..)	VDO FFR Step 9
 TG-A	CRUISE MANAGEME	24.XXX (06-..)	VDO Navigator
 TG-A	CRUISE MANAGEME	26.XXX (...05)	VDO Navigator
 TG-A	CRUISE MANAGEME	26.XXX (06-..)	VDO FFR Step 9
 TG-A	CRUISE MANAGEME	26.XXX (06-..)	VDO Navigator
 TG-A	CRUISE MANAGEME	28.XXX (06-..)	VDO FFR Step 9
 TG-A	CRUISE MANAGEME	28.XXX (06-..)	VDO Navigator
 TG-A	CRUISE MANAGEME	32.XXX (06-..)	VDO FFR Step 9
 TG-A	CRUISE MANAGEME	32.XXX (06-..)	VDO Navigator
 TG-A	CRUISE MANAGEME	33.XXX (...05)	VDO Navigator
 TG-A	CRUISE MANAGEME	33.XXX (06-..)	VDO FFR Step 9
 TG-A	CRUISE MANAGEME	33.XXX (06-..)	VDO Navigator
 TG-A	CRUISE MANAGEME	35.XXX (...05)	VDO Navigator
 TG-A	CRUISE MANAGEME	35.XXX (06-..)	VDO FFR Step 9
 TG-A	CRUISE MANAGEME	35.XXX (06-..)	VDO Navigator
 TG-A	CRUISE MANAGEME	39.XXX (06-..)	VDO FFR Step 9
 TG-A	CRUISE MANAGEME	39.XXX (06-..)	VDO Navigator
 TG-A	CRUISE MANAGEME	40.XXX (06-..)	VDO FFR Step 9
 TG-A	CRUISE MANAGEME	40.XXX (06-..)	VDO Navigator
 TG-A	CRUISE MANAGEME	41.XXX (...05)	VDO Navigator
 TG-A	CRUISE MANAGEME	41.XXX (06-..)	VDO FFR Step 9
 TG-A	CRUISE MANAGEME	41.XXX (06-..)	VDO Navigator
 TG-A	DASHBOARD	18.XXX (...05)	VDO/Kienzle
 TG-A	DASHBOARD	18.XXX (06-..)	Stoneridge Electronics
 TG-A	DASHBOARD	18.XXX (06-..)	VDO/Kienzle
 TG-A	DASHBOARD	24.XXX (06-..)	Stoneridge Electronics

## Systems supported by ECUREADER (up to V5.40)

### TRUCKS




























**MAN**

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 TG-A	DASHBOARD	24.XXX (06-..)	VDO/Kienzle
 TG-A	DASHBOARD	26.XXX (...05)	VDO/Kienzle
 TG-A	DASHBOARD	26.XXX (06-..)	Stoneridge Electronics
 TG-A	DASHBOARD	26.XXX (06-..)	VDO/Kienzle
 TG-A	DASHBOARD	28.XXX (06-..)	Stoneridge Electronics
 TG-A	DASHBOARD	28.XXX (06-..)	VDO/Kienzle
 TG-A	DASHBOARD	32.XXX (06-..)	Stoneridge Electronics
 TG-A	DASHBOARD	32.XXX (06-..)	VDO/Kienzle
 TG-A	DASHBOARD	33.XXX (...05)	VDO/Kienzle
 TG-A	DASHBOARD	33.XXX (06-..)	Stoneridge Electronics
 TG-A	DASHBOARD	33.XXX (06-..)	VDO/Kienzle
 TG-A	DASHBOARD	35.XXX (...05)	VDO/Kienzle
 TG-A	DASHBOARD	35.XXX (06-..)	Stoneridge Electronics
 TG-A	DASHBOARD	35.XXX (06-..)	VDO/Kienzle
 TG-A	DASHBOARD	39.XXX (06-..)	Stoneridge Electronics
 TG-A	DASHBOARD	39.XXX (06-..)	VDO/Kienzle
 TG-A	DASHBOARD	40.XXX (06-..)	Stoneridge Electronics
 TG-A	DASHBOARD	40.XXX (06-..)	VDO/Kienzle
 TG-A	DASHBOARD	41.XXX (...05)	VDO/Kienzle
 TG-A	DASHBOARD	41.XXX (06-..)	Stoneridge Electronics
 TG-A	DASHBOARD	41.XXX (06-..)	VDO/Kienzle
 TG-A	ENGINE MANAGEME	18.XXX (...05)	BOSCH EDC 7
 TG-A	ENGINE MANAGEME	18.XXX (...05)	BOSCH EDC MS 6.1
 TG-A	ENGINE MANAGEME	18.XXX (06-..)	BOSCH EDC 7
 TG-A	ENGINE MANAGEME	18.XXX (06-..)	Bosch EDC 7 C32
 TG-A	ENGINE MANAGEME	24.XXX (06-..)	BOSCH EDC 7
 TG-A	ENGINE MANAGEME	24.XXX (06-..)	Bosch EDC 7 C32

## Systems supported by ECUreader (up to V5.40)

### TRUCKS




























**MAN**

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 TG-A	ENGINE MANAGEME	26.XXX (...05)	BOSCH EDC 7
 TG-A	ENGINE MANAGEME	26.XXX (...05)	BOSCH EDC MS 6.1
 TG-A	ENGINE MANAGEME	26.XXX (06-..)	BOSCH EDC 7
 TG-A	ENGINE MANAGEME	26.XXX (06-..)	Bosch EDC 7 C32
 TG-A	ENGINE MANAGEME	28.XXX (06-..)	BOSCH EDC 7
 TG-A	ENGINE MANAGEME	28.XXX (06-..)	Bosch EDC 7 C32
 TG-A	ENGINE MANAGEME	32.XXX (06-..)	BOSCH EDC 7
 TG-A	ENGINE MANAGEME	32.XXX (06-..)	Bosch EDC 7 C32
 TG-A	ENGINE MANAGEME	33.XXX (...05)	BOSCH EDC 7
 TG-A	ENGINE MANAGEME	33.XXX (...05)	BOSCH EDC MS 6.1
 TG-A	ENGINE MANAGEME	33.XXX (06-..)	BOSCH EDC 7
 TG-A	ENGINE MANAGEME	33.XXX (06-..)	Bosch EDC 7 C32
 TG-A	ENGINE MANAGEME	35.XXX (...05)	BOSCH EDC 7
 TG-A	ENGINE MANAGEME	35.XXX (...05)	BOSCH EDC MS 6.1
 TG-A	ENGINE MANAGEME	35.XXX (06-..)	BOSCH EDC 7
 TG-A	ENGINE MANAGEME	35.XXX (06-..)	Bosch EDC 7 C32
 TG-A	ENGINE MANAGEME	39.XXX (06-..)	BOSCH EDC 7
 TG-A	ENGINE MANAGEME	39.XXX (06-..)	Bosch EDC 7 C32
 TG-A	ENGINE MANAGEME	40.XXX (06-..)	BOSCH EDC 7
 TG-A	ENGINE MANAGEME	40.XXX (06-..)	Bosch EDC 7 C32
 TG-A	ENGINE MANAGEME	41.XXX (...05)	BOSCH EDC 7
 TG-A	ENGINE MANAGEME	41.XXX (...05)	BOSCH EDC MS 6.1
 TG-A	ENGINE MANAGEME	41.XXX (06-..)	BOSCH EDC 7
 TG-A	ENGINE MANAGEME	41.XXX (06-..)	Bosch EDC 7 C32
 TG-A	MAINTENANCE SYST	18.XXX (...05)	
 TG-A	MAINTENANCE SYST	18.XXX (06-..)	
 TG-A	MAINTENANCE SYST	24.XXX (...05)	

## Systems supported by ECReader (up to V5.40)

### TRUCKS



























**MAN**

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 TG-A	MAINTENANCE SYST	24.XXX (06-..)	
 TG-A	MAINTENANCE SYST	26.XXX (...05)	
 TG-A	MAINTENANCE SYST	26.XXX (06-..)	
 TG-A	MAINTENANCE SYST	28.XXX (...05)	
 TG-A	MAINTENANCE SYST	28.XXX (06-..)	
 TG-A	MAINTENANCE SYST	32.XXX (...05)	
 TG-A	MAINTENANCE SYST	32.XXX (06-..)	
 TG-A	MAINTENANCE SYST	33.XXX (...05)	
 TG-A	MAINTENANCE SYST	33.XXX (06-..)	
 TG-A	MAINTENANCE SYST	35.XXX (...05)	
 TG-A	MAINTENANCE SYST	35.XXX (06-..)	
 TG-A	MAINTENANCE SYST	39.XXX (...05)	
 TG-A	MAINTENANCE SYST	39.XXX (06-..)	
 TG-A	MAINTENANCE SYST	40.XXX (...05)	
 TG-A	MAINTENANCE SYST	40.XXX (06-..)	
 TG-A	MAINTENANCE SYST	41.XXX (...05)	
 TG-A	MAINTENANCE SYST	41.XXX (06-..)	
 TG-A	SUSPENSION CONTR	18.XXX (...05)	WABCO ECAS
 TG-A	SUSPENSION CONTR	18.XXX (06-..)	WABCO ECAS
 TG-A	SUSPENSION CONTR	18.XXX (06-..)	WABCO ECAS 2
 TG-A	SUSPENSION CONTR	24.XXX (06-..)	WABCO ECAS
 TG-A	SUSPENSION CONTR	24.XXX (06-..)	WABCO ECAS 2
 TG-A	SUSPENSION CONTR	26.XXX (...05)	WABCO ECAS
 TG-A	SUSPENSION CONTR	26.XXX (06-..)	WABCO ECAS
 TG-A	SUSPENSION CONTR	26.XXX (06-..)	WABCO ECAS 2
 TG-A	SUSPENSION CONTR	28.XXX (06-..)	WABCO ECAS
 TG-A	SUSPENSION CONTR	28.XXX (06-..)	WABCO ECAS 2

## Systems supported by ECReader (up to V5.40)

### TRUCKS




























**MAN**

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 TG-A	SUSPENSION CONTR	32.XXX (06-..)	WABCO ECAS
 TG-A	SUSPENSION CONTR	32.XXX (06-..)	WABCO ECAS 2
 TG-A	SUSPENSION CONTR	33.XXX (..-05)	WABCO ECAS
 TG-A	SUSPENSION CONTR	33.XXX (06-..)	WABCO ECAS
 TG-A	SUSPENSION CONTR	33.XXX (06-..)	WABCO ECAS 2
 TG-A	SUSPENSION CONTR	35.XXX (..-05)	WABCO ECAS
 TG-A	SUSPENSION CONTR	35.XXX (06-..)	WABCO ECAS
 TG-A	SUSPENSION CONTR	35.XXX (06-..)	WABCO ECAS 2
 TG-A	SUSPENSION CONTR	39.XXX (06-..)	WABCO ECAS
 TG-A	SUSPENSION CONTR	39.XXX (06-..)	WABCO ECAS 2
 TG-A	SUSPENSION CONTR	40.XXX (06-..)	WABCO ECAS
 TG-A	SUSPENSION CONTR	40.XXX (06-..)	WABCO ECAS 2
 TG-A	SUSPENSION CONTR	41.XXX (..-05)	WABCO ECAS
 TG-A	SUSPENSION CONTR	41.XXX (06-..)	WABCO ECAS
 TG-A	SUSPENSION CONTR	41.XXX (06-..)	WABCO ECAS 2
 TG-L	AUTOM. TRANSMISSI	10.180 (05-..)	ZF ASTRONIC LITE
 TG-L	AUTOM. TRANSMISSI	10.180 FK (05-..)	ZF ASTRONIC LITE
 TG-L	AUTOM. TRANSMISSI	10.210 (05-..)	ZF ASTRONIC LITE
 TG-L	AUTOM. TRANSMISSI	10.210 FK (05-..)	ZF ASTRONIC LITE
 TG-L	AUTOM. TRANSMISSI	10.240 (05-..)	ZF ASTRONIC LITE
 TG-L	AUTOM. TRANSMISSI	10.240 FK (05-..)	ZF ASTRONIC LITE
 TG-L	AUTOM. TRANSMISSI	12.180 (05-..)	ZF ASTRONIC LITE
 TG-L	AUTOM. TRANSMISSI	12.180 FK (05-..)	ZF ASTRONIC LITE
 TG-L	AUTOM. TRANSMISSI	12.210 (05-..)	ZF ASTRONIC LITE
 TG-L	AUTOM. TRANSMISSI	12.210 FK (05-..)	ZF ASTRONIC LITE
 TG-L	AUTOM. TRANSMISSI	12.240 (05-..)	ZF ASTRONIC LITE

## Systems supported by ECReader (up to V5.40)

### TRUCKS




























**MAN**

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 TG-L	AUTOM. TRANSMISSI	12.240 FK (05-..)	ZF ASTRONIC LITE
 TG-L	AUTOM. TRANSMISSI	7.150 (05-..)	ZF ASTRONIC LITE
 TG-L	AUTOM. TRANSMISSI	8.180 (05-..)	ZF ASTRONIC LITE
 TG-L	AUTOM. TRANSMISSI	8.180 FK (05-..)	ZF ASTRONIC LITE
 TG-L	AUTOM. TRANSMISSI	8.210 (05-..)	ZF ASTRONIC LITE
 TG-L	AUTOM. TRANSMISSI	8.210 FK (05-..)	ZF ASTRONIC LITE
 TG-L	AUTOM. TRANSMISSI	8.240 (05-..)	ZF ASTRONIC LITE
 TG-L	AUTOM. TRANSMISSI	8.240 FK (05-..)	ZF ASTRONIC LITE
 TG-L	BRAKE SYS. MANAG	10.180 (05-..)	WABCO EBS 2
 TG-L	BRAKE SYS. MANAG	10.180 FK (05-..)	WABCO EBS 2
 TG-L	BRAKE SYS. MANAG	10.210 (05-..)	WABCO EBS 2
 TG-L	BRAKE SYS. MANAG	10.210 FK (05-..)	WABCO EBS 2
 TG-L	BRAKE SYS. MANAG	10.240 (05-..)	WABCO EBS 2
 TG-L	BRAKE SYS. MANAG	10.240 FK (05-..)	WABCO EBS 2
 TG-L	BRAKE SYS. MANAG	12.180 (05-..)	WABCO EBS 2
 TG-L	BRAKE SYS. MANAG	12.180 FK (05-..)	WABCO EBS 2
 TG-L	BRAKE SYS. MANAG	12.210 (05-..)	WABCO EBS 2
 TG-L	BRAKE SYS. MANAG	12.210 FK (05-..)	WABCO EBS 2
 TG-L	BRAKE SYS. MANAG	12.240 (05-..)	WABCO EBS 2
 TG-L	BRAKE SYS. MANAG	12.240 FK (05-..)	WABCO EBS 2
 TG-L	BRAKE SYS. MANAG	7.150 (05-..)	WABCO EBS 2
 TG-L	BRAKE SYS. MANAG	8.180 (05-..)	WABCO EBS 2
 TG-L	BRAKE SYS. MANAG	8.180 FK (05-..)	WABCO EBS 2
 TG-L	BRAKE SYS. MANAG	8.210 (05-..)	WABCO EBS 2
 TG-L	BRAKE SYS. MANAG	8.210 FK (05-..)	WABCO EBS 2
 TG-L	BRAKE SYS. MANAG	8.240 (05-..)	WABCO EBS 2
 TG-L	BRAKE SYS. MANAG	8.240 FK (05-..)	WABCO EBS 2

## Systems supported by ECUREADER (up to V5.40)

### TRUCKS




























**MAN**

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 TG-L	CHASSIS NETWORK	10.180 (05-..)	BERIFORS Door Module
 TG-L	CHASSIS NETWORK	10.180 (05-..)	WABCO Body Computer ZBR2
 TG-L	CHASSIS NETWORK	10.180 FK (05-..)	BERIFORS Door Module
 TG-L	CHASSIS NETWORK	10.180 FK (05-..)	WABCO Body Computer ZBR2
 TG-L	CHASSIS NETWORK	10.210 (05-..)	BERIFORS Door Module
 TG-L	CHASSIS NETWORK	10.210 (05-..)	WABCO Body Computer ZBR2
 TG-L	CHASSIS NETWORK	10.210 FK (05-..)	BERIFORS Door Module
 TG-L	CHASSIS NETWORK	10.210 FK (05-..)	WABCO Body Computer ZBR2
 TG-L	CHASSIS NETWORK	10.240 (05-..)	BERIFORS Door Module
 TG-L	CHASSIS NETWORK	10.240 (05-..)	WABCO Body Computer ZBR2
 TG-L	CHASSIS NETWORK	10.240 FK (05-..)	BERIFORS Door Module
 TG-L	CHASSIS NETWORK	10.240 FK (05-..)	WABCO Body Computer ZBR2
 TG-L	CHASSIS NETWORK	12.180 (05-..)	BERIFORS Door Module
 TG-L	CHASSIS NETWORK	12.180 (05-..)	WABCO Body Computer ZBR2
 TG-L	CHASSIS NETWORK	12.180 FK (05-..)	BERIFORS Door Module
 TG-L	CHASSIS NETWORK	12.180 FK (05-..)	WABCO Body Computer ZBR2
 TG-L	CHASSIS NETWORK	12.210 (05-..)	BERIFORS Door Module
 TG-L	CHASSIS NETWORK	12.210 (05-..)	WABCO Body Computer ZBR2
 TG-L	CHASSIS NETWORK	12.210 FK (05-..)	BERIFORS Door Module
 TG-L	CHASSIS NETWORK	12.210 FK (05-..)	WABCO Body Computer ZBR2
 TG-L	CHASSIS NETWORK	12.240 (05-..)	BERIFORS Door Module
 TG-L	CHASSIS NETWORK	12.240 (05-..)	WABCO Body Computer ZBR2
 TG-L	CHASSIS NETWORK	12.240 FK (05-..)	BERIFORS Door Module
 TG-L	CHASSIS NETWORK	12.240 FK (05-..)	WABCO Body Computer ZBR2
 TG-L	CHASSIS NETWORK	7.150 (05-..)	BERIFORS Door Module
 TG-L	CHASSIS NETWORK	7.150 (05-..)	WABCO Body Computer ZBR2
 TG-L	CHASSIS NETWORK	8.180 (05-..)	BERIFORS Door Module

## Systems supported by ECReader (up to V5.40)

### TRUCKS




























**MAN**

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 TG-L	CHASSIS NETWORK	8.180 (05-..)	WABCO Body Computer ZBR2
 TG-L	CHASSIS NETWORK	8.180 FK (05-..)	BERIFORS Door Module
 TG-L	CHASSIS NETWORK	8.180 FK (05-..)	WABCO Body Computer ZBR2
 TG-L	CHASSIS NETWORK	8.210 (05-..)	BERIFORS Door Module
 TG-L	CHASSIS NETWORK	8.210 (05-..)	WABCO Body Computer ZBR2
 TG-L	CHASSIS NETWORK	8.210 FK (05-..)	BERIFORS Door Module
 TG-L	CHASSIS NETWORK	8.210 FK (05-..)	WABCO Body Computer ZBR2
 TG-L	CHASSIS NETWORK	8.240 (05-..)	BERIFORS Door Module
 TG-L	CHASSIS NETWORK	8.240 (05-..)	WABCO Body Computer ZBR2
 TG-L	CHASSIS NETWORK	8.240 FK (05-..)	BERIFORS Door Module
 TG-L	CHASSIS NETWORK	8.240 FK (05-..)	WABCO Body Computer ZBR2
 TG-L	CLIMA	10.180 (05-..)	BEHR/GKR Klima
 TG-L	CLIMA	10.180 FK (05-..)	BEHR/GKR Klima
 TG-L	CLIMA	10.210 (05-..)	BEHR/GKR Klima
 TG-L	CLIMA	10.210 FK (05-..)	BEHR/GKR Klima
 TG-L	CLIMA	10.240 (05-..)	BEHR/GKR Klima
 TG-L	CLIMA	10.240 FK (05-..)	BEHR/GKR Klima
 TG-L	CLIMA	12.180 (05-..)	BEHR/GKR Klima
 TG-L	CLIMA	12.180 FK (05-..)	BEHR/GKR Klima
 TG-L	CLIMA	12.210 (05-..)	BEHR/GKR Klima
 TG-L	CLIMA	12.210 FK (05-..)	BEHR/GKR Klima
 TG-L	CLIMA	12.240 (05-..)	BEHR/GKR Klima
 TG-L	CLIMA	12.240 FK (05-..)	BEHR/GKR Klima
 TG-L	CLIMA	7.150 (05-..)	BEHR/GKR Klima
 TG-L	CLIMA	8.180 (05-..)	BEHR/GKR Klima
 TG-L	CLIMA	8.180 FK (05-..)	BEHR/GKR Klima
 TG-L	CLIMA	8.210 (05-..)	BEHR/GKR Klima

## Systems supported by ECUREADER (up to V5.40)

### TRUCKS













**MAN**

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 TG-L	CLIMA	8.210 FK (05-..)	BEHR/GKR Klima
 TG-L	CLIMA	8.240 (05-..)	BEHR/GKR Klima
 TG-L	CLIMA	8.240 FK (05-..)	BEHR/GKR Klima
 TG-L	DASHBOARD	10.180 (05-..)	Stoneridge Electronics
 TG-L	DASHBOARD	10.180 FK (05-..)	Stoneridge Electronics
 TG-L	DASHBOARD	10.210 (05-..)	Stoneridge Electronics
 TG-L	DASHBOARD	10.210 FK (05-..)	Stoneridge Electronics
 TG-L	DASHBOARD	10.240 (05-..)	Stoneridge Electronics
 TG-L	DASHBOARD	10.240 FK (05-..)	Stoneridge Electronics
 TG-L	DASHBOARD	12.180 (05-..)	Stoneridge Electronics
 TG-L	DASHBOARD	12.180 FK (05-..)	Stoneridge Electronics
 TG-L	DASHBOARD	12.210 (05-..)	Stoneridge Electronics
 TG-L	DASHBOARD	12.210 FK (05-..)	Stoneridge Electronics
 TG-L	DASHBOARD	12.240 (05-..)	Stoneridge Electronics
 TG-L	DASHBOARD	12.240 FK (05-..)	Stoneridge Electronics
 TG-L	DASHBOARD	7.150 (05-..)	Stoneridge Electronics
 TG-L	DASHBOARD	8.180 FK (05-..)	Stoneridge Electronics
 TG-L	DASHBOARD	8.210 (05-..)	Stoneridge Electronics
 TG-L	DASHBOARD	8.210 FK (05-..)	Stoneridge Electronics
 TG-L	DASHBOARD	8.240 (05-..)	Stoneridge Electronics
 TG-L	DASHBOARD	8.240 FK (05-..)	Stoneridge Electronics
 TG-L	ENGINE MANAGEME	10.180 (05-..)	BOSCH EDC 7
 TG-L	ENGINE MANAGEME	10.180 FK (05-..)	BOSCH EDC 7
 TG-L	ENGINE MANAGEME	10.210 (05-..)	BOSCH EDC 7
 TG-L	ENGINE MANAGEME	10.210 FK (05-..)	BOSCH EDC 7
 TG-L	ENGINE MANAGEME	10.240 (05-..)	BOSCH EDC 7
 TG-L	ENGINE MANAGEME	10.240 FK (05-..)	BOSCH EDC 7

## Systems supported by ECUreader (up to V5.40)

### TRUCKS



























**MAN**

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 TG-L	ENGINE MANAGEME	12.180 (05-..)	BOSCH EDC 7
 TG-L	ENGINE MANAGEME	12.180 FK (05-..)	BOSCH EDC 7
 TG-L	ENGINE MANAGEME	12.210 (05-..)	BOSCH EDC 7
 TG-L	ENGINE MANAGEME	12.210 FK (05-..)	BOSCH EDC 7
 TG-L	ENGINE MANAGEME	12.240 (05-..)	BOSCH EDC 7
 TG-L	ENGINE MANAGEME	12.240 FK (05-..)	BOSCH EDC 7
 TG-L	ENGINE MANAGEME	7.150 (05-..)	BOSCH EDC 7
 TG-L	ENGINE MANAGEME	8.180 (05-..)	BOSCH EDC 7
 TG-L	ENGINE MANAGEME	8.180 FK (05-..)	BOSCH EDC 7
 TG-L	ENGINE MANAGEME	8.210 (05-..)	BOSCH EDC 7
 TG-L	ENGINE MANAGEME	8.210 FK (05-..)	BOSCH EDC 7
 TG-L	ENGINE MANAGEME	8.240 (05-..)	BOSCH EDC 7
 TG-L	ENGINE MANAGEME	8.240 FK (05-..)	BOSCH EDC 7
 TG-L	SUSPENSION CONTR	10.180 (05-..)	WABCO ECAS 2
 TG-L	SUSPENSION CONTR	10.180 FK (05-..)	WABCO ECAS 2
 TG-L	SUSPENSION CONTR	10.210 (05-..)	WABCO ECAS 2
 TG-L	SUSPENSION CONTR	10.210 FK (05-..)	WABCO ECAS 2
 TG-L	SUSPENSION CONTR	10.240 (05-..)	WABCO ECAS 2
 TG-L	SUSPENSION CONTR	10.240 FK (05-..)	WABCO ECAS 2
 TG-L	SUSPENSION CONTR	12.180 (05-..)	WABCO ECAS 2
 TG-L	SUSPENSION CONTR	12.180 FK (05-..)	WABCO ECAS 2
 TG-L	SUSPENSION CONTR	12.210 (05-..)	WABCO ECAS 2
 TG-L	SUSPENSION CONTR	12.210 FK (05-..)	WABCO ECAS 2
 TG-L	SUSPENSION CONTR	12.240 (05-..)	WABCO ECAS 2
 TG-L	SUSPENSION CONTR	12.240 FK (05-..)	WABCO ECAS 2
 TG-L	SUSPENSION CONTR	7.150 (05-..)	WABCO ECAS 2
 TG-L	SUSPENSION CONTR	8.180 (05-..)	WABCO ECAS 2

## Systems supported by ECUREADER (up to V5.40)

### TRUCKS


























**MAN**

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 TG-L	SUSPENSION CONTR	8.180 FK (05-..)	WABCO ECAS 2
 TG-L	SUSPENSION CONTR	8.210 (05-..)	WABCO ECAS 2
 TG-L	SUSPENSION CONTR	8.210 FK (05-..)	WABCO ECAS 2
 TG-L	SUSPENSION CONTR	8.240 (05-..)	WABCO ECAS 2
 TG-L	SUSPENSION CONTR	8.240 FK (05-..)	WABCO ECAS 2
 TG-M	CHASSIS NETWORK	12.240 (08-..)	VDO Accelerator pedal calib. FFR STEP 11
 TG-M	CHASSIS NETWORK	12.250 (08-..)	VDO Accelerator pedal calib. FFR STEP 11
 TG-M	CHASSIS NETWORK	12.280 (08-..)	VDO Accelerator pedal calib. FFR STEP 11
 TG-M	CHASSIS NETWORK	12.290 (08-..)	VDO Accelerator pedal calib. FFR STEP 11
 TG-M	CHASSIS NETWORK	15.240 (08-..)	VDO Accelerator pedal calib. FFR STEP 11
 TG-M	CHASSIS NETWORK	15.250 (08-..)	VDO Accelerator pedal calib. FFR STEP 11
 TG-M	CHASSIS NETWORK	15.280 (08-..)	VDO Accelerator pedal calib. FFR STEP 11
 TG-M	CHASSIS NETWORK	15.290 (08-..)	VDO Accelerator pedal calib. FFR STEP 11
 TG-M	CHASSIS NETWORK	18.240 (08-..)	VDO Accelerator pedal calib. FFR STEP 11
 TG-M	CHASSIS NETWORK	18.250 (08-..)	VDO Accelerator pedal calib. FFR STEP 11
 TG-M	CHASSIS NETWORK	18.280 (08-..)	VDO Accelerator pedal calib. FFR STEP 11
 TG-M	CHASSIS NETWORK	18.290 (08-..)	VDO Accelerator pedal calib. FFR STEP 11
 TG-M	CHASSIS NETWORK	26.240 (08-..)	VDO Accelerator pedal calib. FFR STEP 11
 TG-M	CHASSIS NETWORK	26.250 (08-..)	VDO Accelerator pedal calib. FFR STEP 11
 TG-M	CHASSIS NETWORK	26.280 (08-..)	VDO Accelerator pedal calib. FFR STEP 11
 TG-M	CHASSIS NETWORK	26.290 (08-..)	VDO Accelerator pedal calib. FFR STEP 11
 TG-M	ENGINE MANAGEME	12.240 (08-..)	Bosch EDC 7 C32
 TG-M	ENGINE MANAGEME	12.250 (08-..)	Bosch EDC 7 C32
 TG-M	ENGINE MANAGEME	12.280 (08-..)	Bosch EDC 7 C32
 TG-M	ENGINE MANAGEME	12.290 (08-..)	Bosch EDC 7 C32
 TG-M	ENGINE MANAGEME	15.240 (08-..)	Bosch EDC 7 C32

## Systems supported by ECUREADER (up to V5.40)

### TRUCKS



























**MAN**

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 TG-M	ENGINE MANAGEME	15.250 (08-..)	Bosch EDC 7 C32
 TG-M	ENGINE MANAGEME	15.280 (08-..)	Bosch EDC 7 C32
 TG-M	ENGINE MANAGEME	15.290 (08-..)	Bosch EDC 7 C32
 TG-M	ENGINE MANAGEME	18.240 (08-..)	Bosch EDC 7 C32
 TG-M	ENGINE MANAGEME	18.250 (08-..)	Bosch EDC 7 C32
 TG-M	ENGINE MANAGEME	18.280 (08-..)	Bosch EDC 7 C32
 TG-M	ENGINE MANAGEME	18.290 (08-..)	Bosch EDC 7 C32
 TG-M	ENGINE MANAGEME	26.240 (08-..)	Bosch EDC 7 C32
 TG-M	ENGINE MANAGEME	26.250 (08-..)	Bosch EDC 7 C32
 TG-M	ENGINE MANAGEME	26.280 (08-..)	Bosch EDC 7 C32
 TG-M	ENGINE MANAGEME	26.290 (08-..)	Bosch EDC 7 C32
 TG-M	MAINTENANCE SYST	12.240 (08-..)	
 TG-M	MAINTENANCE SYST	12.250 (08-..)	
 TG-M	MAINTENANCE SYST	12.280 (08-..)	
 TG-M	MAINTENANCE SYST	12.290 (08-..)	
 TG-M	MAINTENANCE SYST	15.240 (08-..)	
 TG-M	MAINTENANCE SYST	15.250 (08-..)	
 TG-M	MAINTENANCE SYST	15.280 (08-..)	
 TG-M	MAINTENANCE SYST	15.290 (08-..)	
 TG-M	MAINTENANCE SYST	18.240 (08-..)	
 TG-M	MAINTENANCE SYST	18.250 (08-..)	
 TG-M	MAINTENANCE SYST	18.280 (08-..)	
 TG-M	MAINTENANCE SYST	18.290 (08-..)	
 TG-M	MAINTENANCE SYST	26.240 (08-..)	
 TG-M	MAINTENANCE SYST	26.250 (08-..)	
 TG-M	MAINTENANCE SYST	26.280 (08-..)	
 TG-M	MAINTENANCE SYST	26.290 (08-..)	

## Systems supported by ECReader (up to V5.40)

### TRUCKS




























**MAN**

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 TG-S	BRAKE SYS. MANAG	18.320 (08-..)	Knorr EBS 5
 TG-S	BRAKE SYS. MANAG	18.360 (08-..)	Knorr EBS 5
 TG-S	BRAKE SYS. MANAG	18.400 (08-..)	Knorr EBS 5
 TG-S	BRAKE SYS. MANAG	18.440 (08-..)	Knorr EBS 5
 TG-S	BRAKE SYS. MANAG	18.480 (08-..)	Knorr EBS 5
 TG-S	BRAKE SYS. MANAG	24.320 (08-..)	Knorr EBS 5
 TG-S	BRAKE SYS. MANAG	24.360 (08-..)	Knorr EBS 5
 TG-S	BRAKE SYS. MANAG	24.400 (08-..)	Knorr EBS 5
 TG-S	BRAKE SYS. MANAG	24.440 (08-..)	Knorr EBS 5
 TG-S	BRAKE SYS. MANAG	24.480 (08-..)	Knorr EBS 5
 TG-S	BRAKE SYS. MANAG	26.320 (08-..)	Knorr EBS 5
 TG-S	BRAKE SYS. MANAG	26.360 (08-..)	Knorr EBS 5
 TG-S	BRAKE SYS. MANAG	26.400 (08-..)	Knorr EBS 5
 TG-S	BRAKE SYS. MANAG	26.440 (08-..)	Knorr EBS 5
 TG-S	BRAKE SYS. MANAG	26.480 (08-..)	Knorr EBS 5
 TG-S	BRAKE SYS. MANAG	26.540 (08-..)	Knorr EBS 5
 TG-S	BRAKE SYS. MANAG	28.320 (08-..)	Knorr EBS 5
 TG-S	BRAKE SYS. MANAG	28.360 (08-..)	Knorr EBS 5
 TG-S	BRAKE SYS. MANAG	28.400 (08-..)	Knorr EBS 5
 TG-S	BRAKE SYS. MANAG	28.440 (08-..)	Knorr EBS 5
 TG-S	BRAKE SYS. MANAG	28.480 (08-..)	Knorr EBS 5
 TG-S	BRAKE SYS. MANAG	33.320 (08-..)	Knorr EBS 5
 TG-S	BRAKE SYS. MANAG	33.360 (08-..)	Knorr EBS 5
 TG-S	BRAKE SYS. MANAG	33.400 (08-..)	Knorr EBS 5
 TG-S	BRAKE SYS. MANAG	33.440 (08-..)	Knorr EBS 5
 TG-S	BRAKE SYS. MANAG	33.480 (08-..)	Knorr EBS 5

## Systems supported by ECUreader (up to V5.40)

### TRUCKS




























**MAN**

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 TG-S	BRAKE SYS. MANAG	33.540 (08-..)	Knorr EBS 5
 TG-S	BRAKE SYS. MANAG	35.320 (08-..)	Knorr EBS 5
 TG-S	BRAKE SYS. MANAG	35.360 (08-..)	Knorr EBS 5
 TG-S	BRAKE SYS. MANAG	35.400 (08-..)	Knorr EBS 5
 TG-S	BRAKE SYS. MANAG	35.440 (08-..)	Knorr EBS 5
 TG-S	BRAKE SYS. MANAG	35.480 (08-..)	Knorr EBS 5
 TG-S	BRAKE SYS. MANAG	37.320 (08-..)	Knorr EBS 5
 TG-S	BRAKE SYS. MANAG	37.360 (08-..)	Knorr EBS 5
 TG-S	BRAKE SYS. MANAG	37.400 (08-..)	Knorr EBS 5
 TG-S	BRAKE SYS. MANAG	37.440 (08-..)	Knorr EBS 5
 TG-S	BRAKE SYS. MANAG	37.480 (08-..)	Knorr EBS 5
 TG-S	BRAKE SYS. MANAG	39.320 (08-..)	Knorr EBS 5
 TG-S	BRAKE SYS. MANAG	39.360 (08-..)	Knorr EBS 5
 TG-S	BRAKE SYS. MANAG	39.400 (08-..)	Knorr EBS 5
 TG-S	BRAKE SYS. MANAG	39.440 (08-..)	Knorr EBS 5
 TG-S	BRAKE SYS. MANAG	39.480 (08-..)	Knorr EBS 5
 TG-S	BRAKE SYS. MANAG	40.440 (08-..)	Knorr EBS 5
 TG-S	BRAKE SYS. MANAG	40.480 (08-..)	Knorr EBS 5
 TG-S	BRAKE SYS. MANAG	41.320 (08-..)	Knorr EBS 5
 TG-S	BRAKE SYS. MANAG	41.360 (08-..)	Knorr EBS 5
 TG-S	BRAKE SYS. MANAG	41.400 (08-..)	Knorr EBS 5
 TG-S	BRAKE SYS. MANAG	41.440 (08-..)	Knorr EBS 5
 TG-S	BRAKE SYS. MANAG	41.480 (08-..)	Knorr EBS 5
 TG-S	BRAKE SYS. MANAG	41.540 (08-..)	Knorr EBS 5
 TG-S	CHASSIS NETWORK	18.320 (08-..)	VDO Accelerator pedal calib. FFR STEP 11
 TG-S	CHASSIS NETWORK	18.320 (08-..)	VDO Clutch Calibration FFR STEP 11
 TG-S	CHASSIS NETWORK	18.360 (08-..)	VDO Accelerator pedal calib. FFR STEP 11

## Systems supported by ECReader (up to V5.40)

### TRUCKS




























**MAN**

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 TG-S	CHASSIS NETWORK	18.360 (08-..)	VDO Clutch Calibration FFR STEP 11
 TG-S	CHASSIS NETWORK	18.400 (08-..)	VDO Accelerator pedal calib. FFR STEP 11
 TG-S	CHASSIS NETWORK	18.400 (08-..)	VDO Clutch Calibration FFR STEP 11
 TG-S	CHASSIS NETWORK	18.440 (08-..)	VDO Accelerator pedal calib. FFR STEP 11
 TG-S	CHASSIS NETWORK	18.440 (08-..)	VDO Clutch Calibration FFR STEP 11
 TG-S	CHASSIS NETWORK	18.480 (08-..)	VDO Accelerator pedal calib. FFR STEP 11
 TG-S	CHASSIS NETWORK	18.480 (08-..)	VDO Clutch Calibration FFR STEP 11
 TG-S	CHASSIS NETWORK	24.320 (08-..)	VDO Accelerator pedal calib. FFR STEP 11
 TG-S	CHASSIS NETWORK	24.320 (08-..)	VDO Clutch Calibration FFR STEP 11
 TG-S	CHASSIS NETWORK	24.360 (08-..)	VDO Accelerator pedal calib. FFR STEP 11
 TG-S	CHASSIS NETWORK	24.360 (08-..)	VDO Clutch Calibration FFR STEP 11
 TG-S	CHASSIS NETWORK	24.400 (08-..)	VDO Accelerator pedal calib. FFR STEP 11
 TG-S	CHASSIS NETWORK	24.400 (08-..)	VDO Clutch Calibration FFR STEP 11
 TG-S	CHASSIS NETWORK	24.440 (08-..)	VDO Accelerator pedal calib. FFR STEP 11
 TG-S	CHASSIS NETWORK	24.440 (08-..)	VDO Clutch Calibration FFR STEP 11
 TG-S	CHASSIS NETWORK	24.480 (08-..)	VDO Accelerator pedal calib. FFR STEP 11
 TG-S	CHASSIS NETWORK	24.480 (08-..)	VDO Clutch Calibration FFR STEP 11
 TG-S	CHASSIS NETWORK	26.320 (08-..)	VDO Accelerator pedal calib. FFR STEP 11
 TG-S	CHASSIS NETWORK	26.320 (08-..)	VDO Clutch Calibration FFR STEP 11
 TG-S	CHASSIS NETWORK	26.360 (08-..)	VDO Accelerator pedal calib. FFR STEP 11
 TG-S	CHASSIS NETWORK	26.360 (08-..)	VDO Clutch Calibration FFR STEP 11
 TG-S	CHASSIS NETWORK	26.400 (08-..)	VDO Accelerator pedal calib. FFR STEP 11
 TG-S	CHASSIS NETWORK	26.400 (08-..)	VDO Clutch Calibration FFR STEP 11
 TG-S	CHASSIS NETWORK	26.440 (08-..)	VDO Accelerator pedal calib. FFR STEP 11
 TG-S	CHASSIS NETWORK	26.440 (08-..)	VDO Clutch Calibration FFR STEP 11
 TG-S	CHASSIS NETWORK	26.480 (08-..)	VDO Accelerator pedal calib. FFR STEP 11
 TG-S	CHASSIS NETWORK	26.480 (08-..)	VDO Clutch Calibration FFR STEP 11

## Systems supported by ECUREADER (up to V5.40)

### TRUCKS




























**MAN**

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 TG-S	CHASSIS NETWORK	26.540 (08-..)	VDO Accelerator pedal calib. FFR STEP 11
 TG-S	CHASSIS NETWORK	26.540 (08-..)	VDO Clutch Calibration FFR STEP 11
 TG-S	CHASSIS NETWORK	28.320 (08-..)	VDO Accelerator pedal calib. FFR STEP 11
 TG-S	CHASSIS NETWORK	28.320 (08-..)	VDO Clutch Calibration FFR STEP 11
 TG-S	CHASSIS NETWORK	28.360 (08-..)	VDO Accelerator pedal calib. FFR STEP 11
 TG-S	CHASSIS NETWORK	28.360 (08-..)	VDO Clutch Calibration FFR STEP 11
 TG-S	CHASSIS NETWORK	28.400 (08-..)	VDO Accelerator pedal calib. FFR STEP 11
 TG-S	CHASSIS NETWORK	28.400 (08-..)	VDO Clutch Calibration FFR STEP 11
 TG-S	CHASSIS NETWORK	28.440 (08-..)	VDO Accelerator pedal calib. FFR STEP 11
 TG-S	CHASSIS NETWORK	28.440 (08-..)	VDO Clutch Calibration FFR STEP 11
 TG-S	CHASSIS NETWORK	28.480 (08-..)	VDO Accelerator pedal calib. FFR STEP 11
 TG-S	CHASSIS NETWORK	28.480 (08-..)	VDO Clutch Calibration FFR STEP 11
 TG-S	CHASSIS NETWORK	33.320 (08-..)	VDO Accelerator pedal calib. FFR STEP 11
 TG-S	CHASSIS NETWORK	33.320 (08-..)	VDO Clutch Calibration FFR STEP 11
 TG-S	CHASSIS NETWORK	33.360 (08-..)	VDO Accelerator pedal calib. FFR STEP 11
 TG-S	CHASSIS NETWORK	33.360 (08-..)	VDO Clutch Calibration FFR STEP 11
 TG-S	CHASSIS NETWORK	33.400 (08-..)	VDO Accelerator pedal calib. FFR STEP 11
 TG-S	CHASSIS NETWORK	33.400 (08-..)	VDO Clutch Calibration FFR STEP 11
 TG-S	CHASSIS NETWORK	33.440 (08-..)	VDO Accelerator pedal calib. FFR STEP 11
 TG-S	CHASSIS NETWORK	33.440 (08-..)	VDO Clutch Calibration FFR STEP 11
 TG-S	CHASSIS NETWORK	33.480 (08-..)	VDO Accelerator pedal calib. FFR STEP 11
 TG-S	CHASSIS NETWORK	33.480 (08-..)	VDO Clutch Calibration FFR STEP 11
 TG-S	CHASSIS NETWORK	33.540 (08-..)	VDO Accelerator pedal calib. FFR STEP 11
 TG-S	CHASSIS NETWORK	33.540 (08-..)	VDO Clutch Calibration FFR STEP 11
 TG-S	CHASSIS NETWORK	35.320 (08-..)	VDO Accelerator pedal calib. FFR STEP 11
 TG-S	CHASSIS NETWORK	35.320 (08-..)	VDO Clutch Calibration FFR STEP 11
 TG-S	CHASSIS NETWORK	35.360 (08-..)	VDO Accelerator pedal calib. FFR STEP 11

## Systems supported by ECUREADER (up to V5.40)

### TRUCKS




























**MAN**

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 TG-S	CHASSIS NETWORK	35.360 (08-..)	VDO Clutch Calibration FFR STEP 11
 TG-S	CHASSIS NETWORK	35.400 (08-..)	VDO Accelerator pedal calib. FFR STEP 11
 TG-S	CHASSIS NETWORK	35.400 (08-..)	VDO Clutch Calibration FFR STEP 11
 TG-S	CHASSIS NETWORK	35.440 (08-..)	VDO Accelerator pedal calib. FFR STEP 11
 TG-S	CHASSIS NETWORK	35.440 (08-..)	VDO Clutch Calibration FFR STEP 11
 TG-S	CHASSIS NETWORK	35.480 (08-..)	VDO Accelerator pedal calib. FFR STEP 11
 TG-S	CHASSIS NETWORK	35.480 (08-..)	VDO Clutch Calibration FFR STEP 11
 TG-S	CHASSIS NETWORK	37.320 (08-..)	VDO Accelerator pedal calib. FFR STEP 11
 TG-S	CHASSIS NETWORK	37.320 (08-..)	VDO Clutch Calibration FFR STEP 11
 TG-S	CHASSIS NETWORK	37.360 (08-..)	VDO Accelerator pedal calib. FFR STEP 11
 TG-S	CHASSIS NETWORK	37.360 (08-..)	VDO Clutch Calibration FFR STEP 11
 TG-S	CHASSIS NETWORK	37.400 (08-..)	VDO Accelerator pedal calib. FFR STEP 11
 TG-S	CHASSIS NETWORK	37.400 (08-..)	VDO Clutch Calibration FFR STEP 11
 TG-S	CHASSIS NETWORK	37.440 (08-..)	VDO Accelerator pedal calib. FFR STEP 11
 TG-S	CHASSIS NETWORK	37.440 (08-..)	VDO Clutch Calibration FFR STEP 11
 TG-S	CHASSIS NETWORK	37.480 (08-..)	VDO Accelerator pedal calib. FFR STEP 11
 TG-S	CHASSIS NETWORK	37.480 (08-..)	VDO Clutch Calibration FFR STEP 11
 TG-S	CHASSIS NETWORK	39.320 (08-..)	VDO Accelerator pedal calib. FFR STEP 11
 TG-S	CHASSIS NETWORK	39.320 (08-..)	VDO Clutch Calibration FFR STEP 11
 TG-S	CHASSIS NETWORK	39.360 (08-..)	VDO Accelerator pedal calib. FFR STEP 11
 TG-S	CHASSIS NETWORK	39.360 (08-..)	VDO Clutch Calibration FFR STEP 11
 TG-S	CHASSIS NETWORK	39.400 (08-..)	VDO Accelerator pedal calib. FFR STEP 11
 TG-S	CHASSIS NETWORK	39.400 (08-..)	VDO Clutch Calibration FFR STEP 11
 TG-S	CHASSIS NETWORK	39.440 (08-..)	VDO Accelerator pedal calib. FFR STEP 11
 TG-S	CHASSIS NETWORK	39.440 (08-..)	VDO Clutch Calibration FFR STEP 11
 TG-S	CHASSIS NETWORK	39.480 (08-..)	VDO Accelerator pedal calib. FFR STEP 11
 TG-S	CHASSIS NETWORK	39.480 (08-..)	VDO Clutch Calibration FFR STEP 11

## Systems supported by ECUREADER (up to V5.40)

### TRUCKS




























**MAN**

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 TG-S	CHASSIS NETWORK	40.440 (08-..)	VDO Accelerator pedal calib. FFR STEP 11
 TG-S	CHASSIS NETWORK	40.440 (08-..)	VDO Clutch Calibration FFR STEP 11
 TG-S	CHASSIS NETWORK	40.480 (08-..)	VDO Accelerator pedal calib. FFR STEP 11
 TG-S	CHASSIS NETWORK	40.480 (08-..)	VDO Clutch Calibration FFR STEP 11
 TG-S	CHASSIS NETWORK	41.320 (08-..)	VDO Accelerator pedal calib. FFR STEP 11
 TG-S	CHASSIS NETWORK	41.320 (08-..)	VDO Clutch Calibration FFR STEP 11
 TG-S	CHASSIS NETWORK	41.360 (08-..)	VDO Accelerator pedal calib. FFR STEP 11
 TG-S	CHASSIS NETWORK	41.360 (08-..)	VDO Clutch Calibration FFR STEP 11
 TG-S	CHASSIS NETWORK	41.400 (08-..)	VDO Accelerator pedal calib. FFR STEP 11
 TG-S	CHASSIS NETWORK	41.400 (08-..)	VDO Clutch Calibration FFR STEP 11
 TG-S	CHASSIS NETWORK	41.440 (08-..)	VDO Accelerator pedal calib. FFR STEP 11
 TG-S	CHASSIS NETWORK	41.440 (08-..)	VDO Clutch Calibration FFR STEP 11
 TG-S	CHASSIS NETWORK	41.480 (08-..)	VDO Accelerator pedal calib. FFR STEP 11
 TG-S	CHASSIS NETWORK	41.480 (08-..)	VDO Clutch Calibration FFR STEP 11
 TG-S	CHASSIS NETWORK	41.540 (08-..)	VDO Accelerator pedal calib. FFR STEP 11
 TG-S	CHASSIS NETWORK	41.540 (08-..)	VDO Clutch Calibration FFR STEP 11
 TG-S	DASHBOARD	18.320 (08-..)	Stoneridge Electronics
 TG-S	DASHBOARD	18.360 (08-..)	Stoneridge Electronics
 TG-S	DASHBOARD	18.400 (08-..)	Stoneridge Electronics
 TG-S	DASHBOARD	18.440 (08-..)	Stoneridge Electronics
 TG-S	DASHBOARD	18.480 (08-..)	Stoneridge Electronics
 TG-S	DASHBOARD	24.320 (08-..)	Stoneridge Electronics
 TG-S	DASHBOARD	24.360 (08-..)	Stoneridge Electronics
 TG-S	DASHBOARD	24.400 (08-..)	Stoneridge Electronics
 TG-S	DASHBOARD	24.440 (08-..)	Stoneridge Electronics
 TG-S	DASHBOARD	24.480 (08-..)	Stoneridge Electronics
 TG-S	DASHBOARD	26.320 (08-..)	Stoneridge Electronics

## Systems supported by ECureader (up to V5.40)

### TRUCKS




























**MAN**

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 TG-S	DASHBOARD	26.360 (08-..)	Stoneridge Electronics
 TG-S	DASHBOARD	26.400 (08-..)	Stoneridge Electronics
 TG-S	DASHBOARD	26.440 (08-..)	Stoneridge Electronics
 TG-S	DASHBOARD	26.480 (08-..)	Stoneridge Electronics
 TG-S	DASHBOARD	26.540 (08-..)	Stoneridge Electronics
 TG-S	DASHBOARD	28.320 (08-..)	Stoneridge Electronics
 TG-S	DASHBOARD	28.360 (08-..)	Stoneridge Electronics
 TG-S	DASHBOARD	28.400 (08-..)	Stoneridge Electronics
 TG-S	DASHBOARD	28.440 (08-..)	Stoneridge Electronics
 TG-S	DASHBOARD	28.480 (08-..)	Stoneridge Electronics
 TG-S	DASHBOARD	33.320 (08-..)	Stoneridge Electronics
 TG-S	DASHBOARD	33.360 (08-..)	Stoneridge Electronics
 TG-S	DASHBOARD	33.400 (08-..)	Stoneridge Electronics
 TG-S	DASHBOARD	33.440 (08-..)	Stoneridge Electronics
 TG-S	DASHBOARD	33.480 (08-..)	Stoneridge Electronics
 TG-S	DASHBOARD	33.540 (08-..)	Stoneridge Electronics
 TG-S	DASHBOARD	35.320 (08-..)	Stoneridge Electronics
 TG-S	DASHBOARD	35.360 (08-..)	Stoneridge Electronics
 TG-S	DASHBOARD	35.400 (08-..)	Stoneridge Electronics
 TG-S	DASHBOARD	35.440 (08-..)	Stoneridge Electronics
 TG-S	DASHBOARD	35.480 (08-..)	Stoneridge Electronics
 TG-S	DASHBOARD	37.320 (08-..)	Stoneridge Electronics
 TG-S	DASHBOARD	37.360 (08-..)	Stoneridge Electronics
 TG-S	DASHBOARD	37.400 (08-..)	Stoneridge Electronics
 TG-S	DASHBOARD	37.440 (08-..)	Stoneridge Electronics
 TG-S	DASHBOARD	37.480 (08-..)	Stoneridge Electronics
 TG-S	DASHBOARD	39.320 (08-..)	Stoneridge Electronics

## Systems supported by ECUREADER (up to V5.40)

### TRUCKS




























**MAN**

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 TG-S	DASHBOARD	39.360 (08-..)	Stoneridge Electronics
 TG-S	DASHBOARD	39.400 (08-..)	Stoneridge Electronics
 TG-S	DASHBOARD	39.440 (08-..)	Stoneridge Electronics
 TG-S	DASHBOARD	39.480 (08-..)	Stoneridge Electronics
 TG-S	DASHBOARD	40.440 (08-..)	Stoneridge Electronics
 TG-S	DASHBOARD	40.480 (08-..)	Stoneridge Electronics
 TG-S	DASHBOARD	41.320 (08-..)	Stoneridge Electronics
 TG-S	DASHBOARD	41.360 (08-..)	Stoneridge Electronics
 TG-S	DASHBOARD	41.400 (08-..)	Stoneridge Electronics
 TG-S	DASHBOARD	41.440 (08-..)	Stoneridge Electronics
 TG-S	DASHBOARD	41.480 (08-..)	Stoneridge Electronics
 TG-S	DASHBOARD	41.540 (08-..)	Stoneridge Electronics
 TG-S	ENGINE MANAGEME	18.320 (08-..)	Bosch EDC 7 C32
 TG-S	ENGINE MANAGEME	18.360 (08-..)	Bosch EDC 7 C32
 TG-S	ENGINE MANAGEME	18.400 (08-..)	Bosch EDC 7 C32
 TG-S	ENGINE MANAGEME	18.440 (08-..)	Bosch EDC 7 C32
 TG-S	ENGINE MANAGEME	18.480 (08-..)	Bosch EDC 7 C32
 TG-S	ENGINE MANAGEME	24.320 (08-..)	Bosch EDC 7 C32
 TG-S	ENGINE MANAGEME	24.360 (08-..)	Bosch EDC 7 C32
 TG-S	ENGINE MANAGEME	24.400 (08-..)	Bosch EDC 7 C32
 TG-S	ENGINE MANAGEME	24.440 (08-..)	Bosch EDC 7 C32
 TG-S	ENGINE MANAGEME	24.480 (08-..)	Bosch EDC 7 C32
 TG-S	ENGINE MANAGEME	26.320 (08-..)	Bosch EDC 7 C32
 TG-S	ENGINE MANAGEME	26.360 (08-..)	Bosch EDC 7 C32
 TG-S	ENGINE MANAGEME	26.400 (08-..)	Bosch EDC 7 C32
 TG-S	ENGINE MANAGEME	26.440 (08-..)	Bosch EDC 7 C32
 TG-S	ENGINE MANAGEME	26.480 (08-..)	Bosch EDC 7 C32

## Systems supported by ECReader (up to V5.40)

### TRUCKS



























**MAN**

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 TG-S	ENGINE MANAGEME	26.540 (08-..)	Bosch EDC 7 C32
 TG-S	ENGINE MANAGEME	28.320 (08-..)	Bosch EDC 7 C32
 TG-S	ENGINE MANAGEME	28.360 (08-..)	Bosch EDC 7 C32
 TG-S	ENGINE MANAGEME	28.400 (08-..)	Bosch EDC 7 C32
 TG-S	ENGINE MANAGEME	28.440 (08-..)	Bosch EDC 7 C32
 TG-S	ENGINE MANAGEME	28.480 (08-..)	Bosch EDC 7 C32
 TG-S	ENGINE MANAGEME	33.320 (08-..)	Bosch EDC 7 C32
 TG-S	ENGINE MANAGEME	33.360 (08-..)	Bosch EDC 7 C32
 TG-S	ENGINE MANAGEME	33.400 (08-..)	Bosch EDC 7 C32
 TG-S	ENGINE MANAGEME	33.440 (08-..)	Bosch EDC 7 C32
 TG-S	ENGINE MANAGEME	33.480 (08-..)	Bosch EDC 7 C32
 TG-S	ENGINE MANAGEME	33.540 (08-..)	Bosch EDC 7 C32
 TG-S	ENGINE MANAGEME	35.320 (08-..)	Bosch EDC 7 C32
 TG-S	ENGINE MANAGEME	35.360 (08-..)	Bosch EDC 7 C32
 TG-S	ENGINE MANAGEME	35.400 (08-..)	Bosch EDC 7 C32
 TG-S	ENGINE MANAGEME	35.440 (08-..)	Bosch EDC 7 C32
 TG-S	ENGINE MANAGEME	35.480 (08-..)	Bosch EDC 7 C32
 TG-S	ENGINE MANAGEME	37.320 (08-..)	Bosch EDC 7 C32
 TG-S	ENGINE MANAGEME	37.360 (08-..)	Bosch EDC 7 C32
 TG-S	ENGINE MANAGEME	37.400 (08-..)	Bosch EDC 7 C32
 TG-S	ENGINE MANAGEME	37.440 (08-..)	Bosch EDC 7 C32
 TG-S	ENGINE MANAGEME	37.480 (08-..)	Bosch EDC 7 C32
 TG-S	ENGINE MANAGEME	39.320 (08-..)	Bosch EDC 7 C32
 TG-S	ENGINE MANAGEME	39.360 (08-..)	Bosch EDC 7 C32
 TG-S	ENGINE MANAGEME	39.400 (08-..)	Bosch EDC 7 C32
 TG-S	ENGINE MANAGEME	39.440 (08-..)	Bosch EDC 7 C32
 TG-S	ENGINE MANAGEME	39.480 (08-..)	Bosch EDC 7 C32

## Systems supported by ECReader (up to V5.40)

### TRUCKS




























**MAN**

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 TG-S	ENGINE MANAGEME	40.440 (08-..)	Bosch EDC 7 C32
 TG-S	ENGINE MANAGEME	40.480 (08-..)	Bosch EDC 7 C32
 TG-S	ENGINE MANAGEME	41.320 (08-..)	Bosch EDC 7 C32
 TG-S	ENGINE MANAGEME	41.360 (08-..)	Bosch EDC 7 C32
 TG-S	ENGINE MANAGEME	41.400 (08-..)	Bosch EDC 7 C32
 TG-S	ENGINE MANAGEME	41.440 (08-..)	Bosch EDC 7 C32
 TG-S	ENGINE MANAGEME	41.480 (08-..)	Bosch EDC 7 C32
 TG-S	ENGINE MANAGEME	41.540 (08-..)	Bosch EDC 7 C32
 TG-X	AUX. HEATING	18.360 (08-..)	Eberspacher Airtronic D2/D4
 TG-X	AUX. HEATING	18.400 (08-..)	Eberspacher Airtronic D2/D4
 TG-X	AUX. HEATING	18.440 (08-..)	Eberspacher Airtronic D2/D4
 TG-X	AUX. HEATING	18.480 (08-..)	Eberspacher Airtronic D2/D4
 TG-X	AUX. HEATING	18.540 (08-..)	Eberspacher Airtronic D2/D4
 TG-X	AUX. HEATING	18.680 (08-..)	Eberspacher Airtronic D2/D4
 TG-X	AUX. HEATING	24.360 (08-..)	Eberspacher Airtronic D2/D4
 TG-X	AUX. HEATING	24.400 (08-..)	Eberspacher Airtronic D2/D4
 TG-X	AUX. HEATING	24.440 (08-..)	Eberspacher Airtronic D2/D4
 TG-X	AUX. HEATING	24.480 (08-..)	Eberspacher Airtronic D2/D4
 TG-X	AUX. HEATING	24.540 (08-..)	Eberspacher Airtronic D2/D4
 TG-X	AUX. HEATING	26.360 (08-..)	Eberspacher Airtronic D2/D4
 TG-X	AUX. HEATING	26.400 (08-..)	Eberspacher Airtronic D2/D4
 TG-X	AUX. HEATING	26.440 (08-..)	Eberspacher Airtronic D2/D4
 TG-X	AUX. HEATING	26.480 (08-..)	Eberspacher Airtronic D2/D4
 TG-X	AUX. HEATING	26.540 (08-..)	Eberspacher Airtronic D2/D4
 TG-X	AUX. HEATING	28.360 (08-..)	Eberspacher Airtronic D2/D4
 TG-X	AUX. HEATING	28.400 (08-..)	Eberspacher Airtronic D2/D4

## Systems supported by ECReader (up to V5.40)

### TRUCKS





**MAN**

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 TG-X	AUX. HEATING	28.440 (08-..)	Eberspacher Airtronic D2/D4
 TG-X	AUX. HEATING	28.480 (08-..)	Eberspacher Airtronic D2/D4
 TG-X	AUX. HEATING	28.540 (08-..)	Eberspacher Airtronic D2/D4
 TG-X	AUX. HEATING	33.360 (08-..)	Eberspacher Airtronic D2/D4
 TG-X	AUX. HEATING	33.400 (08-..)	Eberspacher Airtronic D2/D4
 TG-X	AUX. HEATING	33.440 (08-..)	Eberspacher Airtronic D2/D4
 TG-X	AUX. HEATING	33.480 (08-..)	Eberspacher Airtronic D2/D4
 TG-X	AUX. HEATING	33.680 (08-..)	Eberspacher Airtronic D2/D4
 TG-X	AUX. HEATING	41.540 (08-..)	Eberspacher Airtronic D2/D4
 TG-X	AUX. HEATING	41.680 (08-..)	Eberspacher Airtronic D2/D4
 TG-X	BRAKE POWER SUP	18.360 (08-..)	ZF Intarder
 TG-X	BRAKE POWER SUP	18.400 (08-..)	ZF Intarder
 TG-X	BRAKE POWER SUP	18.440 (08-..)	ZF Intarder
 TG-X	BRAKE POWER SUP	18.480 (08-..)	ZF Intarder
 TG-X	BRAKE POWER SUP	18.540 (08-..)	ZF Intarder
 TG-X	BRAKE POWER SUP	18.680 (08-..)	ZF Intarder
 TG-X	BRAKE POWER SUP	24.360 (08-..)	ZF Intarder
 TG-X	BRAKE POWER SUP	24.400 (08-..)	ZF Intarder
 TG-X	BRAKE POWER SUP	24.440 (08-..)	ZF Intarder
 TG-X	BRAKE POWER SUP	24.480 (08-..)	ZF Intarder
 TG-X	BRAKE POWER SUP	24.540 (08-..)	ZF Intarder
 TG-X	BRAKE POWER SUP	26.360 (08-..)	ZF Intarder
 TG-X	BRAKE POWER SUP	26.400 (08-..)	ZF Intarder
 TG-X	BRAKE POWER SUP	26.440 (08-..)	ZF Intarder
 TG-X	BRAKE POWER SUP	26.480 (08-..)	ZF Intarder
 TG-X	BRAKE POWER SUP	26.540 (08-..)	ZF Intarder
 TG-X	BRAKE POWER SUP	28.360 (08-..)	ZF Intarder

## Systems supported by ECUREADER (up to V5.40)

### TRUCKS




























**MAN**

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 TG-X	BRAKE POWER SUP	28.400 (08-..)	ZF Intarder
 TG-X	BRAKE POWER SUP	28.440 (08-..)	ZF Intarder
 TG-X	BRAKE POWER SUP	28.480 (08-..)	ZF Intarder
 TG-X	BRAKE POWER SUP	28.540 (08-..)	ZF Intarder
 TG-X	BRAKE POWER SUP	33.360 (08-..)	ZF Intarder
 TG-X	BRAKE POWER SUP	33.400 (08-..)	ZF Intarder
 TG-X	BRAKE POWER SUP	33.440 (08-..)	ZF Intarder
 TG-X	BRAKE POWER SUP	33.480 (08-..)	ZF Intarder
 TG-X	BRAKE POWER SUP	33.680 (08-..)	ZF Intarder
 TG-X	BRAKE POWER SUP	41.540 (08-..)	ZF Intarder
 TG-X	BRAKE POWER SUP	41.680 (08-..)	ZF Intarder
 TG-X	BRAKE SYS. MANAG	18.360 (08-..)	Knorr EBS 5
 TG-X	BRAKE SYS. MANAG	18.400 (08-..)	Knorr EBS 5
 TG-X	BRAKE SYS. MANAG	18.440 (08-..)	Knorr EBS 5
 TG-X	BRAKE SYS. MANAG	18.480 (08-..)	Knorr EBS 5
 TG-X	BRAKE SYS. MANAG	18.540 (08-..)	Knorr EBS 5
 TG-X	BRAKE SYS. MANAG	18.680 (08-..)	Knorr EBS 5
 TG-X	BRAKE SYS. MANAG	24.360 (08-..)	Knorr EBS 5
 TG-X	BRAKE SYS. MANAG	24.400 (08-..)	Knorr EBS 5
 TG-X	BRAKE SYS. MANAG	24.440 (08-..)	Knorr EBS 5
 TG-X	BRAKE SYS. MANAG	24.480 (08-..)	Knorr EBS 5
 TG-X	BRAKE SYS. MANAG	24.540 (08-..)	Knorr EBS 5
 TG-X	BRAKE SYS. MANAG	26.360 (08-..)	Knorr EBS 5
 TG-X	BRAKE SYS. MANAG	26.400 (08-..)	Knorr EBS 5
 TG-X	BRAKE SYS. MANAG	26.440 (08-..)	Knorr EBS 5
 TG-X	BRAKE SYS. MANAG	26.480 (08-..)	Knorr EBS 5
 TG-X	BRAKE SYS. MANAG	26.540 (08-..)	Knorr EBS 5

## Systems supported by ECUREADER (up to V5.40)

### TRUCKS




























**MAN**

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 TG-X	BRAKE SYS. MANAG	28.360 (08-..)	Knorr EBS 5
 TG-X	BRAKE SYS. MANAG	28.400 (08-..)	Knorr EBS 5
 TG-X	BRAKE SYS. MANAG	28.440 (08-..)	Knorr EBS 5
 TG-X	BRAKE SYS. MANAG	28.480 (08-..)	Knorr EBS 5
 TG-X	BRAKE SYS. MANAG	28.540 (08-..)	Knorr EBS 5
 TG-X	BRAKE SYS. MANAG	33.360 (08-..)	Knorr EBS 5
 TG-X	BRAKE SYS. MANAG	33.400 (08-..)	Knorr EBS 5
 TG-X	BRAKE SYS. MANAG	33.440 (08-..)	Knorr EBS 5
 TG-X	BRAKE SYS. MANAG	33.480 (08-..)	Knorr EBS 5
 TG-X	BRAKE SYS. MANAG	33.680 (08-..)	Knorr EBS 5
 TG-X	BRAKE SYS. MANAG	41.540 (08-..)	Knorr EBS 5
 TG-X	BRAKE SYS. MANAG	41.680 (08-..)	Knorr EBS 5
 TG-X	CHASSIS NETWORK	18.360 (08-..)	VDO Accelerator pedal calib. FFR STEP 11
 TG-X	CHASSIS NETWORK	18.360 (08-..)	VDO Clutch Calibration FFR STEP 11
 TG-X	CHASSIS NETWORK	18.400 (08-..)	VDO Accelerator pedal calib. FFR STEP 11
 TG-X	CHASSIS NETWORK	18.400 (08-..)	VDO Clutch Calibration FFR STEP 11
 TG-X	CHASSIS NETWORK	18.440 (08-..)	VDO Accelerator pedal calib. FFR STEP 11
 TG-X	CHASSIS NETWORK	18.440 (08-..)	VDO Clutch Calibration FFR STEP 11
 TG-X	CHASSIS NETWORK	18.480 (08-..)	VDO Accelerator pedal calib. FFR STEP 11
 TG-X	CHASSIS NETWORK	18.480 (08-..)	VDO Clutch Calibration FFR STEP 11
 TG-X	CHASSIS NETWORK	18.540 (08-..)	VDO Accelerator pedal calib. FFR STEP 11
 TG-X	CHASSIS NETWORK	18.540 (08-..)	VDO Clutch Calibration FFR STEP 11
 TG-X	CHASSIS NETWORK	18.680 (08-..)	VDO Accelerator pedal calib. FFR STEP 11
 TG-X	CHASSIS NETWORK	18.680 (08-..)	VDO Clutch Calibration FFR STEP 11
 TG-X	CHASSIS NETWORK	24.360 (08-..)	VDO Accelerator pedal calib. FFR STEP 11
 TG-X	CHASSIS NETWORK	24.360 (08-..)	VDO Clutch Calibration FFR STEP 11
 TG-X	CHASSIS NETWORK	24.400 (08-..)	VDO Accelerator pedal calib. FFR STEP 11

## Systems supported by ECUREADER (up to V5.40)

### TRUCKS




























**MAN**

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 TG-X	CHASSIS NETWORK	24.400 (08-..)	VDO Clutch Calibration FFR STEP 11
 TG-X	CHASSIS NETWORK	24.440 (08-..)	VDO Accelerator pedal calib. FFR STEP 11
 TG-X	CHASSIS NETWORK	24.440 (08-..)	VDO Clutch Calibration FFR STEP 11
 TG-X	CHASSIS NETWORK	24.480 (08-..)	VDO Accelerator pedal calib. FFR STEP 11
 TG-X	CHASSIS NETWORK	24.480 (08-..)	VDO Clutch Calibration FFR STEP 11
 TG-X	CHASSIS NETWORK	24.540 (08-..)	VDO Accelerator pedal calib. FFR STEP 11
 TG-X	CHASSIS NETWORK	24.540 (08-..)	VDO Clutch Calibration FFR STEP 11
 TG-X	CHASSIS NETWORK	26.360 (08-..)	VDO Accelerator pedal calib. FFR STEP 11
 TG-X	CHASSIS NETWORK	26.360 (08-..)	VDO Clutch Calibration FFR STEP 11
 TG-X	CHASSIS NETWORK	26.400 (08-..)	VDO Accelerator pedal calib. FFR STEP 11
 TG-X	CHASSIS NETWORK	26.400 (08-..)	VDO Clutch Calibration FFR STEP 11
 TG-X	CHASSIS NETWORK	26.440 (08-..)	VDO Accelerator pedal calib. FFR STEP 11
 TG-X	CHASSIS NETWORK	26.440 (08-..)	VDO Clutch Calibration FFR STEP 11
 TG-X	CHASSIS NETWORK	26.480 (08-..)	VDO Accelerator pedal calib. FFR STEP 11
 TG-X	CHASSIS NETWORK	26.480 (08-..)	VDO Clutch Calibration FFR STEP 11
 TG-X	CHASSIS NETWORK	26.540 (08-..)	VDO Accelerator pedal calib. FFR STEP 11
 TG-X	CHASSIS NETWORK	26.540 (08-..)	VDO Clutch Calibration FFR STEP 11
 TG-X	CHASSIS NETWORK	28.360 (08-..)	VDO Accelerator pedal calib. FFR STEP 11
 TG-X	CHASSIS NETWORK	28.360 (08-..)	VDO Clutch Calibration FFR STEP 11
 TG-X	CHASSIS NETWORK	28.400 (08-..)	VDO Accelerator pedal calib. FFR STEP 11
 TG-X	CHASSIS NETWORK	28.400 (08-..)	VDO Clutch Calibration FFR STEP 11
 TG-X	CHASSIS NETWORK	28.440 (08-..)	VDO Accelerator pedal calib. FFR STEP 11
 TG-X	CHASSIS NETWORK	28.440 (08-..)	VDO Clutch Calibration FFR STEP 11
 TG-X	CHASSIS NETWORK	28.480 (08-..)	VDO Accelerator pedal calib. FFR STEP 11
 TG-X	CHASSIS NETWORK	28.480 (08-..)	VDO Clutch Calibration FFR STEP 11
 TG-X	CHASSIS NETWORK	28.540 (08-..)	VDO Accelerator pedal calib. FFR STEP 11
 TG-X	CHASSIS NETWORK	28.540 (08-..)	VDO Clutch Calibration FFR STEP 11

## Systems supported by ECUREADER (up to V5.40)

### TRUCKS




























**MAN**

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 TG-X	CHASSIS NETWORK	33.360 (08-..)	VDO Accelerator pedal calib. FFR STEP 11
 TG-X	CHASSIS NETWORK	33.360 (08-..)	VDO Clutch Calibration FFR STEP 11
 TG-X	CHASSIS NETWORK	33.400 (08-..)	VDO Accelerator pedal calib. FFR STEP 11
 TG-X	CHASSIS NETWORK	33.400 (08-..)	VDO Clutch Calibration FFR STEP 11
 TG-X	CHASSIS NETWORK	33.440 (08-..)	VDO Accelerator pedal calib. FFR STEP 11
 TG-X	CHASSIS NETWORK	33.440 (08-..)	VDO Clutch Calibration FFR STEP 11
 TG-X	CHASSIS NETWORK	33.480 (08-..)	VDO Accelerator pedal calib. FFR STEP 11
 TG-X	CHASSIS NETWORK	33.480 (08-..)	VDO Clutch Calibration FFR STEP 11
 TG-X	CHASSIS NETWORK	33.680 (08-..)	VDO Accelerator pedal calib. FFR STEP 11
 TG-X	CHASSIS NETWORK	33.680 (08-..)	VDO Clutch Calibration FFR STEP 11
 TG-X	CHASSIS NETWORK	41.540 (08-..)	VDO Accelerator pedal calib. FFR STEP 11
 TG-X	CHASSIS NETWORK	41.540 (08-..)	VDO Clutch Calibration FFR STEP 11
 TG-X	CHASSIS NETWORK	41.680 (08-..)	VDO Accelerator pedal calib. FFR STEP 11
 TG-X	CHASSIS NETWORK	41.680 (08-..)	VDO Clutch Calibration FFR STEP 11
 TG-X	DASHBOARD	18.360 (08-..)	Stoneridge Electronics
 TG-X	DASHBOARD	18.400 (08-..)	Stoneridge Electronics
 TG-X	DASHBOARD	18.440 (08-..)	Stoneridge Electronics
 TG-X	DASHBOARD	18.480 (08-..)	Stoneridge Electronics
 TG-X	DASHBOARD	18.540 (08-..)	Stoneridge Electronics
 TG-X	DASHBOARD	18.680 (08-..)	Stoneridge Electronics
 TG-X	DASHBOARD	24.360 (08-..)	Stoneridge Electronics
 TG-X	DASHBOARD	24.400 (08-..)	Stoneridge Electronics
 TG-X	DASHBOARD	24.440 (08-..)	Stoneridge Electronics
 TG-X	DASHBOARD	24.480 (08-..)	Stoneridge Electronics
 TG-X	DASHBOARD	24.540 (08-..)	Stoneridge Electronics
 TG-X	DASHBOARD	26.360 (08-..)	Stoneridge Electronics
 TG-X	DASHBOARD	26.400 (08-..)	Stoneridge Electronics

## Systems supported by ECReader (up to V5.40)

### TRUCKS




























**MAN**

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 TG-X	DASHBOARD	26.440 (08-..)	Stoneridge Electronics
 TG-X	DASHBOARD	26.480 (08-..)	Stoneridge Electronics
 TG-X	DASHBOARD	26.540 (08-..)	Stoneridge Electronics
 TG-X	DASHBOARD	28.360 (08-..)	Stoneridge Electronics
 TG-X	DASHBOARD	28.400 (08-..)	Stoneridge Electronics
 TG-X	DASHBOARD	28.440 (08-..)	Stoneridge Electronics
 TG-X	DASHBOARD	28.480 (08-..)	Stoneridge Electronics
 TG-X	DASHBOARD	28.540 (08-..)	Stoneridge Electronics
 TG-X	DASHBOARD	33.360 (08-..)	Stoneridge Electronics
 TG-X	DASHBOARD	33.400 (08-..)	Stoneridge Electronics
 TG-X	DASHBOARD	33.440 (08-..)	Stoneridge Electronics
 TG-X	DASHBOARD	33.480 (08-..)	Stoneridge Electronics
 TG-X	DASHBOARD	33.680 (08-..)	Stoneridge Electronics
 TG-X	DASHBOARD	41.540 (08-..)	Stoneridge Electronics
 TG-X	DASHBOARD	41.680 (08-..)	Stoneridge Electronics
 TG-X	ENGINE MANAGEME	18.360 (08-..)	Bosch EDC 7 C32
 TG-X	ENGINE MANAGEME	18.400 (08-..)	Bosch EDC 7 C32
 TG-X	ENGINE MANAGEME	18.440 (08-..)	Bosch EDC 7 C32
 TG-X	ENGINE MANAGEME	18.480 (08-..)	Bosch EDC 7 C32
 TG-X	ENGINE MANAGEME	18.540 (08-..)	Bosch EDC 7 C32
 TG-X	ENGINE MANAGEME	18.680 (08-..)	Bosch EDC 7 C32
 TG-X	ENGINE MANAGEME	24.360 (08-..)	Bosch EDC 7 C32
 TG-X	ENGINE MANAGEME	24.400 (08-..)	Bosch EDC 7 C32
 TG-X	ENGINE MANAGEME	24.440 (08-..)	Bosch EDC 7 C32
 TG-X	ENGINE MANAGEME	24.480 (08-..)	Bosch EDC 7 C32
 TG-X	ENGINE MANAGEME	24.540 (08-..)	Bosch EDC 7 C32
 TG-X	ENGINE MANAGEME	26.360 (08-..)	Bosch EDC 7 C32

## Systems supported by ECReader (up to V5.40)

### TRUCKS




























**MAN**

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 TG-X	ENGINE MANAGEME	26.400 (08-..)	Bosch EDC 7 C32
 TG-X	ENGINE MANAGEME	26.440 (08-..)	Bosch EDC 7 C32
 TG-X	ENGINE MANAGEME	26.480 (08-..)	Bosch EDC 7 C32
 TG-X	ENGINE MANAGEME	26.540 (08-..)	Bosch EDC 7 C32
 TG-X	ENGINE MANAGEME	28.360 (08-..)	Bosch EDC 7 C32
 TG-X	ENGINE MANAGEME	28.400 (08-..)	Bosch EDC 7 C32
 TG-X	ENGINE MANAGEME	28.440 (08-..)	Bosch EDC 7 C32
 TG-X	ENGINE MANAGEME	28.480 (08-..)	Bosch EDC 7 C32
 TG-X	ENGINE MANAGEME	28.540 (08-..)	Bosch EDC 7 C32
 TG-X	ENGINE MANAGEME	33.360 (08-..)	Bosch EDC 7 C32
 TG-X	ENGINE MANAGEME	33.400 (08-..)	Bosch EDC 7 C32
 TG-X	ENGINE MANAGEME	33.440 (08-..)	Bosch EDC 7 C32
 TG-X	ENGINE MANAGEME	33.480 (08-..)	Bosch EDC 7 C32
 TG-X	ENGINE MANAGEME	33.680 (08-..)	Bosch EDC 7 C32
 TG-X	ENGINE MANAGEME	41.540 (08-..)	Bosch EDC 7 C32
 TG-X	ENGINE MANAGEME	41.680 (08-..)	Bosch EDC 7 C32
 TG-X	MAINTENANCE SYST	18.360 (08-..)	
 TG-X	MAINTENANCE SYST	18.400 (08-..)	
 TG-X	MAINTENANCE SYST	18.440 (08-..)	
 TG-X	MAINTENANCE SYST	18.480 (08-..)	
 TG-X	MAINTENANCE SYST	18.540 (08-..)	
 TG-X	MAINTENANCE SYST	18.680 (08-..)	
 TG-X	MAINTENANCE SYST	24.360 (08-..)	
 TG-X	MAINTENANCE SYST	24.400 (08-..)	
 TG-X	MAINTENANCE SYST	24.440 (08-..)	
 TG-X	MAINTENANCE SYST	24.480 (08-..)	
 TG-X	MAINTENANCE SYST	24.540 (08-..)	

## Systems supported by ECReader (up to V5.40)

### TRUCKS


























**MAN**

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 TG-X	MAINTENANCE SYST	26.360 (08-..)	
 TG-X	MAINTENANCE SYST	26.400 (08-..)	
 TG-X	MAINTENANCE SYST	26.440 (08-..)	
 TG-X	MAINTENANCE SYST	26.480 (08-..)	
 TG-X	MAINTENANCE SYST	26.540 (08-..)	
 TG-X	MAINTENANCE SYST	28.360 (08-..)	
 TG-X	MAINTENANCE SYST	28.400 (08-..)	
 TG-X	MAINTENANCE SYST	28.440 (08-..)	
 TG-X	MAINTENANCE SYST	28.480 (08-..)	
 TG-X	MAINTENANCE SYST	28.540 (08-..)	
 TG-X	MAINTENANCE SYST	33.360 (08-..)	
 TG-X	MAINTENANCE SYST	33.400 (08-..)	
 TG-X	MAINTENANCE SYST	33.440 (08-..)	
 TG-X	MAINTENANCE SYST	33.480 (08-..)	
 TG-X	MAINTENANCE SYST	33.680 (08-..)	
 TG-X	MAINTENANCE SYST	41.540 (08-..)	
 TG-X	MAINTENANCE SYST	41.680 (08-..)	
 TG-X	SUSPENSION CONTR	18.360 (08-..)	Wabco ECAS 2
 TG-X	SUSPENSION CONTR	18.400 (08-..)	Wabco ECAS 2
 TG-X	SUSPENSION CONTR	18.440 (08-..)	Wabco ECAS 2
 TG-X	SUSPENSION CONTR	18.480 (08-..)	Wabco ECAS 2
 TG-X	SUSPENSION CONTR	18.540 (08-..)	Wabco ECAS 2
 TG-X	SUSPENSION CONTR	18.680 (08-..)	Wabco ECAS 2
 TG-X	SUSPENSION CONTR	24.360 (08-..)	Wabco ECAS 2
 TG-X	SUSPENSION CONTR	24.400 (08-..)	Wabco ECAS 2
 TG-X	SUSPENSION CONTR	24.440 (08-..)	Wabco ECAS 2
 TG-X	SUSPENSION CONTR	24.480 (08-..)	Wabco ECAS 2

## Systems supported by ECUreader (up to V5.40)

### TRUCKS




















**MAN**

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 TG-X	SUSPENSION CONTR	24.540 (08-..)	Wabco ECAS 2
 TG-X	SUSPENSION CONTR	26.360 (08-..)	Wabco ECAS 2
 TG-X	SUSPENSION CONTR	26.400 (08-..)	Wabco ECAS 2
 TG-X	SUSPENSION CONTR	26.440 (08-..)	Wabco ECAS 2
 TG-X	SUSPENSION CONTR	26.480 (08-..)	Wabco ECAS 2
 TG-X	SUSPENSION CONTR	26.540 (08-..)	Wabco ECAS 2
 TG-X	SUSPENSION CONTR	28.360 (08-..)	Wabco ECAS 2
 TG-X	SUSPENSION CONTR	28.400 (08-..)	Wabco ECAS 2
 TG-X	SUSPENSION CONTR	28.440 (08-..)	Wabco ECAS 2
 TG-X	SUSPENSION CONTR	28.480 (08-..)	Wabco ECAS 2
 TG-X	SUSPENSION CONTR	28.540 (08-..)	Wabco ECAS 2
 TG-X	SUSPENSION CONTR	33.360 (08-..)	Wabco ECAS 2
 TG-X	SUSPENSION CONTR	33.400 (08-..)	Wabco ECAS 2
 TG-X	SUSPENSION CONTR	33.440 (08-..)	Wabco ECAS 2
 TG-X	SUSPENSION CONTR	33.480 (08-..)	Wabco ECAS 2
 TG-X	SUSPENSION CONTR	33.680 (08-..)	Wabco ECAS 2
 TG-X	SUSPENSION CONTR	41.540 (08-..)	Wabco ECAS 2
 TG-X	SUSPENSION CONTR	41.680 (08-..)	Wabco ECAS 2
 U90	ABS		BOSCH ABS/ASR 2E
 U90	ABS		BOSCH ABS/ASR 2M Stufe 1
 U90	ABS		BOSCH ABS/ASR 3E
 U90	ABS		BOSCH/KNORR ABS Ci 12
 U90	ABS		KNORR ABS
 U90	CLIMA		Konvekta MANUAL
 U90	CLIMA		WABCO ATC MANUAL

## Systems supported by ECUREADER (up to V5.40)

### TRUCKS

























### MAN Bus

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 EM220	ABS		BOSCH ABS Ci 12 MANUAL
 EM220	ABS		BOSCH ABS/ASR 2E
 EM220	ABS		BOSCH ABS/ASR 2M MANUAL
 EM220	ABS		BOSCH ABS/ASR 2M Stufe 1
 EM220	ABS		BOSCH ABS/ASR 3E
 EM220	ABS		KNORR ABS
 EM220	ABS		KNORR ABS KB3AL MANUAL
 EM220	CLIMA		Konvekta MANUAL
 EM220	CLIMA		WABCO ATC MANUAL
 EM222	ABS		BOSCH ABS Ci 12 MANUAL
 EM222	ABS		BOSCH ABS/ASR 2E
 EM222	ABS		BOSCH ABS/ASR 2M MANUAL
 EM222	ABS		BOSCH ABS/ASR 2M Stufe 1
 EM222	ABS		BOSCH ABS/ASR 3E
 EM222	ABS		KNORR ABS
 EM222	ABS		KNORR ABS KB3AL MANUAL
 EM222	CLIMA		Konvekta MANUAL
 EM222	CLIMA		WABCO ATC MANUAL
 EM223	ABS		BOSCH ABS Ci 12 MANUAL
 EM223	ABS		BOSCH ABS/ASR 2E
 EM223	ABS		BOSCH ABS/ASR 2M MANUAL
 EM223	ABS		BOSCH ABS/ASR 2M Stufe 1
 EM223	ABS		BOSCH ABS/ASR 3E
 EM223	ABS		KNORR ABS
 EM223	ABS		KNORR ABS KB3AL MANUAL
 EM223	CLIMA		Konvekta MANUAL

## Systems supported by ECUREADER (up to V5.40)

### TRUCKS



























### MAN Bus

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 EM223	CLIMA		WABCO ATC MANUAL
 ND222	ABS		BOSCH ABS Ci 12
 ND222	ABS		BOSCH ABS/ASR 2E
 ND222	ABS		BOSCH ABS/ASR 2M
 ND222	ABS		BOSCH ABS/ASR 2M Stufe 1
 ND222	ABS		BOSCH ABS/ASR 3E
 ND222	ABS		KNORR ABS
 ND222	ABS		KNORR ABS KB3AL
 ND222	CLIMA		Konvekta MANUAL
 ND222	CLIMA		WABCO ATC MANUAL
 NG/SG 263 Lion's Classic	ABS		BOSCH ABS Ci 12 MANUAL
 NG/SG 263 Lion's Classic	ABS		BOSCH ABS/ASR 2E
 NG/SG 263 Lion's Classic	ABS		BOSCH ABS/ASR 2M MANUAL
 NG/SG 263 Lion's Classic	ABS		BOSCH ABS/ASR 2M Stufe 1
 NG/SG 263 Lion's Classic	ABS		BOSCH ABS/ASR 3E
 NG/SG 263 Lion's Classic	ABS		KNORR ABS
 NG/SG 263 Lion's Classic	ABS		KNORR ABS KB3AL MANUAL
 NG/SG 263 Lion's Classic	CLIMA		Konvekta MANUAL
 NG/SG 263 Lion's Classic	CLIMA		WABCO ATC MANUAL
 NG/SG 313 Lion's Classic	ABS		BOSCH ABS Ci 12 MANUAL
 NG/SG 313 Lion's Classic	ABS		BOSCH ABS/ASR 2E
 NG/SG 313 Lion's Classic	ABS		BOSCH ABS/ASR 2M MANUAL
 NG/SG 313 Lion's Classic	ABS		BOSCH ABS/ASR 2M Stufe 1
 NG/SG 313 Lion's Classic	ABS		BOSCH ABS/ASR 3E
 NG/SG 313 Lion's Classic	ABS		KNORR ABS
 NG/SG 313 Lion's Classic	ABS		KNORR ABS KB3AL MANUAL

## Systems supported by ECUREADER (up to V5.40)

### TRUCKS



























### MAN Bus

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 NG/SG 313 Lion's Classic	CLIMA		Konvekta MANUAL
 NG/SG 313 Lion's Classic	CLIMA		WABCO ATC MANUAL
 NG262	ABS		BOSCH ABS Ci 12 MANUAL
 NG262	ABS		BOSCH ABS/ASR 2E
 NG262	ABS		BOSCH ABS/ASR 2M MANUAL
 NG262	ABS		BOSCH ABS/ASR 2M Stufe 1
 NG262	ABS		BOSCH ABS/ASR 3E
 NG262	ABS		KNORR ABS
 NG262	ABS		KNORR ABS KB3AL MANUAL
 NG262	CLIMA		Konvekta MANUAL
 NG262	CLIMA		WABCO ATC MANUAL
 NL 223 Lion's Classic	ABS		BOSCH ABS Ci 12 MANUAL
 NL 223 Lion's Classic	ABS		BOSCH ABS/ASR 2E
 NL 223 Lion's Classic	ABS		BOSCH ABS/ASR 2M MANUAL
 NL 223 Lion's Classic	ABS		BOSCH ABS/ASR 2M Stufe 1
 NL 223 Lion's Classic	ABS		BOSCH ABS/ASR 3E
 NL 223 Lion's Classic	ABS		KNORR ABS
 NL 223 Lion's Classic	ABS		KNORR ABS KB3AL MANUAL
 NL 223 Lion's Classic	CLIMA		Konvekta MANUAL
 NL 223 Lion's Classic	CLIMA		WABCO ATC MANUAL
 NL 243 Lion's Classic	ABS		BOSCH ABS Ci 12 MANUAL
 NL 243 Lion's Classic	ABS		BOSCH ABS/ASR 2E
 NL 243 Lion's Classic	ABS		BOSCH ABS/ASR 2M MANUAL
 NL 243 Lion's Classic	ABS		BOSCH ABS/ASR 2M Stufe 1
 NL 243 Lion's Classic	ABS		BOSCH ABS/ASR 3E
 NL 243 Lion's Classic	ABS		KNORR ABS

## Systems supported by ECUreader (up to V5.40)

### TRUCKS



























### MAN Bus

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 NL 243 Lion's Classic	ABS		KNORR ABS KB3AL MANUAL
 NL 243 Lion's Classic	CLIMA		Konvekta MANUAL
 NL 243 Lion's Classic	CLIMA		WABCO ATC MANUAL
 NL 263 Lion's Classic	ABS		BOSCH ABS Ci 12 MANUAL
 NL 263 Lion's Classic	ABS		BOSCH ABS/ASR 2E
 NL 263 Lion's Classic	ABS		BOSCH ABS/ASR 2M MANUAL
 NL 263 Lion's Classic	ABS		BOSCH ABS/ASR 2M Stufe 1
 NL 263 Lion's Classic	ABS		BOSCH ABS/ASR 3E
 NL 263 Lion's Classic	ABS		KNORR ABS
 NL 263 Lion's Classic	ABS		KNORR ABS KB3AL MANUAL
 NL 263 Lion's Classic	CLIMA		Konvekta MANUAL
 NL 263 Lion's Classic	CLIMA		WABCO ATC MANUAL
 NL 283 Lion's Classic	ABS		BOSCH ABS Ci 12 MANUAL
 NL 283 Lion's Classic	ABS		BOSCH ABS/ASR 2E
 NL 283 Lion's Classic	ABS		BOSCH ABS/ASR 2M MANUAL
 NL 283 Lion's Classic	ABS		BOSCH ABS/ASR 2M Stufe 1
 NL 283 Lion's Classic	ABS		BOSCH ABS/ASR 3E
 NL 283 Lion's Classic	ABS		KNORR ABS
 NL 283 Lion's Classic	ABS		KNORR ABS KB3AL MANUAL
 NL 283 Lion's Classic	CLIMA		Konvekta MANUAL
 NL 283 Lion's Classic	CLIMA		WABCO ATC MANUAL
 NL 313 Lion's Classic	ABS		BOSCH ABS Ci 12 MANUAL
 NL 313 Lion's Classic	ABS		BOSCH ABS/ASR 2E
 NL 313 Lion's Classic	ABS		BOSCH ABS/ASR 2M MANUAL
 NL 313 Lion's Classic	ABS		BOSCH ABS/ASR 2M Stufe 1
 NL 313 Lion's Classic	ABS		BOSCH ABS/ASR 3E

## Systems supported by ECUreader (up to V5.40)

### TRUCKS



























### MAN Bus

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 NL 313 Lion's Classic	ABS		KNORR ABS
 NL 313 Lion's Classic	ABS		KNORR ABS KB3AL MANUAL
 NL 313 Lion's Classic	CLIMA		Konvekta MANUAL
 NL 313 Lion's Classic	CLIMA		WABCO ATC MANUAL
 NL 363 Lion's Classic	ABS		BOSCH ABS Ci 12 MANUAL
 NL 363 Lion's Classic	ABS		BOSCH ABS/ASR 2E
 NL 363 Lion's Classic	ABS		BOSCH ABS/ASR 2M MANUAL
 NL 363 Lion's Classic	ABS		BOSCH ABS/ASR 2M Stufe 1
 NL 363 Lion's Classic	ABS		BOSCH ABS/ASR 3E
 NL 363 Lion's Classic	ABS		KNORR ABS
 NL 363 Lion's Classic	ABS		KNORR ABS KB3AL MANUAL
 NL 363 Lion's Classic	CLIMA		Konvekta MANUAL
 NL 363 Lion's Classic	CLIMA		WABCO ATC MANUAL
 NM223	ABS		BOSCH ABS Ci 12 MANUAL
 NM223	ABS		BOSCH ABS/ASR 2E
 NM223	ABS		BOSCH ABS/ASR 2M MANUAL
 NM223	ABS		BOSCH ABS/ASR 2M Stufe 1
 NM223	ABS		BOSCH ABS/ASR 3E
 NM223	ABS		KNORR ABS
 NM223	ABS		KNORR ABS KB3AL MANUAL
 NM223	CLIMA		Konvekta MANUAL
 NM223	CLIMA		WABCO ATC MANUAL
 NM283	ABS		BOSCH ABS Ci 12 MANUAL
 NM283	ABS		BOSCH ABS/ASR 2E
 NM283	ABS		BOSCH ABS/ASR 2M MANUAL
 NM283	ABS		BOSCH ABS/ASR 2M Stufe 1

## Systems supported by ECUreader (up to V5.40)

### TRUCKS


























### MAN Bus

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 NM283	ABS		BOSCH ABS/ASR 3E
 NM283	ABS		KNORR ABS
 NM283	ABS		KNORR ABS KB3AL MANUAL
 NM283	CLIMA		Konvekta MANUAL
 NM283	CLIMA		WABCO ATC MANUAL
 NU 263 Lion's Classic	ABS		BOSCH ABS Ci 12 MANUAL
 NU 263 Lion's Classic	ABS		BOSCH ABS/ASR 2E
 NU 263 Lion's Classic	ABS		BOSCH ABS/ASR 2M MANUAL
 NU 263 Lion's Classic	ABS		BOSCH ABS/ASR 2M Stufe 1
 NU 263 Lion's Classic	ABS		BOSCH ABS/ASR 3E
 NU 263 Lion's Classic	ABS		KNORR ABS
 NU 263 Lion's Classic	ABS		KNORR ABS KB3AL MANUAL
 NU 263 Lion's Classic	CLIMA		Konvekta MANUAL
 NU 263 Lion's Classic	CLIMA		WABCO ATC MANUAL
 NU 283 Lion's Classic	ABS		BOSCH ABS Ci 12 MANUAL
 NU 283 Lion's Classic	ABS		BOSCH ABS/ASR 2E
 NU 283 Lion's Classic	ABS		BOSCH ABS/ASR 2M MANUAL
 NU 283 Lion's Classic	ABS		BOSCH ABS/ASR 2M Stufe 1
 NU 283 Lion's Classic	ABS		BOSCH ABS/ASR 3E
 NU 283 Lion's Classic	ABS		KNORR ABS
 NU 283 Lion's Classic	ABS		KNORR ABS KB3AL MANUAL
 NU 283 Lion's Classic	CLIMA		Konvekta MANUAL
 NU 283 Lion's Classic	CLIMA		WABCO ATC MANUAL
 NU 313 Lion's Classic	ABS		BOSCH ABS Ci 12 MANUAL
 NU 313 Lion's Classic	ABS		BOSCH ABS/ASR 2E
 NU 313 Lion's Classic	ABS		BOSCH ABS/ASR 2M MANUAL

## Systems supported by ECUREADER (up to V5.40)

### TRUCKS



























### MAN Bus

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 NU 313 Lion's Classic	ABS		BOSCH ABS/ASR 2M Stufe 1
 NU 313 Lion's Classic	ABS		BOSCH ABS/ASR 3E
 NU 313 Lion's Classic	ABS		KNORR ABS
 NU 313 Lion's Classic	ABS		KNORR ABS KB3AL MANUAL
 NU 313 Lion's Classic	CLIMA		Konvekta MANUAL
 NU 313 Lion's Classic	CLIMA		WABCO ATC MANUAL
 NU 363 Lion's Classic	ABS		BOSCH ABS Ci 12 MANUAL
 NU 363 Lion's Classic	ABS		BOSCH ABS/ASR 2E
 NU 363 Lion's Classic	ABS		BOSCH ABS/ASR 2M MANUAL
 NU 363 Lion's Classic	ABS		BOSCH ABS/ASR 2M Stufe 1
 NU 363 Lion's Classic	ABS		BOSCH ABS/ASR 3E
 NU 363 Lion's Classic	ABS		KNORR ABS
 NU 363 Lion's Classic	ABS		KNORR ABS KB3AL MANUAL
 NU 363 Lion's Classic	CLIMA		Konvekta MANUAL
 NU 363 Lion's Classic	CLIMA		WABCO ATC MANUAL
 R 313 Lion's Comfort	ABS		BOSCH ABS Ci 12 MANUAL
 R 313 Lion's Comfort	ABS		BOSCH ABS/ASR 2E
 R 313 Lion's Comfort	ABS		BOSCH ABS/ASR 2M MANUAL
 R 313 Lion's Comfort	ABS		BOSCH ABS/ASR 2M Stufe 1
 R 313 Lion's Comfort	ABS		BOSCH ABS/ASR 3E
 R 313 Lion's Comfort	ABS		KNORR ABS
 R 313 Lion's Comfort	ABS		KNORR ABS KB3AL MANUAL
 R 313 Lion's Comfort	CLIMA		Konvekta MANUAL
 R 313 Lion's Comfort	CLIMA		WABCO ATC MANUAL
 R 363 Lion's Comfort	ABS		BOSCH ABS Ci 12 MANUAL
 R 363 Lion's Comfort	ABS		BOSCH ABS/ASR 2E

## Systems supported by ECUREADER (up to V5.40)

### TRUCKS
























### MAN Bus

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 R 363 Lion's Comfort	ABS		BOSCH ABS/ASR 2M MANUAL
 R 363 Lion's Comfort	ABS		BOSCH ABS/ASR 2M Stufe 1
 R 363 Lion's Comfort	ABS		BOSCH ABS/ASR 3E
 R 363 Lion's Comfort	ABS		KNORR ABS
 R 363 Lion's Comfort	ABS		KNORR ABS KB3AL MANUAL
 R 363 Lion's Comfort	CLIMA		Konvekta MANUAL
 R 363 Lion's Comfort	CLIMA		WABCO ATC MANUAL
 RH 352 Lion's Coach	ABS		BOSCH ABS Ci 12 MANUAL
 RH 352 Lion's Coach	ABS		BOSCH ABS/ASR 2E
 RH 352 Lion's Coach	ABS		BOSCH ABS/ASR 2M MANUAL
 RH 352 Lion's Coach	ABS		BOSCH ABS/ASR 2M Stufe 1
 RH 352 Lion's Coach	ABS		BOSCH ABS/ASR 3E
 RH 352 Lion's Coach	ABS		KNORR ABS
 RH 352 Lion's Coach	ABS		KNORR ABS KB3AL MANUAL
 RH 352 Lion's Coach	CLIMA		Konvekta MANUAL
 RH 352 Lion's Coach	CLIMA		WABCO ATC MANUAL
 RH 352 Lion's Star	ABS		BOSCH ABS Ci 12 MANUAL
 RH 352 Lion's Star	ABS		BOSCH ABS/ASR 2E
 RH 352 Lion's Star	ABS		BOSCH ABS/ASR 2M MANUAL
 RH 352 Lion's Star	ABS		BOSCH ABS/ASR 2M Stufe 1
 RH 352 Lion's Star	ABS		BOSCH ABS/ASR 3E
 RH 352 Lion's Star	ABS		KNORR ABS
 RH 352 Lion's Star	ABS		KNORR ABS KB3AL MANUAL
 RH 352 Lion's Star	CLIMA		Konvekta MANUAL
 RH 352 Lion's Star	CLIMA		WABCO ATC MANUAL
 RH 402 Lion's Coach	ABS		BOSCH ABS Ci 12 MANUAL

## Systems supported by ECUREADER (up to V5.40)

### TRUCKS



























### MAN Bus

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 RH 402 Lion's Coach	ABS		BOSCH ABS/ASR 2E
 RH 402 Lion's Coach	ABS		BOSCH ABS/ASR 2M MANUAL
 RH 402 Lion's Coach	ABS		BOSCH ABS/ASR 2M Stufe 1
 RH 402 Lion's Coach	ABS		BOSCH ABS/ASR 3E
 RH 402 Lion's Coach	ABS		KNORR ABS
 RH 402 Lion's Coach	ABS		KNORR ABS KB3AL MANUAL
 RH 402 Lion's Coach	CLIMA		Konvekta MANUAL
 RH 402 Lion's Coach	CLIMA		WABCO ATC MANUAL
 RH 402 Lion's Star	ABS		BOSCH ABS Ci 12 MANUAL
 RH 402 Lion's Star	ABS		BOSCH ABS/ASR 2E
 RH 402 Lion's Star	ABS		BOSCH ABS/ASR 2M MANUAL
 RH 402 Lion's Star	ABS		BOSCH ABS/ASR 2M Stufe 1
 RH 402 Lion's Star	ABS		BOSCH ABS/ASR 3E
 RH 402 Lion's Star	ABS		KNORR ABS
 RH 402 Lion's Star	ABS		KNORR ABS KB3AL MANUAL
 RH 402 Lion's Star	CLIMA		Konvekta MANUAL
 RH 402 Lion's Star	CLIMA		WABCO ATC MANUAL
 RH 403 Lion's Top Coach	ABS		BOSCH ABS Ci 12 MANUAL
 RH 403 Lion's Top Coach	ABS		BOSCH ABS/ASR 2E
 RH 403 Lion's Top Coach	ABS		BOSCH ABS/ASR 2M MANUAL
 RH 403 Lion's Top Coach	ABS		BOSCH ABS/ASR 2M Stufe 1
 RH 403 Lion's Top Coach	ABS		BOSCH ABS/ASR 3E
 RH 403 Lion's Top Coach	ABS		KNORR ABS
 RH 403 Lion's Top Coach	ABS		KNORR ABS KB3AL MANUAL
 RH 403 Lion's Top Coach	CLIMA		Konvekta MANUAL
 RH 403 Lion's Top Coach	CLIMA		WABCO ATC MANUAL

## Systems supported by ECUreader (up to V5.40)

### TRUCKS

























### MAN Bus

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 RH 463 Lion's Star	ABS		BOSCH ABS Ci 12 MANUAL
 RH 463 Lion's Star	ABS		BOSCH ABS/ASR 2E
 RH 463 Lion's Star	ABS		BOSCH ABS/ASR 2M MANUAL
 RH 463 Lion's Star	ABS		BOSCH ABS/ASR 2M Stufe 1
 RH 463 Lion's Star	ABS		BOSCH ABS/ASR 3E
 RH 463 Lion's Star	ABS		KNORR ABS
 RH 463 Lion's Star	ABS		KNORR ABS KB3AL MANUAL
 RH 463 Lion's Star	CLIMA		Konvekta MANUAL
 RH 463 Lion's Star	CLIMA		WABCO ATC MANUAL
 RH 463 Lion's Top Coach	ABS		BOSCH ABS Ci 12 MANUAL
 RH 463 Lion's Top Coach	ABS		BOSCH ABS/ASR 2E
 RH 463 Lion's Top Coach	ABS		BOSCH ABS/ASR 2M MANUAL
 RH 463 Lion's Top Coach	ABS		BOSCH ABS/ASR 2M Stufe 1
 RH 463 Lion's Top Coach	ABS		BOSCH ABS/ASR 3E
 RH 463 Lion's Top Coach	ABS		KNORR ABS
 RH 463 Lion's Top Coach	ABS		KNORR ABS KB3AL MANUAL
 RH 463 Lion's Top Coach	CLIMA		Konvekta MANUAL
 RH 463 Lion's Top Coach	CLIMA		WABCO ATC MANUAL
 RHC 414 Lion's Coach	ABS		BOSCH ABS Ci 12 MANUAL
 RHC 414 Lion's Coach	ABS		BOSCH ABS/ASR 2E
 RHC 414 Lion's Coach	ABS		BOSCH ABS/ASR 2M MANUAL
 RHC 414 Lion's Coach	ABS		BOSCH ABS/ASR 2M Stufe 1
 RHC 414 Lion's Coach	ABS		BOSCH ABS/ASR 3E
 RHC 414 Lion's Coach	ABS		KNORR ABS
 RHC 414 Lion's Coach	ABS		KNORR ABS KB3AL MANUAL
 RHC 414 Lion's Coach	CLIMA		Konvekta MANUAL

## Systems supported by ECUreader (up to V5.40)

### TRUCKS



























### MAN Bus

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 RHC 414 Lion's Coach	CLIMA		WABCO ATC MANUAL
 RHC 414 Lion's Top Coach	ABS		BOSCH ABS Ci 12 MANUAL
 RHC 414 Lion's Top Coach	ABS		BOSCH ABS/ASR 2E
 RHC 414 Lion's Top Coach	ABS		BOSCH ABS/ASR 2M MANUAL
 RHC 414 Lion's Top Coach	ABS		BOSCH ABS/ASR 2M Stufe 1
 RHC 414 Lion's Top Coach	ABS		BOSCH ABS/ASR 3E
 RHC 414 Lion's Top Coach	ABS		KNORR ABS
 RHC 414 Lion's Top Coach	ABS		KNORR ABS KB3AL MANUAL
 RHC 414 Lion's Top Coach	CLIMA		Konvekta MANUAL
 RHC 414 Lion's Top Coach	CLIMA		WABCO ATC MANUAL
 RHC 464 Lion's Coach	ABS		BOSCH ABS Ci 12 MANUAL
 RHC 464 Lion's Coach	ABS		BOSCH ABS/ASR 2E
 RHC 464 Lion's Coach	ABS		BOSCH ABS/ASR 2M MANUAL
 RHC 464 Lion's Coach	ABS		BOSCH ABS/ASR 2M Stufe 1
 RHC 464 Lion's Coach	ABS		BOSCH ABS/ASR 3E
 RHC 464 Lion's Coach	ABS		KNORR ABS
 RHC 464 Lion's Coach	ABS		KNORR ABS KB3AL MANUAL
 RHC 464 Lion's Coach	CLIMA		Konvekta MANUAL
 RHC 464 Lion's Coach	CLIMA		WABCO ATC MANUAL
 RHC 464 Lion's Top Coach	ABS		BOSCH ABS Ci 12 MANUAL
 RHC 464 Lion's Top Coach	ABS		BOSCH ABS/ASR 2E
 RHC 464 Lion's Top Coach	ABS		BOSCH ABS/ASR 2M MANUAL
 RHC 464 Lion's Top Coach	ABS		BOSCH ABS/ASR 2M Stufe 1
 RHC 464 Lion's Top Coach	ABS		BOSCH ABS/ASR 3E
 RHC 464 Lion's Top Coach	ABS		KNORR ABS
 RHC 464 Lion's Top Coach	ABS		KNORR ABS KB3AL MANUAL

## Systems supported by ECUREADER (up to V5.40)

### TRUCKS



























### MAN Bus

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 RHC 464 Lion's Top Coach	CLIMA		Konvekta MANUAL
 RHC 464 Lion's Top Coach	CLIMA		WABCO ATC MANUAL
 RHS 414 Lion's Star	ABS		BOSCH ABS Ci 12 MANUAL
 RHS 414 Lion's Star	ABS		BOSCH ABS/ASR 2E
 RHS 414 Lion's Star	ABS		BOSCH ABS/ASR 2M MANUAL
 RHS 414 Lion's Star	ABS		BOSCH ABS/ASR 2M Stufe 1
 RHS 414 Lion's Star	ABS		BOSCH ABS/ASR 3E
 RHS 414 Lion's Star	ABS		KNORR ABS
 RHS 414 Lion's Star	ABS		KNORR ABS KB3AL MANUAL
 RHS 414 Lion's Star	CLIMA		Konvekta MANUAL
 RHS 414 Lion's Star	CLIMA		WABCO ATC MANUAL
 RHS 414 Lion's Top Star	ABS		BOSCH ABS Ci 12 MANUAL
 RHS 414 Lion's Top Star	ABS		BOSCH ABS/ASR 2E
 RHS 414 Lion's Top Star	ABS		BOSCH ABS/ASR 2M MANUAL
 RHS 414 Lion's Top Star	ABS		BOSCH ABS/ASR 2M Stufe 1
 RHS 414 Lion's Top Star	ABS		BOSCH ABS/ASR 3E
 RHS 414 Lion's Top Star	ABS		KNORR ABS
 RHS 414 Lion's Top Star	ABS		KNORR ABS KB3AL MANUAL
 RHS 414 Lion's Top Star	CLIMA		Konvekta MANUAL
 RHS 414 Lion's Top Star	CLIMA		WABCO ATC MANUAL
 RHS 464 Lion's Star	ABS		BOSCH ABS Ci 12 MANUAL
 RHS 464 Lion's Star	ABS		BOSCH ABS/ASR 2E
 RHS 464 Lion's Star	ABS		BOSCH ABS/ASR 2M MANUAL
 RHS 464 Lion's Star	ABS		BOSCH ABS/ASR 2M Stufe 1
 RHS 464 Lion's Star	ABS		BOSCH ABS/ASR 3E
 RHS 464 Lion's Star	ABS		KNORR ABS

## Systems supported by ECUREADER (up to V5.40)

### TRUCKS



























### MAN Bus

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 RHS 464 Lion's Star	ABS		KNORR ABS KB3AL MANUAL
 RHS 464 Lion's Star	CLIMA		Konvekta MANUAL
 RHS 464 Lion's Star	CLIMA		WABCO ATC MANUAL
 RHS 464 Lion's Top Star	ABS		BOSCH ABS Ci 12 MANUAL
 RHS 464 Lion's Top Star	ABS		BOSCH ABS/ASR 2E
 RHS 464 Lion's Top Star	ABS		BOSCH ABS/ASR 2M MANUAL
 RHS 464 Lion's Top Star	ABS		BOSCH ABS/ASR 2M Stufe 1
 RHS 464 Lion's Top Star	ABS		BOSCH ABS/ASR 3E
 RHS 464 Lion's Top Star	ABS		KNORR ABS
 RHS 464 Lion's Top Star	ABS		KNORR ABS KB3AL MANUAL
 RHS 464 Lion's Top Star	CLIMA		Konvekta MANUAL
 RHS 464 Lion's Top Star	CLIMA		WABCO ATC MANUAL
 SD202	ABS		BOSCH ABS Ci 12 MANUAL
 SD202	ABS		BOSCH ABS/ASR 2E
 SD202	ABS		BOSCH ABS/ASR 2M MANUAL
 SD202	ABS		BOSCH ABS/ASR 2M Stufe 1
 SD202	ABS		BOSCH ABS/ASR 3E
 SD202	ABS		KNORR ABS
 SD202	ABS		KNORR ABS KB3AL MANUAL
 SD202	CLIMA		Konvekta MANUAL
 SD202	CLIMA		WABCO ATC MANUAL
 SG 263 Lion's Classic G	ABS		BOSCH ABS Ci 12 MANUAL
 SG 263 Lion's Classic G	ABS		BOSCH ABS/ASR 2E
 SG 263 Lion's Classic G	ABS		BOSCH ABS/ASR 2M MANUAL
 SG 263 Lion's Classic G	ABS		BOSCH ABS/ASR 2M Stufe 1
 SG 263 Lion's Classic G	ABS		BOSCH ABS/ASR 3E

## Systems supported by ECUreader (up to V5.40)

### TRUCKS



























### MAN Bus

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 SG 263 Lion's Classic G	ABS		KNORR ABS
 SG 263 Lion's Classic G	ABS		KNORR ABS KB3AL MANUAL
 SG 263 Lion's Classic G	CLIMA		Konvekta MANUAL
 SG 263 Lion's Classic G	CLIMA		WABCO ATC MANUAL
 SG 313 Lion's Classic G	ABS		BOSCH ABS Ci 12 MANUAL
 SG 313 Lion's Classic G	ABS		BOSCH ABS/ASR 2E
 SG 313 Lion's Classic G	ABS		BOSCH ABS/ASR 2M MANUAL
 SG 313 Lion's Classic G	ABS		BOSCH ABS/ASR 2M Stufe 1
 SG 313 Lion's Classic G	ABS		BOSCH ABS/ASR 3E
 SG 313 Lion's Classic G	ABS		KNORR ABS
 SG 313 Lion's Classic G	ABS		KNORR ABS KB3AL MANUAL
 SG 313 Lion's Classic G	CLIMA		Konvekta MANUAL
 SG 313 Lion's Classic G	CLIMA		WABCO ATC MANUAL
 SG292	ABS		BOSCH ABS Ci 12 MANUAL
 SG292	ABS		BOSCH ABS/ASR 2E
 SG292	ABS		BOSCH ABS/ASR 2M MANUAL
 SG292	ABS		BOSCH ABS/ASR 2M Stufe 1
 SG292	ABS		BOSCH ABS/ASR 3E
 SG292	ABS		KNORR ABS
 SG292	ABS		KNORR ABS KB3AL MANUAL
 SG292	CLIMA		Konvekta MANUAL
 SG292	CLIMA		WABCO ATC MANUAL
 SL 223 Lion's Classic	ABS		BOSCH ABS Ci 12 MANUAL
 SL 223 Lion's Classic	ABS		BOSCH ABS/ASR 2E
 SL 223 Lion's Classic	ABS		BOSCH ABS/ASR 2M MANUAL
 SL 223 Lion's Classic	ABS		BOSCH ABS/ASR 2M Stufe 1

## Systems supported by ECUreader (up to V5.40)

### TRUCKS



























### MAN Bus

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 SL 223 Lion's Classic	ABS		BOSCH ABS/ASR 3E
 SL 223 Lion's Classic	ABS		KNORR ABS
 SL 223 Lion's Classic	ABS		KNORR ABS KB3AL MANUAL
 SL 223 Lion's Classic	CLIMA		Konvekta MANUAL
 SL 223 Lion's Classic	CLIMA		WABCO ATC MANUAL
 SL 283 Lion's Classic	ABS		BOSCH ABS Ci 12 MANUAL
 SL 283 Lion's Classic	ABS		BOSCH ABS/ASR 2E
 SL 283 Lion's Classic	ABS		BOSCH ABS/ASR 2M MANUAL
 SL 283 Lion's Classic	ABS		BOSCH ABS/ASR 2M Stufe 1
 SL 283 Lion's Classic	ABS		BOSCH ABS/ASR 3E
 SL 283 Lion's Classic	ABS		KNORR ABS
 SL 283 Lion's Classic	ABS		KNORR ABS KB3AL MANUAL
 SL 283 Lion's Classic	CLIMA		Konvekta MANUAL
 SL 283 Lion's Classic	CLIMA		WABCO ATC MANUAL
 SU 223 Lion's Classic	ABS		BOSCH ABS Ci 12 MANUAL
 SU 223 Lion's Classic	ABS		BOSCH ABS/ASR 2E
 SU 223 Lion's Classic	ABS		BOSCH ABS/ASR 2M MANUAL
 SU 223 Lion's Classic	ABS		BOSCH ABS/ASR 2M Stufe 1
 SU 223 Lion's Classic	ABS		BOSCH ABS/ASR 3E
 SU 223 Lion's Classic	ABS		KNORR ABS
 SU 223 Lion's Classic	ABS		KNORR ABS KB3AL MANUAL
 SU 223 Lion's Classic	CLIMA		Konvekta MANUAL
 SU 223 Lion's Classic	CLIMA		WABCO ATC MANUAL
 SU 263 Lion's Classic	ABS		BOSCH ABS Ci 12 MANUAL
 SU 263 Lion's Classic	ABS		BOSCH ABS/ASR 2E
 SU 263 Lion's Classic	ABS		BOSCH ABS/ASR 2M MANUAL

## Systems supported by ECUREADER (up to V5.40)

### TRUCKS


























### MAN Bus

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 SU 263 Lion's Classic	ABS		BOSCH ABS/ASR 2M Stufe 1
 SU 263 Lion's Classic	ABS		BOSCH ABS/ASR 3E
 SU 263 Lion's Classic	ABS		KNORR ABS
 SU 263 Lion's Classic	ABS		KNORR ABS KB3AL MANUAL
 SU 263 Lion's Classic	CLIMA		Konvekta MANUAL
 SU 263 Lion's Classic	CLIMA		WABCO ATC MANUAL
 SU 313 Lion's Classic	ABS		BOSCH ABS Ci 12 MANUAL
 SU 313 Lion's Classic	ABS		BOSCH ABS/ASR 2E
 SU 313 Lion's Classic	ABS		BOSCH ABS/ASR 2M MANUAL
 SU 313 Lion's Classic	ABS		BOSCH ABS/ASR 2M Stufe 1
 SU 313 Lion's Classic	ABS		BOSCH ABS/ASR 3E
 SU 313 Lion's Classic	ABS		KNORR ABS
 SU 313 Lion's Classic	ABS		KNORR ABS KB3AL MANUAL
 SU 313 Lion's Classic	CLIMA		Konvekta MANUAL
 SU 313 Lion's Classic	CLIMA		WABCO ATC MANUAL
 SU 363 Lion's Classic	ABS		BOSCH ABS Ci 12 MANUAL
 SU 363 Lion's Classic	ABS		BOSCH ABS/ASR 2E
 SU 363 Lion's Classic	ABS		BOSCH ABS/ASR 2M MANUAL
 SU 363 Lion's Classic	ABS		BOSCH ABS/ASR 2M Stufe 1
 SU 363 Lion's Classic	ABS		BOSCH ABS/ASR 3E
 SU 363 Lion's Classic	ABS		KNORR ABS
 SU 363 Lion's Classic	ABS		KNORR ABS KB3AL MANUAL
 SU 363 Lion's Classic	CLIMA		Konvekta MANUAL
 SU 363 Lion's Classic	CLIMA		WABCO ATC MANUAL
 UL 313 Lion's Classic	ABS		BOSCH ABS Ci 12 MANUAL
 UL 313 Lion's Classic	ABS		BOSCH ABS/ASR 2E

## Systems supported by ECUreader (up to V5.40)

### TRUCKS





### MAN Bus

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 UL 313 Lion's Classic	ABS		BOSCH ABS/ASR 2M MANUAL
 UL 313 Lion's Classic	ABS		BOSCH ABS/ASR 2M Stufe 1
 UL 313 Lion's Classic	ABS		BOSCH ABS/ASR 3E
 UL 313 Lion's Classic	ABS		KNORR ABS
 UL 313 Lion's Classic	ABS		KNORR ABS KB3AL MANUAL
 UL 313 Lion's Comfort	CLIMA		Konvekta MANUAL
 UL 313 Lion's Comfort	CLIMA		WABCO ATC MANUAL
 UL 353 Lion's Classic	ABS		BOSCH ABS Ci 12 MANUAL
 UL 353 Lion's Classic	ABS		BOSCH ABS/ASR 2E
 UL 353 Lion's Classic	ABS		BOSCH ABS/ASR 2M MANUAL
 UL 353 Lion's Classic	ABS		BOSCH ABS/ASR 2M Stufe 1
 UL 353 Lion's Classic	ABS		BOSCH ABS/ASR 3E
 UL 353 Lion's Classic	ABS		KNORR ABS
 UL 353 Lion's Classic	ABS		KNORR ABS KB3AL MANUAL
 UL 353 Lion's Comfort	CLIMA		Konvekta MANUAL
 UL 353 Lion's Comfort	CLIMA		WABCO ATC MANUAL
 UL 363 Lion's Classic	ABS		BOSCH ABS Ci 12 MANUAL
 UL 363 Lion's Classic	ABS		BOSCH ABS/ASR 2E
 UL 363 Lion's Classic	ABS		BOSCH ABS/ASR 2M MANUAL
 UL 363 Lion's Classic	ABS		BOSCH ABS/ASR 2M Stufe 1
 UL 363 Lion's Classic	ABS		BOSCH ABS/ASR 3E
 UL 363 Lion's Classic	ABS		KNORR ABS
 UL 363 Lion's Classic	ABS		KNORR ABS KB3AL MANUAL
 UL 363 Lion's Comfort	CLIMA		Konvekta MANUAL
 UL 363 Lion's Comfort	CLIMA		WABCO ATC MANUAL

## Systems supported by ECUreader (up to V5.40)

### TRUCKS






**Meiller-Kipper**

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Trailers	BRAKE SYS. MANAG	Trailers	Wabco Trailers EBS
 Trailers	BRAKE SYS. MANAG	Trailers	Wabco Trailers EBS kw2000
 Trailers	BRAKE SYS. MANAG	Trailers Haldex	Haldex EBS EB+
 Trailers	BRAKE SYS. MANAG	Trailers Knorr	Knorr Trailer EBS

## Systems supported by ECUreader (up to V5.40)

### TRUCKS




























Menci

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Trailers	BRAKE SYS. MANAG	Trailers	Wabco Trailer EBS
 Trailers	BRAKE SYS. MANAG	Trailers	Wabco Trailer VCS II
 Trailers	BRAKE SYS. MANAG	Trailers	Wabco Trailers EBS kw2000
 Trailers	BRAKE SYS. MANAG	Trailers Haldex	Haldex EBS EB+
 Trailers	BRAKE SYS. MANAG	Trailers Knorr	Knorr Trailer EBS

## Systems supported by ECUREADER (up to V5.40)

### TRUCKS




























### Mercedes Benz

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Sprinter	ABS	208 CDI (...-06)	ABS
 Sprinter	ABS	211 CDI (...-06)	ABS
 Sprinter	ABS	213 CDI (...-06)	ABS
 Sprinter	ABS	216 CDI (...-06)	ABS
 Sprinter	ABS	308 CDI (...-06)	ABS
 Sprinter	ABS	311 CDI (...-06)	ABS
 Sprinter	ABS	313 CDI (...-06)	ABS
 Sprinter	ABS	316 CDI (...-06)	ABS
 Sprinter	ABS	408 CDI (...-06)	ABS
 Sprinter	ABS	411 CDI (...-06)	ABS
 Sprinter	ABS	413 CDI (...-06)	ABS
 Sprinter	ABS	416 CDI (...-06)	ABS
 Sprinter	ABS	616 CDI (...-06)	ABS
 Sprinter	ABS + TRACT. CONT	208 CDI (...-06)	EBS KWP
 Sprinter	ABS + TRACT. CONT	211 CDI (...-06)	EBS KWP
 Sprinter	ABS + TRACT. CONT	213 CDI (...-06)	EBS KWP
 Sprinter	ABS + TRACT. CONT	215 CDI (07-..)	BOSCH ESP ABS ESP 906
 Sprinter	ABS + TRACT. CONT	216 CDI (...-06)	EBS KWP
 Sprinter	ABS + TRACT. CONT	218 CDI (07-..)	BOSCH ESP ABS ESP 906
 Sprinter	ABS + TRACT. CONT	308 CDI (...-06)	EBS KWP
 Sprinter	ABS + TRACT. CONT	311 CDI (...-06)	EBS KWP
 Sprinter	ABS + TRACT. CONT	313 CDI (...-06)	EBS KWP
 Sprinter	ABS + TRACT. CONT	315 CDI (07-..)	BOSCH ESP ABS ESP 906
 Sprinter	ABS + TRACT. CONT	316 CDI (...-06)	EBS KWP
 Sprinter	ABS + TRACT. CONT	318 CDI (07-..)	BOSCH ESP ABS ESP 906
 Sprinter	ABS + TRACT. CONT	408 CDI (...-06)	EBS KWP
 Sprinter	ABS + TRACT. CONT	411 CDI (...-06)	EBS KWP

## Systems supported by ECUreader (up to V5.40)

### TRUCKS




























### Mercedes Benz

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Sprinter	ABS + TRACT. CONT	413 CDI (...-06)	EBS KWP
 Sprinter	ABS + TRACT. CONT	415 CDI (07-..)	BOSCH ESP ABS ESP 906
 Sprinter	ABS + TRACT. CONT	416 CDI (...-06)	EBS KWP
 Sprinter	ABS + TRACT. CONT	418 CDI (07-..)	BOSCH ESP ABS ESP 906
 Sprinter	ABS + TRACT. CONT	518 CDI (07-..)	BOSCH ESP ABS ESP 906
 Sprinter	ABS + TRACT. CONT	616 CDI (...-06)	EBS KWP
 Sprinter	AIRBAG	215 CDI (07-..)	BOSCH SRS ARCADE 906
 Sprinter	AIRBAG	218 CDI (07-..)	BOSCH SRS ARCADE 906
 Sprinter	AIRBAG	315 CDI (07-..)	BOSCH SRS ARCADE 906
 Sprinter	AIRBAG	318 CDI (07-..)	BOSCH SRS ARCADE 906
 Sprinter	AIRBAG	415 CDI (07-..)	BOSCH SRS ARCADE 906
 Sprinter	AIRBAG	418 CDI (07-..)	BOSCH SRS ARCADE 906
 Sprinter	AIRBAG	518 CDI (07-..)	BOSCH SRS ARCADE 906
 Sprinter	AUTOM. TRANSMISSI	208 CDI (...-06)	MB SSG Sprintshift
 Sprinter	AUTOM. TRANSMISSI	211 CDI (...-06)	MB SSG Sprintshift
 Sprinter	AUTOM. TRANSMISSI	213 CDI (...-06)	MB SSG Sprintshift
 Sprinter	AUTOM. TRANSMISSI	215 CDI (...-06)	MB SSG Sprintshift
 Sprinter	AUTOM. TRANSMISSI	215 CDI (07-..)	SIEMENS EGS
 Sprinter	AUTOM. TRANSMISSI	216 CDI (...-06)	MB SSG Sprintshift
 Sprinter	AUTOM. TRANSMISSI	218 CDI (...-06)	MB SSG Sprintshift
 Sprinter	AUTOM. TRANSMISSI	218 CDI (07-..)	SIEMENS EGS
 Sprinter	AUTOM. TRANSMISSI	308 CDI (...-06)	MB SSG Sprintshift
 Sprinter	AUTOM. TRANSMISSI	311 CDI (...-06)	MB SSG Sprintshift
 Sprinter	AUTOM. TRANSMISSI	312 D (...-06)	MB SSG Sprintshift
 Sprinter	AUTOM. TRANSMISSI	313 CDI (...-06)	MB SSG Sprintshift
 Sprinter	AUTOM. TRANSMISSI	315 CDI (...-06)	MB SSG Sprintshift
 Sprinter	AUTOM. TRANSMISSI	315 CDI (07-..)	SIEMENS EGS

## Systems supported by ECUreader (up to V5.40)

### TRUCKS




























### Mercedes Benz

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Sprinter	AUTOM. TRANSMISSI	316 CDI (...-06)	MB SSG Sprintshift
 Sprinter	AUTOM. TRANSMISSI	318 CDI (...-06)	MB SSG Sprintshift
 Sprinter	AUTOM. TRANSMISSI	318 CDI (07-..)	SIEMENS EGS
 Sprinter	AUTOM. TRANSMISSI	408 CDI (...-06)	MB SSG Sprintshift
 Sprinter	AUTOM. TRANSMISSI	411 CDI (...-06)	MB SSG Sprintshift
 Sprinter	AUTOM. TRANSMISSI	413 CDI (...-06)	MB SSG Sprintshift
 Sprinter	AUTOM. TRANSMISSI	415 CDI (...-06)	MB SSG Sprintshift
 Sprinter	AUTOM. TRANSMISSI	415 CDI (07-..)	SIEMENS EGS
 Sprinter	AUTOM. TRANSMISSI	416 CDI (...-06)	MB SSG Sprintshift
 Sprinter	AUTOM. TRANSMISSI	418 CDI (...-06)	MB SSG Sprintshift
 Sprinter	AUTOM. TRANSMISSI	418 CDI (07-..)	SIEMENS EGS
 Sprinter	AUTOM. TRANSMISSI	518 CDI (...-06)	MB SSG Sprintshift
 Sprinter	AUTOM. TRANSMISSI	518 CDI (07-..)	SIEMENS EGS
 Sprinter	AUTOM. TRANSMISSI	616 CDI (...-06)	MB SSG Sprintshift
 Sprinter	CHASSIS NETWORK	215 CDI (07-..)	MARQUARDT OBF Upper Switches Panel
 Sprinter	CHASSIS NETWORK	215 CDI (07-..)	TEMIC SAM
 Sprinter	CHASSIS NETWORK	218 CDI (07-..)	MARQUARDT OBF Upper Switches Panel
 Sprinter	CHASSIS NETWORK	218 CDI (07-..)	TEMIC SAM
 Sprinter	CHASSIS NETWORK	315 CDI (07-..)	MARQUARDT OBF Upper Switches Panel
 Sprinter	CHASSIS NETWORK	315 CDI (07-..)	TEMIC SAM
 Sprinter	CHASSIS NETWORK	318 CDI (07-..)	MARQUARDT OBF Upper Switches Panel
 Sprinter	CHASSIS NETWORK	318 CDI (07-..)	TEMIC SAM
 Sprinter	CHASSIS NETWORK	415 CDI (07-..)	MARQUARDT OBF Upper Switches Panel
 Sprinter	CHASSIS NETWORK	415 CDI (07-..)	TEMIC SAM
 Sprinter	CHASSIS NETWORK	418 CDI (07-..)	MARQUARDT OBF Upper Switches Panel
 Sprinter	CHASSIS NETWORK	418 CDI (07-..)	TEMIC SAM
 Sprinter	CHASSIS NETWORK	518 CDI (07-..)	MARQUARDT OBF Upper Switches Panel

## Systems supported by ECUREADER (up to V5.40)

### TRUCKS




























### Mercedes Benz

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Sprinter	CHASSIS NETWORK	518 CDI (07-..)	TEMIC SAM
 Sprinter	CLIMA	215 CDI (07-..)	HELLA KLA
 Sprinter	CLIMA	218 CDI (07-..)	HELLA KLA
 Sprinter	CLIMA	315 CDI (07-..)	HELLA KLA
 Sprinter	CLIMA	318 CDI (07-..)	HELLA KLA
 Sprinter	CLIMA	415 CDI (07-..)	HELLA KLA
 Sprinter	CLIMA	418 CDI (07-..)	HELLA KLA
 Sprinter	CLIMA	518 CDI (07-..)	HELLA KLA
 Sprinter	DASHBOARD	208 CDI (...06)	VDO KOMBI
 Sprinter	DASHBOARD	211 CDI (...06)	VDO KOMBI
 Sprinter	DASHBOARD	213 CDI (...06)	VDO KOMBI
 Sprinter	DASHBOARD	215 CDI (...06)	VDO KOMBI
 Sprinter	DASHBOARD	215 CDI (07-..)	BORG Kombi Instrument KI 906
 Sprinter	DASHBOARD	216 CDI (...06)	VDO KOMBI
 Sprinter	DASHBOARD	218 CDI (...06)	VDO KOMBI
 Sprinter	DASHBOARD	218 CDI (07-..)	BORG Kombi Instrument KI 906
 Sprinter	DASHBOARD	308 CDI (...06)	VDO KOMBI
 Sprinter	DASHBOARD	311 CDI (...06)	VDO KOMBI
 Sprinter	DASHBOARD	313 CDI (...06)	VDO KOMBI
 Sprinter	DASHBOARD	315 CDI (...06)	VDO KOMBI
 Sprinter	DASHBOARD	315 CDI (07-..)	BORG Kombi Instrument KI 906
 Sprinter	DASHBOARD	316 CDI (...06)	VDO KOMBI
 Sprinter	DASHBOARD	318 CDI (...06)	VDO KOMBI
 Sprinter	DASHBOARD	318 CDI (07-..)	BORG Kombi Instrument KI 906
 Sprinter	DASHBOARD	408 CDI (...06)	VDO KOMBI
 Sprinter	DASHBOARD	411 CDI (...06)	VDO KOMBI
 Sprinter	DASHBOARD	413 CDI (...06)	VDO KOMBI

## Systems supported by ECUREADER (up to V5.40)

### TRUCKS




























### Mercedes Benz

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Sprinter	DASHBOARD	415 CDI (...06)	VDO KOMBI
 Sprinter	DASHBOARD	415 CDI (07-..)	BORG Kombi Instrument KI 906
 Sprinter	DASHBOARD	416 CDI (...06)	VDO KOMBI
 Sprinter	DASHBOARD	418 CDI (...06)	VDO KOMBI
 Sprinter	DASHBOARD	418 CDI (07-..)	BORG Kombi Instrument KI 906
 Sprinter	DASHBOARD	518 CDI (...06)	VDO KOMBI
 Sprinter	DASHBOARD	518 CDI (07-..)	BORG Kombi Instrument KI 906
 Sprinter	DASHBOARD	616 CDI (...06)	VDO KOMBI
 Sprinter	DIESEL MANAGEMEN	312 D 602980 (96-..)	BOSCH EVE
 Sprinter	DRIVER SIDE DOOR	215 CDI (07-..)	TEMIC TSG
 Sprinter	DRIVER SIDE DOOR	218 CDI (07-..)	TEMIC TSG
 Sprinter	DRIVER SIDE DOOR	315 CDI (07-..)	TEMIC TSG
 Sprinter	DRIVER SIDE DOOR	318 CDI (07-..)	TEMIC TSG
 Sprinter	DRIVER SIDE DOOR	415 CDI (07-..)	TEMIC TSG
 Sprinter	DRIVER SIDE DOOR	418 CDI (07-..)	TEMIC TSG
 Sprinter	DRIVER SIDE DOOR	518 CDI (07-..)	TEMIC TSG
 Sprinter	ENGINE MANAGEME	208 CDI (...06)	BOSCH EDC Common Rail
 Sprinter	ENGINE MANAGEME	211 CDI (...06)	BOSCH EDC Common Rail
 Sprinter	ENGINE MANAGEME	213 CDI (...06)	BOSCH EDC Common Rail
 Sprinter	ENGINE MANAGEME	215 CDI (07-..)	BOSCH EDC CDI 4 Common Rail
 Sprinter	ENGINE MANAGEME	216 CDI (...06)	BOSCH EDC Common Rail
 Sprinter	ENGINE MANAGEME	218 CDI (07-..)	BOSCH EDC CDI 4 Common Rail
 Sprinter	ENGINE MANAGEME	308 CDI (...06)	BOSCH EDC Common Rail
 Sprinter	ENGINE MANAGEME	311 CDI (...06)	BOSCH EDC Common Rail
 Sprinter	ENGINE MANAGEME	313 CDI (...06)	BOSCH EDC Common Rail
 Sprinter	ENGINE MANAGEME	315 CDI (07-..)	BOSCH EDC CDI 4 Common Rail
 Sprinter	ENGINE MANAGEME	316 CDI (...06)	BOSCH EDC Common Rail

## Systems supported by ECReader (up to V5.40)

### TRUCKS




























### Mercedes Benz

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Sprinter	ENGINE MANAGEME	318 CDI (07-..)	BOSCH EDC CDI 4 Common Rail
 Sprinter	ENGINE MANAGEME	408 CDI (..-06)	BOSCH EDC Common Rail
 Sprinter	ENGINE MANAGEME	411 CDI (..-06)	BOSCH EDC Common Rail
 Sprinter	ENGINE MANAGEME	413 CDI (..-06)	BOSCH EDC Common Rail
 Sprinter	ENGINE MANAGEME	415 CDI (07-..)	BOSCH EDC CDI 4 Common Rail
 Sprinter	ENGINE MANAGEME	416 CDI (..-06)	BOSCH EDC Common Rail
 Sprinter	ENGINE MANAGEME	418 CDI (07-..)	BOSCH EDC CDI 4 Common Rail
 Sprinter	ENGINE MANAGEME	518 CDI (07-..)	BOSCH EDC CDI 4 Common Rail
 Sprinter	ENGINE MANAGEME	616 CDI (..-06)	BOSCH EDC Common Rail
 Sprinter	IGNITION SWITCH	215 CDI (07-..)	MARQUARDT EZS
 Sprinter	IGNITION SWITCH	218 CDI (07-..)	MARQUARDT EZS
 Sprinter	IGNITION SWITCH	315 CDI (07-..)	MARQUARDT EZS
 Sprinter	IGNITION SWITCH	318 CDI (07-..)	MARQUARDT EZS
 Sprinter	IGNITION SWITCH	415 CDI (07-..)	MARQUARDT EZS
 Sprinter	IGNITION SWITCH	418 CDI (07-..)	MARQUARDT EZS
 Sprinter	IGNITION SWITCH	518 CDI (07-..)	MARQUARDT EZS
 Sprinter	IMMOBILIZER	208 CDI (..-06)	
 Sprinter	IMMOBILIZER	211 CDI (..-06)	
 Sprinter	IMMOBILIZER	213 CDI (..-06)	
 Sprinter	IMMOBILIZER	215 CDI (..-06)	
 Sprinter	IMMOBILIZER	216 CDI (..-06)	
 Sprinter	IMMOBILIZER	218 CDI (..-06)	
 Sprinter	IMMOBILIZER	308 CDI (..-06)	
 Sprinter	IMMOBILIZER	311 CDI (..-06)	
 Sprinter	IMMOBILIZER	313 CDI (..-06)	
 Sprinter	IMMOBILIZER	315 CDI (..-06)	
 Sprinter	IMMOBILIZER	316 CDI (..-06)	

## Systems supported by ECReader (up to V5.40)

### TRUCKS



























### Mercedes Benz

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Sprinter	IMMOBILIZER	318 CDI (...-06)	
 Sprinter	IMMOBILIZER	408 CDI (...-06)	
 Sprinter	IMMOBILIZER	411 CDI (...-06)	
 Sprinter	IMMOBILIZER	413 CDI (...-06)	
 Sprinter	IMMOBILIZER	415 CDI (...-06)	
 Sprinter	IMMOBILIZER	416 CDI (...-06)	
 Sprinter	IMMOBILIZER	418 CDI (...-06)	
 Sprinter	IMMOBILIZER	518 CDI (...-06)	
 Sprinter	IMMOBILIZER	616 CDI (...-06)	
 Sprinter	RATIO SEL. MANAGE	215 CDI (07-..)	DAIMLERCHRYSLER EWS Selector Lever
 Sprinter	RATIO SEL. MANAGE	218 CDI (07-..)	DAIMLERCHRYSLER EWS Selector Lever
 Sprinter	RATIO SEL. MANAGE	315 CDI (07-..)	DAIMLERCHRYSLER EWS Selector Lever
 Sprinter	RATIO SEL. MANAGE	318 CDI (07-..)	DAIMLERCHRYSLER EWS Selector Lever
 Sprinter	RATIO SEL. MANAGE	415 CDI (07-..)	DAIMLERCHRYSLER EWS Selector Lever
 Sprinter	RATIO SEL. MANAGE	418 CDI (07-..)	DAIMLERCHRYSLER EWS Selector Lever
 Sprinter	RATIO SEL. MANAGE	518 CDI (07-..)	DAIMLERCHRYSLER EWS Selector Lever
 Sprinter	SERVICE LIGHT RES	208 CDI (99-03)	VDO/MARELLI MANUAL
 Sprinter	SERVICE LIGHT RES	211 CDI (...-03)	VDO/MARELLI MANUAL
 Sprinter	SERVICE LIGHT RES	213 CDI (...-03)	VDO/MARELLI MANUAL
 Sprinter	SERVICE LIGHT RES	215 CDI (...-03)	VDO/MARELLI MANUAL
 Sprinter	SERVICE LIGHT RES	215 CDI (07-..)	MANUAL
 Sprinter	SERVICE LIGHT RES	216 CDI (...-03)	VDO/MARELLI MANUAL
 Sprinter	SERVICE LIGHT RES	218 CDI (...-03)	VDO/MARELLI MANUAL
 Sprinter	SERVICE LIGHT RES	218 CDI (07-..)	MANUAL
 Sprinter	SERVICE LIGHT RES	308 CDI (...-03)	VDO/MARELLI MANUAL
 Sprinter	SERVICE LIGHT RES	311 CDI (...-03)	VDO/MARELLI MANUAL
 Sprinter	SERVICE LIGHT RES	312 D (...-03)	VDO/MARELLI MANUAL

## Systems supported by ECUREADER (up to V5.40)

### TRUCKS

### Mercedes Benz

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Sprinter	SERVICE LIGHT RES	313 CDI (99-03)	VDO/MARELLI MANUAL
 Sprinter	SERVICE LIGHT RES	315 CDI (07-..)	MANUAL
 Sprinter	SERVICE LIGHT RES	315 CDI (99-03)	VDO/MARELLI MANUAL
 Sprinter	SERVICE LIGHT RES	316 CDI (99-03)	VDO/MARELLI MANUAL
 Sprinter	SERVICE LIGHT RES	318 CDI (07-..)	MANUAL
 Sprinter	SERVICE LIGHT RES	318 CDI (99-03)	VDO/MARELLI MANUAL
 Sprinter	SERVICE LIGHT RES	408 CDI (99-03)	VDO/MARELLI MANUAL
 Sprinter	SERVICE LIGHT RES	411 CDI (99-03)	VDO/MARELLI MANUAL
 Sprinter	SERVICE LIGHT RES	413 CDI (99-03)	VDO/MARELLI MANUAL
 Sprinter	SERVICE LIGHT RES	415 CDI (07-..)	MANUAL
 Sprinter	SERVICE LIGHT RES	415 CDI (99-03)	VDO/MARELLI MANUAL
 Sprinter	SERVICE LIGHT RES	416 CDI (99-03)	VDO/MARELLI MANUAL
 Sprinter	SERVICE LIGHT RES	418 CDI (07-..)	MANUAL
 Sprinter	SERVICE LIGHT RES	418 CDI (99-03)	VDO/MARELLI MANUAL
 Sprinter	SERVICE LIGHT RES	518 CDI (07-..)	MANUAL
 Sprinter	SERVICE LIGHT RES	518 CDI (99-03)	VDO/MARELLI MANUAL
 Sprinter	SERVICE LIGHT RES	616 CDI (99-03)	VDO/MARELLI MANUAL
 Sprinter	SWITCHLIGHT MODU	215 CDI (07-..)	VALEO MRM
 Sprinter	SWITCHLIGHT MODU	218 CDI (07-..)	VALEO MRM
 Sprinter	SWITCHLIGHT MODU	315 CDI (07-..)	VALEO MRM
 Sprinter	SWITCHLIGHT MODU	318 CDI (07-..)	VALEO MRM
 Sprinter	SWITCHLIGHT MODU	415 CDI (07-..)	VALEO MRM
 Sprinter	SWITCHLIGHT MODU	418 CDI (07-..)	VALEO MRM
 Sprinter	SWITCHLIGHT MODU	518 CDI (07-..)	VALEO MRM
 V-Class & VITO	ABS + TRACT. CONT	V 200 CDI	BOSCH ETS 5
 V-Class & VITO	ABS + TRACT. CONT	V 200 CDI (...99)	BOSCH ASR/ABD BAS/ETS

## Systems supported by ECReader (up to V5.40)

### TRUCKS


### Mercedes Benz

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 V-Class & VITO	ABS + TRACT. CONT	V 220 CDI	BOSCH ETS 5
 V-Class & VITO	ABS + TRACT. CONT	V 220 CDI (...-99)	BOSCH ASR/ABD BAS/ETS
 V-Class & VITO	ABS + TRACT. CONT	V 230	BOSCH ETS 5
 V-Class & VITO	ABS + TRACT. CONT	V 230 (...-99)	BOSCH ASR/ABD BAS/ETS
 V-Class & VITO	ABS + TRACT. CONT	V 280	BOSCH ETS 5
 V-Class & VITO	ABS + TRACT. CONT	V 280 (...-99)	BOSCH ASR/ABD BAS/ETS
 V-Class & VITO	ABS + TRACT. CONT	Vito F 108 CDI	BOSCH ETS 5
 V-Class & VITO	ABS + TRACT. CONT	Vito F 108 CDI (...-99)	BOSCH ASR/ABD BAS/ETS
 V-Class & VITO	ABS + TRACT. CONT	Vito F 108 D	BOSCH ETS 5
 V-Class & VITO	ABS + TRACT. CONT	Vito F 108 D (...-99)	BOSCH ASR/ABD BAS/ETS
 V-Class & VITO	ABS + TRACT. CONT	Vito F 110 CDI	BOSCH ETS 5
 V-Class & VITO	ABS + TRACT. CONT	Vito F 110 CDI (...-99)	BOSCH ASR/ABD BAS/ETS
 V-Class & VITO	ABS + TRACT. CONT	Vito F 110 TD	BOSCH ETS 5
 V-Class & VITO	ABS + TRACT. CONT	Vito F 110 TD (...-99)	BOSCH ASR/ABD BAS/ETS
 V-Class & VITO	ABS + TRACT. CONT	Vito F 112 CDI	BOSCH ETS 5
 V-Class & VITO	ABS + TRACT. CONT	Vito F 112 CDI (...-99)	BOSCH ASR/ABD BAS/ETS
 V-Class & VITO	ABS + TRACT. CONT	Vito F 113 CDI	BOSCH ETS 5
 V-Class & VITO	ABS + TRACT. CONT	Vito F 113 CDI (...-99)	BOSCH ASR/ABD BAS/ETS
 V-Class & VITO	ABS + TRACT. CONT	Vito F 114 CDI	BOSCH ETS 5
 V-Class & VITO	ABS + TRACT. CONT	Vito F 114 CDI (...-99)	BOSCH ASR/ABD BAS/ETS
 V-Class & VITO	ABS + TRACT. CONT	Vito L 108 CDI	BOSCH ETS 5
 V-Class & VITO	ABS + TRACT. CONT	Vito L 108 CDI (...-99)	BOSCH ASR/ABD BAS/ETS
 V-Class & VITO	ABS + TRACT. CONT	Vito L 108 D	BOSCH ETS 5
 V-Class & VITO	ABS + TRACT. CONT	Vito L 108 D (...-99)	BOSCH ASR/ABD BAS/ETS
 V-Class & VITO	ABS + TRACT. CONT	Vito L 110 CDI	BOSCH ETS 5
 V-Class & VITO	ABS + TRACT. CONT	Vito L 110 CDI (...-99)	BOSCH ASR/ABD BAS/ETS
 V-Class & VITO	ABS + TRACT. CONT	Vito L 110 TD	BOSCH ETS 5

## Systems supported by ECReader (up to V5.40)

### TRUCKS




























### Mercedes Benz

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 V-Class & VITO	ABS + TRACT. CONT	Vito L 110 TD (...-99)	BOSCH ASR/ABD BAS/ETS
 V-Class & VITO	ABS + TRACT. CONT	Vito L 112 CDI	BOSCH ETS 5
 V-Class & VITO	ABS + TRACT. CONT	Vito L 112 CDI (...-99)	BOSCH ASR/ABD BAS/ETS
 V-Class & VITO	ABS + TRACT. CONT	Vito L 113 CDI	BOSCH ETS 5
 V-Class & VITO	ABS + TRACT. CONT	Vito L 113 CDI (...-99)	BOSCH ASR/ABD BAS/ETS
 V-Class & VITO	ABS + TRACT. CONT	Vito L 114 CDI	BOSCH ETS 5
 V-Class & VITO	ABS + TRACT. CONT	Vito L 114 CDI (...-99)	BOSCH ASR/ABD BAS/ETS
 V-Class & VITO	AUTOM. TRANSMISSI	V 200 CDI (...-99)	BOSCH ETC 6
 V-Class & VITO	AUTOM. TRANSMISSI	V 220 CDI (...-99)	BOSCH ETC 6
 V-Class & VITO	AUTOM. TRANSMISSI	V 230 (...-99)	BOSCH ETC 6
 V-Class & VITO	AUTOM. TRANSMISSI	V 280 (...-99)	BOSCH ETC 6
 V-Class & VITO	AUTOM. TRANSMISSI	Vito F 108 CDI (...-99)	BOSCH ETC 6
 V-Class & VITO	AUTOM. TRANSMISSI	Vito F 108 D (...-99)	BOSCH ETC 6
 V-Class & VITO	AUTOM. TRANSMISSI	Vito F 110 CDI (...-99)	BOSCH ETC 6
 V-Class & VITO	AUTOM. TRANSMISSI	Vito F 110 TD (...-99)	BOSCH ETC 6
 V-Class & VITO	AUTOM. TRANSMISSI	Vito F 112 CDI (...-99)	BOSCH ETC 6
 V-Class & VITO	AUTOM. TRANSMISSI	Vito F 113 CDI (...-99)	BOSCH ETC 6
 V-Class & VITO	AUTOM. TRANSMISSI	Vito F 114 CDI (...-99)	BOSCH ETC 6
 V-Class & VITO	AUTOM. TRANSMISSI	Vito L 108 CDI (...-99)	BOSCH ETC 6
 V-Class & VITO	AUTOM. TRANSMISSI	Vito L 108 D (...-99)	BOSCH ETC 6
 V-Class & VITO	AUTOM. TRANSMISSI	Vito L 110 CDI (...-99)	BOSCH ETC 6
 V-Class & VITO	AUTOM. TRANSMISSI	Vito L 110 TD (...-99)	BOSCH ETC 6
 V-Class & VITO	AUTOM. TRANSMISSI	Vito L 112 CDI (...-99)	BOSCH ETC 6
 V-Class & VITO	AUTOM. TRANSMISSI	Vito L 113 CDI (...-99)	BOSCH ETC 6
 V-Class & VITO	AUTOM. TRANSMISSI	Vito L 114 CDI (...-99)	BOSCH ETC 6
 V-Class & VITO	ENGINE MANAGEME	V 114 111 (...-99)	BOSCH Motronic ME 2.0
 V-Class & VITO	ENGINE MANAGEME	V 200 CDI 611 (98-00)	BOSCH EDC 15 C4 Common Rail

## Systems supported by ECUreader (up to V5.40)

### TRUCKS



























### Mercedes Benz

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 V-Class & VITO	ENGINE MANAGEME	V 200 CDI 611 (98-00)	BOSCH EDC 15 C6 Common Rail
 V-Class & VITO	ENGINE MANAGEME	V 220 CDI 611 (98-00)	BOSCH EDC 15 C4 Common Rail
 V-Class & VITO	ENGINE MANAGEME	V 220 CDI 611 (98-00)	BOSCH EDC 15 C6 Common Rail
 V-Class & VITO	ENGINE MANAGEME	V 230 111 (...99)	BOSCH Motronic ME 2.0
 V-Class & VITO	ENGINE MANAGEME	Vito F 108 CDI 611 (98-00)	BOSCH EDC 15 C4 Common Rail
 V-Class & VITO	ENGINE MANAGEME	Vito F 108 CDI 611 (98-00)	BOSCH EDC 15 C6 Common Rail
 V-Class & VITO	ENGINE MANAGEME	Vito L 108 CDI 611 (98-00)	BOSCH EDC 15 C4 Common Rail
 V-Class & VITO	ENGINE MANAGEME	Vito L 108 CDI 611 (98-00)	BOSCH EDC 15 C6 Common Rail
 V-Class & VITO	SERVICE LIGHT RES	V 114 (99-03)	VDO/MARELLI MANUAL
 V-Class & VITO	SERVICE LIGHT RES	V 200 CDI (99-03)	VDO/MARELLI MANUAL
 V-Class & VITO	SERVICE LIGHT RES	V 220 CDI (99-03)	VDO/MARELLI MANUAL
 V-Class & VITO	SERVICE LIGHT RES	V 230 (99-03)	VDO/MARELLI MANUAL
 V-Class & VITO	SERVICE LIGHT RES	V 280 (99-03)	VDO/MARELLI MANUAL
 V-Class & VITO	SERVICE LIGHT RES	Vito F 108 CDI (99-03)	VDO/MARELLI MANUAL
 V-Class & VITO	SERVICE LIGHT RES	Vito F 108 D (99-03)	VDO/MARELLI MANUAL
 V-Class & VITO	SERVICE LIGHT RES	Vito F 110 CDI (99-03)	VDO/MARELLI MANUAL
 V-Class & VITO	SERVICE LIGHT RES	Vito F 110 TD (99-03)	VDO/MARELLI MANUAL
 V-Class & VITO	SERVICE LIGHT RES	Vito F 112 CDI (99-03)	VDO/MARELLI MANUAL
 V-Class & VITO	SERVICE LIGHT RES	Vito F 113 CDI (99-03)	VDO/MARELLI MANUAL
 V-Class & VITO	SERVICE LIGHT RES	Vito F 114 CDI (99-03)	VDO/MARELLI MANUAL
 V-Class & VITO	SERVICE LIGHT RES	Vito L 108 CDI (99-03)	VDO/MARELLI MANUAL
 V-Class & VITO	SERVICE LIGHT RES	Vito L 108 D (99-03)	VDO/MARELLI MANUAL
 V-Class & VITO	SERVICE LIGHT RES	Vito L 110 CDI (99-03)	VDO/MARELLI MANUAL
 V-Class & VITO	SERVICE LIGHT RES	Vito L 110 TD (99-03)	VDO/MARELLI MANUAL
 V-Class & VITO	SERVICE LIGHT RES	Vito L 112 CDI (99-03)	VDO/MARELLI MANUAL
 V-Class & VITO	SERVICE LIGHT RES	Vito L 113 CDI (99-03)	VDO/MARELLI MANUAL
 V-Class & VITO	SERVICE LIGHT RES	Vito L 114 CDI (99-03)	VDO/MARELLI MANUAL

## Systems supported by ECUreader (up to V5.40)

### TRUCKS




























### Mercedes Benz

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Vito	ABS + TRACT. CONT	109 CDI (07-..)	BOSCH ESP ABS
 Vito	ABS + TRACT. CONT	111 CDI (07-..)	BOSCH ESP ABS
 Vito	ABS + TRACT. CONT	111 CDI 4X4 (07-..)	BOSCH ESP ABS
 Vito	ABS + TRACT. CONT	115 CDI (07-..)	BOSCH ESP ABS
 Vito	ABS + TRACT. CONT	115 CDI 4X4 (07-..)	BOSCH ESP ABS
 Vito	ABS + TRACT. CONT	119 (07-..)	BOSCH ESP ABS
 Vito	ABS + TRACT. CONT	120 CDI (07-..)	BOSCH ESP ABS
 Vito	ABS + TRACT. CONT	123 (07-..)	BOSCH ESP ABS
 Vito	AIRBAG	109 CDI (07-..)	BOSCH SRS ARCADE 639
 Vito	AIRBAG	111 CDI (07-..)	BOSCH SRS ARCADE 639
 Vito	AIRBAG	111 CDI 4X4 (07-..)	BOSCH SRS ARCADE 639
 Vito	AIRBAG	115 CDI (07-..)	BOSCH SRS ARCADE 639
 Vito	AIRBAG	115 CDI 4X4 (07-..)	BOSCH SRS ARCADE 639
 Vito	AIRBAG	119 (07-..)	BOSCH SRS ARCADE 639
 Vito	AIRBAG	120 CDI (07-..)	BOSCH SRS ARCADE 639
 Vito	AIRBAG	123 (07-..)	BOSCH SRS ARCADE 639
 Vito	AUTOM. TRANSMISSI	109 CDI (07-..)	SIEMENS EGS
 Vito	AUTOM. TRANSMISSI	111 CDI (07-..)	SIEMENS EGS
 Vito	AUTOM. TRANSMISSI	111 CDI 4X4 (07-..)	SIEMENS EGS
 Vito	AUTOM. TRANSMISSI	115 CDI (07-..)	SIEMENS EGS
 Vito	AUTOM. TRANSMISSI	115 CDI 4X4 (07-..)	SIEMENS EGS
 Vito	AUTOM. TRANSMISSI	119 (07-..)	SIEMENS EGS
 Vito	AUTOM. TRANSMISSI	120 CDI (07-..)	SIEMENS EGS
 Vito	AUTOM. TRANSMISSI	123 (07-..)	SIEMENS EGS
 Vito	CHASSIS NETWORK	109 CDI (07-..)	Marquardt OBF Upper Switches Panel
 Vito	CHASSIS NETWORK	111 CDI (07-..)	Marquardt OBF Upper Switches Panel

## Systems supported by ECUREADER (up to V5.40)

### TRUCKS




























### Mercedes Benz

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Vito	CHASSIS NETWORK	111 CDI 4X4 (07-..)	Marquardt OBF Upper Switches Panel
 Vito	CHASSIS NETWORK	115 CDI (07-..)	Marquardt OBF Upper Switches Panel
 Vito	CHASSIS NETWORK	115 CDI 4X4 (07-..)	Marquardt OBF Upper Switches Panel
 Vito	CHASSIS NETWORK	119 (07-..)	Marquardt OBF Upper Switches Panel
 Vito	CHASSIS NETWORK	120 CDI (07-..)	Marquardt OBF Upper Switches Panel
 Vito	CHASSIS NETWORK	123 (07-..)	Marquardt OBF Upper Switches Panel
 Vito	DASHBOARD	109 CDI (07-..)	BORG Kombi Instrument 639 M
 Vito	DASHBOARD	111 CDI (07-..)	BORG Kombi Instrument 639 M
 Vito	DASHBOARD	111 CDI 4X4 (07-..)	BORG Kombi Instrument 639 M
 Vito	DASHBOARD	115 CDI (07-..)	BORG Kombi Instrument 639 M
 Vito	DASHBOARD	115 CDI 4X4 (07-..)	BORG Kombi Instrument 639 M
 Vito	DASHBOARD	119 (07-..)	BORG Kombi Instrument 639 M
 Vito	DASHBOARD	120 CDI (07-..)	BORG Kombi Instrument 639 M
 Vito	DASHBOARD	123 (07-..)	BORG Kombi Instrument 639 M
 Vito	ENGINE MANAGEME	111 CDI (07-..)	BOSCH EDC
 Vito	IGNITION SWITCH	109 CDI (07-..)	EZS
 Vito	IGNITION SWITCH	111 CDI (07-..)	EZS
 Vito	IGNITION SWITCH	111 CDI 4X4 (07-..)	EZS
 Vito	IGNITION SWITCH	115 CDI (07-..)	EZS
 Vito	IGNITION SWITCH	115 CDI 4X4 (07-..)	EZS
 Vito	IGNITION SWITCH	119 (07-..)	EZS
 Vito	IGNITION SWITCH	120 CDI (07-..)	EZS
 Vito	IGNITION SWITCH	123 (07-..)	EZS
 Vito	LEFT FRONT DOOR	109 CDI (07-..)	TEMIC TSG-VL
 Vito	LEFT FRONT DOOR	111 CDI (07-..)	TEMIC TSG-VL
 Vito	LEFT FRONT DOOR	111 CDI 4X4 (07-..)	TEMIC TSG-VL
 Vito	LEFT FRONT DOOR	115 CDI (07-..)	TEMIC TSG-VL

## Systems supported by ECReader (up to V5.40)

### TRUCKS










### Mercedes Benz

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Vito	LEFT FRONT DOOR	115 CDI 4X4 (07-..)	TEMIC TSG-VL
 Vito	LEFT FRONT DOOR	119 (07-..)	TEMIC TSG-VL
 Vito	LEFT FRONT DOOR	120 CDI (07-..)	TEMIC TSG-VL
 Vito	LEFT FRONT DOOR	123 (07-..)	TEMIC TSG-VL
 Vito	RATIO SEL. MANAGE	109 CDI (07-..)	EWM
 Vito	RATIO SEL. MANAGE	111 CDI (07-..)	EWM
 Vito	RATIO SEL. MANAGE	111 CDI 4X4 (07-..)	EWM
 Vito	RATIO SEL. MANAGE	115 CDI (07-..)	EWM
 Vito	RATIO SEL. MANAGE	115 CDI 4X4 (07-..)	EWM
 Vito	RATIO SEL. MANAGE	119 (07-..)	EWM
 Vito	RATIO SEL. MANAGE	120 CDI (07-..)	EWM
 Vito	RATIO SEL. MANAGE	123 (07-..)	EWM
 Vito	RIGHT FRONT DOOR	109 CDI (07-..)	TEMIC TSG-VR
 Vito	RIGHT FRONT DOOR	111 CDI (07-..)	TEMIC TSG-VR
 Vito	RIGHT FRONT DOOR	111 CDI 4X4 (07-..)	TEMIC TSG-VR
 Vito	RIGHT FRONT DOOR	115 CDI (07-..)	TEMIC TSG-VR
 Vito	RIGHT FRONT DOOR	115 CDI 4X4 (07-..)	TEMIC TSG-VR
 Vito	RIGHT FRONT DOOR	119 (07-..)	TEMIC TSG-VR
 Vito	RIGHT FRONT DOOR	120 CDI (07-..)	TEMIC TSG-VR
 Vito	RIGHT FRONT DOOR	123 (07-..)	TEMIC TSG-VR
 Vito	SERVICE LIGHT RES	109 CDI (03-07)	MANUAL
 Vito	SERVICE LIGHT RES	111 CDI (03-07)	MANUAL
 Vito	SERVICE LIGHT RES	111 CDI 4X4 (03-07)	MANUAL
 Vito	SERVICE LIGHT RES	115 CDI (03-07)	MANUAL
 Vito	SERVICE LIGHT RES	115 CDI 4X4 (03-07)	MANUAL
 Vito	SERVICE LIGHT RES	119 (03-07)	MANUAL
 Vito	SERVICE LIGHT RES	120 CDI (03-07)	MANUAL

## Systems supported by ECUREADER (up to V5.40)

### TRUCKS




























### Mercedes Benz

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Vito	SERVICE LIGHT RES	123 (03-07)	MANUAL
 Vito	SUSPENSION CONTR	109 CDI (07-..)	WEHRLE ENR
 Vito	SUSPENSION CONTR	111 CDI (07-..)	WEHRLE ENR
 Vito	SUSPENSION CONTR	111 CDI 4X4 (07-..)	WEHRLE ENR
 Vito	SUSPENSION CONTR	115 CDI (07-..)	WEHRLE ENR
 Vito	SUSPENSION CONTR	115 CDI 4X4 (07-..)	WEHRLE ENR
 Vito	SUSPENSION CONTR	119 (07-..)	WEHRLE ENR
 Vito	SUSPENSION CONTR	120 CDI (07-..)	WEHRLE ENR
 Vito	SUSPENSION CONTR	123 (07-..)	WEHRLE ENR

## Systems supported by ECUREADER (up to V5.40)

### TRUCKS




























### Mercedes Trucks

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Actros (...00)	ABS	1831 (...00)	MB ABS
 Actros (...00)	ABS	1831 K (...00)	MB ABS
 Actros (...00)	ABS	1831 L (...00)	MB ABS
 Actros (...00)	ABS	1831 L nR (...00)	MB ABS
 Actros (...00)	ABS	1835 L (...00)	MB ABS
 Actros (...00)	ABS	1835 L nR (...00)	MB ABS
 Actros (...00)	ABS	1840 (...00)	MB ABS
 Actros (...00)	ABS	1840 K (...00)	MB ABS
 Actros (...00)	ABS	1840 L (...00)	MB ABS
 Actros (...00)	ABS	1840 L nR (...00)	MB ABS
 Actros (...00)	ABS	1843 (...00)	MB ABS
 Actros (...00)	ABS	1843 K (...00)	MB ABS
 Actros (...00)	ABS	1843 L (...00)	MB ABS
 Actros (...00)	ABS	1843 L nR (...00)	MB ABS
 Actros (...00)	ABS	1846 (...00)	MB ABS
 Actros (...00)	ABS	1846 L (...00)	MB ABS
 Actros (...00)	ABS	1848 (...00)	MB ABS
 Actros (...00)	ABS	1848 L (...00)	MB ABS
 Actros (...00)	ABS	1853 L (...00)	MB ABS
 Actros (...00)	ABS	1857 L (...00)	MB ABS
 Actros (...00)	ABS	2031 AK (...00)	MB ABS
 Actros (...00)	ABS	2531 L (...00)	MB ABS
 Actros (...00)	ABS	2535 L (...00)	MB ABS
 Actros (...00)	ABS	2540 L (...00)	MB ABS
 Actros (...00)	ABS	2543 L (...00)	MB ABS
 Actros (...00)	ABS	2546 L (...00)	MB ABS
 Actros (...00)	ABS	2548 L (...00)	MB ABS

## Systems supported by ECReader (up to V5.40)

### TRUCKS




























### Mercedes Trucks

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Actros (...00)	ABS	2553 L (...00)	MB ABS
 Actros (...00)	ABS	2557 L (...00)	MB ABS
 Actros (...00)	ABS	3243 (...00)	MB ABS
 Actros (...00)	ABS	3335 B (...00)	MB ABS
 Actros (...00)	ABS	3335 K (...00)	MB ABS
 Actros (...00)	ABS	3340 AK (...00)	MB ABS
 Actros (...00)	ABS	3340 B (...00)	MB ABS
 Actros (...00)	ABS	3340 K (...00)	MB ABS
 Actros (...00)	ABS	3343 K (...00)	MB ABS
 Actros (...00)	ABS	3346 K (...00)	MB ABS
 Actros (...00)	ABS	3348 K (...00)	MB ABS
 Actros (...00)	ABS	4140 B (...00)	MB ABS
 Actros (...00)	ABS	4140 K (...00)	MB ABS
 Actros (...00)	ABS	4143 K (...00)	MB ABS
 Actros (...00)	ABS	4146 K (...00)	MB ABS
 Actros (...00)	ABS	4148 K (...00)	MB ABS
 Actros (...00)	BRAKE POWER SUP	1831 (...00)	MB RS Retarder
 Actros (...00)	BRAKE POWER SUP	1831 K (...00)	MB RS Retarder
 Actros (...00)	BRAKE POWER SUP	1831 L (...00)	MB RS Retarder
 Actros (...00)	BRAKE POWER SUP	1831 L nR (...00)	MB RS Retarder
 Actros (...00)	BRAKE POWER SUP	1835 L (...00)	MB RS Retarder
 Actros (...00)	BRAKE POWER SUP	1835 L nR (...00)	MB RS Retarder
 Actros (...00)	BRAKE POWER SUP	1840 (...00)	MB RS Retarder
 Actros (...00)	BRAKE POWER SUP	1840 K (...00)	MB RS Retarder
 Actros (...00)	BRAKE POWER SUP	1840 L (...00)	MB RS Retarder
 Actros (...00)	BRAKE POWER SUP	1840 L nR (...00)	MB RS Retarder
 Actros (...00)	BRAKE POWER SUP	1843 (...00)	MB RS Retarder

## Systems supported by ECReader (up to V5.40)

### TRUCKS




























### Mercedes Trucks

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Actros (...00)	BRAKE POWER SUP	1843 K (...00)	MB RS Retarder
 Actros (...00)	BRAKE POWER SUP	1843 L (...00)	MB RS Retarder
 Actros (...00)	BRAKE POWER SUP	1843 L nR (...00)	MB RS Retarder
 Actros (...00)	BRAKE POWER SUP	1846 (...00)	MB RS Retarder
 Actros (...00)	BRAKE POWER SUP	1846 L (...00)	MB RS Retarder
 Actros (...00)	BRAKE POWER SUP	1848 (...00)	MB RS Retarder
 Actros (...00)	BRAKE POWER SUP	1848 L (...00)	MB RS Retarder
 Actros (...00)	BRAKE POWER SUP	1853 L (...00)	MB RS Retarder
 Actros (...00)	BRAKE POWER SUP	1857 L (...00)	MB RS Retarder
 Actros (...00)	BRAKE POWER SUP	2031 AK (...00)	MB RS Retarder
 Actros (...00)	BRAKE POWER SUP	2531 L (...00)	MB RS Retarder
 Actros (...00)	BRAKE POWER SUP	2535 L (...00)	MB RS Retarder
 Actros (...00)	BRAKE POWER SUP	2540 L (...00)	MB RS Retarder
 Actros (...00)	BRAKE POWER SUP	2543 L (...00)	MB RS Retarder
 Actros (...00)	BRAKE POWER SUP	2546 L (...00)	MB RS Retarder
 Actros (...00)	BRAKE POWER SUP	2548 L (...00)	MB RS Retarder
 Actros (...00)	BRAKE POWER SUP	2553 L (...00)	MB RS Retarder
 Actros (...00)	BRAKE POWER SUP	2557 L (...00)	MB RS Retarder
 Actros (...00)	BRAKE POWER SUP	3243 (...00)	MB RS Retarder
 Actros (...00)	BRAKE POWER SUP	3335 B (...00)	MB RS Retarder
 Actros (...00)	BRAKE POWER SUP	3335 K (...00)	MB RS Retarder
 Actros (...00)	BRAKE POWER SUP	3340 AK (...00)	MB RS Retarder
 Actros (...00)	BRAKE POWER SUP	3340 B (...00)	MB RS Retarder
 Actros (...00)	BRAKE POWER SUP	3340 K (...00)	MB RS Retarder
 Actros (...00)	BRAKE POWER SUP	3343 K (...00)	MB RS Retarder
 Actros (...00)	BRAKE POWER SUP	3346 K (...00)	MB RS Retarder
 Actros (...00)	BRAKE POWER SUP	3348 K (...00)	MB RS Retarder

## Systems supported by ECReader (up to V5.40)

### TRUCKS




























### Mercedes Trucks

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Actros (...00)	BRAKE POWER SUP	4140 B (...00)	MB RS Retarder
 Actros (...00)	BRAKE POWER SUP	4140 K (...00)	MB RS Retarder
 Actros (...00)	BRAKE POWER SUP	4143 K (...00)	MB RS Retarder
 Actros (...00)	BRAKE POWER SUP	4146 K (...00)	MB RS Retarder
 Actros (...00)	BRAKE POWER SUP	4148 K (...00)	MB RS Retarder
 Actros (...00)	BRAKE SYS. MANAG	1831 (...00)	MB BS EPB
 Actros (...00)	BRAKE SYS. MANAG	1831 K (...00)	MB BS EPB
 Actros (...00)	BRAKE SYS. MANAG	1831 L (...00)	MB BS EPB
 Actros (...00)	BRAKE SYS. MANAG	1831 L nR (...00)	MB BS EPB
 Actros (...00)	BRAKE SYS. MANAG	1835 L (...00)	MB BS EPB
 Actros (...00)	BRAKE SYS. MANAG	1835 L nR (...00)	MB BS EPB
 Actros (...00)	BRAKE SYS. MANAG	1840 (...00)	MB BS EPB
 Actros (...00)	BRAKE SYS. MANAG	1840 K (...00)	MB BS EPB
 Actros (...00)	BRAKE SYS. MANAG	1840 L (...00)	MB BS EPB
 Actros (...00)	BRAKE SYS. MANAG	1840 L nR (...00)	MB BS EPB
 Actros (...00)	BRAKE SYS. MANAG	1843 (...00)	MB BS EPB
 Actros (...00)	BRAKE SYS. MANAG	1843 K (...00)	MB BS EPB
 Actros (...00)	BRAKE SYS. MANAG	1843 L (...00)	MB BS EPB
 Actros (...00)	BRAKE SYS. MANAG	1843 L nR (...00)	MB BS EPB
 Actros (...00)	BRAKE SYS. MANAG	1846 (...00)	MB BS EPB
 Actros (...00)	BRAKE SYS. MANAG	1846 L (...00)	MB BS EPB
 Actros (...00)	BRAKE SYS. MANAG	1848 (...00)	MB BS EPB
 Actros (...00)	BRAKE SYS. MANAG	1848 L (...00)	MB BS EPB
 Actros (...00)	BRAKE SYS. MANAG	1853 L (...00)	MB BS EPB
 Actros (...00)	BRAKE SYS. MANAG	1857 L (...00)	MB BS EPB
 Actros (...00)	BRAKE SYS. MANAG	2031 AK (...00)	MB BS EPB
 Actros (...00)	BRAKE SYS. MANAG	2531 L (...00)	MB BS EPB

## Systems supported by ECReader (up to V5.40)

### TRUCKS




























### Mercedes Trucks

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Actros (...00)	BRAKE SYS. MANAG	2535 L (...00)	MB BS EPB
 Actros (...00)	BRAKE SYS. MANAG	2540 L (...00)	MB BS EPB
 Actros (...00)	BRAKE SYS. MANAG	2543 L (...00)	MB BS EPB
 Actros (...00)	BRAKE SYS. MANAG	2546 L (...00)	MB BS EPB
 Actros (...00)	BRAKE SYS. MANAG	2548 L (...00)	MB BS EPB
 Actros (...00)	BRAKE SYS. MANAG	2553 L (...00)	MB BS EPB
 Actros (...00)	BRAKE SYS. MANAG	2557 L (...00)	MB BS EPB
 Actros (...00)	BRAKE SYS. MANAG	3243 (...00)	MB BS EPB
 Actros (...00)	BRAKE SYS. MANAG	3335 B (...00)	MB BS EPB
 Actros (...00)	BRAKE SYS. MANAG	3335 K (...00)	MB BS EPB
 Actros (...00)	BRAKE SYS. MANAG	3340 AK (...00)	MB BS EPB
 Actros (...00)	BRAKE SYS. MANAG	3340 B (...00)	MB BS EPB
 Actros (...00)	BRAKE SYS. MANAG	3340 K (...00)	MB BS EPB
 Actros (...00)	BRAKE SYS. MANAG	3343 K (...00)	MB BS EPB
 Actros (...00)	BRAKE SYS. MANAG	3346 K (...00)	MB BS EPB
 Actros (...00)	BRAKE SYS. MANAG	3348 K (...00)	MB BS EPB
 Actros (...00)	BRAKE SYS. MANAG	4140 B (...00)	MB BS EPB
 Actros (...00)	BRAKE SYS. MANAG	4140 K (...00)	MB BS EPB
 Actros (...00)	BRAKE SYS. MANAG	4143 K (...00)	MB BS EPB
 Actros (...00)	BRAKE SYS. MANAG	4146 K (...00)	MB BS EPB
 Actros (...00)	BRAKE SYS. MANAG	4148 K (...00)	MB BS EPB
 Actros (...00)	CLIMA	1831 (...00)	MB HZR
 Actros (...00)	CLIMA	1831 K (...00)	MB HZR
 Actros (...00)	CLIMA	1831 L (...00)	MB HZR
 Actros (...00)	CLIMA	1831 L nR (...00)	MB HZR
 Actros (...00)	CLIMA	1835 L (...00)	MB HZR
 Actros (...00)	CLIMA	1835 L nR (...00)	MB HZR

## Systems supported by ECUREADER (up to V5.40)

### TRUCKS

### Mercedes Trucks

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Actros (...00)	CLIMA	1840 (...00)	MB HZR
 Actros (...00)	CLIMA	1840 K (...00)	MB HZR
 Actros (...00)	CLIMA	1840 L (...00)	MB HZR
 Actros (...00)	CLIMA	1840 L nR (...00)	MB HZR
 Actros (...00)	CLIMA	1843 (...00)	MB HZR
 Actros (...00)	CLIMA	1843 K (...00)	MB HZR
 Actros (...00)	CLIMA	1843 L (...00)	MB HZR
 Actros (...00)	CLIMA	1843 L nR (...00)	MB HZR
 Actros (...00)	CLIMA	1846 (...00)	MB HZR
 Actros (...00)	CLIMA	1846 L (...00)	MB HZR
 Actros (...00)	CLIMA	1848 (...00)	MB HZR
 Actros (...00)	CLIMA	1848 L (...00)	MB HZR
 Actros (...00)	CLIMA	1853 L (...00)	MB HZR
 Actros (...00)	CLIMA	1857 L (...00)	MB HZR
 Actros (...00)	CLIMA	2031 AK (...00)	MB HZR
 Actros (...00)	CLIMA	2531 L (...00)	MB HZR
 Actros (...00)	CLIMA	2535 L (...00)	MB HZR
 Actros (...00)	CLIMA	2540 L (...00)	MB HZR
 Actros (...00)	CLIMA	2543 L (...00)	MB HZR
 Actros (...00)	CLIMA	2546 L (...00)	MB HZR
 Actros (...00)	CLIMA	2548 L (...00)	MB HZR
 Actros (...00)	CLIMA	2553 L (...00)	MB HZR
 Actros (...00)	CLIMA	2557 L (...00)	MB HZR
 Actros (...00)	CLIMA	3243 (...00)	MB HZR
 Actros (...00)	CLIMA	3335 B (...00)	MB HZR
 Actros (...00)	CLIMA	3335 K (...00)	MB HZR
 Actros (...00)	CLIMA	3340 AK (...00)	MB HZR

## Systems supported by ECUREADER (up to V5.40)

### TRUCKS




























### Mercedes Trucks

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Actros (...00)	CLIMA	3340 B (...00)	MB HZR
 Actros (...00)	CLIMA	3340 K (...00)	MB HZR
 Actros (...00)	CLIMA	3343 K (...00)	MB HZR
 Actros (...00)	CLIMA	3346 K (...00)	MB HZR
 Actros (...00)	CLIMA	3348 K (...00)	MB HZR
 Actros (...00)	CLIMA	4140 B (...00)	MB HZR
 Actros (...00)	CLIMA	4140 K (...00)	MB HZR
 Actros (...00)	CLIMA	4143 K (...00)	MB HZR
 Actros (...00)	CLIMA	4146 K (...00)	MB HZR
 Actros (...00)	CLIMA	4148 K (...00)	MB HZR
 Actros (...00)	CLUTCH ELECTRONI	1831 (...00)	MB KS MKR
 Actros (...00)	CLUTCH ELECTRONI	1831 K (...00)	MB KS MKR
 Actros (...00)	CLUTCH ELECTRONI	1831 L (...00)	MB KS MKR
 Actros (...00)	CLUTCH ELECTRONI	1831 L nR (...00)	MB KS MKR
 Actros (...00)	CLUTCH ELECTRONI	1835 L (...00)	MB KS MKR
 Actros (...00)	CLUTCH ELECTRONI	1835 L nR (...00)	MB KS MKR
 Actros (...00)	CLUTCH ELECTRONI	1840 (...00)	MB KS MKR
 Actros (...00)	CLUTCH ELECTRONI	1840 K (...00)	MB KS MKR
 Actros (...00)	CLUTCH ELECTRONI	1840 L (...00)	MB KS MKR
 Actros (...00)	CLUTCH ELECTRONI	1840 L nR (...00)	MB KS MKR
 Actros (...00)	CLUTCH ELECTRONI	1843 (...00)	MB KS MKR
 Actros (...00)	CLUTCH ELECTRONI	1843 K (...00)	MB KS MKR
 Actros (...00)	CLUTCH ELECTRONI	1843 L (...00)	MB KS MKR
 Actros (...00)	CLUTCH ELECTRONI	1843 L nR (...00)	MB KS MKR
 Actros (...00)	CLUTCH ELECTRONI	1846 (...00)	MB KS MKR
 Actros (...00)	CLUTCH ELECTRONI	1846 L (...00)	MB KS MKR
 Actros (...00)	CLUTCH ELECTRONI	1848 (...00)	MB KS MKR

## Systems supported by ECUREADER (up to V5.40)

### TRUCKS




























### Mercedes Trucks

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Actros (...00)	CLUTCH ELECTRONI	1848 L (...00)	MB KS MKR
 Actros (...00)	CLUTCH ELECTRONI	1853 L (...00)	MB KS MKR
 Actros (...00)	CLUTCH ELECTRONI	1857 L (...00)	MB KS MKR
 Actros (...00)	CLUTCH ELECTRONI	2031 AK (...00)	MB KS MKR
 Actros (...00)	CLUTCH ELECTRONI	2531 L (...00)	MB KS MKR
 Actros (...00)	CLUTCH ELECTRONI	2535 L (...00)	MB KS MKR
 Actros (...00)	CLUTCH ELECTRONI	2540 L (...00)	MB KS MKR
 Actros (...00)	CLUTCH ELECTRONI	2543 L (...00)	MB KS MKR
 Actros (...00)	CLUTCH ELECTRONI	2546 L (...00)	MB KS MKR
 Actros (...00)	CLUTCH ELECTRONI	2548 L (...00)	MB KS MKR
 Actros (...00)	CLUTCH ELECTRONI	2553 L (...00)	MB KS MKR
 Actros (...00)	CLUTCH ELECTRONI	2557 L (...00)	MB KS MKR
 Actros (...00)	CLUTCH ELECTRONI	3243 (...00)	MB KS MKR
 Actros (...00)	CLUTCH ELECTRONI	3335 B (...00)	MB KS MKR
 Actros (...00)	CLUTCH ELECTRONI	3335 K (...00)	MB KS MKR
 Actros (...00)	CLUTCH ELECTRONI	3340 AK (...00)	MB KS MKR
 Actros (...00)	CLUTCH ELECTRONI	3340 B (...00)	MB KS MKR
 Actros (...00)	CLUTCH ELECTRONI	3340 K (...00)	MB KS MKR
 Actros (...00)	CLUTCH ELECTRONI	3343 K (...00)	MB KS MKR
 Actros (...00)	CLUTCH ELECTRONI	3346 K (...00)	MB KS MKR
 Actros (...00)	CLUTCH ELECTRONI	3348 K (...00)	MB KS MKR
 Actros (...00)	CLUTCH ELECTRONI	4140 B (...00)	MB KS MKR
 Actros (...00)	CLUTCH ELECTRONI	4140 K (...00)	MB KS MKR
 Actros (...00)	CLUTCH ELECTRONI	4143 K (...00)	MB KS MKR
 Actros (...00)	CLUTCH ELECTRONI	4146 K (...00)	MB KS MKR
 Actros (...00)	CLUTCH ELECTRONI	4148 K (...00)	MB KS MKR
 Actros (...00)	CRUISE MANAGEME	1831 (...00)	FR FMR

## Systems supported by ECReader (up to V5.40)

### TRUCKS




























### Mercedes Trucks

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Actros (...00)	CRUISE MANAGEME	1831 K (...00)	FR FMR
 Actros (...00)	CRUISE MANAGEME	1831 L (...00)	FR FMR
 Actros (...00)	CRUISE MANAGEME	1831 L nR (...00)	FR FMR
 Actros (...00)	CRUISE MANAGEME	1835 L (...00)	FR FMR
 Actros (...00)	CRUISE MANAGEME	1835 L nR (...00)	FR FMR
 Actros (...00)	CRUISE MANAGEME	1840 (...00)	FR FMR
 Actros (...00)	CRUISE MANAGEME	1840 K (...00)	FR FMR
 Actros (...00)	CRUISE MANAGEME	1840 L (...00)	FR FMR
 Actros (...00)	CRUISE MANAGEME	1840 L nR (...00)	FR FMR
 Actros (...00)	CRUISE MANAGEME	1843 (...00)	FR FMR
 Actros (...00)	CRUISE MANAGEME	1843 K (...00)	FR FMR
 Actros (...00)	CRUISE MANAGEME	1843 L (...00)	FR FMR
 Actros (...00)	CRUISE MANAGEME	1843 L nR (...00)	FR FMR
 Actros (...00)	CRUISE MANAGEME	1846 (...00)	FR FMR
 Actros (...00)	CRUISE MANAGEME	1846 L (...00)	FR FMR
 Actros (...00)	CRUISE MANAGEME	1848 (...00)	FR FMR
 Actros (...00)	CRUISE MANAGEME	1848 L (...00)	FR FMR
 Actros (...00)	CRUISE MANAGEME	1853 L (...00)	FR FMR
 Actros (...00)	CRUISE MANAGEME	1857 L (...00)	FR FMR
 Actros (...00)	CRUISE MANAGEME	2031 AK (...00)	FR FMR
 Actros (...00)	CRUISE MANAGEME	2531 L (...00)	FR FMR
 Actros (...00)	CRUISE MANAGEME	2535 L (...00)	FR FMR
 Actros (...00)	CRUISE MANAGEME	2540 L (...00)	FR FMR
 Actros (...00)	CRUISE MANAGEME	2543 L (...00)	FR FMR
 Actros (...00)	CRUISE MANAGEME	2546 L (...00)	FR FMR
 Actros (...00)	CRUISE MANAGEME	2548 L (...00)	FR FMR
 Actros (...00)	CRUISE MANAGEME	2553 L (...00)	FR FMR

## Systems supported by ECReader (up to V5.40)

### TRUCKS




























### Mercedes Trucks

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Actros (...00)	CRUISE MANAGEME	2557 L (...00)	FR FMR
 Actros (...00)	CRUISE MANAGEME	3243 (...00)	FR FMR
 Actros (...00)	CRUISE MANAGEME	3335 B (...00)	FR FMR
 Actros (...00)	CRUISE MANAGEME	3335 K (...00)	FR FMR
 Actros (...00)	CRUISE MANAGEME	3340 AK (...00)	FR FMR
 Actros (...00)	CRUISE MANAGEME	3340 B (...00)	FR FMR
 Actros (...00)	CRUISE MANAGEME	3340 K (...00)	FR FMR
 Actros (...00)	CRUISE MANAGEME	3343 K (...00)	FR FMR
 Actros (...00)	CRUISE MANAGEME	3346 K (...00)	FR FMR
 Actros (...00)	CRUISE MANAGEME	3348 K (...00)	FR FMR
 Actros (...00)	CRUISE MANAGEME	4140 B (...00)	FR FMR
 Actros (...00)	CRUISE MANAGEME	4140 K (...00)	FR FMR
 Actros (...00)	CRUISE MANAGEME	4143 K (...00)	FR FMR
 Actros (...00)	CRUISE MANAGEME	4146 K (...00)	FR FMR
 Actros (...00)	CRUISE MANAGEME	4148 K (...00)	FR FMR
 Actros (...00)	DASHBOARD	1831 (...00)	MB INS Comb. Instrument
 Actros (...00)	DASHBOARD	1831 K (...00)	MB INS Comb. Instrument
 Actros (...00)	DASHBOARD	1831 L (...00)	MB INS Comb. Instrument
 Actros (...00)	DASHBOARD	1831 L nR (...00)	MB INS Comb. Instrument
 Actros (...00)	DASHBOARD	1835 L (...00)	MB INS Comb. Instrument
 Actros (...00)	DASHBOARD	1835 L nR (...00)	MB INS Comb. Instrument
 Actros (...00)	DASHBOARD	1840 (...00)	MB INS Comb. Instrument
 Actros (...00)	DASHBOARD	1840 K (...00)	MB INS Comb. Instrument
 Actros (...00)	DASHBOARD	1840 L (...00)	MB INS Comb. Instrument
 Actros (...00)	DASHBOARD	1840 L nR (...00)	MB INS Comb. Instrument
 Actros (...00)	DASHBOARD	1843 (...00)	MB INS Comb. Instrument
 Actros (...00)	DASHBOARD	1843 K (...00)	MB INS Comb. Instrument

## Systems supported by ECUREADER (up to V5.40)

### TRUCKS




























### Mercedes Trucks

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Actros (...00)	DASHBOARD	1843 L (...00)	MB INS Comb. Instrument
 Actros (...00)	DASHBOARD	1843 L nR (...00)	MB INS Comb. Instrument
 Actros (...00)	DASHBOARD	1846 (...00)	MB INS Comb. Instrument
 Actros (...00)	DASHBOARD	1846 L (...00)	MB INS Comb. Instrument
 Actros (...00)	DASHBOARD	1848 (...00)	MB INS Comb. Instrument
 Actros (...00)	DASHBOARD	1848 L (...00)	MB INS Comb. Instrument
 Actros (...00)	DASHBOARD	1853 L (...00)	MB INS Comb. Instrument
 Actros (...00)	DASHBOARD	1857 L (...00)	MB INS Comb. Instrument
 Actros (...00)	DASHBOARD	2031 AK (...00)	MB INS Comb. Instrument
 Actros (...00)	DASHBOARD	2531 L (...00)	MB INS Comb. Instrument
 Actros (...00)	DASHBOARD	2535 L (...00)	MB INS Comb. Instrument
 Actros (...00)	DASHBOARD	2540 L (...00)	MB INS Comb. Instrument
 Actros (...00)	DASHBOARD	2543 L (...00)	MB INS Comb. Instrument
 Actros (...00)	DASHBOARD	2546 L (...00)	MB INS Comb. Instrument
 Actros (...00)	DASHBOARD	2548 L (...00)	MB INS Comb. Instrument
 Actros (...00)	DASHBOARD	2553 L (...00)	MB INS Comb. Instrument
 Actros (...00)	DASHBOARD	2557 L (...00)	MB INS Comb. Instrument
 Actros (...00)	DASHBOARD	3243 (...00)	MB INS Comb. Instrument
 Actros (...00)	DASHBOARD	3335 B (...00)	MB INS Comb. Instrument
 Actros (...00)	DASHBOARD	3335 K (...00)	MB INS Comb. Instrument
 Actros (...00)	DASHBOARD	3340 AK (...00)	MB INS Comb. Instrument
 Actros (...00)	DASHBOARD	3340 B (...00)	MB INS Comb. Instrument
 Actros (...00)	DASHBOARD	3340 K (...00)	MB INS Comb. Instrument
 Actros (...00)	DASHBOARD	3343 K (...00)	MB INS Comb. Instrument
 Actros (...00)	DASHBOARD	3346 K (...00)	MB INS Comb. Instrument
 Actros (...00)	DASHBOARD	3348 K (...00)	MB INS Comb. Instrument
 Actros (...00)	DASHBOARD	4140 B (...00)	MB INS Comb. Instrument

## Systems supported by ECReader (up to V5.40)

### TRUCKS




























### Mercedes Trucks

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Actros (...00)	DASHBOARD	4140 K (...00)	MB INS Comb. Instrument
 Actros (...00)	DASHBOARD	4143 K (...00)	MB INS Comb. Instrument
 Actros (...00)	DASHBOARD	4146 K (...00)	MB INS Comb. Instrument
 Actros (...00)	DASHBOARD	4148 K (...00)	MB INS Comb. Instrument
 Actros (...00)	ENGINE MANAGEME	1831 (...00)	MB MR PLD (EDC)
 Actros (...00)	ENGINE MANAGEME	1831 K (...00)	MB MR PLD (EDC)
 Actros (...00)	ENGINE MANAGEME	1831 L (...00)	MB MR PLD (EDC)
 Actros (...00)	ENGINE MANAGEME	1831 L nR (...00)	MB MR PLD (EDC)
 Actros (...00)	ENGINE MANAGEME	1835 L (...00)	MB MR PLD (EDC)
 Actros (...00)	ENGINE MANAGEME	1835 L nR (...00)	MB MR PLD (EDC)
 Actros (...00)	ENGINE MANAGEME	1840 (...00)	MB MR PLD (EDC)
 Actros (...00)	ENGINE MANAGEME	1840 K (...00)	MB MR PLD (EDC)
 Actros (...00)	ENGINE MANAGEME	1840 L (...00)	MB MR PLD (EDC)
 Actros (...00)	ENGINE MANAGEME	1840 L nR (...00)	MB MR PLD (EDC)
 Actros (...00)	ENGINE MANAGEME	1843 (...00)	MB MR PLD (EDC)
 Actros (...00)	ENGINE MANAGEME	1843 K (...00)	MB MR PLD (EDC)
 Actros (...00)	ENGINE MANAGEME	1843 L (...00)	MB MR PLD (EDC)
 Actros (...00)	ENGINE MANAGEME	1843 L nR (...00)	MB MR PLD (EDC)
 Actros (...00)	ENGINE MANAGEME	1846 (...00)	MB MR PLD (EDC)
 Actros (...00)	ENGINE MANAGEME	1846 L (...00)	MB MR PLD (EDC)
 Actros (...00)	ENGINE MANAGEME	1848 (...00)	MB MR PLD (EDC)
 Actros (...00)	ENGINE MANAGEME	1848 L (...00)	MB MR PLD (EDC)
 Actros (...00)	ENGINE MANAGEME	1853 L (...00)	MB MR PLD (EDC)
 Actros (...00)	ENGINE MANAGEME	1857 L (...00)	MB MR PLD (EDC)
 Actros (...00)	ENGINE MANAGEME	2031 AK (...00)	MB MR PLD (EDC)
 Actros (...00)	ENGINE MANAGEME	2531 L (...00)	MB MR PLD (EDC)
 Actros (...00)	ENGINE MANAGEME	2535 L (...00)	MB MR PLD (EDC)

## Systems supported by ECUreader (up to V5.40)

### TRUCKS




























### Mercedes Trucks

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Actros (...00)	ENGINE MANAGEME	2540 L (...00)	MB MR PLD (EDC)
 Actros (...00)	ENGINE MANAGEME	2543 L (...00)	MB MR PLD (EDC)
 Actros (...00)	ENGINE MANAGEME	2546 L (...00)	MB MR PLD (EDC)
 Actros (...00)	ENGINE MANAGEME	2548 L (...00)	MB MR PLD (EDC)
 Actros (...00)	ENGINE MANAGEME	2553 L (...00)	MB MR PLD (EDC)
 Actros (...00)	ENGINE MANAGEME	2557 L (...00)	MB MR PLD (EDC)
 Actros (...00)	ENGINE MANAGEME	3243 (...00)	MB MR PLD (EDC)
 Actros (...00)	ENGINE MANAGEME	3335 B (...00)	MB MR PLD (EDC)
 Actros (...00)	ENGINE MANAGEME	3335 K (...00)	MB MR PLD (EDC)
 Actros (...00)	ENGINE MANAGEME	3340 AK (...00)	MB MR PLD (EDC)
 Actros (...00)	ENGINE MANAGEME	3340 B (...00)	MB MR PLD (EDC)
 Actros (...00)	ENGINE MANAGEME	3340 K (...00)	MB MR PLD (EDC)
 Actros (...00)	ENGINE MANAGEME	3343 K (...00)	MB MR PLD (EDC)
 Actros (...00)	ENGINE MANAGEME	3346 K (...00)	MB MR PLD (EDC)
 Actros (...00)	ENGINE MANAGEME	3348 K (...00)	MB MR PLD (EDC)
 Actros (...00)	ENGINE MANAGEME	4140 B (...00)	MB MR PLD (EDC)
 Actros (...00)	ENGINE MANAGEME	4140 K (...00)	MB MR PLD (EDC)
 Actros (...00)	ENGINE MANAGEME	4143 K (...00)	MB MR PLD (EDC)
 Actros (...00)	ENGINE MANAGEME	4146 K (...00)	MB MR PLD (EDC)
 Actros (...00)	ENGINE MANAGEME	4148 K (...00)	MB MR PLD (EDC)
 Actros (...00)	GEARBOX MANAGEM	1831 (...00)	MB GS EPS
 Actros (...00)	GEARBOX MANAGEM	1831 K (...00)	MB GS EPS
 Actros (...00)	GEARBOX MANAGEM	1831 L (...00)	MB GS EPS
 Actros (...00)	GEARBOX MANAGEM	1831 L nR (...00)	MB GS EPS
 Actros (...00)	GEARBOX MANAGEM	1835 L (...00)	MB GS EPS
 Actros (...00)	GEARBOX MANAGEM	1835 L nR (...00)	MB GS EPS
 Actros (...00)	GEARBOX MANAGEM	1840 (...00)	MB GS EPS

## Systems supported by ECReader (up to V5.40)

### TRUCKS




























### Mercedes Trucks

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Actros (...00)	GEARBOX MANAGEM	1840 K (...00)	MB GS EPS
 Actros (...00)	GEARBOX MANAGEM	1840 L (...00)	MB GS EPS
 Actros (...00)	GEARBOX MANAGEM	1840 L nR (...00)	MB GS EPS
 Actros (...00)	GEARBOX MANAGEM	1843 (...00)	MB GS EPS
 Actros (...00)	GEARBOX MANAGEM	1843 K (...00)	MB GS EPS
 Actros (...00)	GEARBOX MANAGEM	1843 L (...00)	MB GS EPS
 Actros (...00)	GEARBOX MANAGEM	1843 L nR (...00)	MB GS EPS
 Actros (...00)	GEARBOX MANAGEM	1846 (...00)	MB GS EPS
 Actros (...00)	GEARBOX MANAGEM	1846 L (...00)	MB GS EPS
 Actros (...00)	GEARBOX MANAGEM	1848 (...00)	MB GS EPS
 Actros (...00)	GEARBOX MANAGEM	1848 L (...00)	MB GS EPS
 Actros (...00)	GEARBOX MANAGEM	1853 L (...00)	MB GS EPS
 Actros (...00)	GEARBOX MANAGEM	1857 L (...00)	MB GS EPS
 Actros (...00)	GEARBOX MANAGEM	2031 AK (...00)	MB GS EPS
 Actros (...00)	GEARBOX MANAGEM	2531 L (...00)	MB GS EPS
 Actros (...00)	GEARBOX MANAGEM	2535 L (...00)	MB GS EPS
 Actros (...00)	GEARBOX MANAGEM	2540 L (...00)	MB GS EPS
 Actros (...00)	GEARBOX MANAGEM	2543 L (...00)	MB GS EPS
 Actros (...00)	GEARBOX MANAGEM	2546 L (...00)	MB GS EPS
 Actros (...00)	GEARBOX MANAGEM	2548 L (...00)	MB GS EPS
 Actros (...00)	GEARBOX MANAGEM	2553 L (...00)	MB GS EPS
 Actros (...00)	GEARBOX MANAGEM	2557 L (...00)	MB GS EPS
 Actros (...00)	GEARBOX MANAGEM	3243 (...00)	MB GS EPS
 Actros (...00)	GEARBOX MANAGEM	3335 B (...00)	MB GS EPS
 Actros (...00)	GEARBOX MANAGEM	3335 K (...00)	MB GS EPS
 Actros (...00)	GEARBOX MANAGEM	3340 AK (...00)	MB GS EPS
 Actros (...00)	GEARBOX MANAGEM	3340 B (...00)	MB GS EPS

## Systems supported by ECReader (up to V5.40)

### TRUCKS




























### Mercedes Trucks

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Actros (...00)	GEARBOX MANAGEM	3340 K (...00)	MB GS EPS
 Actros (...00)	GEARBOX MANAGEM	3343 K (...00)	MB GS EPS
 Actros (...00)	GEARBOX MANAGEM	3346 K (...00)	MB GS EPS
 Actros (...00)	GEARBOX MANAGEM	3348 K (...00)	MB GS EPS
 Actros (...00)	GEARBOX MANAGEM	4140 B (...00)	MB GS EPS
 Actros (...00)	GEARBOX MANAGEM	4140 K (...00)	MB GS EPS
 Actros (...00)	GEARBOX MANAGEM	4143 K (...00)	MB GS EPS
 Actros (...00)	GEARBOX MANAGEM	4146 K (...00)	MB GS EPS
 Actros (...00)	GEARBOX MANAGEM	4148 K (...00)	MB GS EPS
 Actros (...00)	MAINTENANCE SYST	1831 (...00)	MB WS FSS
 Actros (...00)	MAINTENANCE SYST	1831 K (...00)	MB WS FSS
 Actros (...00)	MAINTENANCE SYST	1831 L (...00)	MB WS FSS
 Actros (...00)	MAINTENANCE SYST	1831 L nR (...00)	MB WS FSS
 Actros (...00)	MAINTENANCE SYST	1835 L (...00)	MB WS FSS
 Actros (...00)	MAINTENANCE SYST	1835 L nR (...00)	MB WS FSS
 Actros (...00)	MAINTENANCE SYST	1840 (...00)	MB WS FSS
 Actros (...00)	MAINTENANCE SYST	1840 K (...00)	MB WS FSS
 Actros (...00)	MAINTENANCE SYST	1840 L (...00)	MB WS FSS
 Actros (...00)	MAINTENANCE SYST	1840 L nR (...00)	MB WS FSS
 Actros (...00)	MAINTENANCE SYST	1843 (...00)	MB WS FSS
 Actros (...00)	MAINTENANCE SYST	1843 K (...00)	MB WS FSS
 Actros (...00)	MAINTENANCE SYST	1843 L (...00)	MB WS FSS
 Actros (...00)	MAINTENANCE SYST	1843 L nR (...00)	MB WS FSS
 Actros (...00)	MAINTENANCE SYST	1846 (...00)	MB WS FSS
 Actros (...00)	MAINTENANCE SYST	1846 L (...00)	MB WS FSS
 Actros (...00)	MAINTENANCE SYST	1848 (...00)	MB WS FSS
 Actros (...00)	MAINTENANCE SYST	1848 L (...00)	MB WS FSS

## Systems supported by ECReader (up to V5.40)

### TRUCKS




























### Mercedes Trucks

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Actros (...00)	MAINTENANCE SYST	1853 L (...00)	MB WS FSS
 Actros (...00)	MAINTENANCE SYST	1857 L (...00)	MB WS FSS
 Actros (...00)	MAINTENANCE SYST	2031 AK (...00)	MB WS FSS
 Actros (...00)	MAINTENANCE SYST	2531 L (...00)	MB WS FSS
 Actros (...00)	MAINTENANCE SYST	2535 L (...00)	MB WS FSS
 Actros (...00)	MAINTENANCE SYST	2540 L (...00)	MB WS FSS
 Actros (...00)	MAINTENANCE SYST	2543 L (...00)	MB WS FSS
 Actros (...00)	MAINTENANCE SYST	2546 L (...00)	MB WS FSS
 Actros (...00)	MAINTENANCE SYST	2548 L (...00)	MB WS FSS
 Actros (...00)	MAINTENANCE SYST	2553 L (...00)	MB WS FSS
 Actros (...00)	MAINTENANCE SYST	2557 L (...00)	MB WS FSS
 Actros (...00)	MAINTENANCE SYST	3243 (...00)	MB WS FSS
 Actros (...00)	MAINTENANCE SYST	3335 B (...00)	MB WS FSS
 Actros (...00)	MAINTENANCE SYST	3335 K (...00)	MB WS FSS
 Actros (...00)	MAINTENANCE SYST	3340 AK (...00)	MB WS FSS
 Actros (...00)	MAINTENANCE SYST	3340 B (...00)	MB WS FSS
 Actros (...00)	MAINTENANCE SYST	3340 K (...00)	MB WS FSS
 Actros (...00)	MAINTENANCE SYST	3343 K (...00)	MB WS FSS
 Actros (...00)	MAINTENANCE SYST	3346 K (...00)	MB WS FSS
 Actros (...00)	MAINTENANCE SYST	3348 K (...00)	MB WS FSS
 Actros (...00)	MAINTENANCE SYST	4140 B (...00)	MB WS FSS
 Actros (...00)	MAINTENANCE SYST	4140 K (...00)	MB WS FSS
 Actros (...00)	MAINTENANCE SYST	4143 K (...00)	MB WS FSS
 Actros (...00)	MAINTENANCE SYST	4146 K (...00)	MB WS FSS
 Actros (...00)	MAINTENANCE SYST	4148 K (...00)	MB WS FSS
 Actros (...00)	PRELIMINARY HEATI	1831 (...00)	MB FLA Termostart.
 Actros (...00)	PRELIMINARY HEATI	1831 K (...00)	MB FLA Termostart.

## Systems supported by ECUreader (up to V5.40)

### TRUCKS




























### Mercedes Trucks

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Actros (...00)	PRELIMINARY HEATI	1831 L (...00)	MB FLA Termostart.
 Actros (...00)	PRELIMINARY HEATI	1831 L nR (...00)	MB FLA Termostart.
 Actros (...00)	PRELIMINARY HEATI	1835 L (...00)	MB FLA Termostart.
 Actros (...00)	PRELIMINARY HEATI	1835 L nR (...00)	MB FLA Termostart.
 Actros (...00)	PRELIMINARY HEATI	1840 (...00)	MB FLA Termostart.
 Actros (...00)	PRELIMINARY HEATI	1840 K (...00)	MB FLA Termostart.
 Actros (...00)	PRELIMINARY HEATI	1840 L (...00)	MB FLA Termostart.
 Actros (...00)	PRELIMINARY HEATI	1840 L nR (...00)	MB FLA Termostart.
 Actros (...00)	PRELIMINARY HEATI	1843 (...00)	MB FLA Termostart.
 Actros (...00)	PRELIMINARY HEATI	1843 K (...00)	MB FLA Termostart.
 Actros (...00)	PRELIMINARY HEATI	1843 L (...00)	MB FLA Termostart.
 Actros (...00)	PRELIMINARY HEATI	1843 L nR (...00)	MB FLA Termostart.
 Actros (...00)	PRELIMINARY HEATI	1846 (...00)	MB FLA Termostart.
 Actros (...00)	PRELIMINARY HEATI	1846 L (...00)	MB FLA Termostart.
 Actros (...00)	PRELIMINARY HEATI	1848 (...00)	MB FLA Termostart.
 Actros (...00)	PRELIMINARY HEATI	1848 L (...00)	MB FLA Termostart.
 Actros (...00)	PRELIMINARY HEATI	1853 L (...00)	MB FLA Termostart.
 Actros (...00)	PRELIMINARY HEATI	1857 L (...00)	MB FLA Termostart.
 Actros (...00)	PRELIMINARY HEATI	2031 AK (...00)	MB FLA Termostart.
 Actros (...00)	PRELIMINARY HEATI	2531 L (...00)	MB FLA Termostart.
 Actros (...00)	PRELIMINARY HEATI	2535 L (...00)	MB FLA Termostart.
 Actros (...00)	PRELIMINARY HEATI	2540 L (...00)	MB FLA Termostart.
 Actros (...00)	PRELIMINARY HEATI	2543 L (...00)	MB FLA Termostart.
 Actros (...00)	PRELIMINARY HEATI	2546 L (...00)	MB FLA Termostart.
 Actros (...00)	PRELIMINARY HEATI	2548 L (...00)	MB FLA Termostart.
 Actros (...00)	PRELIMINARY HEATI	2553 L (...00)	MB FLA Termostart.
 Actros (...00)	PRELIMINARY HEATI	2557 L (...00)	MB FLA Termostart.

## Systems supported by ECReader (up to V5.40)

### TRUCKS




























### Mercedes Trucks

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Actros (...00)	PRELIMINARY HEATI	3243 (...00)	MB FLA Termostart.
 Actros (...00)	PRELIMINARY HEATI	3335 B (...00)	MB FLA Termostart.
 Actros (...00)	PRELIMINARY HEATI	3335 K (...00)	MB FLA Termostart.
 Actros (...00)	PRELIMINARY HEATI	3340 AK (...00)	MB FLA Termostart.
 Actros (...00)	PRELIMINARY HEATI	3340 B (...00)	MB FLA Termostart.
 Actros (...00)	PRELIMINARY HEATI	3340 K (...00)	MB FLA Termostart.
 Actros (...00)	PRELIMINARY HEATI	3343 K (...00)	MB FLA Termostart.
 Actros (...00)	PRELIMINARY HEATI	3346 K (...00)	MB FLA Termostart.
 Actros (...00)	PRELIMINARY HEATI	3348 K (...00)	MB FLA Termostart.
 Actros (...00)	PRELIMINARY HEATI	4140 B (...00)	MB FLA Termostart.
 Actros (...00)	PRELIMINARY HEATI	4140 K (...00)	MB FLA Termostart.
 Actros (...00)	PRELIMINARY HEATI	4143 K (...00)	MB FLA Termostart.
 Actros (...00)	PRELIMINARY HEATI	4146 K (...00)	MB FLA Termostart.
 Actros (...00)	PRELIMINARY HEATI	4148 K (...00)	MB FLA Termostart.
 Actros (...00)	RATIO SEL. MANAGE	1831 (...00)	MB AG AGE
 Actros (...00)	RATIO SEL. MANAGE	1831 K (...00)	MB AG AGE
 Actros (...00)	RATIO SEL. MANAGE	1831 L (...00)	MB AG AGE
 Actros (...00)	RATIO SEL. MANAGE	1831 L nR (...00)	MB AG AGE
 Actros (...00)	RATIO SEL. MANAGE	1835 L (...00)	MB AG AGE
 Actros (...00)	RATIO SEL. MANAGE	1835 L nR (...00)	MB AG AGE
 Actros (...00)	RATIO SEL. MANAGE	1840 (...00)	MB AG AGE
 Actros (...00)	RATIO SEL. MANAGE	1840 K (...00)	MB AG AGE
 Actros (...00)	RATIO SEL. MANAGE	1840 L (...00)	MB AG AGE
 Actros (...00)	RATIO SEL. MANAGE	1840 L nR (...00)	MB AG AGE
 Actros (...00)	RATIO SEL. MANAGE	1843 (...00)	MB AG AGE
 Actros (...00)	RATIO SEL. MANAGE	1843 K (...00)	MB AG AGE
 Actros (...00)	RATIO SEL. MANAGE	1843 L (...00)	MB AG AGE

## Systems supported by ECReader (up to V5.40)

### TRUCKS






### Mercedes Trucks

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Actros (...00)	RATIO SEL. MANAGE	1843 L nR (...00)	MB AG AGE
 Actros (...00)	RATIO SEL. MANAGE	1846 (...00)	MB AG AGE
 Actros (...00)	RATIO SEL. MANAGE	1846 L (...00)	MB AG AGE
 Actros (...00)	RATIO SEL. MANAGE	1848 (...00)	MB AG AGE
 Actros (...00)	RATIO SEL. MANAGE	1848 L (...00)	MB AG AGE
 Actros (...00)	RATIO SEL. MANAGE	1853 L (...00)	MB AG AGE
 Actros (...00)	RATIO SEL. MANAGE	1857 L (...00)	MB AG AGE
 Actros (...00)	RATIO SEL. MANAGE	2031 AK (...00)	MB AG AGE
 Actros (...00)	RATIO SEL. MANAGE	2531 L (...00)	MB AG AGE
 Actros (...00)	RATIO SEL. MANAGE	2535 L (...00)	MB AG AGE
 Actros (...00)	RATIO SEL. MANAGE	2540 L (...00)	MB AG AGE
 Actros (...00)	RATIO SEL. MANAGE	2543 L (...00)	MB AG AGE
 Actros (...00)	RATIO SEL. MANAGE	2546 L (...00)	MB AG AGE
 Actros (...00)	RATIO SEL. MANAGE	2548 L (...00)	MB AG AGE
 Actros (...00)	RATIO SEL. MANAGE	2553 L (...00)	MB AG AGE
 Actros (...00)	RATIO SEL. MANAGE	2557 L (...00)	MB AG AGE
 Actros (...00)	RATIO SEL. MANAGE	3243 (...00)	MB AG AGE
 Actros (...00)	RATIO SEL. MANAGE	3335 B (...00)	MB AG AGE
 Actros (...00)	RATIO SEL. MANAGE	3335 K (...00)	MB AG AGE
 Actros (...00)	RATIO SEL. MANAGE	3340 AK (...00)	MB AG AGE
 Actros (...00)	RATIO SEL. MANAGE	3340 B (...00)	MB AG AGE
 Actros (...00)	RATIO SEL. MANAGE	3340 K (...00)	MB AG AGE
 Actros (...00)	RATIO SEL. MANAGE	3343 K (...00)	MB AG AGE
 Actros (...00)	RATIO SEL. MANAGE	3346 K (...00)	MB AG AGE
 Actros (...00)	RATIO SEL. MANAGE	3348 K (...00)	MB AG AGE
 Actros (...00)	RATIO SEL. MANAGE	4140 B (...00)	MB AG AGE
 Actros (...00)	RATIO SEL. MANAGE	4140 K (...00)	MB AG AGE

## Systems supported by ECUREADER (up to V5.40)

### TRUCKS




























### Mercedes Trucks

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Actros (...00)	RATIO SEL. MANAGE	4143 K (...00)	MB AG AGE
 Actros (...00)	RATIO SEL. MANAGE	4146 K (...00)	MB AG AGE
 Actros (...00)	RATIO SEL. MANAGE	4148 K (...00)	MB AG AGE
 Actros (...00)	SERVICE LIGHT RES	1831 (...00)	MB WS FSS
 Actros (...00)	SERVICE LIGHT RES	1831 K (...00)	MB WS FSS
 Actros (...00)	SERVICE LIGHT RES	1831 L (...00)	MB WS FSS
 Actros (...00)	SERVICE LIGHT RES	1831 L nR (...00)	MB WS FSS
 Actros (...00)	SERVICE LIGHT RES	1835 L (...00)	MB WS FSS
 Actros (...00)	SERVICE LIGHT RES	1835 L nR (...00)	MB WS FSS
 Actros (...00)	SERVICE LIGHT RES	1840 (...00)	MB WS FSS
 Actros (...00)	SERVICE LIGHT RES	1840 K (...00)	MB WS FSS
 Actros (...00)	SERVICE LIGHT RES	1840 L (...00)	MB WS FSS
 Actros (...00)	SERVICE LIGHT RES	1840 L nR (...00)	MB WS FSS
 Actros (...00)	SERVICE LIGHT RES	1843 (...00)	MB WS FSS
 Actros (...00)	SERVICE LIGHT RES	1843 K (...00)	MB WS FSS
 Actros (...00)	SERVICE LIGHT RES	1843 L (...00)	MB WS FSS
 Actros (...00)	SERVICE LIGHT RES	1843 L nR (...00)	MB WS FSS
 Actros (...00)	SERVICE LIGHT RES	1846 (...00)	MB WS FSS
 Actros (...00)	SERVICE LIGHT RES	1846 L (...00)	MB WS FSS
 Actros (...00)	SERVICE LIGHT RES	1848 (...00)	MB WS FSS
 Actros (...00)	SERVICE LIGHT RES	1848 L (...00)	MB WS FSS
 Actros (...00)	SERVICE LIGHT RES	1853 L (...00)	MB WS FSS
 Actros (...00)	SERVICE LIGHT RES	1857 L (...00)	MB WS FSS
 Actros (...00)	SERVICE LIGHT RES	2031 AK (...00)	MB WS FSS
 Actros (...00)	SERVICE LIGHT RES	2531 L (...00)	MB WS FSS
 Actros (...00)	SERVICE LIGHT RES	2535 L (...00)	MB WS FSS
 Actros (...00)	SERVICE LIGHT RES	2540 L (...00)	MB WS FSS

## Systems supported by ECUreader (up to V5.40)

### TRUCKS




























### Mercedes Trucks

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Actros (...00)	SERVICE LIGHT RES	2543 L (...00)	MB WS FSS
 Actros (...00)	SERVICE LIGHT RES	2546 L (...00)	MB WS FSS
 Actros (...00)	SERVICE LIGHT RES	2548 L (...00)	MB WS FSS
 Actros (...00)	SERVICE LIGHT RES	2553 L (...00)	MB WS FSS
 Actros (...00)	SERVICE LIGHT RES	2557 L (...00)	MB WS FSS
 Actros (...00)	SERVICE LIGHT RES	3243 (...00)	MB WS FSS
 Actros (...00)	SERVICE LIGHT RES	3335 B (...00)	MB WS FSS
 Actros (...00)	SERVICE LIGHT RES	3335 K (...00)	MB WS FSS
 Actros (...00)	SERVICE LIGHT RES	3340 AK (...00)	MB WS FSS
 Actros (...00)	SERVICE LIGHT RES	3340 B (...00)	MB WS FSS
 Actros (...00)	SERVICE LIGHT RES	3340 K (...00)	MB WS FSS
 Actros (...00)	SERVICE LIGHT RES	3343 K (...00)	MB WS FSS
 Actros (...00)	SERVICE LIGHT RES	3346 K (...00)	MB WS FSS
 Actros (...00)	SERVICE LIGHT RES	3348 K (...00)	MB WS FSS
 Actros (...00)	SERVICE LIGHT RES	4140 K (...00)	MB WS FSS
 Actros (...00)	SERVICE LIGHT RES	4143 K (...00)	MB WS FSS
 Actros (...00)	SERVICE LIGHT RES	4146 K (...00)	MB WS FSS
 Actros (...00)	SERVICE LIGHT RES	4148 K (...00)	MB WS FSS
 Actros (...00)	SUSPENSION CONTR	1831 (...00)	Wabco NR ECAS
 Actros (...00)	SUSPENSION CONTR	1831 K (...00)	Wabco NR ECAS
 Actros (...00)	SUSPENSION CONTR	1831 L (...00)	Wabco NR ECAS
 Actros (...00)	SUSPENSION CONTR	1831 L nR (...00)	Wabco NR ECAS
 Actros (...00)	SUSPENSION CONTR	1835 L (...00)	Wabco NR ECAS
 Actros (...00)	SUSPENSION CONTR	1835 L nR (...00)	Wabco NR ECAS
 Actros (...00)	SUSPENSION CONTR	1840 (...00)	Wabco NR ECAS
 Actros (...00)	SUSPENSION CONTR	1840 K (...00)	Wabco NR ECAS
 Actros (...00)	SUSPENSION CONTR	1840 L (...00)	Wabco NR ECAS

## Systems supported by ECReader (up to V5.40)

### TRUCKS



























### Mercedes Trucks

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Actros (...00)	SUSPENSION CONTR	1840 L nR (...00)	Wabco NR ECAS
 Actros (...00)	SUSPENSION CONTR	1843 (...00)	Wabco NR ECAS
 Actros (...00)	SUSPENSION CONTR	1843 K (...00)	Wabco NR ECAS
 Actros (...00)	SUSPENSION CONTR	1843 L (...00)	Wabco NR ECAS
 Actros (...00)	SUSPENSION CONTR	1843 L nR (...00)	Wabco NR ECAS
 Actros (...00)	SUSPENSION CONTR	1846 (...00)	Wabco NR ECAS
 Actros (...00)	SUSPENSION CONTR	1846 L (...00)	Wabco NR ECAS
 Actros (...00)	SUSPENSION CONTR	1848 (...00)	Wabco NR ECAS
 Actros (...00)	SUSPENSION CONTR	1848 L (...00)	Wabco NR ECAS
 Actros (...00)	SUSPENSION CONTR	1853 L (...00)	Wabco NR ECAS
 Actros (...00)	SUSPENSION CONTR	1857 L (...00)	Wabco NR ECAS
 Actros (...00)	SUSPENSION CONTR	2031 AK (...00)	Wabco NR ECAS
 Actros (...00)	SUSPENSION CONTR	2531 L (...00)	Wabco NR ECAS
 Actros (...00)	SUSPENSION CONTR	2535 L (...00)	Wabco NR ECAS
 Actros (...00)	SUSPENSION CONTR	2540 L (...00)	Wabco NR ECAS
 Actros (...00)	SUSPENSION CONTR	2543 L (...00)	Wabco NR ECAS
 Actros (...00)	SUSPENSION CONTR	2546 L (...00)	Wabco NR ECAS
 Actros (...00)	SUSPENSION CONTR	2548 L (...00)	Wabco NR ECAS
 Actros (...00)	SUSPENSION CONTR	2553 L (...00)	Wabco NR ECAS
 Actros (...00)	SUSPENSION CONTR	2557 L (...00)	Wabco NR ECAS
 Actros (...00)	SUSPENSION CONTR	3243 (...00)	Wabco NR ECAS
 Actros (...00)	SUSPENSION CONTR	3335 B (...00)	Wabco NR ECAS
 Actros (...00)	SUSPENSION CONTR	3335 K (...00)	Wabco NR ECAS
 Actros (...00)	SUSPENSION CONTR	3340 AK (...00)	Wabco NR ECAS
 Actros (...00)	SUSPENSION CONTR	3340 B (...00)	Wabco NR ECAS
 Actros (...00)	SUSPENSION CONTR	3340 K (...00)	Wabco NR ECAS
 Actros (...00)	SUSPENSION CONTR	3343 K (...00)	Wabco NR ECAS

## Systems supported by ECReader (up to V5.40)

### TRUCKS


























### Mercedes Trucks

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Actros (...00)	SUSPENSION CONTR	3346 K (...00)	Wabco NR ECAS
 Actros (...00)	SUSPENSION CONTR	3348 K (...00)	Wabco NR ECAS
 Actros (...00)	SUSPENSION CONTR	4140 B (...00)	Wabco NR ECAS
 Actros (...00)	SUSPENSION CONTR	4140 K (...00)	Wabco NR ECAS
 Actros (...00)	SUSPENSION CONTR	4143 K (...00)	Wabco NR ECAS
 Actros (...00)	SUSPENSION CONTR	4146 K (...00)	Wabco NR ECAS
 Actros (...00)	SUSPENSION CONTR	4148 K (...00)	Wabco NR ECAS
 Actros (01-02)	ABS	1831 (01-02)	MB ABS
 Actros (01-02)	ABS	1831 K (01-02)	MB ABS
 Actros (01-02)	ABS	1831 L (01-02)	MB ABS
 Actros (01-02)	ABS	1831 L nR (01-02)	MB ABS
 Actros (01-02)	ABS	1835 L (01-02)	MB ABS
 Actros (01-02)	ABS	1835 L nR (01-02)	MB ABS
 Actros (01-02)	ABS	1840 (01-02)	MB ABS
 Actros (01-02)	ABS	1840 K (01-02)	MB ABS
 Actros (01-02)	ABS	1840 L (01-02)	MB ABS
 Actros (01-02)	ABS	1840 L nR (01-02)	MB ABS
 Actros (01-02)	ABS	1843 (01-02)	MB ABS
 Actros (01-02)	ABS	1843 K (01-02)	MB ABS
 Actros (01-02)	ABS	1843 L (01-02)	MB ABS
 Actros (01-02)	ABS	1843 L nR (01-02)	MB ABS
 Actros (01-02)	ABS	1846 (01-02)	MB ABS
 Actros (01-02)	ABS	1846 L (01-02)	MB ABS
 Actros (01-02)	ABS	1848 (01-02)	MB ABS
 Actros (01-02)	ABS	1848 L (01-02)	MB ABS
 Actros (01-02)	ABS	1853 L (01-02)	MB ABS

## Systems supported by ECReader (up to V5.40)

### TRUCKS




























### Mercedes Trucks

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Actros (01-02)	ABS	1857 L (01-02)	MB ABS
 Actros (01-02)	ABS	2031 AK (01-02)	MB ABS
 Actros (01-02)	ABS	2531 L (01-02)	MB ABS
 Actros (01-02)	ABS	2535 L (01-02)	MB ABS
 Actros (01-02)	ABS	2540 L (01-02)	MB ABS
 Actros (01-02)	ABS	2543 L (01-02)	MB ABS
 Actros (01-02)	ABS	2546 L (01-02)	MB ABS
 Actros (01-02)	ABS	2548 L (01-02)	MB ABS
 Actros (01-02)	ABS	2553 L (01-02)	MB ABS
 Actros (01-02)	ABS	2557 L (01-02)	MB ABS
 Actros (01-02)	ABS	3243 (01-02)	MB ABS
 Actros (01-02)	ABS	3335 B (01-02)	MB ABS
 Actros (01-02)	ABS	3335 K (01-02)	MB ABS
 Actros (01-02)	ABS	3340 AK (01-02)	MB ABS
 Actros (01-02)	ABS	3340 B (01-02)	MB ABS
 Actros (01-02)	ABS	3340 K (01-02)	MB ABS
 Actros (01-02)	ABS	3343 K (01-02)	MB ABS
 Actros (01-02)	ABS	3346 K (01-02)	MB ABS
 Actros (01-02)	ABS	3348 K (01-02)	MB ABS
 Actros (01-02)	ABS	4140 B (01-02)	MB ABS
 Actros (01-02)	ABS	4140 K (01-02)	MB ABS
 Actros (01-02)	ABS	4143 K (01-02)	MB ABS
 Actros (01-02)	ABS	4146 K (01-02)	MB ABS
 Actros (01-02)	ABS	4148 K (01-02)	MB ABS
 Actros (01-02)	BRAKE POWER SUP	1831 (01-02)	MB RS Retarder
 Actros (01-02)	BRAKE POWER SUP	1831 K (01-02)	MB RS Retarder
 Actros (01-02)	BRAKE POWER SUP	1831 L (01-02)	MB RS Retarder

## Systems supported by ECReader (up to V5.40)

### TRUCKS




























### Mercedes Trucks

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Actros (01-02)	BRAKE POWER SUP	1831 L nR (01-02)	MB RS Retarder
 Actros (01-02)	BRAKE POWER SUP	1835 L (01-02)	MB RS Retarder
 Actros (01-02)	BRAKE POWER SUP	1835 L nR (01-02)	MB RS Retarder
 Actros (01-02)	BRAKE POWER SUP	1840 (01-02)	MB RS Retarder
 Actros (01-02)	BRAKE POWER SUP	1840 K (01-02)	MB RS Retarder
 Actros (01-02)	BRAKE POWER SUP	1840 L (01-02)	MB RS Retarder
 Actros (01-02)	BRAKE POWER SUP	1840 L nR (01-02)	MB RS Retarder
 Actros (01-02)	BRAKE POWER SUP	1843 (01-02)	MB RS Retarder
 Actros (01-02)	BRAKE POWER SUP	1843 K (01-02)	MB RS Retarder
 Actros (01-02)	BRAKE POWER SUP	1843 L (01-02)	MB RS Retarder
 Actros (01-02)	BRAKE POWER SUP	1843 L nR (01-02)	MB RS Retarder
 Actros (01-02)	BRAKE POWER SUP	1846 (01-02)	MB RS Retarder
 Actros (01-02)	BRAKE POWER SUP	1846 L (01-02)	MB RS Retarder
 Actros (01-02)	BRAKE POWER SUP	1848 (01-02)	MB RS Retarder
 Actros (01-02)	BRAKE POWER SUP	1848 L (01-02)	MB RS Retarder
 Actros (01-02)	BRAKE POWER SUP	1853 L (01-02)	MB RS Retarder
 Actros (01-02)	BRAKE POWER SUP	1857 L (01-02)	MB RS Retarder
 Actros (01-02)	BRAKE POWER SUP	2031 AK (01-02)	MB RS Retarder
 Actros (01-02)	BRAKE POWER SUP	2531 L (01-02)	MB RS Retarder
 Actros (01-02)	BRAKE POWER SUP	2535 L (01-02)	MB RS Retarder
 Actros (01-02)	BRAKE POWER SUP	2540 L (01-02)	MB RS Retarder
 Actros (01-02)	BRAKE POWER SUP	2543 L (01-02)	MB RS Retarder
 Actros (01-02)	BRAKE POWER SUP	2546 L (01-02)	MB RS Retarder
 Actros (01-02)	BRAKE POWER SUP	2548 L (01-02)	MB RS Retarder
 Actros (01-02)	BRAKE POWER SUP	2553 L (01-02)	MB RS Retarder
 Actros (01-02)	BRAKE POWER SUP	2557 L (01-02)	MB RS Retarder
 Actros (01-02)	BRAKE POWER SUP	3243 (01-02)	MB RS Retarder

## Systems supported by ECUreader (up to V5.40)

### TRUCKS




























### Mercedes Trucks

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Actros (01-02)	BRAKE POWER SUP	3335 B (01-02)	MB RS Retarder
 Actros (01-02)	BRAKE POWER SUP	3335 K (01-02)	MB RS Retarder
 Actros (01-02)	BRAKE POWER SUP	3340 AK (01-02)	MB RS Retarder
 Actros (01-02)	BRAKE POWER SUP	3340 B (01-02)	MB RS Retarder
 Actros (01-02)	BRAKE POWER SUP	3340 K (01-02)	MB RS Retarder
 Actros (01-02)	BRAKE POWER SUP	3343 K (01-02)	MB RS Retarder
 Actros (01-02)	BRAKE POWER SUP	3346 K (01-02)	MB RS Retarder
 Actros (01-02)	BRAKE POWER SUP	3348 K (01-02)	MB RS Retarder
 Actros (01-02)	BRAKE POWER SUP	4140 B (01-02)	MB RS Retarder
 Actros (01-02)	BRAKE POWER SUP	4140 K (01-02)	MB RS Retarder
 Actros (01-02)	BRAKE POWER SUP	4143 K (01-02)	MB RS Retarder
 Actros (01-02)	BRAKE POWER SUP	4146 K (01-02)	MB RS Retarder
 Actros (01-02)	BRAKE POWER SUP	4148 K (01-02)	MB RS Retarder
 Actros (01-02)	BRAKE SYS. MANAG	1831 (01-02)	MB BS EPB
 Actros (01-02)	BRAKE SYS. MANAG	1831 K (01-02)	MB BS EPB
 Actros (01-02)	BRAKE SYS. MANAG	1831 L (01-02)	MB BS EPB
 Actros (01-02)	BRAKE SYS. MANAG	1831 L nR (01-02)	MB BS EPB
 Actros (01-02)	BRAKE SYS. MANAG	1835 L (01-02)	MB BS EPB
 Actros (01-02)	BRAKE SYS. MANAG	1835 L nR (01-02)	MB BS EPB
 Actros (01-02)	BRAKE SYS. MANAG	1840 (01-02)	MB BS EPB
 Actros (01-02)	BRAKE SYS. MANAG	1840 K (01-02)	MB BS EPB
 Actros (01-02)	BRAKE SYS. MANAG	1840 L (01-02)	MB BS EPB
 Actros (01-02)	BRAKE SYS. MANAG	1840 L nR (01-02)	MB BS EPB
 Actros (01-02)	BRAKE SYS. MANAG	1843 (01-02)	MB BS EPB
 Actros (01-02)	BRAKE SYS. MANAG	1843 K (01-02)	MB BS EPB
 Actros (01-02)	BRAKE SYS. MANAG	1843 L (01-02)	MB BS EPB
 Actros (01-02)	BRAKE SYS. MANAG	1843 L nR (01-02)	MB BS EPB

## Systems supported by ECReader (up to V5.40)

### TRUCKS




























### Mercedes Trucks

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Actros (01-02)	BRAKE SYS. MANAG	1846 (01-02)	MB BS EPB
 Actros (01-02)	BRAKE SYS. MANAG	1846 L (01-02)	MB BS EPB
 Actros (01-02)	BRAKE SYS. MANAG	1848 (01-02)	MB BS EPB
 Actros (01-02)	BRAKE SYS. MANAG	1848 L (01-02)	MB BS EPB
 Actros (01-02)	BRAKE SYS. MANAG	1853 L (01-02)	MB BS EPB
 Actros (01-02)	BRAKE SYS. MANAG	1857 L (01-02)	MB BS EPB
 Actros (01-02)	BRAKE SYS. MANAG	2031 AK (01-02)	MB BS EPB
 Actros (01-02)	BRAKE SYS. MANAG	2531 L (01-02)	MB BS EPB
 Actros (01-02)	BRAKE SYS. MANAG	2535 L (01-02)	MB BS EPB
 Actros (01-02)	BRAKE SYS. MANAG	2540 L (01-02)	MB BS EPB
 Actros (01-02)	BRAKE SYS. MANAG	2543 L (01-02)	MB BS EPB
 Actros (01-02)	BRAKE SYS. MANAG	2546 L (01-02)	MB BS EPB
 Actros (01-02)	BRAKE SYS. MANAG	2548 L (01-02)	MB BS EPB
 Actros (01-02)	BRAKE SYS. MANAG	2553 L (01-02)	MB BS EPB
 Actros (01-02)	BRAKE SYS. MANAG	2557 L (01-02)	MB BS EPB
 Actros (01-02)	BRAKE SYS. MANAG	3243 (01-02)	MB BS EPB
 Actros (01-02)	BRAKE SYS. MANAG	3335 B (01-02)	MB BS EPB
 Actros (01-02)	BRAKE SYS. MANAG	3335 K (01-02)	MB BS EPB
 Actros (01-02)	BRAKE SYS. MANAG	3340 AK (01-02)	MB BS EPB
 Actros (01-02)	BRAKE SYS. MANAG	3340 B (01-02)	MB BS EPB
 Actros (01-02)	BRAKE SYS. MANAG	3340 K (01-02)	MB BS EPB
 Actros (01-02)	BRAKE SYS. MANAG	3343 K (01-02)	MB BS EPB
 Actros (01-02)	BRAKE SYS. MANAG	3346 K (01-02)	MB BS EPB
 Actros (01-02)	BRAKE SYS. MANAG	3348 K (01-02)	MB BS EPB
 Actros (01-02)	BRAKE SYS. MANAG	4140 B (01-02)	MB BS EPB
 Actros (01-02)	BRAKE SYS. MANAG	4140 K (01-02)	MB BS EPB
 Actros (01-02)	BRAKE SYS. MANAG	4143 K (01-02)	MB BS EPB

## Systems supported by ECUREADER (up to V5.40)

### TRUCKS




























### Mercedes Trucks

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Actros (01-02)	BRAKE SYS. MANAG	4146 K (01-02)	MB BS EPB
 Actros (01-02)	BRAKE SYS. MANAG	4148 K (01-02)	MB BS EPB
 Actros (01-02)	CLIMA	1831 (01-02)	MB HZR
 Actros (01-02)	CLIMA	1831 K (01-02)	MB HZR
 Actros (01-02)	CLIMA	1831 L (01-02)	MB HZR
 Actros (01-02)	CLIMA	1831 L nR (01-02)	MB HZR
 Actros (01-02)	CLIMA	1835 L (01-02)	MB HZR
 Actros (01-02)	CLIMA	1835 L nR (01-02)	MB HZR
 Actros (01-02)	CLIMA	1840 (01-02)	MB HZR
 Actros (01-02)	CLIMA	1840 K (01-02)	MB HZR
 Actros (01-02)	CLIMA	1840 L (01-02)	MB HZR
 Actros (01-02)	CLIMA	1840 L nR (01-02)	MB HZR
 Actros (01-02)	CLIMA	1843 (01-02)	MB HZR
 Actros (01-02)	CLIMA	1843 K (01-02)	MB HZR
 Actros (01-02)	CLIMA	1843 L (01-02)	MB HZR
 Actros (01-02)	CLIMA	1843 L nR (01-02)	MB HZR
 Actros (01-02)	CLIMA	1846 (01-02)	MB HZR
 Actros (01-02)	CLIMA	1846 L (01-02)	MB HZR
 Actros (01-02)	CLIMA	1848 (01-02)	MB HZR
 Actros (01-02)	CLIMA	1848 L (01-02)	MB HZR
 Actros (01-02)	CLIMA	1853 L (01-02)	MB HZR
 Actros (01-02)	CLIMA	1857 L (01-02)	MB HZR
 Actros (01-02)	CLIMA	2031 AK (01-02)	MB HZR
 Actros (01-02)	CLIMA	2531 L (01-02)	MB HZR
 Actros (01-02)	CLIMA	2535 L (01-02)	MB HZR
 Actros (01-02)	CLIMA	2540 L (01-02)	MB HZR
 Actros (01-02)	CLIMA	2543 L (01-02)	MB HZR

## Systems supported by ECUREADER (up to V5.40)

### TRUCKS




























### Mercedes Trucks

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Actros (01-02)	CLIMA	2546 L (01-02)	MB HZR
 Actros (01-02)	CLIMA	2548 L (01-02)	MB HZR
 Actros (01-02)	CLIMA	2553 L (01-02)	MB HZR
 Actros (01-02)	CLIMA	2557 L (01-02)	MB HZR
 Actros (01-02)	CLIMA	3243 (01-02)	MB HZR
 Actros (01-02)	CLIMA	3335 B (01-02)	MB HZR
 Actros (01-02)	CLIMA	3335 K (01-02)	MB HZR
 Actros (01-02)	CLIMA	3340 AK (01-02)	MB HZR
 Actros (01-02)	CLIMA	3340 B (01-02)	MB HZR
 Actros (01-02)	CLIMA	3340 K (01-02)	MB HZR
 Actros (01-02)	CLIMA	3343 K (01-02)	MB HZR
 Actros (01-02)	CLIMA	3346 K (01-02)	MB HZR
 Actros (01-02)	CLIMA	3348 K (01-02)	MB HZR
 Actros (01-02)	CLIMA	4140 B (01-02)	MB HZR
 Actros (01-02)	CLIMA	4140 K (01-02)	MB HZR
 Actros (01-02)	CLIMA	4143 K (01-02)	MB HZR
 Actros (01-02)	CLIMA	4146 K (01-02)	MB HZR
 Actros (01-02)	CLIMA	4148 K (01-02)	MB HZR
 Actros (01-02)	CLUTCH ELECTRONI	1831 (01-02)	MB KS MKR
 Actros (01-02)	CLUTCH ELECTRONI	1831 K (01-02)	MB KS MKR
 Actros (01-02)	CLUTCH ELECTRONI	1831 L (01-02)	MB KS MKR
 Actros (01-02)	CLUTCH ELECTRONI	1831 L nR (01-02)	MB KS MKR
 Actros (01-02)	CLUTCH ELECTRONI	1835 L (01-02)	MB KS MKR
 Actros (01-02)	CLUTCH ELECTRONI	1835 L nR (01-02)	MB KS MKR
 Actros (01-02)	CLUTCH ELECTRONI	1840 (01-02)	MB KS MKR
 Actros (01-02)	CLUTCH ELECTRONI	1840 K (01-02)	MB KS MKR
 Actros (01-02)	CLUTCH ELECTRONI	1840 L (01-02)	MB KS MKR

## Systems supported by ECUREADER (up to V5.40)

### TRUCKS




























### Mercedes Trucks

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Actros (01-02)	CLUTCH ELECTRONI	1840 L nR (01-02)	MB KS MKR
 Actros (01-02)	CLUTCH ELECTRONI	1843 (01-02)	MB KS MKR
 Actros (01-02)	CLUTCH ELECTRONI	1843 K (01-02)	MB KS MKR
 Actros (01-02)	CLUTCH ELECTRONI	1843 L (01-02)	MB KS MKR
 Actros (01-02)	CLUTCH ELECTRONI	1843 L nR (01-02)	MB KS MKR
 Actros (01-02)	CLUTCH ELECTRONI	1846 (01-02)	MB KS MKR
 Actros (01-02)	CLUTCH ELECTRONI	1846 L (01-02)	MB KS MKR
 Actros (01-02)	CLUTCH ELECTRONI	1848 (01-02)	MB KS MKR
 Actros (01-02)	CLUTCH ELECTRONI	1848 L (01-02)	MB KS MKR
 Actros (01-02)	CLUTCH ELECTRONI	1853 L (01-02)	MB KS MKR
 Actros (01-02)	CLUTCH ELECTRONI	1857 L (01-02)	MB KS MKR
 Actros (01-02)	CLUTCH ELECTRONI	2031 AK (01-02)	MB KS MKR
 Actros (01-02)	CLUTCH ELECTRONI	2531 L (01-02)	MB KS MKR
 Actros (01-02)	CLUTCH ELECTRONI	2535 L (01-02)	MB KS MKR
 Actros (01-02)	CLUTCH ELECTRONI	2540 L (01-02)	MB KS MKR
 Actros (01-02)	CLUTCH ELECTRONI	2543 L (01-02)	MB KS MKR
 Actros (01-02)	CLUTCH ELECTRONI	2546 L (01-02)	MB KS MKR
 Actros (01-02)	CLUTCH ELECTRONI	2548 L (01-02)	MB KS MKR
 Actros (01-02)	CLUTCH ELECTRONI	2553 L (01-02)	MB KS MKR
 Actros (01-02)	CLUTCH ELECTRONI	2557 L (01-02)	MB KS MKR
 Actros (01-02)	CLUTCH ELECTRONI	3243 (01-02)	MB KS MKR
 Actros (01-02)	CLUTCH ELECTRONI	3335 B (01-02)	MB KS MKR
 Actros (01-02)	CLUTCH ELECTRONI	3335 K (01-02)	MB KS MKR
 Actros (01-02)	CLUTCH ELECTRONI	3340 AK (01-02)	MB KS MKR
 Actros (01-02)	CLUTCH ELECTRONI	3340 B (01-02)	MB KS MKR
 Actros (01-02)	CLUTCH ELECTRONI	3340 K (01-02)	MB KS MKR
 Actros (01-02)	CLUTCH ELECTRONI	3343 K (01-02)	MB KS MKR

## Systems supported by ECReader (up to V5.40)

### TRUCKS




























### Mercedes Trucks

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Actros (01-02)	CLUTCH ELECTRONI	3346 K (01-02)	MB KS MKR
 Actros (01-02)	CLUTCH ELECTRONI	3348 K (01-02)	MB KS MKR
 Actros (01-02)	CLUTCH ELECTRONI	4140 B (01-02)	MB KS MKR
 Actros (01-02)	CLUTCH ELECTRONI	4140 K (01-02)	MB KS MKR
 Actros (01-02)	CLUTCH ELECTRONI	4143 K (01-02)	MB KS MKR
 Actros (01-02)	CLUTCH ELECTRONI	4146 K (01-02)	MB KS MKR
 Actros (01-02)	CLUTCH ELECTRONI	4148 K (01-02)	MB KS MKR
 Actros (01-02)	CRUISE MANAGEME	1831 (01-02)	FR FMR
 Actros (01-02)	CRUISE MANAGEME	1831 K (01-02)	FR FMR
 Actros (01-02)	CRUISE MANAGEME	1831 L (01-02)	FR FMR
 Actros (01-02)	CRUISE MANAGEME	1831 L nR (01-02)	FR FMR
 Actros (01-02)	CRUISE MANAGEME	1835 L (01-02)	FR FMR
 Actros (01-02)	CRUISE MANAGEME	1835 L nR (01-02)	FR FMR
 Actros (01-02)	CRUISE MANAGEME	1840 (01-02)	FR FMR
 Actros (01-02)	CRUISE MANAGEME	1840 K (01-02)	FR FMR
 Actros (01-02)	CRUISE MANAGEME	1840 L (01-02)	FR FMR
 Actros (01-02)	CRUISE MANAGEME	1840 L nR (01-02)	FR FMR
 Actros (01-02)	CRUISE MANAGEME	1843 (01-02)	FR FMR
 Actros (01-02)	CRUISE MANAGEME	1843 K (01-02)	FR FMR
 Actros (01-02)	CRUISE MANAGEME	1843 L (01-02)	FR FMR
 Actros (01-02)	CRUISE MANAGEME	1843 L nR (01-02)	FR FMR
 Actros (01-02)	CRUISE MANAGEME	1846 (01-02)	FR FMR
 Actros (01-02)	CRUISE MANAGEME	1846 L (01-02)	FR FMR
 Actros (01-02)	CRUISE MANAGEME	1848 (01-02)	FR FMR
 Actros (01-02)	CRUISE MANAGEME	1848 L (01-02)	FR FMR
 Actros (01-02)	CRUISE MANAGEME	1853 L (01-02)	FR FMR
 Actros (01-02)	CRUISE MANAGEME	1857 L (01-02)	FR FMR

## Systems supported by ECReader (up to V5.40)

### TRUCKS




























### Mercedes Trucks

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Actros (01-02)	CRUISE MANAGEME	2031 AK (01-02)	FR FMR
 Actros (01-02)	CRUISE MANAGEME	2531 L (01-02)	FR FMR
 Actros (01-02)	CRUISE MANAGEME	2535 L (01-02)	FR FMR
 Actros (01-02)	CRUISE MANAGEME	2540 L (01-02)	FR FMR
 Actros (01-02)	CRUISE MANAGEME	2543 L (01-02)	FR FMR
 Actros (01-02)	CRUISE MANAGEME	2546 L (01-02)	FR FMR
 Actros (01-02)	CRUISE MANAGEME	2548 L (01-02)	FR FMR
 Actros (01-02)	CRUISE MANAGEME	2553 L (01-02)	FR FMR
 Actros (01-02)	CRUISE MANAGEME	2557 L (01-02)	FR FMR
 Actros (01-02)	CRUISE MANAGEME	3243 (01-02)	FR FMR
 Actros (01-02)	CRUISE MANAGEME	3335 B (01-02)	FR FMR
 Actros (01-02)	CRUISE MANAGEME	3335 K (01-02)	FR FMR
 Actros (01-02)	CRUISE MANAGEME	3340 AK (01-02)	FR FMR
 Actros (01-02)	CRUISE MANAGEME	3340 B (01-02)	FR FMR
 Actros (01-02)	CRUISE MANAGEME	3340 K (01-02)	FR FMR
 Actros (01-02)	CRUISE MANAGEME	3343 K (01-02)	FR FMR
 Actros (01-02)	CRUISE MANAGEME	3346 K (01-02)	FR FMR
 Actros (01-02)	CRUISE MANAGEME	3348 K (01-02)	FR FMR
 Actros (01-02)	CRUISE MANAGEME	4140 B (01-02)	FR FMR
 Actros (01-02)	CRUISE MANAGEME	4140 K (01-02)	FR FMR
 Actros (01-02)	CRUISE MANAGEME	4143 K (01-02)	FR FMR
 Actros (01-02)	CRUISE MANAGEME	4146 K (01-02)	FR FMR
 Actros (01-02)	CRUISE MANAGEME	4148 K (01-02)	FR FMR
 Actros (01-02)	DASHBOARD	1831 (01-02)	MB INS Comb. Instrument
 Actros (01-02)	DASHBOARD	1831 K (01-02)	MB INS Comb. Instrument
 Actros (01-02)	DASHBOARD	1831 L (01-02)	MB INS Comb. Instrument
 Actros (01-02)	DASHBOARD	1831 L nR (01-02)	MB INS Comb. Instrument

## Systems supported by ECReader (up to V5.40)

### TRUCKS




























### Mercedes Trucks

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Actros (01-02)	DASHBOARD	1835 L (01-02)	MB INS Comb. Instrument
 Actros (01-02)	DASHBOARD	1835 L nR (01-02)	MB INS Comb. Instrument
 Actros (01-02)	DASHBOARD	1840 (01-02)	MB INS Comb. Instrument
 Actros (01-02)	DASHBOARD	1840 K (01-02)	MB INS Comb. Instrument
 Actros (01-02)	DASHBOARD	1840 L (01-02)	MB INS Comb. Instrument
 Actros (01-02)	DASHBOARD	1840 L nR (01-02)	MB INS Comb. Instrument
 Actros (01-02)	DASHBOARD	1843 (01-02)	MB INS Comb. Instrument
 Actros (01-02)	DASHBOARD	1843 K (01-02)	MB INS Comb. Instrument
 Actros (01-02)	DASHBOARD	1843 L (01-02)	MB INS Comb. Instrument
 Actros (01-02)	DASHBOARD	1843 L nR (01-02)	MB INS Comb. Instrument
 Actros (01-02)	DASHBOARD	1846 (01-02)	MB INS Comb. Instrument
 Actros (01-02)	DASHBOARD	1846 L (01-02)	MB INS Comb. Instrument
 Actros (01-02)	DASHBOARD	1848 (01-02)	MB INS Comb. Instrument
 Actros (01-02)	DASHBOARD	1848 L (01-02)	MB INS Comb. Instrument
 Actros (01-02)	DASHBOARD	1853 L (01-02)	MB INS Comb. Instrument
 Actros (01-02)	DASHBOARD	1857 L (01-02)	MB INS Comb. Instrument
 Actros (01-02)	DASHBOARD	2031 AK (01-02)	MB INS Comb. Instrument
 Actros (01-02)	DASHBOARD	2531 L (01-02)	MB INS Comb. Instrument
 Actros (01-02)	DASHBOARD	2535 L (01-02)	MB INS Comb. Instrument
 Actros (01-02)	DASHBOARD	2540 L (01-02)	MB INS Comb. Instrument
 Actros (01-02)	DASHBOARD	2543 L (01-02)	MB INS Comb. Instrument
 Actros (01-02)	DASHBOARD	2546 L (01-02)	MB INS Comb. Instrument
 Actros (01-02)	DASHBOARD	2548 L (01-02)	MB INS Comb. Instrument
 Actros (01-02)	DASHBOARD	2553 L (01-02)	MB INS Comb. Instrument
 Actros (01-02)	DASHBOARD	2557 L (01-02)	MB INS Comb. Instrument
 Actros (01-02)	DASHBOARD	3243 (01-02)	MB INS Comb. Instrument
 Actros (01-02)	DASHBOARD	3335 B (01-02)	MB INS Comb. Instrument

## Systems supported by ECUREADER (up to V5.40)

### TRUCKS




























### Mercedes Trucks

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Actros (01-02)	DASHBOARD	3335 K (01-02)	MB INS Comb. Instrument
 Actros (01-02)	DASHBOARD	3340 AK (01-02)	MB INS Comb. Instrument
 Actros (01-02)	DASHBOARD	3340 B (01-02)	MB INS Comb. Instrument
 Actros (01-02)	DASHBOARD	3340 K (01-02)	MB INS Comb. Instrument
 Actros (01-02)	DASHBOARD	3343 K (01-02)	MB INS Comb. Instrument
 Actros (01-02)	DASHBOARD	3346 K (01-02)	MB INS Comb. Instrument
 Actros (01-02)	DASHBOARD	3348 K (01-02)	MB INS Comb. Instrument
 Actros (01-02)	DASHBOARD	4140 B (01-02)	MB INS Comb. Instrument
 Actros (01-02)	DASHBOARD	4140 K (01-02)	MB INS Comb. Instrument
 Actros (01-02)	DASHBOARD	4143 K (01-02)	MB INS Comb. Instrument
 Actros (01-02)	DASHBOARD	4146 K (01-02)	MB INS Comb. Instrument
 Actros (01-02)	DASHBOARD	4148 K (01-02)	MB INS Comb. Instrument
 Actros (01-02)	ENGINE MANAGEME	1831 (01-02)	MB MR PLD (EDC)
 Actros (01-02)	ENGINE MANAGEME	1831 K (01-02)	MB MR PLD (EDC)
 Actros (01-02)	ENGINE MANAGEME	1831 L (01-02)	MB MR PLD (EDC)
 Actros (01-02)	ENGINE MANAGEME	1831 L nR (01-02)	MB MR PLD (EDC)
 Actros (01-02)	ENGINE MANAGEME	1835 L (01-02)	MB MR PLD (EDC)
 Actros (01-02)	ENGINE MANAGEME	1835 L nR (01-02)	MB MR PLD (EDC)
 Actros (01-02)	ENGINE MANAGEME	1840 (01-02)	MB MR PLD (EDC)
 Actros (01-02)	ENGINE MANAGEME	1840 K (01-02)	MB MR PLD (EDC)
 Actros (01-02)	ENGINE MANAGEME	1840 L (01-02)	MB MR PLD (EDC)
 Actros (01-02)	ENGINE MANAGEME	1840 L nR (01-02)	MB MR PLD (EDC)
 Actros (01-02)	ENGINE MANAGEME	1843 (01-02)	MB MR PLD (EDC)
 Actros (01-02)	ENGINE MANAGEME	1843 K (01-02)	MB MR PLD (EDC)
 Actros (01-02)	ENGINE MANAGEME	1843 L (01-02)	MB MR PLD (EDC)
 Actros (01-02)	ENGINE MANAGEME	1843 L nR (01-02)	MB MR PLD (EDC)
 Actros (01-02)	ENGINE MANAGEME	1846 (01-02)	MB MR PLD (EDC)

## Systems supported by ECReader (up to V5.40)

### TRUCKS




























### Mercedes Trucks

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Actros (01-02)	ENGINE MANAGEME	1846 L (01-02)	MB MR PLD (EDC)
 Actros (01-02)	ENGINE MANAGEME	1848 (01-02)	MB MR PLD (EDC)
 Actros (01-02)	ENGINE MANAGEME	1848 L (01-02)	MB MR PLD (EDC)
 Actros (01-02)	ENGINE MANAGEME	1853 L (01-02)	MB MR PLD (EDC)
 Actros (01-02)	ENGINE MANAGEME	1857 L (01-02)	MB MR PLD (EDC)
 Actros (01-02)	ENGINE MANAGEME	2031 AK (01-02)	MB MR PLD (EDC)
 Actros (01-02)	ENGINE MANAGEME	2531 L (01-02)	MB MR PLD (EDC)
 Actros (01-02)	ENGINE MANAGEME	2535 L (01-02)	MB MR PLD (EDC)
 Actros (01-02)	ENGINE MANAGEME	2540 L (01-02)	MB MR PLD (EDC)
 Actros (01-02)	ENGINE MANAGEME	2543 L (01-02)	MB MR PLD (EDC)
 Actros (01-02)	ENGINE MANAGEME	2546 L (01-02)	MB MR PLD (EDC)
 Actros (01-02)	ENGINE MANAGEME	2548 L (01-02)	MB MR PLD (EDC)
 Actros (01-02)	ENGINE MANAGEME	2553 L (01-02)	MB MR PLD (EDC)
 Actros (01-02)	ENGINE MANAGEME	2557 L (01-02)	MB MR PLD (EDC)
 Actros (01-02)	ENGINE MANAGEME	3243 (01-02)	MB MR PLD (EDC)
 Actros (01-02)	ENGINE MANAGEME	3335 B (01-02)	MB MR PLD (EDC)
 Actros (01-02)	ENGINE MANAGEME	3335 K (01-02)	MB MR PLD (EDC)
 Actros (01-02)	ENGINE MANAGEME	3340 AK (01-02)	MB MR PLD (EDC)
 Actros (01-02)	ENGINE MANAGEME	3340 B (01-02)	MB MR PLD (EDC)
 Actros (01-02)	ENGINE MANAGEME	3340 K (01-02)	MB MR PLD (EDC)
 Actros (01-02)	ENGINE MANAGEME	3343 K (01-02)	MB MR PLD (EDC)
 Actros (01-02)	ENGINE MANAGEME	3346 K (01-02)	MB MR PLD (EDC)
 Actros (01-02)	ENGINE MANAGEME	3348 K (01-02)	MB MR PLD (EDC)
 Actros (01-02)	ENGINE MANAGEME	4140 B (01-02)	MB MR PLD (EDC)
 Actros (01-02)	ENGINE MANAGEME	4140 K (01-02)	MB MR PLD (EDC)
 Actros (01-02)	ENGINE MANAGEME	4143 K (01-02)	MB MR PLD (EDC)
 Actros (01-02)	ENGINE MANAGEME	4146 K (01-02)	MB MR PLD (EDC)

## Systems supported by ECUREADER (up to V5.40)

### TRUCKS




























### Mercedes Trucks

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Actros (01-02)	ENGINE MANAGEME	4148 K (01-02)	MB MR PLD (EDC)
 Actros (01-02)	GEARBOX MANAGEM	1831 (01-02)	MB GS EPS
 Actros (01-02)	GEARBOX MANAGEM	1831 K (01-02)	MB GS EPS
 Actros (01-02)	GEARBOX MANAGEM	1831 L (01-02)	MB GS EPS
 Actros (01-02)	GEARBOX MANAGEM	1831 L nR (01-02)	MB GS EPS
 Actros (01-02)	GEARBOX MANAGEM	1835 L (01-02)	MB GS EPS
 Actros (01-02)	GEARBOX MANAGEM	1835 L nR (01-02)	MB GS EPS
 Actros (01-02)	GEARBOX MANAGEM	1840 (01-02)	MB GS EPS
 Actros (01-02)	GEARBOX MANAGEM	1840 K (01-02)	MB GS EPS
 Actros (01-02)	GEARBOX MANAGEM	1840 L (01-02)	MB GS EPS
 Actros (01-02)	GEARBOX MANAGEM	1840 L nR (01-02)	MB GS EPS
 Actros (01-02)	GEARBOX MANAGEM	1843 (01-02)	MB GS EPS
 Actros (01-02)	GEARBOX MANAGEM	1843 K (01-02)	MB GS EPS
 Actros (01-02)	GEARBOX MANAGEM	1843 L (01-02)	MB GS EPS
 Actros (01-02)	GEARBOX MANAGEM	1843 L nR (01-02)	MB GS EPS
 Actros (01-02)	GEARBOX MANAGEM	1846 (01-02)	MB GS EPS
 Actros (01-02)	GEARBOX MANAGEM	1846 L (01-02)	MB GS EPS
 Actros (01-02)	GEARBOX MANAGEM	1848 (01-02)	MB GS EPS
 Actros (01-02)	GEARBOX MANAGEM	1848 L (01-02)	MB GS EPS
 Actros (01-02)	GEARBOX MANAGEM	1853 L (01-02)	MB GS EPS
 Actros (01-02)	GEARBOX MANAGEM	1857 L (01-02)	MB GS EPS
 Actros (01-02)	GEARBOX MANAGEM	2031 AK (01-02)	MB GS EPS
 Actros (01-02)	GEARBOX MANAGEM	2531 L (01-02)	MB GS EPS
 Actros (01-02)	GEARBOX MANAGEM	2535 L (01-02)	MB GS EPS
 Actros (01-02)	GEARBOX MANAGEM	2540 L (01-02)	MB GS EPS
 Actros (01-02)	GEARBOX MANAGEM	2543 L (01-02)	MB GS EPS
 Actros (01-02)	GEARBOX MANAGEM	2546 L (01-02)	MB GS EPS

## Systems supported by ECReader (up to V5.40)

### TRUCKS




























### Mercedes Trucks

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Actros (01-02)	GEARBOX MANAGEM	2548 L (01-02)	MB GS EPS
 Actros (01-02)	GEARBOX MANAGEM	2553 L (01-02)	MB GS EPS
 Actros (01-02)	GEARBOX MANAGEM	2557 L (01-02)	MB GS EPS
 Actros (01-02)	GEARBOX MANAGEM	3243 (01-02)	MB GS EPS
 Actros (01-02)	GEARBOX MANAGEM	3335 B (01-02)	MB GS EPS
 Actros (01-02)	GEARBOX MANAGEM	3335 K (01-02)	MB GS EPS
 Actros (01-02)	GEARBOX MANAGEM	3340 AK (01-02)	MB GS EPS
 Actros (01-02)	GEARBOX MANAGEM	3340 B (01-02)	MB GS EPS
 Actros (01-02)	GEARBOX MANAGEM	3340 K (01-02)	MB GS EPS
 Actros (01-02)	GEARBOX MANAGEM	3343 K (01-02)	MB GS EPS
 Actros (01-02)	GEARBOX MANAGEM	3346 K (01-02)	MB GS EPS
 Actros (01-02)	GEARBOX MANAGEM	3348 K (01-02)	MB GS EPS
 Actros (01-02)	GEARBOX MANAGEM	4140 B (01-02)	MB GS EPS
 Actros (01-02)	GEARBOX MANAGEM	4140 K (01-02)	MB GS EPS
 Actros (01-02)	GEARBOX MANAGEM	4143 K (01-02)	MB GS EPS
 Actros (01-02)	GEARBOX MANAGEM	4146 K (01-02)	MB GS EPS
 Actros (01-02)	GEARBOX MANAGEM	4148 K (01-02)	MB GS EPS
 Actros (01-02)	MAINTENANCE SYST	1831 (01-02)	MB WS FSS
 Actros (01-02)	MAINTENANCE SYST	1831 K (01-02)	MB WS FSS
 Actros (01-02)	MAINTENANCE SYST	1831 L (01-02)	MB WS FSS
 Actros (01-02)	MAINTENANCE SYST	1831 L nR (01-02)	MB WS FSS
 Actros (01-02)	MAINTENANCE SYST	1835 L (01-02)	MB WS FSS
 Actros (01-02)	MAINTENANCE SYST	1835 L nR (01-02)	MB WS FSS
 Actros (01-02)	MAINTENANCE SYST	1840 (01-02)	MB WS FSS
 Actros (01-02)	MAINTENANCE SYST	1840 K (01-02)	MB WS FSS
 Actros (01-02)	MAINTENANCE SYST	1840 L (01-02)	MB WS FSS
 Actros (01-02)	MAINTENANCE SYST	1840 L nR (01-02)	MB WS FSS

## Systems supported by ECReader (up to V5.40)

### TRUCKS




























### Mercedes Trucks

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Actros (01-02)	MAINTENANCE SYST	1843 (01-02)	MB WS FSS
 Actros (01-02)	MAINTENANCE SYST	1843 K (01-02)	MB WS FSS
 Actros (01-02)	MAINTENANCE SYST	1843 L (01-02)	MB WS FSS
 Actros (01-02)	MAINTENANCE SYST	1843 L nR (01-02)	MB WS FSS
 Actros (01-02)	MAINTENANCE SYST	1846 (01-02)	MB WS FSS
 Actros (01-02)	MAINTENANCE SYST	1846 L (01-02)	MB WS FSS
 Actros (01-02)	MAINTENANCE SYST	1848 (01-02)	MB WS FSS
 Actros (01-02)	MAINTENANCE SYST	1848 L (01-02)	MB WS FSS
 Actros (01-02)	MAINTENANCE SYST	1853 L (01-02)	MB WS FSS
 Actros (01-02)	MAINTENANCE SYST	1857 L (01-02)	MB WS FSS
 Actros (01-02)	MAINTENANCE SYST	2031 AK (01-02)	MB WS FSS
 Actros (01-02)	MAINTENANCE SYST	2531 L (01-02)	MB WS FSS
 Actros (01-02)	MAINTENANCE SYST	2535 L (01-02)	MB WS FSS
 Actros (01-02)	MAINTENANCE SYST	2540 L (01-02)	MB WS FSS
 Actros (01-02)	MAINTENANCE SYST	2543 L (01-02)	MB WS FSS
 Actros (01-02)	MAINTENANCE SYST	2546 L (01-02)	MB WS FSS
 Actros (01-02)	MAINTENANCE SYST	2548 L (01-02)	MB WS FSS
 Actros (01-02)	MAINTENANCE SYST	2553 L (01-02)	MB WS FSS
 Actros (01-02)	MAINTENANCE SYST	2557 L (01-02)	MB WS FSS
 Actros (01-02)	MAINTENANCE SYST	3243 (01-02)	MB WS FSS
 Actros (01-02)	MAINTENANCE SYST	3335 B (01-02)	MB WS FSS
 Actros (01-02)	MAINTENANCE SYST	3335 K (01-02)	MB WS FSS
 Actros (01-02)	MAINTENANCE SYST	3340 AK (01-02)	MB WS FSS
 Actros (01-02)	MAINTENANCE SYST	3340 B (01-02)	MB WS FSS
 Actros (01-02)	MAINTENANCE SYST	3340 K (01-02)	MB WS FSS
 Actros (01-02)	MAINTENANCE SYST	3343 K (01-02)	MB WS FSS
 Actros (01-02)	MAINTENANCE SYST	3346 K (01-02)	MB WS FSS

## Systems supported by ECUreader (up to V5.40)

### TRUCKS




























### Mercedes Trucks

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Actros (01-02)	MAINTENANCE SYST	3348 K (01-02)	MB WS FSS
 Actros (01-02)	MAINTENANCE SYST	4140 B (01-02)	MB WS FSS
 Actros (01-02)	MAINTENANCE SYST	4140 K (01-02)	MB WS FSS
 Actros (01-02)	MAINTENANCE SYST	4143 K (01-02)	MB WS FSS
 Actros (01-02)	MAINTENANCE SYST	4146 K (01-02)	MB WS FSS
 Actros (01-02)	MAINTENANCE SYST	4148 K (01-02)	MB WS FSS
 Actros (01-02)	PRELIMINARY HEATI	1831 (01-02)	MB FLA Termostart.
 Actros (01-02)	PRELIMINARY HEATI	1831 K (01-02)	MB FLA Termostart.
 Actros (01-02)	PRELIMINARY HEATI	1831 L (01-02)	MB FLA Termostart.
 Actros (01-02)	PRELIMINARY HEATI	1831 L nR (01-02)	MB FLA Termostart.
 Actros (01-02)	PRELIMINARY HEATI	1835 L (01-02)	MB FLA Termostart.
 Actros (01-02)	PRELIMINARY HEATI	1835 L nR (01-02)	MB FLA Termostart.
 Actros (01-02)	PRELIMINARY HEATI	1840 (01-02)	MB FLA Termostart.
 Actros (01-02)	PRELIMINARY HEATI	1840 K (01-02)	MB FLA Termostart.
 Actros (01-02)	PRELIMINARY HEATI	1840 L (01-02)	MB FLA Termostart.
 Actros (01-02)	PRELIMINARY HEATI	1840 L nR (01-02)	MB FLA Termostart.
 Actros (01-02)	PRELIMINARY HEATI	1843 (01-02)	MB FLA Termostart.
 Actros (01-02)	PRELIMINARY HEATI	1843 K (01-02)	MB FLA Termostart.
 Actros (01-02)	PRELIMINARY HEATI	1843 L (01-02)	MB FLA Termostart.
 Actros (01-02)	PRELIMINARY HEATI	1843 L nR (01-02)	MB FLA Termostart.
 Actros (01-02)	PRELIMINARY HEATI	1846 (01-02)	MB FLA Termostart.
 Actros (01-02)	PRELIMINARY HEATI	1846 L (01-02)	MB FLA Termostart.
 Actros (01-02)	PRELIMINARY HEATI	1848 (01-02)	MB FLA Termostart.
 Actros (01-02)	PRELIMINARY HEATI	1848 L (01-02)	MB FLA Termostart.
 Actros (01-02)	PRELIMINARY HEATI	1853 L (01-02)	MB FLA Termostart.
 Actros (01-02)	PRELIMINARY HEATI	1857 L (01-02)	MB FLA Termostart.
 Actros (01-02)	PRELIMINARY HEATI	2031 AK (01-02)	MB FLA Termostart.

## Systems supported by ECReader (up to V5.40)

### TRUCKS


























### Mercedes Trucks

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Actros (01-02)	PRELIMINARY HEATI	2531 L (01-02)	MB FLA Termostart.
 Actros (01-02)	PRELIMINARY HEATI	2535 L (01-02)	MB FLA Termostart.
 Actros (01-02)	PRELIMINARY HEATI	2540 L (01-02)	MB FLA Termostart.
 Actros (01-02)	PRELIMINARY HEATI	2543 L (01-02)	MB FLA Termostart.
 Actros (01-02)	PRELIMINARY HEATI	2546 L (01-02)	MB FLA Termostart.
 Actros (01-02)	PRELIMINARY HEATI	2548 L (01-02)	MB FLA Termostart.
 Actros (01-02)	PRELIMINARY HEATI	2553 L (01-02)	MB FLA Termostart.
 Actros (01-02)	PRELIMINARY HEATI	2557 L (01-02)	MB FLA Termostart.
 Actros (01-02)	PRELIMINARY HEATI	3243 (01-02)	MB FLA Termostart.
 Actros (01-02)	PRELIMINARY HEATI	3335 B (01-02)	MB FLA Termostart.
 Actros (01-02)	PRELIMINARY HEATI	3335 K (01-02)	MB FLA Termostart.
 Actros (01-02)	PRELIMINARY HEATI	3340 AK (01-02)	MB FLA Termostart.
 Actros (01-02)	PRELIMINARY HEATI	3340 B (01-02)	MB FLA Termostart.
 Actros (01-02)	PRELIMINARY HEATI	3340 K (01-02)	MB FLA Termostart.
 Actros (01-02)	PRELIMINARY HEATI	3343 K (01-02)	MB FLA Termostart.
 Actros (01-02)	PRELIMINARY HEATI	3346 K (01-02)	MB FLA Termostart.
 Actros (01-02)	PRELIMINARY HEATI	3348 K (01-02)	MB FLA Termostart.
 Actros (01-02)	PRELIMINARY HEATI	4140 B (01-02)	MB FLA Termostart.
 Actros (01-02)	PRELIMINARY HEATI	4140 K (01-02)	MB FLA Termostart.
 Actros (01-02)	PRELIMINARY HEATI	4143 K (01-02)	MB FLA Termostart.
 Actros (01-02)	PRELIMINARY HEATI	4146 K (01-02)	MB FLA Termostart.
 Actros (01-02)	PRELIMINARY HEATI	4148 K (01-02)	MB FLA Termostart.
 Actros (01-02)	RATIO SEL. MANAGE	1831 (01-02)	MB AG AGE
 Actros (01-02)	RATIO SEL. MANAGE	1831 K (01-02)	MB AG AGE
 Actros (01-02)	RATIO SEL. MANAGE	1831 L (01-02)	MB AG AGE
 Actros (01-02)	RATIO SEL. MANAGE	1831 L nR (01-02)	MB AG AGE
 Actros (01-02)	RATIO SEL. MANAGE	1835 L (01-02)	MB AG AGE

## Systems supported by ECReader (up to V5.40)

### TRUCKS

### Mercedes Trucks

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Actros (01-02)	RATIO SEL. MANAGE	1835 L nR (01-02)	MB AG AGE
 Actros (01-02)	RATIO SEL. MANAGE	1840 (01-02)	MB AG AGE
 Actros (01-02)	RATIO SEL. MANAGE	1840 K (01-02)	MB AG AGE
 Actros (01-02)	RATIO SEL. MANAGE	1840 L (01-02)	MB AG AGE
 Actros (01-02)	RATIO SEL. MANAGE	1840 L nR (01-02)	MB AG AGE
 Actros (01-02)	RATIO SEL. MANAGE	1843 (01-02)	MB AG AGE
 Actros (01-02)	RATIO SEL. MANAGE	1843 K (01-02)	MB AG AGE
 Actros (01-02)	RATIO SEL. MANAGE	1843 L (01-02)	MB AG AGE
 Actros (01-02)	RATIO SEL. MANAGE	1843 L nR (01-02)	MB AG AGE
 Actros (01-02)	RATIO SEL. MANAGE	1846 (01-02)	MB AG AGE
 Actros (01-02)	RATIO SEL. MANAGE	1846 L (01-02)	MB AG AGE
 Actros (01-02)	RATIO SEL. MANAGE	1848 (01-02)	MB AG AGE
 Actros (01-02)	RATIO SEL. MANAGE	1848 L (01-02)	MB AG AGE
 Actros (01-02)	RATIO SEL. MANAGE	1853 L (01-02)	MB AG AGE
 Actros (01-02)	RATIO SEL. MANAGE	1857 L (01-02)	MB AG AGE
 Actros (01-02)	RATIO SEL. MANAGE	2031 AK (01-02)	MB AG AGE
 Actros (01-02)	RATIO SEL. MANAGE	2531 L (01-02)	MB AG AGE
 Actros (01-02)	RATIO SEL. MANAGE	2535 L (01-02)	MB AG AGE
 Actros (01-02)	RATIO SEL. MANAGE	2540 L (01-02)	MB AG AGE
 Actros (01-02)	RATIO SEL. MANAGE	2543 L (01-02)	MB AG AGE
 Actros (01-02)	RATIO SEL. MANAGE	2546 L (01-02)	MB AG AGE
 Actros (01-02)	RATIO SEL. MANAGE	2548 L (01-02)	MB AG AGE
 Actros (01-02)	RATIO SEL. MANAGE	2553 L (01-02)	MB AG AGE
 Actros (01-02)	RATIO SEL. MANAGE	2557 L (01-02)	MB AG AGE
 Actros (01-02)	RATIO SEL. MANAGE	3243 (01-02)	MB AG AGE
 Actros (01-02)	RATIO SEL. MANAGE	3335 B (01-02)	MB AG AGE
 Actros (01-02)	RATIO SEL. MANAGE	3335 K (01-02)	MB AG AGE

## Systems supported by ECReader (up to V5.40)

### TRUCKS




























### Mercedes Trucks

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Actros (01-02)	RATIO SEL. MANAGE	3340 AK (01-02)	MB AG AGE
 Actros (01-02)	RATIO SEL. MANAGE	3340 B (01-02)	MB AG AGE
 Actros (01-02)	RATIO SEL. MANAGE	3340 K (01-02)	MB AG AGE
 Actros (01-02)	RATIO SEL. MANAGE	3343 K (01-02)	MB AG AGE
 Actros (01-02)	RATIO SEL. MANAGE	3346 K (01-02)	MB AG AGE
 Actros (01-02)	RATIO SEL. MANAGE	3348 K (01-02)	MB AG AGE
 Actros (01-02)	RATIO SEL. MANAGE	4140 B (01-02)	MB AG AGE
 Actros (01-02)	RATIO SEL. MANAGE	4140 K (01-02)	MB AG AGE
 Actros (01-02)	RATIO SEL. MANAGE	4143 K (01-02)	MB AG AGE
 Actros (01-02)	RATIO SEL. MANAGE	4146 K (01-02)	MB AG AGE
 Actros (01-02)	RATIO SEL. MANAGE	4148 K (01-02)	MB AG AGE
 Actros (01-02)	SERVICE LIGHT RES	1831 (01-02)	MB WS FSS
 Actros (01-02)	SERVICE LIGHT RES	1831 K (01-02)	MB WS FSS
 Actros (01-02)	SERVICE LIGHT RES	1831 L (01-02)	MB WS FSS
 Actros (01-02)	SERVICE LIGHT RES	1831 L nR (01-02)	MB WS FSS
 Actros (01-02)	SERVICE LIGHT RES	1835 L (01-02)	MB WS FSS
 Actros (01-02)	SERVICE LIGHT RES	1835 L nR (01-02)	MB WS FSS
 Actros (01-02)	SERVICE LIGHT RES	1840 (01-02)	MB WS FSS
 Actros (01-02)	SERVICE LIGHT RES	1840 K (01-02)	MB WS FSS
 Actros (01-02)	SERVICE LIGHT RES	1840 L (01-02)	MB WS FSS
 Actros (01-02)	SERVICE LIGHT RES	1840 L nR (01-02)	MB WS FSS
 Actros (01-02)	SERVICE LIGHT RES	1843 (01-02)	MB WS FSS
 Actros (01-02)	SERVICE LIGHT RES	1843 K (01-02)	MB WS FSS
 Actros (01-02)	SERVICE LIGHT RES	1843 L (01-02)	MB WS FSS
 Actros (01-02)	SERVICE LIGHT RES	1843 L nR (01-02)	MB WS FSS
 Actros (01-02)	SERVICE LIGHT RES	1846 (01-02)	MB WS FSS
 Actros (01-02)	SERVICE LIGHT RES	1846 L (01-02)	MB WS FSS

## Systems supported by ECUreader (up to V5.40)

### TRUCKS




























### Mercedes Trucks

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Actros (01-02)	SERVICE LIGHT RES	1848 (01-02)	MB WS FSS
 Actros (01-02)	SERVICE LIGHT RES	1848 L (01-02)	MB WS FSS
 Actros (01-02)	SERVICE LIGHT RES	1853 L (01-02)	MB WS FSS
 Actros (01-02)	SERVICE LIGHT RES	1857 L (01-02)	MB WS FSS
 Actros (01-02)	SERVICE LIGHT RES	2031 AK (01-02)	MB WS FSS
 Actros (01-02)	SERVICE LIGHT RES	2531 L (01-02)	MB WS FSS
 Actros (01-02)	SERVICE LIGHT RES	2535 L (01-02)	MB WS FSS
 Actros (01-02)	SERVICE LIGHT RES	2540 L (01-02)	MB WS FSS
 Actros (01-02)	SERVICE LIGHT RES	2543 L (01-02)	MB WS FSS
 Actros (01-02)	SERVICE LIGHT RES	2546 L (01-02)	MB WS FSS
 Actros (01-02)	SERVICE LIGHT RES	2548 L (01-02)	MB WS FSS
 Actros (01-02)	SERVICE LIGHT RES	2553 L (01-02)	MB WS FSS
 Actros (01-02)	SERVICE LIGHT RES	2557 L (01-02)	MB WS FSS
 Actros (01-02)	SERVICE LIGHT RES	3243 (01-02)	MB WS FSS
 Actros (01-02)	SERVICE LIGHT RES	3335 B (01-02)	MB WS FSS
 Actros (01-02)	SERVICE LIGHT RES	3335 K (01-02)	MB WS FSS
 Actros (01-02)	SERVICE LIGHT RES	3340 AK (01-02)	MB WS FSS
 Actros (01-02)	SERVICE LIGHT RES	3340 B (01-02)	MB WS FSS
 Actros (01-02)	SERVICE LIGHT RES	3340 K (01-02)	MB WS FSS
 Actros (01-02)	SERVICE LIGHT RES	3343 K (01-02)	MB WS FSS
 Actros (01-02)	SERVICE LIGHT RES	3346 K (01-02)	MB WS FSS
 Actros (01-02)	SERVICE LIGHT RES	3348 K (01-02)	MB WS FSS
 Actros (01-02)	SERVICE LIGHT RES	4140 K (01-02)	MB WS FSS
 Actros (01-02)	SERVICE LIGHT RES	4143 K (01-02)	MB WS FSS
 Actros (01-02)	SERVICE LIGHT RES	4146 K (01-02)	MB WS FSS
 Actros (01-02)	SERVICE LIGHT RES	4148 K (01-02)	MB WS FSS
 Actros (01-02)	SUSPENSION CONTR	1831 (01-02)	Wabco NR ECAS

## Systems supported by ECReader (up to V5.40)

### TRUCKS



























### Mercedes Trucks

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Actros (01-02)	SUSPENSION CONTR	1831 K (01-02)	Wabco NR ECAS
 Actros (01-02)	SUSPENSION CONTR	1831 L (01-02)	Wabco NR ECAS
 Actros (01-02)	SUSPENSION CONTR	1831 L nR (01-02)	Wabco NR ECAS
 Actros (01-02)	SUSPENSION CONTR	1835 L (01-02)	Wabco NR ECAS
 Actros (01-02)	SUSPENSION CONTR	1835 L nR (01-02)	Wabco NR ECAS
 Actros (01-02)	SUSPENSION CONTR	1840 (01-02)	Wabco NR ECAS
 Actros (01-02)	SUSPENSION CONTR	1840 K (01-02)	Wabco NR ECAS
 Actros (01-02)	SUSPENSION CONTR	1840 L (01-02)	Wabco NR ECAS
 Actros (01-02)	SUSPENSION CONTR	1840 L nR (01-02)	Wabco NR ECAS
 Actros (01-02)	SUSPENSION CONTR	1843 (01-02)	Wabco NR ECAS
 Actros (01-02)	SUSPENSION CONTR	1843 K (01-02)	Wabco NR ECAS
 Actros (01-02)	SUSPENSION CONTR	1843 L (01-02)	Wabco NR ECAS
 Actros (01-02)	SUSPENSION CONTR	1843 L nR (01-02)	Wabco NR ECAS
 Actros (01-02)	SUSPENSION CONTR	1846 (01-02)	Wabco NR ECAS
 Actros (01-02)	SUSPENSION CONTR	1846 L (01-02)	Wabco NR ECAS
 Actros (01-02)	SUSPENSION CONTR	1848 (01-02)	Wabco NR ECAS
 Actros (01-02)	SUSPENSION CONTR	1848 L (01-02)	Wabco NR ECAS
 Actros (01-02)	SUSPENSION CONTR	1853 L (01-02)	Wabco NR ECAS
 Actros (01-02)	SUSPENSION CONTR	1857 L (01-02)	Wabco NR ECAS
 Actros (01-02)	SUSPENSION CONTR	2031 AK (01-02)	Wabco NR ECAS
 Actros (01-02)	SUSPENSION CONTR	2531 L (01-02)	Wabco NR ECAS
 Actros (01-02)	SUSPENSION CONTR	2535 L (01-02)	Wabco NR ECAS
 Actros (01-02)	SUSPENSION CONTR	2540 L (01-02)	Wabco NR ECAS
 Actros (01-02)	SUSPENSION CONTR	2543 L (01-02)	Wabco NR ECAS
 Actros (01-02)	SUSPENSION CONTR	2546 L (01-02)	Wabco NR ECAS
 Actros (01-02)	SUSPENSION CONTR	2548 L (01-02)	Wabco NR ECAS
 Actros (01-02)	SUSPENSION CONTR	2553 L (01-02)	Wabco NR ECAS

## Systems supported by ECReader (up to V5.40)

### TRUCKS
















### Mercedes Trucks

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Actros (01-02)	SUSPENSION CONTR	2557 L (01-02)	Wabco NR ECAS
 Actros (01-02)	SUSPENSION CONTR	3243 (01-02)	Wabco NR ECAS
 Actros (01-02)	SUSPENSION CONTR	3335 B (01-02)	Wabco NR ECAS
 Actros (01-02)	SUSPENSION CONTR	3335 K (01-02)	Wabco NR ECAS
 Actros (01-02)	SUSPENSION CONTR	3340 AK (01-02)	Wabco NR ECAS
 Actros (01-02)	SUSPENSION CONTR	3340 B (01-02)	Wabco NR ECAS
 Actros (01-02)	SUSPENSION CONTR	3340 K (01-02)	Wabco NR ECAS
 Actros (01-02)	SUSPENSION CONTR	3343 K (01-02)	Wabco NR ECAS
 Actros (01-02)	SUSPENSION CONTR	3346 K (01-02)	Wabco NR ECAS
 Actros (01-02)	SUSPENSION CONTR	3348 K (01-02)	Wabco NR ECAS
 Actros (01-02)	SUSPENSION CONTR	4140 B (01-02)	Wabco NR ECAS
 Actros (01-02)	SUSPENSION CONTR	4140 K (01-02)	Wabco NR ECAS
 Actros (01-02)	SUSPENSION CONTR	4143 K (01-02)	Wabco NR ECAS
 Actros (01-02)	SUSPENSION CONTR	4146 K (01-02)	Wabco NR ECAS
 Actros (01-02)	SUSPENSION CONTR	4148 K (01-02)	Wabco NR ECAS
 Actros MPlI (03-05)	AIRBAG	1832 (03-05)	MB SRS AirBag
 Actros MPlI (03-05)	AIRBAG	1832 K (03-05)	MB SRS AirBag
 Actros MPlI (03-05)	AIRBAG	1836 (03-05)	MB SRS AirBag
 Actros MPlI (03-05)	AIRBAG	1841 (03-05)	MB SRS AirBag
 Actros MPlI (03-05)	AIRBAG	1841 K (03-05)	MB SRS AirBag
 Actros MPlI (03-05)	AIRBAG	1844 (03-05)	MB SRS AirBag
 Actros MPlI (03-05)	AIRBAG	1844 K (03-05)	MB SRS AirBag
 Actros MPlI (03-05)	AIRBAG	1846 (03-05)	MB SRS AirBag
 Actros MPlI (03-05)	AIRBAG	1850 (03-05)	MB SRS AirBag
 Actros MPlI (03-05)	AIRBAG	1854 (03-05)	MB SRS AirBag
 Actros MPlI (03-05)	AIRBAG	1858 (03-05)	MB SRS AirBag

## Systems supported by ECReader (up to V5.40)

### TRUCKS




























### Mercedes Trucks

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Actros MPlI (03-05)	AIRBAG	2032 (03-05)	MB SRS AirBag
 Actros MPlI (03-05)	AIRBAG	2041 (03-05)	MB SRS AirBag
 Actros MPlI (03-05)	AIRBAG	2044 (03-05)	MB SRS AirBag
 Actros MPlI (03-05)	AIRBAG	2532 (03-05)	MB SRS AirBag
 Actros MPlI (03-05)	AIRBAG	2536 (03-05)	MB SRS AirBag
 Actros MPlI (03-05)	AIRBAG	2541 (03-05)	MB SRS AirBag
 Actros MPlI (03-05)	AIRBAG	2544 (03-05)	MB SRS AirBag
 Actros MPlI (03-05)	AIRBAG	2546 (03-05)	MB SRS AirBag
 Actros MPlI (03-05)	AIRBAG	2550 (03-05)	MB SRS AirBag
 Actros MPlI (03-05)	AIRBAG	2554 (03-05)	MB SRS AirBag
 Actros MPlI (03-05)	AIRBAG	2558 (03-05)	MB SRS AirBag
 Actros MPlI (03-05)	AIRBAG	4141 (03-05)	MB SRS AirBag
 Actros MPlI (03-05)	AIRBAG	4144 (03-05)	MB SRS AirBag
 Actros MPlI (03-05)	AIRBAG	4146 (03-05)	MB SRS AirBag
 Actros MPlI (03-05)	AIRBAG	4150 (03-05)	MB SRS AirBag
 Actros MPlI (03-05)	AUTOM. TRANSMISSI	1832 (03-05)	MB GS EPS
 Actros MPlI (03-05)	AUTOM. TRANSMISSI	1832 K (03-05)	MB GS EPS
 Actros MPlI (03-05)	AUTOM. TRANSMISSI	1836 (03-05)	MB GS EPS
 Actros MPlI (03-05)	AUTOM. TRANSMISSI	1841 (03-05)	MB GS EPS
 Actros MPlI (03-05)	AUTOM. TRANSMISSI	1841 K (03-05)	MB GS EPS
 Actros MPlI (03-05)	AUTOM. TRANSMISSI	1844 (03-05)	MB GS EPS
 Actros MPlI (03-05)	AUTOM. TRANSMISSI	1844 K (03-05)	MB GS EPS
 Actros MPlI (03-05)	AUTOM. TRANSMISSI	1846 (03-05)	MB GS EPS
 Actros MPlI (03-05)	AUTOM. TRANSMISSI	1850 (03-05)	MB GS EPS
 Actros MPlI (03-05)	AUTOM. TRANSMISSI	1854 (03-05)	MB GS EPS
 Actros MPlI (03-05)	AUTOM. TRANSMISSI	1858 (03-05)	MB GS EPS
 Actros MPlI (03-05)	AUTOM. TRANSMISSI	2032 (03-05)	MB GS EPS

## Systems supported by ECUreader (up to V5.40)

### TRUCKS



### Mercedes Trucks

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Actros MPII (03-05)	AUTOM. TRANSMISSI	2041 (03-05)	MB GS EPS
 Actros MPII (03-05)	AUTOM. TRANSMISSI	2044 (03-05)	MB GS EPS
 Actros MPII (03-05)	AUTOM. TRANSMISSI	2532 (03-05)	MB GS EPS
 Actros MPII (03-05)	AUTOM. TRANSMISSI	2536 (03-05)	MB GS EPS
 Actros MPII (03-05)	AUTOM. TRANSMISSI	2541 (03-05)	MB GS EPS
 Actros MPII (03-05)	AUTOM. TRANSMISSI	2544 (03-05)	MB GS EPS
 Actros MPII (03-05)	AUTOM. TRANSMISSI	2546 (03-05)	MB GS EPS
 Actros MPII (03-05)	AUTOM. TRANSMISSI	2550 (03-05)	MB GS EPS
 Actros MPII (03-05)	AUTOM. TRANSMISSI	2554 (03-05)	MB GS EPS
 Actros MPII (03-05)	AUTOM. TRANSMISSI	2558 (03-05)	MB GS EPS
 Actros MPII (03-05)	AUTOM. TRANSMISSI	4141 (03-05)	MB GS EPS
 Actros MPII (03-05)	AUTOM. TRANSMISSI	4144 (03-05)	MB GS EPS
 Actros MPII (03-05)	AUTOM. TRANSMISSI	4146 (03-05)	MB GS EPS
 Actros MPII (03-05)	AUTOM. TRANSMISSI	4150 (03-05)	MB GS EPS
 Actros MPII (03-05)	BRAKE POWER SUP	1832 (03-05)	MB RS RETARDER
 Actros MPII (03-05)	BRAKE POWER SUP	1832 K (03-05)	MB RS RETARDER
 Actros MPII (03-05)	BRAKE POWER SUP	1836 (03-05)	MB RS RETARDER
 Actros MPII (03-05)	BRAKE POWER SUP	1841 (03-05)	MB RS RETARDER
 Actros MPII (03-05)	BRAKE POWER SUP	1841 K (03-05)	MB RS RETARDER
 Actros MPII (03-05)	BRAKE POWER SUP	1844 (03-05)	MB RS RETARDER
 Actros MPII (03-05)	BRAKE POWER SUP	1844 K (03-05)	MB RS RETARDER
 Actros MPII (03-05)	BRAKE POWER SUP	1846 (03-05)	MB RS RETARDER
 Actros MPII (03-05)	BRAKE POWER SUP	1850 (03-05)	MB RS RETARDER
 Actros MPII (03-05)	BRAKE POWER SUP	1854 (03-05)	MB RS RETARDER
 Actros MPII (03-05)	BRAKE POWER SUP	1858 (03-05)	MB RS RETARDER
 Actros MPII (03-05)	BRAKE POWER SUP	2032 (03-05)	MB RS RETARDER
 Actros MPII (03-05)	BRAKE POWER SUP	2041 (03-05)	MB RS RETARDER

## Systems supported by ECUREADER (up to V5.40)

### TRUCKS




























### Mercedes Trucks

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Actros MPlI (03-05)	BRAKE POWER SUP	2044 (03-05)	MB RS RETARDER
 Actros MPlI (03-05)	BRAKE POWER SUP	2532 (03-05)	MB RS RETARDER
 Actros MPlI (03-05)	BRAKE POWER SUP	2536 (03-05)	MB RS RETARDER
 Actros MPlI (03-05)	BRAKE POWER SUP	2541 (03-05)	MB RS RETARDER
 Actros MPlI (03-05)	BRAKE POWER SUP	2544 (03-05)	MB RS RETARDER
 Actros MPlI (03-05)	BRAKE POWER SUP	2546 (03-05)	MB RS RETARDER
 Actros MPlI (03-05)	BRAKE POWER SUP	2550 (03-05)	MB RS RETARDER
 Actros MPlI (03-05)	BRAKE POWER SUP	2554 (03-05)	MB RS RETARDER
 Actros MPlI (03-05)	BRAKE POWER SUP	2558 (03-05)	MB RS RETARDER
 Actros MPlI (03-05)	BRAKE POWER SUP	4141 (03-05)	MB RS RETARDER
 Actros MPlI (03-05)	BRAKE POWER SUP	4144 (03-05)	MB RS RETARDER
 Actros MPlI (03-05)	BRAKE POWER SUP	4146 (03-05)	MB RS RETARDER
 Actros MPlI (03-05)	BRAKE POWER SUP	4150 (03-05)	MB RS RETARDER
 Actros MPlI (03-05)	BRAKE SYS. MANAG	1832 (03-05)	MB BS EPB
 Actros MPlI (03-05)	BRAKE SYS. MANAG	1832 K (03-05)	MB BS EPB
 Actros MPlI (03-05)	BRAKE SYS. MANAG	1836 (03-05)	MB BS EPB
 Actros MPlI (03-05)	BRAKE SYS. MANAG	1841 (03-05)	MB BS EPB
 Actros MPlI (03-05)	BRAKE SYS. MANAG	1841 K (03-05)	MB BS EPB
 Actros MPlI (03-05)	BRAKE SYS. MANAG	1844 (03-05)	MB BS EPB
 Actros MPlI (03-05)	BRAKE SYS. MANAG	1844 K (03-05)	MB BS EPB
 Actros MPlI (03-05)	BRAKE SYS. MANAG	1846 (03-05)	MB BS EPB
 Actros MPlI (03-05)	BRAKE SYS. MANAG	1850 (03-05)	MB BS EPB
 Actros MPlI (03-05)	BRAKE SYS. MANAG	1854 (03-05)	MB BS EPB
 Actros MPlI (03-05)	BRAKE SYS. MANAG	1858 (03-05)	MB BS EPB
 Actros MPlI (03-05)	BRAKE SYS. MANAG	2032 (03-05)	MB BS EPB
 Actros MPlI (03-05)	BRAKE SYS. MANAG	2041 (03-05)	MB BS EPB
 Actros MPlI (03-05)	BRAKE SYS. MANAG	2044 (03-05)	MB BS EPB

## Systems supported by ECReader (up to V5.40)

### TRUCKS




























### Mercedes Trucks

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Actros MPlI (03-05)	BRAKE SYS. MANAG	2532 (03-05)	MB BS EPB
 Actros MPlI (03-05)	BRAKE SYS. MANAG	2536 (03-05)	MB BS EPB
 Actros MPlI (03-05)	BRAKE SYS. MANAG	2541 (03-05)	MB BS EPB
 Actros MPlI (03-05)	BRAKE SYS. MANAG	2544 (03-05)	MB BS EPB
 Actros MPlI (03-05)	BRAKE SYS. MANAG	2546 (03-05)	MB BS EPB
 Actros MPlI (03-05)	BRAKE SYS. MANAG	2550 (03-05)	MB BS EPB
 Actros MPlI (03-05)	BRAKE SYS. MANAG	2554 (03-05)	MB BS EPB
 Actros MPlI (03-05)	BRAKE SYS. MANAG	2558 (03-05)	MB BS EPB
 Actros MPlI (03-05)	BRAKE SYS. MANAG	4141 (03-05)	MB BS EPB
 Actros MPlI (03-05)	BRAKE SYS. MANAG	4144 (03-05)	MB BS EPB
 Actros MPlI (03-05)	BRAKE SYS. MANAG	4146 (03-05)	MB BS EPB
 Actros MPlI (03-05)	BRAKE SYS. MANAG	4150 (03-05)	MB BS EPB
 Actros MPlI (03-05)	CHASSIS NETWORK	1832 (03-05)	MB Base Module
 Actros MPlI (03-05)	CHASSIS NETWORK	1832 (03-05)	MB Front Module
 Actros MPlI (03-05)	CHASSIS NETWORK	1832 (03-05)	MB Rear Module
 Actros MPlI (03-05)	CHASSIS NETWORK	1832 K (03-05)	MB Base Module
 Actros MPlI (03-05)	CHASSIS NETWORK	1832 K (03-05)	MB Front Module
 Actros MPlI (03-05)	CHASSIS NETWORK	1832 K (03-05)	MB Rear Module
 Actros MPlI (03-05)	CHASSIS NETWORK	1836 (03-05)	MB Base Module
 Actros MPlI (03-05)	CHASSIS NETWORK	1836 (03-05)	MB Front Module
 Actros MPlI (03-05)	CHASSIS NETWORK	1836 (03-05)	MB Rear Module
 Actros MPlI (03-05)	CHASSIS NETWORK	1841 (03-05)	MB Base Module
 Actros MPlI (03-05)	CHASSIS NETWORK	1841 (03-05)	MB Front Module
 Actros MPlI (03-05)	CHASSIS NETWORK	1841 (03-05)	MB Rear Module
 Actros MPlI (03-05)	CHASSIS NETWORK	1841 K (03-05)	MB Base Module
 Actros MPlI (03-05)	CHASSIS NETWORK	1841 K (03-05)	MB Front Module
 Actros MPlI (03-05)	CHASSIS NETWORK	1841 K (03-05)	MB Rear Module

## Systems supported by ECReader (up to V5.40)

### TRUCKS




























### Mercedes Trucks

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Actros MPII (03-05)	CHASSIS NETWORK	1844 (03-05)	MB Base Module
 Actros MPII (03-05)	CHASSIS NETWORK	1844 (03-05)	MB Front Module
 Actros MPII (03-05)	CHASSIS NETWORK	1844 (03-05)	MB Rear Module
 Actros MPII (03-05)	CHASSIS NETWORK	1844 K (03-05)	MB Base Module
 Actros MPII (03-05)	CHASSIS NETWORK	1844 K (03-05)	MB Front Module
 Actros MPII (03-05)	CHASSIS NETWORK	1844 K (03-05)	MB Rear Module
 Actros MPII (03-05)	CHASSIS NETWORK	1846 (03-05)	MB Base Module
 Actros MPII (03-05)	CHASSIS NETWORK	1846 (03-05)	MB Front Module
 Actros MPII (03-05)	CHASSIS NETWORK	1846 (03-05)	MB Rear Module
 Actros MPII (03-05)	CHASSIS NETWORK	1850 (03-05)	MB Base Module
 Actros MPII (03-05)	CHASSIS NETWORK	1850 (03-05)	MB Front Module
 Actros MPII (03-05)	CHASSIS NETWORK	1850 (03-05)	MB Rear Module
 Actros MPII (03-05)	CHASSIS NETWORK	1854 (03-05)	MB Base Module
 Actros MPII (03-05)	CHASSIS NETWORK	1854 (03-05)	MB Front Module
 Actros MPII (03-05)	CHASSIS NETWORK	1854 (03-05)	MB Rear Module
 Actros MPII (03-05)	CHASSIS NETWORK	1858 (03-05)	MB Base Module
 Actros MPII (03-05)	CHASSIS NETWORK	1858 (03-05)	MB Front Module
 Actros MPII (03-05)	CHASSIS NETWORK	1858 (03-05)	MB Rear Module
 Actros MPII (03-05)	CHASSIS NETWORK	2032 (03-05)	MB Base Module
 Actros MPII (03-05)	CHASSIS NETWORK	2032 (03-05)	MB Front Module
 Actros MPII (03-05)	CHASSIS NETWORK	2032 (03-05)	MB Rear Module
 Actros MPII (03-05)	CHASSIS NETWORK	2041 (03-05)	MB Base Module
 Actros MPII (03-05)	CHASSIS NETWORK	2041 (03-05)	MB Front Module
 Actros MPII (03-05)	CHASSIS NETWORK	2041 (03-05)	MB Rear Module
 Actros MPII (03-05)	CHASSIS NETWORK	2044 (03-05)	MB Base Module
 Actros MPII (03-05)	CHASSIS NETWORK	2044 (03-05)	MB Front Module
 Actros MPII (03-05)	CHASSIS NETWORK	2044 (03-05)	MB Rear Module

## Systems supported by ECReader (up to V5.40)

### TRUCKS






### Mercedes Trucks

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Actros MPII (03-05)	CHASSIS NETWORK	2532 (03-05)	MB Base Module
 Actros MPII (03-05)	CHASSIS NETWORK	2532 (03-05)	MB Rear Module
 Actros MPII (03-05)	CHASSIS NETWORK	2536 (03-05)	MB Base Module
 Actros MPII (03-05)	CHASSIS NETWORK	2536 (03-05)	MB Rear Module
 Actros MPII (03-05)	CHASSIS NETWORK	2541 (03-05)	MB Base Module
 Actros MPII (03-05)	CHASSIS NETWORK	2541 (03-05)	MB Front Module
 Actros MPII (03-05)	CHASSIS NETWORK	2541 (03-05)	MB Rear Module
 Actros MPII (03-05)	CHASSIS NETWORK	2544 (03-05)	MB Base Module
 Actros MPII (03-05)	CHASSIS NETWORK	2544 (03-05)	MB Front Module
 Actros MPII (03-05)	CHASSIS NETWORK	2544 (03-05)	MB Rear Module
 Actros MPII (03-05)	CHASSIS NETWORK	2546 (03-05)	MB Base Module
 Actros MPII (03-05)	CHASSIS NETWORK	2546 (03-05)	MB Front Module
 Actros MPII (03-05)	CHASSIS NETWORK	2546 (03-05)	MB Rear Module
 Actros MPII (03-05)	CHASSIS NETWORK	2550 (03-05)	MB Base Module
 Actros MPII (03-05)	CHASSIS NETWORK	2550 (03-05)	MB Front Module
 Actros MPII (03-05)	CHASSIS NETWORK	2550 (03-05)	MB Rear Module
 Actros MPII (03-05)	CHASSIS NETWORK	2554 (03-05)	MB Base Module
 Actros MPII (03-05)	CHASSIS NETWORK	2554 (03-05)	MB Rear Module
 Actros MPII (03-05)	CHASSIS NETWORK	2558 (03-05)	MB Base Module
 Actros MPII (03-05)	CHASSIS NETWORK	2558 (03-05)	MB Front Module
 Actros MPII (03-05)	CHASSIS NETWORK	2558 (03-05)	MB Rear Module
 Actros MPII (03-05)	CHASSIS NETWORK	4141 (03-05)	MB Base Module
 Actros MPII (03-05)	CHASSIS NETWORK	4141 (03-05)	MB Front Module
 Actros MPII (03-05)	CHASSIS NETWORK	4141 (03-05)	MB Rear Module
 Actros MPII (03-05)	CHASSIS NETWORK	4144 (03-05)	MB Base Module
 Actros MPII (03-05)	CHASSIS NETWORK	4144 (03-05)	MB Front Module
 Actros MPII (03-05)	CHASSIS NETWORK	4144 (03-05)	MB Rear Module

## Systems supported by ECReader (up to V5.40)

### TRUCKS




























### Mercedes Trucks

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Actros MPlI (03-05)	CHASSIS NETWORK	4146 (03-05)	MB Base Module
 Actros MPlI (03-05)	CHASSIS NETWORK	4146 (03-05)	MB Front Module
 Actros MPlI (03-05)	CHASSIS NETWORK	4146 (03-05)	MB Rear Module
 Actros MPlI (03-05)	CHASSIS NETWORK	4150 (03-05)	MB Base Module
 Actros MPlI (03-05)	CHASSIS NETWORK	4150 (03-05)	MB Front Module
 Actros MPlI (03-05)	CHASSIS NETWORK	4150 (03-05)	MB Rear Module
 Actros MPlI (03-05)	CHRONOTACHOGRA	1832 (03-05)	MB TACHOGRAPH
 Actros MPlI (03-05)	CHRONOTACHOGRA	1832 K (03-05)	MB TACHOGRAPH
 Actros MPlI (03-05)	CHRONOTACHOGRA	1836 (03-05)	MB TACHOGRAPH
 Actros MPlI (03-05)	CHRONOTACHOGRA	1841 (03-05)	MB TACHOGRAPH
 Actros MPlI (03-05)	CHRONOTACHOGRA	1841 K (03-05)	MB TACHOGRAPH
 Actros MPlI (03-05)	CHRONOTACHOGRA	1844 (03-05)	MB TACHOGRAPH
 Actros MPlI (03-05)	CHRONOTACHOGRA	1844 K (03-05)	MB TACHOGRAPH
 Actros MPlI (03-05)	CHRONOTACHOGRA	1846 (03-05)	MB TACHOGRAPH
 Actros MPlI (03-05)	CHRONOTACHOGRA	1850 (03-05)	MB TACHOGRAPH
 Actros MPlI (03-05)	CHRONOTACHOGRA	1854 (03-05)	MB TACHOGRAPH
 Actros MPlI (03-05)	CHRONOTACHOGRA	1858 (03-05)	MB TACHOGRAPH
 Actros MPlI (03-05)	CHRONOTACHOGRA	2032 (03-05)	MB TACHOGRAPH
 Actros MPlI (03-05)	CHRONOTACHOGRA	2041 (03-05)	MB TACHOGRAPH
 Actros MPlI (03-05)	CHRONOTACHOGRA	2044 (03-05)	MB TACHOGRAPH
 Actros MPlI (03-05)	CHRONOTACHOGRA	2532 (03-05)	MB TACHOGRAPH
 Actros MPlI (03-05)	CHRONOTACHOGRA	2536 (03-05)	MB TACHOGRAPH
 Actros MPlI (03-05)	CHRONOTACHOGRA	2541 (03-05)	MB TACHOGRAPH
 Actros MPlI (03-05)	CHRONOTACHOGRA	2544 (03-05)	MB TACHOGRAPH
 Actros MPlI (03-05)	CHRONOTACHOGRA	2546 (03-05)	MB TACHOGRAPH
 Actros MPlI (03-05)	CHRONOTACHOGRA	2550 (03-05)	MB TACHOGRAPH
 Actros MPlI (03-05)	CHRONOTACHOGRA	2554 (03-05)	MB TACHOGRAPH

## Systems supported by ECUREADER (up to V5.40)

### TRUCKS




























### Mercedes Trucks

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Actros MPlI (03-05)	CHRONOTACHOGRA	2558 (03-05)	MB TACHOGRAPH
 Actros MPlI (03-05)	CHRONOTACHOGRA	4141 (03-05)	MB TACHOGRAPH
 Actros MPlI (03-05)	CHRONOTACHOGRA	4144 (03-05)	MB TACHOGRAPH
 Actros MPlI (03-05)	CHRONOTACHOGRA	4146 (03-05)	MB TACHOGRAPH
 Actros MPlI (03-05)	CHRONOTACHOGRA	4150 (03-05)	MB TACHOGRAPH
 Actros MPlI (03-05)	CRUISE MANAGEME	1832 (03-05)	FR FMR
 Actros MPlI (03-05)	CRUISE MANAGEME	1832 K (03-05)	FR FMR
 Actros MPlI (03-05)	CRUISE MANAGEME	1836 (03-05)	FR FMR
 Actros MPlI (03-05)	CRUISE MANAGEME	1841 (03-05)	FR FMR
 Actros MPlI (03-05)	CRUISE MANAGEME	1841 K (03-05)	FR FMR
 Actros MPlI (03-05)	CRUISE MANAGEME	1844 (03-05)	FR FMR
 Actros MPlI (03-05)	CRUISE MANAGEME	1844 K (03-05)	FR FMR
 Actros MPlI (03-05)	CRUISE MANAGEME	1846 (03-05)	FR FMR
 Actros MPlI (03-05)	CRUISE MANAGEME	1850 (03-05)	FR FMR
 Actros MPlI (03-05)	CRUISE MANAGEME	1854 (03-05)	FR FMR
 Actros MPlI (03-05)	CRUISE MANAGEME	1858 (03-05)	FR FMR
 Actros MPlI (03-05)	CRUISE MANAGEME	2032 (03-05)	FR FMR
 Actros MPlI (03-05)	CRUISE MANAGEME	2041 (03-05)	FR FMR
 Actros MPlI (03-05)	CRUISE MANAGEME	2044 (03-05)	FR FMR
 Actros MPlI (03-05)	CRUISE MANAGEME	2532 (03-05)	FR FMR
 Actros MPlI (03-05)	CRUISE MANAGEME	2536 (03-05)	FR FMR
 Actros MPlI (03-05)	CRUISE MANAGEME	2541 (03-05)	FR FMR
 Actros MPlI (03-05)	CRUISE MANAGEME	2544 (03-05)	FR FMR
 Actros MPlI (03-05)	CRUISE MANAGEME	2546 (03-05)	FR FMR
 Actros MPlI (03-05)	CRUISE MANAGEME	2550 (03-05)	FR FMR
 Actros MPlI (03-05)	CRUISE MANAGEME	2554 (03-05)	FR FMR
 Actros MPlI (03-05)	CRUISE MANAGEME	2558 (03-05)	FR FMR

## Systems supported by ECUREADER (up to V5.40)

### TRUCKS




























### Mercedes Trucks

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Actros MPlI (03-05)	CRUISE MANAGEME	4141 (03-05)	FR FMR
 Actros MPlI (03-05)	CRUISE MANAGEME	4144 (03-05)	FR FMR
 Actros MPlI (03-05)	CRUISE MANAGEME	4146 (03-05)	FR FMR
 Actros MPlI (03-05)	CRUISE MANAGEME	4150 (03-05)	FR FMR
 Actros MPlI (03-05)	DASHBOARD	1832 (03-05)	MB INS
 Actros MPlI (03-05)	DASHBOARD	1832 K (03-05)	MB INS
 Actros MPlI (03-05)	DASHBOARD	1836 (03-05)	MB INS
 Actros MPlI (03-05)	DASHBOARD	1841 (03-05)	MB INS
 Actros MPlI (03-05)	DASHBOARD	1841 K (03-05)	MB INS
 Actros MPlI (03-05)	DASHBOARD	1844 (03-05)	MB INS
 Actros MPlI (03-05)	DASHBOARD	1844 K (03-05)	MB INS
 Actros MPlI (03-05)	DASHBOARD	1846 (03-05)	MB INS
 Actros MPlI (03-05)	DASHBOARD	1850 (03-05)	MB INS
 Actros MPlI (03-05)	DASHBOARD	1854 (03-05)	MB INS
 Actros MPlI (03-05)	DASHBOARD	1858 (03-05)	MB INS
 Actros MPlI (03-05)	DASHBOARD	2032 (03-05)	MB INS
 Actros MPlI (03-05)	DASHBOARD	2041 (03-05)	MB INS
 Actros MPlI (03-05)	DASHBOARD	2044 (03-05)	MB INS
 Actros MPlI (03-05)	DASHBOARD	2532 (03-05)	MB INS
 Actros MPlI (03-05)	DASHBOARD	2536 (03-05)	MB INS
 Actros MPlI (03-05)	DASHBOARD	2541 (03-05)	MB INS
 Actros MPlI (03-05)	DASHBOARD	2544 (03-05)	MB INS
 Actros MPlI (03-05)	DASHBOARD	2546 (03-05)	MB INS
 Actros MPlI (03-05)	DASHBOARD	2550 (03-05)	MB INS
 Actros MPlI (03-05)	DASHBOARD	2554 (03-05)	MB INS
 Actros MPlI (03-05)	DASHBOARD	2558 (03-05)	MB INS
 Actros MPlI (03-05)	DASHBOARD	4141 (03-05)	MB INS

## Systems supported by ECReader (up to V5.40)

### TRUCKS




























### Mercedes Trucks

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Actros MPII (03-05)	DASHBOARD	4144 (03-05)	MB INS
 Actros MPII (03-05)	DASHBOARD	4146 (03-05)	MB INS
 Actros MPII (03-05)	DASHBOARD	4150 (03-05)	MB INS
 Actros MPII (03-05)	ENGINE MANAGEME	1832 (03-05)	MB MR PLD (EDC)
 Actros MPII (03-05)	ENGINE MANAGEME	1832 K (03-05)	MB MR PLD (EDC)
 Actros MPII (03-05)	ENGINE MANAGEME	1836 (03-05)	MB MR PLD (EDC)
 Actros MPII (03-05)	ENGINE MANAGEME	1841 (03-05)	MB MR PLD (EDC)
 Actros MPII (03-05)	ENGINE MANAGEME	1841 K (03-05)	MB MR PLD (EDC)
 Actros MPII (03-05)	ENGINE MANAGEME	1844 (03-05)	MB MR PLD (EDC)
 Actros MPII (03-05)	ENGINE MANAGEME	1844 K (03-05)	MB MR PLD (EDC)
 Actros MPII (03-05)	ENGINE MANAGEME	1846 (03-05)	MB MR PLD (EDC)
 Actros MPII (03-05)	ENGINE MANAGEME	1850 (03-05)	MB MR PLD (EDC)
 Actros MPII (03-05)	ENGINE MANAGEME	1854 (03-05)	MB MR PLD (EDC)
 Actros MPII (03-05)	ENGINE MANAGEME	1858 (03-05)	MB MR PLD (EDC)
 Actros MPII (03-05)	ENGINE MANAGEME	2032 (03-05)	MB MR PLD (EDC)
 Actros MPII (03-05)	ENGINE MANAGEME	2041 (03-05)	MB MR PLD (EDC)
 Actros MPII (03-05)	ENGINE MANAGEME	2044 (03-05)	MB MR PLD (EDC)
 Actros MPII (03-05)	ENGINE MANAGEME	2532 (03-05)	MB MR PLD (EDC)
 Actros MPII (03-05)	ENGINE MANAGEME	2536 (03-05)	MB MR PLD (EDC)
 Actros MPII (03-05)	ENGINE MANAGEME	2541 (03-05)	MB MR PLD (EDC)
 Actros MPII (03-05)	ENGINE MANAGEME	2544 (03-05)	MB MR PLD (EDC)
 Actros MPII (03-05)	ENGINE MANAGEME	2546 (03-05)	MB MR PLD (EDC)
 Actros MPII (03-05)	ENGINE MANAGEME	2550 (03-05)	MB MR PLD (EDC)
 Actros MPII (03-05)	ENGINE MANAGEME	2554 (03-05)	MB MR PLD (EDC)
 Actros MPII (03-05)	ENGINE MANAGEME	2558 (03-05)	MB MR PLD (EDC)
 Actros MPII (03-05)	ENGINE MANAGEME	4141 (03-05)	MB MR PLD (EDC)
 Actros MPII (03-05)	ENGINE MANAGEME	4144 (03-05)	MB MR PLD (EDC)

## Systems supported by ECReader (up to V5.40)

### TRUCKS



























### Mercedes Trucks

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Actros MPlI (03-05)	ENGINE MANAGEME	4146 (03-05)	MB MR PLD (EDC)
 Actros MPlI (03-05)	ENGINE MANAGEME	4150 (03-05)	MB MR PLD (EDC)
 Actros MPlI (03-05)	MAINTENANCE SYST	1832 (03-05)	MB WS
 Actros MPlI (03-05)	MAINTENANCE SYST	1832 K (03-05)	MB WS
 Actros MPlI (03-05)	MAINTENANCE SYST	1836 (03-05)	MB WS
 Actros MPlI (03-05)	MAINTENANCE SYST	1841 (03-05)	MB WS
 Actros MPlI (03-05)	MAINTENANCE SYST	1841 K (03-05)	MB WS
 Actros MPlI (03-05)	MAINTENANCE SYST	1844 (03-05)	MB WS
 Actros MPlI (03-05)	MAINTENANCE SYST	1844 K (03-05)	MB WS
 Actros MPlI (03-05)	MAINTENANCE SYST	1846 (03-05)	MB WS
 Actros MPlI (03-05)	MAINTENANCE SYST	1850 (03-05)	MB WS
 Actros MPlI (03-05)	MAINTENANCE SYST	1854 (03-05)	MB WS
 Actros MPlI (03-05)	MAINTENANCE SYST	1858 (03-05)	MB WS
 Actros MPlI (03-05)	MAINTENANCE SYST	2032 (03-05)	MB WS
 Actros MPlI (03-05)	MAINTENANCE SYST	2041 (03-05)	MB WS
 Actros MPlI (03-05)	MAINTENANCE SYST	2044 (03-05)	MB WS
 Actros MPlI (03-05)	MAINTENANCE SYST	2532 (03-05)	MB WS
 Actros MPlI (03-05)	MAINTENANCE SYST	2536 (03-05)	MB WS
 Actros MPlI (03-05)	MAINTENANCE SYST	2541 (03-05)	MB WS
 Actros MPlI (03-05)	MAINTENANCE SYST	2544 (03-05)	MB WS
 Actros MPlI (03-05)	MAINTENANCE SYST	2546 (03-05)	MB WS
 Actros MPlI (03-05)	MAINTENANCE SYST	2550 (03-05)	MB WS
 Actros MPlI (03-05)	MAINTENANCE SYST	2554 (03-05)	MB WS
 Actros MPlI (03-05)	MAINTENANCE SYST	2558 (03-05)	MB WS
 Actros MPlI (03-05)	MAINTENANCE SYST	4141 (03-05)	MB WS
 Actros MPlI (03-05)	MAINTENANCE SYST	4144 (03-05)	MB WS
 Actros MPlI (03-05)	MAINTENANCE SYST	4146 (03-05)	MB WS

## Systems supported by ECReader (up to V5.40)

### TRUCKS
















### Mercedes Trucks

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Actros MPlI (03-05)	MAINTENANCE SYST	4150 (03-05)	MB WS
 Actros MPlI (05-08)	AUTOM. TRANSMISSI	1832 BlueTec 4/5 (05-08)	GS II
 Actros MPlI (05-08)	AUTOM. TRANSMISSI	1836 BlueTec 4/5 (05-08)	GS II
 Actros MPlI (05-08)	AUTOM. TRANSMISSI	1841 BlueTec 4/5 (05-08)	GS II
 Actros MPlI (05-08)	AUTOM. TRANSMISSI	1844 BlueTec 4/5 (05-08)	GS II
 Actros MPlI (05-08)	AUTOM. TRANSMISSI	1846 BlueTec 4/5 (05-08)	GS II
 Actros MPlI (05-08)	AUTOM. TRANSMISSI	1848 BlueTec 4/5 (05-08)	GS II
 Actros MPlI (05-08)	AUTOM. TRANSMISSI	1851 BlueTec 4/5 (05-08)	GS II
 Actros MPlI (05-08)	AUTOM. TRANSMISSI	1855 BlueTec 4/5 (05-08)	GS II
 Actros MPlI (05-08)	AUTOM. TRANSMISSI	1860 BlueTec 4/5 (05-08)	GS II
 Actros MPlI (05-08)	AUTOM. TRANSMISSI	2532 BlueTec 4/5 (05-08)	GS II
 Actros MPlI (05-08)	AUTOM. TRANSMISSI	2536 BlueTec 4/5 (05-08)	GS II
 Actros MPlI (05-08)	AUTOM. TRANSMISSI	2541 BlueTec 4/5 (05-08)	GS II
 Actros MPlI (05-08)	AUTOM. TRANSMISSI	2544 BlueTec 4/5 (05-08)	GS II
 Actros MPlI (05-08)	AUTOM. TRANSMISSI	2546 BlueTec 4/5 (05-08)	GS II
 Actros MPlI (05-08)	AUTOM. TRANSMISSI	2548 BlueTec 4/5 (05-08)	GS II
 Actros MPlI (05-08)	AUTOM. TRANSMISSI	2551 BlueTec 4/5 (05-08)	GS II
 Actros MPlI (05-08)	AUTOM. TRANSMISSI	2555 BlueTec 4/5 (05-08)	GS II
 Actros MPlI (05-08)	AUTOM. TRANSMISSI	2560 BlueTec 4/5 (05-08)	GS II
 Actros MPlI (05-08)	BRAKE SYS. MANAG	1832 BlueTec 4/5 (05-08)	BS
 Actros MPlI (05-08)	BRAKE SYS. MANAG	1836 BlueTec 4/5 (05-08)	BS
 Actros MPlI (05-08)	BRAKE SYS. MANAG	1841 BlueTec 4/5 (05-08)	BS
 Actros MPlI (05-08)	BRAKE SYS. MANAG	1844 BlueTec 4/5 (05-08)	BS
 Actros MPlI (05-08)	BRAKE SYS. MANAG	1846 BlueTec 4/5 (05-08)	BS
 Actros MPlI (05-08)	BRAKE SYS. MANAG	1848 BlueTec 4/5 (05-08)	BS
 Actros MPlI (05-08)	BRAKE SYS. MANAG	1851 BlueTec 4/5 (05-08)	BS

## Systems supported by ECReader (up to V5.40)

### TRUCKS



























### Mercedes Trucks

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Actros MPlI (05-08)	BRAKE SYS. MANAG	1855 BlueTec 4/5 (05-08)	BS
 Actros MPlI (05-08)	BRAKE SYS. MANAG	1860 BlueTec 4/5 (05-08)	BS
 Actros MPlI (05-08)	BRAKE SYS. MANAG	2532 BlueTec 4/5 (05-08)	BS
 Actros MPlI (05-08)	BRAKE SYS. MANAG	2536 BlueTec 4/5 (05-08)	BS
 Actros MPlI (05-08)	BRAKE SYS. MANAG	2541 BlueTec 4/5 (05-08)	BS
 Actros MPlI (05-08)	BRAKE SYS. MANAG	2544 BlueTec 4/5 (05-08)	BS
 Actros MPlI (05-08)	BRAKE SYS. MANAG	2546 BlueTec 4/5 (05-08)	BS
 Actros MPlI (05-08)	BRAKE SYS. MANAG	2548 BlueTec 4/5 (05-08)	BS
 Actros MPlI (05-08)	BRAKE SYS. MANAG	2551 BlueTec 4/5 (05-08)	BS
 Actros MPlI (05-08)	BRAKE SYS. MANAG	2555 BlueTec 4/5 (05-08)	BS
 Actros MPlI (05-08)	BRAKE SYS. MANAG	2560 BlueTec 4/5 (05-08)	BS
 Actros MPlI (05-08)	CHASSIS NETWORK	1832 BlueTec 4/5 (05-08)	FM Front Module
 Actros MPlI (05-08)	CHASSIS NETWORK	1832 BlueTec 4/5 (05-08)	HM Rear Module
 Actros MPlI (05-08)	CHASSIS NETWORK	1832 BlueTec 4/5 (05-08)	MSF Modular Panel
 Actros MPlI (05-08)	CHASSIS NETWORK	1836 BlueTec 4/5 (05-08)	FM Front Module
 Actros MPlI (05-08)	CHASSIS NETWORK	1836 BlueTec 4/5 (05-08)	HM Rear Module
 Actros MPlI (05-08)	CHASSIS NETWORK	1836 BlueTec 4/5 (05-08)	MSF Modular Panel
 Actros MPlI (05-08)	CHASSIS NETWORK	1841 BlueTec 4/5 (05-08)	FM Front Module
 Actros MPlI (05-08)	CHASSIS NETWORK	1841 BlueTec 4/5 (05-08)	HM Rear Module
 Actros MPlI (05-08)	CHASSIS NETWORK	1841 BlueTec 4/5 (05-08)	MSF Modular Panel
 Actros MPlI (05-08)	CHASSIS NETWORK	1844 BlueTec 4/5 (05-08)	FM Front Module
 Actros MPlI (05-08)	CHASSIS NETWORK	1844 BlueTec 4/5 (05-08)	HM Rear Module
 Actros MPlI (05-08)	CHASSIS NETWORK	1844 BlueTec 4/5 (05-08)	MSF Modular Panel
 Actros MPlI (05-08)	CHASSIS NETWORK	1846 BlueTec 4/5 (05-08)	FM Front Module
 Actros MPlI (05-08)	CHASSIS NETWORK	1846 BlueTec 4/5 (05-08)	HM Rear Module
 Actros MPlI (05-08)	CHASSIS NETWORK	1846 BlueTec 4/5 (05-08)	MSF Modular Panel
 Actros MPlI (05-08)	CHASSIS NETWORK	1848 BlueTec 4/5 (05-08)	FM Front Module

## Systems supported by ECUREADER (up to V5.40)

### TRUCKS























### Mercedes Trucks

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Actros MPlI (05-08)	CHASSIS NETWORK	1848 BlueTec 4/5 (05-08)	HM Rear Module
 Actros MPlI (05-08)	CHASSIS NETWORK	1848 BlueTec 4/5 (05-08)	MSF Modular Panel
 Actros MPlI (05-08)	CHASSIS NETWORK	1851 BlueTec 4/5 (05-08)	FM Front Module
 Actros MPlI (05-08)	CHASSIS NETWORK	1851 BlueTec 4/5 (05-08)	HM Rear Module
 Actros MPlI (05-08)	CHASSIS NETWORK	1851 BlueTec 4/5 (05-08)	MSF Modular Panel
 Actros MPlI (05-08)	CHASSIS NETWORK	1855 BlueTec 4/5 (05-08)	FM Front Module
 Actros MPlI (05-08)	CHASSIS NETWORK	1855 BlueTec 4/5 (05-08)	HM Rear Module
 Actros MPlI (05-08)	CHASSIS NETWORK	1855 BlueTec 4/5 (05-08)	MSF Modular Panel
 Actros MPlI (05-08)	CHASSIS NETWORK	1860 BlueTec 4/5 (05-08)	FM Front Module
 Actros MPlI (05-08)	CHASSIS NETWORK	1860 BlueTec 4/5 (05-08)	HM Rear Module
 Actros MPlI (05-08)	CHASSIS NETWORK	1860 BlueTec 4/5 (05-08)	MSF Modular Panel
 Actros MPlI (05-08)	CHASSIS NETWORK	2532 BlueTec 4/5 (05-08)	FM Front Module
 Actros MPlI (05-08)	CHASSIS NETWORK	2532 BlueTec 4/5 (05-08)	HM Rear Module
 Actros MPlI (05-08)	CHASSIS NETWORK	2532 BlueTec 4/5 (05-08)	MSF Modular Panel
 Actros MPlI (05-08)	CHASSIS NETWORK	2536 BlueTec 4/5 (05-08)	FM Front Module
 Actros MPlI (05-08)	CHASSIS NETWORK	2536 BlueTec 4/5 (05-08)	HM Rear Module
 Actros MPlI (05-08)	CHASSIS NETWORK	2536 BlueTec 4/5 (05-08)	MSF Modular Panel
 Actros MPlI (05-08)	CHASSIS NETWORK	2541 BlueTec 4/5 (05-08)	FM Front Module
 Actros MPlI (05-08)	CHASSIS NETWORK	2541 BlueTec 4/5 (05-08)	HM Rear Module
 Actros MPlI (05-08)	CHASSIS NETWORK	2541 BlueTec 4/5 (05-08)	MSF Modular Panel
 Actros MPlI (05-08)	CHASSIS NETWORK	2544 BlueTec 4/5 (05-08)	FM Front Module
 Actros MPlI (05-08)	CHASSIS NETWORK	2544 BlueTec 4/5 (05-08)	HM Rear Module
 Actros MPlI (05-08)	CHASSIS NETWORK	2544 BlueTec 4/5 (05-08)	MSF Modular Panel
 Actros MPlI (05-08)	CHASSIS NETWORK	2546 BlueTec 4/5 (05-08)	FM Front Module
 Actros MPlI (05-08)	CHASSIS NETWORK	2546 BlueTec 4/5 (05-08)	HM Rear Module
 Actros MPlI (05-08)	CHASSIS NETWORK	2546 BlueTec 4/5 (05-08)	MSF Modular Panel
 Actros MPlI (05-08)	CHASSIS NETWORK	2548 BlueTec 4/5 (05-08)	FM Front Module

## Systems supported by ECReader (up to V5.40)

### TRUCKS


























### Mercedes Trucks

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Actros MPlI (05-08)	CHASSIS NETWORK	2548 BlueTec 4/5 (05-08)	HM Rear Module
 Actros MPlI (05-08)	CHASSIS NETWORK	2548 BlueTec 4/5 (05-08)	MSF Modular Panel
 Actros MPlI (05-08)	CHASSIS NETWORK	2551 BlueTec 4/5 (05-08)	FM Front Module
 Actros MPlI (05-08)	CHASSIS NETWORK	2551 BlueTec 4/5 (05-08)	HM Rear Module
 Actros MPlI (05-08)	CHASSIS NETWORK	2551 BlueTec 4/5 (05-08)	MSF Modular Panel
 Actros MPlI (05-08)	CHASSIS NETWORK	2555 BlueTec 4/5 (05-08)	FM Front Module
 Actros MPlI (05-08)	CHASSIS NETWORK	2555 BlueTec 4/5 (05-08)	HM Rear Module
 Actros MPlI (05-08)	CHASSIS NETWORK	2555 BlueTec 4/5 (05-08)	MSF Modular Panel
 Actros MPlI (05-08)	CHASSIS NETWORK	2560 BlueTec 4/5 (05-08)	FM Front Module
 Actros MPlI (05-08)	CHASSIS NETWORK	2560 BlueTec 4/5 (05-08)	HM Rear Module
 Actros MPlI (05-08)	CHASSIS NETWORK	2560 BlueTec 4/5 (05-08)	MSF Modular Panel
 Actros MPlI (05-08)	DASHBOARD	1832 BlueTec 4/5 (05-08)	INS Kombi instrument
 Actros MPlI (05-08)	DASHBOARD	1836 BlueTec 4/5 (05-08)	INS Kombi instrument
 Actros MPlI (05-08)	DASHBOARD	1841 BlueTec 4/5 (05-08)	INS Kombi instrument
 Actros MPlI (05-08)	DASHBOARD	1844 BlueTec 4/5 (05-08)	INS Kombi instrument
 Actros MPlI (05-08)	DASHBOARD	1846 BlueTec 4/5 (05-08)	INS Kombi instrument
 Actros MPlI (05-08)	DASHBOARD	1848 BlueTec 4/5 (05-08)	INS Kombi instrument
 Actros MPlI (05-08)	DASHBOARD	1851 BlueTec 4/5 (05-08)	INS Kombi instrument
 Actros MPlI (05-08)	DASHBOARD	1855 BlueTec 4/5 (05-08)	INS Kombi instrument
 Actros MPlI (05-08)	DASHBOARD	1860 BlueTec 4/5 (05-08)	INS Kombi instrument
 Actros MPlI (05-08)	DASHBOARD	2532 BlueTec 4/5 (05-08)	INS Kombi instrument
 Actros MPlI (05-08)	DASHBOARD	2536 BlueTec 4/5 (05-08)	INS Kombi instrument
 Actros MPlI (05-08)	DASHBOARD	2541 BlueTec 4/5 (05-08)	INS Kombi instrument
 Actros MPlI (05-08)	DASHBOARD	2544 BlueTec 4/5 (05-08)	INS Kombi instrument
 Actros MPlI (05-08)	DASHBOARD	2546 BlueTec 4/5 (05-08)	INS Kombi instrument
 Actros MPlI (05-08)	DASHBOARD	2548 BlueTec 4/5 (05-08)	INS Kombi instrument
 Actros MPlI (05-08)	DASHBOARD	2551 BlueTec 4/5 (05-08)	INS Kombi instrument

## Systems supported by ECReader (up to V5.40)

### TRUCKS




























### Mercedes Trucks

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Actros MPlI (05-08)	DASHBOARD	2555 BlueTec 4/5 (05-08)	INS Kombi instrument
 Actros MPlI (05-08)	DASHBOARD	2560 BlueTec 4/5 (05-08)	INS Kombi instrument
 Actros MPlI (05-08)	DRIVER SIDE DOOR	1832 BlueTec 4/5 (05-08)	TMF
 Actros MPlI (05-08)	DRIVER SIDE DOOR	1836 BlueTec 4/5 (05-08)	TMF
 Actros MPlI (05-08)	DRIVER SIDE DOOR	1841 BlueTec 4/5 (05-08)	TMF
 Actros MPlI (05-08)	DRIVER SIDE DOOR	1844 BlueTec 4/5 (05-08)	TMF
 Actros MPlI (05-08)	DRIVER SIDE DOOR	1846 BlueTec 4/5 (05-08)	TMF
 Actros MPlI (05-08)	DRIVER SIDE DOOR	1848 BlueTec 4/5 (05-08)	TMF
 Actros MPlI (05-08)	DRIVER SIDE DOOR	1851 BlueTec 4/5 (05-08)	TMF
 Actros MPlI (05-08)	DRIVER SIDE DOOR	1855 BlueTec 4/5 (05-08)	TMF
 Actros MPlI (05-08)	DRIVER SIDE DOOR	1860 BlueTec 4/5 (05-08)	TMF
 Actros MPlI (05-08)	DRIVER SIDE DOOR	2532 BlueTec 4/5 (05-08)	TMF
 Actros MPlI (05-08)	DRIVER SIDE DOOR	2536 BlueTec 4/5 (05-08)	TMF
 Actros MPlI (05-08)	DRIVER SIDE DOOR	2541 BlueTec 4/5 (05-08)	TMF
 Actros MPlI (05-08)	DRIVER SIDE DOOR	2544 BlueTec 4/5 (05-08)	TMF
 Actros MPlI (05-08)	DRIVER SIDE DOOR	2546 BlueTec 4/5 (05-08)	TMF
 Actros MPlI (05-08)	DRIVER SIDE DOOR	2548 BlueTec 4/5 (05-08)	TMF
 Actros MPlI (05-08)	DRIVER SIDE DOOR	2551 BlueTec 4/5 (05-08)	TMF
 Actros MPlI (05-08)	DRIVER SIDE DOOR	2555 BlueTec 4/5 (05-08)	TMF
 Actros MPlI (05-08)	DRIVER SIDE DOOR	2560 BlueTec 4/5 (05-08)	TMF
 Actros MPlI (05-08)	ENGINE MANAGEME	1832 BlueTec 4/5 (05-08)	MR
 Actros MPlI (05-08)	ENGINE MANAGEME	1836 BlueTec 4/5 (05-08)	MR
 Actros MPlI (05-08)	ENGINE MANAGEME	1841 BlueTec 4/5 (05-08)	MR
 Actros MPlI (05-08)	ENGINE MANAGEME	1844 BlueTec 4/5 (05-08)	MR
 Actros MPlI (05-08)	ENGINE MANAGEME	1846 BlueTec 4/5 (05-08)	MR
 Actros MPlI (05-08)	ENGINE MANAGEME	1848 BlueTec 4/5 (05-08)	MR
 Actros MPlI (05-08)	ENGINE MANAGEME	1851 BlueTec 4/5 (05-08)	MR

## Systems supported by ECReader (up to V5.40)

### TRUCKS




























### Mercedes Trucks

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Actros MPlI (05-08)	ENGINE MANAGEME	1855 BlueTec 4/5 (05-08)	MR
 Actros MPlI (05-08)	ENGINE MANAGEME	1860 BlueTec 4/5 (05-08)	MR
 Actros MPlI (05-08)	ENGINE MANAGEME	2532 BlueTec 4/5 (05-08)	MR
 Actros MPlI (05-08)	ENGINE MANAGEME	2536 BlueTec 4/5 (05-08)	MR
 Actros MPlI (05-08)	ENGINE MANAGEME	2541 BlueTec 4/5 (05-08)	MR
 Actros MPlI (05-08)	ENGINE MANAGEME	2544 BlueTec 4/5 (05-08)	MR
 Actros MPlI (05-08)	ENGINE MANAGEME	2546 BlueTec 4/5 (05-08)	MR
 Actros MPlI (05-08)	ENGINE MANAGEME	2548 BlueTec 4/5 (05-08)	MR
 Actros MPlI (05-08)	ENGINE MANAGEME	2551 BlueTec 4/5 (05-08)	MR
 Actros MPlI (05-08)	ENGINE MANAGEME	2555 BlueTec 4/5 (05-08)	MR
 Actros MPlI (05-08)	ENGINE MANAGEME	2560 BlueTec 4/5 (05-08)	MR
 Actros MPlI (05-08)	MAINTENANCE SYST	1832 BlueTec 4/5 (05-08)	WS
 Actros MPlI (05-08)	MAINTENANCE SYST	1836 BlueTec 4/5 (05-08)	WS
 Actros MPlI (05-08)	MAINTENANCE SYST	1841 BlueTec 4/5 (05-08)	WS
 Actros MPlI (05-08)	MAINTENANCE SYST	1844 BlueTec 4/5 (05-08)	WS
 Actros MPlI (05-08)	MAINTENANCE SYST	1846 BlueTec 4/5 (05-08)	WS
 Actros MPlI (05-08)	MAINTENANCE SYST	1848 BlueTec 4/5 (05-08)	WS
 Actros MPlI (05-08)	MAINTENANCE SYST	1851 BlueTec 4/5 (05-08)	WS
 Actros MPlI (05-08)	MAINTENANCE SYST	1855 BlueTec 4/5 (05-08)	WS
 Actros MPlI (05-08)	MAINTENANCE SYST	1860 BlueTec 4/5 (05-08)	WS
 Actros MPlI (05-08)	MAINTENANCE SYST	2532 BlueTec 4/5 (05-08)	WS
 Actros MPlI (05-08)	MAINTENANCE SYST	2536 BlueTec 4/5 (05-08)	WS
 Actros MPlI (05-08)	MAINTENANCE SYST	2541 BlueTec 4/5 (05-08)	WS
 Actros MPlI (05-08)	MAINTENANCE SYST	2544 BlueTec 4/5 (05-08)	WS
 Actros MPlI (05-08)	MAINTENANCE SYST	2546 BlueTec 4/5 (05-08)	WS
 Actros MPlI (05-08)	MAINTENANCE SYST	2548 BlueTec 4/5 (05-08)	WS
 Actros MPlI (05-08)	MAINTENANCE SYST	2551 BlueTec 4/5 (05-08)	WS

## Systems supported by ECUREADER (up to V5.40)

### TRUCKS


























### Mercedes Trucks

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Actros MPlI (05-08)	MAINTENANCE SYST	2555 BlueTec 4/5 (05-08)	WS
 Actros MPlI (05-08)	MAINTENANCE SYST	2560 BlueTec 4/5 (05-08)	WS
 Actros MPlI (05-08)	PASS. SIDE DOOR	1832 BlueTec 4/5 (05-08)	TMB
 Actros MPlI (05-08)	PASS. SIDE DOOR	1836 BlueTec 4/5 (05-08)	TMB
 Actros MPlI (05-08)	PASS. SIDE DOOR	1841 BlueTec 4/5 (05-08)	TMB
 Actros MPlI (05-08)	PASS. SIDE DOOR	1844 BlueTec 4/5 (05-08)	TMB
 Actros MPlI (05-08)	PASS. SIDE DOOR	1846 BlueTec 4/5 (05-08)	TMB
 Actros MPlI (05-08)	PASS. SIDE DOOR	1848 BlueTec 4/5 (05-08)	TMB
 Actros MPlI (05-08)	PASS. SIDE DOOR	1851 BlueTec 4/5 (05-08)	TMB
 Actros MPlI (05-08)	PASS. SIDE DOOR	1855 BlueTec 4/5 (05-08)	TMB
 Actros MPlI (05-08)	PASS. SIDE DOOR	1860 BlueTec 4/5 (05-08)	TMB
 Actros MPlI (05-08)	PASS. SIDE DOOR	2532 BlueTec 4/5 (05-08)	TMB
 Actros MPlI (05-08)	PASS. SIDE DOOR	2536 BlueTec 4/5 (05-08)	TMB
 Actros MPlI (05-08)	PASS. SIDE DOOR	2541 BlueTec 4/5 (05-08)	TMB
 Actros MPlI (05-08)	PASS. SIDE DOOR	2544 BlueTec 4/5 (05-08)	TMB
 Actros MPlI (05-08)	PASS. SIDE DOOR	2546 BlueTec 4/5 (05-08)	TMB
 Actros MPlI (05-08)	PASS. SIDE DOOR	2548 BlueTec 4/5 (05-08)	TMB
 Actros MPlI (05-08)	PASS. SIDE DOOR	2551 BlueTec 4/5 (05-08)	TMB
 Actros MPlI (05-08)	PASS. SIDE DOOR	2555 BlueTec 4/5 (05-08)	TMB
 Actros MPlI (05-08)	PASS. SIDE DOOR	2560 BlueTec 4/5 (05-08)	TMB
 Actros MPlI (05-08)	SUSPENSION CONTR	1832 BlueTec 4/5 (05-08)	NR
 Actros MPlI (05-08)	SUSPENSION CONTR	1836 BlueTec 4/5 (05-08)	NR
 Actros MPlI (05-08)	SUSPENSION CONTR	1841 BlueTec 4/5 (05-08)	NR
 Actros MPlI (05-08)	SUSPENSION CONTR	1844 BlueTec 4/5 (05-08)	NR
 Actros MPlI (05-08)	SUSPENSION CONTR	1846 BlueTec 4/5 (05-08)	NR
 Actros MPlI (05-08)	SUSPENSION CONTR	1848 BlueTec 4/5 (05-08)	NR
 Actros MPlI (05-08)	SUSPENSION CONTR	1851 BlueTec 4/5 (05-08)	NR

## Systems supported by ECReader (up to V5.40)

### TRUCKS




























### Mercedes Trucks

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Actros MPII (05-08)	SUSPENSION CONTR	1855 BlueTec 4/5 (05-08)	NR
 Actros MPII (05-08)	SUSPENSION CONTR	1860 BlueTec 4/5 (05-08)	NR
 Actros MPII (05-08)	SUSPENSION CONTR	2532 BlueTec 4/5 (05-08)	NR
 Actros MPII (05-08)	SUSPENSION CONTR	2536 BlueTec 4/5 (05-08)	NR
 Actros MPII (05-08)	SUSPENSION CONTR	2541 BlueTec 4/5 (05-08)	NR
 Actros MPII (05-08)	SUSPENSION CONTR	2544 BlueTec 4/5 (05-08)	NR
 Actros MPII (05-08)	SUSPENSION CONTR	2546 BlueTec 4/5 (05-08)	NR
 Actros MPII (05-08)	SUSPENSION CONTR	2548 BlueTec 4/5 (05-08)	NR
 Actros MPII (05-08)	SUSPENSION CONTR	2551 BlueTec 4/5 (05-08)	NR
 Actros MPII (05-08)	SUSPENSION CONTR	2555 BlueTec 4/5 (05-08)	NR
 Actros MPII (05-08)	SUSPENSION CONTR	2560 BlueTec 4/5 (05-08)	NR
 Actros MPIII (08-..)	AUTOM. TRANSMISSI	1832 BlueTec 4/5 (08-..)	GS II
 Actros MPIII (08-..)	AUTOM. TRANSMISSI	1836 BlueTec 4/5 (08-..)	GS II
 Actros MPIII (08-..)	AUTOM. TRANSMISSI	1841 BlueTec 4/5 (08-..)	GS II
 Actros MPIII (08-..)	AUTOM. TRANSMISSI	1844 BlueTec 4/5 (08-..)	GS II
 Actros MPIII (08-..)	AUTOM. TRANSMISSI	1846 BlueTec 4/5 (08-..)	GS II
 Actros MPIII (08-..)	AUTOM. TRANSMISSI	1848 BlueTec 4/5 (08-..)	GS II
 Actros MPIII (08-..)	AUTOM. TRANSMISSI	1851 BlueTec 4/5 (08-..)	GS II
 Actros MPIII (08-..)	AUTOM. TRANSMISSI	1855 BlueTec 4/5 (08-..)	GS II
 Actros MPIII (08-..)	AUTOM. TRANSMISSI	1860 BlueTec 4/5 (08-..)	GS II
 Actros MPIII (08-..)	AUTOM. TRANSMISSI	2532 BlueTec 4/5 (08-..)	GS II
 Actros MPIII (08-..)	AUTOM. TRANSMISSI	2536 BlueTec 4/5 (08-..)	GS II
 Actros MPIII (08-..)	AUTOM. TRANSMISSI	2541 BlueTec 4/5 (08-..)	GS II
 Actros MPIII (08-..)	AUTOM. TRANSMISSI	2544 BlueTec 4/5 (08-..)	GS II
 Actros MPIII (08-..)	AUTOM. TRANSMISSI	2546 BlueTec 4/5 (08-..)	GS II
 Actros MPIII (08-..)	AUTOM. TRANSMISSI	2548 BlueTec 4/5 (08-..)	GS II

## Systems supported by ECReader (up to V5.40)

### TRUCKS























### Mercedes Trucks

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Actros MPIII (08-..)	AUTOM. TRANSMISSI	2551 BlueTec 4/5 (08-..)	GS II
 Actros MPIII (08-..)	AUTOM. TRANSMISSI	2555 BlueTec 4/5 (08-..)	GS II
 Actros MPIII (08-..)	AUTOM. TRANSMISSI	2560 BlueTec 4/5 (08-..)	GS II
 Actros MPIII (08-..)	BRAKE SYS. MANAG	1832 BlueTec 4/5 (08-..)	BS
 Actros MPIII (08-..)	BRAKE SYS. MANAG	1836 BlueTec 4/5 (08-..)	BS
 Actros MPIII (08-..)	BRAKE SYS. MANAG	1841 BlueTec 4/5 (08-..)	BS
 Actros MPIII (08-..)	BRAKE SYS. MANAG	1844 BlueTec 4/5 (08-..)	BS
 Actros MPIII (08-..)	BRAKE SYS. MANAG	1846 BlueTec 4/5 (08-..)	BS
 Actros MPIII (08-..)	BRAKE SYS. MANAG	1848 BlueTec 4/5 (08-..)	BS
 Actros MPIII (08-..)	BRAKE SYS. MANAG	1851 BlueTec 4/5 (08-..)	BS
 Actros MPIII (08-..)	BRAKE SYS. MANAG	1855 BlueTec 4/5 (08-..)	BS
 Actros MPIII (08-..)	BRAKE SYS. MANAG	1860 BlueTec 4/5 (08-..)	BS
 Actros MPIII (08-..)	BRAKE SYS. MANAG	2532 BlueTec 4/5 (08-..)	BS
 Actros MPIII (08-..)	BRAKE SYS. MANAG	2536 BlueTec 4/5 (08-..)	BS
 Actros MPIII (08-..)	BRAKE SYS. MANAG	2541 BlueTec 4/5 (08-..)	BS
 Actros MPIII (08-..)	BRAKE SYS. MANAG	2544 BlueTec 4/5 (08-..)	BS
 Actros MPIII (08-..)	BRAKE SYS. MANAG	2546 BlueTec 4/5 (08-..)	BS
 Actros MPIII (08-..)	BRAKE SYS. MANAG	2548 BlueTec 4/5 (08-..)	BS
 Actros MPIII (08-..)	BRAKE SYS. MANAG	2551 BlueTec 4/5 (08-..)	BS
 Actros MPIII (08-..)	BRAKE SYS. MANAG	2555 BlueTec 4/5 (08-..)	BS
 Actros MPIII (08-..)	BRAKE SYS. MANAG	2560 BlueTec 4/5 (08-..)	BS
 Actros MPIII (08-..)	CHASSIS NETWORK	1832 BlueTec 4/5 (08-..)	FM Front Module
 Actros MPIII (08-..)	CHASSIS NETWORK	1832 BlueTec 4/5 (08-..)	HM Rear Module
 Actros MPIII (08-..)	CHASSIS NETWORK	1832 BlueTec 4/5 (08-..)	MSF Modular Panel
 Actros MPIII (08-..)	CHASSIS NETWORK	1836 BlueTec 4/5 (08-..)	FM Front Module
 Actros MPIII (08-..)	CHASSIS NETWORK	1836 BlueTec 4/5 (08-..)	HM Rear Module
 Actros MPIII (08-..)	CHASSIS NETWORK	1836 BlueTec 4/5 (08-..)	MSF Modular Panel

## Systems supported by ECReader (up to V5.40)

### TRUCKS


























### Mercedes Trucks

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Actros MPIII (08-..)	CHASSIS NETWORK	1841 BlueTec 4/5 (08-..)	FM Front Module
 Actros MPIII (08-..)	CHASSIS NETWORK	1841 BlueTec 4/5 (08-..)	HM Rear Module
 Actros MPIII (08-..)	CHASSIS NETWORK	1841 BlueTec 4/5 (08-..)	MSF Modular Panel
 Actros MPIII (08-..)	CHASSIS NETWORK	1844 BlueTec 4/5 (08-..)	FM Front Module
 Actros MPIII (08-..)	CHASSIS NETWORK	1844 BlueTec 4/5 (08-..)	HM Rear Module
 Actros MPIII (08-..)	CHASSIS NETWORK	1844 BlueTec 4/5 (08-..)	MSF Modular Panel
 Actros MPIII (08-..)	CHASSIS NETWORK	1846 BlueTec 4/5 (08-..)	FM Front Module
 Actros MPIII (08-..)	CHASSIS NETWORK	1846 BlueTec 4/5 (08-..)	HM Rear Module
 Actros MPIII (08-..)	CHASSIS NETWORK	1846 BlueTec 4/5 (08-..)	MSF Modular Panel
 Actros MPIII (08-..)	CHASSIS NETWORK	1848 BlueTec 4/5 (08-..)	FM Front Module
 Actros MPIII (08-..)	CHASSIS NETWORK	1848 BlueTec 4/5 (08-..)	HM Rear Module
 Actros MPIII (08-..)	CHASSIS NETWORK	1848 BlueTec 4/5 (08-..)	MSF Modular Panel
 Actros MPIII (08-..)	CHASSIS NETWORK	1851 BlueTec 4/5 (08-..)	FM Front Module
 Actros MPIII (08-..)	CHASSIS NETWORK	1851 BlueTec 4/5 (08-..)	HM Rear Module
 Actros MPIII (08-..)	CHASSIS NETWORK	1851 BlueTec 4/5 (08-..)	MSF Modular Panel
 Actros MPIII (08-..)	CHASSIS NETWORK	1855 BlueTec 4/5 (08-..)	FM Front Module
 Actros MPIII (08-..)	CHASSIS NETWORK	1855 BlueTec 4/5 (08-..)	HM Rear Module
 Actros MPIII (08-..)	CHASSIS NETWORK	1855 BlueTec 4/5 (08-..)	MSF Modular Panel
 Actros MPIII (08-..)	CHASSIS NETWORK	1860 BlueTec 4/5 (08-..)	FM Front Module
 Actros MPIII (08-..)	CHASSIS NETWORK	1860 BlueTec 4/5 (08-..)	HM Rear Module
 Actros MPIII (08-..)	CHASSIS NETWORK	1860 BlueTec 4/5 (08-..)	MSF Modular Panel
 Actros MPIII (08-..)	CHASSIS NETWORK	2532 BlueTec 4/5 (08-..)	FM Front Module
 Actros MPIII (08-..)	CHASSIS NETWORK	2532 BlueTec 4/5 (08-..)	HM Rear Module
 Actros MPIII (08-..)	CHASSIS NETWORK	2532 BlueTec 4/5 (08-..)	MSF Modular Panel
 Actros MPIII (08-..)	CHASSIS NETWORK	2536 BlueTec 4/5 (08-..)	FM Front Module
 Actros MPIII (08-..)	CHASSIS NETWORK	2536 BlueTec 4/5 (08-..)	HM Rear Module
 Actros MPIII (08-..)	CHASSIS NETWORK	2536 BlueTec 4/5 (08-..)	MSF Modular Panel

## Systems supported by ECReader (up to V5.40)

### TRUCKS




























### Mercedes Trucks

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Actros MPlII (08-..)	CHASSIS NETWORK	2541 BlueTec 4/5 (08-..)	FM Front Module
 Actros MPlII (08-..)	CHASSIS NETWORK	2541 BlueTec 4/5 (08-..)	HM Rear Module
 Actros MPlII (08-..)	CHASSIS NETWORK	2541 BlueTec 4/5 (08-..)	MSF Modular Panel
 Actros MPlII (08-..)	CHASSIS NETWORK	2544 BlueTec 4/5 (08-..)	FM Front Module
 Actros MPlII (08-..)	CHASSIS NETWORK	2544 BlueTec 4/5 (08-..)	HM Rear Module
 Actros MPlII (08-..)	CHASSIS NETWORK	2544 BlueTec 4/5 (08-..)	MSF Modular Panel
 Actros MPlII (08-..)	CHASSIS NETWORK	2546 BlueTec 4/5 (08-..)	FM Front Module
 Actros MPlII (08-..)	CHASSIS NETWORK	2546 BlueTec 4/5 (08-..)	HM Rear Module
 Actros MPlII (08-..)	CHASSIS NETWORK	2546 BlueTec 4/5 (08-..)	MSF Modular Panel
 Actros MPlII (08-..)	CHASSIS NETWORK	2548 BlueTec 4/5 (08-..)	FM Front Module
 Actros MPlII (08-..)	CHASSIS NETWORK	2548 BlueTec 4/5 (08-..)	HM Rear Module
 Actros MPlII (08-..)	CHASSIS NETWORK	2548 BlueTec 4/5 (08-..)	MSF Modular Panel
 Actros MPlII (08-..)	CHASSIS NETWORK	2551 BlueTec 4/5 (08-..)	FM Front Module
 Actros MPlII (08-..)	CHASSIS NETWORK	2551 BlueTec 4/5 (08-..)	HM Rear Module
 Actros MPlII (08-..)	CHASSIS NETWORK	2551 BlueTec 4/5 (08-..)	MSF Modular Panel
 Actros MPlII (08-..)	CHASSIS NETWORK	2555 BlueTec 4/5 (08-..)	FM Front Module
 Actros MPlII (08-..)	CHASSIS NETWORK	2555 BlueTec 4/5 (08-..)	HM Rear Module
 Actros MPlII (08-..)	CHASSIS NETWORK	2555 BlueTec 4/5 (08-..)	MSF Modular Panel
 Actros MPlII (08-..)	CHASSIS NETWORK	2560 BlueTec 4/5 (08-..)	FM Front Module
 Actros MPlII (08-..)	CHASSIS NETWORK	2560 BlueTec 4/5 (08-..)	HM Rear Module
 Actros MPlII (08-..)	CHASSIS NETWORK	2560 BlueTec 4/5 (08-..)	MSF Modular Panel
 Actros MPlII (08-..)	DASHBOARD	1832 BlueTec 4/5 (08-..)	INS Kombi instrument
 Actros MPlII (08-..)	DASHBOARD	1836 BlueTec 4/5 (08-..)	INS Kombi instrument
 Actros MPlII (08-..)	DASHBOARD	1841 BlueTec 4/5 (08-..)	INS Kombi instrument
 Actros MPlII (08-..)	DASHBOARD	1844 BlueTec 4/5 (08-..)	INS Kombi instrument
 Actros MPlII (08-..)	DASHBOARD	1846 BlueTec 4/5 (08-..)	INS Kombi instrument
 Actros MPlII (08-..)	DASHBOARD	1848 BlueTec 4/5 (08-..)	INS Kombi instrument

## Systems supported by ECReader (up to V5.40)

### TRUCKS




























### Mercedes Trucks

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Actros MPIII (08-..)	DASHBOARD	1851 BlueTec 4/5 (08-..)	INS Kombi instrument
 Actros MPIII (08-..)	DASHBOARD	1855 BlueTec 4/5 (08-..)	INS Kombi instrument
 Actros MPIII (08-..)	DASHBOARD	1860 BlueTec 4/5 (08-..)	INS Kombi instrument
 Actros MPIII (08-..)	DASHBOARD	2532 BlueTec 4/5 (08-..)	INS Kombi instrument
 Actros MPIII (08-..)	DASHBOARD	2536 BlueTec 4/5 (08-..)	INS Kombi instrument
 Actros MPIII (08-..)	DASHBOARD	2541 BlueTec 4/5 (08-..)	INS Kombi instrument
 Actros MPIII (08-..)	DASHBOARD	2544 BlueTec 4/5 (08-..)	INS Kombi instrument
 Actros MPIII (08-..)	DASHBOARD	2546 BlueTec 4/5 (08-..)	INS Kombi instrument
 Actros MPIII (08-..)	DASHBOARD	2548 BlueTec 4/5 (08-..)	INS Kombi instrument
 Actros MPIII (08-..)	DASHBOARD	2551 BlueTec 4/5 (08-..)	INS Kombi instrument
 Actros MPIII (08-..)	DASHBOARD	2555 BlueTec 4/5 (08-..)	INS Kombi instrument
 Actros MPIII (08-..)	DASHBOARD	2560 BlueTec 4/5 (08-..)	INS Kombi instrument
 Actros MPIII (08-..)	DRIVER SIDE DOOR	1832 BlueTec 4/5 (08-..)	TMF
 Actros MPIII (08-..)	DRIVER SIDE DOOR	1836 BlueTec 4/5 (08-..)	TMF
 Actros MPIII (08-..)	DRIVER SIDE DOOR	1841 BlueTec 4/5 (08-..)	TMF
 Actros MPIII (08-..)	DRIVER SIDE DOOR	1844 BlueTec 4/5 (08-..)	TMF
 Actros MPIII (08-..)	DRIVER SIDE DOOR	1846 BlueTec 4/5 (08-..)	TMF
 Actros MPIII (08-..)	DRIVER SIDE DOOR	1848 BlueTec 4/5 (08-..)	TMF
 Actros MPIII (08-..)	DRIVER SIDE DOOR	1851 BlueTec 4/5 (08-..)	TMF
 Actros MPIII (08-..)	DRIVER SIDE DOOR	1855 BlueTec 4/5 (08-..)	TMF
 Actros MPIII (08-..)	DRIVER SIDE DOOR	1860 BlueTec 4/5 (08-..)	TMF
 Actros MPIII (08-..)	DRIVER SIDE DOOR	2532 BlueTec 4/5 (08-..)	TMF
 Actros MPIII (08-..)	DRIVER SIDE DOOR	2536 BlueTec 4/5 (08-..)	TMF
 Actros MPIII (08-..)	DRIVER SIDE DOOR	2541 BlueTec 4/5 (08-..)	TMF
 Actros MPIII (08-..)	DRIVER SIDE DOOR	2544 BlueTec 4/5 (08-..)	TMF
 Actros MPIII (08-..)	DRIVER SIDE DOOR	2546 BlueTec 4/5 (08-..)	TMF
 Actros MPIII (08-..)	DRIVER SIDE DOOR	2548 BlueTec 4/5 (08-..)	TMF

## Systems supported by ECReader (up to V5.40)

### TRUCKS




























### Mercedes Trucks

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Actros MPIII (08-..)	DRIVER SIDE DOOR	2551 BlueTec 4/5 (08-..)	TMF
 Actros MPIII (08-..)	DRIVER SIDE DOOR	2555 BlueTec 4/5 (08-..)	TMF
 Actros MPIII (08-..)	DRIVER SIDE DOOR	2560 BlueTec 4/5 (08-..)	TMF
 Actros MPIII (08-..)	ENGINE MANAGEME	1832 BlueTec 4/5 (08-..)	MR
 Actros MPIII (08-..)	ENGINE MANAGEME	1836 BlueTec 4/5 (08-..)	MR
 Actros MPIII (08-..)	ENGINE MANAGEME	1841 BlueTec 4/5 (08-..)	MR
 Actros MPIII (08-..)	ENGINE MANAGEME	1844 BlueTec 4/5 (08-..)	MR
 Actros MPIII (08-..)	ENGINE MANAGEME	1846 BlueTec 4/5 (08-..)	MR
 Actros MPIII (08-..)	ENGINE MANAGEME	1848 BlueTec 4/5 (08-..)	MR
 Actros MPIII (08-..)	ENGINE MANAGEME	1851 BlueTec 4/5 (08-..)	MR
 Actros MPIII (08-..)	ENGINE MANAGEME	1855 BlueTec 4/5 (08-..)	MR
 Actros MPIII (08-..)	ENGINE MANAGEME	1860 BlueTec 4/5 (08-..)	MR
 Actros MPIII (08-..)	ENGINE MANAGEME	2532 BlueTec 4/5 (08-..)	MR
 Actros MPIII (08-..)	ENGINE MANAGEME	2536 BlueTec 4/5 (08-..)	MR
 Actros MPIII (08-..)	ENGINE MANAGEME	2541 BlueTec 4/5 (08-..)	MR
 Actros MPIII (08-..)	ENGINE MANAGEME	2544 BlueTec 4/5 (08-..)	MR
 Actros MPIII (08-..)	ENGINE MANAGEME	2546 BlueTec 4/5 (08-..)	MR
 Actros MPIII (08-..)	ENGINE MANAGEME	2548 BlueTec 4/5 (08-..)	MR
 Actros MPIII (08-..)	ENGINE MANAGEME	2551 BlueTec 4/5 (08-..)	MR
 Actros MPIII (08-..)	ENGINE MANAGEME	2555 BlueTec 4/5 (08-..)	MR
 Actros MPIII (08-..)	ENGINE MANAGEME	2560 BlueTec 4/5 (08-..)	MR
 Actros MPIII (08-..)	PASS. SIDE DOOR	1832 BlueTec 4/5 (08-..)	TMB
 Actros MPIII (08-..)	PASS. SIDE DOOR	1836 BlueTec 4/5 (08-..)	TMB
 Actros MPIII (08-..)	PASS. SIDE DOOR	1841 BlueTec 4/5 (08-..)	TMB
 Actros MPIII (08-..)	PASS. SIDE DOOR	1844 BlueTec 4/5 (08-..)	TMB
 Actros MPIII (08-..)	PASS. SIDE DOOR	1846 BlueTec 4/5 (08-..)	TMB
 Actros MPIII (08-..)	PASS. SIDE DOOR	1848 BlueTec 4/5 (08-..)	TMB

## Systems supported by ECUREADER (up to V5.40)

### TRUCKS



























### Mercedes Trucks

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Actros MP111 (08-..)	PASS. SIDE DOOR	1851 BlueTec 4/5 (08-..)	TMB
 Actros MP111 (08-..)	PASS. SIDE DOOR	1855 BlueTec 4/5 (08-..)	TMB
 Actros MP111 (08-..)	PASS. SIDE DOOR	1860 BlueTec 4/5 (08-..)	TMB
 Actros MP111 (08-..)	PASS. SIDE DOOR	2532 BlueTec 4/5 (08-..)	TMB
 Actros MP111 (08-..)	PASS. SIDE DOOR	2536 BlueTec 4/5 (08-..)	TMB
 Actros MP111 (08-..)	PASS. SIDE DOOR	2541 BlueTec 4/5 (08-..)	TMB
 Actros MP111 (08-..)	PASS. SIDE DOOR	2544 BlueTec 4/5 (08-..)	TMB
 Actros MP111 (08-..)	PASS. SIDE DOOR	2546 BlueTec 4/5 (08-..)	TMB
 Actros MP111 (08-..)	PASS. SIDE DOOR	2548 BlueTec 4/5 (08-..)	TMB
 Actros MP111 (08-..)	PASS. SIDE DOOR	2551 BlueTec 4/5 (08-..)	TMB
 Actros MP111 (08-..)	PASS. SIDE DOOR	2555 BlueTec 4/5 (08-..)	TMB
 Actros MP111 (08-..)	PASS. SIDE DOOR	2560 BlueTec 4/5 (08-..)	TMB
 Actros MP111 (08-..)	SUSPENSION CONTR	1832 BlueTec 4/5 (08-..)	NR
 Actros MP111 (08-..)	SUSPENSION CONTR	1836 BlueTec 4/5 (08-..)	NR
 Actros MP111 (08-..)	SUSPENSION CONTR	1841 BlueTec 4/5 (08-..)	NR
 Actros MP111 (08-..)	SUSPENSION CONTR	1844 BlueTec 4/5 (08-..)	NR
 Actros MP111 (08-..)	SUSPENSION CONTR	1846 BlueTec 4/5 (08-..)	NR
 Actros MP111 (08-..)	SUSPENSION CONTR	1848 BlueTec 4/5 (08-..)	NR
 Actros MP111 (08-..)	SUSPENSION CONTR	1851 BlueTec 4/5 (08-..)	NR
 Actros MP111 (08-..)	SUSPENSION CONTR	1855 BlueTec 4/5 (08-..)	NR
 Actros MP111 (08-..)	SUSPENSION CONTR	1860 BlueTec 4/5 (08-..)	NR
 Actros MP111 (08-..)	SUSPENSION CONTR	2532 BlueTec 4/5 (08-..)	NR
 Actros MP111 (08-..)	SUSPENSION CONTR	2536 BlueTec 4/5 (08-..)	NR
 Actros MP111 (08-..)	SUSPENSION CONTR	2541 BlueTec 4/5 (08-..)	NR
 Actros MP111 (08-..)	SUSPENSION CONTR	2544 BlueTec 4/5 (08-..)	NR
 Actros MP111 (08-..)	SUSPENSION CONTR	2546 BlueTec 4/5 (08-..)	NR
 Actros MP111 (08-..)	SUSPENSION CONTR	2548 BlueTec 4/5 (08-..)	NR

## Systems supported by ECUreader (up to V5.40)

### TRUCKS




























### Mercedes Trucks

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Actros MPIII (08-..)	SUSPENSION CONTR	2551 BlueTec 4/5 (08-..)	NR
 Actros MPIII (08-..)	SUSPENSION CONTR	2555 BlueTec 4/5 (08-..)	NR
 Actros MPIII (08-..)	SUSPENSION CONTR	2560 BlueTec 4/5 (08-..)	NR
 Atego	ABS	1017 (98-02)	MB ABS
 Atego	ABS	1018 (98-02)	MB ABS
 Atego	ABS	1018 (99-00)	MB ABS
 Atego	ABS	1018 AK (98-02)	MB ABS
 Atego	ABS	1018 AK (99-00)	MB ABS
 Atego	ABS	1018 Bluetec4 (05-07)	MB
 Atego	ABS	1018 Bluetec5 (06-08)	MB
 Atego	ABS	1018 L (98-02)	MB ABS
 Atego	ABS	1018 L (99-00)	MB ABS
 Atego	ABS	1022 Bluetec4 (05-07)	MB
 Atego	ABS	1022 Bluetec5 (06-08)	MB
 Atego	ABS	1024 Bluetec4 (05-07)	MB
 Atego	ABS	1024 Bluetec5 (06-08)	MB
 Atego	ABS	1217 (98-02)	MB ABS
 Atego	ABS	1218 (98-02)	MB ABS
 Atego	ABS	1218 (99-00)	MB ABS
 Atego	ABS	1218 Bluetec4 (05-07)	MB
 Atego	ABS	1218 Bluetec5 (06-08)	MB
 Atego	ABS	1218 K (98-02)	MB ABS
 Atego	ABS	1218 K (99-00)	MB ABS
 Atego	ABS	1218 L (98-02)	MB ABS
 Atego	ABS	1218 L (99-00)	MB ABS
 Atego	ABS	1222 Bluetec4 (05-07)	MB

## Systems supported by ECUreader (up to V5.40)

### TRUCKS




























### Mercedes Trucks

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Atego	ABS	1222 Bluetec5 (06-08)	MB
 Atego	ABS	1223 (98-02)	MB ABS
 Atego	ABS	1223 (99-00)	MB ABS
 Atego	ABS	1223 L (98-02)	MB ABS
 Atego	ABS	1223 L (99-00)	MB ABS
 Atego	ABS	1224 Bluetec4 (05-07)	MB
 Atego	ABS	1224 Bluetec5 (06-08)	MB
 Atego	ABS	1228 (98-02)	MB ABS
 Atego	ABS	1228 (99-00)	MB ABS
 Atego	ABS	1228 L (98-02)	MB ABS
 Atego	ABS	1228 L (99-00)	MB ABS
 Atego	ABS	1229 Bluetec4 (05-07)	MB
 Atego	ABS	1229 Bluetec5 (06-08)	MB
 Atego	ABS	1324 Bluetec4 (05-07)	MB
 Atego	ABS	1324 Bluetec5 (06-08)	MB
 Atego	ABS	1329 Bluetec4 (05-07)	MB
 Atego	ABS	1329 Bluetec5 (06-08)	MB
 Atego	ABS	1517 (98-02)	MB ABS
 Atego	ABS	1518 (98-02)	MB ABS
 Atego	ABS	1518 (99-00)	MB ABS
 Atego	ABS	1518 K (98-02)	MB ABS
 Atego	ABS	1518 K (99-00)	MB ABS
 Atego	ABS	1518 L (98-02)	MB ABS
 Atego	ABS	1518 L (99-00)	MB ABS
 Atego	ABS	1523 (98-02)	MB ABS
 Atego	ABS	1523 (99-00)	MB ABS
 Atego	ABS	1524 Bluetec4 (05-07)	MB

## Systems supported by ECUreader (up to V5.40)

### TRUCKS




























### Mercedes Trucks

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Atego	ABS	1524 Bluetec5 (06-08)	MB
 Atego	ABS	1529 Bluetec4 (05-07)	MB
 Atego	ABS	1529 Bluetec5 (06-08)	MB
 Atego	ABS	1823 (98-02)	MB ABS
 Atego	ABS	1828 (98-02)	MB ABS
 Atego	ABS	2528 (98-02)	MB ABS
 Atego	ABS	2528 (99-00)	MB ABS
 Atego	ABS	715 (98-02)	MB ABS
 Atego	ABS	715 (99-00)	MB ABS
 Atego	ABS	715 L (98-02)	MB ABS
 Atego	ABS	715 L (99-00)	MB ABS
 Atego	ABS	716 Bluetec4 (05-07)	MB
 Atego	ABS	716 Bluetec5 (06-08)	MB
 Atego	ABS	815 (98-02)	MB ABS
 Atego	ABS	815 (99-00)	MB ABS
 Atego	ABS	815 Eco (98-02)	MB ABS
 Atego	ABS	815 Eco (99-00)	MB ABS
 Atego	ABS	815 L (98-02)	MB ABS
 Atego	ABS	815 L (99-00)	MB ABS
 Atego	ABS	816 Bluetec4 (05-07)	MB
 Atego	ABS	816 Bluetec5 (06-08)	MB
 Atego	ABS	818 (98-02)	MB ABS
 Atego	ABS	818 (99-00)	MB ABS
 Atego	ABS	818 Bluetec4 (05-07)	MB
 Atego	ABS	818 Bluetec5 (06-08)	MB
 Atego	ABS	818 K (98-02)	MB ABS
 Atego	ABS	818 K (99-00)	MB ABS

## Systems supported by ECReader (up to V5.40)

### TRUCKS




























### Mercedes Trucks

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Atego	ABS	818 L (98-02)	MB ABS
 Atego	ABS	818 L (99-00)	MB ABS
 Atego	ABS	822 Bluetec4 (05-07)	MB
 Atego	ABS	822 Bluetec5 (06-08)	MB
 Atego	AUTOM. TRANSMISSI	1018 Bluetec4 (05-07)	MB GS AGS
 Atego	AUTOM. TRANSMISSI	1018 Bluetec5 (06-08)	MB AGS 2
 Atego	AUTOM. TRANSMISSI	1022 Bluetec4 (05-07)	MB GS AGS
 Atego	AUTOM. TRANSMISSI	1022 Bluetec5 (06-08)	MB AGS 2
 Atego	AUTOM. TRANSMISSI	1024 Bluetec4 (05-07)	MB GS AGS
 Atego	AUTOM. TRANSMISSI	1024 Bluetec5 (06-08)	MB AGS 2
 Atego	AUTOM. TRANSMISSI	1218 Bluetec4 (05-07)	MB GS AGS
 Atego	AUTOM. TRANSMISSI	1218 Bluetec5 (06-08)	MB AGS 2
 Atego	AUTOM. TRANSMISSI	1222 Bluetec4 (05-07)	MB GS AGS
 Atego	AUTOM. TRANSMISSI	1222 Bluetec5 (06-08)	MB AGS 2
 Atego	AUTOM. TRANSMISSI	1224 Bluetec4 (05-07)	MB GS AGS
 Atego	AUTOM. TRANSMISSI	1224 Bluetec5 (06-08)	MB AGS 2
 Atego	AUTOM. TRANSMISSI	1229 Bluetec4 (05-07)	MB GS AGS
 Atego	AUTOM. TRANSMISSI	1229 Bluetec5 (06-08)	MB AGS 2
 Atego	AUTOM. TRANSMISSI	1324 Bluetec4 (05-07)	MB GS AGS
 Atego	AUTOM. TRANSMISSI	1324 Bluetec5 (06-08)	MB AGS 2
 Atego	AUTOM. TRANSMISSI	1329 Bluetec4 (05-07)	MB GS AGS
 Atego	AUTOM. TRANSMISSI	1329 Bluetec5 (06-08)	MB AGS 2
 Atego	AUTOM. TRANSMISSI	1524 Bluetec4 (05-07)	MB GS AGS
 Atego	AUTOM. TRANSMISSI	1524 Bluetec5 (06-08)	MB AGS 2
 Atego	AUTOM. TRANSMISSI	1529 Bluetec4 (05-07)	MB GS AGS
 Atego	AUTOM. TRANSMISSI	1529 Bluetec5 (06-08)	MB AGS 2
 Atego	AUTOM. TRANSMISSI	716 Bluetec4 (05-07)	MB GS AGS

## Systems supported by ECReader (up to V5.40)

### TRUCKS

### Mercedes Trucks

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Atego	AUTOM. TRANSMISSI	716 Bluetec5 (06-08)	MB AGS 2
 Atego	AUTOM. TRANSMISSI	816 Bluetec4 (05-07)	MB GS AGS
 Atego	AUTOM. TRANSMISSI	816 Bluetec5 (06-08)	MB AGS 2
 Atego	AUTOM. TRANSMISSI	818 Bluetec4 (05-07)	MB GS AGS
 Atego	AUTOM. TRANSMISSI	818 Bluetec5 (06-08)	MB AGS 2
 Atego	AUTOM. TRANSMISSI	822 Bluetec4 (05-07)	MB GS AGS
 Atego	AUTOM. TRANSMISSI	822 Bluetec5 (06-08)	MB AGS 2
 Atego	BRAKE POWER SUP	1018 Bluetec5 (06-08)	MB Intarder FR
 Atego	BRAKE POWER SUP	1022 Bluetec5 (06-08)	MB Intarder FR
 Atego	BRAKE POWER SUP	1024 Bluetec5 (06-08)	MB Intarder FR
 Atego	BRAKE POWER SUP	1218 Bluetec5 (06-08)	MB Intarder FR
 Atego	BRAKE POWER SUP	1222 Bluetec5 (06-08)	MB Intarder FR
 Atego	BRAKE POWER SUP	1224 Bluetec5 (06-08)	MB Intarder FR
 Atego	BRAKE POWER SUP	1229 Bluetec5 (06-08)	MB Intarder FR
 Atego	BRAKE POWER SUP	1324 Bluetec5 (06-08)	MB Intarder FR
 Atego	BRAKE POWER SUP	1329 Bluetec5 (06-08)	MB Intarder FR
 Atego	BRAKE POWER SUP	1524 Bluetec5 (06-08)	MB Intarder FR
 Atego	BRAKE POWER SUP	1529 Bluetec5 (06-08)	MB Intarder FR
 Atego	BRAKE POWER SUP	716 Bluetec5 (06-08)	MB Intarder FR
 Atego	BRAKE POWER SUP	816 Bluetec5 (06-08)	MB Intarder FR
 Atego	BRAKE POWER SUP	818 Bluetec5 (06-08)	MB Intarder FR
 Atego	BRAKE POWER SUP	822 Bluetec5 (06-08)	MB Intarder FR
 Atego	BRAKE SYS. MANAG	1018 (98-02)	MB BS EPB
 Atego	BRAKE SYS. MANAG	1018 AK (98-02)	MB BS EPB
 Atego	BRAKE SYS. MANAG	1018 L (98-02)	MB BS EPB
 Atego	BRAKE SYS. MANAG	1218 (98-02)	MB BS EPB
 Atego	BRAKE SYS. MANAG	1218 K (98-02)	MB BS EPB

## Systems supported by ECReader (up to V5.40)

### TRUCKS




























### Mercedes Trucks

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Atego	BRAKE SYS. MANAG	1218 L (98-02)	MB BS EPB
 Atego	BRAKE SYS. MANAG	1223 (98-02)	MB BS EPB
 Atego	BRAKE SYS. MANAG	1223 L (98-02)	MB BS EPB
 Atego	BRAKE SYS. MANAG	1228 (98-02)	MB BS EPB
 Atego	BRAKE SYS. MANAG	1228 L (98-02)	MB BS EPB
 Atego	BRAKE SYS. MANAG	1518 (98-02)	MB BS EPB
 Atego	BRAKE SYS. MANAG	1518 K (98-02)	MB BS EPB
 Atego	BRAKE SYS. MANAG	1518 L (98-02)	MB BS EPB
 Atego	BRAKE SYS. MANAG	1523 (98-02)	MB BS EPB
 Atego	BRAKE SYS. MANAG	2528 (00-00)	MB BS EPB
 Atego	BRAKE SYS. MANAG	2528 (98-02)	MB BS EPB
 Atego	CENTRAL LOCKING	1018 Bluetec4 (05-07)	MB FFB
 Atego	CENTRAL LOCKING	1018 Bluetec4 (05-07)	MB ZV
 Atego	CENTRAL LOCKING	1018 Bluetec5 (06-08)	MB FFB
 Atego	CENTRAL LOCKING	1018 Bluetec5 (06-08)	MB ZV
 Atego	CENTRAL LOCKING	1022 Bluetec4 (05-07)	MB FFB
 Atego	CENTRAL LOCKING	1022 Bluetec4 (05-07)	MB ZV
 Atego	CENTRAL LOCKING	1022 Bluetec5 (06-08)	MB FFB
 Atego	CENTRAL LOCKING	1022 Bluetec5 (06-08)	MB ZV
 Atego	CENTRAL LOCKING	1024 Bluetec4 (05-07)	MB FFB
 Atego	CENTRAL LOCKING	1024 Bluetec4 (05-07)	MB ZV
 Atego	CENTRAL LOCKING	1024 Bluetec5 (06-08)	MB FFB
 Atego	CENTRAL LOCKING	1024 Bluetec5 (06-08)	MB ZV
 Atego	CENTRAL LOCKING	1218 Bluetec4 (05-07)	MB FFB
 Atego	CENTRAL LOCKING	1218 Bluetec4 (05-07)	MB ZV
 Atego	CENTRAL LOCKING	1218 Bluetec5 (06-08)	MB FFB
 Atego	CENTRAL LOCKING	1218 Bluetec5 (06-08)	MB ZV

## Systems supported by ECReader (up to V5.40)

### TRUCKS




























### Mercedes Trucks

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Atego	CENTRAL LOCKING	1222 Bluetec4 (05-07)	MB FFB
 Atego	CENTRAL LOCKING	1222 Bluetec4 (05-07)	MB ZV
 Atego	CENTRAL LOCKING	1222 Bluetec5 (06-08)	MB FFB
 Atego	CENTRAL LOCKING	1222 Bluetec5 (06-08)	MB ZV
 Atego	CENTRAL LOCKING	1224 Bluetec4 (05-07)	MB FFB
 Atego	CENTRAL LOCKING	1224 Bluetec4 (05-07)	MB ZV
 Atego	CENTRAL LOCKING	1224 Bluetec5 (06-08)	MB FFB
 Atego	CENTRAL LOCKING	1224 Bluetec5 (06-08)	MB ZV
 Atego	CENTRAL LOCKING	1229 Bluetec4 (05-07)	MB FFB
 Atego	CENTRAL LOCKING	1229 Bluetec4 (05-07)	MB ZV
 Atego	CENTRAL LOCKING	1229 Bluetec5 (06-08)	MB FFB
 Atego	CENTRAL LOCKING	1229 Bluetec5 (06-08)	MB ZV
 Atego	CENTRAL LOCKING	1324 Bluetec4 (05-07)	MB FFB
 Atego	CENTRAL LOCKING	1324 Bluetec4 (05-07)	MB ZV
 Atego	CENTRAL LOCKING	1324 Bluetec5 (06-08)	MB FFB
 Atego	CENTRAL LOCKING	1324 Bluetec5 (06-08)	MB ZV
 Atego	CENTRAL LOCKING	1329 Bluetec4 (05-07)	MB FFB
 Atego	CENTRAL LOCKING	1329 Bluetec4 (05-07)	MB ZV
 Atego	CENTRAL LOCKING	1329 Bluetec5 (06-08)	MB FFB
 Atego	CENTRAL LOCKING	1329 Bluetec5 (06-08)	MB ZV
 Atego	CENTRAL LOCKING	1524 Bluetec4 (05-07)	MB FFB
 Atego	CENTRAL LOCKING	1524 Bluetec4 (05-07)	MB ZV
 Atego	CENTRAL LOCKING	1524 Bluetec5 (06-08)	MB FFB
 Atego	CENTRAL LOCKING	1524 Bluetec5 (06-08)	MB ZV
 Atego	CENTRAL LOCKING	1529 Bluetec4 (05-07)	MB FFB
 Atego	CENTRAL LOCKING	1529 Bluetec4 (05-07)	MB ZV
 Atego	CENTRAL LOCKING	1529 Bluetec5 (06-08)	MB FFB

## Systems supported by ECReader (up to V5.40)

### TRUCKS




























### Mercedes Trucks

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Atego	CENTRAL LOCKING	1529 Bluetec5 (06-08)	MB ZV
 Atego	CENTRAL LOCKING	716 Bluetec4 (05-07)	MB FFB
 Atego	CENTRAL LOCKING	716 Bluetec4 (05-07)	MB ZV
 Atego	CENTRAL LOCKING	716 Bluetec5 (06-08)	MB FFB
 Atego	CENTRAL LOCKING	716 Bluetec5 (06-08)	MB ZV
 Atego	CENTRAL LOCKING	816 Bluetec4 (05-07)	MB FFB
 Atego	CENTRAL LOCKING	816 Bluetec4 (05-07)	MB ZV
 Atego	CENTRAL LOCKING	816 Bluetec5 (06-08)	MB FFB
 Atego	CENTRAL LOCKING	816 Bluetec5 (06-08)	MB ZV
 Atego	CENTRAL LOCKING	818 Bluetec4 (05-07)	MB FFB
 Atego	CENTRAL LOCKING	818 Bluetec4 (05-07)	MB ZV
 Atego	CENTRAL LOCKING	818 Bluetec5 (06-08)	MB FFB
 Atego	CENTRAL LOCKING	818 Bluetec5 (06-08)	MB ZV
 Atego	CENTRAL LOCKING	822 Bluetec4 (05-07)	MB FFB
 Atego	CENTRAL LOCKING	822 Bluetec4 (05-07)	MB ZV
 Atego	CENTRAL LOCKING	822 Bluetec5 (06-08)	MB FFB
 Atego	CENTRAL LOCKING	822 Bluetec5 (06-08)	MB ZV
 Atego	CHRONOTACHOGRA	1017 (98-02)	TCO
 Atego	CHRONOTACHOGRA	1018 (98-02)	TCO
 Atego	CHRONOTACHOGRA	1018 Bluetec4 (05-07)	MB DTCO
 Atego	CHRONOTACHOGRA	1018 Bluetec5 (06-08)	Stoneridge Electronics DTCO
 Atego	CHRONOTACHOGRA	1018 K (98-02)	TCO
 Atego	CHRONOTACHOGRA	1018 L (98-02)	TCO
 Atego	CHRONOTACHOGRA	1022 Bluetec4 (05-07)	MB DTCO
 Atego	CHRONOTACHOGRA	1022 Bluetec5 (06-08)	Stoneridge Electronics DTCO
 Atego	CHRONOTACHOGRA	1024 Bluetec4 (05-07)	MB DTCO
 Atego	CHRONOTACHOGRA	1024 Bluetec5 (06-08)	Stoneridge Electronics DTCO

## Systems supported by ECReader (up to V5.40)

### TRUCKS




























### Mercedes Trucks

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Atego	CHRONOTACHOGRA	1217 (98-02)	TCO
 Atego	CHRONOTACHOGRA	1218 (98-02)	TCO
 Atego	CHRONOTACHOGRA	1218 Bluetec4 (05-07)	MB DTCO
 Atego	CHRONOTACHOGRA	1218 Bluetec5 (06-08)	Stoneridge Electronics DTCO
 Atego	CHRONOTACHOGRA	1218 K (98-02)	TCO
 Atego	CHRONOTACHOGRA	1218 L (98-02)	TCO
 Atego	CHRONOTACHOGRA	1222 Bluetec4 (05-07)	MB DTCO
 Atego	CHRONOTACHOGRA	1222 Bluetec5 (06-08)	Stoneridge Electronics DTCO
 Atego	CHRONOTACHOGRA	1223 (98-02)	TCO
 Atego	CHRONOTACHOGRA	1223 K (98-02)	TCO
 Atego	CHRONOTACHOGRA	1223 L (98-02)	TCO
 Atego	CHRONOTACHOGRA	1224 Bluetec4 (05-07)	MB DTCO
 Atego	CHRONOTACHOGRA	1224 Bluetec5 (06-08)	Stoneridge Electronics DTCO
 Atego	CHRONOTACHOGRA	1228 (98-02)	TCO
 Atego	CHRONOTACHOGRA	1228 K (98-02)	TCO
 Atego	CHRONOTACHOGRA	1228 L (98-02)	TCO
 Atego	CHRONOTACHOGRA	1229 Bluetec4 (05-07)	MB DTCO
 Atego	CHRONOTACHOGRA	1229 Bluetec5 (06-08)	Stoneridge Electronics DTCO
 Atego	CHRONOTACHOGRA	1324 Bluetec4 (05-07)	MB DTCO
 Atego	CHRONOTACHOGRA	1324 Bluetec5 (06-08)	Stoneridge Electronics DTCO
 Atego	CHRONOTACHOGRA	1329 Bluetec4 (05-07)	MB DTCO
 Atego	CHRONOTACHOGRA	1329 Bluetec5 (06-08)	Stoneridge Electronics DTCO
 Atego	CHRONOTACHOGRA	1517 (98-02)	TCO
 Atego	CHRONOTACHOGRA	1518 (98-02)	TCO
 Atego	CHRONOTACHOGRA	1518 K (98-02)	TCO
 Atego	CHRONOTACHOGRA	1518 L (98-02)	TCO
 Atego	CHRONOTACHOGRA	1523 (98-02)	TCO

## Systems supported by ECReader (up to V5.40)

### TRUCKS




























### Mercedes Trucks

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Atego	CHRONOTACHOGRA	1523 K (98-02)	TCO
 Atego	CHRONOTACHOGRA	1523 L (98-02)	TCO
 Atego	CHRONOTACHOGRA	1524 Bluetec4 (05-07)	MB DTCO
 Atego	CHRONOTACHOGRA	1524 Bluetec5 (06-08)	Stoneridge Electronics DTCO
 Atego	CHRONOTACHOGRA	1529 Bluetec4 (05-07)	MB DTCO
 Atego	CHRONOTACHOGRA	1529 Bluetec5 (06-08)	Stoneridge Electronics DTCO
 Atego	CHRONOTACHOGRA	1818 (98-02)	TCO
 Atego	CHRONOTACHOGRA	1823 (98-02)	TCO
 Atego	CHRONOTACHOGRA	1828 (98-02)	TCO
 Atego	CHRONOTACHOGRA	715 (98-02)	TCO
 Atego	CHRONOTACHOGRA	715 L (98-02)	TCO
 Atego	CHRONOTACHOGRA	716 Bluetec4 (05-07)	MB DTCO
 Atego	CHRONOTACHOGRA	716 Bluetec5 (06-08)	Stoneridge Electronics DTCO
 Atego	CHRONOTACHOGRA	815 (98-02)	TCO
 Atego	CHRONOTACHOGRA	815 L (98-02)	TCO
 Atego	CHRONOTACHOGRA	816 Bluetec4 (05-07)	MB DTCO
 Atego	CHRONOTACHOGRA	816 Bluetec5 (06-08)	Stoneridge Electronics DTCO
 Atego	CHRONOTACHOGRA	818 (98-02)	TCO
 Atego	CHRONOTACHOGRA	818 Bluetec4 (05-07)	MB DTCO
 Atego	CHRONOTACHOGRA	818 Bluetec5 (06-08)	Stoneridge Electronics DTCO
 Atego	CHRONOTACHOGRA	818 K (98-02)	TCO
 Atego	CHRONOTACHOGRA	818 L (98-02)	TCO
 Atego	CHRONOTACHOGRA	822 Bluetec4 (05-07)	MB DTCO
 Atego	CHRONOTACHOGRA	822 Bluetec5 (06-08)	Stoneridge Electronics DTCO
 Atego	CLIMA	1018 (98-02)	MB HZR
 Atego	CLIMA	1018 AK (98-02)	MB HZR
 Atego	CLIMA	1018 L (98-02)	MB HZR

## Systems supported by ECUreader (up to V5.40)

### TRUCKS

### Mercedes Trucks

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Atego	CLIMA	1218 (98-02)	MB HZR
 Atego	CLIMA	1218 K (98-02)	MB HZR
 Atego	CLIMA	1218 L (98-02)	MB HZR
 Atego	CLIMA	1223 (98-02)	MB HZR
 Atego	CLIMA	1223 L (98-02)	MB HZR
 Atego	CLIMA	1228 (98-02)	MB HZR
 Atego	CLIMA	1228 L (98-02)	MB HZR
 Atego	CLIMA	1518 (98-02)	MB HZR
 Atego	CLIMA	1518 K (98-02)	MB HZR
 Atego	CLIMA	1518 L (98-02)	MB HZR
 Atego	CLIMA	1523 (98-02)	MB HZR
 Atego	CLIMA	2528 (98-02)	MB HZR
 Atego	CLIMA	715 (98-02)	MB HZR
 Atego	CLIMA	715 L (98-02)	MB HZR
 Atego	CLIMA	815 (98-02)	MB HZR
 Atego	CLIMA	815 Eco (98-02)	MB HZR
 Atego	CLIMA	815 L (98-02)	MB HZR
 Atego	CLIMA	818 (98-02)	MB HZR
 Atego	CLIMA	818 K (98-02)	MB HZR
 Atego	CLIMA	818 L (98-02)	MB HZR
 Atego	CRUISE MANAGEME	1017 (98-02)	MB FR FMR
 Atego	CRUISE MANAGEME	1018 (00-00)	MB FR FMR
 Atego	CRUISE MANAGEME	1018 (98-02)	MB FR FMR
 Atego	CRUISE MANAGEME	1018 AK (00-00)	MB FR FMR
 Atego	CRUISE MANAGEME	1018 AK (98-02)	MB FR FMR
 Atego	CRUISE MANAGEME	1018 L (00-00)	MB FR FMR
 Atego	CRUISE MANAGEME	1018 L (98-02)	MB FR FMR

## Systems supported by ECReader (up to V5.40)

### TRUCKS




























### Mercedes Trucks

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Atego	CRUISE MANAGEME	1217 (98-02)	MB FR FMR
 Atego	CRUISE MANAGEME	1218 (00-00)	MB FR FMR
 Atego	CRUISE MANAGEME	1218 (98-02)	MB FR FMR
 Atego	CRUISE MANAGEME	1218 K (00-00)	MB FR FMR
 Atego	CRUISE MANAGEME	1218 K (98-02)	MB FR FMR
 Atego	CRUISE MANAGEME	1218 L (00-00)	MB FR FMR
 Atego	CRUISE MANAGEME	1218 L (98-02)	MB FR FMR
 Atego	CRUISE MANAGEME	1223 (00-00)	MB FR FMR
 Atego	CRUISE MANAGEME	1223 (98-02)	MB FR FMR
 Atego	CRUISE MANAGEME	1223 L (00-00)	MB FR FMR
 Atego	CRUISE MANAGEME	1223 L (98-02)	MB FR FMR
 Atego	CRUISE MANAGEME	1228 (00-00)	MB FR FMR
 Atego	CRUISE MANAGEME	1228 (98-02)	MB FR FMR
 Atego	CRUISE MANAGEME	1228 L (00-00)	MB FR FMR
 Atego	CRUISE MANAGEME	1228 L (98-02)	MB FR FMR
 Atego	CRUISE MANAGEME	1517 (98-02)	MB FR FMR
 Atego	CRUISE MANAGEME	1518 (00-00)	MB FR FMR
 Atego	CRUISE MANAGEME	1518 (98-02)	MB FR FMR
 Atego	CRUISE MANAGEME	1518 K (00-00)	MB FR FMR
 Atego	CRUISE MANAGEME	1518 K (98-02)	MB FR FMR
 Atego	CRUISE MANAGEME	1518 L (00-00)	MB FR FMR
 Atego	CRUISE MANAGEME	1518 L (98-02)	MB FR FMR
 Atego	CRUISE MANAGEME	1523 (00-00)	MB FR FMR
 Atego	CRUISE MANAGEME	1523 (98-02)	MB FR FMR
 Atego	CRUISE MANAGEME	1818 (98-02)	MB FR FMR
 Atego	CRUISE MANAGEME	1823 (98-02)	MB FR FMR
 Atego	CRUISE MANAGEME	1828 (98-02)	MB FR FMR

## Systems supported by ECReader (up to V5.40)

### TRUCKS



























### Mercedes Trucks

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Atego	CRUISE MANAGEME	2528 (00-00)	MB FR FMR
 Atego	CRUISE MANAGEME	2528 (98-02)	MB FR FMR
 Atego	CRUISE MANAGEME	715 (00-00)	MB FR FMR
 Atego	CRUISE MANAGEME	715 (98-02)	MB FR FMR
 Atego	CRUISE MANAGEME	715 L (00-00)	MB FR FMR
 Atego	CRUISE MANAGEME	715 L (98-02)	MB FR FMR
 Atego	CRUISE MANAGEME	815 (00-00)	MB FR FMR
 Atego	CRUISE MANAGEME	815 (98-02)	MB FR FMR
 Atego	CRUISE MANAGEME	815 Eco (00-00)	MB FR FMR
 Atego	CRUISE MANAGEME	815 Eco (98-02)	MB FR FMR
 Atego	CRUISE MANAGEME	815 L (00-00)	MB FR FMR
 Atego	CRUISE MANAGEME	815 L (98-02)	MB FR FMR
 Atego	CRUISE MANAGEME	818 (00-00)	MB FR FMR
 Atego	CRUISE MANAGEME	818 (98-02)	MB FR FMR
 Atego	CRUISE MANAGEME	818 K (00-00)	MB FR FMR
 Atego	CRUISE MANAGEME	818 K (98-02)	MB FR FMR
 Atego	CRUISE MANAGEME	818 L (00-00)	MB FR FMR
 Atego	CRUISE MANAGEME	818 L (98-02)	MB FR FMR
 Atego	DASHBOARD	1017 (98-02)	MB INS Comb. Instrument
 Atego	DASHBOARD	1018 (00-00)	MB INS Comb. Instrument
 Atego	DASHBOARD	1018 (05-07)	MB
 Atego	DASHBOARD	1018 (98-02)	MB INS Comb. Instrument
 Atego	DASHBOARD	1018 AK (00-00)	MB INS Comb. Instrument
 Atego	DASHBOARD	1018 AK (98-02)	MB INS Comb. Instrument
 Atego	DASHBOARD	1018 L (00-00)	MB INS Comb. Instrument
 Atego	DASHBOARD	1018 L (98-02)	MB INS Comb. Instrument
 Atego	DASHBOARD	1022 (05-07)	MB

## Systems supported by ECUREADER (up to V5.40)

### TRUCKS





















### Mercedes Trucks

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Atego	DASHBOARD	1024 (05-07)	MB
 Atego	DASHBOARD	1217 (98-02)	MB INS Comb. Instrument
 Atego	DASHBOARD	1218 (00-00)	MB INS Comb. Instrument
 Atego	DASHBOARD	1218 (05-07)	MB
 Atego	DASHBOARD	1218 (98-02)	MB INS Comb. Instrument
 Atego	DASHBOARD	1218 K (00-00)	MB INS Comb. Instrument
 Atego	DASHBOARD	1218 K (98-02)	MB INS Comb. Instrument
 Atego	DASHBOARD	1218 L (00-00)	MB INS Comb. Instrument
 Atego	DASHBOARD	1218 L (98-02)	MB INS Comb. Instrument
 Atego	DASHBOARD	1222 (05-07)	MB
 Atego	DASHBOARD	1223 (00-00)	MB INS Comb. Instrument
 Atego	DASHBOARD	1223 (98-02)	MB INS Comb. Instrument
 Atego	DASHBOARD	1223 L (00-00)	MB INS Comb. Instrument
 Atego	DASHBOARD	1223 L (98-02)	MB INS Comb. Instrument
 Atego	DASHBOARD	1224 (05-07)	MB
 Atego	DASHBOARD	1228 (00-00)	MB INS Comb. Instrument
 Atego	DASHBOARD	1228 (98-02)	MB INS Comb. Instrument
 Atego	DASHBOARD	1228 L (00-00)	MB INS Comb. Instrument
 Atego	DASHBOARD	1228 L (98-02)	MB INS Comb. Instrument
 Atego	DASHBOARD	1229 (05-07)	MB
 Atego	DASHBOARD	1324 (05-07)	MB
 Atego	DASHBOARD	1329 (05-07)	MB
 Atego	DASHBOARD	1517 (98-02)	MB INS Comb. Instrument
 Atego	DASHBOARD	1518 (00-00)	MB INS Comb. Instrument
 Atego	DASHBOARD	1518 (98-02)	MB INS Comb. Instrument
 Atego	DASHBOARD	1518 K (00-00)	MB INS Comb. Instrument
 Atego	DASHBOARD	1518 K (98-02)	MB INS Comb. Instrument

## Systems supported by ECUREADER (up to V5.40)

### TRUCKS




























### Mercedes Trucks

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Atego	DASHBOARD	1518 L (98-02)	MB INS Comb. Instrument
 Atego	DASHBOARD	1523 (98-02)	MB INS Comb. Instrument
 Atego	DASHBOARD	1524 (05-07)	MB
 Atego	DASHBOARD	1529 (05-07)	MB
 Atego	DASHBOARD	1818 (98-02)	MB INS Comb. Instrument
 Atego	DASHBOARD	1823 (98-02)	MB INS Comb. Instrument
 Atego	DASHBOARD	1828 (98-02)	MB INS Comb. Instrument
 Atego	DASHBOARD	2528 (98-02)	MB INS Comb. Instrument
 Atego	DASHBOARD	715 (98-02)	MB INS Comb. Instrument
 Atego	DASHBOARD	715 L (98-02)	MB INS Comb. Instrument
 Atego	DASHBOARD	716 (05-07)	MB
 Atego	DASHBOARD	815 (98-02)	MB INS Comb. Instrument
 Atego	DASHBOARD	815 Eco (98-02)	MB INS Comb. Instrument
 Atego	DASHBOARD	815 L (98-02)	MB INS Comb. Instrument
 Atego	DASHBOARD	816 (05-07)	MB
 Atego	DASHBOARD	818 (05-07)	MB
 Atego	DASHBOARD	818 (98-02)	MB INS Comb. Instrument
 Atego	DASHBOARD	818 K (98-02)	MB INS Comb. Instrument
 Atego	DASHBOARD	818 L (98-02)	MB INS Comb. Instrument
 Atego	DASHBOARD	822 (05-07)	MB
 Atego	ENGINE MANAGEME	1017 (98-02)	MB MR PLD
 Atego	ENGINE MANAGEME	1018 (00-00)	MB MR PLD
 Atego	ENGINE MANAGEME	1018 (05-07)	MB MR PLD Bluetec 4
 Atego	ENGINE MANAGEME	1018 (98-02)	MB MR PLD
 Atego	ENGINE MANAGEME	1018 AK (00-00)	MB MR PLD
 Atego	ENGINE MANAGEME	1018 AK (98-02)	MB MR PLD
 Atego	ENGINE MANAGEME	1018 Bluetec5 (06-08)	MB MR PLD

## Systems supported by ECReader (up to V5.40)

### TRUCKS




























### Mercedes Trucks

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Atego	ENGINE MANAGEME	1018 L (00-00)	MB MR PLD
 Atego	ENGINE MANAGEME	1018 L (98-02)	MB MR PLD
 Atego	ENGINE MANAGEME	1022 (05-07)	MB MR PLD Bluetec 4
 Atego	ENGINE MANAGEME	1022 Bluetec5 (06-08)	MB MR PLD
 Atego	ENGINE MANAGEME	1024 (05-07)	MB MR PLD Bluetec 4
 Atego	ENGINE MANAGEME	1024 Bluetec5 (06-08)	MB MR PLD
 Atego	ENGINE MANAGEME	1217 (98-02)	MB MR PLD
 Atego	ENGINE MANAGEME	1218 (00-00)	MB MR PLD
 Atego	ENGINE MANAGEME	1218 (05-07)	MB MR PLD Bluetec 4
 Atego	ENGINE MANAGEME	1218 (98-02)	MB MR PLD
 Atego	ENGINE MANAGEME	1218 Bluetec5 (06-08)	MB MR PLD
 Atego	ENGINE MANAGEME	1218 K (00-00)	MB MR PLD
 Atego	ENGINE MANAGEME	1218 K (98-02)	MB MR PLD
 Atego	ENGINE MANAGEME	1218 L (00-00)	MB MR PLD
 Atego	ENGINE MANAGEME	1218 L (98-02)	MB MR PLD
 Atego	ENGINE MANAGEME	1222 (05-07)	MB MR PLD Bluetec 4
 Atego	ENGINE MANAGEME	1222 Bluetec5 (06-08)	MB MR PLD
 Atego	ENGINE MANAGEME	1223 (00-00)	MB MR PLD
 Atego	ENGINE MANAGEME	1223 (98-02)	MB MR PLD
 Atego	ENGINE MANAGEME	1223 L (00-00)	MB MR PLD
 Atego	ENGINE MANAGEME	1223 L (98-02)	MB MR PLD
 Atego	ENGINE MANAGEME	1224 (05-07)	MB MR PLD Bluetec 4
 Atego	ENGINE MANAGEME	1224 Bluetec5 (06-08)	MB MR PLD
 Atego	ENGINE MANAGEME	1228 (00-00)	MB MR PLD
 Atego	ENGINE MANAGEME	1228 (98-02)	MB MR PLD
 Atego	ENGINE MANAGEME	1228 L (00-00)	MB MR PLD
 Atego	ENGINE MANAGEME	1228 L (98-02)	MB MR PLD

## Systems supported by ECReader (up to V5.40)

### TRUCKS




























### Mercedes Trucks

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Atego	ENGINE MANAGEME	1229 (05-07)	MB MR PLD Bluetec 4
 Atego	ENGINE MANAGEME	1229 Bluetec5 (06-08)	MB MR PLD
 Atego	ENGINE MANAGEME	1324 (05-07)	MB MR PLD Bluetec 4
 Atego	ENGINE MANAGEME	1324 Bluetec5 (06-08)	MB MR PLD
 Atego	ENGINE MANAGEME	1329 (05-07)	MB MR PLD Bluetec 4
 Atego	ENGINE MANAGEME	1329 Bluetec5 (06-08)	MB MR PLD
 Atego	ENGINE MANAGEME	1517 (98-02)	MB MR PLD
 Atego	ENGINE MANAGEME	1518 (00-00)	MB MR PLD
 Atego	ENGINE MANAGEME	1518 (98-02)	MB MR PLD
 Atego	ENGINE MANAGEME	1518 K (00-00)	MB MR PLD
 Atego	ENGINE MANAGEME	1518 K (98-02)	MB MR PLD
 Atego	ENGINE MANAGEME	1518 L (00-00)	MB MR PLD
 Atego	ENGINE MANAGEME	1518 L (98-02)	MB MR PLD
 Atego	ENGINE MANAGEME	1523 (00-00)	MB MR PLD
 Atego	ENGINE MANAGEME	1523 (98-02)	MB MR PLD
 Atego	ENGINE MANAGEME	1524 (05-07)	MB MR PLD Bluetec 4
 Atego	ENGINE MANAGEME	1524 Bluetec5 (06-08)	MB MR PLD
 Atego	ENGINE MANAGEME	1529 (05-07)	MB MR PLD Bluetec 4
 Atego	ENGINE MANAGEME	1529 Bluetec5 (06-08)	MB MR PLD
 Atego	ENGINE MANAGEME	1818 (98-02)	MB MR PLD
 Atego	ENGINE MANAGEME	1823 (98-02)	MB MR PLD
 Atego	ENGINE MANAGEME	1828 (98-02)	MB MR PLD
 Atego	ENGINE MANAGEME	2528 (00-00)	MB MR PLD
 Atego	ENGINE MANAGEME	2528 (98-02)	MB MR PLD
 Atego	ENGINE MANAGEME	715 (00-00)	MB MR PLD
 Atego	ENGINE MANAGEME	715 (98-02)	MB MR PLD
 Atego	ENGINE MANAGEME	715 L (00-00)	MB MR PLD

## Systems supported by ECReader (up to V5.40)

### TRUCKS


### Mercedes Trucks

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Atego	ENGINE MANAGEME	715 L (98-02)	MB MR PLD
 Atego	ENGINE MANAGEME	716 (05-07)	MB MR PLD Bluetec 4
 Atego	ENGINE MANAGEME	716 Bluetec5 (06-08)	MB MR PLD
 Atego	ENGINE MANAGEME	815 (00-00)	MB MR PLD
 Atego	ENGINE MANAGEME	815 (98-02)	MB MR PLD
 Atego	ENGINE MANAGEME	815 Eco (00-00)	MB MR PLD
 Atego	ENGINE MANAGEME	815 Eco (98-02)	MB MR PLD
 Atego	ENGINE MANAGEME	815 L (00-00)	MB MR PLD
 Atego	ENGINE MANAGEME	815 L (98-02)	MB MR PLD
 Atego	ENGINE MANAGEME	816 (05-07)	MB MR PLD Bluetec 4
 Atego	ENGINE MANAGEME	816 Bluetec5 (06-08)	MB MR PLD
 Atego	ENGINE MANAGEME	818 (00-00)	MB MR PLD
 Atego	ENGINE MANAGEME	818 (05-07)	MB MR PLD Bluetec 4
 Atego	ENGINE MANAGEME	818 (98-02)	MB MR PLD
 Atego	ENGINE MANAGEME	818 Bluetec5 (06-08)	MB MR PLD
 Atego	ENGINE MANAGEME	818 K (00-00)	MB MR PLD
 Atego	ENGINE MANAGEME	818 K (98-02)	MB MR PLD
 Atego	ENGINE MANAGEME	818 L (00-00)	MB MR PLD
 Atego	ENGINE MANAGEME	818 L (98-02)	MB MR PLD
 Atego	ENGINE MANAGEME	822 (05-07)	MB MR PLD Bluetec 4
 Atego	ENGINE MANAGEME	822 Bluetec5 (06-08)	MB MR PLD
 Atego	GEARBOX MANAGEM	1018 Bluetec5 (06-08)	MB HPS
 Atego	GEARBOX MANAGEM	1022 Bluetec5 (06-08)	MB HPS
 Atego	GEARBOX MANAGEM	1024 Bluetec5 (06-08)	MB HPS
 Atego	GEARBOX MANAGEM	1218 Bluetec5 (06-08)	MB HPS
 Atego	GEARBOX MANAGEM	1222 Bluetec5 (06-08)	MB HPS
 Atego	GEARBOX MANAGEM	1224 Bluetec5 (06-08)	MB HPS

## Systems supported by ECReader (up to V5.40)

### TRUCKS




























### Mercedes Trucks

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Atego	GEARBOX MANAGEM	1229 Bluetec5 (06-08)	MB HPS
 Atego	GEARBOX MANAGEM	1324 Bluetec5 (06-08)	MB HPS
 Atego	GEARBOX MANAGEM	1329 Bluetec5 (06-08)	MB HPS
 Atego	GEARBOX MANAGEM	1524 Bluetec5 (06-08)	MB HPS
 Atego	GEARBOX MANAGEM	1529 Bluetec5 (06-08)	MB HPS
 Atego	GEARBOX MANAGEM	716 Bluetec5 (06-08)	MB HPS
 Atego	GEARBOX MANAGEM	816 Bluetec5 (06-08)	MB HPS
 Atego	GEARBOX MANAGEM	818 Bluetec5 (06-08)	MB HPS
 Atego	GEARBOX MANAGEM	822 Bluetec5 (06-08)	MB HPS
 Atego	MAINTENANCE SYST	1017 (98-02)	WS FSS
 Atego	MAINTENANCE SYST	1018 (98-02)	MB WS FSS
 Atego	MAINTENANCE SYST	1018 (98-02)	WS FSS
 Atego	MAINTENANCE SYST	1018 AK (98-02)	MB WS FSS
 Atego	MAINTENANCE SYST	1018 K (98-02)	WS FSS
 Atego	MAINTENANCE SYST	1018 L (98-02)	MB WS FSS
 Atego	MAINTENANCE SYST	1018 L (98-02)	WS FSS
 Atego	MAINTENANCE SYST	1217 (98-02)	WS FSS
 Atego	MAINTENANCE SYST	1218 (98-02)	MB WS FSS
 Atego	MAINTENANCE SYST	1218 (98-02)	WS FSS
 Atego	MAINTENANCE SYST	1218 K (98-02)	MB WS FSS
 Atego	MAINTENANCE SYST	1218 K (98-02)	WS FSS
 Atego	MAINTENANCE SYST	1218 L (98-02)	MB WS FSS
 Atego	MAINTENANCE SYST	1218 L (98-02)	WS FSS
 Atego	MAINTENANCE SYST	1223 (98-02)	MB WS FSS
 Atego	MAINTENANCE SYST	1223 (98-02)	WS FSS
 Atego	MAINTENANCE SYST	1223 K (98-02)	WS FSS
 Atego	MAINTENANCE SYST	1223 L (98-02)	MB WS FSS

## Systems supported by ECReader (up to V5.40)

### TRUCKS




























### Mercedes Trucks

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Atego	MAINTENANCE SYST	1223 L (98-02)	WS FSS
 Atego	MAINTENANCE SYST	1228 (98-02)	MB WS FSS
 Atego	MAINTENANCE SYST	1228 (98-02)	WS FSS
 Atego	MAINTENANCE SYST	1228 K (98-02)	WS FSS
 Atego	MAINTENANCE SYST	1228 L (98-02)	MB WS FSS
 Atego	MAINTENANCE SYST	1228 L (98-02)	WS FSS
 Atego	MAINTENANCE SYST	1517 (98-02)	WS FSS
 Atego	MAINTENANCE SYST	1518 (98-02)	MB WS FSS
 Atego	MAINTENANCE SYST	1518 (98-02)	WS FSS
 Atego	MAINTENANCE SYST	1518 K (98-02)	MB WS FSS
 Atego	MAINTENANCE SYST	1518 K (98-02)	WS FSS
 Atego	MAINTENANCE SYST	1518 L (98-02)	MB WS FSS
 Atego	MAINTENANCE SYST	1518 L (98-02)	WS FSS
 Atego	MAINTENANCE SYST	1523 (98-02)	MB WS FSS
 Atego	MAINTENANCE SYST	1523 (98-02)	WS FSS
 Atego	MAINTENANCE SYST	1523 K (98-02)	WS FSS
 Atego	MAINTENANCE SYST	1523 L (98-02)	WS FSS
 Atego	MAINTENANCE SYST	1818 (98-02)	WS FSS
 Atego	MAINTENANCE SYST	1823 (98-02)	WS FSS
 Atego	MAINTENANCE SYST	1828 (98-02)	WS FSS
 Atego	MAINTENANCE SYST	715 (98-02)	MB WS FSS
 Atego	MAINTENANCE SYST	715 (98-02)	WS FSS
 Atego	MAINTENANCE SYST	715 L (98-02)	MB WS FSS
 Atego	MAINTENANCE SYST	715 L (98-02)	WS FSS
 Atego	MAINTENANCE SYST	815 (98-02)	MB WS FSS
 Atego	MAINTENANCE SYST	815 (98-02)	WS FSS
 Atego	MAINTENANCE SYST	815 Eco (98-02)	MB WS FSS

## Systems supported by ECReader (up to V5.40)

### TRUCKS




























### Mercedes Trucks

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Atego	MAINTENANCE SYST	815 L (98-02)	MB WS FSS
 Atego	MAINTENANCE SYST	815 L (98-02)	WS FSS
 Atego	MAINTENANCE SYST	818 (98-02)	MB WS FSS
 Atego	MAINTENANCE SYST	818 (98-02)	WS FSS
 Atego	MAINTENANCE SYST	818 K (98-02)	MB WS FSS
 Atego	MAINTENANCE SYST	818 K (98-02)	WS FSS
 Atego	MAINTENANCE SYST	818 L (98-02)	MB WS FSS
 Atego	MAINTENANCE SYST	818 L (98-02)	WS FSS
 Atego	SUSPENSION CONTR	1017 (98-02)	WABCO NR ECAS
 Atego	SUSPENSION CONTR	1018 (98-02)	WABCO NR ECAS
 Atego	SUSPENSION CONTR	1018 AK (98-02)	WABCO NR ECAS
 Atego	SUSPENSION CONTR	1018 Bluetec4 (05-07)	MB
 Atego	SUSPENSION CONTR	1018 Bluetec5 (06-08)	MB NR
 Atego	SUSPENSION CONTR	1018 L (98-02)	WABCO NR ECAS
 Atego	SUSPENSION CONTR	1022 Bluetec4 (05-07)	MB
 Atego	SUSPENSION CONTR	1022 Bluetec5 (06-08)	MB NR
 Atego	SUSPENSION CONTR	1024 Bluetec4 (05-07)	MB
 Atego	SUSPENSION CONTR	1024 Bluetec5 (06-08)	MB NR
 Atego	SUSPENSION CONTR	1217 (98-02)	WABCO NR ECAS
 Atego	SUSPENSION CONTR	1218 (98-02)	WABCO NR ECAS
 Atego	SUSPENSION CONTR	1218 Bluetec4 (05-07)	MB
 Atego	SUSPENSION CONTR	1218 Bluetec5 (06-08)	MB NR
 Atego	SUSPENSION CONTR	1218 K (98-02)	WABCO NR ECAS
 Atego	SUSPENSION CONTR	1218 L (98-02)	WABCO NR ECAS
 Atego	SUSPENSION CONTR	1222 Bluetec4 (05-07)	MB
 Atego	SUSPENSION CONTR	1222 Bluetec5 (06-08)	MB NR
 Atego	SUSPENSION CONTR	1223 (98-02)	WABCO NR ECAS

## Systems supported by ECReader (up to V5.40)

### TRUCKS



























### Mercedes Trucks

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Atego	SUSPENSION CONTR	1223 L (98-02)	WABCO NR ECAS
 Atego	SUSPENSION CONTR	1224 Bluetec4 (05-07)	MB
 Atego	SUSPENSION CONTR	1224 Bluetec5 (06-08)	MB NR
 Atego	SUSPENSION CONTR	1228 (98-02)	WABCO NR ECAS
 Atego	SUSPENSION CONTR	1228 L (98-02)	WABCO NR ECAS
 Atego	SUSPENSION CONTR	1229 Bluetec4 (05-07)	MB
 Atego	SUSPENSION CONTR	1229 Bluetec5 (06-08)	MB NR
 Atego	SUSPENSION CONTR	1324 Bluetec4 (05-07)	MB
 Atego	SUSPENSION CONTR	1324 Bluetec5 (06-08)	MB NR
 Atego	SUSPENSION CONTR	1329 Bluetec4 (05-07)	MB
 Atego	SUSPENSION CONTR	1329 Bluetec5 (06-08)	MB NR
 Atego	SUSPENSION CONTR	1517 (98-02)	WABCO NR ECAS
 Atego	SUSPENSION CONTR	1518 (98-02)	WABCO NR ECAS
 Atego	SUSPENSION CONTR	1518 K (98-02)	WABCO NR ECAS
 Atego	SUSPENSION CONTR	1518 L (98-02)	WABCO NR ECAS
 Atego	SUSPENSION CONTR	1523 (98-02)	WABCO NR ECAS
 Atego	SUSPENSION CONTR	1524 Bluetec4 (05-07)	MB
 Atego	SUSPENSION CONTR	1524 Bluetec5 (06-08)	MB NR
 Atego	SUSPENSION CONTR	1529 Bluetec4 (05-07)	MB
 Atego	SUSPENSION CONTR	1529 Bluetec5 (06-08)	MB NR
 Atego	SUSPENSION CONTR	1818 (98-02)	WABCO NR ECAS
 Atego	SUSPENSION CONTR	1823 (98-02)	WABCO NR ECAS
 Atego	SUSPENSION CONTR	1828 (98-02)	WABCO NR ECAS
 Atego	SUSPENSION CONTR	2528 (98-02)	WABCO NR ECAS
 Atego	SUSPENSION CONTR	715 (98-02)	WABCO NR ECAS
 Atego	SUSPENSION CONTR	715 L (98-02)	WABCO NR ECAS
 Atego	SUSPENSION CONTR	716 Bluetec4 (05-07)	MB

## Systems supported by ECUreader (up to V5.40)

### TRUCKS




























### Mercedes Trucks

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Atego	SUSPENSION CONTR	716 Bluetec5 (06-08)	MB NR
 Atego	SUSPENSION CONTR	815 (98-02)	WABCO NR ECAS
 Atego	SUSPENSION CONTR	815 Eco (98-02)	WABCO NR ECAS
 Atego	SUSPENSION CONTR	815 L (98-02)	WABCO NR ECAS
 Atego	SUSPENSION CONTR	816 Bluetec4 (05-07)	MB
 Atego	SUSPENSION CONTR	816 Bluetec5 (06-08)	MB NR
 Atego	SUSPENSION CONTR	818 (98-02)	WABCO NR ECAS
 Atego	SUSPENSION CONTR	818 Bluetec4 (05-07)	MB
 Atego	SUSPENSION CONTR	818 Bluetec5 (06-08)	MB NR
 Atego	SUSPENSION CONTR	818 K (98-02)	WABCO NR ECAS
 Atego	SUSPENSION CONTR	818 L (98-02)	WABCO NR ECAS
 Atego	SUSPENSION CONTR	822 Bluetec4 (05-07)	MB
 Atego	SUSPENSION CONTR	822 Bluetec5 (06-08)	MB NR
 Axor SKN/C	ENGINE MANAGEME	1835 LS (...-02)	MR PLD
 Axor SKN/C	ENGINE MANAGEME	1840 LS (...-02)	MR PLD
 Axor SKN/C	ENGINE MANAGEME	1843 LS (...-02)	MR PLD
 Axor SKT	CRUISE MANAGEME	1835 LS (...-99)	FR FMR
 Axor SKT	CRUISE MANAGEME	1835 LS (00-02)	FR FMR
 Axor SKT	CRUISE MANAGEME	1840 LS (...-99)	FR FMR
 Axor SKT	CRUISE MANAGEME	1840 LS (00-02)	FR FMR
 Axor SKT	CRUISE MANAGEME	1843 LS (...-99)	FR FMR
 Axor SKT	CRUISE MANAGEME	1843 LS (00-02)	FR FMR
 Axor SKT	ENGINE MANAGEME	1835 LS (...-02)	MR PLD
 Axor SKT	ENGINE MANAGEME	1840 LS (...-02)	MR PLD
 Axor SKT	ENGINE MANAGEME	1843 LS (...-02)	MR PLD
 Axor	ABS	1829 (05-07)	MB

## Systems supported by ECUREADER (up to V5.40)

### TRUCKS




























### Mercedes Trucks

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Axor	ABS	1833 (05-07)	MB
 Axor	ABS	1840 (05-07)	MB
 Axor	ABS	1843 (05-07)	MB
 Axor	ABS	2529 (05-07)	MB
 Axor	ABS	2533 (05-07)	MB
 Axor	ABS	2536 (05-07)	MB
 Axor	ABS	2540 (05-07)	MB
 Axor	ABS	2543 (05-07)	MB
 Axor	AUTOM. TRANSMISSI	1829 (05-07)	MB GS
 Axor	AUTOM. TRANSMISSI	1833 (05-07)	MB GS
 Axor	AUTOM. TRANSMISSI	1840 (05-07)	MB GS
 Axor	AUTOM. TRANSMISSI	1843 (05-07)	MB GS
 Axor	AUTOM. TRANSMISSI	2529 (05-07)	MB GS
 Axor	AUTOM. TRANSMISSI	2533 (05-07)	MB GS
 Axor	AUTOM. TRANSMISSI	2536 (05-07)	MB GS
 Axor	AUTOM. TRANSMISSI	2540 (05-07)	MB GS
 Axor	AUTOM. TRANSMISSI	2543 (05-07)	MB GS
 Axor	BRAKE POWER SUP	1829 (05-07)	MB Intarder FR
 Axor	BRAKE POWER SUP	1829 (05-07)	MB Retarder RS
 Axor	BRAKE POWER SUP	1833 (05-07)	MB Intarder FR
 Axor	BRAKE POWER SUP	1833 (05-07)	MB Retarder RS
 Axor	BRAKE POWER SUP	1840 (05-07)	MB Intarder FR
 Axor	BRAKE POWER SUP	1840 (05-07)	MB Retarder RS
 Axor	BRAKE POWER SUP	1843 (05-07)	MB Intarder FR
 Axor	BRAKE POWER SUP	1843 (05-07)	MB Retarder RS
 Axor	BRAKE POWER SUP	2529 (05-07)	MB Intarder FR
 Axor	BRAKE POWER SUP	2529 (05-07)	MB Retarder RS

## Systems supported by ECUreader (up to V5.40)

### TRUCKS



























### Mercedes Trucks

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Axor	BRAKE POWER SUP	2533 (05-07)	MB Intarder FR
 Axor	BRAKE POWER SUP	2533 (05-07)	MB Retarder RS
 Axor	BRAKE POWER SUP	2536 (05-07)	MB Intarder FR
 Axor	BRAKE POWER SUP	2536 (05-07)	MB Retarder RS
 Axor	BRAKE POWER SUP	2540 (05-07)	MB Intarder FR
 Axor	BRAKE POWER SUP	2540 (05-07)	MB Retarder RS
 Axor	BRAKE POWER SUP	2543 (05-07)	MB Intarder FR
 Axor	BRAKE POWER SUP	2543 (05-07)	MB Retarder RS
 Axor	CHRONOTACHOGRA	1829 (05-07)	MB DTCO Tachpgraph
 Axor	CHRONOTACHOGRA	1833 (05-07)	MB DTCO Tachpgraph
 Axor	CHRONOTACHOGRA	1840 (05-07)	MB DTCO Tachpgraph
 Axor	CHRONOTACHOGRA	1843 (05-07)	MB DTCO Tachpgraph
 Axor	CHRONOTACHOGRA	2529 (05-07)	MB DTCO Tachpgraph
 Axor	CHRONOTACHOGRA	2533 (05-07)	MB DTCO Tachpgraph
 Axor	CHRONOTACHOGRA	2536 (05-07)	MB DTCO Tachpgraph
 Axor	CHRONOTACHOGRA	2540 (05-07)	MB DTCO Tachpgraph
 Axor	CHRONOTACHOGRA	2543 (05-07)	MB DTCO Tachpgraph
 Axor	DASHBOARD	1829 (05-07)	MB
 Axor	DASHBOARD	1833 (05-07)	MB
 Axor	DASHBOARD	1840 (05-07)	MB
 Axor	DASHBOARD	1843 (05-07)	MB
 Axor	DASHBOARD	2529 (05-07)	MB
 Axor	DASHBOARD	2533 (05-07)	MB
 Axor	DASHBOARD	2536 (05-07)	MB
 Axor	DASHBOARD	2540 (05-07)	MB
 Axor	DASHBOARD	2543 (05-07)	MB
 Axor	ENGINE MANAGEME	1829 bluetec4 (05-07)	MB

## Systems supported by ECReader (up to V5.40)

### TRUCKS




























### Mercedes Trucks

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Axor	ENGINE MANAGEME	1829 bluetec5 (06-08)	MB
 Axor	ENGINE MANAGEME	1833 bluetec4 (05-07)	MB
 Axor	ENGINE MANAGEME	1833 bluetec5 (06-08)	MB
 Axor	ENGINE MANAGEME	1840 bluetec4 (05-07)	MB
 Axor	ENGINE MANAGEME	1840 bluetec5 (06-08)	MB
 Axor	ENGINE MANAGEME	1843 bluetec4 (05-07)	MB
 Axor	ENGINE MANAGEME	1843 bluetec5 (06-08)	MB
 Axor	ENGINE MANAGEME	2529 bluetec4 (05-07)	MB
 Axor	ENGINE MANAGEME	2529 bluetec5 (06-08)	MB
 Axor	ENGINE MANAGEME	2533 bluetec4 (05-07)	MB
 Axor	ENGINE MANAGEME	2533 bluetec5 (06-08)	MB
 Axor	ENGINE MANAGEME	2536 bluetec4 (05-07)	MB
 Axor	ENGINE MANAGEME	2536 bluetec5 (06-08)	MB
 Axor	ENGINE MANAGEME	2540 bluetec4 (05-07)	MB
 Axor	ENGINE MANAGEME	2540 bluetec5 (06-08)	MB
 Axor	ENGINE MANAGEME	2543 bluetec4 (05-07)	MB
 Axor	ENGINE MANAGEME	2543 bluetec5 (06-08)	MB
 Axor	SUSPENSION CONTR	1829 (05-07)	MB NR ECAS
 Axor	SUSPENSION CONTR	1833 (05-07)	MB NR ECAS
 Axor	SUSPENSION CONTR	1840 (05-07)	MB NR ECAS
 Axor	SUSPENSION CONTR	1843 (05-07)	MB NR ECAS
 Axor	SUSPENSION CONTR	2529 (05-07)	MB NR ECAS
 Axor	SUSPENSION CONTR	2533 (05-07)	MB NR ECAS
 Axor	SUSPENSION CONTR	2536 (05-07)	MB NR ECAS
 Axor	SUSPENSION CONTR	2540 (05-07)	MB NR ECAS
 Axor	SUSPENSION CONTR	2543 (05-07)	MB NR ECAS

## Systems supported by ECReader (up to V5.40)

### TRUCKS





















### Mercedes Trucks

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Econic	ABS	1824 LL (05-07)	MB
 Econic	ABS	1829 LL (05-07)	MB
 Econic	ABS	1833 LL (05-07)	MB
 Econic	ABS	2629 LL (05-07)	MB
 Econic	ABS	2633 LL (05-07)	MB
 Econic	BRAKE POWER SUP	1824 LL (05-07)	MB Intarder FR
 Econic	BRAKE POWER SUP	1829 LL (05-07)	MB Intarder FR
 Econic	BRAKE POWER SUP	1833 LL (05-07)	MB Intarder FR
 Econic	BRAKE POWER SUP	2629 LL (05-07)	MB Intarder FR
 Econic	BRAKE POWER SUP	2633 LL (05-07)	MB Intarder FR
 Econic	DASHBOARD	1824 LL (05-07)	MB INS
 Econic	DASHBOARD	1829 LL (05-07)	MB INS
 Econic	DASHBOARD	1833 LL (05-07)	MB INS
 Econic	DASHBOARD	2629 LL (05-07)	MB INS
 Econic	DASHBOARD	2633 LL (05-07)	MB INS
 Econic	ENGINE MANAGEME	1823 LL (00-02)	MR PLD
 Econic	ENGINE MANAGEME	1824 LL (05-07)	MB
 Econic	ENGINE MANAGEME	1828 LL (00-02)	MR PLD
 Econic	ENGINE MANAGEME	1829 LL (05-07)	MB
 Econic	ENGINE MANAGEME	1833 LL (05-07)	MB
 Econic	ENGINE MANAGEME	2628 LLc (00-02)	MR PLD
 Econic	ENGINE MANAGEME	2628 LLp (00-02)	MR PLD
 Econic	ENGINE MANAGEME	2629 LL (05-07)	MB
 Econic	ENGINE MANAGEME	2633 LL (05-07)	MB
 Econic	MAINTENANCE SYST	1824 LL (05-07)	MB WS
 Econic	MAINTENANCE SYST	1829 LL (05-07)	MB WS
 Econic	MAINTENANCE SYST	1833 LL (05-07)	MB WS

## Systems supported by ECReader (up to V5.40)

### TRUCKS



### Mercedes Trucks

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Econic	MAINTENANCE SYST	2629 LL (05-07)	MB WS
 Econic	MAINTENANCE SYST	2633 LL (05-07)	MB WS
 Econic	SUSPENSION CONTR	1824 LL (05-07)	MB NR
 Econic	SUSPENSION CONTR	1829 LL (05-07)	MB NR
 Econic	SUSPENSION CONTR	1833 LL (05-07)	MB NR
 Econic	SUSPENSION CONTR	2629 LL (05-07)	MB NR
 Econic	SUSPENSION CONTR	2633 LL (05-07)	MB NR
 Unimog	ENGINE MANAGEME	(..-02)	BOSCH EVE
 Vario	ABS	614 D	MB ABS
 Vario	ABS	714 D	MB ABS
 Vario	ABS	815 D	MB ABS
 Vario	ABS	818 D	MB ABS
 Vario	ABS	O 815	MB ABS
 Vario	ABS	O 818	MB ABS
 Vario	DASHBOARD	614 D	MB INS
 Vario	DASHBOARD	714 D	MB INS
 Vario	DASHBOARD	815 D	MB INS
 Vario	DASHBOARD	818 D	MB INS
 Vario	DASHBOARD	O 815	MB INS
 Vario	DASHBOARD	O 818	MB INS

## Systems supported by ECUREADER (up to V5.40)

### TRUCKS



Mergul

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Trailers	BRAKE SYS. MANAG	Trailers	Wabco Trailer EBS
 Trailers	BRAKE SYS. MANAG	Trailers	Wabco Trailer VCS II

## Systems supported by ECUreader (up to V5.40)

### TRUCKS



Mirofret

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Trailers	BRAKE SYS. MANAG	Trailers	Wabco Trailer EBS
 Trailers	BRAKE SYS. MANAG	Trailers	Wabco Trailer VCS II

## Systems supported by ECUREADER (up to V5.40)

### TRUCKS






Montalban

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Trailers	BRAKE SYS. MANAG	Trailers	Wabco Trailer EBS
 Trailers	BRAKE SYS. MANAG	Trailers	Wabco Trailer VCS II

## Systems supported by ECUreader (up to V5.40)

### TRUCKS



### Montenegro

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Trailers	BRAKE SYS. MANAG	Trailers	Wabco Trailer EBS
 Trailers	BRAKE SYS. MANAG	Trailers	Wabco Trailer VCS II
 Trailers	BRAKE SYS. MANAG	Trailers	Wabco Trailers EBS kw2000
 Trailers	BRAKE SYS. MANAG	Trailers Haldex	Haldex EBS EB+
 Trailers	BRAKE SYS. MANAG	Trailers Knorr	Knorr Trailer EBS

## Systems supported by ECUREADER (up to V5.40)

### TRUCKS



Montull

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Trailers	BRAKE SYS. MANAG	Trailers	Wabco Trailer EBS
 Trailers	BRAKE SYS. MANAG	Trailers	Wabco Trailer VCS II

## Systems supported by ECUREADER (up to V5.40)

### TRUCKS






Multicar

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 M26	ENGINE MANAGEME	8140	BOSCH EDC MS 6.3 CR
 M30	ENGINE MANAGEME	8140	BOSCH EDC MS 6.3 CR

## Systems supported by ECUreader (up to V5.40)

### TRUCKS



### Multitrailer

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Trailers	BRAKE SYS. MANAG	Trailers	Wabco Trailer EBS
 Trailers	BRAKE SYS. MANAG	Trailers	Wabco Trailer VCS II
 Trailers	BRAKE SYS. MANAG	Trailers	Wabco Trailers EBS kw2000
 Trailers	BRAKE SYS. MANAG	Trailers Haldex	Haldex EBS EB+
 Trailers	BRAKE SYS. MANAG	Trailers Knorr	Knorr Trailer EBS

## Systems supported by ECUreader (up to V5.40)

### TRUCKS






Mursem

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Trailers	BRAKE SYS. MANAG	Trailers	Wabco Trailer EBS
 Trailers	BRAKE SYS. MANAG	Trailers	Wabco Trailer VCS II

## Systems supported by ECUreader (up to V5.40)

### TRUCKS















Nardi

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Trailers	BRAKE SYS. MANAG	Trailers	Wabco Trailer EBS
 Trailers	BRAKE SYS. MANAG	Trailers	Wabco Trailer VCS II
 Trailers	BRAKE SYS. MANAG	Trailers	Wabco Trailers EBS kw2000
 Trailers	BRAKE SYS. MANAG	Trailers Haldex	Haldex EBS EB+
 Trailers	BRAKE SYS. MANAG	Trailers Knorr	Knorr Trailer EBS

## Systems supported by ECReader (up to V5.40)

### TRUCKS






**Nissan**

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Atleon	ENGINE MANAGEME	3.0 TD	BOSCH EDC MSA 15
 Atleon	IMMOBILIZER	3.0 TD	NATS
 Cabstar	ENGINE MANAGEME	3.0 TD	BOSCH EDC MSA 15
 Cabstar	IMMOBILIZER	3.0 TD	NATS
 Navara	ABS + TRACT. CONT	2.5 Dci (04-..)	DENSO ABS
 Navara	AIRBAG	2.5 Dci (04-..)	DENSO AirBag
 Navara	ENGINE MANAGEME	2.4 88kW (01-..)	EOBD
 Navara	ENGINE MANAGEME	2.5 D (04-..)	EOBD
 Navara	ENGINE MANAGEME	2.5 Dci (04-..)	EDC
 Navara	ENGINE MANAGEME	2.5 TD (04-..)	EOBD
 Pick-Up	ENGINE MANAGEME	2.4 88kW (01-..)	EOBD
 Pick-Up	ENGINE MANAGEME	2.5 D (04-..)	EOBD
 Pick-Up	ENGINE MANAGEME	2.5 TD (01-..)	EOBD
 Primastar	ENGINE MANAGEME	1.9 dCi F9Q	BOSCH EDC 15 C3 Common Rail

## Systems supported by ECUreader (up to V5.40)

### TRUCKS




























O.M.E.P.S.

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Trailers	BRAKE SYS. MANAG	Trailers	Wabco Trailer EBS
 Trailers	BRAKE SYS. MANAG	Trailers	Wabco Trailer VCS II
 Trailers	BRAKE SYS. MANAG	Trailers	Wabco Trailers EBS kw2000
 Trailers	BRAKE SYS. MANAG	Trailers Haldex	Haldex EBS EB+
 Trailers	BRAKE SYS. MANAG	Trailers Knorr	Knorr Trailer EBS

## Systems supported by ECReader (up to V5.40)

### TRUCKS























Opel

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Combo	ABS	1.3 CDTI (...03)	BOSCH ABS 5.3/5.4(+TC)
 Combo	ABS	1.3 CDTI (04-..)	BOSCH ABS 8
 Combo	ABS	1.4 (...03)	BOSCH ABS 5.3/5.4(+TC)
 Combo	ABS	1.4 (04-..)	BOSCH ABS 8
 Combo	ABS	1.7 DTL (...03)	BOSCH ABS 5.3/5.4(+TC)
 Combo	ABS	1.7 DTL (04-..)	BOSCH ABS 8
 Combo	AIRBAG	1.3 CDTI (04-..)	SIEMENS AirBag SAB8x
 Combo	AIRBAG	1.3 CDTI (04-..)	TEMIC AirBag 07
 Combo	AIRBAG	1.4	SIEMENS AirBag SAB8x
 Combo	AIRBAG	1.4 (01-..)	TEMIC AirBag 07
 Combo	AIRBAG	1.7 DTL	SIEMENS AirBag SAB8x
 Combo	AIRBAG	1.7 DTL (01-..)	TEMIC AirBag 07
 Combo	CHASSIS NETWORK	1.3 CDTI (04-..)	SIEMENS Body computer
 Combo	CHASSIS NETWORK	1.4	SIEMENS Body computer
 Combo	CHASSIS NETWORK	1.7 DTL	SIEMENS Body computer
 Combo	DASHBOARD	1.3 CDTI (04-..)	SIEMENS Dashboard
 Combo	DASHBOARD	1.4 (02-..)	SIEMENS Dashboard
 Combo	DASHBOARD	1.7 DTL (02-..)	SIEMENS Dashboard
 Combo	ELECTRIC STEERING	1.3 CDTI (04-..)	EPS
 Combo	ELECTRIC STEERING	1.4	EPS
 Combo	ELECTRIC STEERING	1.7 DTL	EPS
 Combo	ENGINE MANAGEME	1.3 CDTI Z13DT (04-..)	MARELLI 6JF CF3 Common Rail
 Combo	ENGINE MANAGEME	1.4 X14SZ (97-00)	GM Multec S (F)
 Combo	ENGINE MANAGEME	1.7 DTL Y17DT (01-05)	DELPHI EDC HDRC
 Combo	ENGINE MANAGEME	1.7 DTL Y17DTL (01-05)	DELPHI HDRC
 Combo	IMMOBILIZER	1.3 CDTI (04-..)	SIEMENS
 Combo	IMMOBILIZER	1.4	SIEMENS

## Systems supported by ECUREADER (up to V5.40)

### TRUCKS






Opel

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Combo	IMMOBILIZER	1.7 DTL	SIEMENS
 Movano	SERVICE LIGHT RES	2.5 CDTI 100 (07-..)	MANUAL
 Movano	SERVICE LIGHT RES	2.5 CDTI 120 (07-..)	MANUAL
 Movano	SERVICE LIGHT RES	2.5 CDTI 150 FAP (07-..)	MANUAL
 Vivaro	AIRBAG	1.9 dCi 100cv (02-06)	SAGEM - Autoliv AirBag ACU x.x
 Vivaro	AIRBAG	2.0 16v 117 (02-06)	SAGEM - Autoliv AirBag ACU x.x
 Vivaro	AIRBAG	2.0 CDTI 114 (02-06)	SAGEM - Autoliv AirBag ACU x.x
 Vivaro	AIRBAG	2.0 CDTI 90 (02-06)	SAGEM - Autoliv AirBag ACU x.x
 Vivaro	AIRBAG	2.5 CDTI 146 (02-06)	SAGEM - Autoliv AirBag ACU x.x
 Vivaro	CHASSIS NETWORK	2.0 16v 117 (07-..)	Body Computer
 Vivaro	CHASSIS NETWORK	2.0 CDTI 114 (07-..)	Body Computer
 Vivaro	CHASSIS NETWORK	2.0 CDTI 90 (07-..)	Body Computer
 Vivaro	CHASSIS NETWORK	2.5 CDTI 146 (07-..)	Body Computer
 Vivaro	ENGINE MANAGEME	1.9 dCi 100cv F9Q U7 (02-06)	BOSCH EDC 15 C3 Common Rail
 Vivaro	SERVICE LIGHT RES	2.0 16v 117 (07-..)	MANUAL
 Vivaro	SERVICE LIGHT RES	2.0 CDTI 114 (07-..)	MANUAL
 Vivaro	SERVICE LIGHT RES	2.0 CDTI 90 (07-..)	MANUAL
 Vivaro	SERVICE LIGHT RES	2.5 CDTI 146 (07-..)	MANUAL
 Vivaro	VISUAL./TELEMATICS	2.0 16v 117 (07-..)	Display
 Vivaro	VISUAL./TELEMATICS	2.0 CDTI 114 (07-..)	Display
 Vivaro	VISUAL./TELEMATICS	2.0 CDTI 90 (07-..)	Display
 Vivaro	VISUAL./TELEMATICS	2.5 CDTI 146 (07-..)	Display

## Systems supported by ECUreader (up to V5.40)

### TRUCKS





Pacton

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Trailers	BRAKE SYS. MANAG	Trailers	Wabco Trailer EBS
 Trailers	BRAKE SYS. MANAG	Trailers	Wabco Trailer EBS kw2000
 Trailers	BRAKE SYS. MANAG	Trailers	Wabco Trailer VCS II
 Trailers	BRAKE SYS. MANAG	Trailers Haldex	Haldex EBS EB+
 Trailers	BRAKE SYS. MANAG	Trailers Knorr	Knorr Trailer EBS

## Systems supported by ECUreader (up to V5.40)

### TRUCKS



Paganini

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Trailers	BRAKE SYS. MANAG	Trailers	Wabco Trailer EBS
 Trailers	BRAKE SYS. MANAG	Trailers	Wabco Trailers EBS kw2000
 Trailers	BRAKE SYS. MANAG	Trailers Haldex	Haldex EBS EB+
 Trailers	BRAKE SYS. MANAG	Trailers Knorr	Knorr Trailer EBS

## Systems supported by ECUreader (up to V5.40)

### TRUCKS



Parcisa

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Trailers	BRAKE SYS. MANAG	Trailers	Wabco Trailer EBS
 Trailers	BRAKE SYS. MANAG	Trailers	Wabco Trailer VCS II

## Systems supported by ECUreader (up to V5.40)

### TRUCKS

Pepin

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Trailers	BRAKE SYS. MANAG	Trailers	Wabco Trailer EBS
 Trailers	BRAKE SYS. MANAG	Trailers	Wabco Trailer VCS II

## Systems supported by ECUREADER (up to V5.40)

### TRUCKS



























Peugeot

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Bipper	ABS + TRACT. CONT	1.3 Multijet 75cv 8HS	ABS BOSCH 8.1 AUTODETECT
 Bipper	ABS + TRACT. CONT	1.4 HDI 8HS	ABS BOSCH 8.1 AUTODETECT
 Bipper	ABS + TRACT. CONT	1.4 HDI 8HS	BOSCH ESP 8
 Bipper	ABS + TRACT. CONT	1.4 KFV	ABS BOSCH 8.1 AUTODETECT
 Bipper	ABS + TRACT. CONT	1.4 KFV	BOSCH ESP 8
 Bipper	AIRBAG	1.3 Multijet 75cv 8HS	AUTOLIV AirBag CENTRAL AUTODETECT
 Bipper	AIRBAG	1.4 HDI 8HS	AUTOLIV AirBag CENTRAL AUTODETECT
 Bipper	AIRBAG	1.4 HDI 8HS	TRW SRS EP
 Bipper	AIRBAG	1.4 KFV	AUTOLIV AirBag CENTRAL AUTODETECT
 Bipper	AIRBAG	1.4 KFV	TRW SRS EP
 Bipper	AUTOM. TRANSMISSI	1.3 Multijet 75cv 8HS	A/T MAP AUTODETECT
 Bipper	AUTOM. TRANSMISSI	1.4 HDI 8HS	A/T MAP AUTODETECT
 Bipper	AUTOM. TRANSMISSI	1.4 KFV	A/T MAP AUTODETECT
 Bipper	CHASSIS NETWORK	1.3 Multijet 75cv 8HS	Body Computer BSI AUTODETECT
 Bipper	CHASSIS NETWORK	1.4 HDI 8HS	Body Computer BSI AUTODETECT
 Bipper	CHASSIS NETWORK	1.4 HDI 8HS	DELPHI Body Computer
 Bipper	CHASSIS NETWORK	1.4 HDI 8HS	DELPHI Body Computer CAN Info
 Bipper	CHASSIS NETWORK	1.4 HDI 8HS	DELPHI EP
 Bipper	CHASSIS NETWORK	1.4 KFV	Body Computer BSI AUTODETECT
 Bipper	CHASSIS NETWORK	1.4 KFV	DELPHI Body Computer
 Bipper	CHASSIS NETWORK	1.4 KFV	DELPHI Body Computer CAN Info
 Bipper	CHASSIS NETWORK	1.4 KFV	DELPHI EP
 Bipper	DASHBOARD	1.3 Multijet 75cv 8HS	AUTODETECT
 Bipper	DASHBOARD	1.4 HDI 8HS	AUTODETECT
 Bipper	DASHBOARD	1.4 HDI 8HS	MARELLI Dashboard Modale
 Bipper	DASHBOARD	1.4 KFV	AUTODETECT
 Bipper	DASHBOARD	1.4 KFV	MARELLI Dashboard Modale

## Systems supported by ECReader (up to V5.40)

### TRUCKS



























Peugeot

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Bipper	ENGINE MANAGEME	1.3 Multijet 75cv 8HS	BOSCH EDC16 C34 Common Rail AUTOD
 Bipper	ENGINE MANAGEME	1.4 HDI 8HS	BOSCH EDC16 C34 Common Rail AUTOD
 Bipper	ENGINE MANAGEME	1.4 KFV	BOSCH EDC16 C34 Common Rail AUTOD
 Bipper	PARK.BRAKE	1.3 Multijet 75cv 8HS	AUTODETECT
 Bipper	PARK.BRAKE	1.4 HDI 8HS	AUTODETECT
 Bipper	PARK.BRAKE	1.4 KFV	AUTODETECT
 Boxer	ABS	2.0 HDI RHV	BOSCH ABS 5.3
 Boxer	ABS	2.2 HDI 4HY	BOSCH ABS 5.3
 Boxer	ABS	2.2 HDI 4HY (06-..)	BOSCH ABS 8
 Boxer	ABS	2.8 HDI SOFIM	BOSCH ABS 5.3
 Boxer	AIRBAG	2.0 HDI RHV	SIEMENS AirBag
 Boxer	AIRBAG	2.2 HDI 4HY	SIEMENS AirBag
 Boxer	AIRBAG	2.2 HDI 4HY (06-..)	TRW SRS 1
 Boxer	AIRBAG	2.8 HDI SOFIM	SIEMENS AirBag
 Boxer	AUTOM. TRANSMISSI	2.0 DW10UTD	A/T 4HP20
 Boxer	AUTOM. TRANSMISSI	2.0 HDI RHV	A/T 4HP20
 Boxer	AUTOM. TRANSMISSI	2.0 RFL	A/T 4HP20
 Boxer	AUTOM. TRANSMISSI	2.2 HDI 4HY	A/T 4HP20
 Boxer	AUTOM. TRANSMISSI	2.8 HDI SOFIM	A/T 4HP20
 Boxer	AUX. HEATING	2.0 DW10UTD	Var.1
 Boxer	AUX. HEATING	2.0 DW10UTD	Var.2
 Boxer	AUX. HEATING	2.0 DW10UTD	Var.3
 Boxer	AUX. HEATING	2.0 HDI RHV	Var.1
 Boxer	AUX. HEATING	2.0 HDI RHV	Var.2
 Boxer	AUX. HEATING	2.0 HDI RHV	Var.3
 Boxer	AUX. HEATING	2.0 RFL	Var.1

## Systems supported by ECReader (up to V5.40)

### TRUCKS




























Peugeot

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Boxer	AUX. HEATING	2.0 RFL	Var.2
 Boxer	AUX. HEATING	2.0 RFL	Var.3
 Boxer	AUX. HEATING	2.2 HDI 4HY	Var.1
 Boxer	AUX. HEATING	2.2 HDI 4HY	Var.2
 Boxer	AUX. HEATING	2.2 HDI 4HY	Var.3
 Boxer	AUX. HEATING	2.8 HDI SOFIM	Var.1
 Boxer	AUX. HEATING	2.8 HDI SOFIM	Var.2
 Boxer	AUX. HEATING	2.8 HDI SOFIM	Var.3
 Boxer	CHASSIS NETWORK	2.2 HDI 4HY (06-..)	MARELLI Body Computer 6
 Boxer	DASHBOARD	2.2 HDI 4HY (06-..)	MARELLI Dashboard
 Boxer	ENGINE MANAGEME	2.0 DW10UTD	Var.1
 Boxer	ENGINE MANAGEME	2.0 DW10UTD	Var.2
 Boxer	ENGINE MANAGEME	2.0 HDI RHV (02-06)	BOSCH EDC 15 Common Rail (JTD '99)
 Boxer	ENGINE MANAGEME	2.0 RFL	MARELLI MM48P
 Boxer	ENGINE MANAGEME	2.2 HDI 4HY	VISTEON PUMA AUTODETECT
 Boxer	ENGINE MANAGEME	2.2 HDI 4HY (02-06)	BOSCH EDC 15 Common Rail (JTD '99)
 Boxer	ENGINE MANAGEME	2.2 HDI 4HY (06-..)	BOSCH EDC 16 Common Rail
 Boxer	ENGINE MANAGEME	2.8 HDI SOFIM	BOSCH EDC Common Rail
 Boxer	ENGINE MANAGEME	2.8 HDI SOFIM (02-06)	BOSCH EDC 15 Common Rail (JTD '99)
 Boxer	IMMOBILIZER	2.0 HDI RHV	Delphi Code 2
 Boxer	IMMOBILIZER	2.2 HDI 4HY	Delphi Code 2
 Boxer	IMMOBILIZER	2.8 HDI SOFIM	Delphi Code 2
 Expert	ABS	1.6 HDI 16v 9HU (07-..)	BOSCH ABS 8
 Expert	ABS	1.9 D WJY	BOSCH ABS ABR 5.3
 Expert	ABS	1.9 TD DHX	BOSCH ABS ABR 5.3
 Expert	ABS	2.0 HDI RHT	BOSCH ABS ABR 5.3

## Systems supported by ECReader (up to V5.40)

### TRUCKS




























Peugeot

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Expert	ABS	2.0 HDI RHT (07-..)	BOSCH ABS 8
 Expert	ABS	2.0 HDI RHX	BOSCH ABS ABR 5.3
 Expert	ABS	2.0 HDI RHX (07-..)	BOSCH ABS 8
 Expert	ABS	2.0 HDI RHZ	BOSCH ABS ABR 5.3
 Expert	ABS	2.0 HDI RHZ (07-..)	BOSCH ABS 8
 Expert	ABS	2.0 RFN	BOSCH ABS ABR 5.3
 Expert	AIRBAG	1.6 HDI 16v 9HU (07-..)	Temic SRS
 Expert	AIRBAG	2.0 HDI RHT (07-..)	Temic SRS
 Expert	AIRBAG	2.0 HDI RHX (07-..)	Temic SRS
 Expert	AIRBAG	2.0 HDI RHZ (07-..)	Temic SRS
 Expert	AUTOM. TRANSMISSI	1.6 HDI 16v 9HU	Var.1
 Expert	AUTOM. TRANSMISSI	1.6 HDI 16v 9HU	Var.2
 Expert	AUTOM. TRANSMISSI	1.6 HDI 16v 9HU	Var.3
 Expert	AUTOM. TRANSMISSI	1.9 D WJY	Var.1
 Expert	AUTOM. TRANSMISSI	1.9 D WJY	Var.2
 Expert	AUTOM. TRANSMISSI	1.9 D WJY	Var.3
 Expert	AUTOM. TRANSMISSI	1.9 TD DHX	Var.1
 Expert	AUTOM. TRANSMISSI	1.9 TD DHX	Var.2
 Expert	AUTOM. TRANSMISSI	1.9 TD DHX	Var.3
 Expert	AUTOM. TRANSMISSI	2.0 HDI RHT	Var.1
 Expert	AUTOM. TRANSMISSI	2.0 HDI RHT	Var.2
 Expert	AUTOM. TRANSMISSI	2.0 HDI RHT	Var.3
 Expert	AUTOM. TRANSMISSI	2.0 HDI RHW	Var.1
 Expert	AUTOM. TRANSMISSI	2.0 HDI RHW	Var.2
 Expert	AUTOM. TRANSMISSI	2.0 HDI RHW	Var.3
 Expert	AUTOM. TRANSMISSI	2.0 HDI RHX	Var.1
 Expert	AUTOM. TRANSMISSI	2.0 HDI RHX	Var.2

## Systems supported by ECUREADER (up to V5.40)

### TRUCKS



























Peugeot

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Expert	AUTOM. TRANSMISSI	2.0 HDI RHX	Var.3
 Expert	AUTOM. TRANSMISSI	2.0 HDI RHZ	Var.1
 Expert	AUTOM. TRANSMISSI	2.0 HDI RHZ	Var.2
 Expert	AUTOM. TRANSMISSI	2.0 HDI RHZ	Var.3
 Expert	AUTOM. TRANSMISSI	2.0 RFN	Var.1
 Expert	AUTOM. TRANSMISSI	2.0 RFN	Var.2
 Expert	AUTOM. TRANSMISSI	2.0 RFN	Var.3
 Expert	CHASSIS NETWORK	1.6 HDI 16v 9HU (07-..)	Valeo 2 1/2
 Expert	CHASSIS NETWORK	1.6 HDI 16v 9HU (07-..)	Valeo 2 2/2
 Expert	CHASSIS NETWORK	2.0 HDI RHT (07-..)	Valeo 2 1/2
 Expert	CHASSIS NETWORK	2.0 HDI RHT (07-..)	Valeo 2 2/2
 Expert	CHASSIS NETWORK	2.0 HDI RHX (07-..)	Valeo 2 1/2
 Expert	CHASSIS NETWORK	2.0 HDI RHX (07-..)	Valeo 2 2/2
 Expert	CHASSIS NETWORK	2.0 HDI RHZ (07-..)	Valeo 2 1/2
 Expert	CHASSIS NETWORK	2.0 HDI RHZ (07-..)	Valeo 2 2/2
 Expert	DASHBOARD	1.6 HDI 16v 9HU (07-..)	Marelli Dashboard PSA
 Expert	DASHBOARD	2.0 HDI RHT (07-..)	Marelli Dashboard PSA
 Expert	DASHBOARD	2.0 HDI RHX (07-..)	Marelli Dashboard PSA
 Expert	DASHBOARD	2.0 HDI RHZ (07-..)	Marelli Dashboard PSA
 Expert	DIESEL MANAGEMEN	1.9 D WJY	LUCAS Diesel DCN2
 Expert	DIESEL MANAGEMEN	1.9 TD DHX	BOSCH AS3 VP20
 Expert	ENGINE MANAGEME	1.6 HDI 16v 9HU (07-..)	BOSCH EDC 16 34 Common Rail
 Expert	ENGINE MANAGEME	1.9 D WJY	LUCAS Diesel DCN2
 Expert	ENGINE MANAGEME	2.0 HDI RHT	BOSCH EDC 15 C2 Common Rail
 Expert	ENGINE MANAGEME	2.0 HDI RHW	BOSCH EDC 15 C2 Common Rail
 Expert	ENGINE MANAGEME	2.0 HDI RHX	BOSCH EDC 15 C2 Common Rail
 Expert	ENGINE MANAGEME	2.0 HDI RHZ	BOSCH EDC 15 C2 Common Rail

## Systems supported by ECUREADER (up to V5.40)

### TRUCKS




























Peugeot

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Expert	ENGINE MANAGEME	2.0 HDI RHZ (...00)	BOSCH EDC 15 C2 Common Rail
 Expert	ENGINE MANAGEME	2.0 HDI RHZ (03-..)	BOSCH EDC 15 C2 Common Rail
 Expert	ENGINE MANAGEME	2.0 RFN	MARELLI MM48P
 Expert	RADIO / CD	1.6 HDI 16v 9HU (07-..)	Blaupunkt AudioSystem
 Expert	RADIO / CD	2.0 HDI RHT (07-..)	Blaupunkt AudioSystem
 Expert	RADIO / CD	2.0 HDI RHX (07-..)	Blaupunkt AudioSystem
 Expert	RADIO / CD	2.0 HDI RHZ (07-..)	Blaupunkt AudioSystem
 Expert	SERVICE LIGHT RES	1.6 HDI 16v 9HU (07-..)	MANUAL
 Expert	SERVICE LIGHT RES	1.9 D WJY (07-..)	MANUAL
 Expert	SERVICE LIGHT RES	1.9 TD DHX (07-..)	MANUAL
 Expert	SERVICE LIGHT RES	2.0 HDI RHT (07-..)	MANUAL
 Expert	SERVICE LIGHT RES	2.0 HDI RHX (07-..)	MANUAL
 Expert	SERVICE LIGHT RES	2.0 HDI RHZ (07-..)	MANUAL
 Expert	SERVICE LIGHT RES	2.0 RFN (07-..)	MANUAL
 Expert	SWITCHLIGHT MODU	1.6 HDI 16v 9HU (07-..)	Delphi
 Expert	SWITCHLIGHT MODU	2.0 HDI RHT (07-..)	Delphi
 Expert	SWITCHLIGHT MODU	2.0 HDI RHX (07-..)	Delphi
 Expert	SWITCHLIGHT MODU	2.0 HDI RHZ (07-..)	Delphi
 Partner 2	ABS	1.1 HFX	TEVES MK60
 Partner 2	ABS	1.1 HFX (08-..)	BOSCH ABS 8.1
 Partner 2	ABS	1.4 16v KFU	TEVES MK60
 Partner 2	ABS	1.4 16v KFU (08-..)	BOSCH ABS 8.1
 Partner 2	ABS	1.4 KFV	TEVES MK60
 Partner 2	ABS	1.4 KFV (08-..)	BOSCH ABS 8.1
 Partner 2	ABS	1.6 16v NFR	TEVES MK60
 Partner 2	ABS	1.6 16v NFR (08-..)	BOSCH ABS 8.1

## Systems supported by ECUREADER (up to V5.40)

### TRUCKS




























Peugeot

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Partner 2	ABS	1.6 16v NFU	MK60
 Partner 2	ABS	1.6 HDI 9HT	TEVES MK60
 Partner 2	ABS	1.6 HDI 9HT (08-..)	BOSCH ABS 8.1
 Partner 2	ABS	1.6 HDI 9HW	TEVES MK60
 Partner 2	ABS	1.6 HDI 9HW (08-..)	BOSCH ABS 8.1
 Partner 2	ABS	1.6 HDI 9HX	TEVES MK60
 Partner 2	ABS	1.6 HDI 9HX (08-..)	BOSCH ABS 8.1
 Partner 2	ABS	1.6 N6A	TEVES MK60
 Partner 2	ABS	1.9 D WJY	TEVES MK60
 Partner 2	ABS	1.9 D WJY (08-..)	BOSCH ABS 8.1
 Partner 2	ABS	2.0 HDI RHY	TEVES MK60
 Partner 2	ABS	2.0 HDI RHY (08-..)	BOSCH ABS 8.1
 Partner 2	ABS	2.0 RFV	TEVES MK60
 Partner 2	ABS	2.0 RFV (08-..)	BOSCH ABS 8.1
 Partner 2	ABS + TRACT. CONT	1.1 HFX	BOSCH ESP 5.7
 Partner 2	ABS + TRACT. CONT	1.1 HFX	Var.1
 Partner 2	ABS + TRACT. CONT	1.1 HFX	Var.2
 Partner 2	ABS + TRACT. CONT	1.4 16v KFU	BOSCH ESP 5.7
 Partner 2	ABS + TRACT. CONT	1.4 16v KFU	Var.1
 Partner 2	ABS + TRACT. CONT	1.4 16v KFU	Var.2
 Partner 2	ABS + TRACT. CONT	1.4 KFV	BOSCH ESP 5.7
 Partner 2	ABS + TRACT. CONT	1.4 KFV	Var.1
 Partner 2	ABS + TRACT. CONT	1.4 KFV	Var.2
 Partner 2	ABS + TRACT. CONT	1.6 16v NFR	BOSCH ESP 5.7
 Partner 2	ABS + TRACT. CONT	1.6 16v NFR	Var.1
 Partner 2	ABS + TRACT. CONT	1.6 16v NFR	Var.2
 Partner 2	ABS + TRACT. CONT	1.6 16v NFU	BOSCH ESP 5.7

## Systems supported by ECUREADER (up to V5.40)

### TRUCKS


























Peugeot

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Partner 2	ABS + TRACT. CONT	1.6 16v NFU	Var.1
 Partner 2	ABS + TRACT. CONT	1.6 16v NFU	Var.2
 Partner 2	ABS + TRACT. CONT	1.6 HDI 9HT	ESP 5.7
 Partner 2	ABS + TRACT. CONT	1.6 HDI 9HT	Var.1
 Partner 2	ABS + TRACT. CONT	1.6 HDI 9HT	Var.2
 Partner 2	ABS + TRACT. CONT	1.6 HDI 9HW	BOSCH ESP 5.7
 Partner 2	ABS + TRACT. CONT	1.6 HDI 9HW	Var.1
 Partner 2	ABS + TRACT. CONT	1.6 HDI 9HW	Var.2
 Partner 2	ABS + TRACT. CONT	1.6 HDI 9HX	BOSCH ESP 5.7
 Partner 2	ABS + TRACT. CONT	1.6 HDI 9HX	Var.1
 Partner 2	ABS + TRACT. CONT	1.6 HDI 9HX	Var.2
 Partner 2	ABS + TRACT. CONT	1.6 N6A	BOSCH ESP 5.7
 Partner 2	ABS + TRACT. CONT	1.6 N6A	Var.1
 Partner 2	ABS + TRACT. CONT	1.6 N6A	Var.2
 Partner 2	ABS + TRACT. CONT	1.9 D WJY	BOSCH ESP 5.7
 Partner 2	ABS + TRACT. CONT	1.9 D WJY	Var.1
 Partner 2	ABS + TRACT. CONT	1.9 D WJY	Var.2
 Partner 2	ABS + TRACT. CONT	2.0 HDI RHY	BOSCH ESP 5.7
 Partner 2	ABS + TRACT. CONT	2.0 HDI RHY	Var.1
 Partner 2	ABS + TRACT. CONT	2.0 HDI RHY	Var.2
 Partner 2	ABS + TRACT. CONT	2.0 RFV	BOSCH ESP 5.7
 Partner 2	ABS + TRACT. CONT	2.0 RFV	Var.1
 Partner 2	ABS + TRACT. CONT	2.0 RFV	Var.2
 Partner 2	AIRBAG	1.1 HFX	Temic AirBag CENTRAL
 Partner 2	AIRBAG	1.1 HFX (08-..)	Autoliv AirBag
 Partner 2	AIRBAG	1.4 16v KFV	Temic AirBag CENTRAL
 Partner 2	AIRBAG	1.4 16v KFV (08-..)	Autoliv AirBag

## Systems supported by ECReader (up to V5.40)

### TRUCKS




























Peugeot

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Partner 2	AIRBAG	1.4 KFV	Temic AirBag CENTRAL
 Partner 2	AIRBAG	1.4 KFV (08-..)	Autoliv AirBag
 Partner 2	AIRBAG	1.6 16v NFR	Temic AirBag CENTRAL
 Partner 2	AIRBAG	1.6 16v NFR (08-..)	Autoliv AirBag
 Partner 2	AIRBAG	1.6 16v NFU	Temic AirBag CENTRAL
 Partner 2	AIRBAG	1.6 16v NFU (08-..)	Autoliv AirBag
 Partner 2	AIRBAG	1.6 HDI 9HT	Temic AirBag CENTRAL
 Partner 2	AIRBAG	1.6 HDI 9HT (08-..)	Autoliv
 Partner 2	AIRBAG	1.6 HDI 9HW	Temic AirBag CENTRAL
 Partner 2	AIRBAG	1.6 HDI 9HW (08-..)	Autoliv AirBag
 Partner 2	AIRBAG	1.6 HDI 9HX	Temic AirBag CENTRAL
 Partner 2	AIRBAG	1.6 HDI 9HX (08-..)	Autoliv
 Partner 2	AIRBAG	1.6 N6A	Temic AirBag CENTRAL
 Partner 2	AIRBAG	1.9 D WJY	Temic AirBag CENTRAL
 Partner 2	AIRBAG	1.9 D WJY (08-..)	Autoliv AirBag
 Partner 2	AIRBAG	2.0 HDI RHY	Temic AirBag CENTRAL
 Partner 2	AIRBAG	2.0 HDI RHY (08-..)	Autoliv AirBag
 Partner 2	AIRBAG	2.0 NFR (08-..)	Autoliv AirBag
 Partner 2	AIRBAG	2.0 RFV	Temic AirBag CENTRAL
 Partner 2	ANTITHEFT	1.1 HFX	Alarm PSA2
 Partner 2	ANTITHEFT	1.4 16v KFU	Alarm PSA2
 Partner 2	ANTITHEFT	1.4 KFV	Alarm PSA2
 Partner 2	ANTITHEFT	1.6 16v NFR	Alarm PSA2
 Partner 2	ANTITHEFT	1.6 16v NFU	Alarm PSA2
 Partner 2	ANTITHEFT	1.6 HDI 9HT	Alarm PSA2
 Partner 2	ANTITHEFT	1.6 HDI 9HW	Alarm PSA2
 Partner 2	ANTITHEFT	1.6 HDI 9HX	Alarm PSA2

## Systems supported by ECReader (up to V5.40)

### TRUCKS





Peugeot

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Partner 2	ANTITHEFT	1.6 N6A	Alarm PSA2
 Partner 2	ANTITHEFT	1.9 D WJY	Alarm PSA2
 Partner 2	ANTITHEFT	2.0 HDI RHY	Alarm PSA2
 Partner 2	ANTITHEFT	2.0 RFV	Alarm PSA2
 Partner 2	CHASSIS NETWORK	1.1 HFX	BodyComputer BSI
 Partner 2	CHASSIS NETWORK	1.1 HFX	Var.1
 Partner 2	CHASSIS NETWORK	1.1 HFX (08-..)	Delphi BSM
 Partner 2	CHASSIS NETWORK	1.1 HFX (08-..)	JCAE BSI 5.20
 Partner 2	CHASSIS NETWORK	1.4 16v KFU	BodyComputer BSI
 Partner 2	CHASSIS NETWORK	1.4 16v KFU	Var.1
 Partner 2	CHASSIS NETWORK	1.4 16v KFU (08-..)	JCAE BSI 5.20
 Partner 2	CHASSIS NETWORK	1.4 16v NFU (08-..)	Delphi BSM
 Partner 2	CHASSIS NETWORK	1.4 KFU	BodyComputer BSI
 Partner 2	CHASSIS NETWORK	1.4 KFU	Var.1
 Partner 2	CHASSIS NETWORK	1.4 KFU (08-..)	Delphi BSM
 Partner 2	CHASSIS NETWORK	1.4 KFU (08-..)	JCAE BSI 5.20
 Partner 2	CHASSIS NETWORK	1.6 16v NFR	BodyComputer BSI
 Partner 2	CHASSIS NETWORK	1.6 16v NFR	Var.1
 Partner 2	CHASSIS NETWORK	1.6 16v NFR (08-..)	Delphi BSM
 Partner 2	CHASSIS NETWORK	1.6 16v NFR (08-..)	JCAE BSI 5.20
 Partner 2	CHASSIS NETWORK	1.6 16v NFU	BodyComputer BSI
 Partner 2	CHASSIS NETWORK	1.6 16v NFU	Var.1
 Partner 2	CHASSIS NETWORK	1.6 16v NFU (08-..)	Delphi BSM
 Partner 2	CHASSIS NETWORK	1.6 16v NFU (08-..)	JCAE BSI 5.20
 Partner 2	CHASSIS NETWORK	1.6 HDI 9HT	BodyComputer BSI
 Partner 2	CHASSIS NETWORK	1.6 HDI 9HT	Var.1
 Partner 2	CHASSIS NETWORK	1.6 HDI 9HT (08-..)	Delphi BSM

## Systems supported by ECUREADER (up to V5.40)

### TRUCKS




























Peugeot

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Partner 2	CHASSIS NETWORK	1.6 HDI 9HT (08-..)	JCAE BSI 5.20
 Partner 2	CHASSIS NETWORK	1.6 HDI 9HW	BodyComputer BSI
 Partner 2	CHASSIS NETWORK	1.6 HDI 9HW	Var.1
 Partner 2	CHASSIS NETWORK	1.6 HDI 9HW (08-..)	Delphi BSM
 Partner 2	CHASSIS NETWORK	1.6 HDI 9HW (08-..)	JCAE BSI 5.20
 Partner 2	CHASSIS NETWORK	1.6 HDI 9HX	BodyComputer BSI
 Partner 2	CHASSIS NETWORK	1.6 HDI 9HX	Var.1
 Partner 2	CHASSIS NETWORK	1.6 HDI 9HX (08-..)	Delphi BSM
 Partner 2	CHASSIS NETWORK	1.6 HDI 9HX (08-..)	JCAE BSI 5.20
 Partner 2	CHASSIS NETWORK	1.6 N6A	BodyComputer BSI
 Partner 2	CHASSIS NETWORK	1.6 N6A	Var.1
 Partner 2	CHASSIS NETWORK	1.6 N6A (08-..)	Delphi BSM
 Partner 2	CHASSIS NETWORK	1.6 N6A (08-..)	JCAE BSI 5.20
 Partner 2	CHASSIS NETWORK	1.9 D WJY	BodyComputer BSI
 Partner 2	CHASSIS NETWORK	1.9 D WJY	Var.1
 Partner 2	CHASSIS NETWORK	1.9 D WJY (08-..)	Delphi BSM
 Partner 2	CHASSIS NETWORK	1.9 D WJY (08-..)	JCAE BSI 5.20
 Partner 2	CHASSIS NETWORK	2.0 HDI RHY	BodyComputer BSI
 Partner 2	CHASSIS NETWORK	2.0 HDI RHY	Var.1
 Partner 2	CHASSIS NETWORK	2.0 HDI RHY (08-..)	Delphi BSM
 Partner 2	CHASSIS NETWORK	2.0 HDI RHY (08-..)	JCAE BSI 5.20
 Partner 2	CHASSIS NETWORK	2.0 RFV	BodyComputer BSI
 Partner 2	CHASSIS NETWORK	2.0 RFV	Var.1
 Partner 2	CHASSIS NETWORK	2.0 RFV (08-..)	Delphi BSM
 Partner 2	CHASSIS NETWORK	2.0 RFV (08-..)	JCAE BSI 5.20
 Partner 2	DASHBOARD	1.1 HFX	
 Partner 2	DASHBOARD	1.1 HFX (08-..)	MARELLI

## Systems supported by ECUREADER (up to V5.40)

### TRUCKS




























Peugeot

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Partner 2	DASHBOARD	1.4 16v KFU	
 Partner 2	DASHBOARD	1.4 16v KFU (08-..)	MARELLI
 Partner 2	DASHBOARD	1.4 KFV	
 Partner 2	DASHBOARD	1.4 KFV (08-..)	MARELLI
 Partner 2	DASHBOARD	1.6 16v NFR	
 Partner 2	DASHBOARD	1.6 16v NFR (08-..)	MARELLI
 Partner 2	DASHBOARD	1.6 16v NFU	
 Partner 2	DASHBOARD	1.6 16v NFU (08-..)	MARELLI
 Partner 2	DASHBOARD	1.6 HDI 9HT	
 Partner 2	DASHBOARD	1.6 HDI 9HT (08-..)	MARELLI
 Partner 2	DASHBOARD	1.6 HDI 9HW	
 Partner 2	DASHBOARD	1.6 HDI 9HW (08-..)	MARELLI
 Partner 2	DASHBOARD	1.6 HDI 9HX	
 Partner 2	DASHBOARD	1.6 HDI 9HX (08-..)	MARELLI
 Partner 2	DASHBOARD	1.6 N6A	
 Partner 2	DASHBOARD	1.6 N6A (08-..)	MARELLI
 Partner 2	DASHBOARD	1.9 D WJY	
 Partner 2	DASHBOARD	1.9 D WJY (08-..)	MARELLI
 Partner 2	DASHBOARD	2.0 HDI RHY	
 Partner 2	DASHBOARD	2.0 HDI RHY (08-..)	MARELLI
 Partner 2	DASHBOARD	2.0 RFV	
 Partner 2	DASHBOARD	2.0 RFV (08-..)	MARELLI
 Partner 2	ENGINE MANAGEME	1.1 HFX	MARELLI MM48P
 Partner 2	ENGINE MANAGEME	1.4 16v KFU	MARELLI MM6LP
 Partner 2	ENGINE MANAGEME	1.4 KFV	SAGEM S2000 PM1
 Partner 2	ENGINE MANAGEME	1.6 16v NFR (08-..)	BOSCH Motronic ME 7.4.5
 Partner 2	ENGINE MANAGEME	1.6 16v NFU	BOSCH ME7.4.4

## Systems supported by ECReader (up to V5.40)

### TRUCKS



























Peugeot

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Partner 2	ENGINE MANAGEME	1.6 HDI 9HW	BOSCH EDC 16 C34 Common Rail Var.1
 Partner 2	ENGINE MANAGEME	1.6 HDI 9HW	BOSCH EDC 16 C34 Common Rail Var.2
 Partner 2	ENGINE MANAGEME	1.6 N6A	BOSCH ME7.4.4
 Partner 2	ENGINE MANAGEME	1.9 D WJY	LUCAS Diesel DCN2
 Partner 2	ENGINE MANAGEME	2.0 HDI RHY	SIEMENS SID 801 Common Rail
 Partner 2	ENGINE MANAGEME	2.0 RFV	JCAE SAX500
 Partner 2	PARK.BRAKE	1.1 HFX	Var.1
 Partner 2	PARK.BRAKE	1.1 HFX	Var.2
 Partner 2	PARK.BRAKE	1.4 16v KFU	Var.1
 Partner 2	PARK.BRAKE	1.4 16v KFU	Var.2
 Partner 2	PARK.BRAKE	1.4 KFV	Var.1
 Partner 2	PARK.BRAKE	1.4 KFV	Var.2
 Partner 2	PARK.BRAKE	1.6 16v NFR	Var.1
 Partner 2	PARK.BRAKE	1.6 16v NFR	Var.2
 Partner 2	PARK.BRAKE	1.6 16v NFU	Var.1
 Partner 2	PARK.BRAKE	1.6 16v NFU	Var.2
 Partner 2	PARK.BRAKE	1.6 HDI 9HT	Var.1
 Partner 2	PARK.BRAKE	1.6 HDI 9HT	Var.2
 Partner 2	PARK.BRAKE	1.6 HDI 9HW	Var.1
 Partner 2	PARK.BRAKE	1.6 HDI 9HW	Var.2
 Partner 2	PARK.BRAKE	1.6 HDI 9HX	Var.1
 Partner 2	PARK.BRAKE	1.6 HDI 9HX	Var.2
 Partner 2	PARK.BRAKE	1.6 N6A	Var.1
 Partner 2	PARK.BRAKE	1.6 N6A	Var.2
 Partner 2	PARK.BRAKE	1.9 D WJY	Var.1
 Partner 2	PARK.BRAKE	1.9 D WJY	Var.2
 Partner 2	PARK.BRAKE	2.0 HDI RHY	Var.1

## Systems supported by ECUREADER (up to V5.40)

### TRUCKS



























Peugeot

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Partner 2	PARK.BRAKE	2.0 HDI RHY	Var.2
 Partner 2	PARK.BRAKE	2.0 RFV	Var.1
 Partner 2	PARK.BRAKE	2.0 RFV	Var.2
 Partner 2	RADIO / CD	1.1 HFX	Var.1
 Partner 2	RADIO / CD	1.1 HFX	Var.2
 Partner 2	RADIO / CD	1.1 HFX	Var.3
 Partner 2	RADIO / CD	1.1 HFX	Var.4
 Partner 2	RADIO / CD	1.4 16v KFU	Var.1
 Partner 2	RADIO / CD	1.4 16v KFU	Var.2
 Partner 2	RADIO / CD	1.4 16v KFU	Var.3
 Partner 2	RADIO / CD	1.4 16v KFU	Var.4
 Partner 2	RADIO / CD	1.4 KfV	Var.1
 Partner 2	RADIO / CD	1.4 KfV	Var.2
 Partner 2	RADIO / CD	1.4 KfV	Var.3
 Partner 2	RADIO / CD	1.4 KfV	Var.4
 Partner 2	RADIO / CD	1.6 16v NFR	Var.1
 Partner 2	RADIO / CD	1.6 16v NFR	Var.2
 Partner 2	RADIO / CD	1.6 16v NFR	Var.3
 Partner 2	RADIO / CD	1.6 16v NFR	Var.4
 Partner 2	RADIO / CD	1.6 16v NFU	Var.1
 Partner 2	RADIO / CD	1.6 16v NFU	Var.2
 Partner 2	RADIO / CD	1.6 16v NFU	Var.3
 Partner 2	RADIO / CD	1.6 16v NFU	Var.4
 Partner 2	RADIO / CD	1.6 HDI 9HT	Var.1
 Partner 2	RADIO / CD	1.6 HDI 9HT	Var.2
 Partner 2	RADIO / CD	1.6 HDI 9HT	Var.3
 Partner 2	RADIO / CD	1.6 HDI 9HT	Var.4

## Systems supported by ECUREADER (up to V5.40)

### TRUCKS




























Peugeot

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Partner 2	RADIO / CD	1.6 HDI 9HW	Var.1
 Partner 2	RADIO / CD	1.6 HDI 9HW	Var.2
 Partner 2	RADIO / CD	1.6 HDI 9HW	Var.3
 Partner 2	RADIO / CD	1.6 HDI 9HW	Var.4
 Partner 2	RADIO / CD	1.6 HDI 9HX	Var.1
 Partner 2	RADIO / CD	1.6 HDI 9HX	Var.2
 Partner 2	RADIO / CD	1.6 HDI 9HX	Var.3
 Partner 2	RADIO / CD	1.6 HDI 9HX	Var.4
 Partner 2	RADIO / CD	1.6 N6A	Var.1
 Partner 2	RADIO / CD	1.6 N6A	Var.2
 Partner 2	RADIO / CD	1.6 N6A	Var.3
 Partner 2	RADIO / CD	1.6 N6A	Var.4
 Partner 2	RADIO / CD	1.9 D WJY	Var.1
 Partner 2	RADIO / CD	1.9 D WJY	Var.2
 Partner 2	RADIO / CD	1.9 D WJY	Var.3
 Partner 2	RADIO / CD	1.9 D WJY	Var.4
 Partner 2	RADIO / CD	2.0 HDI RHY	Var.1
 Partner 2	RADIO / CD	2.0 HDI RHY	Var.2
 Partner 2	RADIO / CD	2.0 HDI RHY	Var.3
 Partner 2	RADIO / CD	2.0 HDI RHY	Var.4
 Partner 2	RADIO / CD	2.0 RFV	Var.1
 Partner 2	RADIO / CD	2.0 RFV	Var.2
 Partner 2	RADIO / CD	2.0 RFV	Var.3
 Partner 2	RADIO / CD	2.0 RFV	Var.4
 Partner 2	RAIN-LUMINOSITY SE	1.1 HFX	Var.1
 Partner 2	RAIN-LUMINOSITY SE	1.1 HFX	Var.2
 Partner 2	RAIN-LUMINOSITY SE	1.4 16v KFV	Var.1

## Systems supported by ECUREADER (up to V5.40)

### TRUCKS




























Peugeot

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Partner 2	RAIN-LUMINOSITY SE	1.4 16v KFU	Var.2
 Partner 2	RAIN-LUMINOSITY SE	1.4 KFV	Var.1
 Partner 2	RAIN-LUMINOSITY SE	1.4 KFV	Var.2
 Partner 2	RAIN-LUMINOSITY SE	1.6 16v NFR	Var.1
 Partner 2	RAIN-LUMINOSITY SE	1.6 16v NFR	Var.2
 Partner 2	RAIN-LUMINOSITY SE	1.6 16v NFU	Var.1
 Partner 2	RAIN-LUMINOSITY SE	1.6 16v NFU	Var.2
 Partner 2	RAIN-LUMINOSITY SE	1.6 HDI 9HT	Var.1
 Partner 2	RAIN-LUMINOSITY SE	1.6 HDI 9HT	Var.2
 Partner 2	RAIN-LUMINOSITY SE	1.6 HDI 9HW	Var.1
 Partner 2	RAIN-LUMINOSITY SE	1.6 HDI 9HW	Var.2
 Partner 2	RAIN-LUMINOSITY SE	1.6 HDI 9HX	Var.1
 Partner 2	RAIN-LUMINOSITY SE	1.6 HDI 9HX	Var.2
 Partner 2	RAIN-LUMINOSITY SE	1.6 N6A	Var.1
 Partner 2	RAIN-LUMINOSITY SE	1.6 N6A	Var.2
 Partner 2	RAIN-LUMINOSITY SE	1.9 D WJY	Var.1
 Partner 2	RAIN-LUMINOSITY SE	1.9 D WJY	Var.2
 Partner 2	RAIN-LUMINOSITY SE	2.0 HDI RHY	Var.1
 Partner 2	RAIN-LUMINOSITY SE	2.0 HDI RHY	Var.2
 Partner 2	RAIN-LUMINOSITY SE	2.0 RFV	Var.1
 Partner 2	RAIN-LUMINOSITY SE	2.0 RFV	Var.2
 Partner 2	STEERING COLUMN	1.1 HFX	
 Partner 2	STEERING COLUMN	1.4 16v KFU	
 Partner 2	STEERING COLUMN	1.4 KFV	
 Partner 2	STEERING COLUMN	1.6 16v NFR	
 Partner 2	STEERING COLUMN	1.6 16v NFU	
 Partner 2	STEERING COLUMN	1.6 HDI 9HT	

## Systems supported by ECUREADER (up to V5.40)

### TRUCKS



























Peugeot

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Partner 2	STEERING COLUMN	1.6 HDI 9HW	
 Partner 2	STEERING COLUMN	1.6 HDI 9HX	
 Partner 2	STEERING COLUMN	1.6 N6A	
 Partner 2	STEERING COLUMN	1.9 D WJY	
 Partner 2	STEERING COLUMN	2.0 HDI RHY	
 Partner 2	STEERING COLUMN	2.0 RFV	
 Partner 2	SWITCHLIGHT MODU	1.1 HFX (08-..)	Delphi
 Partner 2	SWITCHLIGHT MODU	1.4 KFV (08-..)	Delphi
 Partner 2	SWITCHLIGHT MODU	1.6 16v KFU (08-..)	Delphi
 Partner 2	SWITCHLIGHT MODU	1.6 16v NFR (08-..)	Delphi
 Partner 2	SWITCHLIGHT MODU	1.6 HDI 9HT (08-..)	Delphi
 Partner 2	SWITCHLIGHT MODU	1.6 HDI 9HW (08-..)	Delphi
 Partner 2	SWITCHLIGHT MODU	1.6 HDI 9HX (08-..)	Delphi
 Partner 2	SWITCHLIGHT MODU	1.6 N6A (08-..)	Delphi
 Partner 2	SWITCHLIGHT MODU	1.9 D WJY (08-..)	Delphi
 Partner 2	SWITCHLIGHT MODU	2.0 HDI RHY (08-..)	Delphi
 Partner 2	SWITCHLIGHT MODU	2.0 RFV (08-..)	Delphi
 Partner 2	VISUAL./TELEMATICS	1.1 HFX	
 Partner 2	VISUAL./TELEMATICS	1.4 16v KFU	Display
 Partner 2	VISUAL./TELEMATICS	1.4 KFV	
 Partner 2	VISUAL./TELEMATICS	1.6 16v NFR	Display
 Partner 2	VISUAL./TELEMATICS	1.6 16v NFU	Display
 Partner 2	VISUAL./TELEMATICS	1.6 HDI 9HT	
 Partner 2	VISUAL./TELEMATICS	1.6 HDI 9HW	
 Partner 2	VISUAL./TELEMATICS	1.6 HDI 9HX	
 Partner 2	VISUAL./TELEMATICS	1.6 N6A	
 Partner 2	VISUAL./TELEMATICS	1.9 D WJY	

## Systems supported by ECReader (up to V5.40)

### TRUCKS












Peugeot

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Partner 2	VISUAL./TELEMATICS	2.0 HDI RHY	
 Partner 2	VISUAL./TELEMATICS	2.0 RFV	
 Partner	ABS	1.1 HDY	BOSCH ABS ABR 5.3
 Partner	ABS	1.1 HDZ	BOSCH ABS ABR 5.3
 Partner	ABS	1.4 KFW	BOSCH ABS ABR 5.3
 Partner	ABS	1.4 KFX	BOSCH ABS ABR 5.3
 Partner	ABS	1.6 16v NFU	BOSCH ABS ABR 5.3
 Partner	ABS	1.6 HDI 16v 9HW	BOSCH ABS ABR 5.3
 Partner	ABS	1.6 HDI 16v 9HX	BOSCH ABS ABR 5.3
 Partner	ABS	1.6 N6A	BOSCH ABS ABR 5.3
 Partner	ABS	1.9 D WJY	BOSCH ABS ABR 5.3
 Partner	ABS	2.0 HDI RHY	BOSCH ABS ABR 5.3
 Partner	ABS	2.0 HDI RHZ	BOSCH ABS ABR 5.3
 Partner	AIRBAG	1.1 HDY	AKF- Autoliv AirBag no SIDE AB
 Partner	AIRBAG	1.1 HDZ	AKF- Autoliv AirBag no SIDE AB
 Partner	AIRBAG	1.4 KFW	AKF- Autoliv AirBag no SIDE AB
 Partner	AIRBAG	1.4 KFX	AKF- Autoliv AirBag no SIDE AB
 Partner	AIRBAG	1.6 16v NFU	AKF- Autoliv AirBag no SIDE AB
 Partner	AIRBAG	1.6 HDI 16v 9HW	AKF- Autoliv AirBag no SIDE AB
 Partner	AIRBAG	1.6 HDI 16v 9HX	AKF- Autoliv AirBag no SIDE AB
 Partner	AIRBAG	1.6 N6A	AKF- Autoliv AirBag no SIDE AB
 Partner	AIRBAG	1.9 D WJY	AKF- Autoliv AirBag no SIDE AB
 Partner	AIRBAG	2.0 HDI RHY	AKF- Autoliv AirBag no SIDE AB
 Partner	AIRBAG	2.0 HDI RHZ	AKF- Autoliv AirBag no SIDE AB
 Partner	CHASSIS NETWORK	1.1 HDY	Body Computer BSI
 Partner	CHASSIS NETWORK	1.1 HDZ	Body Computer BSI

## Systems supported by ECUreader (up to V5.40)

### TRUCKS


Peugeot

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Partner	CHASSIS NETWORK	1.1 HFX	Body Computer BSI
 Partner	CHASSIS NETWORK	1.4 KFW	Body Computer BSI
 Partner	CHASSIS NETWORK	1.4 KFX	Body Computer BSI
 Partner	CHASSIS NETWORK	1.6 16v NFU	Body Computer BSI
 Partner	CHASSIS NETWORK	1.6 HDI 16v 9HW	Body Computer BSI
 Partner	CHASSIS NETWORK	1.6 HDI 16v 9HX	Body Computer BSI
 Partner	CHASSIS NETWORK	1.6 N6A	Body Computer BSI
 Partner	CHASSIS NETWORK	1.6 NFU	Body Computer BSI
 Partner	CHASSIS NETWORK	1.9 D WJY	Body Computer BSI
 Partner	CHASSIS NETWORK	2.0 HDI RHY	Body Computer BSI
 Partner	CHASSIS NETWORK	2.0 HDI RHZ	Body Computer BSI
 Partner	DASHBOARD	1.1 HDY	
 Partner	DASHBOARD	1.1 HDZ	
 Partner	DASHBOARD	1.1 HFX	
 Partner	DASHBOARD	1.4 KFW	
 Partner	DASHBOARD	1.4 KFX	
 Partner	DASHBOARD	1.6 16v NFU	
 Partner	DASHBOARD	1.6 HDI 16v 9HW	
 Partner	DASHBOARD	1.6 HDI 16v 9HX	
 Partner	DASHBOARD	1.6 N6A	
 Partner	DASHBOARD	1.9 D WJY	
 Partner	DASHBOARD	2.0 HDI RHY	
 Partner	DASHBOARD	2.0 HDI RHZ	
 Partner	DIESEL MANAGEMEN	1.9 D WJY	LUCAS Diesel DCN2
 Partner	ENGINE MANAGEME	1.1 HDY	BOSCH MonoMotronic MA3.1
 Partner	ENGINE MANAGEME	1.1 HDZ	BOSCH MonoMotronic MA3.1
 Partner	ENGINE MANAGEME	1.1 HFX	BOSCH M7.4.4

## Systems supported by ECReader (up to V5.40)

### TRUCKS




























Peugeot

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Partner	ENGINE MANAGEME	1.4 KFW	SAGEM S2000
 Partner	ENGINE MANAGEME	1.4 KFX	MARELLI MM 1AP.81
 Partner	ENGINE MANAGEME	1.4 KFX	SAGEM SL 96
 Partner	ENGINE MANAGEME	1.6 N6A	BOSCH ME7.4.4
 Partner	ENGINE MANAGEME	1.6 NFU	BOSCH ME7.4.4
 Partner	ENGINE MANAGEME	1.9 D WJY	LUCAS Diesel DCN2
 Partner	ENGINE MANAGEME	2.0 HDI RHY	BOSCH EDC 15 C2 Common Rail
 Partner	ENGINE MANAGEME	2.0 HDI RHY	SIEMENS Diesel SID 801 Common Rail
 Partner	ENGINE MANAGEME	2.0 HDI RHY	SIEMENS SID 801 Common Rail
 Partner	ENGINE MANAGEME	2.0 HDI RHY (...00)	BOSCH EDC 15 C2 Common Rail
 Partner	ENGINE MANAGEME	2.0 HDI RHY (03-..)	BOSCH EDC 15 C2 Common Rail
 Partner	ENGINE MANAGEME	2.0 HDI RHZ (...00)	BOSCH EDC 15 C2 Common Rail
 Partner	KEY ENCODE	1.1 HDY (...03)	Valeo/Siemens
 Partner	KEY ENCODE	1.1 HDY (03-..)	VALEO Body Siemens
 Partner	KEY ENCODE	1.1 HDZ (...03)	Valeo/Siemens
 Partner	KEY ENCODE	1.1 HDZ (03-..)	VALEO Body Siemens
 Partner	KEY ENCODE	1.4 KFW (...03)	Valeo/Siemens
 Partner	KEY ENCODE	1.4 KFW (03-..)	VALEO Body Siemens
 Partner	KEY ENCODE	1.4 KFX (...03)	Valeo/Siemens
 Partner	KEY ENCODE	1.4 KFX (03-..)	VALEO Body Siemens
 Partner	KEY ENCODE	1.6 16v NFU (...03)	Valeo/Siemens
 Partner	KEY ENCODE	1.6 16v NFU (03-..)	VALEO Body Siemens
 Partner	KEY ENCODE	1.6 HDI 16v 9HW (...03)	Valeo/Siemens
 Partner	KEY ENCODE	1.6 HDI 16v 9HW (03-..)	VALEO Body Siemens
 Partner	KEY ENCODE	1.6 HDI 16v 9HX (...03)	Valeo/Siemens
 Partner	KEY ENCODE	1.6 HDI 16v 9HX (03-..)	VALEO Body Siemens
 Partner	KEY ENCODE	1.6 N6A (...03)	Valeo/Siemens

## Systems supported by ECUREADER (up to V5.40)

### TRUCKS




























Peugeot

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Partner	KEY ENCODE	1.6 N6A (03-..)	VALEO Body Siemens
 Partner	KEY ENCODE	1.9 D WJY (..-03)	Valeo/Siemens
 Partner	KEY ENCODE	1.9 D WJY (03-..)	VALEO Body Siemens
 Partner	KEY ENCODE	2.0 HDI RHY (..-03)	Valeo/Siemens
 Partner	KEY ENCODE	2.0 HDI RHY (03-..)	VALEO Body Siemens
 Partner	KEY ENCODE	2.0 HDI RHZ (..-03)	Valeo/Siemens
 Partner	KEY ENCODE	2.0 HDI RHZ (03-..)	VALEO Body Siemens
 Partner	RADIO / CD	1.1 HDY	Var.1
 Partner	RADIO / CD	1.1 HDY	Var.2
 Partner	RADIO / CD	1.1 HDY	Var.3
 Partner	RADIO / CD	1.1 HDY	Var.4
 Partner	RADIO / CD	1.1 HDZ	Var.1
 Partner	RADIO / CD	1.1 HDZ	Var.2
 Partner	RADIO / CD	1.1 HDZ	Var.3
 Partner	RADIO / CD	1.1 HDZ	Var.4
 Partner	RADIO / CD	1.1 HFX	Var.1
 Partner	RADIO / CD	1.1 HFX	Var.2
 Partner	RADIO / CD	1.1 HFX	Var.3
 Partner	RADIO / CD	1.1 HFX	Var.4
 Partner	RADIO / CD	1.4 KFW	Var.1
 Partner	RADIO / CD	1.4 KFW	Var.2
 Partner	RADIO / CD	1.4 KFW	Var.3
 Partner	RADIO / CD	1.4 KFW	Var.4
 Partner	RADIO / CD	1.4 KFX	Var.1
 Partner	RADIO / CD	1.4 KFX	Var.2
 Partner	RADIO / CD	1.4 KFX	Var.3
 Partner	RADIO / CD	1.4 KFX	Var.4

## Systems supported by ECUREADER (up to V5.40)

### TRUCKS



























Peugeot

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Partner	RADIO / CD	1.6 16v NFU	Var.1
 Partner	RADIO / CD	1.6 16v NFU	Var.2
 Partner	RADIO / CD	1.6 16v NFU	Var.3
 Partner	RADIO / CD	1.6 16v NFU	Var.4
 Partner	RADIO / CD	1.6 HDI 16v 9HW	Var.1
 Partner	RADIO / CD	1.6 HDI 16v 9HW	Var.2
 Partner	RADIO / CD	1.6 HDI 16v 9HW	Var.3
 Partner	RADIO / CD	1.6 HDI 16v 9HW	Var.4
 Partner	RADIO / CD	1.6 HDI 16v 9HX	Var.1
 Partner	RADIO / CD	1.6 HDI 16v 9HX	Var.2
 Partner	RADIO / CD	1.6 HDI 16v 9HX	Var.3
 Partner	RADIO / CD	1.6 HDI 16v 9HX	Var.4
 Partner	RADIO / CD	1.6 N6A	Var.1
 Partner	RADIO / CD	1.6 N6A	Var.2
 Partner	RADIO / CD	1.6 N6A	Var.3
 Partner	RADIO / CD	1.6 N6A	Var.4
 Partner	RADIO / CD	1.9 D WJY	Var.1
 Partner	RADIO / CD	1.9 D WJY	Var.2
 Partner	RADIO / CD	1.9 D WJY	Var.3
 Partner	RADIO / CD	1.9 D WJY	Var.4
 Partner	RADIO / CD	2.0 HDI RHY	Var.1
 Partner	RADIO / CD	2.0 HDI RHY	Var.2
 Partner	RADIO / CD	2.0 HDI RHY	Var.3
 Partner	RADIO / CD	2.0 HDI RHY	Var.4
 Partner	RADIO / CD	2.0 HDI RHZ	Var.1
 Partner	RADIO / CD	2.0 HDI RHZ	Var.2
 Partner	RADIO / CD	2.0 HDI RHZ	Var.3

## Systems supported by ECUREADER (up to V5.40)

### TRUCKS




























Peugeot

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Partner	RADIO / CD	2.0 HDI RHZ	Var.4
 Ranch	ABS	1.1 HDY	BOSCH ABS ABR 5.3
 Ranch	ABS	1.1 HDZ	BOSCH ABS ABR 5.3
 Ranch	ABS	1.4 KFW	BOSCH ABS ABR 5.3
 Ranch	ABS	1.4 KFX	BOSCH ABS ABR 5.3
 Ranch	ABS	1.6 16v NFU	BOSCH ABS ABR 5.3
 Ranch	ABS	1.9 D WJY	BOSCH ABS ABR 5.3
 Ranch	ABS	2.0 HDI RHY	BOSCH ABS ABR 5.3
 Ranch	ABS	2.0 HDI RHZ	BOSCH ABS ABR 5.3
 Ranch	AIRBAG	1.1 HDY (97-00)	AKF- Autoliv AirBag no SIDE AB
 Ranch	AIRBAG	1.1 HDZ (97-00)	AKF- Autoliv AirBag no SIDE AB
 Ranch	AIRBAG	1.4 KFW (97-00)	AKF- Autoliv AirBag no SIDE AB
 Ranch	AIRBAG	1.4 KFX (97-00)	AKF- Autoliv AirBag no SIDE AB
 Ranch	AIRBAG	1.6 16v NFU (97-00)	AKF- Autoliv AirBag no SIDE AB
 Ranch	AIRBAG	1.9 D WJY (97-00)	AKF- Autoliv AirBag no SIDE AB
 Ranch	AIRBAG	2.0 HDI RHY (97-00)	AKF- Autoliv AirBag no SIDE AB
 Ranch	AIRBAG	2.0 HDI RHZ (97-00)	AKF- Autoliv AirBag no SIDE AB
 Ranch	CHASSIS NETWORK	1.1 HDY (...-01)	VALEO Body Computer
 Ranch	CHASSIS NETWORK	1.1 HDZ (...-01)	VALEO Body Computer
 Ranch	CHASSIS NETWORK	1.4 KFW (...-01)	VALEO Body Computer
 Ranch	CHASSIS NETWORK	1.4 KFX (...-01)	VALEO Body Computer
 Ranch	CHASSIS NETWORK	1.6 16v NFU (...-01)	VALEO Body Computer
 Ranch	CHASSIS NETWORK	1.9 D WJY (...-01)	VALEO Body Computer
 Ranch	CHASSIS NETWORK	2.0 HDI RHY (...-01)	VALEO Body Computer
 Ranch	CHASSIS NETWORK	2.0 HDI RHZ (...-01)	VALEO Body Computer
 Ranch	DIESEL MANAGEMEN	1.9 D WJY	LUCAS Diesel DCN2

## Systems supported by ECUREADER (up to V5.40)

### TRUCKS




























Peugeot

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Ranch	ENGINE MANAGEME	1.1 HDY	BOSCH MonoMotronic MA3.1
 Ranch	ENGINE MANAGEME	1.1 HDZ	BOSCH MonoMotronic MA3.1
 Ranch	ENGINE MANAGEME	1.4 KFW	SAGEM S2000
 Ranch	ENGINE MANAGEME	1.4 KFX	MARELLI MM 1AP.40
 Ranch	ENGINE MANAGEME	1.6 16v NFU	BOSCH Motronic ME7.4.4
 Ranch	ENGINE MANAGEME	2.0 HDI RHY	SIEMENS Diesel SID 801 Common Rail
 Ranch	ENGINE MANAGEME	2.0 HDI RHY (..-00)	BOSCH EDC 15 C2 Common Rail
 Ranch	ENGINE MANAGEME	2.0 HDI RHZ (..-99)	BOSCH EDC 15 C2 Common Rail
 Ranch	RADIO / CD	1.1 HDY	CLARION AudioSystem
 Ranch	RADIO / CD	1.1 HDY	PHILIPS AudioSystem
 Ranch	RADIO / CD	1.1 HDY	VDO AudioSystem
 Ranch	RADIO / CD	1.1 HDZ	CLARION AudioSystem
 Ranch	RADIO / CD	1.1 HDZ	PHILIPS AudioSystem
 Ranch	RADIO / CD	1.1 HDZ	VDO AudioSystem
 Ranch	RADIO / CD	1.4 KFW	CLARION AudioSystem
 Ranch	RADIO / CD	1.4 KFW	PHILIPS AudioSystem
 Ranch	RADIO / CD	1.4 KFW	VDO AudioSystem
 Ranch	RADIO / CD	1.4 KFX	CLARION AudioSystem
 Ranch	RADIO / CD	1.4 KFX	PHILIPS AudioSystem
 Ranch	RADIO / CD	1.4 KFX	VDO AudioSystem
 Ranch	RADIO / CD	1.6 16v NFU	CLARION AudioSystem
 Ranch	RADIO / CD	1.6 16v NFU	PHILIPS AudioSystem
 Ranch	RADIO / CD	1.6 16v NFU	VDO AudioSystem
 Ranch	RADIO / CD	1.9 D WJY	CLARION AudioSystem
 Ranch	RADIO / CD	1.9 D WJY	PHILIPS AudioSystem
 Ranch	RADIO / CD	1.9 D WJY	VDO AudioSystem
 Ranch	RADIO / CD	2.0 HDI RHY	CLARION AudioSystem

## Systems supported by ECUREADER (up to V5.40)

### TRUCKS



Peugeot

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Ranch	RADIO / CD	2.0 HDI RHY	PHILIPS AudioSystem
 Ranch	RADIO / CD	2.0 HDI RHY	VDO AudioSystem
 Ranch	RADIO / CD	2.0 HDI RHZ	CLARION AudioSystem
 Ranch	RADIO / CD	2.0 HDI RHZ	PHILIPS AudioSystem
 Ranch	RADIO / CD	2.0 HDI RHZ	VDO AudioSystem
 Ranch	SERVICE LIGHT RES	1.1 HDY (98-00)	VDO MANUAL
 Ranch	SERVICE LIGHT RES	1.1 HDZ (98-00)	VDO MANUAL
 Ranch	SERVICE LIGHT RES	1.4 KFW (98-00)	VDO MANUAL
 Ranch	SERVICE LIGHT RES	1.4 KFX (98-00)	VDO MANUAL
 Ranch	SERVICE LIGHT RES	1.6 16v NFU (98-00)	VDO MANUAL
 Ranch	SERVICE LIGHT RES	1.9 D WJY (98-00)	VDO MANUAL
 Ranch	SERVICE LIGHT RES	2.0 HDI RHY (98-00)	VDO MANUAL
 Ranch	SERVICE LIGHT RES	2.0 HDI RHZ (98-00)	VDO MANUAL
 Ranch	SWITCHLIGHT MODU	1.1 HDY	EATON
 Ranch	SWITCHLIGHT MODU	1.1 HDZ	EATON
 Ranch	SWITCHLIGHT MODU	1.4 KFW	EATON
 Ranch	SWITCHLIGHT MODU	1.4 KFX	EATON
 Ranch	SWITCHLIGHT MODU	1.6 16v NFU	EATON
 Ranch	SWITCHLIGHT MODU	1.9 D WJY	EATON
 Ranch	SWITCHLIGHT MODU	2.0 HDI RHY	EATON
 Ranch	SWITCHLIGHT MODU	2.0 HDI RHZ	EATON
 Ranch	VISUAL./TELEMATICS	1.1 HDY	SAGEM
 Ranch	VISUAL./TELEMATICS	1.1 HDZ	SAGEM
 Ranch	VISUAL./TELEMATICS	1.4 KFW	SAGEM
 Ranch	VISUAL./TELEMATICS	1.4 KFX	SAGEM
 Ranch	VISUAL./TELEMATICS	1.6 16v NFU	SAGEM
 Ranch	VISUAL./TELEMATICS	1.9 D WJY	SAGEM

## Systems supported by ECUreader (up to V5.40)

### TRUCKS






Peugeot

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Ranch	VISUAL./TELEMATICS	2.0 HDI RHY	SAGEM
 Ranch	VISUAL./TELEMATICS	2.0 HDI RHZ	SAGEM

## Systems supported by ECUreader (up to V5.40)

### TRUCKS



Piacenza

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Trailers	ABS	Trailers Wabco	Wabco VARIO C1-C2-C plus
 Trailers	BRAKE SYS. MANAG	Trailers	Wabco Trailer EBS
 Trailers	BRAKE SYS. MANAG	Trailers	Wabco Trailers EBS kw2000
 Trailers	BRAKE SYS. MANAG	Trailers Haldex	Haldex EBS EB+
 Trailers	BRAKE SYS. MANAG	Trailers Knorr	Knorr Trailer EBS

## Systems supported by ECUreader (up to V5.40)

### TRUCKS





























**Primball**

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Trailers	BRAKE SYS. MANAG	Trailers	Wabco Trailer EBS
 Trailers	BRAKE SYS. MANAG	Trailers	Wabco Trailer VCS II

## Systems supported by ECReader (up to V5.40)

### TRUCKS




























Renault

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Express	AIRBAG	1.2 40kw C3G-702	SIEMENS - Autoliv AirBag AC4
 Express	AIRBAG	1.2 40kw C3G-702	SIEMENS - Autoliv AirBag EC5
 Express	AIRBAG	1.2 40kw C3G-710	SIEMENS - Autoliv AirBag AC4
 Express	AIRBAG	1.2 40kw C3G-710	SIEMENS - Autoliv AirBag EC5
 Express	AIRBAG	1.4 44kw C3J-702	SIEMENS - Autoliv AirBag AC4
 Express	AIRBAG	1.4 44kw C3J-702	SIEMENS - Autoliv AirBag EC5
 Express	AIRBAG	1.4 44kw C3J-760	SIEMENS - Autoliv AirBag AC4
 Express	AIRBAG	1.4 44kw C3J-760	SIEMENS - Autoliv AirBag EC5
 Express	AIRBAG	1.4 44kw C3J-762	SIEMENS - Autoliv AirBag AC4
 Express	AIRBAG	1.4 44kw C3J-762	SIEMENS - Autoliv AirBag EC5
 Express	AIRBAG	1.4 55kw E7J-720	SIEMENS - Autoliv AirBag AC4
 Express	AIRBAG	1.4 55kw E7J-720	SIEMENS - Autoliv AirBag EC5
 Express	AIRBAG	1.4 55kw E7J-728	SIEMENS - Autoliv AirBag AC4
 Express	AIRBAG	1.4 55kw E7J-728	SIEMENS - Autoliv AirBag EC5
 Express	AIRBAG	1.4 55kw E7J-770	SIEMENS - Autoliv AirBag AC4
 Express	AIRBAG	1.4 55kw E7J-770	SIEMENS - Autoliv AirBag EC5
 Express	AIRBAG	1.4 57kw E7J-724	SIEMENS - Autoliv AirBag AC4
 Express	AIRBAG	1.4 57kw E7J-724	SIEMENS - Autoliv AirBag EC5
 Express	AIRBAG	1.4 57kw E7J-773	SIEMENS - Autoliv AirBag AC4
 Express	AIRBAG	1.4 57kw E7J-773	SIEMENS - Autoliv AirBag EC5
 Express	ENGINE MANAGEME	1.2 40kw C3G-702	MARELLI IAW 6R
 Express	ENGINE MANAGEME	1.2 40kw C3G-710	MARELLI IAW 6R
 Express	ENGINE MANAGEME	1.2 40kw C3G-710	MARELLI IAW 6R
 Express	ENGINE MANAGEME	1.2 40kw C3G-710	MARELLI IAW 6R
 Express	ENGINE MANAGEME	1.2 40kw C3G-710	MARELLI IAW 6R
 Express	ENGINE MANAGEME	1.2 40kw C3G-710	MARELLI IAW 6R
 Express	ENGINE MANAGEME	1.2 40kw C3G-710	MARELLI IAW 6R
 Express	ENGINE MANAGEME	1.2 40kw C3G-710	MARELLI IAW 6R

## Systems supported by ECReader (up to V5.40)

### TRUCKS




























Renault

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Express	ENGINE MANAGEME	1.4 44kw C3J-702	SIEMENS RENIX SPI
 Express	ENGINE MANAGEME	1.4 44kw C3J-760	SIEMENS RENIX SPI
 Express	ENGINE MANAGEME	1.4 44kw C3J-762	SIEMENS RENIX SPI
 Express	ENGINE MANAGEME	1.4 55kw E7J-720	SIEMENS BOSCH SPI
 Express	ENGINE MANAGEME	1.4 55kw E7J-720	SIEMENS BOSCH SPI
 Express	ENGINE MANAGEME	1.4 55kw E7J-720	SIEMENS BOSCH SPI
 Express	ENGINE MANAGEME	1.4 55kw E7J-720	SIEMENS BOSCH SPI
 Express	ENGINE MANAGEME	1.4 55kw E7J-720	SIEMENS BOSCH SPI
 Express	ENGINE MANAGEME	1.4 55kw E7J-728	SIEMENS BOSCH SPI
 Express	ENGINE MANAGEME	1.4 55kw E7J-728	SIEMENS BOSCH SPI
 Express	ENGINE MANAGEME	1.4 55kw E7J-728	SIEMENS BOSCH SPI
 Express	ENGINE MANAGEME	1.4 55kw E7J-728	SIEMENS BOSCH SPI
 Express	ENGINE MANAGEME	1.4 55kw E7J-728	SIEMENS BOSCH SPI
 Express	ENGINE MANAGEME	1.4 55kw E7J-770	SIEMENS BOSCH SPI
 Express	ENGINE MANAGEME	1.4 57kw E7J-724	SIEMENS BOSCH SPI
 Express	ENGINE MANAGEME	1.4 57kw E7J-724	SIEMENS BOSCH SPI
 Express	ENGINE MANAGEME	1.4 57kw E7J-724	SIEMENS BOSCH SPI
 Express	ENGINE MANAGEME	1.4 57kw E7J-724	SIEMENS BOSCH SPI
 Express	ENGINE MANAGEME	1.4 57kw E7J-724	SIEMENS BOSCH SPI
 Express	ENGINE MANAGEME	1.4 57kw E7J-724	SIEMENS BOSCH SPI
 Express	ENGINE MANAGEME	1.4 57kw E7J-773	SIEMENS BOSCH SPI
 Express	ENGINE MANAGEME	1.4 57kw E7J-773	SIEMENS BOSCH SPI
 Express	ENGINE MANAGEME	1.4 57kw E7J-773	SIEMENS BOSCH SPI
 Kangoo II	ABS	1.5 dCi 50kw K9K-802 (08-..)	BOSCH ABS 8.0
 Kangoo II	ABS	1.5 dCi 63kw K9K-802 (08-..)	BOSCH ABS 8.0
 Kangoo II	ABS	1.5 dCi 66kw K9K-808 (08-..)	BOSCH ABS 8.0
 Kangoo II	ABS	1.5 dCi 78kw K9K-804 (08-..)	BOSCH ABS 8.0

## Systems supported by ECReader (up to V5.40)

### TRUCKS

**Renault**

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Kangoo II	ABS	1.5 dCi FAP 76kw K9K-806 (08-..)	BOSCH ABS 8.0
 Kangoo II	ABS	1.6 16v 78kw K4M-830 (08-..)	BOSCH ABS 8.0
 Kangoo II	ABS	1.6 16v 78kw K4M-831 (08-..)	BOSCH ABS 8.0
 Kangoo II	ABS	1.6 16v 78kw K4M-834 (08-..)	BOSCH ABS 8.0
 Kangoo II	ABS	1.6 64kw K7M-750 (08-..)	BOSCH ABS 8.0
 Kangoo II	AIRBAG	1.5 dCi 50kw K9K-802 (08-..)	BOSCH AirBag AB9
 Kangoo II	AIRBAG	1.5 dCi 63kw K9K-802 (08-..)	BOSCH AirBag AB9
 Kangoo II	AIRBAG	1.5 dCi 66kw K9K-808 (08-..)	BOSCH AirBag AB9
 Kangoo II	AIRBAG	1.5 dCi 78kw K9K-804 (08-..)	BOSCH AirBag AB9
 Kangoo II	AIRBAG	1.5 dCi FAP 76kw K9K-806 (08-..)	BOSCH AirBag AB9
 Kangoo II	AIRBAG	1.6 16v 78kw K4M-830 (08-..)	BOSCH AirBag AB9
 Kangoo II	AIRBAG	1.6 16v 78kw K4M-831 (08-..)	BOSCH AirBag AB9
 Kangoo II	AIRBAG	1.6 16v 78kw K4M-834 (08-..)	BOSCH AirBag AB9
 Kangoo II	AIRBAG	1.6 64kw K7M-750 (08-..)	BOSCH AirBag AB9
 Kangoo II	CHASSIS NETWORK	1.5 dCi 50kw K9K-802 (08-..)	Body Computer UCH
 Kangoo II	CHASSIS NETWORK	1.5 dCi 50kw K9K-802 (08-..)	Body Computer UPC
 Kangoo II	CHASSIS NETWORK	1.5 dCi 63kw K9K-802 (08-..)	Body Computer UCH
 Kangoo II	CHASSIS NETWORK	1.5 dCi 63kw K9K-802 (08-..)	Body Computer UPC
 Kangoo II	CHASSIS NETWORK	1.5 dCi 66kw K9K-808 (08-..)	Body Computer UCH
 Kangoo II	CHASSIS NETWORK	1.5 dCi 66kw K9K-808 (08-..)	Body Computer UPC
 Kangoo II	CHASSIS NETWORK	1.5 dCi 78kw K9K-804 (08-..)	Body Computer UCH
 Kangoo II	CHASSIS NETWORK	1.5 dCi 78kw K9K-804 (08-..)	Body Computer UPC
 Kangoo II	CHASSIS NETWORK	1.5 dCi FAP 76kw K9K-806 (08-..)	Body Computer UCH
 Kangoo II	CHASSIS NETWORK	1.5 dCi FAP 76kw K9K-806 (08-..)	Body Computer UPC
 Kangoo II	CHASSIS NETWORK	1.6 16v 78kw K4M-830 (08-..)	Body Computer UCH
 Kangoo II	CHASSIS NETWORK	1.6 16v 78kw K4M-830 (08-..)	Body Computer UPC
 Kangoo II	CHASSIS NETWORK	1.6 16v 78kw K4M-831 (08-..)	Body Computer UCH

## Systems supported by ECUREADER (up to V5.40)

### TRUCKS



























Renault

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Kangoo II	CHASSIS NETWORK	1.6 16v 78kw K4M-831 (08-..)	Body Computer UPC
 Kangoo II	CHASSIS NETWORK	1.6 16v 78kw K4M-834 (08-..)	Body Computer UCH
 Kangoo II	CHASSIS NETWORK	1.6 16v 78kw K4M-834 (08-..)	Body Computer UPC
 Kangoo II	CHASSIS NETWORK	1.6 64kw K7M-750 (08-..)	Body Computer UCH
 Kangoo II	CHASSIS NETWORK	1.6 64kw K7M-750 (08-..)	Body Computer UPC
 Kangoo II	DASHBOARD	1.5 dCi 50kw K9K-802 (08-..)	SAGEM Kombi
 Kangoo II	DASHBOARD	1.5 dCi 63kw K9K-802 (08-..)	SAGEM Kombi
 Kangoo II	DASHBOARD	1.5 dCi 66kw K9K-808 (08-..)	SAGEM Kombi
 Kangoo II	DASHBOARD	1.5 dCi 78kw K9K-804 (08-..)	SAGEM Kombi
 Kangoo II	DASHBOARD	1.5 dCi FAP 76kw K9K-806 (08-..)	SAGEM Kombi
 Kangoo II	DASHBOARD	1.6 16v 78kw K4M-830 (08-..)	SAGEM Kombi
 Kangoo II	DASHBOARD	1.6 16v 78kw K4M-831 (08-..)	SAGEM Kombi
 Kangoo II	DASHBOARD	1.6 16v 78kw K4M-834 (08-..)	SAGEM Kombi
 Kangoo II	DASHBOARD	1.6 64kw K7M-750 (08-..)	SAGEM Kombi
 Kangoo II	ELECTRIC STEERING	1.5 dCi 50kw K9K-802 (08-..)	KOYO EPS
 Kangoo II	ELECTRIC STEERING	1.5 dCi 63kw K9K-802 (08-..)	KOYO EPS
 Kangoo II	ELECTRIC STEERING	1.5 dCi 66kw K9K-808 (08-..)	KOYO EPS
 Kangoo II	ELECTRIC STEERING	1.5 dCi 78kw K9K-804 (08-..)	KOYO EPS
 Kangoo II	ELECTRIC STEERING	1.5 dCi FAP 76kw K9K-806 (08-..)	KOYO EPS
 Kangoo II	ELECTRIC STEERING	1.6 16v 78kw K4M-830 (08-..)	KOYO EPS
 Kangoo II	ELECTRIC STEERING	1.6 16v 78kw K4M-831 (08-..)	KOYO EPS
 Kangoo II	ELECTRIC STEERING	1.6 16v 78kw K4M-834 (08-..)	KOYO EPS
 Kangoo II	ELECTRIC STEERING	1.6 64kw K7M-750 (08-..)	KOYO EPS
 Kangoo II	ENGINE MANAGEME	1.5 dCi 66kw K9K-808 (08-..)	DELPHI EDC Common Rail
 Kangoo II	ENGINE MANAGEME	1.5 dCi 78kw K9K-804 (08-..)	DELPHI EDC Common Rail
 Kangoo II	SERVICE LIGHT RES	1.5 dCi 50kw K9K-802 (08-..)	MANUAL
 Kangoo II	SERVICE LIGHT RES	1.5 dCi 63kw K9K-802 (08-..)	MANUAL

## Systems supported by ECUREADER (up to V5.40)

### TRUCKS




























Renault

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Kangoo II	SERVICE LIGHT RES	1.5 dCi 66kw K9K-808 (08-..)	MANUAL
 Kangoo II	SERVICE LIGHT RES	1.5 dCi 78kw K9K-804 (08-..)	MANUAL
 Kangoo II	SERVICE LIGHT RES	1.5 dCi FAP 76kw K9K-806 (08-..)	MANUAL
 Kangoo II	SERVICE LIGHT RES	1.6 16v 78kw K4M-830 (08-..)	MANUAL
 Kangoo II	SERVICE LIGHT RES	1.6 16v 78kw K4M-831 (08-..)	MANUAL
 Kangoo II	SERVICE LIGHT RES	1.6 16v 78kw K4M-834 (08-..)	MANUAL
 Kangoo II	SERVICE LIGHT RES	1.6 64kw K7M-750 (08-..)	MANUAL
 Kangoo	ABS	1.2 16v 55kw D4F-712	BOSCH ABS 5.3
 Kangoo	ABS	1.2 16v 55kw D4F-712	BOSCH ABS 5.3 T
 Kangoo	ABS	1.2 44kw D7F-726	BOSCH ABS 5.3
 Kangoo	ABS	1.2 44kw D7F-726	BOSCH ABS 5.3 T
 Kangoo	ABS	1.2 44kw D7F-746	BOSCH ABS 5.3
 Kangoo	ABS	1.2 44kw D7F-746	BOSCH ABS 5.3 T
 Kangoo	ABS	1.4 55kw E7J-634	BOSCH ABS 5.3
 Kangoo	ABS	1.4 55kw E7J-634	BOSCH ABS 5.3 T
 Kangoo	ABS	1.4 55kw E7J-635	BOSCH ABS 5.3
 Kangoo	ABS	1.4 55kw E7J-635	BOSCH ABS 5.3 T
 Kangoo	ABS	1.4 55kw E7J-780	BOSCH ABS 5.3
 Kangoo	ABS	1.4 55kw E7J-780	BOSCH ABS 5.3 T
 Kangoo	ABS	1.5 dCi 42kw K9K-710	BOSCH ABS 5.3
 Kangoo	ABS	1.5 dCi 42kw K9K-710	BOSCH ABS 5.3 T
 Kangoo	ABS	1.5 dCi 48kw K9K-700	BOSCH ABS 5.3
 Kangoo	ABS	1.5 dCi 48kw K9K-700	BOSCH ABS 5.3 T
 Kangoo	ABS	1.5 dCi 48kw K9K-704	BOSCH ABS 5.3
 Kangoo	ABS	1.5 dCi 48kw K9K-704	BOSCH ABS 5.3 T
 Kangoo	ABS	1.5 dCi 60kw K9K-702	BOSCH ABS 5.3

## Systems supported by ECUREADER (up to V5.40)

### TRUCKS




























Renault

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Kangoo	ABS	1.5 dCi 60kw K9K-702	BOSCH ABS 5.3 T
 Kangoo	ABS	1.5 dCi 60kw K9K-706	BOSCH ABS 5.3
 Kangoo	ABS	1.5 dCi 60kw K9K-706	BOSCH ABS 5.3 T
 Kangoo	ABS	1.6 16v 70kw K4M-750	BOSCH ABS 5.3
 Kangoo	ABS	1.6 16v 70kw K4M-750	BOSCH ABS 5.3 T
 Kangoo	ABS	1.9 D 40kw F8Q-662	BOSCH ABS 5.3
 Kangoo	ABS	1.9 D 40kw F8Q-662	BOSCH ABS 5.3 T
 Kangoo	ABS	1.9 D 48kw F8Q-630	BOSCH ABS 5.3
 Kangoo	ABS	1.9 D 48kw F8Q-630	BOSCH ABS 5.3 T
 Kangoo	ABS	1.9 D 48kw F8Q-632	BOSCH ABS 5.3
 Kangoo	ABS	1.9 D 48kw F8Q-632	BOSCH ABS 5.3 T
 Kangoo	ABS	1.9 D 48kw F8Q-660	BOSCH ABS 5.3
 Kangoo	ABS	1.9 D 48kw F8Q-660	BOSCH ABS 5.3 T
 Kangoo	ABS	1.9 dCi 59kw F9Q-790	BOSCH ABS 5.3
 Kangoo	ABS	1.9 dCi 59kw F9Q-790	BOSCH ABS 5.3 T
 Kangoo	ABS	1.9 dTi 59kw F9Q-780	BOSCH ABS 5.3
 Kangoo	ABS	1.9 dTi 59kw F9Q-780	BOSCH ABS 5.3 T
 Kangoo	ABS	1.9 dTi 59kw F9Q-782	BOSCH ABS 5.3
 Kangoo	ABS	1.9 dTi 59kw F9Q-782	BOSCH ABS 5.3 T
 Kangoo	AIRBAG	1.2 16v 55kw D4F-712	SAGEM - Autoliv AirBag ACU 3
 Kangoo	AIRBAG	1.2 16v 55kw D4F-712	SIEMENS - Autoliv AirBag AC4
 Kangoo	AIRBAG	1.2 16v 55kw D4F-712	SIEMENS - Autoliv AirBag AC6
 Kangoo	AIRBAG	1.2 16v 55kw D4F-712	SIEMENS - Autoliv AirBag EC5
 Kangoo	AIRBAG	1.2 44kw D7F-726	SAGEM - Autoliv AirBag ACU 3
 Kangoo	AIRBAG	1.2 44kw D7F-726	SIEMENS - Autoliv AirBag AC4
 Kangoo	AIRBAG	1.2 44kw D7F-726	SIEMENS - Autoliv AirBag AC6
 Kangoo	AIRBAG	1.2 44kw D7F-726	SIEMENS - Autoliv AirBag EC5

## Systems supported by ECReader (up to V5.40)

### TRUCKS




























**Renault**

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Kangoo	AIRBAG	1.2 44kw D7F-746	SAGEM - Autoliv AirBag ACU 3
 Kangoo	AIRBAG	1.2 44kw D7F-746	SIEMENS - Autoliv AirBag AC4
 Kangoo	AIRBAG	1.2 44kw D7F-746	SIEMENS - Autoliv AirBag AC6
 Kangoo	AIRBAG	1.2 44kw D7F-746	SIEMENS - Autoliv AirBag EC5
 Kangoo	AIRBAG	1.4 55kw E7J-634	SAGEM - Autoliv AirBag ACU 3
 Kangoo	AIRBAG	1.4 55kw E7J-634	SIEMENS - Autoliv AirBag AC4
 Kangoo	AIRBAG	1.4 55kw E7J-634	SIEMENS - Autoliv AirBag AC6
 Kangoo	AIRBAG	1.4 55kw E7J-634	SIEMENS - Autoliv AirBag EC5
 Kangoo	AIRBAG	1.4 55kw E7J-635	SAGEM - Autoliv AirBag ACU 3
 Kangoo	AIRBAG	1.4 55kw E7J-635	SIEMENS - Autoliv AirBag AC4
 Kangoo	AIRBAG	1.4 55kw E7J-635	SIEMENS - Autoliv AirBag AC6
 Kangoo	AIRBAG	1.4 55kw E7J-635	SIEMENS - Autoliv AirBag EC5
 Kangoo	AIRBAG	1.4 55kw E7J-780	SAGEM - Autoliv AirBag ACU 3
 Kangoo	AIRBAG	1.4 55kw E7J-780	SIEMENS - Autoliv AirBag AC4
 Kangoo	AIRBAG	1.4 55kw E7J-780	SIEMENS - Autoliv AirBag AC6
 Kangoo	AIRBAG	1.4 55kw E7J-780	SIEMENS - Autoliv AirBag EC5
 Kangoo	AIRBAG	1.5 dCi 42kw K9K-710	SAGEM - Autoliv AirBag ACU 3
 Kangoo	AIRBAG	1.5 dCi 42kw K9K-710	SIEMENS - Autoliv AirBag AC4
 Kangoo	AIRBAG	1.5 dCi 42kw K9K-710	SIEMENS - Autoliv AirBag AC6
 Kangoo	AIRBAG	1.5 dCi 42kw K9K-710	SIEMENS - Autoliv AirBag EC5
 Kangoo	AIRBAG	1.5 dCi 48kw K9K-700	SAGEM - Autoliv AirBag ACU 3
 Kangoo	AIRBAG	1.5 dCi 48kw K9K-700	SIEMENS - Autoliv AirBag AC4
 Kangoo	AIRBAG	1.5 dCi 48kw K9K-700	SIEMENS - Autoliv AirBag AC6
 Kangoo	AIRBAG	1.5 dCi 48kw K9K-700	SIEMENS - Autoliv AirBag EC5
 Kangoo	AIRBAG	1.5 dCi 48kw K9K-704	SAGEM - Autoliv AirBag ACU 3
 Kangoo	AIRBAG	1.5 dCi 48kw K9K-704	SIEMENS - Autoliv AirBag AC4
 Kangoo	AIRBAG	1.5 dCi 48kw K9K-704	SIEMENS - Autoliv AirBag AC6

## Systems supported by ECReader (up to V5.40)

### TRUCKS



























Renault

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Kangoo	AIRBAG	1.5 dCi 48kw K9K-704	SIEMENS - Autoliv AirBag EC5
 Kangoo	AIRBAG	1.5 dCi 60kw K9K-702	SAGEM - Autoliv AirBag ACU 3
 Kangoo	AIRBAG	1.5 dCi 60kw K9K-702	SIEMENS - Autoliv AirBag AC4
 Kangoo	AIRBAG	1.5 dCi 60kw K9K-702	SIEMENS - Autoliv AirBag AC6
 Kangoo	AIRBAG	1.5 dCi 60kw K9K-702	SIEMENS - Autoliv AirBag EC5
 Kangoo	AIRBAG	1.5 dCi 60kw K9K-706	SAGEM - Autoliv AirBag ACU 3
 Kangoo	AIRBAG	1.5 dCi 60kw K9K-706	SIEMENS - Autoliv AirBag AC4
 Kangoo	AIRBAG	1.5 dCi 60kw K9K-706	SIEMENS - Autoliv AirBag AC6
 Kangoo	AIRBAG	1.5 dCi 60kw K9K-706	SIEMENS - Autoliv AirBag EC5
 Kangoo	AIRBAG	1.6 16v 70kw K4M-750	SAGEM - Autoliv AirBag ACU 3
 Kangoo	AIRBAG	1.6 16v 70kw K4M-750	SIEMENS - Autoliv AirBag AC4
 Kangoo	AIRBAG	1.6 16v 70kw K4M-750	SIEMENS - Autoliv AirBag AC6
 Kangoo	AIRBAG	1.6 16v 70kw K4M-750	SIEMENS - Autoliv AirBag EC5
 Kangoo	AIRBAG	1.9 D 40kw F8Q-662	SAGEM - Autoliv AirBag ACU 3
 Kangoo	AIRBAG	1.9 D 40kw F8Q-662	SIEMENS - Autoliv AirBag AC4
 Kangoo	AIRBAG	1.9 D 40kw F8Q-662	SIEMENS - Autoliv AirBag AC6
 Kangoo	AIRBAG	1.9 D 40kw F8Q-662	SIEMENS - Autoliv AirBag EC5
 Kangoo	AIRBAG	1.9 D 48kw F8Q-630	SAGEM - Autoliv AirBag ACU 3
 Kangoo	AIRBAG	1.9 D 48kw F8Q-630	SIEMENS - Autoliv AirBag AC4
 Kangoo	AIRBAG	1.9 D 48kw F8Q-630	SIEMENS - Autoliv AirBag AC6
 Kangoo	AIRBAG	1.9 D 48kw F8Q-630	SIEMENS - Autoliv AirBag EC5
 Kangoo	AIRBAG	1.9 D 48kw F8Q-632	SAGEM - Autoliv AirBag ACU 3
 Kangoo	AIRBAG	1.9 D 48kw F8Q-632	SIEMENS - Autoliv AirBag AC4
 Kangoo	AIRBAG	1.9 D 48kw F8Q-632	SIEMENS - Autoliv AirBag AC6
 Kangoo	AIRBAG	1.9 D 48kw F8Q-632	SIEMENS - Autoliv AirBag EC5
 Kangoo	AIRBAG	1.9 D 48kw F8Q-660	SAGEM - Autoliv AirBag ACU 3
 Kangoo	AIRBAG	1.9 D 48kw F8Q-660	SIEMENS - Autoliv AirBag AC4

## Systems supported by ECUREADER (up to V5.40)

### TRUCKS




























Renault

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Kangoo	AIRBAG	1.9 D 48kw F8Q-660	SIEMENS - Autoliv AirBag AC6
 Kangoo	AIRBAG	1.9 D 48kw F8Q-660	SIEMENS - Autoliv AirBag EC5
 Kangoo	AIRBAG	1.9 dCi 59kw F9Q-790	SAGEM - Autoliv AirBag ACU 3
 Kangoo	AIRBAG	1.9 dCi 59kw F9Q-790	SIEMENS - Autoliv AirBag AC4
 Kangoo	AIRBAG	1.9 dCi 59kw F9Q-790	SIEMENS - Autoliv AirBag AC6
 Kangoo	AIRBAG	1.9 dCi 59kw F9Q-790	SIEMENS - Autoliv AirBag EC5
 Kangoo	AIRBAG	1.9 dTi 59kw F9Q-780	SAGEM - Autoliv AirBag ACU 3
 Kangoo	AIRBAG	1.9 dTi 59kw F9Q-780	SIEMENS - Autoliv AirBag AC4
 Kangoo	AIRBAG	1.9 dTi 59kw F9Q-780	SIEMENS - Autoliv AirBag AC6
 Kangoo	AIRBAG	1.9 dTi 59kw F9Q-780	SIEMENS - Autoliv AirBag EC5
 Kangoo	AIRBAG	1.9 dTi 59kw F9Q-782	SAGEM - Autoliv AirBag ACU 3
 Kangoo	AIRBAG	1.9 dTi 59kw F9Q-782	SIEMENS - Autoliv AirBag AC4
 Kangoo	AIRBAG	1.9 dTi 59kw F9Q-782	SIEMENS - Autoliv AirBag AC6
 Kangoo	AIRBAG	1.9 dTi 59kw F9Q-782	SIEMENS - Autoliv AirBag EC5
 Kangoo	DIESEL MANAGEMEN	1.9 D 40kw F8Q-662	SIEMENS Diesel DCU3R
 Kangoo	DIESEL MANAGEMEN	1.9 D 40kw F8Q-662 (...99)	LUCAS Diesel DPCN1
 Kangoo	DIESEL MANAGEMEN	1.9 D 48kw F8Q-630	SIEMENS Diesel DCU3R
 Kangoo	DIESEL MANAGEMEN	1.9 D 48kw F8Q-630 (...99)	LUCAS Diesel DPCN1
 Kangoo	DIESEL MANAGEMEN	1.9 D 48kw F8Q-632	SIEMENS Diesel DCU3R
 Kangoo	DIESEL MANAGEMEN	1.9 D 48kw F8Q-632 (...99)	LUCAS Diesel DPCN1
 Kangoo	DIESEL MANAGEMEN	1.9 D 48kw F8Q-660	SIEMENS Diesel DCU3R
 Kangoo	DIESEL MANAGEMEN	1.9 D 48kw F8Q-660 (...99)	LUCAS Diesel DPCN1
 Kangoo	DIESEL MANAGEMEN	1.9 dTi 59kw F9Q-780	BOSCH MSA 15
 Kangoo	DIESEL MANAGEMEN	1.9 dTi 59kw F9Q-782	BOSCH MSA 15
 Kangoo	ENGINE MANAGEME	1.2 16v 55kw D4F-712	SIEMENS Sirius 32 AUTODETECT
 Kangoo	ENGINE MANAGEME	1.2 16v 55kw D4F-712	SIEMENS Sirius 32 MUX
 Kangoo	ENGINE MANAGEME	1.2 44kw D7F-726	SAGEM SAFIR MPI

## Systems supported by ECUreader (up to V5.40)

### TRUCKS




























Renault

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Kangoo	ENGINE MANAGEME	1.2 44kw D7F-726	SAGEM SAFIR MPI
 Kangoo	ENGINE MANAGEME	1.2 44kw D7F-726	SAGEM SAFIR MPI
 Kangoo	ENGINE MANAGEME	1.2 44kw D7F-726	SAGEM SAFIR MPI
 Kangoo	ENGINE MANAGEME	1.2 44kw D7F-726	SAGEM SAFIR MPI
 Kangoo	ENGINE MANAGEME	1.2 44kw D7F-726	SAGEM SAFIR MPI
 Kangoo	ENGINE MANAGEME	1.2 44kw D7F-726	SAGEM SAFIR MPI
 Kangoo	ENGINE MANAGEME	1.2 44kw D7F-726	SAGEM SAFIR MPI
 Kangoo	ENGINE MANAGEME	1.2 44kw D7F-726	SIEMENS Sirius 32
 Kangoo	ENGINE MANAGEME	1.2 44kw D7F-726	SIEMENS Sirius 32 AUTODETECT
 Kangoo	ENGINE MANAGEME	1.2 44kw D7F-726	SIEMENS Sirius 32 MUX AUTODETECT
 Kangoo	ENGINE MANAGEME	1.2 44kw D7F-746	SAGEM SAFIR MPI
 Kangoo	ENGINE MANAGEME	1.2 44kw D7F-746	SAGEM SAFIR MPI
 Kangoo	ENGINE MANAGEME	1.2 44kw D7F-746	SAGEM SAFIR MPI
 Kangoo	ENGINE MANAGEME	1.2 44kw D7F-746	SAGEM SAFIR MPI
 Kangoo	ENGINE MANAGEME	1.2 44kw D7F-746	SAGEM SAFIR MPI
 Kangoo	ENGINE MANAGEME	1.2 44kw D7F-746	SAGEM SAFIR MPI
 Kangoo	ENGINE MANAGEME	1.2 44kw D7F-746	SAGEM SAFIR MPI
 Kangoo	ENGINE MANAGEME	1.2 44kw D7F-746	SAGEM SAFIR MPI
 Kangoo	ENGINE MANAGEME	1.2 44kw D7F-746	SIEMENS Sirius 32
 Kangoo	ENGINE MANAGEME	1.4 55kw D7F-746	SIEMENS Sirius 32 AUTODETECT
 Kangoo	ENGINE MANAGEME	1.4 55kw D7F-746	SIEMENS Sirius 32 MUX
 Kangoo	ENGINE MANAGEME	1.4 55kw E7J-634	SIEMENS FENIX 5
 Kangoo	ENGINE MANAGEME	1.4 55kw E7J-634	SIEMENS Sirius 32
 Kangoo	ENGINE MANAGEME	1.4 55kw E7J-634	SIEMENS Sirius 32 AUTODETECT
 Kangoo	ENGINE MANAGEME	1.4 55kw E7J-634	SIEMENS Sirius 32 MUX AUTODETECT
 Kangoo	ENGINE MANAGEME	1.4 55kw E7J-634 (01-..)	EOBD
 Kangoo	ENGINE MANAGEME	1.4 55kw E7J-635	SIEMENS FENIX 5

## Systems supported by ECReader (up to V5.40)

### TRUCKS




**Renault**

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Kangoo	ENGINE MANAGEME	1.4 55kw E7J-635	SIEMENS Sirius 32
 Kangoo	ENGINE MANAGEME	1.4 55kw E7J-635	SIEMENS Sirius 32 AUTODETECT
 Kangoo	ENGINE MANAGEME	1.4 55kw E7J-635	SIEMENS Sirius 32 MUX AUTODETECT
 Kangoo	ENGINE MANAGEME	1.4 55kw E7J-635 (01-..)	EOBD
 Kangoo	ENGINE MANAGEME	1.4 55kw E7J-780	SIEMENS FENIX 5
 Kangoo	ENGINE MANAGEME	1.4 55kw E7J-780	SIEMENS Sirius 32
 Kangoo	ENGINE MANAGEME	1.4 55kw E7J-780	SIEMENS Sirius 32 AUTODETECT
 Kangoo	ENGINE MANAGEME	1.4 55kw E7J-780	SIEMENS Sirius 32 MUX AUTODETECT
 Kangoo	ENGINE MANAGEME	1.4 55kw E7J-780 (01-..)	EOBD
 Kangoo	ENGINE MANAGEME	1.5 dCi 42kw K9K-710	DELPHI LUCAS LVCR Common Rail
 Kangoo	ENGINE MANAGEME	1.5 dCi 42kw K9K-710 (04-..)	SIEMENS EDC SID
 Kangoo	ENGINE MANAGEME	1.5 dCi 42kw K9K-710 (05-..)	SIEMENS EDC SID
 Kangoo	ENGINE MANAGEME	1.5 dCi 42kw K9K-710 (06-..)	SIEMENS EDC SID 301 Common Rail
 Kangoo	ENGINE MANAGEME	1.5 dCi 48kw K9K-700	DELPHI LUCAS LVCR Common Rail
 Kangoo	ENGINE MANAGEME	1.5 dCi 48kw K9K-700 (04-..)	SIEMENS EDC SID
 Kangoo	ENGINE MANAGEME	1.5 dCi 48kw K9K-700 (05-..)	SIEMENS EDC SID
 Kangoo	ENGINE MANAGEME	1.5 dCi 48kw K9K-700 (06-..)	SIEMENS EDC SID 301 Common Rail
 Kangoo	ENGINE MANAGEME	1.5 dCi 48kw K9K-704	DELPHI LUCAS LVCR Common Rail
 Kangoo	ENGINE MANAGEME	1.5 dCi 48kw K9K-704 (04-..)	SIEMENS EDC SID
 Kangoo	ENGINE MANAGEME	1.5 dCi 48kw K9K-704 (05-..)	SIEMENS EDC SID
 Kangoo	ENGINE MANAGEME	1.5 dCi 48kw K9K-704 (06-..)	SIEMENS EDC SID 301 Common Rail
 Kangoo	ENGINE MANAGEME	1.5 dCi 60kw K9K-702	DELPHI LUCAS LVCR Common Rail
 Kangoo	ENGINE MANAGEME	1.5 dCi 60kw K9K-702 (04-..)	SIEMENS EDC SID
 Kangoo	ENGINE MANAGEME	1.5 dCi 60kw K9K-702 (05-..)	SIEMENS EDC SID
 Kangoo	ENGINE MANAGEME	1.5 dCi 60kw K9K-702 (06-..)	SIEMENS EDC SID 301 Common Rail
 Kangoo	ENGINE MANAGEME	1.5 dCi 60kw K9K-706	DELPHI LUCAS LVCR Common Rail
 Kangoo	ENGINE MANAGEME	1.5 dCi 60kw K9K-706 (04-..)	SIEMENS EDC SID

## Systems supported by ECReader (up to V5.40)

### TRUCKS



























Renault

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Kangoo	ENGINE MANAGEME	1.5 dCi 60kw K9K-706 (05-..)	SIEMENS EDC SID
 Kangoo	ENGINE MANAGEME	1.5 dCi 60kw K9K-706 (06-..)	SIEMENS EDC SID 301 Common Rail
 Kangoo	ENGINE MANAGEME	1.6 16v 70kw K4M-750	SIEMENS Sirius 32
 Kangoo	ENGINE MANAGEME	1.6 16v 70kw K4M-750	SIEMENS Sirius 32 AUTODETECT
 Kangoo	ENGINE MANAGEME	1.6 16v 70kw K4M-750	SIEMENS Sirius 32 MUX AUTODETECT
 Kangoo	ENGINE MANAGEME	1.9 D 40kw F8Q-662	LUCAS Diesel DCU3R
 Kangoo	ENGINE MANAGEME	1.9 D 48kw F8Q-630	LUCAS Diesel DCU3R
 Kangoo	ENGINE MANAGEME	1.9 D 48kw F8Q-632	LUCAS Diesel DCU3R
 Kangoo	ENGINE MANAGEME	1.9 D 48kw F8Q-660	LUCAS Diesel DCU3R
 Kangoo	ENGINE MANAGEME	1.9 dCi 59kw F9Q-790 (...00)	BOSCH EDC 15 C3 Common Rail
 Kangoo	ENGINE MANAGEME	1.9 dCi 59kw F9Q-790 (01-..)	BOSCH EDC 15 C3 Common Rail
 Kangoo	IMMOBILIZER	1.2 16v 55kw D4F-712	Immobilizer Body Computer
 Kangoo	IMMOBILIZER	1.2 44kw D7F-726	Immobilizer Body Computer
 Kangoo	IMMOBILIZER	1.4 55kw E7J-634	Immobilizer Body Computer
 Kangoo	IMMOBILIZER	1.4 55kw E7J-635	Immobilizer Body Computer
 Kangoo	IMMOBILIZER	1.4 55kw E7J-780	Immobilizer Body Computer
 Kangoo	IMMOBILIZER	1.5 dCi 42kw K9K-710	Immobilizer Body Computer
 Kangoo	IMMOBILIZER	1.5 dCi 48kw K9K-700	Immobilizer Body Computer
 Kangoo	IMMOBILIZER	1.5 dCi 60kw K9K-702	Immobilizer Body Computer
 Kangoo	IMMOBILIZER	1.5 dCi 60kw K9K-704	Immobilizer Body Computer
 Kangoo	IMMOBILIZER	1.5 dCi 60kw K9K-706	Immobilizer Body Computer
 Kangoo	IMMOBILIZER	1.6 16v 70kw K4M-750	Immobilizer Body Computer
 Kangoo	IMMOBILIZER	1.9 D 40kw F8Q-662	Immobilizer Body Computer
 Kangoo	IMMOBILIZER	1.9 D 48kw F8Q-630	Immobilizer Body Computer
 Kangoo	IMMOBILIZER	1.9 D 48kw F8Q-632	Immobilizer Body Computer
 Kangoo	IMMOBILIZER	1.9 D 48kw F8Q-660	Immobilizer Body Computer
 Kangoo	IMMOBILIZER	1.9 dCi 59kw F9Q-790	Immobilizer Body Computer

## Systems supported by ECUREADER (up to V5.40)

### TRUCKS


























**Renault**

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Kangoo	IMMOBILIZER	1.9 dTi 59kw F9Q-780	Immobilizer Body Computer
 Kangoo	IMMOBILIZER	1.9 dTi 59kw F9Q-782	Immobilizer Body Computer
 Master	ABS	2.2 16v dCi 66kw G9T-722	TEVES ABS MK20T
 Master	ABS	2.2 16v dCi 66kw G9T-722 (01-..)	TEVES ABS Mk60
 Master	ABS	2.2 J7T-782	TEVES ABS MK20T
 Master	ABS	2.2 J7T-782 (01-..)	TEVES ABS Mk60
 Master	ABS	2.2 J7T-788	TEVES ABS MK20T
 Master	ABS	2.2 J7T-788 (01-..)	TEVES ABS Mk60
 Master	ABS	2.5 dCi 74kw G9U-650	TEVES ABS MK20T
 Master	ABS	2.5 dCi 74kw G9U-650 (01-..)	TEVES ABS Mk60
 Master	ABS	2.5 dCi 74kw G9U-726	TEVES ABS MK20T
 Master	ABS	2.5 dCi 74kw G9U-726 (01-..)	TEVES ABS Mk60
 Master	ABS	2.5 dCi 85kw G9U-720	TEVES ABS MK20T
 Master	ABS	2.5 dCi 85kw G9U-720 (01-..)	TEVES ABS Mk60
 Master	ABS	2.5 dCi 88kw G9U-650	TEVES ABS MK20T
 Master	ABS	2.5 dCi 88kw G9U-650 (01-..)	TEVES ABS Mk60
 Master	AIRBAG	2.2 16v dCi 66kw G9T-722	SAGEM - Autoliv AirBag ACU 3
 Master	AIRBAG	2.2 16v dCi 66kw G9T-722	SIEMENS - Autoliv AirBag AC4
 Master	AIRBAG	2.2 16v dCi 66kw G9T-722	SIEMENS - Autoliv AirBag EC5
 Master	AIRBAG	2.2 J7T-782	SAGEM - Autoliv AirBag ACU 3
 Master	AIRBAG	2.2 J7T-782	SIEMENS - Autoliv AirBag AC4
 Master	AIRBAG	2.2 J7T-782	SIEMENS - Autoliv AirBag EC5
 Master	AIRBAG	2.2 J7T-788	SAGEM - Autoliv AirBag ACU 3
 Master	AIRBAG	2.2 J7T-788	SIEMENS - Autoliv AirBag AC4
 Master	AIRBAG	2.2 J7T-788	SIEMENS - Autoliv AirBag EC5
 Master	AIRBAG	2.5 dCi 74kw G9U-650	SAGEM - Autoliv AirBag ACU 3

## Systems supported by ECReader (up to V5.40)

### TRUCKS














**Renault**

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Master	AIRBAG	2.5 dCi 74kw G9U-650	SIEMENS - Autoliv AirBag AC4
 Master	AIRBAG	2.5 dCi 74kw G9U-650	SIEMENS - Autoliv AirBag EC5
 Master	AIRBAG	2.5 dCi 74kw G9U-726	SAGEM - Autoliv AirBag ACU 3
 Master	AIRBAG	2.5 dCi 74kw G9U-726	SIEMENS - Autoliv AirBag AC4
 Master	AIRBAG	2.5 dCi 74kw G9U-726	SIEMENS - Autoliv AirBag EC5
 Master	AIRBAG	2.5 dCi 85kw G9U-720	SAGEM - Autoliv AirBag ACU 3
 Master	AIRBAG	2.5 dCi 85kw G9U-720	SIEMENS - Autoliv AirBag AC4
 Master	AIRBAG	2.5 dCi 85kw G9U-720	SIEMENS - Autoliv AirBag EC5
 Master	AIRBAG	2.5 dCi 88kw G9U-650	SAGEM - Autoliv AirBag ACU 3
 Master	AIRBAG	2.5 dCi 88kw G9U-650	SIEMENS - Autoliv AirBag AC4
 Master	AIRBAG	2.5 dCi 88kw G9U-650	SIEMENS - Autoliv AirBag EC5
 Master	AUTOM. TRANSMISSI	2.2 16v dCi 66kw G9T-722	AUTOTETECT
 Master	AUTOM. TRANSMISSI	2.5 dCi 88kw G9U-650	AUTOTETECT
 Master	ENGINE MANAGEME	2.2 16v dCi 66kw G9T-722	AUTOTETECT
 Master	ENGINE MANAGEME	2.2 16v dCi 66kw G9T-722 (01-..)	BOSCH EDC 15 C3 Common Rail
 Master	ENGINE MANAGEME	2.2 J7T-782	SIEMENS MPI
 Master	ENGINE MANAGEME	2.2 J7T-788	SIEMENS MPI
 Master	ENGINE MANAGEME	2.5 dCi 74kw G9U-650	AUTOTETECT
 Master	ENGINE MANAGEME	2.5 dCi 74kw G9U-726	AUTOTETECT
 Master	ENGINE MANAGEME	2.5 dCi 85kw G9U-720	AUTOTETECT
 Master	ENGINE MANAGEME	2.5 dCi 88kw G9U-650	AUTOTETECT
 Master	ENGINE MANAGEME	2.5 dCi 88kw G9U-650 (01-..)	BOSCH EDC 15 C3 Common Rail
 Trafic	AIRBAG	1.9 dCi 60kw F9Q-762	SIEMENS - Autoliv AirBag AC4
 Trafic	AIRBAG	1.9 dCi 60kw F9Q-762	SIEMENS - Autoliv AirBag EC5
 Trafic	AIRBAG	1.9 dCi 60kw F9Q-762 (...02)	SAGEM - Autoliv AirBag ACU x.x
 Trafic	AIRBAG	1.9 dCi 74kw F9Q-760	SIEMENS - Autoliv AirBag AC4

## Systems supported by ECReader (up to V5.40)




























### TRUCKS

**Renault**

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Trafic	AIRBAG	1.9 dCi 74kw F9Q-760	SIEMENS - Autoliv AirBag EC5
 Trafic	AIRBAG	1.9 dCi 74kw F9Q-760 (...02)	SAGEM - Autoliv AirBag ACU x.x
 Trafic	AIRBAG	2.2 74kw J7T-600	SIEMENS - Autoliv AirBag AC4
 Trafic	AIRBAG	2.2 74kw J7T-600	SIEMENS - Autoliv AirBag EC5
 Trafic	AUTOM. TRANSMISSI	1.9 dCi 60kw F9Q-762	AUTODETECT
 Trafic	AUTOM. TRANSMISSI	1.9 dCi 74kw F9Q-760	AUTODETECT
 Trafic	ENGINE MANAGEME	1.9 dCi 60kw F9Q-762	AUTODETECT
 Trafic	ENGINE MANAGEME	1.9 dCi 60kw F9Q-762	BOSCH EDC 15 C3 Common Rail
 Trafic	ENGINE MANAGEME	1.9 dCi 74kw F9Q-760	AUTODETECT
 Trafic	ENGINE MANAGEME	1.9 dCi 74kw F9Q-760	BOSCH EDC 15 C3 Common Rail
 Trafic	ENGINE MANAGEME	2.2 74kw J7T-600	SIEMENS BENDIX-FENIX MPI
 Trafic	ENGINE MANAGEME	2.2 74kw J7T-600	SIEMENS BENDIX-FENIX MPI
 Trafic	ENGINE MANAGEME	2.2 74kw J7T-600	SIEMENS BENDIX-FENIX MPI

## Systems supported by ECUreader (up to V5.40)



### TRUCKS Renault Trucks

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Kerax	ABS	260	Bosch ABS 24
 Kerax	ABS	260	BOSCH ABS I8
 Kerax	ABS	260	WABCO ABS D-E
 Kerax	ABS	270	Bosch ABS 24
 Kerax	ABS	270	BOSCH ABS I8
 Kerax	ABS	270	WABCO ABS D-E
 Kerax	ABS	300	Bosch ABS 24
 Kerax	ABS	300	BOSCH ABS I8
 Kerax	ABS	300	WABCO ABS D-E
 Kerax	ABS	320	Bosch ABS 24
 Kerax	ABS	320	BOSCH ABS I8
 Kerax	ABS	320	WABCO ABS D-E
 Kerax	ABS	340	BOSCH ABS 24
 Kerax	ABS	340	BOSCH ABS I8
 Kerax	ABS	340	WABCO ABS D-E
 Kerax	ABS	370	Bosch ABS 24
 Kerax	ABS	370	BOSCH ABS I8
 Kerax	ABS	370	WABCO ABS D-E
 Kerax	ABS	385	BOSCH ABS 24
 Kerax	ABS	385	BOSCH ABS I8
 Kerax	ABS	385	WABCO ABS D-E
 Kerax	ABS	400	BOSCH ABS 24
 Kerax	ABS	400	BOSCH ABS I8
 Kerax	ABS	400	WABCO ABS D-E
 Kerax	ABS	420	Bosch ABS 24
 Kerax	ABS	420	BOSCH ABS I8
 Kerax	ABS	420	WABCO ABS D-E

## Systems supported by ECReader (up to V5.40)

### TRUCKS




























### Renault Trucks

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Kerax	AUTOM. TRANSMISSI	260	ZF ASTRONIC
 Kerax	AUTOM. TRANSMISSI	270	ZF ASTRONIC
 Kerax	AUTOM. TRANSMISSI	300	ZF ASTRONIC
 Kerax	AUTOM. TRANSMISSI	320	ZF ASTRONIC
 Kerax	AUTOM. TRANSMISSI	340	ZF ASTRONIC
 Kerax	AUTOM. TRANSMISSI	370	ZF ASTRONIC
 Kerax	AUTOM. TRANSMISSI	385	ZF ASTRONIC
 Kerax	AUTOM. TRANSMISSI	400	ZF ASTRONIC
 Kerax	AUTOM. TRANSMISSI	420	ZF ASTRONIC
 Kerax	BRAKE POWER SUP	260	ZF Intarder
 Kerax	BRAKE POWER SUP	270	ZF Intarder
 Kerax	BRAKE POWER SUP	300	ZF Intarder
 Kerax	BRAKE POWER SUP	320	ZF Intarder
 Kerax	BRAKE POWER SUP	340	ZF Intarder
 Kerax	BRAKE POWER SUP	370	ZF Intarder
 Kerax	BRAKE POWER SUP	385	ZF Intarder
 Kerax	BRAKE POWER SUP	400	ZF Intarder
 Kerax	BRAKE POWER SUP	420	ZF Intarder
 Kerax	BRAKE SYS. MANAG	260	EBS
 Kerax	BRAKE SYS. MANAG	270	EBS
 Kerax	BRAKE SYS. MANAG	300	EBS
 Kerax	BRAKE SYS. MANAG	320	EBS
 Kerax	BRAKE SYS. MANAG	340	EBS
 Kerax	BRAKE SYS. MANAG	370	EBS
 Kerax	BRAKE SYS. MANAG	385	EBS
 Kerax	BRAKE SYS. MANAG	400	EBS
 Kerax	BRAKE SYS. MANAG	420	EBS

## Systems supported by ECUreader (up to V5.40)

### TRUCKS




























### Renault Trucks

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Kerax	CHASSIS NETWORK	260	VECU 3 Body Computer Euro3
 Kerax	CHASSIS NETWORK	270	VECU 3 Body Computer Euro3
 Kerax	CHASSIS NETWORK	300	VECU 3 Body Computer Euro3
 Kerax	CHASSIS NETWORK	320	VECU 3 Body Computer Euro3
 Kerax	CHASSIS NETWORK	340	VECU 3 Body Computer Euro3
 Kerax	CHASSIS NETWORK	370	VECU 3 Body Computer Euro3
 Kerax	CHASSIS NETWORK	385	VECU 3 Body Computer Euro3
 Kerax	CHASSIS NETWORK	400	VECU 3 Body Computer Euro3
 Kerax	CHASSIS NETWORK	420	VECU 3 Body Computer Euro3
 Kerax	DASHBOARD	260	AFFI COMBISTRUM 2000
 Kerax	DASHBOARD	270	AFFI COMBISTRUM 2000
 Kerax	DASHBOARD	300	AFFI COMBISTRUM 2000
 Kerax	DASHBOARD	320	AFFI COMBISTRUM 2000
 Kerax	DASHBOARD	340	AFFI COMBISTRUM 2000
 Kerax	DASHBOARD	370	AFFI COMBISTRUM 2000
 Kerax	DASHBOARD	385	AFFI COMBISTRUM 2000
 Kerax	DASHBOARD	400	AFFI COMBISTRUM 2000
 Kerax	DASHBOARD	420	AFFI COMBISTRUM 2000
 Kerax	ENGINE MANAGEME	260	DENSO ITC
 Kerax	ENGINE MANAGEME	260	E-Tech 3
 Kerax	ENGINE MANAGEME	270	DENSO ITC
 Kerax	ENGINE MANAGEME	270	E-Tech 3
 Kerax	ENGINE MANAGEME	300	DENSO ITC
 Kerax	ENGINE MANAGEME	300	E-Tech 3
 Kerax	ENGINE MANAGEME	320	DENSO ITC
 Kerax	ENGINE MANAGEME	340	DENSO ITC
 Kerax	ENGINE MANAGEME	340	E-Tech 3

## Systems supported by ECReader (up to V5.40)

### TRUCKS



























### Renault Trucks

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Kerax	ENGINE MANAGEME	370	DENSO ITC
 Kerax	ENGINE MANAGEME	370	E-Tech 3
 Kerax	ENGINE MANAGEME	385	DENSO ITC
 Kerax	ENGINE MANAGEME	385	E-Tech 3
 Kerax	ENGINE MANAGEME	400	DENSO ITC
 Kerax	ENGINE MANAGEME	400	E-Tech 3
 Kerax	ENGINE MANAGEME	420	DENSO ITC
 Kerax	ENGINE MANAGEME	420	E-Tech 3
 Kerax	SPEED LIMITER	260	ACTIA LIVASR
 Kerax	SPEED LIMITER	270	ACTIA LIVASR
 Kerax	SPEED LIMITER	300	ACTIA LIVASR
 Kerax	SPEED LIMITER	320	ACTIA LIVASR
 Kerax	SPEED LIMITER	340	ACTIA LIVASR
 Kerax	SPEED LIMITER	370	ACTIA LIVASR
 Kerax	SPEED LIMITER	385	ACTIA LIVASR
 Kerax	SPEED LIMITER	400	ACTIA LIVASR
 Kerax	SPEED LIMITER	420	ACTIA LIVASR
 Kerax	SUSPENSION CONTR	260	WABCO ECAS
 Kerax	SUSPENSION CONTR	260	WABCO ECAS JED
 Kerax	SUSPENSION CONTR	270	WABCO ECAS
 Kerax	SUSPENSION CONTR	270	WABCO ECAS JED
 Kerax	SUSPENSION CONTR	300	WABCO ECAS
 Kerax	SUSPENSION CONTR	300	WABCO ECAS JED
 Kerax	SUSPENSION CONTR	320	WABCO ECAS
 Kerax	SUSPENSION CONTR	320	WABCO ECAS JED
 Kerax	SUSPENSION CONTR	340	WABCO ECAS
 Kerax	SUSPENSION CONTR	340	WABCO ECAS JED

## Systems supported by ECUREADER (up to V5.40)



























### TRUCKS

### Renault Trucks

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Kerax	SUSPENSION CONTR	370	WABCO ECAS
 Kerax	SUSPENSION CONTR	370	WABCO ECAS JED
 Kerax	SUSPENSION CONTR	385	WABCO ECAS
 Kerax	SUSPENSION CONTR	385	WABCO ECAS JED
 Kerax	SUSPENSION CONTR	400	WABCO ECAS
 Kerax	SUSPENSION CONTR	400	WABCO ECAS JED
 Kerax	SUSPENSION CONTR	420	WABCO ECAS
 Kerax	SUSPENSION CONTR	420	WABCO ECAS JED
 Kerax	ENGINE MANAGEME	180	dCi Euro 3
 Kerax	ENGINE MANAGEME	220	dCi Euro 3
 Kerax	ENGINE MANAGEME	260	dCi Euro 3
 Kerax	ENGINE MANAGEME	270	dCi Euro 3
 Kerax	ENGINE MANAGEME	300	dCi Euro 3
 Kerax	ENGINE MANAGEME	340	dCi Euro 3
 Kerax	ENGINE MANAGEME	370	dCi Euro 3
 Kerax	ENGINE MANAGEME	385	dCi Euro 3
 Kerax	ENGINE MANAGEME	400	dCi Euro 3
 Kerax	ENGINE MANAGEME	420	dCi Euro 3
 Magnum Dxi	BRAKE SYS. MANAG	460 (07-..)	Knorr EBS
 Magnum Dxi	BRAKE SYS. MANAG	500 (07-..)	Knorr EBS
 Magnum Dxi	DASHBOARD	460 (07-..)	Dashboard
 Magnum Dxi	DASHBOARD	500 (07-..)	Dashboard
 Magnum Dxi	ENGINE MANAGEME	460 (07-..)	EDC Euro 5
 Magnum Dxi	ENGINE MANAGEME	500 (07-..)	EDC Euro 5
 Magnum Dxi	ENGINE MANAGEME	460 (07-..)	
 Magnum Dxi	ENGINE MANAGEME	500 (07-..)	



























## Systems supported by ECUREADER (up to V5.40)

### TRUCKS Renault Trucks

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Magnum Dxi	IMMOBILIZER	460 (07-..)	
 Magnum Dxi	IMMOBILIZER	500 (07-..)	
 Magnum Dxi	SUSPENSION CONTR	460 (07-..)	Knorr
 Magnum Dxi	SUSPENSION CONTR	500 (07-..)	Knorr
 Magnum Dxi	BRAKE SYS. MANAG	460 (07-..)	Knorr EBS
 Magnum Dxi	BRAKE SYS. MANAG	500 (07-..)	Knorr EBS
 Magnum Dxi	DASHBOARD	460 (07-..)	Dashboard
 Magnum Dxi	DASHBOARD	500 (07-..)	Dashboard
 Magnum Dxi	ENGINE MANAGEME	460 (07-..)	EDC Euro 5
 Magnum Dxi	ENGINE MANAGEME	500 (07-..)	EDC Euro 5
 Magnum Dxi	ENGINE MANAGEME	460 (07-..)	
 Magnum Dxi	ENGINE MANAGEME	500 (07-..)	
 Magnum Dxi	IMMOBILIZER	460 (07-..)	
 Magnum Dxi	IMMOBILIZER	500 (07-..)	
 Magnum Dxi	SUSPENSION CONTR	460 (07-..)	Knorr
 Magnum Dxi	SUSPENSION CONTR	500 (07-..)	Knorr
 Magnum	ABS	440	Bosch ABS 24
 Magnum	ABS	440	BOSCH ABS I8
 Magnum	ABS	440	WABCO ABS D-E
 Magnum	ABS	480	Bosch ABS 24
 Magnum	ABS	480	BOSCH ABS I8
 Magnum	ABS	480	WABCO ABS D-E
 Magnum	AUTOM. TRANSMISSI	440	ZF ASTRONIC
 Magnum	AUTOM. TRANSMISSI	480	ZF ASTRONIC
 Magnum	BRAKE POWER SUP	440	ZF Intarder
 Magnum	BRAKE POWER SUP	480	ZF Intarder

## Systems supported by ECUreader (up to V5.40)



























### TRUCKS Renault Trucks

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Magnum	BRAKE SYS. MANAG	440	EBS
 Magnum	BRAKE SYS. MANAG	480	EBS
 Magnum	CHASSIS NETWORK	440	VECU 3 Body Computer Euro3
 Magnum	CHASSIS NETWORK	480	VECU 3 Body Computer Euro3
 Magnum	DASHBOARD	440	AFFI COMBISTRUM 2000
 Magnum	DASHBOARD	480	AFFI COMBISTRUM 2000
 Magnum	ENGINE MANAGEME	440	DENSO ITC
 Magnum	ENGINE MANAGEME	440	E-Tech 3
 Magnum	ENGINE MANAGEME	480	DENSO ITC
 Magnum	ENGINE MANAGEME	480	E-Tech 3
 Magnum	SPEED LIMITER	440	ACTIA LIVASR
 Magnum	SPEED LIMITER	480	ACTIA LIVASR
 Magnum	SUSPENSION CONTR	440	WABCO ECAS JED
 Magnum	SUSPENSION CONTR	480	WABCO ECAS
 Magnum	ABS	420	Bosch ABS 24
 Magnum	ABS	420	BOSCH ABS I8
 Magnum	ABS	440	WABCO ABS D-E
 Magnum	ABS	480	BOSCH ABS 24
 Magnum	ABS	480	BOSCH ABS I8
 Magnum	ABS	480	WABCO ABS D-E
 Magnum	AUTOM. TRANSMISSI	440	ZF ASTRONIC
 Magnum	AUTOM. TRANSMISSI	480	ZF ASTRONIC
 Magnum	BRAKE POWER SUP	440	ZF Intarder
 Magnum	BRAKE POWER SUP	480	ZF Intarder
 Magnum	BRAKE SYS. MANAG	440	EBS
 Magnum	BRAKE SYS. MANAG	480	EBS

## Systems supported by ECUreader (up to V5.40)

### TRUCKS




























### Renault Trucks

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Magnum	CHASSIS NETWORK	440	VECU 3 Body Computer Euro3
 Magnum	CHASSIS NETWORK	480	VECU 3 Body Computer Euro3
 Magnum	DASHBOARD	440	AFFI COMBISTRUM 2000
 Magnum	DASHBOARD	480	AFFI COMBISTRUM 2000
 Magnum	ENGINE MANAGEME	420	DENSO ITC
 Magnum	ENGINE MANAGEME	440	dCi Euro 3
 Magnum	ENGINE MANAGEME	440	E-Tech 3
 Magnum	ENGINE MANAGEME	480	dCi Euro 3
 Magnum	ENGINE MANAGEME	480	DENSO ITC
 Magnum	ENGINE MANAGEME	480	E-Tech 3
 Magnum	SPEED LIMITER	440	ACTIA LIVASR
 Magnum	SPEED LIMITER	480	ACTIA LIVASR
 Magnum	SUSPENSION CONTR	440	WABCO ECAS
 Magnum	SUSPENSION CONTR	480	WABCO ECAS JED
 Maxter	ENGINE MANAGEME	300	DENSO ITC
 Maxter	ENGINE MANAGEME	340	DENSO ITC
 Maxter	ENGINE MANAGEME	385	DENSO ITC
 Maxter	ENGINE MANAGEME	400	DENSO ITC
 Midliner M	ENGINE MANAGEME	250	DENSO ITC
 Midlum	ABS	150	BOSCH ABS 24
 Midlum	ABS	150	BOSCH ABS I8
 Midlum	ABS	150	WABCO ABS D-E
 Midlum	ABS	180	BOSCH ABS 24
 Midlum	ABS	180	BOSCH ABS I8
 Midlum	ABS	180	WABCO ABS D-E
 Midlum	ABS	220	BOSCH ABS 24

## Systems supported by ECUreader (up to V5.40)

### TRUCKS



























### Renault Trucks

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Midlum	ABS	220	BOSCH ABS I8
 Midlum	ABS	220	WABCO ABS D-E
 Midlum	ABS	270	BOSCH ABS 24
 Midlum	ABS	270	BOSCH ABS I8
 Midlum	ABS	270	WABCO ABS D-E
 Midlum	AUTOM. TRANSMISSI	150	ZF ASTRONIC
 Midlum	AUTOM. TRANSMISSI	180	ZF ASTRONIC
 Midlum	AUTOM. TRANSMISSI	220	ZF ASTRONIC
 Midlum	AUTOM. TRANSMISSI	270	ZF ASTRONIC
 Midlum	BRAKE POWER SUP	150	ZF Intarder
 Midlum	BRAKE POWER SUP	180	ZF Intarder
 Midlum	BRAKE POWER SUP	220	ZF Intarder
 Midlum	BRAKE POWER SUP	270	ZF Intarder
 Midlum	BRAKE SYS. MANAG	150	EBS
 Midlum	BRAKE SYS. MANAG	180	EBS
 Midlum	BRAKE SYS. MANAG	220	EBS
 Midlum	BRAKE SYS. MANAG	270	EBS
 Midlum	CHASSIS NETWORK	150	VECU 3 Body Computer Euro3
 Midlum	CHASSIS NETWORK	180	VECU 3 Body Computer Euro3
 Midlum	CHASSIS NETWORK	220	VECU 3 Body Computer Euro3
 Midlum	CHASSIS NETWORK	270	VECU 3 Body Computer Euro3
 Midlum	DASHBOARD	150	AFFI COMBINSTRUM 2000
 Midlum	DASHBOARD	180	AFFI COMBINSTRUM 2000
 Midlum	DASHBOARD	220	AFFI COMBINSTRUM 2000
 Midlum	DASHBOARD	270	AFFI COMBINSTRUM 2000
 Midlum	ENGINE MANAGEME	150	DENSO ITC
 Midlum	ENGINE MANAGEME	150	E-Tech 3

## Systems supported by ECUreader (up to V5.40)

### TRUCKS



























### Renault Trucks

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Midlum	ENGINE MANAGEME	180	DENSO ITC
 Midlum	ENGINE MANAGEME	180	E-Tech 3
 Midlum	ENGINE MANAGEME	220	DENSO ITC
 Midlum	ENGINE MANAGEME	220	E-Tech 3
 Midlum	ENGINE MANAGEME	270	DENSO ITC
 Midlum	ENGINE MANAGEME	270	E-Tech 3
 Midlum	SPEED LIMITER	150	ACTIA LIVASR
 Midlum	SPEED LIMITER	180	ACTIA LIVASR
 Midlum	SPEED LIMITER	220	ACTIA LIVASR
 Midlum	SPEED LIMITER	270	ACTIA LIVASR
 Midlum	SUSPENSION CONTR	150	WABCO ECAS
 Midlum	SUSPENSION CONTR	150	Wabco ECAS JED
 Midlum	SUSPENSION CONTR	180	WABCO ECAS
 Midlum	SUSPENSION CONTR	180	Wabco ECAS JED
 Midlum	SUSPENSION CONTR	220	WABCO ECAS
 Midlum	SUSPENSION CONTR	220	Wabco ECAS JED
 Midlum	SUSPENSION CONTR	270	WABCO ECAS
 Midlum	SUSPENSION CONTR	270	Wabco ECAS JED
 Midlum	ENGINE MANAGEME	150	dCi Euro 3
 Premium Dxi	BRAKE SYS. MANAG	370 (07-..)	Knorr EBS
 Premium Dxi	BRAKE SYS. MANAG	410 (07-..)	Knorr EBS
 Premium Dxi	BRAKE SYS. MANAG	450 (07-..)	Knorr EBS
 Premium Dxi	DASHBOARD	370 (07-..)	Dashboard
 Premium Dxi	DASHBOARD	410 (07-..)	Dashboard
 Premium Dxi	DASHBOARD	450 (07-..)	Dashboard
 Premium Dxi	ENGINE MANAGEME	370 (07-..)	EDC Euro 5

## Systems supported by ECReader (up to V5.40)



























### TRUCKS

### Renault Trucks

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Premium Dxi	ENGINE MANAGEME	410 (07-..)	EDC Euro 5
 Premium Dxi	ENGINE MANAGEME	450 (07-..)	EDC Euro 5
 Premium Dxi	ENGINE MANAGEME	370 (07-..)	
 Premium Dxi	ENGINE MANAGEME	410 (07-..)	
 Premium Dxi	ENGINE MANAGEME	450 (07-..)	
 Premium Dxi	IMMOBILIZER	370 (07-..)	
 Premium Dxi	IMMOBILIZER	410 (07-..)	
 Premium Dxi	IMMOBILIZER	450 (07-..)	
 Premium Dxi	SUSPENSION CONTR	370 (07-..)	Knorr
 Premium Dxi	SUSPENSION CONTR	410 (07-..)	Knorr
 Premium Dxi	SUSPENSION CONTR	450 (07-..)	Knorr
 Premium Dxi	BRAKE SYS. MANAG	370 (07-..)	Knorr EBS
 Premium Dxi	BRAKE SYS. MANAG	410 (07-..)	Knorr EBS
 Premium Dxi	BRAKE SYS. MANAG	450 (07-..)	Knorr EBS
 Premium Dxi	DASHBOARD	370 (07-..)	Dashboard
 Premium Dxi	DASHBOARD	410 (07-..)	Dashboard
 Premium Dxi	DASHBOARD	450 (07-..)	Dashboard
 Premium Dxi	ENGINE MANAGEME	370 (07-..)	EDC Euro 5
 Premium Dxi	ENGINE MANAGEME	410 (07-..)	EDC Euro 5
 Premium Dxi	ENGINE MANAGEME	450 (07-..)	EDC Euro 5
 Premium Dxi	ENGINE MANAGEME	370 (07-..)	
 Premium Dxi	ENGINE MANAGEME	410 (07-..)	
 Premium Dxi	ENGINE MANAGEME	450 (07-..)	
 Premium Dxi	IMMOBILIZER	370 (07-..)	
 Premium Dxi	IMMOBILIZER	410 (07-..)	
 Premium Dxi	IMMOBILIZER	450 (07-..)	

## Systems supported by ECReader (up to V5.40)




























### TRUCKS Renault Trucks

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Premium Dxi	SUSPENSION CONTR	370 (07-..)	Knorr
 Premium Dxi	SUSPENSION CONTR	410 (07-..)	Knorr
 Premium Dxi	SUSPENSION CONTR	450 (07-..)	Knorr
 Premium	ABS	220	BOSCH ABS 24
 Premium	ABS	220	BOSCH ABS I8
 Premium	ABS	220	WABCO ABS D-E
 Premium	ABS	260	BOSCH ABS 24
 Premium	ABS	260	BOSCH ABS I8
 Premium	ABS	260	WABCO ABS D-E
 Premium	ABS	270	BOSCH ABS 24
 Premium	ABS	270	BOSCH ABS I8
 Premium	ABS	270	WABCO ABS D-E
 Premium	ABS	300	BOSCH ABS 24
 Premium	ABS	300	BOSCH ABS I8
 Premium	ABS	300	WABCO ABS D-E
 Premium	ABS	320	BOSCH ABS 24
 Premium	ABS	320	BOSCH ABS I8
 Premium	ABS	320	WABCO ABS D-E
 Premium	ABS	340	BOSCH ABS 24
 Premium	ABS	340	BOSCH ABS I8
 Premium	ABS	340	WABCO ABS D-E
 Premium	ABS	370	BOSCH ABS 24
 Premium	ABS	370	BOSCH ABS I8
 Premium	ABS	370	WABCO ABS D-E
 Premium	ABS	385	BOSCH ABS 24
 Premium	ABS	385	BOSCH ABS I8

## Systems supported by ECureader (up to V5.40)

### TRUCKS





### Renault Trucks

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Premium	ABS	400	BOSCH ABS 24
 Premium	ABS	400	BOSCH ABS I8
 Premium	ABS	400	WABCO ABS D-E
 Premium	ABS	420	BOSCH ABS 24
 Premium	ABS	420	BOSCH ABS I8
 Premium	ABS	420	WABCO ABS D-E
 Premium	AUTOM. TRANSMISSI	220	ZF ASTRONIC
 Premium	AUTOM. TRANSMISSI	260	ZF ASTRONIC
 Premium	AUTOM. TRANSMISSI	270	ZF ASTRONIC
 Premium	AUTOM. TRANSMISSI	300	ZF ASTRONIC
 Premium	AUTOM. TRANSMISSI	320	ZF ASTRONIC
 Premium	AUTOM. TRANSMISSI	340	ZF ASTRONIC
 Premium	AUTOM. TRANSMISSI	370	ZF ASTRONIC
 Premium	AUTOM. TRANSMISSI	385	ZF ASTRONIC
 Premium	AUTOM. TRANSMISSI	400	ZF ASTRONIC
 Premium	AUTOM. TRANSMISSI	420	ZF ASTRONIC
 Premium	BRAKE POWER SUP	220	ZF Intarder
 Premium	BRAKE POWER SUP	260	ZF Intarder
 Premium	BRAKE POWER SUP	270	ZF Intarder
 Premium	BRAKE POWER SUP	300	ZF Intarder
 Premium	BRAKE POWER SUP	320	ZF Intarder
 Premium	BRAKE POWER SUP	340	ZF Intarder
 Premium	BRAKE POWER SUP	370	ZF Intarder
 Premium	BRAKE POWER SUP	385	ZF Intarder
 Premium	BRAKE POWER SUP	400	ZF Intarder
 Premium	BRAKE POWER SUP	420	ZF Intarder
 Premium	BRAKE SYS. MANAG	220	EBS

## Systems supported by ECUreader (up to V5.40)

### TRUCKS

### Renault Trucks

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Premium	BRAKE SYS. MANAG	260	EBS
 Premium	BRAKE SYS. MANAG	270	EBS
 Premium	BRAKE SYS. MANAG	300	EBS
 Premium	BRAKE SYS. MANAG	320	EBS
 Premium	BRAKE SYS. MANAG	340	EBS
 Premium	BRAKE SYS. MANAG	370	EBS
 Premium	BRAKE SYS. MANAG	385	EBS
 Premium	BRAKE SYS. MANAG	400	EBS
 Premium	BRAKE SYS. MANAG	420	EBS
 Premium	CHASSIS NETWORK	220	VECU 3 Body Computer Euro3
 Premium	CHASSIS NETWORK	260	VECU 3 Body Computer Euro3
 Premium	CHASSIS NETWORK	270	VECU 3 Body Computer Euro3
 Premium	CHASSIS NETWORK	300	VECU 3 Body Computer Euro3
 Premium	CHASSIS NETWORK	320	VECU 3 Body Computer Euro3
 Premium	CHASSIS NETWORK	340	VECU 3 Body Computer Euro3
 Premium	CHASSIS NETWORK	370	VECU 3 Body Computer Euro3
 Premium	CHASSIS NETWORK	385	VECU 3 Body Computer Euro3
 Premium	CHASSIS NETWORK	400	VECU 3 Body Computer Euro3
 Premium	CHASSIS NETWORK	420	VECU 3 Body Computer Euro3
 Premium	DASHBOARD	220	AFFI COMBINSTRUM 2000
 Premium	DASHBOARD	260	AFFI COMBINSTRUM 2000
 Premium	DASHBOARD	270	AFFI COMBINSTRUM 2000
 Premium	DASHBOARD	300	AFFI COMBINSTRUM 2000
 Premium	DASHBOARD	320	AFFI COMBINSTRUM 2000
 Premium	DASHBOARD	340	AFFI COMBINSTRUM 2000
 Premium	DASHBOARD	370	AFFI COMBINSTRUM 2000
 Premium	DASHBOARD	385	AFFI COMBINSTRUM 2000

## Systems supported by ECUREADER (up to V5.40)

### TRUCKS




























### Renault Trucks

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Premium	DASHBOARD	400	AFFI COMBINSTRUM 2000
 Premium	DASHBOARD	420	AFFI COMBINSTRUM 2000
 Premium	ENGINE MANAGEME	220	dCi Euro 3
 Premium	ENGINE MANAGEME	220	DENSO ITC
 Premium	ENGINE MANAGEME	220	E-Tech 3
 Premium	ENGINE MANAGEME	250	dCi Euro 3
 Premium	ENGINE MANAGEME	250	DENSO ITC
 Premium	ENGINE MANAGEME	250	E-Tech 3
 Premium	ENGINE MANAGEME	270	dCi Euro 3
 Premium	ENGINE MANAGEME	270	DENSO ITC
 Premium	ENGINE MANAGEME	270	E-Tech 3
 Premium	ENGINE MANAGEME	300	dCi Euro 3
 Premium	ENGINE MANAGEME	300	DENSO ITC
 Premium	ENGINE MANAGEME	300	E-Tech 3
 Premium	ENGINE MANAGEME	320	dCi Euro 3
 Premium	ENGINE MANAGEME	320	DENSO ITC
 Premium	ENGINE MANAGEME	320	E-Tech 3
 Premium	ENGINE MANAGEME	340	dCi Euro 3
 Premium	ENGINE MANAGEME	340	DENSO ITC
 Premium	ENGINE MANAGEME	340	E-Tech 3
 Premium	ENGINE MANAGEME	370	dCi Euro 3
 Premium	ENGINE MANAGEME	370	DENSO ITC
 Premium	ENGINE MANAGEME	370	E-Tech 3
 Premium	ENGINE MANAGEME	385	DENSO ITC
 Premium	ENGINE MANAGEME	400	dCi Euro 3
 Premium	ENGINE MANAGEME	400	DENSO ITC
 Premium	ENGINE MANAGEME	400	E-Tech 3

## Systems supported by ECUreader (up to V5.40)

### TRUCKS







### Renault Trucks

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Premium	ENGINE MANAGEME	420	dCi Euro 3
 Premium	ENGINE MANAGEME	420	DENSO ITC
 Premium	ENGINE MANAGEME	420	E-Tech 3
 Premium	SPEED LIMITER	220	ACTIA LIVASR
 Premium	SPEED LIMITER	260	ACTIA LIVASR
 Premium	SPEED LIMITER	270	ACTIA LIVASR
 Premium	SPEED LIMITER	300	ACTIA LIVASR
 Premium	SPEED LIMITER	320	ACTIA LIVASR
 Premium	SPEED LIMITER	340	ACTIA LIVASR
 Premium	SPEED LIMITER	370	ACTIA LIVASR
 Premium	SPEED LIMITER	385	ACTIA LIVASR
 Premium	SPEED LIMITER	400	ACTIA LIVASR
 Premium	SPEED LIMITER	420	ACTIA LIVASR
 Premium	SUSPENSION CONTR	220	WABCO ECAS
 Premium	SUSPENSION CONTR	220	WABCO ECAS JED
 Premium	SUSPENSION CONTR	260	WABCO ECAS
 Premium	SUSPENSION CONTR	260	WABCO ECAS JED
 Premium	SUSPENSION CONTR	270	WABCO ECAS
 Premium	SUSPENSION CONTR	270	WABCO ECAS JED
 Premium	SUSPENSION CONTR	300	WABCO ECAS
 Premium	SUSPENSION CONTR	300	WABCO ECAS JED
 Premium	SUSPENSION CONTR	320	WABCO ECAS
 Premium	SUSPENSION CONTR	320	WABCO ECAS JED
 Premium	SUSPENSION CONTR	340	WABCO ECAS
 Premium	SUSPENSION CONTR	340	WABCO ECAS JED
 Premium	SUSPENSION CONTR	370	WABCO ECAS
 Premium	SUSPENSION CONTR	370	WABCO ECAS JED

## Systems supported by ECUreader (up to V5.40)

### TRUCKS



### Renault Trucks

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Premium	SUSPENSION CONTR	385	WABCO ECAS
 Premium	SUSPENSION CONTR	385	WABCO ECAS JED
 Premium	SUSPENSION CONTR	400	WABCO ECAS
 Premium	SUSPENSION CONTR	400	WABCO ECAS JED
 Premium	SUSPENSION CONTR	420	WABCO ECAS
 Premium	SUSPENSION CONTR	420	WABCO ECAS JED

## Systems supported by ECUREADER (up to V5.40)

### TRUCKS



Reparafrota

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Trailers	BRAKE SYS. MANAG	Trailers	Wabco Trailer EBS
 Trailers	BRAKE SYS. MANAG	Trailers	Wabco Trailer VCS II

## Systems supported by ECUREADER (up to V5.40)

### TRUCKS




























### Ros Roca Index

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Trailers	BRAKE SYS. MANAG	Trailers	Wabco Trailer EBS
 Trailers	BRAKE SYS. MANAG	Trailers	Wabco Trailer VCS II

## Systems supported by ECUreader (up to V5.40)

### TRUCKS



























Scania

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 G-series	BRAKE SYS. MANAG	G340 Euro 4 (08-..)	Brake management system
 G-series	BRAKE SYS. MANAG	G360 Euro 5 (08-..)	Brake management system
 G-series	BRAKE SYS. MANAG	G380 Euro 4 (08-..)	Brake management system
 G-series	BRAKE SYS. MANAG	G380 Euro 5 (08-..)	Brake management system
 G-series	BRAKE SYS. MANAG	G400 Euro 5 (08-..)	Brake management system
 G-series	BRAKE SYS. MANAG	G420 Euro 4 (08-..)	Brake management system
 G-series	BRAKE SYS. MANAG	G420 Euro 5 (08-..)	Brake management system
 G-series	BRAKE SYS. MANAG	G440 Euro 5 (08-..)	Brake management system
 G-series	BRAKE SYS. MANAG	G480 Euro 4 (08-..)	Brake management system
 G-series	BRAKE SYS. MANAG	G480 Euro 5 (08-..)	Brake management system
 G-series	CHASSIS NETWORK	G340 Euro 4 (08-..)	Body Computer
 G-series	CHASSIS NETWORK	G360 Euro 5 (08-..)	Body Computer
 G-series	CHASSIS NETWORK	G380 Euro 4 (08-..)	Body Computer
 G-series	CHASSIS NETWORK	G380 Euro 5 (08-..)	Body Computer
 G-series	CHASSIS NETWORK	G400 Euro 5 (08-..)	Body Computer
 G-series	CHASSIS NETWORK	G420 Euro 4 (08-..)	Body Computer
 G-series	CHASSIS NETWORK	G420 Euro 5 (08-..)	Body Computer
 G-series	CHASSIS NETWORK	G440 Euro 5 (08-..)	Body Computer
 G-series	CHASSIS NETWORK	G480 Euro 4 (08-..)	Body Computer
 G-series	CHASSIS NETWORK	G480 Euro 5 (08-..)	Body Computer
 G-series	ENGINE MANAGEME	G340 Euro 4 (08-..)	EMS
 G-series	ENGINE MANAGEME	G360 Euro 5 (08-..)	EMS
 G-series	ENGINE MANAGEME	G380 Euro 4 (08-..)	EMS
 G-series	ENGINE MANAGEME	G380 Euro 5 (08-..)	EMS
 G-series	ENGINE MANAGEME	G400 Euro 5 (08-..)	EMS
 G-series	ENGINE MANAGEME	G420 Euro 4 (08-..)	EMS
 G-series	ENGINE MANAGEME	G420 Euro 5 (08-..)	EMS

## Systems supported by ECReader (up to V5.40)

### TRUCKS




























Scania

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 G-series	ENGINE MANAGEME	G440 Euro 5 (08-..)	EMS
 G-series	ENGINE MANAGEME	G480 Euro 4 (08-..)	EMS
 G-series	ENGINE MANAGEME	G480 Euro 5 (08-..)	EMS
 G-series	SUSPENSION CONTR	G340 Euro 4 (08-..)	SMS ECAS
 G-series	SUSPENSION CONTR	G360 Euro 5 (08-..)	SMS ECAS
 G-series	SUSPENSION CONTR	G380 Euro 4 (08-..)	SMS ECAS
 G-series	SUSPENSION CONTR	G380 Euro 5 (08-..)	SMS ECAS
 G-series	SUSPENSION CONTR	G400 Euro 5 (08-..)	SMS ECAS
 G-series	SUSPENSION CONTR	G420 Euro 4 (08-..)	SMS ECAS
 G-series	SUSPENSION CONTR	G420 Euro 5 (08-..)	SMS ECAS
 G-series	SUSPENSION CONTR	G440 Euro 5 (08-..)	SMS ECAS
 G-series	SUSPENSION CONTR	G480 Euro 4 (08-..)	SMS ECAS
 G-series	SUSPENSION CONTR	G480 Euro 5 (08-..)	SMS ECAS
 L-series	ABS	L124-420 (..-99)	BOSCH ABS I8
 L-series	ABS	L144-530 (..-99)	BOSCH ABS I8
 L-series	ABS	L164-480 (..-99)	BOSCH ABS I8
 P-series	ABS	P113-400 (..-99)	BOSCH ABS I8
 P-series	ABS	P114-340 (..-99)	BOSCH ABS I8
 P-series	ABS	P114-380 (..-99)	BOSCH ABS I8
 P-series	ABS	P124-420 (..-99)	BOSCH ABS I8
 P-series	ABS	P164-580 (..-99)	BOSCH ABS I8
 P-series	ABS	P94-230 (..-99)	BOSCH ABS I8
 P-series	ABS	P94-260 (..-99)	BOSCH ABS I8
 P-series	ABS	P94-300 (..-99)	BOSCH ABS I8
 P-series	AIR BRAKE MANAGE	P230 (07-08)	VIS
 P-series	AIR BRAKE MANAGE	P270 (07-08)	VIS

## Systems supported by ECUreader (up to V5.40)

### TRUCKS
























Scania

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 P-series	AIR BRAKE MANAGE	P310 (07-08)	VIS
 P-series	AIR BRAKE MANAGE	P340 (07-08)	VIS
 P-series	AIR BRAKE MANAGE	P380 (07-08)	VIS
 P-series	AIR BRAKE MANAGE	P420 Euro 4 (07-08)	VIS
 P-series	AIR BRAKE MANAGE	P420 Euro 5 (08-..)	VIS
 P-series	AIRBAG	P230 (07-08)	CSS
 P-series	AIRBAG	P270 (07-08)	CSS
 P-series	AIRBAG	P310 (07-08)	CSS
 P-series	AIRBAG	P340 (07-08)	CSS
 P-series	AIRBAG	P380 (07-08)	CSS
 P-series	AIRBAG	P420 Euro 4 (07-08)	CSS
 P-series	AIRBAG	P420 Euro 5 (08-..)	CSS
 P-series	ANTITHEFT	P230 (07-08)	LAS
 P-series	ANTITHEFT	P270 (07-08)	LAS
 P-series	ANTITHEFT	P310 (07-08)	LAS
 P-series	ANTITHEFT	P340 (07-08)	LAS
 P-series	ANTITHEFT	P380 (07-08)	LAS
 P-series	ANTITHEFT	P420 Euro 4 (07-08)	LAS
 P-series	ANTITHEFT	P420 Euro 5 (08-..)	LAS
 P-series	AUTOM. TRANSMISSI	P230 (07-08)	GMS Opticruise
 P-series	AUTOM. TRANSMISSI	P270 (07-08)	GMS Opticruise
 P-series	AUTOM. TRANSMISSI	P310 (07-08)	GMS Opticruise
 P-series	AUTOM. TRANSMISSI	P340 (07-08)	GMS Opticruise
 P-series	AUTOM. TRANSMISSI	P380 (07-08)	GMS Opticruise
 P-series	AUTOM. TRANSMISSI	P420 Euro 4 (07-08)	GMS Opticruise
 P-series	AUTOM. TRANSMISSI	P420 Euro 5 (08-..)	GMS Opticruise
 P-series	BRAKE SYS. MANAG	P230 (07-08)	Brake management system

## Systems supported by ECUREADER (up to V5.40)

### TRUCKS
























Scania

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 P-series	BRAKE SYS. MANAG	P270 (07-08)	Brake management system
 P-series	BRAKE SYS. MANAG	P310 (07-08)	Brake management system
 P-series	BRAKE SYS. MANAG	P340 (07-08)	Brake management system
 P-series	BRAKE SYS. MANAG	P380 (07-08)	Brake management system
 P-series	BRAKE SYS. MANAG	P420 Euro 4 (07-08)	Brake management system
 P-series	BRAKE SYS. MANAG	P420 Euro 5 (08-..)	Brake management system
 P-series	CHASSIS NETWORK	P230 (07-08)	Body Computer
 P-series	CHASSIS NETWORK	P270 (07-08)	Body Computer
 P-series	CHASSIS NETWORK	P310 (07-08)	Body Computer
 P-series	CHASSIS NETWORK	P340 (07-08)	Body Computer
 P-series	CHASSIS NETWORK	P380 (07-08)	Body Computer
 P-series	CHASSIS NETWORK	P420 Euro 4 (07-08)	Body Computer
 P-series	CHASSIS NETWORK	P420 Euro 5 (08-..)	Body Computer
 P-series	CLIMA	P230 (07-08)	CCS
 P-series	CLIMA	P270 (07-08)	CCS
 P-series	CLIMA	P310 (07-08)	CCS
 P-series	CLIMA	P340 (07-08)	CCS
 P-series	CLIMA	P380 (07-08)	CCS
 P-series	CLIMA	P420 Euro 4 (07-08)	CCS
 P-series	CLIMA	P420 Euro 5 (08-..)	CCS
 P-series	DASHBOARD	P230 (07-08)	Dashboard
 P-series	DASHBOARD	P270 (07-08)	Dashboard
 P-series	DASHBOARD	P310 (07-08)	Dashboard
 P-series	DASHBOARD	P340 (07-08)	Dashboard
 P-series	DASHBOARD	P380 (07-08)	Dashboard
 P-series	DASHBOARD	P420 Euro 4 (07-08)	Dashboard
 P-series	DASHBOARD	P420 Euro 5 (08-..)	Dashboard

## Systems supported by ECUreader (up to V5.40)

### TRUCKS




























Scania

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 P-series	ENGINE MANAGEME	P124-420 (96-99)	BOSCH EDC
 P-series	ENGINE MANAGEME	P230 (07-08)	EMS
 P-series	ENGINE MANAGEME	P270 (07-08)	EMS
 P-series	ENGINE MANAGEME	P310 (07-08)	EMS
 P-series	ENGINE MANAGEME	P340 (07-08)	EMS
 P-series	ENGINE MANAGEME	P380 (07-08)	EMS
 P-series	ENGINE MANAGEME	P420 Euro 4 (07-08)	EMS
 P-series	ENGINE MANAGEME	P420 Euro 5 (08-..)	EMS
 P-series	HEADLIGHT LEVEL	P230 (07-08)	VIS
 P-series	HEADLIGHT LEVEL	P270 (07-08)	VIS
 P-series	HEADLIGHT LEVEL	P310 (07-08)	VIS
 P-series	HEADLIGHT LEVEL	P340 (07-08)	VIS
 P-series	HEADLIGHT LEVEL	P380 (07-08)	VIS
 P-series	HEADLIGHT LEVEL	P420 Euro 4 (07-08)	VIS
 P-series	HEADLIGHT LEVEL	P420 Euro 5 (08-..)	VIS
 P-series	SUSPENSION CONTR	P230 (07-08)	SMS ECAS
 P-series	SUSPENSION CONTR	P270 (07-08)	SMS ECAS
 P-series	SUSPENSION CONTR	P310 (07-08)	SMS ECAS
 P-series	SUSPENSION CONTR	P340 (07-08)	SMS ECAS
 P-series	SUSPENSION CONTR	P380 (07-08)	SMS ECAS
 P-series	SUSPENSION CONTR	P420 Euro 4 (07-08)	SMS ECAS
 P-series	SUSPENSION CONTR	P420 Euro 5 (08-..)	SMS ECAS
 P-series	ABS	P124-420 (...99)	BOSCH ABS I8
 P-series	AIR BRAKE MANAGE	P230 (07-08)	VIS
 P-series	AIR BRAKE MANAGE	P270 (07-08)	VIS
 P-series	AIR BRAKE MANAGE	P310 (07-08)	VIS

## Systems supported by ECUREADER (up to V5.40)

### TRUCKS




























Scania

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 P-series	AIR BRAKE MANAGE	P340 (07-08)	VIS
 P-series	AIR BRAKE MANAGE	P380 (07-08)	VIS
 P-series	AIR BRAKE MANAGE	P420 Euro 4 (07-08)	VIS
 P-series	AIR BRAKE MANAGE	P420 Euro 5 (08-..)	VIS
 P-series	AIRBAG	P230 (07-08)	CSS
 P-series	AIRBAG	P270 (07-08)	CSS
 P-series	AIRBAG	P310 (07-08)	CSS
 P-series	AIRBAG	P340 (07-08)	CSS
 P-series	AIRBAG	P380 (07-08)	CSS
 P-series	AIRBAG	P420 Euro 4 (07-08)	CSS
 P-series	AIRBAG	P420 Euro 5 (08-..)	CSS
 P-series	ANTITHEFT	P230 (07-08)	LAS
 P-series	ANTITHEFT	P270 (07-08)	LAS
 P-series	ANTITHEFT	P310 (07-08)	LAS
 P-series	ANTITHEFT	P340 (07-08)	LAS
 P-series	ANTITHEFT	P380 (07-08)	LAS
 P-series	ANTITHEFT	P420 Euro 4 (07-08)	LAS
 P-series	ANTITHEFT	P420 Euro 5 (08-..)	LAS
 P-series	AUTOM. TRANSMISSI	P230 (07-08)	GMS Opticruise
 P-series	AUTOM. TRANSMISSI	P270 (07-08)	GMS Opticruise
 P-series	AUTOM. TRANSMISSI	P310 (07-08)	GMS Opticruise
 P-series	AUTOM. TRANSMISSI	P340 (07-08)	GMS Opticruise
 P-series	AUTOM. TRANSMISSI	P380 (07-08)	GMS Opticruise
 P-series	AUTOM. TRANSMISSI	P420 Euro 4 (07-08)	GMS Opticruise
 P-series	AUTOM. TRANSMISSI	P420 Euro 5 (08-..)	GMS Opticruise
 P-series	BRAKE SYS. MANAG	P230 (07-08)	Brake management system
 P-series	BRAKE SYS. MANAG	P270 (07-08)	Brake management system

## Systems supported by ECUreader (up to V5.40)

### TRUCKS



























Scania

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 P-series	BRAKE SYS. MANAG	P310 (07-08)	Brake management system
 P-series	BRAKE SYS. MANAG	P340 (07-08)	Brake management system
 P-series	BRAKE SYS. MANAG	P380 (07-08)	Brake management system
 P-series	BRAKE SYS. MANAG	P420 Euro 4 (07-08)	Brake management system
 P-series	BRAKE SYS. MANAG	P420 Euro 5 (08-..)	Brake management system
 P-series	CHASSIS NETWORK	P230 (07-08)	Body Computer
 P-series	CHASSIS NETWORK	P270 (07-08)	Body Computer
 P-series	CHASSIS NETWORK	P310 (07-08)	Body Computer
 P-series	CHASSIS NETWORK	P340 (07-08)	Body Computer
 P-series	CHASSIS NETWORK	P380 (07-08)	Body Computer
 P-series	CHASSIS NETWORK	P420 Euro 4 (07-08)	Body Computer
 P-series	CHASSIS NETWORK	P420 Euro 5 (08-..)	Body Computer
 P-series	CLIMA	P230 (07-08)	CCS
 P-series	CLIMA	P270 (07-08)	CCS
 P-series	CLIMA	P310 (07-08)	CCS
 P-series	CLIMA	P340 (07-08)	CCS
 P-series	CLIMA	P380 (07-08)	CCS
 P-series	CLIMA	P420 Euro 4 (07-08)	CCS
 P-series	CLIMA	P420 Euro 5 (08-..)	CCS
 P-series	DASHBOARD	P230 (07-08)	Dashboard
 P-series	DASHBOARD	P270 (07-08)	Dashboard
 P-series	DASHBOARD	P310 (07-08)	Dashboard
 P-series	DASHBOARD	P340 (07-08)	Dashboard
 P-series	DASHBOARD	P380 (07-08)	Dashboard
 P-series	DASHBOARD	P420 Euro 4 (07-08)	Dashboard
 P-series	DASHBOARD	P420 Euro 5 (08-..)	Dashboard
 P-series	ENGINE MANAGEME	P113-400 (92-97)	BOSCH EDC M7

## Systems supported by ECUreader (up to V5.40)

### TRUCKS

Scania

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 P-series	ENGINE MANAGEME	P114-340 (96-99)	BOSCH EDC
 P-series	ENGINE MANAGEME	P114-380 (96-99)	BOSCH EDC
 P-series	ENGINE MANAGEME	P124-420 (96-99)	BOSCH EDC
 P-series	ENGINE MANAGEME	P230 (07-08)	EMS
 P-series	ENGINE MANAGEME	P270 (07-08)	EMS
 P-series	ENGINE MANAGEME	P310 (07-08)	EMS
 P-series	ENGINE MANAGEME	P340 (07-08)	EMS
 P-series	ENGINE MANAGEME	P380 (07-08)	EMS
 P-series	ENGINE MANAGEME	P420 Euro 4 (07-08)	EMS
 P-series	ENGINE MANAGEME	P420 Euro 5 (08-..)	EMS
 P-series	HEADLIGHT LEVEL	P230 (07-08)	VIS
 P-series	HEADLIGHT LEVEL	P270 (07-08)	VIS
 P-series	HEADLIGHT LEVEL	P310 (07-08)	VIS
 P-series	HEADLIGHT LEVEL	P340 (07-08)	VIS
 P-series	HEADLIGHT LEVEL	P380 (07-08)	VIS
 P-series	HEADLIGHT LEVEL	P420 Euro 4 (07-08)	VIS
 P-series	HEADLIGHT LEVEL	P420 Euro 5 (08-..)	VIS
 P-series	SUSPENSION CONTR	P230 (07-08)	SMS ECAS
 P-series	SUSPENSION CONTR	P270 (07-08)	SMS ECAS
 P-series	SUSPENSION CONTR	P310 (07-08)	SMS ECAS
 P-series	SUSPENSION CONTR	P340 (07-08)	SMS ECAS
 P-series	SUSPENSION CONTR	P380 (07-08)	SMS ECAS
 P-series	SUSPENSION CONTR	P420 Euro 4 (07-08)	SMS ECAS
 P-series	SUSPENSION CONTR	P420 Euro 5 (08-..)	SMS ECAS
 R-series	ABS	R113-380 (...-99)	BOSCH ABS I8
 R-series	AIR BRAKE MANAGE	R230 (07-08)	VIS

## Systems supported by ECUreader (up to V5.40)

### TRUCKS




























Scania

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 R-series	AIR BRAKE MANAGE	R270 (07-08)	VIS
 R-series	AIR BRAKE MANAGE	R310 (07-08)	VIS
 R-series	AIR BRAKE MANAGE	R340 (07-08)	VIS
 R-series	AIR BRAKE MANAGE	R380 (07-08)	VIS
 R-series	AIR BRAKE MANAGE	R420 Euro 4 (07-08)	VIS
 R-series	AIR BRAKE MANAGE	R420 Euro 5 (08-..)	VIS
 R-series	AIR BRAKE MANAGE	R470 (07-08)	VIS
 R-series	AIR BRAKE MANAGE	R500 (07-08)	VIS
 R-series	AIR BRAKE MANAGE	R560 (07-08)	VIS
 R-series	AIR BRAKE MANAGE	R580 (07-08)	VIS
 R-series	AIR BRAKE MANAGE	R620 (07-08)	VIS
 R-series	AIRBAG	R230 (07-08)	CSS
 R-series	AIRBAG	R270 (07-08)	CSS
 R-series	AIRBAG	R310 (07-08)	CSS
 R-series	AIRBAG	R340 (07-08)	CSS
 R-series	AIRBAG	R380 (07-08)	CSS
 R-series	AIRBAG	R420 Euro 4 (07-08)	CSS
 R-series	AIRBAG	R420 Euro 5 (08-..)	CSS
 R-series	AIRBAG	R470 (07-08)	CSS
 R-series	AIRBAG	R500 (07-08)	CSS
 R-series	AIRBAG	R560 (07-08)	CSS
 R-series	AIRBAG	R580 (07-08)	CSS
 R-series	AIRBAG	R620 (07-08)	CSS
 R-series	ANTITHEFT	R230 (07-08)	LAS
 R-series	ANTITHEFT	R270 (07-08)	LAS
 R-series	ANTITHEFT	R310 (07-08)	LAS
 R-series	ANTITHEFT	R340 (07-08)	LAS

## Systems supported by ECUreader (up to V5.40)

### TRUCKS
















Scania

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 R-series	ANTITHEFT	R380 (07-08)	LAS
 R-series	ANTITHEFT	R420 Euro 4 (07-08)	LAS
 R-series	ANTITHEFT	R420 Euro 5 (08-..)	LAS
 R-series	ANTITHEFT	R470 (07-08)	LAS
 R-series	ANTITHEFT	R500 (07-08)	LAS
 R-series	ANTITHEFT	R560 (07-08)	LAS
 R-series	ANTITHEFT	R580 (07-08)	LAS
 R-series	ANTITHEFT	R620 (07-08)	LAS
 R-series	AUTOM. TRANSMISSI	R230 (07-08)	GMS Opticruise
 R-series	AUTOM. TRANSMISSI	R270 (07-08)	GMS Opticruise
 R-series	AUTOM. TRANSMISSI	R310 (07-08)	GMS Opticruise
 R-series	AUTOM. TRANSMISSI	R340 (07-08)	GMS Opticruise
 R-series	AUTOM. TRANSMISSI	R380 (07-08)	GMS Opticruise
 R-series	AUTOM. TRANSMISSI	R420 Euro 4 (07-08)	GMS Opticruise
 R-series	AUTOM. TRANSMISSI	R420 Euro 5 (08-..)	GMS Opticruise
 R-series	AUTOM. TRANSMISSI	R470 (07-08)	GMS Opticruise
 R-series	AUTOM. TRANSMISSI	R500 (07-08)	GMS Opticruise
 R-series	AUTOM. TRANSMISSI	R560 (07-08)	GMS Opticruise
 R-series	AUTOM. TRANSMISSI	R580 (07-08)	GMS Opticruise
 R-series	AUTOM. TRANSMISSI	R620 (07-08)	GMS Opticruise
 R-series	BRAKE SYS. MANAG	R230 (07-08)	Brake management system
 R-series	BRAKE SYS. MANAG	R270 (07-08)	Brake management system
 R-series	BRAKE SYS. MANAG	R310 (07-08)	Brake management system
 R-series	BRAKE SYS. MANAG	R340 (07-08)	Brake management system
 R-series	BRAKE SYS. MANAG	R380 (07-08)	Brake management system
 R-series	BRAKE SYS. MANAG	R420 Euro 4 (07-08)	Brake management system
 R-series	BRAKE SYS. MANAG	R420 Euro 5 (08-..)	Brake management system

## Systems supported by ECUreader (up to V5.40)

### TRUCKS






















Scania

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 R-series	BRAKE SYS. MANAG	R470 (07-08)	Brake management system
 R-series	BRAKE SYS. MANAG	R500 (07-08)	Brake management system
 R-series	BRAKE SYS. MANAG	R560 (07-08)	Brake management system
 R-series	BRAKE SYS. MANAG	R580 (07-08)	Brake management system
 R-series	BRAKE SYS. MANAG	R620 (07-08)	Brake management system
 R-series	CHASSIS NETWORK	R230 (07-08)	Body Computer
 R-series	CHASSIS NETWORK	R270 (07-08)	Body Computer
 R-series	CHASSIS NETWORK	R310 (07-08)	Body Computer
 R-series	CHASSIS NETWORK	R340 (07-08)	Body Computer
 R-series	CHASSIS NETWORK	R380 (07-08)	Body Computer
 R-series	CHASSIS NETWORK	R420 Euro 4 (07-08)	Body Computer
 R-series	CHASSIS NETWORK	R420 Euro 5 (08-..)	Body Computer
 R-series	CHASSIS NETWORK	R470 (07-08)	Body Computer
 R-series	CHASSIS NETWORK	R500 (07-08)	Body Computer
 R-series	CHASSIS NETWORK	R560 (07-08)	Body Computer
 R-series	CHASSIS NETWORK	R580 (07-08)	Body Computer
 R-series	CHASSIS NETWORK	R620 (07-08)	Body Computer
 R-series	CLIMA	R230 (07-08)	CCS
 R-series	CLIMA	R270 (07-08)	CCS
 R-series	CLIMA	R310 (07-08)	CCS
 R-series	CLIMA	R340 (07-08)	CCS
 R-series	CLIMA	R380 (07-08)	CCS
 R-series	CLIMA	R420 Euro 4 (07-08)	CCS
 R-series	CLIMA	R420 Euro 5 (08-..)	CCS
 R-series	CLIMA	R470 (07-08)	CCS
 R-series	CLIMA	R500 (07-08)	CCS
 R-series	CLIMA	R560 (07-08)	CCS

## Systems supported by ECUreader (up to V5.40)

### TRUCKS



























Scania

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 R-series	CLIMA	R580 (07-08)	CCS
 R-series	CLIMA	R620 (07-08)	CCS
 R-series	DASHBOARD	R230 (07-08)	Dashboard
 R-series	DASHBOARD	R270 (07-08)	Dashboard
 R-series	DASHBOARD	R310 (07-08)	Dashboard
 R-series	DASHBOARD	R340 (07-08)	Dashboard
 R-series	DASHBOARD	R380 (07-08)	Dashboard
 R-series	DASHBOARD	R420 Euro 4 (07-08)	Dashboard
 R-series	DASHBOARD	R420 Euro 5 (08-..)	Dashboard
 R-series	DASHBOARD	R470 (07-08)	Dashboard
 R-series	DASHBOARD	R500 (07-08)	Dashboard
 R-series	DASHBOARD	R560 (07-08)	Dashboard
 R-series	DASHBOARD	R580 (07-08)	Dashboard
 R-series	DASHBOARD	R620 (07-08)	Dashboard
 R-series	ENGINE MANAGEME	R230 (07-08)	EMS
 R-series	ENGINE MANAGEME	R270 (07-08)	EMS
 R-series	ENGINE MANAGEME	R310 (07-08)	EMS
 R-series	ENGINE MANAGEME	R340 (07-08)	EMS
 R-series	ENGINE MANAGEME	R380 (07-08)	EMS
 R-series	ENGINE MANAGEME	R420 Euro 4 (07-08)	EMS
 R-series	ENGINE MANAGEME	R420 Euro 5 (08-..)	EMS
 R-series	ENGINE MANAGEME	R470 (07-08)	EMS
 R-series	ENGINE MANAGEME	R500 (07-08)	EMS
 R-series	ENGINE MANAGEME	R560 (07-08)	EMS
 R-series	ENGINE MANAGEME	R580 (07-08)	EMS
 R-series	ENGINE MANAGEME	R620 (07-08)	EMS
 R-series	HEADLIGHT LEVEL	R230 (07-08)	VIS

## Systems supported by ECUreader (up to V5.40)

### TRUCKS




























Scania

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 R-series	HEADLIGHT LEVEL	R270 (07-08)	VIS
 R-series	HEADLIGHT LEVEL	R310 (07-08)	VIS
 R-series	HEADLIGHT LEVEL	R340 (07-08)	VIS
 R-series	HEADLIGHT LEVEL	R380 (07-08)	VIS
 R-series	HEADLIGHT LEVEL	R420 Euro 4 (07-08)	VIS
 R-series	HEADLIGHT LEVEL	R420 Euro 5 (08-..)	VIS
 R-series	HEADLIGHT LEVEL	R470 (07-08)	VIS
 R-series	HEADLIGHT LEVEL	R500 (07-08)	VIS
 R-series	HEADLIGHT LEVEL	R560 (07-08)	VIS
 R-series	HEADLIGHT LEVEL	R580 (07-08)	VIS
 R-series	HEADLIGHT LEVEL	R620 (07-08)	VIS
 R-series	SUSPENSION CONTR	R230 (07-08)	SMS ECAS
 R-series	SUSPENSION CONTR	R270 (07-08)	SMS ECAS
 R-series	SUSPENSION CONTR	R310 (07-08)	SMS ECAS
 R-series	SUSPENSION CONTR	R340 (07-08)	SMS ECAS
 R-series	SUSPENSION CONTR	R380 (07-08)	SMS ECAS
 R-series	SUSPENSION CONTR	R420 Euro 4 (07-08)	SMS ECAS
 R-series	SUSPENSION CONTR	R420 Euro 5 (08-..)	SMS ECAS
 R-series	SUSPENSION CONTR	R470 (07-08)	SMS ECAS
 R-series	SUSPENSION CONTR	R500 (07-08)	SMS ECAS
 R-series	SUSPENSION CONTR	R560 (07-08)	SMS ECAS
 R-series	SUSPENSION CONTR	R580 (07-08)	SMS ECAS
 R-series	SUSPENSION CONTR	R620 (07-08)	SMS ECAS
 R-series	ABS	R114-340 (...-99)	BOSCH ABS I8
 R-series	ABS	R114-380 (...-99)	BOSCH ABS I8
 R-series	ABS	R124-420 (...-99)	BOSCH ABS I8

## Systems supported by ECUREADER (up to V5.40)

### TRUCKS




























Scania

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 R-series	ABS	R124-440 (...-99)	BOSCH ABS I8
 R-series	ABS	R124-470 (...-99)	BOSCH ABS I8
 R-series	ABS	R143-470 (...-99)	BOSCH ABS I8
 R-series	ABS	R143-500 (...-99)	BOSCH ABS I8
 R-series	ABS	R144-530 (...-99)	BOSCH ABS I8
 R-series	ABS	R164-480 (...-99)	BOSCH ABS I8
 R-series	ABS	R164-580 (...-99)	BOSCH ABS I8
 R-series	AIR BRAKE MANAGE	R230 (07-08)	VIS
 R-series	AIR BRAKE MANAGE	R270 (07-08)	VIS
 R-series	AIR BRAKE MANAGE	R310 (07-08)	VIS
 R-series	AIR BRAKE MANAGE	R340 (07-08)	VIS
 R-series	AIR BRAKE MANAGE	R380 (07-08)	VIS
 R-series	AIR BRAKE MANAGE	R420 Euro 4 (07-08)	VIS
 R-series	AIR BRAKE MANAGE	R420 Euro 5 (08-..)	VIS
 R-series	AIR BRAKE MANAGE	R470 (07-08)	VIS
 R-series	AIR BRAKE MANAGE	R500 (07-08)	VIS
 R-series	AIR BRAKE MANAGE	R560 (07-08)	VIS
 R-series	AIR BRAKE MANAGE	R580 (07-08)	VIS
 R-series	AIR BRAKE MANAGE	R620 (07-08)	VIS
 R-series	AIRBAG	R230 (07-08)	CSS
 R-series	AIRBAG	R270 (07-08)	CSS
 R-series	AIRBAG	R310 (07-08)	CSS
 R-series	AIRBAG	R340 (07-08)	CSS
 R-series	AIRBAG	R380 (07-08)	CSS
 R-series	AIRBAG	R420 Euro 4 (07-08)	CSS
 R-series	AIRBAG	R420 Euro 5 (08-..)	CSS
 R-series	AIRBAG	R470 (07-08)	CSS

## Systems supported by ECUREADER (up to V5.40)

### TRUCKS




























Scania

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 R-series	AIRBAG	R500 (07-08)	CSS
 R-series	AIRBAG	R560 (07-08)	CSS
 R-series	AIRBAG	R580 (07-08)	CSS
 R-series	AIRBAG	R620 (07-08)	CSS
 R-series	ANTITHEFT	R230 (07-08)	LAS
 R-series	ANTITHEFT	R270 (07-08)	LAS
 R-series	ANTITHEFT	R310 (07-08)	LAS
 R-series	ANTITHEFT	R340 (07-08)	LAS
 R-series	ANTITHEFT	R380 (07-08)	LAS
 R-series	ANTITHEFT	R420 Euro 4 (07-08)	LAS
 R-series	ANTITHEFT	R420 Euro 5 (08-..)	LAS
 R-series	ANTITHEFT	R470 (07-08)	LAS
 R-series	ANTITHEFT	R500 (07-08)	LAS
 R-series	ANTITHEFT	R560 (07-08)	LAS
 R-series	ANTITHEFT	R580 (07-08)	LAS
 R-series	ANTITHEFT	R620 (07-08)	LAS
 R-series	AUTOM. TRANSMISSI	R230 (07-08)	GMS Opticruise
 R-series	AUTOM. TRANSMISSI	R270 (07-08)	GMS Opticruise
 R-series	AUTOM. TRANSMISSI	R310 (07-08)	GMS Opticruise
 R-series	AUTOM. TRANSMISSI	R340 (07-08)	GMS Opticruise
 R-series	AUTOM. TRANSMISSI	R380 (07-08)	GMS Opticruise
 R-series	AUTOM. TRANSMISSI	R420 Euro 4 (07-08)	GMS Opticruise
 R-series	AUTOM. TRANSMISSI	R420 Euro 5 (08-..)	GMS Opticruise
 R-series	AUTOM. TRANSMISSI	R470 (07-08)	GMS Opticruise
 R-series	AUTOM. TRANSMISSI	R500 (07-08)	GMS Opticruise
 R-series	AUTOM. TRANSMISSI	R560 (07-08)	GMS Opticruise
 R-series	AUTOM. TRANSMISSI	R580 (07-08)	GMS Opticruise

## Systems supported by ECUreader (up to V5.40)

### TRUCKS




















Scania

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 R-series	AUTOM. TRANSMISSI	R620 (07-08)	GMS Opticruise
 R-series	BRAKE SYS. MANAG	R230 (07-08)	Brake management system
 R-series	BRAKE SYS. MANAG	R270 (07-08)	Brake management system
 R-series	BRAKE SYS. MANAG	R310 (07-08)	Brake management system
 R-series	BRAKE SYS. MANAG	R340 (07-08)	Brake management system
 R-series	BRAKE SYS. MANAG	R380 (07-08)	Brake management system
 R-series	BRAKE SYS. MANAG	R420 Euro 4 (07-08)	Brake management system
 R-series	BRAKE SYS. MANAG	R420 Euro 5 (08-..)	Brake management system
 R-series	BRAKE SYS. MANAG	R470 (07-08)	Brake management system
 R-series	BRAKE SYS. MANAG	R500 (07-08)	Brake management system
 R-series	BRAKE SYS. MANAG	R560 (07-08)	Brake management system
 R-series	BRAKE SYS. MANAG	R580 (07-08)	Brake management system
 R-series	BRAKE SYS. MANAG	R620 (07-08)	Brake management system
 R-series	CHASSIS NETWORK	R230 (07-08)	Body Computer
 R-series	CHASSIS NETWORK	R270 (07-08)	Body Computer
 R-series	CHASSIS NETWORK	R310 (07-08)	Body Computer
 R-series	CHASSIS NETWORK	R340 (07-08)	Body Computer
 R-series	CHASSIS NETWORK	R380 (07-08)	Body Computer
 R-series	CHASSIS NETWORK	R420 Euro 4 (07-08)	Body Computer
 R-series	CHASSIS NETWORK	R420 Euro 5 (08-..)	Body Computer
 R-series	CHASSIS NETWORK	R470 (07-08)	Body Computer
 R-series	CHASSIS NETWORK	R500 (07-08)	Body Computer
 R-series	CHASSIS NETWORK	R560 (07-08)	Body Computer
 R-series	CHASSIS NETWORK	R580 (07-08)	Body Computer
 R-series	CHASSIS NETWORK	R620 (07-08)	Body Computer
 R-series	CLIMA	R230 (07-08)	CCS
 R-series	CLIMA	R270 (07-08)	CCS

## Systems supported by ECUreader (up to V5.40)

### TRUCKS




























Scania

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 R-series	CLIMA	R310 (07-08)	CCS
 R-series	CLIMA	R340 (07-08)	CCS
 R-series	CLIMA	R380 (07-08)	CCS
 R-series	CLIMA	R420 Euro 4 (07-08)	CCS
 R-series	CLIMA	R420 Euro 5 (08-..)	CCS
 R-series	CLIMA	R470 (07-08)	CCS
 R-series	CLIMA	R500 (07-08)	CCS
 R-series	CLIMA	R560 (07-08)	CCS
 R-series	CLIMA	R580 (07-08)	CCS
 R-series	CLIMA	R620 (07-08)	CCS
 R-series	DASHBOARD	R230 (07-08)	Dashboard
 R-series	DASHBOARD	R270 (07-08)	Dashboard
 R-series	DASHBOARD	R310 (07-08)	Dashboard
 R-series	DASHBOARD	R340 (07-08)	Dashboard
 R-series	DASHBOARD	R380 (07-08)	Dashboard
 R-series	DASHBOARD	R420 Euro 4 (07-08)	Dashboard
 R-series	DASHBOARD	R420 Euro 5 (08-..)	Dashboard
 R-series	DASHBOARD	R470 (07-08)	Dashboard
 R-series	DASHBOARD	R500 (07-08)	Dashboard
 R-series	DASHBOARD	R560 (07-08)	Dashboard
 R-series	DASHBOARD	R580 (07-08)	Dashboard
 R-series	DASHBOARD	R620 (07-08)	Dashboard
 R-series	DIESEL ADDITION	R230 (07-08)	EEC
 R-series	DIESEL ADDITION	R270 (07-08)	EEC
 R-series	DIESEL ADDITION	R310 (07-08)	EEC
 R-series	DIESEL ADDITION	R340 (07-08)	EEC
 R-series	DIESEL ADDITION	R380 (07-08)	EEC

## Systems supported by ECReader (up to V5.40)

### TRUCKS



























Scania

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 R-series	DIESEL ADDITION	R420 Euro 4 (07-08)	EEC
 R-series	DIESEL ADDITION	R420 Euro 5 (08-..)	EEC
 R-series	DIESEL ADDITION	R470 (07-08)	EEC
 R-series	DIESEL ADDITION	R500 (07-08)	EEC
 R-series	DIESEL ADDITION	R560 (07-08)	EEC
 R-series	DIESEL ADDITION	R580 (07-08)	EEC
 R-series	DIESEL ADDITION	R620 (07-08)	EEC
 R-series	ENGINE MANAGEME	R113-380 (92-97)	BOSCH EDC M7
 R-series	ENGINE MANAGEME	R114-340 (96-99)	BOSCH EDC
 R-series	ENGINE MANAGEME	R114-380 (96-99)	BOSCH EDC
 R-series	ENGINE MANAGEME	R124-420 (96-99)	BOSCH EDC
 R-series	ENGINE MANAGEME	R143-470 (88-91)	BOSCH EDC M7
 R-series	ENGINE MANAGEME	R143-500 (91-96)	BOSCH EDC M7
 R-series	ENGINE MANAGEME	R144-530 (96-99)	BOSCH EDC
 R-series	ENGINE MANAGEME	R230 (07-08)	EMS
 R-series	ENGINE MANAGEME	R270 (07-08)	EMS
 R-series	ENGINE MANAGEME	R310 (07-08)	EMS
 R-series	ENGINE MANAGEME	R340 (07-08)	EMS
 R-series	ENGINE MANAGEME	R380 (07-08)	EMS
 R-series	ENGINE MANAGEME	R420 Euro 4 (07-08)	EMS
 R-series	ENGINE MANAGEME	R420 Euro 5 (08-..)	EMS
 R-series	ENGINE MANAGEME	R470 (07-08)	EMS
 R-series	ENGINE MANAGEME	R500 (07-08)	EMS
 R-series	ENGINE MANAGEME	R560 (07-08)	EMS
 R-series	ENGINE MANAGEME	R580 (07-08)	EMS
 R-series	ENGINE MANAGEME	R620 (07-08)	EMS
 R-series	HEADLIGHT LEVEL	R230 (07-08)	VIS

## Systems supported by ECUreader (up to V5.40)

### TRUCKS











Scania

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 R-series	HEADLIGHT LEVEL	R270 (07-08)	VIS
 R-series	HEADLIGHT LEVEL	R310 (07-08)	VIS
 R-series	HEADLIGHT LEVEL	R340 (07-08)	VIS
 R-series	HEADLIGHT LEVEL	R380 (07-08)	VIS
 R-series	HEADLIGHT LEVEL	R420 Euro 4 (07-08)	VIS
 R-series	HEADLIGHT LEVEL	R420 Euro 5 (08-..)	VIS
 R-series	HEADLIGHT LEVEL	R470 (07-08)	VIS
 R-series	HEADLIGHT LEVEL	R500 (07-08)	VIS
 R-series	HEADLIGHT LEVEL	R560 (07-08)	VIS
 R-series	HEADLIGHT LEVEL	R580 (07-08)	VIS
 R-series	HEADLIGHT LEVEL	R620 (07-08)	VIS
 R-series	SUSPENSION CONTR	R230 (07-08)	SMS ECAS
 R-series	SUSPENSION CONTR	R270 (07-08)	SMS ECAS
 R-series	SUSPENSION CONTR	R310 (07-08)	SMS ECAS
 R-series	SUSPENSION CONTR	R340 (07-08)	SMS ECAS
 R-series	SUSPENSION CONTR	R380 (07-08)	SMS ECAS
 R-series	SUSPENSION CONTR	R420 Euro 4 (07-08)	SMS ECAS
 R-series	SUSPENSION CONTR	R420 Euro 5 (08-..)	SMS ECAS
 R-series	SUSPENSION CONTR	R470 (07-08)	SMS ECAS
 R-series	SUSPENSION CONTR	R500 (07-08)	SMS ECAS
 R-series	SUSPENSION CONTR	R560 (07-08)	SMS ECAS
 R-series	SUSPENSION CONTR	R580 (07-08)	SMS ECAS
 R-series	SUSPENSION CONTR	R620 (07-08)	SMS ECAS
 T-series	ABS	T114-380 (...99)	BOSCH ABS I8
 T-series	ABS	T124-400 (...99)	BOSCH ABS I8
 T-series	ABS	T124-420 (...99)	BOSCH ABS I8

## Systems supported by ECUreader (up to V5.40)

### TRUCKS











**Scania**

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 T-series	ABS	T143-500 (..-99)	BOSCH ABS I8
 T-series	ABS	T144-500 (..-99)	BOSCH ABS I8
 T-series	ABS	T146-480 (..-99)	BOSCH ABS I8
 T-series	ABS	T146-580 (..-99)	BOSCH ABS I8
 T-series	ENGINE MANAGEME	T114-340 (96-99)	BOSCH EDC
 T-series	ENGINE MANAGEME	T114-380 (96-99)	BOSCH EDC
 T-series	ENGINE MANAGEME	T124-400 (95-99)	BOSCH EDC
 T-series	ENGINE MANAGEME	T124-420 (95-99)	BOSCH EDC
 T-series	ENGINE MANAGEME	T143-500 (88-96)	BOSCH EDC M7
 T-series	ENGINE MANAGEME	T144-530 (96-99)	BOSCH EDC

## Systems supported by ECUreader (up to V5.40)

### TRUCKS






### Scania Bus

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 BN113	ENGINE MANAGEME	180 (90-98)	BOSCH EDC M7
 BN113	ENGINE MANAGEME	260 (90-98)	BOSCH EDC M7
 K113	ENGINE MANAGEME	380 (90-..)	BOSCH EDC M7
 K124	ENGINE MANAGEME	360 (97-..)	BOSCH EDC M7
 K124	ENGINE MANAGEME	420 (97-..)	BOSCH EDC
 K124	ENGINE MANAGEME	420 (97-..)	BOSCH EDC Lucas
 K124	ENGINE MANAGEME	420 (97-..)	BOSCH EDC M7
 L113	ENGINE MANAGEME	250 (92-98)	BOSCH EDC M7
 L113	ENGINE MANAGEME	250 (93-98)	BOSCH EDC M7
 N113	ENGINE MANAGEME	250 (91-98)	BOSCH EDC M7

## Systems supported by ECUreader (up to V5.40)

### TRUCKS






**Schmitz**

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Trailers	ABS	Trailers Wabco	Wabco VARIO C1-C2-C plus
 Trailers	BRAKE SYS. MANAG	Trailers	Wabco Trailer EBS
 Trailers	BRAKE SYS. MANAG	Trailers	Wabco Trailers EBS kw2000
 Trailers	BRAKE SYS. MANAG	Trailers Haldex	Haldex EBS EB+
 Trailers	BRAKE SYS. MANAG	Trailers Knorr	Knorr Trailer EBS

## Systems supported by ECUreader (up to V5.40)

### TRUCKS












Schwartz

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Trailers	BRAKE SYS. MANAG	Trailers	Wabco Trailer EBS
 Trailers	BRAKE SYS. MANAG	Trailers	Wabco Trailer VCS II
 Trailers	BRAKE SYS. MANAG	Trailers	Wabco Trailers EBS kw2000
 Trailers	BRAKE SYS. MANAG	Trailers Haldex	Haldex EBS EB+
 Trailers	BRAKE SYS. MANAG	Trailers Knorr	Knorr Trailer EBS

## Systems supported by ECUREADER (up to V5.40)

### TRUCKS



### Seddon Atkinson

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Strato/Pacer	ENGINE MANAGEME	Cursor 10	BOSCH EDC 7
 Strato/Pacer	ENGINE MANAGEME	Cursor 13	BOSCH EDC 7
 Strato/Pacer	ENGINE MANAGEME	Cursor 8	BOSCH EDC 7
 Strato	CHASSIS NETWORK	Cursor 10	VDO Body Controller
 Strato	DASHBOARD	Cursor 10	VDO Instrument Cluster
 Strato	ENGINE MANAGEME	Cursor 10 F3AE0681A	BOSCH EDC MS 6.2
 Strato	ENGINE MANAGEME	Cursor 10 F3AE0681B	BOSCH EDC MS 6.2
 Strato	ENGINE MANAGEME	Cursor 10 F3AE0681D	BOSCH EDC MS 6.2
 Strato	ENGINE MANAGEME	Cursor 10 F3AE0681E	BOSCH EDC MS 6.2
 Strato	ENGINE MANAGEME	Cursor 10 F3AE0681H	BOSCH EDC MS 6.2
 Strato	GEARBOX MANAGEM	Cursor 10	Eurotronic 2

## Systems supported by ECUREADER (up to V5.40)

### TRUCKS
















Serviplus Baryval

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Trailers	BRAKE SYS. MANAG	Trailers	Wabco Trailer EBS
 Trailers	BRAKE SYS. MANAG	Trailers	Wabco Trailer VCS II

## Systems supported by ECReader (up to V5.40)

### TRUCKS



Setra

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Top Class	BRAKE SYS. MANAG	S 411 HD	BS EBS ZF
 Top Class	BRAKE SYS. MANAG	S 415 HD	BS EBS ZF
 Top Class	BRAKE SYS. MANAG	S 415 HDH	BS EBS ZF
 Top Class	BRAKE SYS. MANAG	S 417 HDH	BS EBS ZF
 Top Class	BRAKE SYS. MANAG	S 431 DT	BS EBS ZF
 Top Class	CRUISE MANAGEME	S 411 HD	FR FMR
 Top Class	CRUISE MANAGEME	S 415 HD	FR FMR
 Top Class	CRUISE MANAGEME	S 415 HDH	FR FMR
 Top Class	CRUISE MANAGEME	S 417 HDH	FR FMR
 Top Class	CRUISE MANAGEME	S 431 DT	FR FMR
 Top Class	ENGINE MANAGEME	S 411 HD	MR PLD
 Top Class	ENGINE MANAGEME	S 415 HD	MR PLD
 Top Class	ENGINE MANAGEME	S 415 HDH	MR PLD
 Top Class	ENGINE MANAGEME	S 417 HDH	MR PLD
 Top Class	ENGINE MANAGEME	S 431 DT	MR PLD

## Systems supported by ECUREADER (up to V5.40)

### TRUCKS



Sical

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Trailers	BRAKE SYS. MANAG	Trailers	Wabco Trailer EBS
 Trailers	BRAKE SYS. MANAG	Trailers	Wabco Trailer VCS II

## Systems supported by ECUREADER (up to V5.40)

### TRUCKS










Silva

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Trailers	BRAKE SYS. MANAG	Trailers	Wabco Trailer EBS
 Trailers	BRAKE SYS. MANAG	Trailers	Wabco Trailer VCS II

## Systems supported by ECUreader (up to V5.40)

### TRUCKS



Skoda

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Pick-up (67) (96-01)	ABS	(..-01)	
 Pick-up (67) (96-01)	AIRBAG	(..-01)	
 Pick-up (67) (96-01)	CENTRAL LOCKING	(..-01)	
 Pick-up (67) (96-01)	DASHBOARD	(..-01)	
 Pick-up (67) (96-01)	ENGINE MANAGEME	(..-01)	
 Pick-up (67) (96-01)	ENGINE MANAGEME	(..-01)	
 Pick-up (67) (96-01)	ENGINE MANAGEME	(..-01)	
 Pick-up (67) (96-01)	IMMOBILIZER	(..-01)	
 Pick-up (67) (96-01)	RADIO / CD	(..-01)	

## Systems supported by ECUREADER (up to V5.40)

### TRUCKS





Tafyma

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Trailers	BRAKE SYS. MANAG	Trailers	Wabco Trailer EBS
 Trailers	BRAKE SYS. MANAG	Trailers	Wabco Trailer VCS II

## Systems supported by ECUreader (up to V5.40)

### TRUCKS



Tecnokar

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Trailers	BRAKE SYS. MANAG	Trailers	Wabco Trailer EBS
 Trailers	BRAKE SYS. MANAG	Trailers	Wabco Trailers EBS kw2000
 Trailers	BRAKE SYS. MANAG	Trailers Haldex	Haldex EBS EB+
 Trailers	BRAKE SYS. MANAG	Trailers Knorr	Knorr Trailer EBS

## Systems supported by ECUREADER (up to V5.40)

### TRUCKS




Tisvol

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Trailers	BRAKE SYS. MANAG	Trailers	Wabco Trailer EBS
 Trailers	BRAKE SYS. MANAG	Trailers	Wabco Trailer VCS II

## Systems supported by ECUreader (up to V5.40)

### TRUCKS



Toyota

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 HiAce	ENGINE MANAGEME	2.5 D-4D 2KD-FTV (04-..)	EOBD
 HiAce	ENGINE MANAGEME	2.7 3RZ-FE (01-..)	EOBD
 HiLux	ENGINE MANAGEME	2.5 D-4D 2KD-FTV (04-..)	EOBD

## Systems supported by ECUREADER (up to V5.40)

### TRUCKS



























### Voltrailer

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Trailers	BRAKE SYS. MANAG	Trailers	Wabco Trailer EBS
 Trailers	BRAKE SYS. MANAG	Trailers	Wabco Trailer VCS II

## Systems supported by ECReader (up to V5.40)

### TRUCKS





Volvo

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 F10	ENGINE MANAGEME	290 (91-94)	BOSCH EDC M7
 F12	ENGINE MANAGEME	370 (90-94)	BOSCH EDC M7
 F12	ENGINE MANAGEME	390 (87-94)	BOSCH EDC M7
 F16	ENGINE MANAGEME	370 (91-94)	BOSCH EDC M7
 FH12	AIR DRYER	380 (...-05)	Air Dryer
 FH12	AIR DRYER	420 (...-05)	Air Dryer
 FH12	AIR DRYER	460 (...-05)	Air Dryer
 FH12	AIR DRYER	500 (...-05)	Air Dryer
 FH12	AUX. HEATING	380 (03-05)	
 FH12	AUX. HEATING	420 (03-05)	
 FH12	AUX. HEATING	460 (03-05)	
 FH12	AUX. HEATING	500 (03-05)	
 FH12	BRAKE SYS. MANAG	340 (98-02)	ABS/ATC
 FH12	BRAKE SYS. MANAG	380 (03-05)	
 FH12	BRAKE SYS. MANAG	380 (98-02)	ABS/ATC
 FH12	BRAKE SYS. MANAG	420 (03-05)	
 FH12	BRAKE SYS. MANAG	420 (98-02)	ABS/ATC
 FH12	BRAKE SYS. MANAG	460 (03-05)	
 FH12	BRAKE SYS. MANAG	460 (98-02)	ABS/ATC
 FH12	BRAKE SYS. MANAG	500 (03-05)	
 FH12	BRAKE SYS. MANAG	500 (98-02)	ABS/ATC
 FH12	CHANGE BRAKE PAD	380 (03-05)	
 FH12	CHANGE BRAKE PAD	420 (03-05)	
 FH12	CHANGE BRAKE PAD	460 (03-05)	
 FH12	CHANGE BRAKE PAD	500 (03-05)	
 FH12	CHASSIS MANAGEME	380 (03-05)	

## Systems supported by ECReader (up to V5.40)

### TRUCKS

Volvo

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 FH12	CHASSIS MANAGEME	420 (03-05)	
 FH12	CHASSIS MANAGEME	460 (03-05)	
 FH12	CHASSIS MANAGEME	500 (03-05)	
 FH12	CHASSIS NETWORK	340 (98-02)	Vehicle ECU
 FH12	CHASSIS NETWORK	380 (03-05)	Vehicle ECU
 FH12	CHASSIS NETWORK	380 (98-02)	Vehicle ECU
 FH12	CHASSIS NETWORK	420 (03-05)	Vehicle ECU
 FH12	CHASSIS NETWORK	420 (98-02)	Vehicle ECU
 FH12	CHASSIS NETWORK	460 (03-05)	Vehicle ECU
 FH12	CHASSIS NETWORK	460 (98-02)	Vehicle ECU
 FH12	CHASSIS NETWORK	500 (03-05)	Vehicle ECU
 FH12	CHASSIS NETWORK	500 (98-02)	Vehicle ECU
 FH12	CHRONOTACHOGRA	380 (03-05)	
 FH12	CHRONOTACHOGRA	420 (03-05)	
 FH12	CHRONOTACHOGRA	460 (03-05)	
 FH12	CHRONOTACHOGRA	500 (03-05)	
 FH12	DASHBOARD	340 (98-02)	Display
 FH12	DASHBOARD	380 (03-05)	
 FH12	DASHBOARD	380 (98-02)	Display
 FH12	DASHBOARD	420 (03-05)	
 FH12	DASHBOARD	420 (98-02)	Display
 FH12	DASHBOARD	460 (03-05)	
 FH12	DASHBOARD	460 (98-02)	Display
 FH12	DASHBOARD	500 (03-05)	
 FH12	DASHBOARD	500 (98-02)	Display
 FH12	ELECTRIC ACTUATIO	380 (03-05)	
 FH12	ELECTRIC ACTUATIO	420 (03-05)	

## Systems supported by ECUreader (up to V5.40)

### TRUCKS



























Volvo

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 FH12	ELECTRIC ACTUATIO	460 (03-05)	
 FH12	ELECTRIC ACTUATIO	500 (03-05)	
 FH12	ENGINE MANAGEME	340 (93-98)	BOSCH EDC
 FH12	ENGINE MANAGEME	340 (94-98)	D12 MANUAL
 FH12	ENGINE MANAGEME	380 (03-05)	
 FH12	ENGINE MANAGEME	380 (93-98)	BOSCH EDC
 FH12	ENGINE MANAGEME	380 (94-98)	D12 MANUAL
 FH12	ENGINE MANAGEME	420 (03-05)	
 FH12	ENGINE MANAGEME	420 (93-98)	BOSCH EDC
 FH12	ENGINE MANAGEME	420 (94-98)	D12 MANUAL
 FH12	ENGINE MANAGEME	460 (03-05)	
 FH12	ENGINE MANAGEME	460 (94-98)	D12 MANUAL
 FH12	ENGINE MANAGEME	500 (03-05)	
 FH12	ENGINE MANAGEME	500 (94-98)	D12 MANUAL
 FH12	HEADLIGHT LEVEL	380 (03-05)	
 FH12	HEADLIGHT LEVEL	420 (03-05)	
 FH12	HEADLIGHT LEVEL	460 (03-05)	
 FH12	HEADLIGHT LEVEL	500 (03-05)	
 FH12	SUSPENSION CONTR	340 (98-02)	ECAS
 FH12	SUSPENSION CONTR	380 (03-05)	
 FH12	SUSPENSION CONTR	380 (98-02)	ECAS
 FH12	SUSPENSION CONTR	420 (03-05)	
 FH12	SUSPENSION CONTR	420 (98-02)	ECAS
 FH12	SUSPENSION CONTR	460 (03-05)	
 FH12	SUSPENSION CONTR	460 (98-02)	ECAS
 FH12	SUSPENSION CONTR	500 (03-05)	
 FH12	SUSPENSION CONTR	500 (98-02)	ECAS

## Systems supported by ECUREADER (up to V5.40)

### TRUCKS



























**Volvo**

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 FH16	AIR DRYER	540 (...-07)	Air Dryer
 FH16	AIR DRYER	580 (...-07)	Air Dryer
 FH16	AIR DRYER	610 (...-07)	Air Dryer
 FH16	AIR DRYER	660 (...-07)	Air Dryer
 FH16	AUX. HEATING	540 (03-07)	
 FH16	AUX. HEATING	580 (03-07)	
 FH16	AUX. HEATING	610 (03-07)	
 FH16	AUX. HEATING	660 (03-07)	
 FH16	BRAKE SYS. MANAG	540 (03-07)	
 FH16	BRAKE SYS. MANAG	580 (03-07)	
 FH16	BRAKE SYS. MANAG	610 (03-07)	
 FH16	BRAKE SYS. MANAG	660 (03-07)	
 FH16	CHANGE BRAKE PAD	540 (03-07)	
 FH16	CHANGE BRAKE PAD	580 (03-07)	
 FH16	CHANGE BRAKE PAD	610 (03-07)	
 FH16	CHANGE BRAKE PAD	660 (03-07)	
 FH16	CHASSIS MANAGEME	540 (03-07)	
 FH16	CHASSIS MANAGEME	580 (03-07)	
 FH16	CHASSIS MANAGEME	610 (03-07)	
 FH16	CHASSIS MANAGEME	660 (03-07)	
 FH16	CHASSIS NETWORK	540 (03-07)	Vehicle ECU
 FH16	CHASSIS NETWORK	580 (03-07)	Vehicle ECU
 FH16	CHASSIS NETWORK	610 (03-07)	Vehicle ECU
 FH16	CHASSIS NETWORK	660 (03-07)	Vehicle ECU
 FH16	CHRONOTACHOGRA	540 (03-07)	
 FH16	CHRONOTACHOGRA	580 (03-07)	

## Systems supported by ECUREADER (up to V5.40)

### TRUCKS




























Volvo

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 FH16	CHRONOTACHOGRA	610 (03-07)	
 FH16	CHRONOTACHOGRA	660 (03-07)	
 FH16	DASHBOARD	540 (03-07)	
 FH16	DASHBOARD	580 (03-07)	
 FH16	DASHBOARD	610 (03-07)	
 FH16	DASHBOARD	660 (03-07)	
 FH16	ELECTRIC ACTUATIO	540 (03-07)	
 FH16	ELECTRIC ACTUATIO	580 (03-07)	
 FH16	ELECTRIC ACTUATIO	610 (03-07)	
 FH16	ELECTRIC ACTUATIO	660 (03-07)	
 FH16	ENGINE MANAGEME	470 (93-98)	BOSCH EDC M7
 FH16	ENGINE MANAGEME	520 (93-98)	BOSCH EDC M7
 FH16	ENGINE MANAGEME	540 (03-07)	
 FH16	ENGINE MANAGEME	580 (03-07)	
 FH16	ENGINE MANAGEME	610 (03-07)	
 FH16	ENGINE MANAGEME	660 (03-07)	
 FH16	HEADLIGHT LEVEL	540 (03-07)	
 FH16	HEADLIGHT LEVEL	580 (03-07)	
 FH16	HEADLIGHT LEVEL	610 (03-07)	
 FH16	HEADLIGHT LEVEL	660 (03-07)	
 FH16	SUSPENSION CONTR	540 (03-07)	
 FH16	SUSPENSION CONTR	580 (03-07)	
 FH16	SUSPENSION CONTR	610 (03-07)	
 FH16	SUSPENSION CONTR	660 (03-07)	
 FH16	AIR DRYER	540 (...-07)	Air Dryer
 FH16	AIR DRYER	580 (...-07)	Air Dryer

## Systems supported by ECReader (up to V5.40)

### TRUCKS



























Volvo

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 FH16	AIR DRYER	610 (...-07)	Air Dryer
 FH16	AIR DRYER	660 (...-07)	Air Dryer
 FH16	AUX. HEATING	540 (03-07)	
 FH16	AUX. HEATING	580 (03-07)	
 FH16	AUX. HEATING	610 (03-07)	
 FH16	AUX. HEATING	660 (03-07)	
 FH16	BRAKE SYS. MANAG	540 (03-07)	
 FH16	BRAKE SYS. MANAG	580 (03-07)	
 FH16	BRAKE SYS. MANAG	610 (03-07)	
 FH16	BRAKE SYS. MANAG	660 (03-07)	
 FH16	CHANGE BRAKE PAD	540 (03-07)	
 FH16	CHANGE BRAKE PAD	580 (03-07)	
 FH16	CHANGE BRAKE PAD	610 (03-07)	
 FH16	CHANGE BRAKE PAD	660 (03-07)	
 FH16	CHASSIS MANAGEME	540 (03-07)	
 FH16	CHASSIS MANAGEME	580 (03-07)	
 FH16	CHASSIS MANAGEME	610 (03-07)	
 FH16	CHASSIS MANAGEME	660 (03-07)	
 FH16	CHASSIS NETWORK	540 (03-07)	Vehicle ECU
 FH16	CHASSIS NETWORK	580 (03-07)	Vehicle ECU
 FH16	CHASSIS NETWORK	610 (03-07)	Vehicle ECU
 FH16	CHASSIS NETWORK	660 (03-07)	Vehicle ECU
 FH16	CHRONOTACHOGRA	540 (03-07)	
 FH16	CHRONOTACHOGRA	580 (03-07)	
 FH16	CHRONOTACHOGRA	610 (03-07)	
 FH16	CHRONOTACHOGRA	660 (03-07)	
 FH16	DASHBOARD	540 (03-07)	

## Systems supported by ECReader (up to V5.40)

### TRUCKS

















Volvo

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 FH16	DASHBOARD	580 (03-07)	
 FH16	DASHBOARD	610 (03-07)	
 FH16	DASHBOARD	660 (03-07)	
 FH16	ELECTRIC ACTUATIO	540 (03-07)	
 FH16	ELECTRIC ACTUATIO	580 (03-07)	
 FH16	ELECTRIC ACTUATIO	610 (03-07)	
 FH16	ELECTRIC ACTUATIO	660 (03-07)	
 FH16	ENGINE MANAGEME	540 (03-07)	
 FH16	ENGINE MANAGEME	580 (03-07)	
 FH16	ENGINE MANAGEME	610 (03-07)	
 FH16	ENGINE MANAGEME	660 (03-07)	
 FH16	HEADLIGHT LEVEL	540 (03-07)	
 FH16	HEADLIGHT LEVEL	580 (03-07)	
 FH16	HEADLIGHT LEVEL	610 (03-07)	
 FH16	HEADLIGHT LEVEL	660 (03-07)	
 FH16	SUSPENSION CONTR	540 (03-07)	
 FH16	SUSPENSION CONTR	580 (03-07)	
 FH16	SUSPENSION CONTR	610 (03-07)	
 FH16	SUSPENSION CONTR	660 (03-07)	
 FH	AIR DRYER	400 (05-07)	Air Dryer
 FH	AIR DRYER	440 (05-07)	Air Dryer
 FH	AIR DRYER	480 (05-07)	Air Dryer
 FH	AIR DRYER	520 (05-07)	Air Dryer
 FH	AUX. HEATING	400 (05-..)	
 FH	AUX. HEATING	440 (05-..)	
 FH	AUX. HEATING	480 (05-..)	

## Systems supported by ECReader (up to V5.40)

### TRUCKS



























Volvo

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 FH	AUX. HEATING	520 (05-..)	
 FH	BRAKE SYS. MANAG	400 (05-..)	
 FH	BRAKE SYS. MANAG	440 (05-..)	
 FH	BRAKE SYS. MANAG	480 (05-..)	
 FH	BRAKE SYS. MANAG	520 (05-..)	
 FH	CHANGE BRAKE PAD	400 (05-..)	
 FH	CHANGE BRAKE PAD	440 (05-..)	
 FH	CHANGE BRAKE PAD	480 (05-..)	
 FH	CHANGE BRAKE PAD	520 (05-..)	
 FH	CHASSIS MANAGEME	400 (05-..)	
 FH	CHASSIS MANAGEME	440 (05-..)	
 FH	CHASSIS MANAGEME	480 (05-..)	
 FH	CHASSIS MANAGEME	520 (05-..)	
 FH	CHASSIS NETWORK	400 (05-..)	Vehicle ECU
 FH	CHASSIS NETWORK	440 (05-..)	Vehicle ECU
 FH	CHASSIS NETWORK	480 (05-..)	Vehicle ECU
 FH	CHASSIS NETWORK	520 (05-..)	Vehicle ECU
 FH	CHRONOTACHOGRA	400 (05-..)	
 FH	CHRONOTACHOGRA	440 (05-..)	
 FH	CHRONOTACHOGRA	480 (05-..)	
 FH	CHRONOTACHOGRA	520 (05-..)	
 FH	DASHBOARD	400 (05-..)	
 FH	DASHBOARD	440 (05-..)	
 FH	DASHBOARD	480 (05-..)	
 FH	DASHBOARD	520 (05-..)	
 FH	ELECTRIC ACTUATIO	400 (05-..)	
 FH	ELECTRIC ACTUATIO	440 (05-..)	

## Systems supported by ECReader (up to V5.40)

### TRUCKS

Volvo

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 FH	ELECTRIC ACTUATIO	480 (05-..)	
 FH	ELECTRIC ACTUATIO	520 (05-..)	
 FH	ENGINE MANAGEME	400 (05-..)	
 FH	ENGINE MANAGEME	440 (05-..)	
 FH	ENGINE MANAGEME	480 (05-..)	
 FH	ENGINE MANAGEME	520 (05-..)	
 FH	HEADLIGHT LEVEL	400 (05-..)	
 FH	HEADLIGHT LEVEL	440 (05-..)	
 FH	HEADLIGHT LEVEL	480 (05-..)	
 FH	HEADLIGHT LEVEL	520 (05-..)	
 FH	SUSPENSION CONTR	400 (05-..)	
 FH	SUSPENSION CONTR	440 (05-..)	
 FH	SUSPENSION CONTR	480 (05-..)	
 FH	SUSPENSION CONTR	520 (05-..)	
 FL10	ENGINE MANAGEME	286 (92-94)	BOSCH EDC M7
 FL12	ENGINE MANAGEME	380 (95-..)	BOSCH EDC
 FL12	ENGINE MANAGEME	420 (95-..)	BOSCH EDC
 FM12	AIR DRYER	360 (03-07)	Air dryer
 FM12	AIR DRYER	400 (03-07)	Air dryer
 FM12	AIR DRYER	440 (03-07)	Air dryer
 FM12	AIR DRYER	480 (03-07)	Air dryer
 FM12	AUX. HEATING	360 (03-07)	
 FM12	AUX. HEATING	400 (03-07)	
 FM12	AUX. HEATING	440 (03-07)	
 FM12	AUX. HEATING	480 (03-07)	
 FM12	BRAKE SYS. MANAG	360 (03-07)	

## Systems supported by ECReader (up to V5.40)

### TRUCKS



























Volvo

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 FM12	BRAKE SYS. MANAG	360 (98-02)	ABS/ATC
 FM12	BRAKE SYS. MANAG	400 (03-07)	
 FM12	BRAKE SYS. MANAG	400 (98-02)	ABS/ATC
 FM12	BRAKE SYS. MANAG	440 (03-07)	
 FM12	BRAKE SYS. MANAG	440 (98-02)	ABS/ATC
 FM12	BRAKE SYS. MANAG	480 (03-07)	
 FM12	BRAKE SYS. MANAG	480 (98-02)	ABS/ATC
 FM12	CHANGE BRAKE PAD	360 (03-07)	
 FM12	CHANGE BRAKE PAD	400 (03-07)	
 FM12	CHANGE BRAKE PAD	440 (03-07)	
 FM12	CHANGE BRAKE PAD	480 (03-07)	
 FM12	CHASSIS NETWORK	360 (03-07)	Vehicle ECU
 FM12	CHASSIS NETWORK	360 (98-02)	Vehicle ECU
 FM12	CHASSIS NETWORK	400 (03-07)	Vehicle ECU
 FM12	CHASSIS NETWORK	400 (98-02)	Vehicle ECU
 FM12	CHASSIS NETWORK	440 (03-07)	Vehicle ECU
 FM12	CHASSIS NETWORK	440 (98-02)	Vehicle ECU
 FM12	CHASSIS NETWORK	480 (03-07)	Vehicle ECU
 FM12	CHASSIS NETWORK	480 (98-02)	Vehicle ECU
 FM12	DASHBOARD	360 (03-07)	
 FM12	DASHBOARD	360 (98-02)	Display
 FM12	DASHBOARD	400 (03-07)	
 FM12	DASHBOARD	400 (98-02)	Display
 FM12	DASHBOARD	440 (03-07)	
 FM12	DASHBOARD	440 (98-02)	Display
 FM12	DASHBOARD	480 (03-07)	
 FM12	DASHBOARD	480 (98-02)	Display

## Systems supported by ECUreader (up to V5.40)

### TRUCKS



























Volvo

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 FM12	ENGINE MANAGEME	360 (03-07)	
 FM12	ENGINE MANAGEME	400 (03-07)	
 FM12	ENGINE MANAGEME	440 (03-07)	
 FM12	ENGINE MANAGEME	480 (03-07)	
 FM12	HEADLIGHT LEVEL	360 (03-07)	
 FM12	HEADLIGHT LEVEL	400 (03-07)	
 FM12	HEADLIGHT LEVEL	440 (03-07)	
 FM12	HEADLIGHT LEVEL	480 (03-07)	
 FM12	SUSPENSION CONTR	360 (03-07)	
 FM12	SUSPENSION CONTR	360 (98-02)	ECAS
 FM12	SUSPENSION CONTR	400 (03-07)	
 FM12	SUSPENSION CONTR	400 (98-02)	ECAS
 FM12	SUSPENSION CONTR	440 (03-07)	
 FM12	SUSPENSION CONTR	440 (98-02)	ECAS
 FM12	SUSPENSION CONTR	480 (03-07)	
 FM12	SUSPENSION CONTR	480 (98-02)	ECAS
 FM12	AUX. HEATING	360 (03-07)	
 FM12	AUX. HEATING	400 (03-07)	
 FM12	AUX. HEATING	440 (03-07)	
 FM12	AUX. HEATING	480 (03-07)	
 FM12	BRAKE SYS. MANAG	360 (03-07)	
 FM12	BRAKE SYS. MANAG	400 (03-07)	
 FM12	BRAKE SYS. MANAG	440 (03-07)	
 FM12	BRAKE SYS. MANAG	480 (03-07)	
 FM12	CHANGE BRAKE PAD	360 (03-07)	
 FM12	CHANGE BRAKE PAD	400 (03-07)	

## Systems supported by ECReader (up to V5.40)

### TRUCKS




























Volvo

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 FM12	CHANGE BRAKE PAD	440 (03-07)	
 FM12	CHANGE BRAKE PAD	480 (03-07)	
 FM12	CHASSIS MANAGEME	360 (03-07)	
 FM12	CHASSIS MANAGEME	400 (03-07)	
 FM12	CHASSIS MANAGEME	440 (03-07)	
 FM12	CHASSIS MANAGEME	480 (03-07)	
 FM12	CHASSIS NETWORK	360 (03-07)	Vehicle ECU
 FM12	CHASSIS NETWORK	400 (03-07)	Vehicle ECU
 FM12	CHASSIS NETWORK	440 (03-07)	Vehicle ECU
 FM12	CHASSIS NETWORK	480 (03-07)	Vehicle ECU
 FM12	DASHBOARD	360 (03-07)	
 FM12	DASHBOARD	400 (03-07)	
 FM12	DASHBOARD	440 (03-07)	
 FM12	DASHBOARD	480 (03-07)	
 FM12	ENGINE MANAGEME	360 (03-07)	
 FM12	ENGINE MANAGEME	400 (03-07)	
 FM12	ENGINE MANAGEME	440 (03-07)	
 FM12	ENGINE MANAGEME	480 (03-07)	
 FM12	HEADLIGHT LEVEL	360 (03-07)	
 FM12	HEADLIGHT LEVEL	400 (03-07)	
 FM12	HEADLIGHT LEVEL	440 (03-07)	
 FM12	HEADLIGHT LEVEL	480 (03-07)	
 FM12	SUSPENSION CONTR	360 (03-07)	
 FM12	SUSPENSION CONTR	400 (03-07)	
 FM12	SUSPENSION CONTR	440 (03-07)	
 FM12	SUSPENSION CONTR	480 (03-07)	

## Systems supported by ECReader (up to V5.40)

### TRUCKS












Volvo

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 FM9	AUX. HEATING	260 (03-07)	
 FM9	AUX. HEATING	300 (03-07)	
 FM9	AUX. HEATING	340 (03-07)	
 FM9	AUX. HEATING	380 (03-07)	
 FM9	BRAKE SYS. MANAG	260 (03-07)	
 FM9	BRAKE SYS. MANAG	300 (03-07)	
 FM9	BRAKE SYS. MANAG	340 (03-07)	
 FM9	BRAKE SYS. MANAG	380 (03-07)	
 FM9	CHANGE BRAKE PAD	260 (03-07)	
 FM9	CHANGE BRAKE PAD	300 (03-07)	
 FM9	CHANGE BRAKE PAD	340 (03-07)	
 FM9	CHANGE BRAKE PAD	380 (03-07)	
 FM9	CHASSIS MANAGEME	260 (03-07)	
 FM9	CHASSIS MANAGEME	300 (03-07)	
 FM9	CHASSIS MANAGEME	340 (03-07)	
 FM9	CHASSIS MANAGEME	380 (03-07)	
 FM9	CHASSIS NETWORK	260 (03-07)	Vehicle ECU
 FM9	CHASSIS NETWORK	300 (03-07)	Vehicle ECU
 FM9	CHASSIS NETWORK	340 (03-07)	Vehicle ECU
 FM9	CHASSIS NETWORK	380 (03-07)	Vehicle ECU
 FM9	DASHBOARD	260 (03-07)	
 FM9	DASHBOARD	300 (03-07)	
 FM9	DASHBOARD	340 (03-07)	
 FM9	DASHBOARD	380 (03-07)	
 FM9	ENGINE MANAGEME	260 (03-07)	
 FM9	ENGINE MANAGEME	300 (03-07)	
 FM9	ENGINE MANAGEME	340 (03-07)	

## Systems supported by ECUREADER (up to V5.40)

### TRUCKS





Volvo

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 FM9	ENGINE MANAGEME	380 (03-07)	
 FM9	HEADLIGHT LEVEL	260 (03-07)	
 FM9	HEADLIGHT LEVEL	300 (03-07)	
 FM9	HEADLIGHT LEVEL	340 (03-07)	
 FM9	HEADLIGHT LEVEL	380 (03-07)	
 FM9	SUSPENSION CONTR	260 (03-07)	
 FM9	SUSPENSION CONTR	300 (03-07)	
 FM9	SUSPENSION CONTR	340 (03-07)	
 FM9	SUSPENSION CONTR	380 (03-07)	
 NL12	ENGINE MANAGEME	360 (96-...)	BOSCH EDC M7
 NL12	ENGINE MANAGEME	400 (96-...)	BOSCH EDC M7

## Systems supported by ECUreader (up to V5.40)

### TRUCKS



























### Volvo Bus

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 B12	ENGINE MANAGEME	340 (95-..)	BOSCH EDC
 B12	ENGINE MANAGEME	380 (95-..)	BOSCH EDC
 B12	ENGINE MANAGEME	400 (92-95)	BOSCH EDC M7
 B12	ENGINE MANAGEME	420 (95-..)	BOSCH EDC

## Systems supported by ECUREADER (up to V5.40)

### TRUCKS



























VW

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Caddy (2K) (04-..)	ABS	(04-10)	
 Caddy (2K) (04-..)	AIRBAG	(04-10)	
 Caddy (2K) (04-..)	AUTOM. TRANSMISSI	(04-10)	
 Caddy (2K) (04-..)	AUX. HEATING	(04-10)	CAN Gateway
 Caddy (2K) (04-..)	CENTRAL ELECTRIC	(04-10)	
 Caddy (2K) (04-..)	CHASSIS NETWORK	(04-10)	CAN Gateway
 Caddy (2K) (04-..)	CLIMA	(04-10)	
 Caddy (2K) (04-..)	COMFORT SYSTEM	(04-10)	
 Caddy (2K) (04-..)	DASHBOARD	(04-10)	
 Caddy (2K) (04-..)	DRIVER SIDE DOOR	(04-10)	CAN Gateway
 Caddy (2K) (04-..)	ELECTRIC STEERING	(04-10)	
 Caddy (2K) (04-..)	ENGINE MANAGEME	(04-10)	CAN
 Caddy (2K) (04-..)	ENGINE MANAGEME	1.9 TDI BKC (04-10)	
 Caddy (2K) (04-..)	HEADLIGHT LEVEL	(04-10)	CAN Gateway
 Caddy (2K) (04-..)	IMMOBILIZER	(04-10)	
 Caddy (2K) (04-..)	NAVIGATION	(04-10)	CAN Gateway
 Caddy (2K) (04-..)	PASS. SIDE DOOR	(04-10)	CAN Gateway
 Caddy (2K) (04-..)	PHONE	(04-10)	CAN Gateway
 Caddy (2K) (04-..)	RADIO / CD	(04-10)	
 Caddy (2K) (04-..)	SERVICE LIGHT RES	(04-10)	
 Caddy (2K) (04-..)	SERVICE LIGHT RES	(04-10)	MANUAL
 Caddy (2K) (04-..)	STEERING WHEEL EL	(04-10)	
 Caddy (2K) (04-..)	SUPP HEATER/AUTO	(04-10)	
 Caddy (2K) (04-..)	TRANSPORT MODALI	(04-10)	
 Caddy (9K) (96-03)	AIRBAG	(..-03)	
 Caddy (9K) (96-03)	ENGINE MANAGEME	(..-03)	

## Systems supported by ECReader (up to V5.40)

### TRUCKS



























**VW**

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Caddy (9K) (96-03)	ENGINE MANAGEME	(..-03)	
 Caddy (9K) (96-03)	ENGINE MANAGEME	(..-03)	
 Caddy (9K) (96-03)	IMMOBILIZER	(..-03)	
 Caddy (9K) (96-03)	SERVICE LIGHT RES	(93-96)	MANUAL
 Caddy (9K) (96-03)	SERVICE LIGHT RES	(97-98)	MANUAL
 Crafter (2E-2F) (06-..)	ABS + TRACT. CONT	2.5 TDI 109cv (06-10)	
 Crafter (2E-2F) (06-..)	ABS + TRACT. CONT	2.5 TDI 130cv (06-10)	
 Crafter (2E-2F) (06-..)	ABS + TRACT. CONT	2.5 TDI 164cv (06-10)	
 Crafter (2E-2F) (06-..)	ABS + TRACT. CONT	2.5 TDI 89cv (06-10)	
 Crafter (2E-2F) (06-..)	AIRBAG	2.5 TDI 109cv (06-10)	
 Crafter (2E-2F) (06-..)	AIRBAG	2.5 TDI 130cv (06-10)	
 Crafter (2E-2F) (06-..)	AIRBAG	2.5 TDI 164cv (06-10)	
 Crafter (2E-2F) (06-..)	AIRBAG	2.5 TDI 89cv (06-10)	
 Crafter (2E-2F) (06-..)	AUTOM. TRANSMISSI	2.5 TDI 109cv (06-10)	
 Crafter (2E-2F) (06-..)	AUTOM. TRANSMISSI	2.5 TDI 130cv (06-10)	
 Crafter (2E-2F) (06-..)	AUTOM. TRANSMISSI	2.5 TDI 164cv (06-10)	
 Crafter (2E-2F) (06-..)	AUTOM. TRANSMISSI	2.5 TDI 89cv (06-10)	
 Crafter (2E-2F) (06-..)	DASHBOARD	2.5 TDI 109cv (06-10)	
 Crafter (2E-2F) (06-..)	DASHBOARD	2.5 TDI 130cv (06-10)	
 Crafter (2E-2F) (06-..)	DASHBOARD	2.5 TDI 164cv (06-10)	
 Crafter (2E-2F) (06-..)	DASHBOARD	2.5 TDI 89cv (06-10)	
 Crafter (2E-2F) (06-..)	ENGINE MANAGEME	2.5 TDI 109cv (06-10)	
 Crafter (2E-2F) (06-..)	ENGINE MANAGEME	2.5 TDI 130cv (06-10)	
 Crafter (2E-2F) (06-..)	ENGINE MANAGEME	2.5 TDI 164cv (06-10)	
 Crafter (2E-2F) (06-..)	ENGINE MANAGEME	2.5 TDI 89cv (06-10)	
 Crafter (2E-2F) (06-..)	SERVICE LIGHT RES	2.5 TDI 109cv (06-10)	MANUAL

## Systems supported by ECUreader (up to V5.40)

### TRUCKS



























**VW**

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Crafter (2E-2F) (06-..)	SERVICE LIGHT RES	2.5 TDI 130cv (06-10)	MANUAL
 Crafter (2E-2F) (06-..)	SERVICE LIGHT RES	2.5 TDI 164cv (06-10)	MANUAL
 Crafter (2E-2F) (06-..)	SERVICE LIGHT RES	2.5 TDI 89cv (06-10)	MANUAL
 LT (21-28) (92-96)	ABS	(..-6/96)	
 LT (21-28) (92-96)	ENGINE MANAGEME	(..-6/96)	
 LT (21-28) (92-96)	ENGINE MANAGEME	(..-6/96)	
 LT (21-28) (92-96)	ENGINE MANAGEME	(..-6/96)	
 LT (21-28) (92-96)	IMMOBILIZER	(..-6/96)	
 LT (21-28) (92-96)	SERVICE LIGHT RES	(93-96)	MANUAL
 LT (2D) (97-06)	ABS	(..-06)	ABS/ABD 5.3
 LT (2D) (97-06)	AIRBAG	(..-06)	
 LT (2D) (97-06)	ENGINE MANAGEME	(..-06)	
 LT (2D) (97-06)	IMMOBILIZER	(..-01)	
 LT (2D) (97-06)	IMMOBILIZER	(..-06)	
 LT (2D) (97-06)	SERVICE LIGHT RES	(98-98)	MANUAL
 T4-Caravelle (70-7H-7J) (90	ABS	(..-03)	
 T4-Caravelle (70-7H-7J) (90	AIRBAG	(..-03)	
 T4-Caravelle (70-7H-7J) (90	AUTOM. TRANSMISSI	(..-03)	
 T4-Caravelle (70-7H-7J) (90	CENTRAL LOCKING	(..-03)	
 T4-Caravelle (70-7H-7J) (90	CHASSIS NETWORK	(..-03)	
 T4-Caravelle (70-7H-7J) (90	CLIMA	(..-03)	
 T4-Caravelle (70-7H-7J) (90	DASHBOARD	(..-03)	
 T4-Caravelle (70-7H-7J) (90	ENGINE MANAGEME	(..-03)	
 T4-Caravelle (70-7H-7J) (90	ENGINE MANAGEME	(..-03)	
 T4-Caravelle (70-7H-7J) (90	ENGINE MANAGEME	(..-03)	
 T4-Caravelle (70-7H-7J) (90	IMMOBILIZER	(..-03)	

## Systems supported by ECReader (up to V5.40)

### TRUCKS




**VW**

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 T4-Caravelle (70-7H-7J) (90	RADIO / CD	(..-03)	
 T4-Caravelle (70-7H-7J) (90	SERVICE LIGHT RES	(93-96)	MANUAL
 T4-Caravelle (70-7H-7J) (90	SERVICE LIGHT RES	(97-98)	MANUAL
 T4-Caravelle (70-7H-7J) (90	SERVICE LIGHT RES	(99-03)	
 T4-Transporter (70-7H-7J) (	ABS	(..-03)	
 T4-Transporter (70-7H-7J) (	AIRBAG	(..-03)	
 T4-Transporter (70-7H-7J) (	AUTOM. TRANSMISSI	(..-03)	
 T4-Transporter (70-7H-7J) (	CENTRAL LOCKING	(..-03)	
 T4-Transporter (70-7H-7J) (	CHASSIS NETWORK	(..-03)	
 T4-Transporter (70-7H-7J) (	CLIMA	(..-03)	
 T4-Transporter (70-7H-7J) (	DASHBOARD	(..-03)	
 T4-Transporter (70-7H-7J) (	ENGINE MANAGEME	(..-03)	
 T4-Transporter (70-7H-7J) (	ENGINE MANAGEME	(..-03)	
 T4-Transporter (70-7H-7J) (	ENGINE MANAGEME	(..-03)	
 T4-Transporter (70-7H-7J) (	IMMOBILIZER	(..-03)	
 T4-Transporter (70-7H-7J) (	RADIO / CD	(..-03)	
 T4-Transporter (70-7H-7J) (	SERVICE LIGHT RES	(93-96)	MANUAL
 T4-Transporter (70-7H-7J) (	SERVICE LIGHT RES	(97-98)	MANUAL
 T4-Transporter (70-7H-7J) (	SERVICE LIGHT RES	(99-02)	
 T5-Caravelle (70-7H-7J) (03	4WD ELECTRONICS	(03-06)	
 T5-Caravelle (70-7H-7J) (03	ABS	(03-06)	
 T5-Caravelle (70-7H-7J) (03	AIRBAG	(03-06)	
 T5-Caravelle (70-7H-7J) (03	AUTOM. TRANSMISSI	(03-06)	
 T5-Caravelle (70-7H-7J) (03	CENTRAL ELECTRIC	(03-06)	
 T5-Caravelle (70-7H-7J) (03	CLIMA	(03-06)	
 T5-Caravelle (70-7H-7J) (03	DASHBOARD	(03-06)	

## Systems supported by ECReader (up to V5.40)

### TRUCKS











VW

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 T5-Caravelle (70-7H-7J) (03	ENGINE MANAGEME	(03-06)	
 T5-Caravelle (70-7H-7J) (03	HEADLIGHT LEVEL	(03-06)	
 T5-Caravelle (70-7H-7J) (03	IMMOBILIZER	(03-06)	
 T5-Caravelle (70-7H-7J) (03	NAVIGATION	(03-06)	
 T5-Caravelle (70-7H-7J) (03	PARKING HELP	(03-06)	
 T5-Caravelle (70-7H-7J) (03	PHONE	(03-06)	
 T5-Caravelle (70-7H-7J) (03	RADIO / CD	(03-06)	
 T5-Caravelle (70-7H-7J) (03	SERVICE LIGHT RES	(03-06)	
 T5-Caravelle (70-7H-7J) (03	STEERING WHEEL EL	(03-06)	
 T5-Caravelle (70-7H-7J) (03	SUPP HEATER/AUTO	(03-06)	
 T5-Caravelle (70-7H-7J) (03	TOW FUNCTION	(03-06)	
 T5-Transporter (70-7H-7J) (	4WD ELECTRONICS	(03-06)	
 T5-Transporter (70-7H-7J) (	ABS	(03-06)	
 T5-Transporter (70-7H-7J) (	AIRBAG	(03-06)	
 T5-Transporter (70-7H-7J) (	AUTOM. TRANSMISSI	(03-06)	
 T5-Transporter (70-7H-7J) (	CENTRAL ELECTRIC	(03-06)	
 T5-Transporter (70-7H-7J) (	CLIMA	(03-06)	
 T5-Transporter (70-7H-7J) (	DASHBOARD	(03-06)	
 T5-Transporter (70-7H-7J) (	ENGINE MANAGEME	(03-06)	
 T5-Transporter (70-7H-7J) (	HEADLIGHT LEVEL	(03-06)	
 T5-Transporter (70-7H-7J) (	IMMOBILIZER	(03-06)	
 T5-Transporter (70-7H-7J) (	NAVIGATION	(03-06)	
 T5-Transporter (70-7H-7J) (	PARKING HELP	(03-06)	
 T5-Transporter (70-7H-7J) (	PHONE	(03-06)	
 T5-Transporter (70-7H-7J) (	RADIO / CD	(03-06)	
 T5-Transporter (70-7H-7J) (	SERVICE LIGHT RES	(03-06)	

## Systems supported by ECUREADER (up to V5.40)

### TRUCKS





**VW**

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 T5-Transporter (70-7H-7J) (	STEERING WHEEL EL	(03-06)	
 T5-Transporter (70-7H-7J) (	SUPP HEATER/AUTO	(03-06)	
 T5-Transporter (70-7H-7J) (	TOW FUNCTION	(03-06)	
 Taro (7A) (89-97)	AIRBAG	(..-97)	
 Taro (7A) (89-97)	ENGINE MANAGEME	(..-97)	
 Taro (7A) (89-97)	ENGINE MANAGEME	(..-97)	
 Taro (7A) (89-97)	ENGINE MANAGEME	(..-97)	
 Taro (7A) (89-97)	IMMOBILIZER	(..-97)	
 Taro (7A) (89-97)	SERVICE LIGHT RES	(..-97)	MANUAL
 Taro (7A) (89-97)	SERVICE LIGHT RES	(93-96)	MANUAL

## Systems supported by ECUREADER (up to V5.40)

### TRUCKS


**WABCO**

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Trailers	ABS	Trailers	Wabco Trailer VCS II
 Trailers	ABS	Trailers Wabco	Wabco VARIO C1-C2-C plus
 Trailers	BRAKE SYS. MANAG	Trailers	Wabco Trailer EBS
 Trailers	BRAKE SYS. MANAG	Trailers	Wabco Trailer EBS Kw2000

## Systems supported by ECUreader (up to V5.40)

### TRUCKS

Zorzi

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Trailers	BRAKE SYS. MANAG	Trailers	Wabco Trailer EBS
 Trailers	BRAKE SYS. MANAG	Trailers	Wabco Trailers EBS kw2000
 Trailers	BRAKE SYS. MANAG	Trailers Haldex	Haldex EBS EB+
 Trailers	BRAKE SYS. MANAG	Trailers Knorr	Knorr Trailer EBS
 Trailers	BRAKE SYS. MANAG	Trailers Wabco (01-..)	Wabco VARIO C1-C2-C plus