

## Systems supported by ECUreader (up to V4,90)

### TRUCKS

Acerbi

**MODEL**

**SYSTEM TYPE**

**ENGINE / SYSTEM**

**ECU**

 Trailers



BRAKE SYS. MANAG Trailers

Wabco Trailer EBS

## Systems supported by ECUREADER (up to V4,90)

### TRUCKS





**ACM**

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Trailers	BRAKE SYS. MANAG	Trailers	Wabco Trailer EBS
 Trailers	BRAKE SYS. MANAG	Trailers	Wabco Trailer VCS II

## Systems supported by ECUREADER (up to V4,90)

### TRUCKS






Adamoli

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Trailers	BRAKE SYS. MANAG	Trailers	Wabco Trailer EBS
 Trailers	BRAKE SYS. MANAG	Trailers	Wabco Trailers EBS kw2000
 Trailers	BRAKE SYS. MANAG	Trailers Haldex	Haldex EBS EB+
 Trailers	BRAKE SYS. MANAG	Trailers Knorr	Knorr Trailer EBS

## Systems supported by ECUreader (up to V4,90)

### TRUCKS



Adige

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Trailers	ABS	Trailers Wabco	Wabco VARIO C1-C2-C plus
 Trailers	BRAKE SYS. MANAG	Trailers	Wabco Trailer EBS
 Trailers	BRAKE SYS. MANAG	Trailers	Wabco Trailers EBS kw2000
 Trailers	BRAKE SYS. MANAG	Trailers Haldex	Haldex EBS EB+
 Trailers	BRAKE SYS. MANAG	Trailers Knorr	Knorr Trailer EBS

## Systems supported by ECUREADER (up to V4,90)

### TRUCKS











### AGP Cisternas

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Trailers	BRAKE SYS. MANAG	Trailers	Wabco Trailer EBS
 Trailers	BRAKE SYS. MANAG	Trailers	Wabco Trailer VCS II

## Systems supported by ECReader (up to V4,90)

### TRUCKS





Astra

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 HD7-C 42.36	ENGINE MANAGEME	Cursor 13 F3BE0681JB	BOSCH EDC MS 6.2
 HD7-C 42.40	ENGINE MANAGEME	Cursor 13 F3BE0681DB	BOSCH EDC MS 6.2
 HD7-C 42.45	ENGINE MANAGEME	Cursor 13 F3BE0681HB	BOSCH EDC MS 6.2
 HD7-C 64.36	ENGINE MANAGEME	Cursor 13 F3BE0681JB	BOSCH EDC MS 6.2
 HD7-C 64.40	ENGINE MANAGEME	Cursor 13 F3BE0681DB	BOSCH EDC MS 6.2
 HD7-C 64.45	ENGINE MANAGEME	Cursor 13 F3BE0681HB	BOSCH EDC MS 6.2
 HD7-C 64.50	ENGINE MANAGEME	Cursor 13 F3BE0681FB	BOSCH EDC MS 6.2
 HD7-C 66.36	ENGINE MANAGEME	Cursor 13 F3BE0681DB	BOSCH EDC MS 6.2
 HD7-C 66.36	ENGINE MANAGEME	Cursor 13 F3BE0681FB	BOSCH EDC MS 6.2
 HD7-C 66.36	ENGINE MANAGEME	Cursor 13 F3BE0681HB	BOSCH EDC MS 6.2
 HD7-C 66.36	ENGINE MANAGEME	Cursor 13 F3BE0681JB	BOSCH EDC MS 6.2
 HD7-C 84.36	ENGINE MANAGEME	Cursor 13 F3BE0681JB	BOSCH EDC MS 6.2
 HD7-C 84.40	ENGINE MANAGEME	Cursor 13 F3BE0681DB	BOSCH EDC MS 6.2
 HD7-C 84.45	ENGINE MANAGEME	Cursor 13 F3BE0681HB	BOSCH EDC MS 6.2
 HD7-C 84.50	ENGINE MANAGEME	Cursor 13 F3BE0681FB	BOSCH EDC MS 6.2
 HD7-C 86.40	ENGINE MANAGEME	Cursor 13 F3BE0681DB	BOSCH EDC MS 6.2
 HD7-C 86.45	ENGINE MANAGEME	Cursor 13 F3BE0681HB	BOSCH EDC MS 6.2
 HD7-C 86.50	ENGINE MANAGEME	Cursor 13 F3BE0681FB	BOSCH EDC MS 6.2

## Systems supported by ECUREADER (up to V4,90)

### TRUCKS





Atlas

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Trailers	BRAKE SYS. MANAG	Trailers	Wabco Trailers EBS
 Trailers	BRAKE SYS. MANAG	Trailers	Wabco Trailers EBS kw2000
 Trailers	BRAKE SYS. MANAG	Trailers Haldex	Haldex EBS EB+
 Trailers	BRAKE SYS. MANAG	Trailers Knorr	Knorr Trailer EBS

## Systems supported by ECUREADER (up to V4,90)

### TRUCKS



**Bartoletti**

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Trailers	BRAKE SYS. MANAG	Trailers	Wabco Trailer EBS
 Trailers	BRAKE SYS. MANAG	Trailers	Wabco Trailers EBS kw2000
 Trailers	BRAKE SYS. MANAG	Trailers Haldex	Haldex EBS EB+
 Trailers	BRAKE SYS. MANAG	Trailers Knorr	Knorr Trailer EBS

## Systems supported by ECUreader (up to V4,90)

### TRUCKS



Basben

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Trailers	BRAKE SYS. MANAG	Trailers	Wabco Trailer EBS
 Trailers	BRAKE SYS. MANAG	Trailers	Wabco Trailer VCS II

## Systems supported by ECUreader (up to V4,90)

### TRUCKS





### Basculantes Martin

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Trailers	BRAKE SYS. MANAG	Trailers	Wabco Trailer EBS
 Trailers	BRAKE SYS. MANAG	Trailers	Wabco Trailer VCS II

## Systems supported by ECUreader (up to V4,90)

### TRUCKS





**Berger**

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Trailers	BRAKE SYS. MANAG	Trailers	Wabco Trailer EBS
 Trailers	BRAKE SYS. MANAG	Trailers	Wabco Trailers EBS kw2000
 Trailers	BRAKE SYS. MANAG	Trailers Haldex	Haldex EBS EB+
 Trailers	BRAKE SYS. MANAG	Trailers Knorr	Knorr Trailer EBS

## Systems supported by ECUreader (up to V4,90)

### TRUCKS






Bertoja

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Trailers	BRAKE SYS. MANAG	Trailers	Wabco Trailers EBS
 Trailers	BRAKE SYS. MANAG	Trailers	Wabco Trailers EBS kw2000
 Trailers	BRAKE SYS. MANAG	Trailers Haldex	Haldex EBS EB+
 Trailers	BRAKE SYS. MANAG	Trailers Knorr	Knorr Trailer EBS

## Systems supported by ECUreader (up to V4,90)

### TRUCKS



Broshuis

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Trailers	BRAKE SYS. MANAG	Trailers	Wabco Trailer EBS
 Trailers	BRAKE SYS. MANAG	Trailers	Wabco Trailer VCS II
 Trailers	BRAKE SYS. MANAG	Trailers	Wabco Trailers EBS kw2000
 Trailers	BRAKE SYS. MANAG	Trailers Haldex	Haldex EBS EB+
 Trailers	BRAKE SYS. MANAG	Trailers Knorr	Knorr Trailer EBS

## Systems supported by ECUREADER (up to V4,90)

### TRUCKS



**Caldal**

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Trailers	BRAKE SYS. MANAG	Trailers	Wabco Trailer EBS
 Trailers	BRAKE SYS. MANAG	Trailers	Wabco Trailer VCS II

## Systems supported by ECUREADER (up to V4,90)

### TRUCKS



**Cametal**

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Trailers	BRAKE SYS. MANAG	Trailers	Wabco Trailer EBS
 Trailers	BRAKE SYS. MANAG	Trailers	Wabco Trailer VCS II

## Systems supported by ECUREADER (up to V4,90)

### TRUCKS

Campillo Mursem

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Trailers	BRAKE SYS. MANAG	Trailers	Wabco Trailer EBS
 Trailers	BRAKE SYS. MANAG	Trailers	Wabco Trailer VCS II

## Systems supported by ECUreader (up to V4,90)

### TRUCKS






Cardi

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Trailers	ABS	Trailers Wabco	Wabco VARIO C1-C2-C plus
 Trailers	BRAKE SYS. MANAG	Trailers	Wabco Trailer EBS
 Trailers	BRAKE SYS. MANAG	Trailers	Wabco Trailers EBS kw2000
 Trailers	BRAKE SYS. MANAG	Trailers Haldex	Haldex EBS EB+
 Trailers	BRAKE SYS. MANAG	Trailers Knorr	Knorr Trailer EBS

## Systems supported by ECUREADER (up to V4,90)

### TRUCKS



**Carmosino**

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Trailers	BRAKE SYS. MANAG	Trailers	Wabco Trailer EBS
 Trailers	BRAKE SYS. MANAG	Trailers	Wabco Trailer VCS II
 Trailers	BRAKE SYS. MANAG	Trailers	Wabco Trailers EBS kw2000
 Trailers	BRAKE SYS. MANAG	Trailers Haldex	Haldex EBS EB+
 Trailers	BRAKE SYS. MANAG	Trailers Knorr	Knorr Trailer EBS

## Systems supported by ECUreader (up to V4,90)

### TRUCKS





### Chasis Levante

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Trailers	BRAKE SYS. MANAG	Trailers	Wabco Trailer EBS
 Trailers	BRAKE SYS. MANAG	Trailers	Wabco Trailer VCS II

## Systems supported by ECUREADER (up to V4,90)

### TRUCKS



Chiavetta

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Trailers	BRAKE SYS. MANAG	Trailers	Wabco Trailers EBS
 Trailers	BRAKE SYS. MANAG	Trailers	Wabco Trailers EBS kw2000
 Trailers	BRAKE SYS. MANAG	Trailers Haldex	Haldex EBS EB+
 Trailers	BRAKE SYS. MANAG	Trailers Knorr	Knorr Trailer EBS

## Systems supported by ECUREADER (up to V4,90)

### TRUCKS



**Chizalosa**

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Trailers	BRAKE SYS. MANAG	Trailers	Wabco Trailer EBS
 Trailers	BRAKE SYS. MANAG	Trailers	Wabco Trailer VCS II

## Systems supported by ECUreader (up to V4,90)

### TRUCKS

### Cisternas La Mancha

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Trailers	BRAKE SYS. MANAG	Trailers	Wabco Trailer EBS
 Trailers	BRAKE SYS. MANAG	Trailers	Wabco Trailer VCS II

## Systems supported by ECUREADER (up to V4,90)

### TRUCKS














Citroen

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Berlingo 2	ABS + TRACT. CONT	1.4	BOSCH ABS/ESP 5.7
 Berlingo 2	ABS + TRACT. CONT	1.6 16v	BOSCH ABS/ESP 5.7
 Berlingo 2	ABS + TRACT. CONT	1.9 D	BOSCH ABS/ESP 5.7
 Berlingo 2	ABS + TRACT. CONT	2.0 16v	BOSCH ABS/ESP 5.7
 Berlingo 2	ABS + TRACT. CONT	2.0 HDI	BOSCH ABS/ESP 5.7
 Berlingo 2	ABS + TRACT. CONT	2.0 HDI 16v	BOSCH ABS/ESP 5.7
 Berlingo 2	ENGINE MANAGEME	1.4 KFW	SAGEM S2000
 Berlingo 2	ENGINE MANAGEME	1.6 16v NFU	BOSCH Motronic ME7.4.4
 Berlingo 2	ENGINE MANAGEME	2.0 HDI RHT	BOSCH EDC 15 C2 Common Rail
 Berlingo 2	ENGINE MANAGEME	2.0 HDI RHY	BOSCH EDC 15 C2 Common Rail
 Berlingo 2	ENGINE MANAGEME	2.0 HDI RHY	SIEMENS Diesel SID 801 Common Rail
 Berlingo 2	KEY ENCODE	1.4	VALEO Body Siemens
 Berlingo 2	KEY ENCODE	1.6 16v	VALEO Body Siemens
 Berlingo 2	KEY ENCODE	1.9 D	VALEO Body Siemens
 Berlingo 2	KEY ENCODE	2.0 16v	VALEO Body Siemens
 Berlingo 2	KEY ENCODE	2.0 HDI 16v	VALEO Body Siemens
 Berlingo 2	RADIO / CD	1.4	CLARION AudioSystem
 Berlingo 2	RADIO / CD	1.4	PHILIPS AudioSystem
 Berlingo 2	RADIO / CD	1.4	VDO AudioSystem
 Berlingo 2	RADIO / CD	1.6 16v	CLARION AudioSystem
 Berlingo 2	RADIO / CD	1.6 16v	PHILIPS AudioSystem
 Berlingo 2	RADIO / CD	1.6 16v	VDO AudioSystem
 Berlingo 2	RADIO / CD	1.9 D	CLARION AudioSystem
 Berlingo 2	RADIO / CD	1.9 D	PHILIPS AudioSystem
 Berlingo 2	RADIO / CD	1.9 D	VDO AudioSystem
 Berlingo 2	RADIO / CD	2.0 16v	CLARION AudioSystem
 Berlingo 2	RADIO / CD	2.0 16v	PHILIPS

## Systems supported by ECReader (up to V4,90)

### TRUCKS



























Citroen

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Berlingo 2	RADIO / CD	2.0 16v	VDO AudioSystem
 Berlingo 2	RADIO / CD	2.0 HDI	CLARION AudioSystem
 Berlingo 2	RADIO / CD	2.0 HDI	PHILIPS AudioSystem
 Berlingo 2	RADIO / CD	2.0 HDI	VDO AudioSystem
 Berlingo 2	RADIO / CD	2.0 HDI 16v	CLARION AudioSystem
 Berlingo 2	RADIO / CD	2.0 HDI 16v	PHILIPS AudioSystem
 Berlingo 2	RADIO / CD	2.0 HDI 16v	VDO
 Berlingo 2	VISUAL./TELEMATICS	1.4	SAGEM JCAE
 Berlingo 2	VISUAL./TELEMATICS	1.6 16v	SAGEM JCAE
 Berlingo 2	VISUAL./TELEMATICS	1.9 D	SAGEM JCAE
 Berlingo 2	VISUAL./TELEMATICS	2.0 16v	SAGEM JCAE
 Berlingo 2	VISUAL./TELEMATICS	2.0 HDI	SAGEM JCAE
 Berlingo 2	VISUAL./TELEMATICS	2.0 HDI 16v	SAGEM JCAE
 Berlingo B9	ABS	1.6 HDI 75cv	BOSCH ABS 8.1
 Berlingo B9	ABS	1.6 HDI 90cv	BOSCH ABS 8.1
 Berlingo B9	ABS	1.6 i 16v	BOSCH ABS 8.1
 Berlingo B9	AIRBAG	1.6 HDI 75cv	Autoliv
 Berlingo B9	AIRBAG	1.6 HDI 90cv	Autoliv
 Berlingo B9	AIRBAG	1.6 i 16v	Autoliv
 Berlingo B9	CHASSIS NETWORK	1.6 HDI 75cv	Delphi BSM
 Berlingo B9	CHASSIS NETWORK	1.6 HDI 75cv	JCAE BSI 5.20
 Berlingo B9	CHASSIS NETWORK	1.6 HDI 90cv	Delphi BSM
 Berlingo B9	CHASSIS NETWORK	1.6 HDI 90cv	JCAE BSI 5.20
 Berlingo B9	CHASSIS NETWORK	1.6 i 16v	Delphi BSM
 Berlingo B9	CHASSIS NETWORK	1.6 i 16v	JCAE BSI 5.20
 Berlingo B9	DASHBOARD	1.6 HDI 75cv	MARELLI

## Systems supported by ECReader (up to V4,90)

### TRUCKS



























Citroen

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Berlingo B9	DASHBOARD	1.6 HDI 90cv	MARELLI
 Berlingo B9	DASHBOARD	1.6 i 16v	MARELLI
 Berlingo B9	ENGINE MANAGEME	1.6 i 16v NFR	BOSCH Motronic ME 7.4.5
 Berlingo B9	SERVICE LIGHT RES	1.6 HDI 75cv	
 Berlingo B9	SERVICE LIGHT RES	1.6 HDI 90cv	
 Berlingo B9	SERVICE LIGHT RES	1.6 i 16v	
 Berlingo B9	SWITCHLIGHT MODU	1.6 HDI 75cv	Delphi
 Berlingo B9	SWITCHLIGHT MODU	1.6 HDI 90cv	Delphi
 Berlingo B9	SWITCHLIGHT MODU	1.6 i 16v	Delphi
 Berlingo	ABS	1.1	BOSCH ABS ABR 5.3
 Berlingo	ABS	1.4	BOSCH ABS ABR 5.3
 Berlingo	ABS	1.9 D	BOSCH ABS ABR 5.3
 Berlingo	ABS	2.0 HDI	BOSCH ABS ABR 5.3
 Berlingo	AIRBAG	1.1 (97-00)	AKF- Autoliv AirBag no SIDE AB
 Berlingo	AIRBAG	1.4 (97-00)	AKF- Autoliv AirBag no SIDE AB
 Berlingo	AIRBAG	1.9 D (97-00)	AKF- Autoliv AirBag no SIDE AB
 Berlingo	AIRBAG	2.0 HDI (97-00)	AKF- Autoliv AirBag no SIDE AB
 Berlingo	CHASSIS NETWORK	1.1 (...01)	VALEO Body Computer
 Berlingo	CHASSIS NETWORK	1.4 (...01)	VALEO Body Computer
 Berlingo	CHASSIS NETWORK	1.9 D (...01)	VALEO Body Computer
 Berlingo	CHASSIS NETWORK	2.0 HDI (...01)	VALEO Body Computer
 Berlingo	DIESEL MANAGEMEN	1.9 D WJY	LUCAS Diesel DCN2
 Berlingo	ENGINE MANAGEME	1.1 HDY	BOSCH MonoMotronic MA3.1
 Berlingo	ENGINE MANAGEME	1.1 HDZ	BOSCH MonoMotronic MA3.1
 Berlingo	ENGINE MANAGEME	1.4 KFX	MARELLI MM 1AP.40
 Berlingo	ENGINE MANAGEME	1.4 KFX	SAGEM SL 96

## Systems supported by ECReader (up to V4,90)

### TRUCKS



























Citroen

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Berlingo	ENGINE MANAGEME	2.0 HDI RHY	SIEMENS Diesel SID 801 Common Rail
 Berlingo	ENGINE MANAGEME	2.0 HDI RHY (..-00)	BOSCH EDC 15 C2 Common Rail
 Berlingo	ENGINE MANAGEME	2.0 HDI RHY (03-..)	BOSCH EDC 15 C2 Common Rail
 Berlingo	KEY ENCODE	1.1	Valeo/Siemens
 Berlingo	KEY ENCODE	1.4	Valeo/Siemens
 Berlingo	KEY ENCODE	1.9 D	Valeo/Siemens
 Berlingo	KEY ENCODE	2.0 HDI	Valeo/Siemens
 Berlingo	RADIO / CD	1.1	CLARION AudioSystem
 Berlingo	RADIO / CD	1.1	PHILIPS AudioSystem
 Berlingo	RADIO / CD	1.1	VDO AudioSystem
 Berlingo	RADIO / CD	1.4	CLARION AudioSystem
 Berlingo	RADIO / CD	1.4	PHILIPS AudioSystem
 Berlingo	RADIO / CD	1.4	VDO AudioSystem
 Berlingo	RADIO / CD	1.9 D	CLARION AudioSystem
 Berlingo	RADIO / CD	1.9 D	PHILIPS AudioSystem
 Berlingo	RADIO / CD	1.9 D	VDO AudioSystem
 Berlingo	RADIO / CD	2.0 HDI	CLARION AudioSystem
 Berlingo	RADIO / CD	2.0 HDI	PHILIPS AudioSystem
 Berlingo	RADIO / CD	2.0 HDI	VDO AudioSystem
 Berlingo	SERVICE LIGHT RES	(98-00)	Sagem
 Berlingo	SERVICE LIGHT RES	1.1 (98-00)	Sagem
 Berlingo	SERVICE LIGHT RES	1.4 (98-00)	Sagem
 Berlingo	SERVICE LIGHT RES	1.9 D (98-00)	Sagem
 Berlingo	SERVICE LIGHT RES	2.0 HDI (98-00)	Sagem
 C15	DIESEL MANAGEMEN	1.9 D WJY	LUCAS Diesel DCN2
 C15	ELECTRONIC INJECTI	1.1 HDZ	BOSCH MonoJetronic A2.2 [Slow]

## Systems supported by ECUREADER (up to V4,90)

### TRUCKS























Citroen

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 C15	ELECTRONIC INJECTI	1.4 KDY	BOSCH MonoJetronic A2.2 [Slow]
 Jumper 2	ABS	2.0 16v	BOSCH ABS ABR 5.3
 Jumper 2	ABS	2.8 HDI (06-..)	BOSCH ABS ABR 5.3
 Jumper 2	AIRBAG		SIEMENS AirBag
 Jumper 2	ENGINE MANAGEME	2.0 HDI (02-06)	BOSCH EDC 15 Common Rail (JTD '99)
 Jumper 2	ENGINE MANAGEME	2.3 HDI (02-06)	BOSCH EDC 15 Common Rail (JTD '99)
 Jumper 2	ENGINE MANAGEME	2.8 HDI (02-06)	BOSCH EDC 15 Common Rail (JTD '99)
 Jumper	ABS		BOSCH ABS ABR 5.3
 Jumpy 2	ABS	1.6 HDI (07-..)	BOSCH 8 PSA
 Jumpy 2	ABS	2.0 HDI (07-..)	BOSCH 8 PSA
 Jumpy 2	AIRBAG	1.6 HDI (07-..)	Temic SRS
 Jumpy 2	AIRBAG	2.0 HDI (07-..)	Temic SRS
 Jumpy 2	CHASSIS NETWORK	1.6 HDI (07-..)	Valeo 2 1/2
 Jumpy 2	CHASSIS NETWORK	1.6 HDI (07-..)	Valeo 2 2/2
 Jumpy 2	CHASSIS NETWORK	2.0 HDI (07-..)	Valeo 2 1/2
 Jumpy 2	CHASSIS NETWORK	2.0 HDI (07-..)	Valeo 2 2/2
 Jumpy 2	DASHBOARD	1.6 HDI (07-..)	Marelli Dashboard PSA
 Jumpy 2	DASHBOARD	2.0 HDI (07-..)	Marelli Dashboard PSA
 Jumpy 2	DIESEL ADDITION	2.0 JTD FAP	MARVAL
 Jumpy 2	DIESEL MANAGEMEN	1.9 D WJY	LUCAS Diesel DCN2
 Jumpy 2	ENGINE MANAGEME	1.6 HDI (07-..)	BOSCH EDC 16 34 Common Rail
 Jumpy 2	ENGINE MANAGEME	2.0 HDI RHZ (...00)	BOSCH EDC 15 C2 Common Rail
 Jumpy 2	RADIO / CD	1.6 HDI (07-..)	Blaupunkt AudioSystem
 Jumpy 2	RADIO / CD	2.0 HDI (07-..)	Blaupunkt AudioSystem
 Jumpy 2	SERVICE LIGHT RES	1.6 HDI (07-..)	MANUAL
 Jumpy 2	SERVICE LIGHT RES	2.0 HDI (07-..)	MANUAL

## Systems supported by ECUREADER (up to V4,90)

### TRUCKS



Citroen

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Jumpy 2	SWITCHLIGHT MODU	1.6 HDI (07-..)	Delphi
 Jumpy 2	SWITCHLIGHT MODU	2.0 HDI (07-..)	Delphi
 Jumpy	ABS	1.9 D	BOSCH ABS ABR 5.3
 Jumpy	ABS	1.9 TD	BOSCH ABS ABR 5.3
 Jumpy	ABS	2.0 HDI	BOSCH ABS ABR 5.3
 Jumpy	DIESEL MANAGEMEN	1.9 D WJY	LUCAS Diesel DCN2
 Jumpy	DIESEL MANAGEMEN	1.9 TD DHX	BOSCH AS3 VP20
 Jumpy	ENGINE MANAGEME	2.0 HDI RHT	BOSCH EDC 15 C2 Common Rail
 Jumpy	ENGINE MANAGEME	2.0 HDI RHY (...00)	BOSCH EDC 15 C2 Common Rail
 Nemo	ABS + TRACT. CONT	1.3 Multijet 75cv	BOSCH ESP 8
 Nemo	ABS + TRACT. CONT	1.4 8v	BOSCH ESP 8
 Nemo	AIRBAG	1.3 Multijet 75cv	TRW SRS EP
 Nemo	AIRBAG	1.4 8v	TRW SRS EP
 Nemo	CHASSIS NETWORK	1.3 Multijet 75cv	DELPHI Body Computer
 Nemo	CHASSIS NETWORK	1.3 Multijet 75cv	DELPHI Body Computer CAN Info
 Nemo	CHASSIS NETWORK	1.3 Multijet 75cv	DELPHI EP
 Nemo	CHASSIS NETWORK	1.4 8v	DELPHI Body Computer
 Nemo	CHASSIS NETWORK	1.4 8v	DELPHI Body Computer CAN Info
 Nemo	CHASSIS NETWORK	1.4 8v	DELPHI EP
 Nemo	DASHBOARD	1.3 Multijet 75cv	MARELLI Dashboard Modale
 Nemo	DASHBOARD	1.4 8v	MARELLI Dashboard Modale
 Nemo	ENGINE MANAGEME	1.3 Multijet 75cv	MARELLI IAW 6F3

## Systems supported by ECUREADER (up to V4,90)

### TRUCKS





**Cobo Hermanos**

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Trailers	BRAKE SYS. MANAG	Trailers	Wabco Trailer EBS
 Trailers	BRAKE SYS. MANAG	Trailers	Wabco Trailer VCS II

## Systems supported by ECUreader (up to V4,90)

### TRUCKS




























**CTC**

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Trailers	BRAKE SYS. MANAG	Trailers	Wabco Trailers EBS
 Trailers	BRAKE SYS. MANAG	Trailers	Wabco Trailers EBS kw2000
 Trailers	BRAKE SYS. MANAG	Trailers Haldex	Haldex EBS EB+
 Trailers	BRAKE SYS. MANAG	Trailers Knorr	Knorr Trailer EBS

## Systems supported by ECUreader (up to V4,90)

### TRUCKS


























**DAF**

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 CF 65	AUTOM. TRANSMISSI	XE 340 (02-05)	ZF ASTRONIC
 CF 65	AUTOM. TRANSMISSI	XE 380 (02-05)	ZF ASTRONIC
 CF 65	AUTOM. TRANSMISSI	XE 430 (02-05)	ZF ASTRONIC
 CF 65	AUTOM. TRANSMISSI	XE 480 (02-05)	ZF ASTRONIC
 CF 65	BRAKE SYS. MANAG	280 (07-..)	WABCO EBS 2
 CF 65	BRAKE SYS. MANAG	CF 65.180 (02-..)	WABCO EBS EURO
 CF 65	BRAKE SYS. MANAG	CF 65.220 (02-..)	WABCO EBS EURO
 CF 65	BRAKE SYS. MANAG	CF 65.250 (02-..)	WABCO EBS EURO
 CF 65	DASHBOARD	280 (07-..)	DIP 4
 CF 65	DASHBOARD	XE 340 (02-05)	
 CF 65	DASHBOARD	XE 380 (02-05)	
 CF 65	DASHBOARD	XE 430 (02-05)	
 CF 65	DASHBOARD	XE 480 (02-05)	
 CF 65	ENGINE MANAGEME	XE 340 (02-05)	DAF UPEC
 CF 65	ENGINE MANAGEME	XE 380 (02-05)	DAF UPEC
 CF 65	ENGINE MANAGEME	XE 430 (02-05)	DAF UPEC
 CF 65	ENGINE MANAGEME	XE 480 (02-05)	DAF UPEC
 CF 65	SUSPENSION CONTR	CF 65.180 (02-..)	WABCO ECAS 3
 CF 65	SUSPENSION CONTR	CF 65.180 (02-..)	WABCO ECAS JED
 CF 65	SUSPENSION CONTR	CF 65.220 (02-..)	WABCO ECAS 3
 CF 65	SUSPENSION CONTR	CF 65.220 (02-..)	WABCO ECAS JED
 CF 65	SUSPENSION CONTR	CF 65.250 (02-..)	WABCO ECAS 3
 CF 65	SUSPENSION CONTR	CF 65.250 (02-..)	WABCO ECAS JED
 CF 65	SUSPENSION CONTR	XE 340 (02-05)	WABCO ECAS 3
 CF 65	SUSPENSION CONTR	XE 380 (02-05)	WABCO ECAS 3
 CF 65	SUSPENSION CONTR	XE 430 (02-05)	WABCO ECAS 3
 CF 65	SUSPENSION CONTR	XE 480 (02-05)	WABCO ECAS 3

## Systems supported by ECUreader (up to V4,90)

### TRUCKS



























**DAF**

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 CF 75	AUTOM. TRANSMISSI	XE 340 (02-05)	ZF ASTRONIC
 CF 75	AUTOM. TRANSMISSI	XE 380 (02-05)	ZF ASTRONIC
 CF 75	AUTOM. TRANSMISSI	XE 430 (02-05)	ZF ASTRONIC
 CF 75	AUTOM. TRANSMISSI	XE 480 (02-05)	ZF ASTRONIC
 CF 75	BRAKE SYS. MANAG	310 (07-..)	WABCO EBS 2
 CF 75	BRAKE SYS. MANAG	360 (07-..)	WABCO EBS 2
 CF 75	BRAKE SYS. MANAG	CF 75.250 (02-..)	WABCO EBS EURO
 CF 75	BRAKE SYS. MANAG	CF 75.310 (02-..)	WABCO EBS EURO
 CF 75	BRAKE SYS. MANAG	CF 75.360 (02-..)	WABCO EBS EURO
 CF 75	DASHBOARD	310 (07-..)	DIP 4
 CF 75	DASHBOARD	360 (07-..)	DIP 4
 CF 75	DASHBOARD	XE 340 (02-05)	
 CF 75	DASHBOARD	XE 380 (02-05)	
 CF 75	DASHBOARD	XE 430 (02-05)	
 CF 75	DASHBOARD	XE 480 (02-05)	
 CF 75	ENGINE MANAGEME	XE 340 (02-05)	DAF UPEC
 CF 75	ENGINE MANAGEME	XE 380 (02-05)	DAF UPEC
 CF 75	ENGINE MANAGEME	XE 430 (02-05)	DAF UPEC
 CF 75	ENGINE MANAGEME	XE 480 (02-05)	DAF UPEC
 CF 75	SUSPENSION CONTR	CF 75.250 (02-..)	WABCO ECAS 3
 CF 75	SUSPENSION CONTR	CF 75.250 (02-..)	WABCO ECAS JED
 CF 75	SUSPENSION CONTR	CF 75.310 (02-..)	WABCO ECAS 3
 CF 75	SUSPENSION CONTR	CF 75.310 (02-..)	WABCO ECAS JED
 CF 75	SUSPENSION CONTR	CF 75.360 (02-..)	WABCO ECAS 3
 CF 75	SUSPENSION CONTR	CF 75.360 (02-..)	WABCO ECAS JED
 CF 75	SUSPENSION CONTR	XE 340 (02-05)	WABCO ECAS 3

## Systems supported by ECUreader (up to V4,90)

### TRUCKS



























**DAF**

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 CF 75	SUSPENSION CONTR	XE 380 (02-05)	WABCO ECAS 3
 CF 75	SUSPENSION CONTR	XE 430 (02-05)	WABCO ECAS 3
 CF 75	SUSPENSION CONTR	XE 480 (02-05)	WABCO ECAS 3
 CF 85	AUTOM. TRANSMISSI	XE 340 (02-05)	ZF ASTRONIC
 CF 85	AUTOM. TRANSMISSI	XE 380 (02-05)	ZF ASTRONIC
 CF 85	AUTOM. TRANSMISSI	XE 430 (02-05)	ZF ASTRONIC
 CF 85	AUTOM. TRANSMISSI	XE 480 (02-05)	ZF ASTRONIC
 CF 85	BRAKE SYS. MANAG	410 (07-..)	WABCO EBS 2
 CF 85	BRAKE SYS. MANAG	460 (07-..)	WABCO EBS 2
 CF 85	BRAKE SYS. MANAG	CF 85.340 (02-..)	WABCO EBS EURO
 CF 85	BRAKE SYS. MANAG	CF 85.380 (02-..)	WABCO EBS EURO
 CF 85	BRAKE SYS. MANAG	CF 85.430 (02-..)	WABCO EBS EURO
 CF 85	BRAKE SYS. MANAG	CF 85.480 (02-..)	WABCO EBS EURO
 CF 85	DASHBOARD	410 (07-..)	DIP 4
 CF 85	DASHBOARD	460 (07-..)	DIP 4
 CF 85	DASHBOARD	XE 340 (02-05)	
 CF 85	DASHBOARD	XE 380 (02-05)	
 CF 85	DASHBOARD	XE 430 (02-05)	
 CF 85	DASHBOARD	XE 480 (02-05)	
 CF 85	ENGINE MANAGEME	XE 340 (02-05)	DAF UPEC
 CF 85	ENGINE MANAGEME	XE 380 (02-05)	DAF UPEC
 CF 85	ENGINE MANAGEME	XE 430 (02-05)	DAF UPEC
 CF 85	ENGINE MANAGEME	XE 480 (02-05)	DAF UPEC
 CF 85	SUSPENSION CONTR	CF 85.340 (02-..)	WABCO ECAS 3
 CF 85	SUSPENSION CONTR	CF 85.340 (02-..)	WABCO ECAS JED
 CF 85	SUSPENSION CONTR	CF 85.380 (02-..)	WABCO ECAS 3

## Systems supported by ECUreader (up to V4,90)

### TRUCKS




















**DAF**

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 CF 85	SUSPENSION CONTR	CF 85.380 (02-..)	WABCO ECAS JED
 CF 85	SUSPENSION CONTR	CF 85.430 (02-..)	WABCO ECAS 3
 CF 85	SUSPENSION CONTR	CF 85.430 (02-..)	WABCO ECAS JED
 CF 85	SUSPENSION CONTR	CF 85.480 (02-..)	WABCO ECAS 3
 CF 85	SUSPENSION CONTR	CF 85.480 (02-..)	WABCO ECAS JED
 CF 85	SUSPENSION CONTR	XE 340 (02-05)	WABCO ECAS 3
 CF 85	SUSPENSION CONTR	XE 380 (02-05)	WABCO ECAS 3
 CF 85	SUSPENSION CONTR	XE 430 (02-05)	WABCO ECAS 3
 CF 85	SUSPENSION CONTR	XE 480 (02-05)	WABCO ECAS 3
 XF 105	BRAKE SYS. MANAG	410 (07-..)	WABCO EBS 2
 XF 105	BRAKE SYS. MANAG	460 (07-..)	WABCO EBS 2
 XF 105	BRAKE SYS. MANAG	510 (07-..)	WABCO EBS 2
 XF 105	BRAKE SYS. MANAG	560 (07-..)	WABCO EBS 2
 XF 105	DASHBOARD	410 (07-..)	DIP 4
 XF 105	DASHBOARD	460 (07-..)	DIP 4
 XF 105	DASHBOARD	510 (07-..)	DIP 4
 XF 105	DASHBOARD	560 (07-..)	DIP 4
 XF 95	AUTOM. TRANSMISSI	XE 380 C (02-05)	ZF ASTRONIC
 XF 95	AUTOM. TRANSMISSI	XE 430 C (02-05)	ZF ASTRONIC
 XF 95	AUTOM. TRANSMISSI	XE 480 C (02-05)	ZF ASTRONIC
 XF 95	AUTOM. TRANSMISSI	XE 530 C (02-05)	ZF ASTRONIC
 XF 95	BRAKE SYS. MANAG	XE 280 C (02-..)	WABCO EBS EURO
 XF 95	BRAKE SYS. MANAG	XE 315 C (02-..)	WABCO EBS EURO
 XF 95	BRAKE SYS. MANAG	XE 355 C (02-..)	WABCO EBS EURO
 XF 95	BRAKE SYS. MANAG	XE 390 C (02-..)	WABCO EBS EURO
 XF 95	DASHBOARD	XE 380 C (02-05)	

## Systems supported by ECUreader (up to V4,90)

### TRUCKS





**DAF**

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 XF 95	DASHBOARD	XE 430 C (02-05)	
 XF 95	DASHBOARD	XE 480 C (02-05)	
 XF 95	DASHBOARD	XE 530 C (02-05)	
 XF 95	ENGINE MANAGEME	XE 380 C (02-05)	DAF UPEC
 XF 95	ENGINE MANAGEME	XE 430 C (02-05)	DAF UPEC
 XF 95	ENGINE MANAGEME	XE 480 C (02-05)	DAF UPEC
 XF 95	ENGINE MANAGEME	XE 530 C (02-05)	DAF UPEC
 XF 95	SUSPENSION CONTR	XE 280 C (02-..)	WABCO ECAS 3
 XF 95	SUSPENSION CONTR	XE 280 C (02-..)	WABCO ECAS JED
 XF 95	SUSPENSION CONTR	XE 315 C (02-..)	WABCO ECAS 3
 XF 95	SUSPENSION CONTR	XE 315 C (02-..)	WABCO ECAS JED
 XF 95	SUSPENSION CONTR	XE 355 C (02-..)	WABCO ECAS 3
 XF 95	SUSPENSION CONTR	XE 355 C (02-..)	WABCO ECAS JED
 XF 95	SUSPENSION CONTR	XE 380 C (02-05)	WABCO ECAS 3
 XF 95	SUSPENSION CONTR	XE 390 C (02-..)	WABCO ECAS 3
 XF 95	SUSPENSION CONTR	XE 390 C (02-..)	WABCO ECAS JED
 XF 95	SUSPENSION CONTR	XE 430 C (02-05)	WABCO ECAS 3
 XF 95	SUSPENSION CONTR	XE 480 C (02-05)	WABCO ECAS 3
 XF 95	SUSPENSION CONTR	XE 530 C (02-05)	WABCO ECAS 3

## Systems supported by ECUreader (up to V4,90)

### TRUCKS






De Angelis

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Trailers	BRAKE SYS. MANAG	Trailers	Wabco Trailers EBS
 Trailers	BRAKE SYS. MANAG	Trailers	Wabco Trailers EBS kw2000
 Trailers	BRAKE SYS. MANAG	Trailers Haldex	Haldex EBS EB+
 Trailers	BRAKE SYS. MANAG	Trailers Knorr	Knorr Trailer EBS

## Systems supported by ECUreader (up to V4,90)

### TRUCKS





**Doll**

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Trailers	BRAKE SYS. MANAG	Trailers	Wabco Trailer EBS
 Trailers	BRAKE SYS. MANAG	Trailers	Wabco Trailer VCS II
 Trailers	BRAKE SYS. MANAG	Trailers	Wabco Trailers EBS kw2000
 Trailers	BRAKE SYS. MANAG	Trailers Haldex	Haldex EBS EB+
 Trailers	BRAKE SYS. MANAG	Trailers Knorr	Knorr Trailer EBS

## Systems supported by ECUreader (up to V4,90)

### TRUCKS










### D-TEC

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Trailers	BRAKE SYS. MANAG	Trailers	Wabco Trailers EBS
 Trailers	BRAKE SYS. MANAG	Trailers	Wabco Trailers EBS kw2000
 Trailers	BRAKE SYS. MANAG	Trailers Haldex	Haldex EBS EB+
 Trailers	BRAKE SYS. MANAG	Trailers Knorr	Knorr Trailer EBS

## Systems supported by ECUREADER (up to V4,90)

### TRUCKS



**EvoBus**

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 TRAVEGO	BRAKE SYS. MANAG	O 580 15 RH	BS EBS ZF
 TRAVEGO	BRAKE SYS. MANAG	O 580 15 RHD	BS EBS ZF
 TRAVEGO	BRAKE SYS. MANAG	O 580 17 RHD	BS EBS ZF
 TRAVEGO	CRUISE CONTROL	O 580 15 RH	FR FMR
 TRAVEGO	CRUISE CONTROL	O 580 15 RHD	FR FMR
 TRAVEGO	CRUISE CONTROL	O 580 17 RHD	FR FMR
 TRAVEGO	ENGINE MANAGEME	O 580 15 RH	MR PLD
 TRAVEGO	ENGINE MANAGEME	O 580 15 RHD	MR PLD
 TRAVEGO	ENGINE MANAGEME	O 580 17 RHD	MR PLD

## Systems supported by ECUREADER (up to V4,90)

### TRUCKS



**Fabrisem**

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Trailers	BRAKE SYS. MANAG	Trailers	Wabco Trailer EBS
 Trailers	BRAKE SYS. MANAG	Trailers	Wabco Trailer VCS II

## Systems supported by ECUREADER (up to V4,90)

### TRUCKS





**Farcinox**

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Trailers	BRAKE SYS. MANAG	Trailers	Wabco Trailer EBS
 Trailers	BRAKE SYS. MANAG	Trailers	Wabco Trailer VCS II

## Systems supported by ECUREADER (up to V4,90)

### TRUCKS




























Feldbinder

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Trailers	BRAKE SYS. MANAG	Trailers	Wabco Trailers EBS
 Trailers	BRAKE SYS. MANAG	Trailers	Wabco Trailers EBS kw2000
 Trailers	BRAKE SYS. MANAG	Trailers Haldex	Haldex EBS EB+
 Trailers	BRAKE SYS. MANAG	Trailers Knorr	Knorr Trailer EBS

## Systems supported by ECReader (up to V4,90)

### TRUCKS



























**Fiat**

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Doblo' 03	ABS	1.2 8v	ATE TEVES ABS Mk20
 Doblo' 03	ABS	1.3 Multijet	ATE TEVES ABS Mk20
 Doblo' 03	ABS	1.6 16v Bipower	ATE TEVES ABS Mk20
 Doblo' 03	ABS	1.9 D	ATE TEVES ABS Mk20
 Doblo' 03	ABS	1.9 JTD	ATE TEVES ABS Mk20
 Doblo' 03	ABS	120 1.9 JTD	ATE TEVES ABS Mk20
 Doblo' 03	AIRBAG		AUTOLIV AirBag MY 99 (1F-2P)
 Doblo' 03	AIRBAG		AUTOLIV AirBag MY 99 (2F-2P-2L-I)
 Doblo' 03	AIRBAG		AUTOLIV AirBag MY 99 (2F-2P-I)
 Doblo' 03	AIRBAG		SIEMENS AirBag MY 99 (2F-2P-2L-2T-2I-S)
 Doblo' 03	AIRBAG		SIEMENS AirBag MY 99 (2F-2P-I-S)
 Doblo' 03	AIRBAG		SIEMENS AirBag MY 99 (2F-4P-4L-2T-2I-S)
 Doblo' 03	CHASSIS NETWORK	1.2 8v (03-..)	DELPHI/MARELLI Body Computer
 Doblo' 03	CHASSIS NETWORK	1.3 Multijet (03-..)	DELPHI/MARELLI Body Computer
 Doblo' 03	CHASSIS NETWORK	1.6 16v Bipower (03-..)	DELPHI/MARELLI Body Computer
 Doblo' 03	CHASSIS NETWORK	1.9 DS (03-..)	DELPHI/MARELLI Body Computer
 Doblo' 03	CHASSIS NETWORK	1.9 JTD (03-..)	DELPHI/MARELLI Body Computer
 Doblo' 03	CHASSIS NETWORK	120 1.9 JTD (03-..)	DELPHI/MARELLI Body Computer
 Doblo' 03	DASHBOARD	1.2 8v	MARELLI Dashboard Comfort
 Doblo' 03	DASHBOARD	1.2 8v	MARELLI Dashboard Strip/Modale
 Doblo' 03	DASHBOARD	1.3 Multijet	MARELLI Dashboard Comfort
 Doblo' 03	DASHBOARD	1.3 Multijet	MARELLI Dashboard Strip/Modale
 Doblo' 03	DASHBOARD	1.6 16v Bipower	MARELLI Dashboard Comfort
 Doblo' 03	DASHBOARD	1.6 16v Bipower	MARELLI Dashboard Strip/Modale
 Doblo' 03	DASHBOARD	1.9 DS	MARELLI Dashboard Comfort
 Doblo' 03	DASHBOARD	1.9 DS	MARELLI Dashboard Strip/Modale
 Doblo' 03	DASHBOARD	1.9 JTD	MARELLI Dashboard Comfort

## Systems supported by ECReader (up to V4,90)

### TRUCKS
























**Fiat**

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Doblo' 03	DASHBOARD	1.9 JTD	MARELLI Dashboard Strip/Modale
 Doblo' 03	DASHBOARD	120 1.9 JTD	MARELLI Dashboard Comfort
 Doblo' 03	DASHBOARD	120 1.9 JTD	MARELLI Dashboard Strip/Modale
 Doblo' 03	DIESEL MANAGEMEN	1.9 D	LUCAS EPIC DCU3F
 Doblo' 03	ENGINE MANAGEME	1.3 Multijet	MARELLI 6JF CF3 Common Rail
 Doblo' 03	ENGINE MANAGEME	1.3 Multijet FAP	MARELLI 6F3 CF3 Common Rail
 Doblo' 03	ENGINE MANAGEME	1.6 16v Bipower	MARELLI IAW 49F/59F EOBD
 Doblo' 03	ENGINE MANAGEME	1.6 16v Bipower (03-..)	METATRON 6A0 EOBD
 Doblo' 03	ENGINE MANAGEME	1.9 JTD	BOSCH EDC 15 Common Rail (JTD '99)
 Doblo' 03	ENGINE MANAGEME	120 1.9 JTD	BOSCH EDC 16 Common Rail
 Doblo' 03	KEY ENCODE	1.2 8v	DELPHI/MARELLI CODE Body Computer
 Doblo' 03	KEY ENCODE	1.3 Multijet	DELPHI/MARELLI CODE Body Computer
 Doblo' 03	KEY ENCODE	1.6 16v Bipower	DELPHI/MARELLI CODE Body Computer
 Doblo' 03	KEY ENCODE	1.9 DS	DELPHI/MARELLI CODE Body Computer
 Doblo' 03	KEY ENCODE	1.9 JTD	DELPHI/MARELLI CODE Body Computer
 Doblo' 03	KEY ENCODE	120 1.9 JTD	DELPHI/MARELLI CODE Body Computer
 Doblo'	ABS	1.2	ATE TEVES ABS Mk20
 Doblo'	ABS	1.2 16v	ATE TEVES ABS Mk20
 Doblo'	ABS	1.9 D	ATE TEVES ABS Mk20
 Doblo'	ABS	1.9 JTD	ATE TEVES ABS Mk20
 Doblo'	ABS	80 1.9 JTD	ATE TEVES ABS Mk20
 Doblo'	AIRBAG		AUTOLIV AirBag MY 99 (1F-2P)
 Doblo'	AIRBAG		AUTOLIV AirBag MY 99 (2F-2P-2L-I)
 Doblo'	AIRBAG		AUTOLIV AirBag MY 99 (2F-2P-I)
 Doblo'	AIRBAG		SIEMENS AirBag MY 99 (2F-2P-2L-2T-2I-S)
 Doblo'	AIRBAG		SIEMENS AirBag MY 99 (2F-2P-I-S)

## Systems supported by ECUREADER (up to V4,90)

### TRUCKS



























**Fiat**

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Doblo'	AIRBAG		SIEMENS AirBag MY 99 (2F-4P-4L-2T-2I-S)
 Doblo'	CHASSIS NETWORK	1.2	DELPHI/MARELLI Body Computer
 Doblo'	CHASSIS NETWORK	1.2	Fiat CAN Info
 Doblo'	CHASSIS NETWORK	1.2 (03-..)	DELPHI/MARELLI Body Computer
 Doblo'	CHASSIS NETWORK	1.2 16v	Fiat Proxi Alignement
 Doblo'	CHASSIS NETWORK	1.2 8v	Fiat Proxi Alignement
 Doblo'	CHASSIS NETWORK	1.2 8v (03-..)	Fiat Proxi Alignement
 Doblo'	CHASSIS NETWORK	1.2 8v Bipower (03-..)	DELPHI/MARELLI Body Computer
 Doblo'	CHASSIS NETWORK	1.2 8v Bipower (03-..)	Fiat Proxi Alignement
 Doblo'	CHASSIS NETWORK	1.3 Multijet (03-..)	DELPHI/MARELLI Body Computer
 Doblo'	CHASSIS NETWORK	1.3 Multijet (03-..)	Fiat Proxi Alignement
 Doblo'	CHASSIS NETWORK	1.6 16v (03-..)	DELPHI/MARELLI Body Computer
 Doblo'	CHASSIS NETWORK	1.6 16v (03-..)	Fiat Proxi Alignement
 Doblo'	CHASSIS NETWORK	1.9 D	DELPHI/MARELLI Body Computer
 Doblo'	CHASSIS NETWORK	1.9 D	Fiat CAN Info
 Doblo'	CHASSIS NETWORK	1.9 D	Fiat Proxi Alignement
 Doblo'	CHASSIS NETWORK	1.9 DS (03-..)	DELPHI/MARELLI Body Computer
 Doblo'	CHASSIS NETWORK	1.9 DS (03-..)	Fiat Proxi Alignement
 Doblo'	CHASSIS NETWORK	1.9 JTD	DELPHI/MARELLI Body Computer
 Doblo'	CHASSIS NETWORK	1.9 JTD	Fiat CAN Info
 Doblo'	CHASSIS NETWORK	1.9 JTD	Fiat Proxi Alignement
 Doblo'	CHASSIS NETWORK	1.9 JTD (03-..)	DELPHI/MARELLI Body Computer
 Doblo'	CHASSIS NETWORK	1.9 JTD (03-..)	Fiat Proxi Alignement
 Doblo'	DASHBOARD	1.2	VEGLIA/MARELLI Dashboard
 Doblo'	DASHBOARD	1.9 D	VEGLIA/MARELLI Dashboard
 Doblo'	DASHBOARD	1.9 JTD	VEGLIA/MARELLI Dashboard
 Doblo'	DIESEL MANAGEMEN	1.9 D	LUCAS EPIC DCU3F

## Systems supported by ECReader (up to V4,90)

### TRUCKS



























**Fiat**

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Doblo'	ENGINE MANAGEME	1.2	MARELLI IAW 49F/59F EOBD
 Doblo'	ENGINE MANAGEME	1.2	MARELLI IAW 59F
 Doblo'	ENGINE MANAGEME	1.2	MARELLI IAW 5AF
 Doblo'	ENGINE MANAGEME	1.2 (01-..)	EOBD
 Doblo'	ENGINE MANAGEME	1.3 Multijet	MARELLI 6JF CF3 Common Rail
 Doblo'	ENGINE MANAGEME	100 1.9 JTD (02-..)	BOSCH EDC 15 Common Rail (JTD '99)
 Doblo'	ENGINE MANAGEME	80 1.9 JTD	BOSCH EDC 15 Common Rail (JTD '99)
 Doblo'	KEY ENCODE	1.2	DELPHI/MARELLI CODE Body Computer
 Doblo'	KEY ENCODE	1.9 D	DELPHI/MARELLI CODE Body Computer
 Doblo'	KEY ENCODE	1.9 JTD	DELPHI/MARELLI CODE Body Computer
 Ducato 03	ABS	2.8 JTD	BOSCH ABS 5.3
 Ducato 03	ABS	2.8 JTD (03-..)	BOSCH ABS 5.3
 Ducato 03	AIRBAG		SIEMENS AirBag MY 99 (2F-2P-2L-I)
 Ducato 03	AIRBAG		SIEMENS AirBag MY 99 (2F-2P-I)
 Ducato 03	AIRBAG		SIEMENS AirBag MY 99 (2F-3P-I)
 Ducato 03	AIRBAG	(03-..)	SIEMENS AirBag MY 99 (1F-2P)
 Ducato 03	AIRBAG	(03-..)	SIEMENS AirBag MY 99 (1F-3P)
 Ducato 03	AIRBAG	(03-..)	SIEMENS AirBag MY 99 (2F-2P-2L-I)
 Ducato 03	AIRBAG	(03-..)	SIEMENS AirBag MY 99 (2F-2P-I)
 Ducato 03	AIRBAG	(03-..)	SIEMENS AirBag MY 99 (2F-3P-I)
 Ducato 03	ENGINE MANAGEME	2.8 JTD (03-..)	BOSCH EDC 15 Common Rail (JTD '99)
 Ducato 03	IMMOBILIZER	2.8 JTD	DELPHI CODE 2
 Ducato 03	IMMOBILIZER	2.8 JTD (03-..)	DELPHI CODE 2
 Ducato 03	SERVICE LIGHT RES	(03-..)	
 Ducato 98	ABS	2.0 (98-..)	BOSCH ABS 5.3
 Ducato 98	ABS	2.0 JTD (98-..)	BOSCH ABS 5.3

## Systems supported by ECReader (up to V4,90)

### TRUCKS



























Fiat

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Ducato 98	ABS	2.3 JTD (98-..)	BOSCH ABS 5.3
 Ducato 98	ABS	2.8 JTD (98-..)	BOSCH ABS 5.3
 Ducato 98	ABS	Bipower-Gpower (98-..)	BOSCH ABS 5.3
 Ducato 98	AIRBAG		SIEMENS AirBag MY 99 (1F-2P)
 Ducato 98	AIRBAG		SIEMENS AirBag MY 99 (1F-3P)
 Ducato 98	AIRBAG		SIEMENS AirBag MY 99 (2F-2P-2L-I)
 Ducato 98	AIRBAG		SIEMENS AirBag MY 99 (2F-2P-I)
 Ducato 98	AIRBAG		SIEMENS AirBag MY 99 (2F-3P-I)
 Ducato 98	CENTRAL LOCKING	2.0	RF Bloccaporte/ricevitore VAS 97/3
 Ducato 98	CENTRAL LOCKING	2.0 JTD	RF Bloccaporte/ricevitore VAS 97/3
 Ducato 98	CENTRAL LOCKING	2.3 JTD	RF Bloccaporte/ricevitore VAS 97/3
 Ducato 98	CENTRAL LOCKING	2.8 JTD	RF Bloccaporte/ricevitore VAS 97/3
 Ducato 98	CENTRAL LOCKING	Bipower-Gpower	RF Bloccaporte/ricevitore VAS 97/3
 Ducato 98	ENGINE MANAGEME	2.0 JTD	BOSCH EDC 15 Common Rail (JTD '99)
 Ducato 98	ENGINE MANAGEME	2.3 JTD	BOSCH EDC 15 Common Rail (JTD '99)
 Ducato 98	ENGINE MANAGEME	2.8 JTD	BOSCH EDC 15 Common Rail (JTD '99)
 Ducato 98	IMMOBILIZER	2.0	DELPHI CODE 2
 Ducato 98	IMMOBILIZER	2.0 JTD	DELPHI CODE 2
 Ducato 98	IMMOBILIZER	2.3 JTD	DELPHI CODE 2
 Ducato 98	IMMOBILIZER	2.8 JTD	DELPHI CODE 2
 Ducato 98	IMMOBILIZER	Bipower-Gpower	DELPHI CODE 2
 Ducato 98	SERVICE LIGHT RES	2.0	
 Ducato 98	SERVICE LIGHT RES	2.0 JTD	
 Ducato 98	SERVICE LIGHT RES	2.3 JTD	
 Ducato 98	SERVICE LIGHT RES	2.8 JTD	
 Ducato 98	SERVICE LIGHT RES	Bipower-Gpower	

## Systems supported by ECReader (up to V4,90)

### TRUCKS
















**Fiat**

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Ducato	ABS		BOSCH ABS 5.3
 Ducato	AIRBAG		BREED AirBag + Pret.
 Ducato	AIRBAG		BREED AirBag MY 97 (1F-2P)
 Fiorino 08	ABS + TRACT. CONT	1.3 Multijet 75cv (08-..)	Bosch ESP 8
 Fiorino 08	ABS + TRACT. CONT	1.4 8v (08-..)	Bosch ESP 8
 Fiorino 08	AIRBAG	1.3 Multijet 75cv (08-..)	TRW SRS EP
 Fiorino 08	AIRBAG	1.4 8v (08-..)	TRW SRS EP
 Fiorino 08	CHASSIS NETWORK	1.3 Multijet 75cv (08-..)	DELPHI Body Computer
 Fiorino 08	CHASSIS NETWORK	1.3 Multijet 75cv (08-..)	DELPHI Body Computer CAN Info
 Fiorino 08	CHASSIS NETWORK	1.3 Multijet 75cv (08-..)	DELPHI EP
 Fiorino 08	CHASSIS NETWORK	1.4 8v (08-..)	DELPHI Body Computer
 Fiorino 08	CHASSIS NETWORK	1.4 8v (08-..)	DELPHI Body Computer CAN Info
 Fiorino 08	CHASSIS NETWORK	1.4 8v (08-..)	DELPHI EP
 Fiorino 08	DASHBOARD	1.3 Multijet 75cv (08-..)	MARELLI Dashboard Comfort
 Fiorino 08	DASHBOARD	1.3 Multijet 75cv (08-..)	MARELLI Dashboard Modale
 Fiorino 08	DASHBOARD	1.4 8v (08-..)	MARELLI Dashboard Comfort
 Fiorino 08	DASHBOARD	1.4 8v (08-..)	MARELLI Dashboard Modale
 Fiorino 08	ENGINE MANAGEME	1.3 Multijet 75cv (08-..)	MARELLI IAW 6F3
 Fiorino	ABS + TRACT. CONT	1.3 Multijet 75cv	BOSCH ESP 8
 Fiorino	ABS + TRACT. CONT	1.4 8v	BOSCH ESP 8
 Fiorino	AIRBAG	1.3 Multijet 75cv	TRW SRS EP
 Fiorino	AIRBAG	1.4 8v	TRW SRS EP
 Fiorino	CHASSIS NETWORK	1.3 Multijet 75cv	DELPHI Body Computer
 Fiorino	CHASSIS NETWORK	1.3 Multijet 75cv	DELPHI Body Computer CAN Info
 Fiorino	CHASSIS NETWORK	1.3 Multijet 75cv	DELPHI EP
 Fiorino	CHASSIS NETWORK	1.4 8v	DELPHI Body Computer

## Systems supported by ECUREADER (up to V4,90)

### TRUCKS





**Fiat**

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Fiorino	CHASSIS NETWORK	1.4 8v	DELPHI Body Computer CAN Info
 Fiorino	CHASSIS NETWORK	1.4 8v	DELPHI EP
 Fiorino	DASHBOARD	1.3 Multijet 75cv	MARELLI Dashboard Modale
 Fiorino	DASHBOARD	1.4 8v	MARELLI Dashboard Modale
 Fiorino	ELECTRONIC INJECTI	1.5 AT Kat	BOSCH MonoJetronic A2.2
 Fiorino	ELECTRONIC INJECTI	1.5 Kat	BOSCH MonoJetronic A2.2
 Fiorino	ENGINE MANAGEME	1.3 Multijet 75cv	MARELLI IAW 6F3
 Fiorino	ENGINE MANAGEME	1.6 Kat	BOSCH MonoMotronic MA1.7
 Scudo	ABS		BOSCH ABS ABR 5.3
 Scudo	DIESEL MANAGEMEN	1.9 D WJY (00-..)	LUCAS Diesel DCN2
 Scudo	DIESEL MANAGEMEN	1.9 TD	BOSCH AS3 VP20
 Scudo	ENGINE MANAGEME	1.6 Kat	BOSCH MonoMotronic MA1.7
 Scudo	ENGINE MANAGEME	2.0 JTD (..-99)	BOSCH EDC 15 C2 Common Rail
 Scudo	ENGINE MANAGEME	2.0 JTD RHT	BOSCH EDC 15 C2 Common Rail
 Strada	DIESEL MANAGEMEN	1.9 D (99-..)	LUCAS EPIC DCU3F

## Systems supported by ECUREADER (up to V4,90)

### TRUCKS

























Fliegl

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Trailers	BRAKE SYS. MANAG	Trailers	Wabco Trailer EBS
 Trailers	BRAKE SYS. MANAG	Trailers	Wabco Trailers EBS kw2000
 Trailers	BRAKE SYS. MANAG	Trailers Haldex	Haldex EBS EB+
 Trailers	BRAKE SYS. MANAG	Trailers Knorr	Knorr Trailer EBS

## Systems supported by ECReader (up to V4,90)

### TRUCKS



Ford

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Courier	ENGINE MANAGEME	1.3 J4C (95-..)	FORD SEFI EEC-V
 Courier	ENGINE MANAGEME	1.3 J6B (..-96)	FORD EFI EEC-IV
 Courier	ENGINE MANAGEME	1.4 FHA (95-..)	FORD SEFI EEC-V
 Tourneo	ENGINE MANAGEME	2.0 NGS (94-..)	FORD SEFI EEC-V
 Tourneo	ENGINE MANAGEME	2.0 NSF (94-..)	FORD SEFI EEC-V
 Transit	ABS		BOSCH ABS 5
 Transit	ABS	2.2 TDCi 110cv (07-..)	ABS
 Transit	ABS	2.2 TDCi 140cv (07-..)	ABS
 Transit	ABS	2.3 (07-..)	ABS
 Transit	ABS	2.4 TDCi 100cv (07-..)	ABS
 Transit	ABS	2.4 TDCi 115cv (07-..)	ABS
 Transit	ABS	2.4 TDCi 140cv (07-..)	ABS
 Transit	ABS	3.2 TDCi 200cv (07-..)	ABS
 Transit	AIRBAG	(..-00)	FORD AirBag SRS
 Transit	AIRBAG	(..-01)	FORD AirBag SRS
 Transit	ENGINE MANAGEME	2.0 (97-..)	FORD SEFI EEC-V
 Transit	ENGINE MANAGEME	2.4 TDCi 100cv (07-..)	PCM
 Transit	ENGINE MANAGEME	2.4 TDCi 115cv (07-..)	PCM
 Transit	ENGINE MANAGEME	2.4 TDCi 140cv (07-..)	PCM
 Transit	ENGINE MANAGEME	2.4 TDDi DOFA (..-01)	FORD Diesel - Duratorq-Di EEC-V
 Transit	ENGINE MANAGEME	2.5 TD (97-..)	FORD Diesel EEC-V
 Transit	KEY ENCODE	(..-00)	FORD PATS
 Transit	KEY ENCODE	(95-99)	FORD PATS
 Transit	SERVICE LIGHT RES	(00-..)	

## Systems supported by ECUREADER (up to V4,90)

### TRUCKS



### Frenos Camino

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Trailers	BRAKE SYS. MANAG	Trailers	Wabco Trailer EBS
 Trailers	BRAKE SYS. MANAG	Trailers	Wabco Trailer VCS II

## Systems supported by ECUREADER (up to V4,90)

### TRUCKS



Fruehauf

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Trailers	BRAKE SYS. MANAG	Trailers	Wabco Trailer EBS
 Trailers	BRAKE SYS. MANAG	Trailers	Wabco Trailer VCS II

## Systems supported by ECUREADER (up to V4,90)

### TRUCKS





**Galucho**

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Trailers	BRAKE SYS. MANAG	Trailers	Wabco Trailer EBS
 Trailers	BRAKE SYS. MANAG	Trailers	Wabco Trailer VCS II

## Systems supported by ECUreader (up to V4,90)

### TRUCKS





Goldhofer

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Trailers	BRAKE SYS. MANAG	Trailers	Wabco Trailers EBS
 Trailers	BRAKE SYS. MANAG	Trailers	Wabco Trailers EBS kw2000
 Trailers	BRAKE SYS. MANAG	Trailers Haldex	Haldex EBS EB+
 Trailers	BRAKE SYS. MANAG	Trailers Knorr	Knorr Trailer EBS

## Systems supported by ECUreader (up to V4,90)

### TRUCKS



### Gontrailer

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Trailers	BRAKE SYS. MANAG	Trailers	Wabco Trailers EBS
 Trailers	BRAKE SYS. MANAG	Trailers	Wabco Trailers EBS kw2000
 Trailers	BRAKE SYS. MANAG	Trailers Haldex	Haldex EBS EB+
 Trailers	BRAKE SYS. MANAG	Trailers Knorr	Knorr Trailer EBS

## Systems supported by ECUreader (up to V4,90)

### TRUCKS

Guillen

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Trailers	BRAKE SYS. MANAG	Trailers	Wabco Trailer EBS
 Trailers	BRAKE SYS. MANAG	Trailers	Wabco Trailer VCS II

## Systems supported by ECUREADER (up to V4,90)

### TRUCKS

**Haldex**

**MODEL**

**SYSTEM TYPE**

**ENGINE / SYSTEM**

**ECU**



Trailers



BRAKE SYS. MANAG Trailers

Haldex EBS EB+

## Systems supported by ECUREADER (up to V4,90)

### TRUCKS



**Hermanns**

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Trailers	BRAKE SYS. MANAG	Trailers	Wabco Trailer EBS
 Trailers	BRAKE SYS. MANAG	Trailers	Wabco Trailer VCS II

## Systems supported by ECUREADER (up to V4,90)

### TRUCKS





















Invepe

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Trailers	BRAKE SYS. MANAG	Trailers	Wabco Trailer EBS
 Trailers	BRAKE SYS. MANAG	Trailers	Wabco Trailer VCS II

## Systems supported by ECUREADER (up to V4,90)

### TRUCKS

**IrisBus**

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 CityClass	ENGINE MANAGEME	Cursor	BOSCH EDC MS 6.2
 Domino	ENGINE MANAGEME	380	BOSCH EDC M7
 EuroClass HD	BRAKE SYS. MANAG		Wabco EBS EURO
 EuroClass HD	ENGINE MANAGEME	Cursor	Bosch EDC MS 6.2
 EuroClass ND	BRAKE SYS. MANAG		Wabco EBS EURO
 Euroclass	ENGINE MANAGEME	380	BOSCH EDC M7
 Mini & Midi (Daily)	ABS + TRACT. CONT	8140 MiniBUS	Bosch ABS/ABD/EBD 5.3
 Mini & Midi (Daily)	ABS + TRACT. CONT	8140 ScuolaBUS	Bosch ABS/ABD/EBD 5.3
 Mini & Midi (Daily)	CLIMA	8140 MiniBUS	Marelli A/C Clima
 Mini & Midi (Daily)	CLIMA	8140 ScuolaBUS	Marelli A/C Clima
 Mini & Midi (Daily)	ENGINE MANAGEME	8140 MiniBUS	Bosch EDC MS6.3
 Mini & Midi (Daily)	ENGINE MANAGEME	8140 ScuolaBUS	Bosch EDC MS6.3
 Mini & Midi (Daily)	IMMOBILIZER		BOSCH
 My way	ENGINE MANAGEME	393	BOSCH EDC M7
 My way	ENGINE MANAGEME	393 E	BOSCH EDC M7
 My way	ENGINE MANAGEME	Cursor	BOSCH EDC MS 6.2
 Touring by ORLANDI (Daily)	ABS + TRACT. CONT	8140 MiniBUS	Bosch ABS/ABD/EBD 5.3
 Touring by ORLANDI (Daily)	CLIMA	8140 MiniBUS	Marelli A/C Clima
 Touring by ORLANDI (Daily)	ENGINE MANAGEME	8140 MiniBUS	Bosch EDC MS6.3
 Touring by ORLANDI (Daily)	IMMOBILIZER		BOSCH

## Systems supported by ECReader (up to V4,90)

### TRUCKS



























Iveco

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Daily & TurboDaily	ABS + TRACT. CONT	29 L 10 FIAE0481A	BOSCH ABS/ABD/EBD 5.3
 Daily & TurboDaily	ABS + TRACT. CONT	29 L 11 8140	BOSCH ABS/ABD/EBD 5.3
 Daily & TurboDaily	ABS + TRACT. CONT	29 L 12 FIAE0481B	BOSCH ABS/ABD/EBD 5.3
 Daily & TurboDaily	ABS + TRACT. CONT	29 L 9 8140	BOSCH ABS/ABD/EBD 5.3
 Daily & TurboDaily	ABS + TRACT. CONT	35 C 10 FIAE0481A	BOSCH ABS/ABD/EBD 5.3
 Daily & TurboDaily	ABS + TRACT. CONT	35 C 11 8140	BOSCH ABS/ABD/EBD 5.3
 Daily & TurboDaily	ABS + TRACT. CONT	35 C 12 FIAE0481B	BOSCH ABS/ABD/EBD 5.3
 Daily & TurboDaily	ABS + TRACT. CONT	35 C 13 8140	BOSCH ABS/ABD/EBD 5.3
 Daily & TurboDaily	ABS + TRACT. CONT	35 C 9 8140	BOSCH ABS/ABD/EBD 5.3
 Daily & TurboDaily	ABS + TRACT. CONT	35 L 9 8140	BOSCH ABS/ABD/EBD 5.3
 Daily & TurboDaily	ABS + TRACT. CONT	35 S 11 8140	BOSCH ABS/ABD/EBD 5.3
 Daily & TurboDaily	ABS + TRACT. CONT	35 S 12 FIAE0481B	BOSCH ABS/ABD/EBD 5.3
 Daily & TurboDaily	ABS + TRACT. CONT	35 S 13 8140	BOSCH ABS/ABD/EBD 5.3
 Daily & TurboDaily	ABS + TRACT. CONT	40 C 10 FIAE0481A	BOSCH ABS/ABD/EBD 5.3
 Daily & TurboDaily	ABS + TRACT. CONT	40 C 11 8140	BOSCH ABS/ABD/EBD 5.3
 Daily & TurboDaily	ABS + TRACT. CONT	40 C 12 FIAE0481B	BOSCH ABS/ABD/EBD 5.3
 Daily & TurboDaily	ABS + TRACT. CONT	40 C 13 8140	BOSCH ABS/ABD/EBD 5.3
 Daily & TurboDaily	ABS + TRACT. CONT	40 C 9 8140	BOSCH ABS/ABD/EBD 5.3
 Daily & TurboDaily	ABS + TRACT. CONT	65 C 15 8140	BOSCH ABS/ABD/EBD 5.3
 Daily & TurboDaily	AIRBAG		ALLIED AirBag MY 97 (2F-2P)
 Daily & TurboDaily	CLIMA	(..-02)	Marelli A/C Clima
 Daily & TurboDaily	CLIMA	Unijet (02-05)	Marelli
 Daily & TurboDaily	ENGINE MANAGEME	2.3 HPI 16v F1AE0481A	BOSCH EDC 16 Common Rail
 Daily & TurboDaily	ENGINE MANAGEME	2.3 HPI 16v F1AE0481B	BOSCH EDC 16 Common Rail
 Daily & TurboDaily	ENGINE MANAGEME	2.3 Unijet (04-06)	BOSCH EDC MS6.3
 Daily & TurboDaily	ENGINE MANAGEME	2.8 Unijet 8140 (00-04)	BOSCH EDC MS6.3
 Daily & TurboDaily	IMMOBILIZER		BOSCH

## Systems supported by ECUreader (up to V4,90)

### TRUCKS



























Iveco

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Daily & TurboDaily	IMMOBILIZER	2.3 Unijet	
 Daily & TurboDaily	KEY ENCODE		BOSCH CODE
 EuroCargo	ABS		BOSCH/KNORR ABS 2X
 EuroCargo	ABS + TRACT. CONT		BOSCH ABS/ASR/SL P4 Full Air
 EuroCargo	ABS + TRACT. CONT		WABCO ABS/ASR/EBS C3
 EuroCargo	EMERGENCY START	Tector	
 EuroCargo	ENGINE MANAGEME		BOSCH EDC 7
 EuroCargo	SUSPENSION CONTR	Tector	WABCO ECAS F. P. + CAN
 EuroFire	ABS + TRACT. CONT		BOSCH ABS/ASR/SL P4 Full Air
 EuroFire	ABS + TRACT. CONT		WABCO ABS/ASR/EBS C3
 EuroFire	ENGINE MANAGEME		BOSCH EDC 7
 EuroFire	SUSPENSION CONTR		WABCO ECAS Full Pneumatic
 EuroFire	SUSPENSION CONTR		WABCO ECAS Pneumatic
 EuroMover	ABS + TRACT. CONT		WABCO ABS/ASR/EBS C3
 EuroMover	ENGINE MANAGEME	Cursor 10 F3AE0681A	BOSCH EDC MS 6.2
 EuroMover	ENGINE MANAGEME	Cursor 10 F3AE0681B	BOSCH EDC MS 6.2
 EuroMover	ENGINE MANAGEME	Cursor 10 F3AE0681D	BOSCH EDC MS 6.2
 EuroMover	ENGINE MANAGEME	Cursor 10 F3AE0681E	BOSCH EDC MS 6.2
 EuroMover	ENGINE MANAGEME	Cursor 10 F3AE0681H	BOSCH EDC MS 6.2
 EuroMover	GEARBOX MANAGEM		Eurotronic 2
 EuroMover	SUSPENSION CONTR		WABCO ECAS Full Pneumatic
 EuroMover	SUSPENSION CONTR		WABCO ECAS Pneumatic
 EuroStar	ABS		WABCO ABS E
 EuroStar	ABS + TRACT. CONT		BOSCH ABS/ASR/SL P4 Full Air
 EuroStar	ABS + TRACT. CONT		WABCO ABS/ASR/EBS C3
 EuroStar	BRAKE POWER SUP		ZF Intarder no CAN

## Systems supported by ECReader (up to V4,90)

### TRUCKS




























Iveco

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 EuroStar	BRAKE SYS. MANAG		WABCO EBS EURO
 EuroStar	EMERGENCY START	Cursor 10 F3AE0681A	BOSCH EDC MS 6.2
 EuroStar	EMERGENCY START	Cursor 10 F3AE0681B	BOSCH EDC MS 6.2
 EuroStar	EMERGENCY START	Cursor 10 F3AE0681D	BOSCH EDC MS 6.2
 EuroStar	EMERGENCY START	Cursor 10 F3AE0681E	BOSCH EDC MS 6.2
 EuroStar	EMERGENCY START	Cursor 10 F3AE0681H	BOSCH EDC MS 6.2
 EuroStar	ENGINE MANAGEME	180 E 38	BOSCH EDC M7
 EuroStar	ENGINE MANAGEME	190 E 38	BOSCH EDC M7
 EuroStar	ENGINE MANAGEME	240 E 38	BOSCH EDC M7
 EuroStar	ENGINE MANAGEME	260 E 38	BOSCH EDC M7
 EuroStar	ENGINE MANAGEME	360 E 38	BOSCH EDC M7
 EuroStar	ENGINE MANAGEME	400 E 38	BOSCH EDC M7
 EuroStar	ENGINE MANAGEME	470 E 38	BOSCH EDC M7
 EuroStar	ENGINE MANAGEME	Cursor 10 F3AE0681A	BOSCH EDC MS 6.2
 EuroStar	ENGINE MANAGEME	Cursor 10 F3AE0681B	BOSCH EDC MS 6.2
 EuroStar	ENGINE MANAGEME	Cursor 10 F3AE0681D	BOSCH EDC MS 6.2
 EuroStar	ENGINE MANAGEME	Cursor 10 F3AE0681E	BOSCH EDC MS 6.2
 EuroStar	ENGINE MANAGEME	Cursor 10 F3AE0681H	BOSCH EDC MS 6.2
 EuroStar	GEARBOX MANAGEM		Eurotronic 2
 EuroStar	IMMOBILIZER		
 EuroStar	SUSPENSION CONTR		WABCO ECAS Pneumatic
 EuroTech	ABS + TRACT. CONT		Bosch ABS/ASR/SL P4 Full Air
 EuroTech	ABS + TRACT. CONT		Knorr ABS
 EuroTech	ABS + TRACT. CONT		WABCO ABS/ASR/EBS C3
 EuroTech	ABS + TRACT. CONT		WABCO EBS EURO
 EuroTech	BRAKE POWER SUP		ZF Intarder no CAN

## Systems supported by ECReader (up to V4,90)

### TRUCKS



























Iveco

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 EuroTech	EMERGENCY START	Cursor 10 F3AE0681A	BOSCH EDC MS 6.2
 EuroTech	EMERGENCY START	Cursor 10 F3AE0681B	BOSCH EDC MS 6.2
 EuroTech	EMERGENCY START	Cursor 10 F3AE0681D	BOSCH EDC MS 6.2
 EuroTech	EMERGENCY START	Cursor 10 F3AE0681E	BOSCH EDC MS 6.2
 EuroTech	EMERGENCY START	Cursor 10 F3AE0681H	BOSCH EDC MS 6.2
 EuroTech	EMERGENCY START	Cursor 13 F3BE0681C	BOSCH EDC MS 6.2
 EuroTech	EMERGENCY START	Cursor 13 F3BE0681D	BOSCH EDC MS 6.2
 EuroTech	EMERGENCY START	Cursor 13 F3BE0681E	BOSCH EDC MS 6.2
 EuroTech	EMERGENCY START	Cursor 13 F3BE0681F	BOSCH EDC MS 6.2
 EuroTech	EMERGENCY START	Cursor 13 F3BE0681G	BOSCH EDC MS 6.2
 EuroTech	EMERGENCY START	Cursor 8 F2BE0681A	BOSCH EDC MS 6.2
 EuroTech	EMERGENCY START	Cursor 8 F2BE0681B	BOSCH EDC MS 6.2
 EuroTech	EMERGENCY START	Cursor 8 F2BE0681C	BOSCH EDC MS 6.2
 EuroTech	EMERGENCY START	Cursor 8 F2BE0681D	BOSCH EDC MS 6.2
 EuroTech	EMERGENCY START	Cursor 8 F2BE0681E	BOSCH EDC MS 6.2
 EuroTech	EMERGENCY START	Cursor 8 F2BE0681F	BOSCH EDC MS 6.2
 EuroTech	EMERGENCY START	Cursor 8 F2BE0681G	BOSCH EDC MS 6.2
 EuroTech	ENGINE MANAGEME	180 E 38	BOSCH EDC M7
 EuroTech	ENGINE MANAGEME	190 E 38	BOSCH EDC M7
 EuroTech	ENGINE MANAGEME	240 E 38	BOSCH EDC M7
 EuroTech	ENGINE MANAGEME	Cursor 10 F3AE0681A	BOSCH EDC MS 6.2
 EuroTech	ENGINE MANAGEME	Cursor 10 F3AE0681B	BOSCH EDC MS 6.2
 EuroTech	ENGINE MANAGEME	Cursor 10 F3AE0681D	BOSCH EDC MS 6.2
 EuroTech	ENGINE MANAGEME	Cursor 10 F3AE0681E	BOSCH EDC MS 6.2
 EuroTech	ENGINE MANAGEME	Cursor 10 F3AE0681H	BOSCH EDC MS 6.2
 EuroTech	ENGINE MANAGEME	Cursor 13 F3BE0681C	BOSCH EDC MS 6.2
 EuroTech	ENGINE MANAGEME	Cursor 13 F3BE0681D	BOSCH EDC MS 6.2

## Systems supported by ECUreader (up to V4,90)

### TRUCKS



























Iveco

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 EuroTech	ENGINE MANAGEME	Cursor 13 F3BE0681E	BOSCH EDC MS 6.2
 EuroTech	ENGINE MANAGEME	Cursor 13 F3BE0681F	BOSCH EDC MS 6.2
 EuroTech	ENGINE MANAGEME	Cursor 13 F3BE0681G	BOSCH EDC MS 6.2
 EuroTech	ENGINE MANAGEME	Cursor 8 F2BE0681A	BOSCH EDC MS 6.2
 EuroTech	ENGINE MANAGEME	Cursor 8 F2BE0681B	BOSCH EDC MS 6.2
 EuroTech	ENGINE MANAGEME	Cursor 8 F2BE0681C	BOSCH EDC MS 6.2
 EuroTech	ENGINE MANAGEME	Cursor 8 F2BE0681D	BOSCH EDC MS 6.2
 EuroTech	ENGINE MANAGEME	Cursor 8 F2BE0681E	BOSCH EDC MS 6.2
 EuroTech	ENGINE MANAGEME	Cursor 8 F2BE0681F	BOSCH EDC MS 6.2
 EuroTech	ENGINE MANAGEME	Cursor 8 F2BE0681G	BOSCH EDC MS 6.2
 EuroTech	GEARBOX MANAGEM		Eurotronic 2
 EuroTech	SUSPENSION CONTR		WABCO ECAS Full Pneumatic
 EuroTech	SUSPENSION CONTR		WABCO ECAS Pneumatic
 EuroTrakker	ABS + TRACT. CONT		Bosch ABS/ASR/SL P4 Full Air
 EuroTrakker	ABS + TRACT. CONT		WABCO ABS/ASR/EBS C3
 EuroTrakker	BRAKE POWER SUP		ZF Intarder no CAN
 EuroTrakker	BRAKE SYS. MANAG	Cursor 13 F3BE0681C	WABCO EBS EURO
 EuroTrakker	BRAKE SYS. MANAG	Cursor 13 F3BE0681D	WABCO EBS EURO
 EuroTrakker	BRAKE SYS. MANAG	Cursor 13 F3BE0681E	WABCO EBS EURO
 EuroTrakker	BRAKE SYS. MANAG	Cursor 13 F3BE0681F	WABCO EBS EURO
 EuroTrakker	BRAKE SYS. MANAG	Cursor 13 F3BE0681G	WABCO EBS EURO
 EuroTrakker	BRAKE SYS. MANAG	Cursor 8 F2BE0681A	WABCO EBS EURO
 EuroTrakker	BRAKE SYS. MANAG	Cursor 8 F2BE0681B	WABCO EBS EURO
 EuroTrakker	BRAKE SYS. MANAG	Cursor 8 F2BE0681C	WABCO EBS EURO
 EuroTrakker	BRAKE SYS. MANAG	Cursor 8 F2BE0681D	WABCO EBS EURO
 EuroTrakker	BRAKE SYS. MANAG	Cursor 8 F2BE0681E	WABCO EBS EURO

## Systems supported by ECUreader (up to V4,90)

### TRUCKS



























Iveco

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 EuroTrakker	BRAKE SYS. MANAG	Cursor 8 F2BE0681F	WABCO EBS EURO
 EuroTrakker	BRAKE SYS. MANAG	Cursor 8 F2BE0681G	WABCO EBS EURO
 EuroTrakker	ENGINE MANAGEME	190 E 47	BOSCH EDC M7
 EuroTrakker	ENGINE MANAGEME	260 E 47	BOSCH EDC M7
 EuroTrakker	ENGINE MANAGEME	340 E 47	BOSCH EDC M7
 EuroTrakker	ENGINE MANAGEME	380 E 47	BOSCH EDC M7
 EuroTrakker	ENGINE MANAGEME	410 E 47	BOSCH EDC M7
 EuroTrakker	ENGINE MANAGEME	440 E 47	BOSCH EDC M7
 EuroTrakker	ENGINE MANAGEME	720 E 47	BOSCH EDC M7
 EuroTrakker	ENGINE MANAGEME	Cursor 13 F3BE0681C	BOSCH EDC MS 6.2
 EuroTrakker	ENGINE MANAGEME	Cursor 13 F3BE0681D	BOSCH EDC MS 6.2
 EuroTrakker	ENGINE MANAGEME	Cursor 13 F3BE0681E	BOSCH EDC MS 6.2
 EuroTrakker	ENGINE MANAGEME	Cursor 13 F3BE0681F	BOSCH EDC MS 6.2
 EuroTrakker	ENGINE MANAGEME	Cursor 13 F3BE0681G	BOSCH EDC MS 6.2
 EuroTrakker	ENGINE MANAGEME	Cursor 8 F2BE0681A	BOSCH EDC MS 6.2
 EuroTrakker	ENGINE MANAGEME	Cursor 8 F2BE0681B	BOSCH EDC MS 6.2
 EuroTrakker	ENGINE MANAGEME	Cursor 8 F2BE0681C	BOSCH EDC MS 6.2
 EuroTrakker	ENGINE MANAGEME	Cursor 8 F2BE0681D	BOSCH EDC MS 6.2
 EuroTrakker	ENGINE MANAGEME	Cursor 8 F2BE0681E	BOSCH EDC MS 6.2
 EuroTrakker	ENGINE MANAGEME	Cursor 8 F2BE0681F	BOSCH EDC MS 6.2
 EuroTrakker	ENGINE MANAGEME	Cursor 8 F2BE0681G	BOSCH EDC MS 6.2
 EuroTrakker	GEARBOX MANAGEM		Eurotronic 2
 EuroTrakker	SUSPENSION CONTR		WABCO ECAS Full Pneumatic
 EuroTrakker	SUSPENSION CONTR		WABCO ECAS Pneumatic
 New Daily	ABS + TRACT. CONT	2.3 HPI 116cv	BOSCH ABS 8
 New Daily	ABS + TRACT. CONT	2.3 HPI 96cv	BOSCH ABS 8

## Systems supported by ECReader (up to V4,90)

### TRUCKS




























Iveco

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 New Daily	ABS + TRACT. CONT	2.3 HPT 136cv	BOSCH ABS 8
 New Daily	ABS + TRACT. CONT	3.0 CNG	BOSCH ABS 8
 New Daily	ABS + TRACT. CONT	3.0 HPI	BOSCH ABS 8
 New Daily	ABS + TRACT. CONT	3.0 HPT	BOSCH ABS 8
 New Daily	AIRBAG	2.3 HPI 116cv (07-..)	AB/SRS
 New Daily	AIRBAG	2.3 HPI 96cv (07-..)	AB/SRS
 New Daily	AIRBAG	2.3 HPT 136cv (07-..)	AB/SRS
 New Daily	AIRBAG	3.0 CNG (07-..)	AB/SRS
 New Daily	AIRBAG	3.0 HPI (07-..)	AB/SRS
 New Daily	AIRBAG	3.0 HPT (07-..)	AB/SRS
 New Daily	CHASSIS NETWORK	2.3 HPI 116cv	
 New Daily	CHASSIS NETWORK	2.3 HPI 96cv	
 New Daily	CHASSIS NETWORK	2.3 HPT 136cv	
 New Daily	CHASSIS NETWORK	3.0 CNG	
 New Daily	CHASSIS NETWORK	3.0 HPI	
 New Daily	CHASSIS NETWORK	3.0 HPT	
 New Daily	DASHBOARD	2.3 HPI 116cv	MARELLI
 New Daily	DASHBOARD	2.3 HPI 96cv	MARELLI
 New Daily	DASHBOARD	2.3 HPT 136cv	MARELLI
 New Daily	DASHBOARD	3.0 CNG	MARELLI
 New Daily	DASHBOARD	3.0 HPI	MARELLI
 New Daily	DASHBOARD	3.0 HPT	MARELLI
 New Daily	ENGINE MANAGEME	3.0 HPI	BOSCH EDC 16 Common Rail
 New Eurocargo	ABS	100 E 17	BOSCH/KNORR ABS 2X
 New Eurocargo	ABS	100 E 18	BOSCH/KNORR ABS 2X
 New Eurocargo	ABS	100 E 21	BOSCH/KNORR ABS 2X

## Systems supported by ECUREADER (up to V4,90)

### TRUCKS




























Iveco

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 New Eurocargo	ABS	60 E 13	BOSCH/KNORR ABS 2X
 New Eurocargo	ABS	60 E 15	BOSCH/KNORR ABS 2X
 New Eurocargo	ABS	65 E 13	BOSCH/KNORR ABS 2X
 New Eurocargo	ABS	65 E 15	BOSCH/KNORR ABS 2X
 New Eurocargo	ABS	75 E 13	BOSCH/KNORR ABS 2X
 New Eurocargo	ABS	75 E 15	BOSCH/KNORR ABS 2X
 New Eurocargo	ABS	75 E 17	BOSCH/KNORR ABS 2X
 New Eurocargo	ABS	75 E 18	BOSCH/KNORR ABS 2X
 New Eurocargo	ABS	80 E 17	BOSCH/KNORR ABS 2X
 New Eurocargo	ABS	80 E 18	BOSCH/KNORR ABS 2X
 New Eurocargo	ABS	80 E 21	BOSCH/KNORR ABS 2X
 New Eurocargo	ABS	80 EL 15	BOSCH/KNORR ABS 2X
 New Eurocargo	ABS	80 EL 17	BOSCH/KNORR ABS 2X
 New Eurocargo	ABS	90 E 17	BOSCH/KNORR ABS 2X
 New Eurocargo	ABS	90 E 18	BOSCH/KNORR ABS 2X
 New Eurocargo	ABS	90 E 21	BOSCH/KNORR ABS 2X
 New Eurocargo	CAN LANES TEST	100 E 17	
 New Eurocargo	CAN LANES TEST	100 E 18	
 New Eurocargo	CAN LANES TEST	100 E 21	
 New Eurocargo	CAN LANES TEST	60 E 13	
 New Eurocargo	CAN LANES TEST	60 E 15	
 New Eurocargo	CAN LANES TEST	65 E 13	
 New Eurocargo	CAN LANES TEST	65 E 15	
 New Eurocargo	CAN LANES TEST	75 E 13	
 New Eurocargo	CAN LANES TEST	75 E 15	
 New Eurocargo	CAN LANES TEST	75 E 17	
 New Eurocargo	CAN LANES TEST	75 E 18	

## Systems supported by ECReader (up to V4,90)

### TRUCKS




























Iveco

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 New Eurocargo	CAN LANES TEST	80 E 17	
 New Eurocargo	CAN LANES TEST	80 E 18	
 New Eurocargo	CAN LANES TEST	80 E 21	
 New Eurocargo	CAN LANES TEST	80 EL 15	
 New Eurocargo	CAN LANES TEST	80 EL 17	
 New Eurocargo	CAN LANES TEST	90 E 17	
 New Eurocargo	CAN LANES TEST	90 E 18	
 New Eurocargo	CAN LANES TEST	90 E 21	
 New Eurocargo	CHASSIS NETWORK	100 E 17	VDO Body Controller
 New Eurocargo	CHASSIS NETWORK	100 E 18	VDO Body Controller
 New Eurocargo	CHASSIS NETWORK	100 E 21	VDO Body Controller
 New Eurocargo	CHASSIS NETWORK	60 E 13	VDO Body Controller
 New Eurocargo	CHASSIS NETWORK	60 E 15	VDO Body Controller
 New Eurocargo	CHASSIS NETWORK	65 E 13	VDO Body Controller
 New Eurocargo	CHASSIS NETWORK	65 E 15	VDO Body Controller
 New Eurocargo	CHASSIS NETWORK	75 E 13	VDO Body Controller
 New Eurocargo	CHASSIS NETWORK	75 E 15	VDO Body Controller
 New Eurocargo	CHASSIS NETWORK	75 E 17	VDO Body Controller
 New Eurocargo	CHASSIS NETWORK	75 E 18	VDO Body Controller
 New Eurocargo	CHASSIS NETWORK	80 E 17	VDO Body Controller
 New Eurocargo	CHASSIS NETWORK	80 E 18	VDO Body Controller
 New Eurocargo	CHASSIS NETWORK	80 E 21	VDO Body Controller
 New Eurocargo	CHASSIS NETWORK	80 EL 15	VDO Body Controller
 New Eurocargo	CHASSIS NETWORK	80 EL 17	VDO Body Controller
 New Eurocargo	CHASSIS NETWORK	90 E 17	VDO Body Controller
 New Eurocargo	CHASSIS NETWORK	90 E 18	VDO Body Controller
 New Eurocargo	CHASSIS NETWORK	90 E 21	VDO Body Controller

## Systems supported by ECReader (up to V4,90)

### TRUCKS




























Iveco

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 New Eurocargo	DASHBOARD	100 E 17	VDO Instrument Cluster
 New Eurocargo	DASHBOARD	100 E 18	VDO Instrument Cluster
 New Eurocargo	DASHBOARD	100 E 21	VDO Instrument Cluster
 New Eurocargo	DASHBOARD	60 E 13	VDO Instrument Cluster
 New Eurocargo	DASHBOARD	60 E 15	VDO Instrument Cluster
 New Eurocargo	DASHBOARD	65 E 13	VDO Instrument Cluster
 New Eurocargo	DASHBOARD	65 E 15	VDO Instrument Cluster
 New Eurocargo	DASHBOARD	75 E 13	VDO Instrument Cluster
 New Eurocargo	DASHBOARD	75 E 15	VDO Instrument Cluster
 New Eurocargo	DASHBOARD	75 E 17	VDO Instrument Cluster
 New Eurocargo	DASHBOARD	75 E 18	VDO Instrument Cluster
 New Eurocargo	DASHBOARD	80 E 17	VDO Instrument Cluster
 New Eurocargo	DASHBOARD	80 E 18	VDO Instrument Cluster
 New Eurocargo	DASHBOARD	80 E 21	VDO Instrument Cluster
 New Eurocargo	DASHBOARD	80 EL 15	VDO Instrument Cluster
 New Eurocargo	DASHBOARD	80 EL 17	VDO Instrument Cluster
 New Eurocargo	DASHBOARD	90 E 17	VDO Instrument Cluster
 New Eurocargo	DASHBOARD	90 E 18	VDO Instrument Cluster
 New Eurocargo	DASHBOARD	90 E 21	VDO Instrument Cluster
 New Eurocargo	DIESEL ADDITION		DeNoxtronic 2
 New Eurocargo	EMERGENCY START	100 E 17	
 New Eurocargo	EMERGENCY START	100 E 18	
 New Eurocargo	EMERGENCY START	60 E 13	
 New Eurocargo	EMERGENCY START	60 E 15	
 New Eurocargo	EMERGENCY START	65 E 13	
 New Eurocargo	EMERGENCY START	65 E 15	
 New Eurocargo	EMERGENCY START	75 E 13	

## Systems supported by ECUreader (up to V4,90)

### TRUCKS



























Iveco

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 New Eurocargo	EMERGENCY START	75 E 15	
 New Eurocargo	EMERGENCY START	75 E 17	
 New Eurocargo	EMERGENCY START	75 E 18	
 New Eurocargo	EMERGENCY START	80 E 17	
 New Eurocargo	EMERGENCY START	80 E 18	
 New Eurocargo	EMERGENCY START	80 E 21	
 New Eurocargo	EMERGENCY START	80 EL 15	
 New Eurocargo	EMERGENCY START	80 EL 17	
 New Eurocargo	EMERGENCY START	90 E 17	
 New Eurocargo	EMERGENCY START	90 E 18	
 New Eurocargo	ENGINE MANAGEME	Tector 110Kw F4AE481C	BOSCH EDC 7 Tector
 New Eurocargo	SUSPENSION CONTR	100 E 17	WABCO ECAS CAN
 New Eurocargo	SUSPENSION CONTR	100 E 18	WABCO ECAS CAN
 New Eurocargo	SUSPENSION CONTR	100 E 21	WABCO ECAS CAN
 New Eurocargo	SUSPENSION CONTR	60 E 13	WABCO ECAS CAN
 New Eurocargo	SUSPENSION CONTR	60 E 15	WABCO ECAS CAN
 New Eurocargo	SUSPENSION CONTR	65 E 13	WABCO ECAS CAN
 New Eurocargo	SUSPENSION CONTR	65 E 15	WABCO ECAS CAN
 New Eurocargo	SUSPENSION CONTR	75 E 13	WABCO ECAS CAN
 New Eurocargo	SUSPENSION CONTR	75 E 15	WABCO ECAS CAN
 New Eurocargo	SUSPENSION CONTR	75 E 17	WABCO ECAS CAN
 New Eurocargo	SUSPENSION CONTR	75 E 18	WABCO ECAS CAN
 New Eurocargo	SUSPENSION CONTR	80 E 17	WABCO ECAS CAN
 New Eurocargo	SUSPENSION CONTR	80 E 18	WABCO ECAS CAN
 New Eurocargo	SUSPENSION CONTR	80 E 21	WABCO ECAS CAN
 New Eurocargo	SUSPENSION CONTR	80 EL 15	WABCO ECAS CAN
 New Eurocargo	SUSPENSION CONTR	80 EL 17	WABCO ECAS CAN

## Systems supported by ECUreader (up to V4,90)

### TRUCKS



























Iveco

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 New Eurocargo	SUSPENSION CONTR	90 E 17	WABCO ECAS CAN
 New Eurocargo	SUSPENSION CONTR	90 E 18	WABCO ECAS CAN
 New Eurocargo	SUSPENSION CONTR	90 E 21	WABCO ECAS CAN
 Stralis	ABS		WABCO ABS E
 Stralis	BRAKE SYS. MANAG		WABCO EBS EURO
 Stralis	BRAKE SYS. MANAG	(04-..)	WABCO EBS 2
 Stralis	CAN LANES TEST		
 Stralis	CHASSIS NETWORK	(..-05)	Body Computer 1
 Stralis	CHASSIS NETWORK	(..-05)	Body Computer 2
 Stralis	CHASSIS NETWORK	(..-05)	Cabin Module
 Stralis	CHASSIS NETWORK	(..-05)	Driver Door Module
 Stralis	CHASSIS NETWORK	(..-05)	Front Frame Computer
 Stralis	CHASSIS NETWORK	(..-05)	Passenger Door Module
 Stralis	CHASSIS NETWORK	(..-05)	Rear Frame Computer
 Stralis	CHASSIS NETWORK	(06-..)	Body Computer 2
 Stralis	DASHBOARD		Instrument Cluster 1
 Stralis	DASHBOARD		Instrument Cluster 2
 Stralis	DIESEL ADDITION	(06-..)	DeNoxtronic 2
 Stralis	EMERGENCY START	Cursor 10 F3AE0681B	BOSCH EDC MS 6.2
 Stralis	EMERGENCY START	Cursor 10 F3AE0681D	BOSCH EDC MS 6.2
 Stralis	EMERGENCY START	Cursor 13 F3BE0681F	BOSCH EDC MS 6.2
 Stralis	EMERGENCY START	Cursor 13 F3BE0681G	BOSCH EDC MS 6.2
 Stralis	EMERGENCY START	Cursor 8 F2BE0681A	BOSCH EDC MS 6.2
 Stralis	EMERGENCY START	Cursor 8 F2BE0681B	BOSCH EDC MS 6.2
 Stralis	EMERGENCY START	Cursor 8 F2BE0681E	BOSCH EDC MS 6.2
 Stralis	EMERGENCY START	Cursor 8 F2BE0681F	BOSCH EDC MS 6.2

## Systems supported by ECUreader (up to V4,90)

### TRUCKS

























Iveco

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Stralis	ENGINE MANAGEME	Cursor 10 F3AE0681B	BOSCH EDC MS 6.2
 Stralis	ENGINE MANAGEME	Cursor 10 F3AE0681D	BOSCH EDC MS 6.2
 Stralis	ENGINE MANAGEME	Cursor 10 F3AE0681DM	BOSCH EDC 7
 Stralis	ENGINE MANAGEME	Cursor 10 F3AE3681A	BOSCH EDC 7
 Stralis	ENGINE MANAGEME	Cursor 10 F3AE3681D	BOSCH EDC 7
 Stralis	ENGINE MANAGEME	Cursor 13 F3BE0681F	BOSCH EDC MS 6.2
 Stralis	ENGINE MANAGEME	Cursor 13 F3BE0681G	BOSCH EDC MS 6.2
 Stralis	ENGINE MANAGEME	Cursor 13 F3BE3681A	BOSCH EDC 7
 Stralis	ENGINE MANAGEME	Cursor 13 F3BE3681B	BOSCH EDC 7
 Stralis	ENGINE MANAGEME	Cursor 8 F2BE03681A	BOSCH EDC 7
 Stralis	ENGINE MANAGEME	Cursor 8 F2BE03681C	BOSCH EDC 7
 Stralis	ENGINE MANAGEME	Cursor 8 F2BE0681A	BOSCH EDC MS 6.2
 Stralis	ENGINE MANAGEME	Cursor 8 F2BE0681B	BOSCH EDC MS 6.2
 Stralis	ENGINE MANAGEME	Cursor 8 F2BE0681E	BOSCH EDC MS 6.2
 Stralis	ENGINE MANAGEME	Cursor 8 F2BE0681F	BOSCH EDC MS 6.2
 Stralis	ENGINE MANAGEME	Cursor 8 F2BE3681A	BOSCH EDC 7
 Stralis	ENGINE MANAGEME	Cursor 8 F2BE3681B	BOSCH EDC 7
 Stralis	ENGINE MANAGEME	Cursor 8 F2BE3681C	BOSCH EDC 7
 Stralis	GEARBOX MANAGEM		Eurotronic 2
 Stralis	IMMOBILIZER	(..-05)	
 Stralis	SUSPENSION CONTR		WABCO ECAS + CAN
 Trakker	CAN LANES TEST		
 Trakker	CHASSIS NETWORK		Body Computer
 Trakker	CHASSIS NETWORK		Driver Door Module
 Trakker	CHASSIS NETWORK		Front Frame Computer
 Trakker	CHASSIS NETWORK		Passenger Door Module

## Systems supported by ECUreader (up to V4,90)

### TRUCKS








Iveco

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Trakker	CHASSIS NETWORK		Rear Frame Computer
 Trakker	DASHBOARD		Instrument Cluster
 Trakker	DIESEL ADDITION		DeNoxtronic 2
 Trakker	EMERGENCY START	Cursor 13 F3BE0681F	BOSCH EDC MS 6.2
 Trakker	EMERGENCY START	Cursor 13 F3BE0681G	BOSCH EDC MS 6.2
 Trakker	EMERGENCY START	Cursor 8 F2BE0681A	BOSCH EDC MS 6.2
 Trakker	EMERGENCY START	Cursor 8 F2BE0681B	BOSCH EDC MS 6.2
 Trakker	EMERGENCY START	Cursor 8 F2BE0681E	BOSCH EDC MS 6.2
 Trakker	EMERGENCY START	Cursor 8 F2BE0681F	BOSCH EDC MS 6.2
 Trakker	ENGINE MANAGEME	Cursor 13 F3BE0681B	BOSCH EDC 7
 Trakker	ENGINE MANAGEME	Cursor 13 F3BE0681F	BOSCH EDC MS 6.2
 Trakker	ENGINE MANAGEME	Cursor 13 F3BE0681G	BOSCH EDC MS 6.2
 Trakker	ENGINE MANAGEME	Cursor 13 F3BE3681B	BOSCH EDC 7
 Trakker	ENGINE MANAGEME	Cursor 13 F3BE3681C	BOSCH EDC 7
 Trakker	ENGINE MANAGEME	Cursor 13 F3BE3681D	BOSCH EDC 7
 Trakker	ENGINE MANAGEME	Cursor 13 F3BE3681P	BOSCH EDC 7
 Trakker	ENGINE MANAGEME	Cursor 8 F2BE0681A	BOSCH EDC MS 6.2
 Trakker	ENGINE MANAGEME	Cursor 8 F2BE0681B	BOSCH EDC MS 6.2
 Trakker	ENGINE MANAGEME	Cursor 8 F2BE0681E	BOSCH EDC MS 6.2
 Trakker	ENGINE MANAGEME	Cursor 8 F2BE0681F	BOSCH EDC MS 6.2
 Trakker	ENGINE MANAGEME	Cursor 8 F2BE3681A	BOSCH EDC 7
 Trakker	GEARBOX MANAGEM		Eurotronic 2
 Trakker	IMMOBILIZER		
 Trakker	SUSPENSION CONTR		WABCO ECAS + CAN

## Systems supported by ECUreader (up to V4,90)

### TRUCKS






Iveco Bus

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 3 Series	ENGINE MANAGEME	315	BOSCH EDC M7
 3 Series	ENGINE MANAGEME	316	BOSCH EDC M7
 3 Series	ENGINE MANAGEME	370	BOSCH EDC M7
 3 Series	ENGINE MANAGEME	380	BOSCH EDC M7
 3 Series	ENGINE MANAGEME	391	BOSCH EDC M7
 3 Series	ENGINE MANAGEME	393	BOSCH EDC M7
 Euroreader	ENGINE MANAGEME	391	BOSCH EDC M7

## Systems supported by ECUREADER (up to V4,90)

### TRUCKS

**Kassbohrer**

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Trailers	BRAKE SYS. MANAG	Trailers	Wabco Trailer EBS
 Trailers	BRAKE SYS. MANAG	Trailers	Wabco Trailer VCS II
 Trailers	BRAKE SYS. MANAG	Trailers	Wabco Trailers EBS kw2000
 Trailers	BRAKE SYS. MANAG	Trailers Haldex	Haldex EBS EB+
 Trailers	BRAKE SYS. MANAG	Trailers Knorr	Knorr Trailer EBS

## Systems supported by ECUREADER (up to V4,90)

### TRUCKS





**Knorr**

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Trailers	BRAKE SYS. MANAG	Trailers	Knorr Trailer EBS

## Systems supported by ECUreader (up to V4,90)

### TRUCKS





Kogel

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Trailers	BRAKE SYS. MANAG	Trailers	Wabco Trailer EBS
 Trailers	BRAKE SYS. MANAG	Trailers	Wabco Trailers EBS kw2000
 Trailers	BRAKE SYS. MANAG	Trailers Haldex	Haldex EBS EB+
 Trailers	BRAKE SYS. MANAG	Trailers Knorr	Knorr Trailer EBS

## Systems supported by ECUREADER (up to V4,90)

### TRUCKS


**Kraker**

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Trailers	BRAKE SYS. MANAG	Trailers	Wabco Trailer EBS
 Trailers	BRAKE SYS. MANAG	Trailers	Wabco Trailers EBS kw2000
 Trailers	BRAKE SYS. MANAG	Trailers Haldex	Haldex EBS EB+
 Trailers	BRAKE SYS. MANAG	Trailers Knorr	Knorr Trailer EBS

## Systems supported by ECUreader (up to V4,90)

### TRUCKS



Krone

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Trailers	ABS	Trailers Wabco	Wabco VARIO C1-C2-C plus
 Trailers	BRAKE SYS. MANAG	Trailers	Wabco Trailer EBS
 Trailers	BRAKE SYS. MANAG	Trailers	Wabco Trailers EBS kw2000
 Trailers	BRAKE SYS. MANAG	Trailers Haldex	Haldex EBS EB+
 Trailers	BRAKE SYS. MANAG	Trailers Knorr	Knorr Trailer EBS

## Systems supported by ECUreader (up to V4,90)

### TRUCKS





Laneko

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Trailers	BRAKE SYS. MANAG	Trailers	Wabco Trailer EBS
 Trailers	BRAKE SYS. MANAG	Trailers	Wabco Trailer VCS II

## Systems supported by ECUREADER (up to V4,90)

### TRUCKS



Lecinena

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Trailers	BRAKE SYS. MANAG	Trailers	Wabco Trailers EBS
 Trailers	BRAKE SYS. MANAG	Trailers	Wabco Trailers EBS kw2000
 Trailers	BRAKE SYS. MANAG	Trailers Haldex	Haldex EBS EB+
 Trailers	BRAKE SYS. MANAG	Trailers Knorr	Knorr Trailer EBS

## Systems supported by ECUreader (up to V4,90)

### TRUCKS



























Lecitrailer

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Trailers	BRAKE SYS. MANAG	Trailers	Wabco Trailer EBS
 Trailers	BRAKE SYS. MANAG	Trailers	Wabco Trailer VCS II

## Systems supported by ECUreader (up to V4,90)

### TRUCKS


























**MAN**

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 E2000	ABS		BOSCH ABS/ASR 2E
 E2000	ABS		BOSCH ABS/ASR 2M Stufe 1
 E2000	ABS		BOSCH ABS/ASR 3E
 E2000	ABS		BOSCH/KNORR ABS Ci 12
 E2000	ABS		KNORR ABS
 E2000	AUX. HEATING		ZH Webasto AT2000
 E2000	BRAKE POWER SUP		ZF Intarder est 32
 E2000	CLIMA		Konvekta
 E2000	CLIMA		WABCO ATC
 E2000	ENGINE MANAGEME		EDC MS5
 E2000	SUSPENSION CONTR		WABCO ECAS
 F2000	ABS		BOSCH ABS/ASR 2E
 F2000	ABS		BOSCH ABS/ASR 2M Stufe 1
 F2000	ABS		BOSCH ABS/ASR 3E
 F2000	ABS		KNORR ABS
 F2000	ABS	19.414 (99-00)	BOSCH/KNORR ABS Ci 12
 F2000	ABS	19.463 (99-00)	BOSCH/KNORR ABS Ci 12
 F2000	AUX. HEATING	19.414 (99-00)	ZH Webasto AT2000
 F2000	AUX. HEATING	19.463 (99-00)	ZH Webasto AT2000
 F2000	BRAKE POWER SUP	19.414 (99-00)	ZF Intarder est 32
 F2000	BRAKE POWER SUP	19.463 (99-00)	ZF Intarder est 32
 F2000	CLIMA		Konvekta
 F2000	CLIMA		WABCO ATC
 F2000	CLIMA	19.414 (99-00)	WABCO ACT
 F2000	CLIMA	19.463 (99-00)	WABCO ACT
 F2000	ENGINE MANAGEME	19.414 (99-00)	EDC MS5

## Systems supported by ECUreader (up to V4,90)

### TRUCKS



























**MAN**

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 F2000	ENGINE MANAGEME	19.463 (99-00)	EDC MS5
 F2000	SUSPENSION CONTR	19.414 (99-00)	WABCO ECAS 4x2 6x4
 F2000	SUSPENSION CONTR	19.463 (99-00)	WABCO ECAS 4x2 6x4
 F90	ABS		BOSCH/KNORR ABS Ci 12
 F90	ABS	19.322 F-sm	BOSCH ABS/ASR 2E
 F90	ABS	19.322 F-sm	BOSCH ABS/ASR 2M Stufe 1
 F90	ABS	19.322 F-sm	BOSCH ABS/ASR 3E
 F90	ABS	19.322 F-sm	BOSCH ABS/ASR 3M
 F90	ABS	19.322 F-sm	KNORR ABS
 F90	ABS	19.372 F-cl	BOSCH ABS/ASR 2E
 F90	ABS	19.372 F-cl	BOSCH ABS/ASR 2M Stufe 1
 F90	ABS	19.372 F-cl	BOSCH ABS/ASR 3E
 F90	ABS	19.372 F-cl	BOSCH ABS/ASR 3M
 F90	ABS	19.372 F-cl	KNORR ABS
 F90	ABS	19.422 FL-cl	BOSCH ABS/ASR 2E
 F90	ABS	19.422 FL-cl	BOSCH ABS/ASR 2M Stufe 1
 F90	ABS	19.422 FL-cl	BOSCH ABS/ASR 3E
 F90	ABS	19.422 FL-cl	BOSCH ABS/ASR 3M
 F90	ABS	19.422 FL-cl	KNORR ABS
 F90	ABS	19.422 FLT-cl-SPP	BOSCH ABS/ASR 2E
 F90	ABS	19.422 FLT-cl-SPP	BOSCH ABS/ASR 2M Stufe 1
 F90	ABS	19.422 FLT-cl-SPP	BOSCH ABS/ASR 3E
 F90	ABS	19.422 FLT-cl-SPP	BOSCH ABS/ASR 3M
 F90	ABS	19.422 FLT-cl-SPP	KNORR ABS
 F90	CLIMA		Konvekta
 F90	CLIMA		WABCO ATC

## Systems supported by ECUreader (up to V4,90)

### TRUCKS



























**MAN**

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 F90	DIESEL MANAGEMEN	19.322 F-sm	BOSCH EDC M7
 F90	DIESEL MANAGEMEN	19.372 F-cl	BOSCH ECD M7
 F90	DIESEL MANAGEMEN	19.422 FL-cl	BOSCH EDC M7
 F90	DIESEL MANAGEMEN	19.422 FLT-cl-SPP	BOSCH EDC M7
 F90	SUSPENSION CONTR	19.322 F-sm	ECAS
 F90	SUSPENSION CONTR	19.372 F-cl	ECAS
 F90	SUSPENSION CONTR	19.422 FL-cl	ECAS
 F90	SUSPENSION CONTR	19.422 FLT-cl-SPP	ECAS
 L2000	ABS		BOSCH ABS Ci 12
 L2000	ABS		BOSCH ABS/ASR 2E
 L2000	ABS		BOSCH ABS/ASR 2M
 L2000	ABS		BOSCH ABS/ASR 2M Stufe 1
 L2000	ABS		BOSCH ABS/ASR 3E
 L2000	ABS		BOSCH/KNORR ABS Ci 12
 L2000	ABS		KNORR ABS
 L2000	ABS		KNORR ABS KB3AL
 L2000	AUX. HEATING		ZH Webasto AT2000
 L2000	BRAKE POWER SUP		ZF Intarder est 32
 L2000	CLIMA		Konvekta
 L2000	CLIMA		WABCO ATC
 L2000	ENGINE MANAGEME		EDC MS5
 L2000	SUSPENSION CONTR		WABCO ECAS 4x2 6x4
 LE2000	ABS		BOSCH/KNORR ABS Ci 12
 LE2000	AUX. HEATING		ZH Webasto AT2000
 LE2000	SUSPENSION CONTR		WABCO ECAS
 M2000	ABS		BOSCH ABS/ASR 2E

## Systems supported by ECReader (up to V4,90)

### TRUCKS



























**MAN**

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 M2000	ABS		BOSCH ABS/ASR 2M Stufe 1
 M2000	ABS		BOSCH ABS/ASR 3E
 M2000	ABS		BOSCH/KNORR ABS Ci 12
 M2000	ABS		KNORR ABS
 M2000	AUX. HEATING		ZH Webasto AT2000
 M2000	BRAKE POWER SUP		ZF Intarder est 32
 M2000	CLIMA		Konvekta
 M2000	CLIMA		WABCO ATC
 M2000	ENGINE MANAGEME		EDC MS5
 M2000	SUSPENSION CONTR		WABCO ECAS 4x2 6x4
 M90	ABS		BOSCH/KNORR ABS Ci 12
 M90	ABS	12.192 F-sm	BOSCH ABS/ASR 2E
 M90	ABS	12.192 F-sm	BOSCH ABS/ASR 2M Stufe 1
 M90	ABS	12.192 F-sm	BOSCH ABS/ASR 3E
 M90	ABS	12.192 F-sm	BOSCH ABS/ASR 3M
 M90	ABS	12.192 F-sm	KNORR ABS
 M90	ABS	12.232 FL-spp	BOSCH ABS/ASR 2E
 M90	ABS	12.232 FL-spp	BOSCH ABS/ASR 2M Stufe 1
 M90	ABS	12.232 FL-spp	BOSCH ABS/ASR 3E
 M90	ABS	12.232 FL-spp	BOSCH ABS/ASR 3M
 M90	ABS	12.232 FL-spp	KNORR ABS
 M90	ABS	12.272 FL-spp	BOSCH ABS/ASR 2E
 M90	ABS	12.272 FL-spp	BOSCH ABS/ASR 2M Stufe 1
 M90	ABS	12.272 FL-spp	BOSCH ABS/ASR 3E
 M90	ABS	12.272 FL-spp	BOSCH ABS/ASR 3M
 M90	ABS	12.272 FL-spp	KNORR ABS

## Systems supported by ECUreader (up to V4,90)

### TRUCKS



























**MAN**

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 M90	CLIMA		Konvekta
 M90	CLIMA		WABCO ATC
 M90	DIESEL MANAGEMEN		BOSCH EDC M7
 M90	DIESEL MANAGEMEN	12.192 F-sm	BOSCH EDC M7
 M90	DIESEL MANAGEMEN	12.232 FL-spp	BOSCH EDC M7
 M90	DIESEL MANAGEMEN	12.272 FL-spp	BOSCH EDC M7
 M90	SUSPENSION CONTR	12.192 F-sm	ECAS
 M90	SUSPENSION CONTR	12.232 FL-spp	ECAS
 M90	SUSPENSION CONTR	12.272 FL-spp	ECAS
 TG-A 18.XXX	AIR BRAKE MANAG	(..-05)	HALDEX ECAM
 TG-A 18.XXX	AIR BRAKE MANAG	(06-..)	HALDEX ECAM
 TG-A 18.XXX	AUTOM. TRANSMISSI	(..-05)	ZF ASTRONIC 2
 TG-A 18.XXX	AUTOM. TRANSMISSI	(06-..)	ZF ASTRONIC 2
 TG-A 18.XXX	BRAKE POWER SUP	(..-05)	ZF Intarder
 TG-A 18.XXX	BRAKE SYS. MANAG	(..-05)	KNORR EBS 2.3 - 2 axle
 TG-A 18.XXX	BRAKE SYS. MANAG	(..-05)	KNORR EBS 2.3 - 3 axle
 TG-A 18.XXX	BRAKE SYS. MANAG	(..-05)	KNORR EBS 2.3 - 4 axle
 TG-A 18.XXX	BRAKE SYS. MANAG	(..-05)	KNORR EBS 2.3 - axle 3 trained
 TG-A 18.XXX	BRAKE SYS. MANAG	(06-..)	KNORR EBS 2.3 - 2 axle
 TG-A 18.XXX	BRAKE SYS. MANAG	(06-..)	KNORR EBS 2.3 - 3 axle
 TG-A 18.XXX	BRAKE SYS. MANAG	(06-..)	KNORR EBS 2.3 - 4 axle
 TG-A 18.XXX	BRAKE SYS. MANAG	(06-..)	KNORR EBS 2.3 - axle 3 trained
 TG-A 18.XXX	BRAKE SYS. MANAG	(06-..)	KNORR EBS 5
 TG-A 18.XXX	CHASSIS NETWORK	(..-05)	Berifors Door Module
 TG-A 18.XXX	CHASSIS NETWORK	(..-05)	VDO Client Module
 TG-A 18.XXX	CHASSIS NETWORK	(..-05)	VDO Clutch calibration FFR

## Systems supported by ECUreader (up to V4,90)

### TRUCKS



























**MAN**

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 TG-A 18.XXX	CHASSIS NETWORK	(..-05)	WABCO Body Computer ZBR 2
 TG-A 18.XXX	CHASSIS NETWORK	(06-..)	BERIFORS Door Module
 TG-A 18.XXX	CHASSIS NETWORK	(06-..)	VDO Accelerator pedal calibration FFR STE
 TG-A 18.XXX	CHASSIS NETWORK	(06-..)	VDO Clutch calibration FFR
 TG-A 18.XXX	CHASSIS NETWORK	(06-..)	WABCO Body Computer ZBR 2 06>
 TG-A 18.XXX	CHASSIS NETWORK	(06-..)	WABCO Body Computer ZBR 2 07>
 TG-A 18.XXX	CLIMA	(..-05)	BEHR/GKR Klima
 TG-A 18.XXX	CLIMA	(06-..)	BEHR/GKR Klima
 TG-A 18.XXX	CRUISE MANAGEME	(..-05)	VDO Navigator
 TG-A 18.XXX	CRUISE MANAGEME	(06-..)	VDO FFR Step 9
 TG-A 18.XXX	CRUISE MANAGEME	(06-..)	VDO Navigator
 TG-A 18.XXX	DASHBOARD	(..-05)	VDO/Kienzle
 TG-A 18.XXX	DASHBOARD	(06-..)	Stoneridge Electronics
 TG-A 18.XXX	DASHBOARD	(06-..)	VDO/Kienzle
 TG-A 18.XXX	ENGINE MANAGEME	(..-05)	BOSCH EDC 7
 TG-A 18.XXX	ENGINE MANAGEME	(..-05)	BOSCH EDC MS 6.1
 TG-A 18.XXX	ENGINE MANAGEME	(06-..)	BOSCH EDC 7
 TG-A 18.XXX	ENGINE MANAGEME	(06-..)	Bosch EDC 7 C32
 TG-A 18.XXX	MAINTENANCE SYST	(..-05)	
 TG-A 18.XXX	MAINTENANCE SYST	(06-..)	
 TG-A 18.XXX	SUSPENSION CONTR	(..-05)	WABCO ECAS
 TG-A 18.XXX	SUSPENSION CONTR	(06-..)	WABCO ECAS
 TG-A 18.XXX	SUSPENSION CONTR	(06-..)	WABCO ECAS 2
 TG-A 24.XXX	AIR BRAKE MANAGE	(06-..)	HALDEX ECAM
 TG-A 24.XXX	AUTOM. TRANSMISSI	(06-..)	ZF ASTRONIC 2
 TG-A 24.XXX	BRAKE SYS. MANAG	(06-..)	KNORR EBS 2.3 - 3 axle

## Systems supported by ECUreader (up to V4,90)

### TRUCKS




























**MAN**

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 TG-A 24.XXX	BRAKE SYS. MANAG	(06-..)	KNORR EBS 2.3 - 4 axle
 TG-A 24.XXX	BRAKE SYS. MANAG	(06-..)	KNORR EBS 2.3 - axle 3 trained
 TG-A 24.XXX	BRAKE SYS. MANAG	(06-..)	KNORR EBS 5
 TG-A 24.XXX	CHASSIS NETWORK	(06-..)	VDO Accelerator pedal calibration FFR STE
 TG-A 24.XXX	CHASSIS NETWORK	(06-..)	VDO Clutch calibration FFR
 TG-A 24.XXX	CHASSIS NETWORK	(06-..)	WABCO Body Computer ZBR 2 06>
 TG-A 24.XXX	CHASSIS NETWORK	(06-..)	WABCO Body Computer ZBR 2 07>
 TG-A 24.XXX	CLIMA	(06-..)	BEHR/GKR Klima
 TG-A 24.XXX	CRUISE MANAGEME	(06-..)	VDO FFR Step 9
 TG-A 24.XXX	CRUISE MANAGEME	(06-..)	VDO Navigator
 TG-A 24.XXX	DASHBOARD	(06-..)	Stoneridge Electronics
 TG-A 24.XXX	DASHBOARD	(06-..)	VDO/Kienzle
 TG-A 24.XXX	ENGINE MANAGEME	(06-..)	BOSCH EDC 7
 TG-A 24.XXX	ENGINE MANAGEME	(06-..)	Bosch EDC 7 C32
 TG-A 24.XXX	MAINTENANCE SYST	(..-05)	
 TG-A 24.XXX	MAINTENANCE SYST	(06-..)	
 TG-A 24.XXX	SUSPENSION CONTR	(06-..)	WABCO ECAS
 TG-A 24.XXX	SUSPENSION CONTR	(06-..)	WABCO ECAS 2
 TG-A 26.XXX	AIR BRAKE MANAG	(..-05)	HALDEX ECAM
 TG-A 26.XXX	AIR BRAKE MANAG	(06-..)	HALDEX ECAM
 TG-A 26.XXX	AUTOM. TRANSMISSI	(..-05)	ZF ASTRONIC 2
 TG-A 26.XXX	AUTOM. TRANSMISSI	(06-..)	ZF ASTRONIC 2
 TG-A 26.XXX	BRAKE POWER SUP	(..-05)	ZF Intarder
 TG-A 26.XXX	BRAKE SYS. MANAG	(..-05)	KNORR EBS 2.3 - 2 axle
 TG-A 26.XXX	BRAKE SYS. MANAG	(..-05)	KNORR EBS 2.3 - 3 axle
 TG-A 26.XXX	BRAKE SYS. MANAG	(..-05)	KNORR EBS 2.3 - 4 axle

## Systems supported by ECReader (up to V4,90)

### TRUCKS



























**MAN**

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 TG-A 26.XXX	BRAKE SYS. MANAG	(..-05)	KNORR EBS 2.3 - axle 3 trained
 TG-A 26.XXX	BRAKE SYS. MANAG	(06-..)	KNORR EBS 2.3 - 2 axle
 TG-A 26.XXX	BRAKE SYS. MANAG	(06-..)	KNORR EBS 2.3 - 3 axle
 TG-A 26.XXX	BRAKE SYS. MANAG	(06-..)	KNORR EBS 2.3 - 4 axle
 TG-A 26.XXX	BRAKE SYS. MANAG	(06-..)	KNORR EBS 2.3 - axle 3 trained
 TG-A 26.XXX	BRAKE SYS. MANAG	(06-..)	KNORR EBS 5
 TG-A 26.XXX	CHASSIS NETWORK	(..-05)	Berifors Door Module
 TG-A 26.XXX	CHASSIS NETWORK	(..-05)	VDO Client Module
 TG-A 26.XXX	CHASSIS NETWORK	(..-05)	VDO Clutch calibration FFR
 TG-A 26.XXX	CHASSIS NETWORK	(..-05)	WABCO Body Computer ZBR 2
 TG-A 26.XXX	CHASSIS NETWORK	(06-..)	BERIFORS Door Module
 TG-A 26.XXX	CHASSIS NETWORK	(06-..)	VDO Accelerator pedal calibration FFR STE
 TG-A 26.XXX	CHASSIS NETWORK	(06-..)	VDO Clutch calibration FFR
 TG-A 26.XXX	CHASSIS NETWORK	(06-..)	WABCO Body Computer ZBR 2
 TG-A 26.XXX	CHASSIS NETWORK	(06-..)	WABCO Body Computer ZBR 2 07>
 TG-A 26.XXX	CLIMA	(..-05)	BEHR/GKR Klima
 TG-A 26.XXX	CLIMA	(06-..)	BEHR/GKR Klima
 TG-A 26.XXX	CRUISE MANAGEME	(..-05)	VDO Navigator
 TG-A 26.XXX	CRUISE MANAGEME	(06-..)	VDO FFR Step 9
 TG-A 26.XXX	CRUISE MANAGEME	(06-..)	VDO Navigator
 TG-A 26.XXX	DASHBOARD	(..-05)	VDO/Kienzle
 TG-A 26.XXX	DASHBOARD	(06-..)	Stoneridge Electronics
 TG-A 26.XXX	DASHBOARD	(06-..)	VDO/Kienzle
 TG-A 26.XXX	ENGINE MANAGEME	(..-05)	BOSCH EDC 7
 TG-A 26.XXX	ENGINE MANAGEME	(..-05)	BOSCH EDC MS 6.1
 TG-A 26.XXX	ENGINE MANAGEME	(06-..)	BOSCH EDC 7
 TG-A 26.XXX	ENGINE MANAGEME	(06-..)	Bosch EDC 7 C32

## Systems supported by ECUreader (up to V4,90)

### TRUCKS



























**MAN**

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 TG-A 26.XXX	MAINTENANCE SYST	(..-05)	
 TG-A 26.XXX	MAINTENANCE SYST	(06-..)	
 TG-A 26.XXX	SUSPENSION CONTR	(..-05)	WABCO ECAS
 TG-A 26.XXX	SUSPENSION CONTR	(06-..)	WABCO ECAS
 TG-A 26.XXX	SUSPENSION CONTR	(06-..)	WABCO ECAS 2
 TG-A 28.XXX	AIR BRAKE MANAGE	(06-..)	HALDEX ECAM
 TG-A 28.XXX	AUTOM. TRANSMISSI	(06-..)	ZF ASTRONIC 2
 TG-A 28.XXX	BRAKE SYS. MANAG	(06-..)	KNORR EBS 2.3 - 2 axle
 TG-A 28.XXX	BRAKE SYS. MANAG	(06-..)	KNORR EBS 2.3 - 3 axle
 TG-A 28.XXX	BRAKE SYS. MANAG	(06-..)	KNORR EBS 2.3 - 4 axle
 TG-A 28.XXX	BRAKE SYS. MANAG	(06-..)	KNORR EBS 2.3 - axle 3 trained
 TG-A 28.XXX	BRAKE SYS. MANAG	(06-..)	KNORR EBS 5
 TG-A 28.XXX	CHASSIS NETWORK	(06-..)	VDO Accelerator pedal calibration FFR STE
 TG-A 28.XXX	CHASSIS NETWORK	(06-..)	VDO Clutch calibration FFR
 TG-A 28.XXX	CHASSIS NETWORK	(06-..)	WABCO Body Computer ZBR 2
 TG-A 28.XXX	CHASSIS NETWORK	(06-..)	WABCO Body Computer ZBR 2 07>
 TG-A 28.XXX	CLIMA	(06-..)	BEHR/GKR Klima
 TG-A 28.XXX	CRUISE MANAGEME	(06-..)	VDO FFR Step 9
 TG-A 28.XXX	CRUISE MANAGEME	(06-..)	VDO Navigator
 TG-A 28.XXX	DASHBOARD	(06-..)	Stoneridge Electronics
 TG-A 28.XXX	DASHBOARD	(06-..)	VDO/Kienzle
 TG-A 28.XXX	ENGINE MANAGEME	(06-..)	BOSCH EDC 7
 TG-A 28.XXX	ENGINE MANAGEME	(06-..)	Bosch EDC 7 C32
 TG-A 28.XXX	MAINTENANCE SYST	(..-05)	
 TG-A 28.XXX	MAINTENANCE SYST	(06-..)	
 TG-A 28.XXX	SUSPENSION CONTR	(06-..)	WABCO ECAS

## Systems supported by ECUreader (up to V4,90)

### TRUCKS




















**MAN**

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 TG-A 28.XXX	SUSPENSION CONTR	(06-..)	WABCO ECAS 2
 TG-A 32.XXX	AIR BRAKE MANAGE	(06-..)	HALDEX ECAM
 TG-A 32.XXX	AUTOM. TRANSMISSI	(06-..)	ZF ASTRONIC 2
 TG-A 32.XXX	BRAKE SYS. MANAG	(06-..)	KNORR EBS 2.3 - 2 axle
 TG-A 32.XXX	BRAKE SYS. MANAG	(06-..)	KNORR EBS 2.3 - 3 axle
 TG-A 32.XXX	BRAKE SYS. MANAG	(06-..)	KNORR EBS 2.3 - 4 axle
 TG-A 32.XXX	BRAKE SYS. MANAG	(06-..)	KNORR EBS 2.3 - axle 3 trained
 TG-A 32.XXX	BRAKE SYS. MANAG	(06-..)	KNORR EBS 5
 TG-A 32.XXX	CHASSIS NETWORK	(06-..)	VDO Accelerator pedal calibration FFR STE
 TG-A 32.XXX	CHASSIS NETWORK	(06-..)	VDO Clutch calibration FFR
 TG-A 32.XXX	CHASSIS NETWORK	(06-..)	WABCO Body Computer ZBR 2
 TG-A 32.XXX	CHASSIS NETWORK	(06-..)	WABCO Body Computer ZBR 2 07>
 TG-A 32.XXX	CLIMA	(06-..)	BEHR/GKR Klima
 TG-A 32.XXX	CRUISE MANAGEME	(06-..)	VDO FFR Step 9
 TG-A 32.XXX	CRUISE MANAGEME	(06-..)	VDO Navigator
 TG-A 32.XXX	DASHBOARD	(06-..)	Stoneridge Electronics
 TG-A 32.XXX	DASHBOARD	(06-..)	VDO/Kienzle
 TG-A 32.XXX	ENGINE MANAGEME	(06-..)	BOSCH EDC 7
 TG-A 32.XXX	ENGINE MANAGEME	(06-..)	Bosch EDC 7 C32
 TG-A 32.XXX	MAINTENANCE SYST	(..-05)	
 TG-A 32.XXX	MAINTENANCE SYST	(06-..)	
 TG-A 32.XXX	SUSPENSION CONTR	(06-..)	WABCO ECAS
 TG-A 32.XXX	SUSPENSION CONTR	(06-..)	WABCO ECAS 2
 TG-A 33.XXX	AIR BRAKE MANAGE	(..-05)	HALDEX ECAM
 TG-A 33.XXX	AIR BRAKE MANAGE	(06-..)	HALDEX ECAM
 TG-A 33.XXX	AUTOM. TRANSMISSI	(..-05)	ZF ASTRONIC 2

## Systems supported by ECReader (up to V4,90)

### TRUCKS



























**MAN**

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 TG-A 33.XXX	AUTOM. TRANSMISSI	(06-..)	ZF ASTRONIC 2
 TG-A 33.XXX	BRAKE POWER SUP	(..-05)	ZF Intarder
 TG-A 33.XXX	BRAKE SYS. MANAG	(..-05)	KNORR EBS 2.3 - 2 axle
 TG-A 33.XXX	BRAKE SYS. MANAG	(..-05)	KNORR EBS 2.3 - 3 axle
 TG-A 33.XXX	BRAKE SYS. MANAG	(..-05)	KNORR EBS 2.3 - 4 axle
 TG-A 33.XXX	BRAKE SYS. MANAG	(..-05)	KNORR EBS 2.3 - axle 3 trained
 TG-A 33.XXX	BRAKE SYS. MANAG	(06-..)	KNORR EBS 2.3 - 2 axle
 TG-A 33.XXX	BRAKE SYS. MANAG	(06-..)	KNORR EBS 2.3 - 3 axle
 TG-A 33.XXX	BRAKE SYS. MANAG	(06-..)	KNORR EBS 2.3 - 4 axle
 TG-A 33.XXX	BRAKE SYS. MANAG	(06-..)	KNORR EBS 2.3 - axle 3 trained
 TG-A 33.XXX	BRAKE SYS. MANAG	(06-..)	KNORR EBS 5
 TG-A 33.XXX	CHASSIS NETWORK	(..-05)	BERIFORS Door Module
 TG-A 33.XXX	CHASSIS NETWORK	(..-05)	VDO Client Module
 TG-A 33.XXX	CHASSIS NETWORK	(..-05)	VDO Clutch calibration FFR
 TG-A 33.XXX	CHASSIS NETWORK	(..-05)	WABCO Body Computer ZBR 2
 TG-A 33.XXX	CHASSIS NETWORK	(06-..)	BERIFORS Door Module
 TG-A 33.XXX	CHASSIS NETWORK	(06-..)	VDO Accelerator pedal calibration FFR STE
 TG-A 33.XXX	CHASSIS NETWORK	(06-..)	VDO Clutch calibration FFR
 TG-A 33.XXX	CHASSIS NETWORK	(06-..)	WABCO Body Computer ZBR 2
 TG-A 33.XXX	CHASSIS NETWORK	(06-..)	WABCO Body Computer ZBR 2 07>
 TG-A 33.XXX	CLIMA	(..-05)	BEHR/GKR Klima
 TG-A 33.XXX	CLIMA	(06-..)	BEHR/GKR Klima
 TG-A 33.XXX	CRUISE MANAGEME	(..-05)	VDO Navigator
 TG-A 33.XXX	CRUISE MANAGEME	(06-..)	VDO FFR Step 9
 TG-A 33.XXX	CRUISE MANAGEME	(06-..)	VDO Navigator
 TG-A 33.XXX	DASHBOARD	(..-05)	VDO/Kienzle
 TG-A 33.XXX	DASHBOARD	(06-..)	Stoneridge Electronics

## Systems supported by ECReader (up to V4,90)

### TRUCKS



























**MAN**

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 TG-A 33.XXX	DASHBOARD	(06-..)	VDO/Kienzle
 TG-A 33.XXX	ENGINE MANAGEME	(..-05)	BOSCH EDC 7
 TG-A 33.XXX	ENGINE MANAGEME	(..-05)	BOSCH EDC MS 6.1
 TG-A 33.XXX	ENGINE MANAGEME	(06-..)	BOSCH EDC 7
 TG-A 33.XXX	ENGINE MANAGEME	(06-..)	Bosch EDC 7 C32
 TG-A 33.XXX	MAINTENANCE SYST	(..-05)	
 TG-A 33.XXX	MAINTENANCE SYST	(06-..)	
 TG-A 33.XXX	SUSPENSION CONTR	(..-05)	WABCO ECAS
 TG-A 33.XXX	SUSPENSION CONTR	(06-..)	WABCO ECAS
 TG-A 33.XXX	SUSPENSION CONTR	(06-..)	WABCO ECAS 2
 TG-A 35.XXX	AIR BRAKE MANAGE	(..-05)	HALDEX ECAM
 TG-A 35.XXX	AIR BRAKE MANAGE	(06-..)	HALDEX ECAM
 TG-A 35.XXX	AUTOM. TRANSMISSI	(..-05)	ZF ASTRONIC 2
 TG-A 35.XXX	AUTOM. TRANSMISSI	(06-..)	ZF ASTRONIC 2
 TG-A 35.XXX	BRAKE POWER SUP	(..-05)	ZF Intarder
 TG-A 35.XXX	BRAKE SYS. MANAG	(..-05)	KNORR EBS 2.3 - 2 axle
 TG-A 35.XXX	BRAKE SYS. MANAG	(..-05)	KNORR EBS 2.3 - 3 axle
 TG-A 35.XXX	BRAKE SYS. MANAG	(..-05)	KNORR EBS 2.3 - 4 axle
 TG-A 35.XXX	BRAKE SYS. MANAG	(..-05)	KNORR EBS 2.3 - axle 3 trained
 TG-A 35.XXX	BRAKE SYS. MANAG	(06-..)	KNORR EBS 2.3 - 2 axle
 TG-A 35.XXX	BRAKE SYS. MANAG	(06-..)	KNORR EBS 2.3 - 3 axle
 TG-A 35.XXX	BRAKE SYS. MANAG	(06-..)	KNORR EBS 2.3 - 4 axle
 TG-A 35.XXX	BRAKE SYS. MANAG	(06-..)	KNORR EBS 2.3 - axle 3 trained
 TG-A 35.XXX	BRAKE SYS. MANAG	(06-..)	KNORR EBS 5
 TG-A 35.XXX	CHASSIS NETWORK	(..-05)	BERIFORS Door Module
 TG-A 35.XXX	CHASSIS NETWORK	(..-05)	VDO Client Module

## Systems supported by ECUreader (up to V4,90)

### TRUCKS










**MAN**

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 TG-A 35.XXX	CHASSIS NETWORK	(..-05)	VDO Clutch calibration FFR
 TG-A 35.XXX	CHASSIS NETWORK	(..-05)	WABCO Body Computer ZBR 2
 TG-A 35.XXX	CHASSIS NETWORK	(06-..)	BERIFORS Door Module
 TG-A 35.XXX	CHASSIS NETWORK	(06-..)	VDO Accelerator pedal calibration FFR STE
 TG-A 35.XXX	CHASSIS NETWORK	(06-..)	VDO Clutch calibration FFR
 TG-A 35.XXX	CHASSIS NETWORK	(06-..)	WABCO Body Computer ZBR 2
 TG-A 35.XXX	CHASSIS NETWORK	(06-..)	WABCO Body Computer ZBR 2 07>
 TG-A 35.XXX	CLIMA	(..-05)	BEHR/GKR Klima
 TG-A 35.XXX	CLIMA	(06-..)	BEHR/GKR Klima
 TG-A 35.XXX	CRUISE MANAGEME	(..-05)	VDO Navigator
 TG-A 35.XXX	CRUISE MANAGEME	(06-..)	VDO FFR Step 9
 TG-A 35.XXX	CRUISE MANAGEME	(06-..)	VDO Navigator
 TG-A 35.XXX	DASHBOARD	(..-05)	VDO/Kienzle
 TG-A 35.XXX	DASHBOARD	(06-..)	Stoneridge Electronics
 TG-A 35.XXX	DASHBOARD	(06-..)	VDO/Kienzle
 TG-A 35.XXX	ENGINE MANAGEME	(..-05)	BOSCH EDC 7
 TG-A 35.XXX	ENGINE MANAGEME	(..-05)	BOSCH EDC MS 6.1
 TG-A 35.XXX	ENGINE MANAGEME	(06-..)	BOSCH EDC 7
 TG-A 35.XXX	ENGINE MANAGEME	(06-..)	Bosch EDC 7 C32
 TG-A 35.XXX	MAINTENANCE SYST	(..-05)	
 TG-A 35.XXX	MAINTENANCE SYST	(06-..)	
 TG-A 35.XXX	SUSPENSION CONTR	(..-05)	WABCO ECAS
 TG-A 35.XXX	SUSPENSION CONTR	(06-..)	WABCO ECAS
 TG-A 35.XXX	SUSPENSION CONTR	(06-..)	WABCO ECAS 2
 TG-A 39.XXX	AIR BRAKE MANAGE	(06-..)	HALDEX ECAM
 TG-A 39.XXX	AUTOM. TRANSMISSI	(06-..)	ZF ASTRONIC 2

## Systems supported by ECUreader (up to V4,90)

### TRUCKS



























**MAN**

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 TG-A 39.XXX	BRAKE SYS. MANAG	(06-..)	KNORR EBS 2.3 - 2 axle
 TG-A 39.XXX	BRAKE SYS. MANAG	(06-..)	KNORR EBS 2.3 - 3 axle
 TG-A 39.XXX	BRAKE SYS. MANAG	(06-..)	KNORR EBS 2.3 - 4 axle
 TG-A 39.XXX	BRAKE SYS. MANAG	(06-..)	KNORR EBS 2.3 - axle 3 trained
 TG-A 39.XXX	BRAKE SYS. MANAG	(06-..)	KNORR EBS 5
 TG-A 39.XXX	CHASSIS NETWORK	(06-..)	VDO Accelerator pedal calibration FFR STE
 TG-A 39.XXX	CHASSIS NETWORK	(06-..)	VDO Clutch calibration FFR
 TG-A 39.XXX	CHASSIS NETWORK	(06-..)	WABCO Body Computer ZBR 2
 TG-A 39.XXX	CHASSIS NETWORK	(06-..)	WABCO Body Computer ZBR 2 07>
 TG-A 39.XXX	CLIMA	(06-..)	BEHR/GKR Klima
 TG-A 39.XXX	CRUISE MANAGEME	(06-..)	VDO FFR Step 9
 TG-A 39.XXX	CRUISE MANAGEME	(06-..)	VDO Navigator
 TG-A 39.XXX	DASHBOARD	(06-..)	Stoneridge Electronics
 TG-A 39.XXX	DASHBOARD	(06-..)	VDO/Kienzle
 TG-A 39.XXX	ENGINE MANAGEME	(06-..)	BOSCH EDC 7
 TG-A 39.XXX	ENGINE MANAGEME	(06-..)	Bosch EDC 7 C32
 TG-A 39.XXX	MAINTENANCE SYST	(..-05)	
 TG-A 39.XXX	MAINTENANCE SYST	(06-..)	
 TG-A 39.XXX	SUSPENSION CONTR	(06-..)	WABCO ECAS
 TG-A 39.XXX	SUSPENSION CONTR	(06-..)	WABCO ECAS 2
 TG-A 40.XXX	AIR BRAKE MANAG	(06-..)	HALDEX ECAM
 TG-A 40.XXX	AUTOM. TRANSMISSI	(06-..)	ZF ASTRONIC 2
 TG-A 40.XXX	BRAKE SYS. MANAG	(06-..)	KNORR EBS 2.3 - 2 axle
 TG-A 40.XXX	BRAKE SYS. MANAG	(06-..)	KNORR EBS 2.3 - 3 axle
 TG-A 40.XXX	BRAKE SYS. MANAG	(06-..)	KNORR EBS 2.3 - 4 axle
 TG-A 40.XXX	BRAKE SYS. MANAG	(06-..)	KNORR EBS 2.3 - axle 3 trained

## Systems supported by ECUreader (up to V4,90)

### TRUCKS




























**MAN**

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 TG-A 40.XXX	BRAKE SYS. MANAG	(06-..)	KNORR EBS 5
 TG-A 40.XXX	CHASSIS NETWORK	(06-..)	VDO Accelerator pedal calibration FFR STE
 TG-A 40.XXX	CHASSIS NETWORK	(06-..)	VDO Clutch calibration FFR
 TG-A 40.XXX	CHASSIS NETWORK	(06-..)	WABCO Body Computer ZBR 2
 TG-A 40.XXX	CHASSIS NETWORK	(06-..)	WABCO Body Computer ZBR 2 07>
 TG-A 40.XXX	CLIMA	(06-..)	BEHR/GKR Klima
 TG-A 40.XXX	CRUISE MANAGEME	(06-..)	VDO FFR Step 9
 TG-A 40.XXX	CRUISE MANAGEME	(06-..)	VDO Navigator
 TG-A 40.XXX	DASHBOARD	(06-..)	Stoneridge Electronics
 TG-A 40.XXX	DASHBOARD	(06-..)	VDO/Kienzle
 TG-A 40.XXX	ENGINE MANAGEME	(06-..)	BOSCH EDC 7
 TG-A 40.XXX	ENGINE MANAGEME	(06-..)	Bosch EDC 7 C32
 TG-A 40.XXX	MAINTENANCE SYST	(..-05)	
 TG-A 40.XXX	MAINTENANCE SYST	(06-..)	
 TG-A 40.XXX	SUSPENSION CONTR	(06-..)	WABCO ECAS
 TG-A 40.XXX	SUSPENSION CONTR	(06-..)	WABCO ECAS 2
 TG-A 41.XXX	AIR BRAKE MANAG	(..-05)	HALDEX ECAM
 TG-A 41.XXX	AIR BRAKE MANAG	(06-..)	HALDEX ECAM
 TG-A 41.XXX	AUTOM. TRANSMISSI	(..-05)	ZF ASTRONIC 2
 TG-A 41.XXX	AUTOM. TRANSMISSI	(06-..)	ZF ASTRONIC 2
 TG-A 41.XXX	BRAKE POWER SUP	(..-05)	ZF Intarder
 TG-A 41.XXX	BRAKE SYS. MANAG	(..-05)	KNORR EBS 2.3 - 2 axle
 TG-A 41.XXX	BRAKE SYS. MANAG	(..-05)	KNORR EBS 2.3 - 3 axle
 TG-A 41.XXX	BRAKE SYS. MANAG	(..-05)	KNORR EBS 2.3 - 4 axle
 TG-A 41.XXX	BRAKE SYS. MANAG	(..-05)	KNORR EBS 2.3 - axle 3 trained
 TG-A 41.XXX	BRAKE SYS. MANAG	(06-..)	KNORR EBS 2.3 - 2 axle

## Systems supported by ECUREADER (up to V4,90)

### TRUCKS



























**MAN**

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 TG-A 41.XXX	BRAKE SYS. MANAG	(06-..)	KNORR EBS 2.3 - 3 axle
 TG-A 41.XXX	BRAKE SYS. MANAG	(06-..)	KNORR EBS 2.3 - 4 axle
 TG-A 41.XXX	BRAKE SYS. MANAG	(06-..)	KNORR EBS 2.3 - axle 3 trained
 TG-A 41.XXX	BRAKE SYS. MANAG	(06-..)	KNORR EBS 5
 TG-A 41.XXX	CHASSIS NETWORK	(..-05)	BERIFORS Door Module
 TG-A 41.XXX	CHASSIS NETWORK	(..-05)	VDO Client Module
 TG-A 41.XXX	CHASSIS NETWORK	(..-05)	VDO Clutch calibration FFR
 TG-A 41.XXX	CHASSIS NETWORK	(..-05)	WABCO Body Computer ZBR 2
 TG-A 41.XXX	CHASSIS NETWORK	(06-..)	BERIFORS Door Module
 TG-A 41.XXX	CHASSIS NETWORK	(06-..)	VDO Accelerator pedal calibration FFR STE
 TG-A 41.XXX	CHASSIS NETWORK	(06-..)	VDO Clutch calibration FFR
 TG-A 41.XXX	CHASSIS NETWORK	(06-..)	WABCO Body Computer ZBR 2
 TG-A 41.XXX	CHASSIS NETWORK	(06-..)	WABCO Body Computer ZBR 2 07>
 TG-A 41.XXX	CLIMA	(..-05)	BEHR/GKR Klima
 TG-A 41.XXX	CLIMA	(06-..)	BEHR/GKR Klima
 TG-A 41.XXX	CRUISE MANAGEME	(..-05)	VDO Navigator
 TG-A 41.XXX	CRUISE MANAGEME	(06-..)	VDO FFR Step 9
 TG-A 41.XXX	CRUISE MANAGEME	(06-..)	VDO Navigator
 TG-A 41.XXX	DASHBOARD	(..-05)	VDO/Kienzle
 TG-A 41.XXX	DASHBOARD	(06-..)	Stoneridge Electronics
 TG-A 41.XXX	DASHBOARD	(06-..)	VDO/Kienzle
 TG-A 41.XXX	ENGINE MANAGEME	(..-05)	BOSCH EDC 7
 TG-A 41.XXX	ENGINE MANAGEME	(..-05)	BOSCH EDC MS 6.1
 TG-A 41.XXX	ENGINE MANAGEME	(06-..)	BOSCH EDC 7
 TG-A 41.XXX	ENGINE MANAGEME	(06-..)	Bosch EDC 7 C32
 TG-A 41.XXX	MAINTENANCE SYST	(..-05)	
 TG-A 41.XXX	MAINTENANCE SYST	(06-..)	

## Systems supported by ECReader (up to V4,90)

### TRUCKS




























**MAN**

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 TG-A 41.XXX	SUSPENSION CONTR	(..-05)	WABCO ECAS
 TG-A 41.XXX	SUSPENSION CONTR	(06-..)	WABCO ECAS
 TG-A 41.XXX	SUSPENSION CONTR	(06-..)	WABCO ECAS 2
 TG-L	AUTOM. TRANSMISSI	10.180 (05-..)	ZF ASTRONIC LITE
 TG-L	AUTOM. TRANSMISSI	10.180 FK (05-..)	ZF ASTRONIC LITE
 TG-L	AUTOM. TRANSMISSI	10.210 (05-..)	ZF ASTRONIC LITE
 TG-L	AUTOM. TRANSMISSI	10.210 FK (05-..)	ZF ASTRONIC LITE
 TG-L	AUTOM. TRANSMISSI	10.240 (05-..)	ZF ASTRONIC LITE
 TG-L	AUTOM. TRANSMISSI	10.240 FK (05-..)	ZF ASTRONIC LITE
 TG-L	AUTOM. TRANSMISSI	12.180 (05-..)	ZF ASTRONIC LITE
 TG-L	AUTOM. TRANSMISSI	12.180 FK (05-..)	ZF ASTRONIC LITE
 TG-L	AUTOM. TRANSMISSI	12.210 (05-..)	ZF ASTRONIC LITE
 TG-L	AUTOM. TRANSMISSI	12.210 FK (05-..)	ZF ASTRONIC LITE
 TG-L	AUTOM. TRANSMISSI	12.240 (05-..)	ZF ASTRONIC LITE
 TG-L	AUTOM. TRANSMISSI	12.240 FK (05-..)	ZF ASTRONIC LITE
 TG-L	AUTOM. TRANSMISSI	7.150 (05-..)	ZF ASTRONIC LITE
 TG-L	AUTOM. TRANSMISSI	8.180 (05-..)	ZF ASTRONIC LITE
 TG-L	AUTOM. TRANSMISSI	8.180 FK (05-..)	ZF ASTRONIC LITE
 TG-L	AUTOM. TRANSMISSI	8.210 (05-..)	ZF ASTRONIC LITE
 TG-L	AUTOM. TRANSMISSI	8.210 FK (05-..)	ZF ASTRONIC LITE
 TG-L	AUTOM. TRANSMISSI	8.240 (05-..)	ZF ASTRONIC LITE
 TG-L	AUTOM. TRANSMISSI	8.240 FK (05-..)	ZF ASTRONIC LITE
 TG-L	BRAKE SYS. MANAG	10.180 (05-..)	WABCO EBS 2
 TG-L	BRAKE SYS. MANAG	10.180 FK (05-..)	WABCO EBS 2
 TG-L	BRAKE SYS. MANAG	10.210 (05-..)	WABCO EBS 2
 TG-L	BRAKE SYS. MANAG	10.210 FK (05-..)	WABCO EBS 2

## Systems supported by ECReader (up to V4,90)

### TRUCKS

























**MAN**

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 TG-L	BRAKE SYS. MANAG	10.240 (05-..)	WABCO EBS 2
 TG-L	BRAKE SYS. MANAG	10.240 FK (05-..)	WABCO EBS 2
 TG-L	BRAKE SYS. MANAG	12.180 (05-..)	WABCO EBS 2
 TG-L	BRAKE SYS. MANAG	12.180 FK (05-..)	WABCO EBS 2
 TG-L	BRAKE SYS. MANAG	12.210 (05-..)	WABCO EBS 2
 TG-L	BRAKE SYS. MANAG	12.210 FK (05-..)	WABCO EBS 2
 TG-L	BRAKE SYS. MANAG	12.240 (05-..)	WABCO EBS 2
 TG-L	BRAKE SYS. MANAG	12.240 FK (05-..)	WABCO EBS 2
 TG-L	BRAKE SYS. MANAG	7.150 (05-..)	WABCO EBS 2
 TG-L	BRAKE SYS. MANAG	8.180 (05-..)	WABCO EBS 2
 TG-L	BRAKE SYS. MANAG	8.180 FK (05-..)	WABCO EBS 2
 TG-L	BRAKE SYS. MANAG	8.210 (05-..)	WABCO EBS 2
 TG-L	BRAKE SYS. MANAG	8.210 FK (05-..)	WABCO EBS 2
 TG-L	BRAKE SYS. MANAG	8.240 (05-..)	WABCO EBS 2
 TG-L	BRAKE SYS. MANAG	8.240 FK (05-..)	WABCO EBS 2
 TG-L	CHASSIS NETWORK	10.180 (05-..)	BERIFORS Door Module
 TG-L	CHASSIS NETWORK	10.180 (05-..)	WABCO Body Computer ZBR2
 TG-L	CHASSIS NETWORK	10.180 FK (05-..)	BERIFORS Door Module
 TG-L	CHASSIS NETWORK	10.180 FK (05-..)	WABCO Body Computer ZBR2
 TG-L	CHASSIS NETWORK	10.210 (05-..)	BERIFORS Door Module
 TG-L	CHASSIS NETWORK	10.210 (05-..)	WABCO Body Computer ZBR2
 TG-L	CHASSIS NETWORK	10.210 FK (05-..)	BERIFORS Door Module
 TG-L	CHASSIS NETWORK	10.210 FK (05-..)	WABCO Body Computer ZBR2
 TG-L	CHASSIS NETWORK	10.240 (05-..)	BERIFORS Door Module
 TG-L	CHASSIS NETWORK	10.240 (05-..)	WABCO Body Computer ZBR2
 TG-L	CHASSIS NETWORK	10.240 FK (05-..)	BERIFORS Door Module
 TG-L	CHASSIS NETWORK	10.240 FK (05-..)	WABCO Body Computer ZBR2

## Systems supported by ECReader (up to V4,90)

### TRUCKS




























**MAN**

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 TG-L	CHASSIS NETWORK	12.180 (05-..)	BERIFORS Door Module
 TG-L	CHASSIS NETWORK	12.180 (05-..)	WABCO Body Computer ZBR2
 TG-L	CHASSIS NETWORK	12.180 FK (05-..)	BERIFORS Door Module
 TG-L	CHASSIS NETWORK	12.180 FK (05-..)	WABCO Body Computer ZBR2
 TG-L	CHASSIS NETWORK	12.210 (05-..)	BERIFORS Door Module
 TG-L	CHASSIS NETWORK	12.210 (05-..)	WABCO Body Computer ZBR2
 TG-L	CHASSIS NETWORK	12.210 FK (05-..)	BERIFORS Door Module
 TG-L	CHASSIS NETWORK	12.210 FK (05-..)	WABCO Body Computer ZBR2
 TG-L	CHASSIS NETWORK	12.240 (05-..)	BERIFORS Door Module
 TG-L	CHASSIS NETWORK	12.240 (05-..)	WABCO Body Computer ZBR2
 TG-L	CHASSIS NETWORK	12.240 FK (05-..)	BERIFORS Door Module
 TG-L	CHASSIS NETWORK	12.240 FK (05-..)	WABCO Body Computer ZBR2
 TG-L	CHASSIS NETWORK	7.150 (05-..)	BERIFORS Door Module
 TG-L	CHASSIS NETWORK	7.150 (05-..)	WABCO Body Computer ZBR2
 TG-L	CHASSIS NETWORK	8.180 (05-..)	BERIFORS Door Module
 TG-L	CHASSIS NETWORK	8.180 (05-..)	WABCO Body Computer ZBR2
 TG-L	CHASSIS NETWORK	8.180 FK (05-..)	BERIFORS Door Module
 TG-L	CHASSIS NETWORK	8.180 FK (05-..)	WABCO Body Computer ZBR2
 TG-L	CHASSIS NETWORK	8.210 (05-..)	BERIFORS Door Module
 TG-L	CHASSIS NETWORK	8.210 (05-..)	WABCO Body Computer ZBR2
 TG-L	CHASSIS NETWORK	8.210 FK (05-..)	BERIFORS Door Module
 TG-L	CHASSIS NETWORK	8.210 FK (05-..)	WABCO Body Computer ZBR2
 TG-L	CHASSIS NETWORK	8.240 (05-..)	BERIFORS Door Module
 TG-L	CHASSIS NETWORK	8.240 (05-..)	WABCO Body Computer ZBR2
 TG-L	CHASSIS NETWORK	8.240 FK (05-..)	BERIFORS Door Module
 TG-L	CHASSIS NETWORK	8.240 FK (05-..)	WABCO Body Computer ZBR2
 TG-L	CLIMA	10.180 (05-..)	BEHR/GKR Klima

## Systems supported by ECUREADER (up to V4,90)

### TRUCKS




























**MAN**

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 TG-L	CLIMA	10.180 FK (05-..)	BEHR/GKR Klima
 TG-L	CLIMA	10.210 (05-..)	BEHR/GKR Klima
 TG-L	CLIMA	10.210 FK (05-..)	BEHR/GKR Klima
 TG-L	CLIMA	10.240 (05-..)	BEHR/GKR Klima
 TG-L	CLIMA	10.240 FK (05-..)	BEHR/GKR Klima
 TG-L	CLIMA	12.180 (05-..)	BEHR/GKR Klima
 TG-L	CLIMA	12.180 FK (05-..)	BEHR/GKR Klima
 TG-L	CLIMA	12.210 (05-..)	BEHR/GKR Klima
 TG-L	CLIMA	12.210 FK (05-..)	BEHR/GKR Klima
 TG-L	CLIMA	12.240 (05-..)	BEHR/GKR Klima
 TG-L	CLIMA	12.240 FK (05-..)	BEHR/GKR Klima
 TG-L	CLIMA	7.150 (05-..)	BEHR/GKR Klima
 TG-L	CLIMA	8.180 (05-..)	BEHR/GKR Klima
 TG-L	CLIMA	8.180 FK (05-..)	BEHR/GKR Klima
 TG-L	CLIMA	8.210 (05-..)	BEHR/GKR Klima
 TG-L	CLIMA	8.210 FK (05-..)	BEHR/GKR Klima
 TG-L	CLIMA	8.240 (05-..)	BEHR/GKR Klima
 TG-L	CLIMA	8.240 FK (05-..)	BEHR/GKR Klima
 TG-L	DASHBOARD	10.180 (05-..)	Stoneridge Electronics
 TG-L	DASHBOARD	10.180 FK (05-..)	Stoneridge Electronics
 TG-L	DASHBOARD	10.210 (05-..)	Stoneridge Electronics
 TG-L	DASHBOARD	10.210 FK (05-..)	Stoneridge Electronics
 TG-L	DASHBOARD	10.240 (05-..)	Stoneridge Electronics
 TG-L	DASHBOARD	10.240 FK (05-..)	Stoneridge Electronics
 TG-L	DASHBOARD	12.180 (05-..)	Stoneridge Electronics
 TG-L	DASHBOARD	12.180 FK (05-..)	Stoneridge Electronics
 TG-L	DASHBOARD	12.210 (05-..)	Stoneridge Electronics

## Systems supported by ECReader (up to V4,90)

### TRUCKS



























**MAN**

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 TG-L	DASHBOARD	12.210 FK (05-..)	Stoneridge Electronics
 TG-L	DASHBOARD	12.240 (05-..)	Stoneridge Electronics
 TG-L	DASHBOARD	12.240 FK (05-..)	Stoneridge Electronics
 TG-L	DASHBOARD	7.150 (05-..)	Stoneridge Electronics
 TG-L	DASHBOARD	8.180 FK (05-..)	Stoneridge Electronics
 TG-L	DASHBOARD	8.210 (05-..)	Stoneridge Electronics
 TG-L	DASHBOARD	8.210 FK (05-..)	Stoneridge Electronics
 TG-L	DASHBOARD	8.240 (05-..)	Stoneridge Electronics
 TG-L	DASHBOARD	8.240 FK (05-..)	Stoneridge Electronics
 TG-L	ENGINE MANAGEME	10.180 (05-..)	BOSCH EDC 7
 TG-L	ENGINE MANAGEME	10.180 FK (05-..)	BOSCH EDC 7
 TG-L	ENGINE MANAGEME	10.210 (05-..)	BOSCH EDC 7
 TG-L	ENGINE MANAGEME	10.210 FK (05-..)	BOSCH EDC 7
 TG-L	ENGINE MANAGEME	10.240 (05-..)	BOSCH EDC 7
 TG-L	ENGINE MANAGEME	10.240 FK (05-..)	BOSCH EDC 7
 TG-L	ENGINE MANAGEME	12.180 (05-..)	BOSCH EDC 7
 TG-L	ENGINE MANAGEME	12.180 FK (05-..)	BOSCH EDC 7
 TG-L	ENGINE MANAGEME	12.210 (05-..)	BOSCH EDC 7
 TG-L	ENGINE MANAGEME	12.210 FK (05-..)	BOSCH EDC 7
 TG-L	ENGINE MANAGEME	12.240 (05-..)	BOSCH EDC 7
 TG-L	ENGINE MANAGEME	12.240 FK (05-..)	BOSCH EDC 7
 TG-L	ENGINE MANAGEME	7.150 (05-..)	BOSCH EDC 7
 TG-L	ENGINE MANAGEME	8.180 (05-..)	BOSCH EDC 7
 TG-L	ENGINE MANAGEME	8.180 FK (05-..)	BOSCH EDC 7
 TG-L	ENGINE MANAGEME	8.210 (05-..)	BOSCH EDC 7
 TG-L	ENGINE MANAGEME	8.210 FK (05-..)	BOSCH EDC 7
 TG-L	ENGINE MANAGEME	8.240 (05-..)	BOSCH EDC 7

## Systems supported by ECUreader (up to V4,90)

### TRUCKS



























**MAN**

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 TG-L	ENGINE MANAGEME	8.240 FK (05-..)	BOSCH EDC 7
 TG-L	SUSPENSION CONTR	10.180 (05-..)	WABCO ECAS 2
 TG-L	SUSPENSION CONTR	10.180 FK (05-..)	WABCO ECAS 2
 TG-L	SUSPENSION CONTR	10.210 (05-..)	WABCO ECAS 2
 TG-L	SUSPENSION CONTR	10.210 FK (05-..)	WABCO ECAS 2
 TG-L	SUSPENSION CONTR	10.240 (05-..)	WABCO ECAS 2
 TG-L	SUSPENSION CONTR	10.240 FK (05-..)	WABCO ECAS 2
 TG-L	SUSPENSION CONTR	12.180 (05-..)	WABCO ECAS 2
 TG-L	SUSPENSION CONTR	12.180 FK (05-..)	WABCO ECAS 2
 TG-L	SUSPENSION CONTR	12.210 (05-..)	WABCO ECAS 2
 TG-L	SUSPENSION CONTR	12.210 FK (05-..)	WABCO ECAS 2
 TG-L	SUSPENSION CONTR	12.240 (05-..)	WABCO ECAS 2
 TG-L	SUSPENSION CONTR	12.240 FK (05-..)	WABCO ECAS 2
 TG-L	SUSPENSION CONTR	7.150 (05-..)	WABCO ECAS 2
 TG-L	SUSPENSION CONTR	8.180 (05-..)	WABCO ECAS 2
 TG-L	SUSPENSION CONTR	8.180 FK (05-..)	WABCO ECAS 2
 TG-L	SUSPENSION CONTR	8.210 (05-..)	WABCO ECAS 2
 TG-L	SUSPENSION CONTR	8.210 FK (05-..)	WABCO ECAS 2
 TG-L	SUSPENSION CONTR	8.240 (05-..)	WABCO ECAS 2
 TG-L	SUSPENSION CONTR	8.240 FK (05-..)	WABCO ECAS 2
 TG-M	CHASSIS NETWORK	12.240 (08-..)	VDO Accelerator pedal calibration FFR STE
 TG-M	CHASSIS NETWORK	12.250 (08-..)	VDO Accelerator pedal calibration FFR STE
 TG-M	CHASSIS NETWORK	12.280 (08-..)	VDO Accelerator pedal calibration FFR STE
 TG-M	CHASSIS NETWORK	12.290 (08-..)	VDO Accelerator pedal calibration FFR STE
 TG-M	CHASSIS NETWORK	15.240 (08-..)	VDO Accelerator pedal calibration FFR STE
 TG-M	CHASSIS NETWORK	15.250 (08-..)	VDO Accelerator pedal calibration FFR STE

## Systems supported by ECUREADER (up to V4,90)

### TRUCKS




























**MAN**

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 TG-M	CHASSIS NETWORK	15.280 (08-..)	VDO Accelerator pedal calibration FFR STE
 TG-M	CHASSIS NETWORK	15.290 (08-..)	VDO Accelerator pedal calibration FFR STE
 TG-M	CHASSIS NETWORK	18.240 (08-..)	VDO Accelerator pedal calibration FFR STE
 TG-M	CHASSIS NETWORK	18.250 (08-..)	VDO Accelerator pedal calibration FFR STE
 TG-M	CHASSIS NETWORK	18.280 (08-..)	VDO Accelerator pedal calibration FFR STE
 TG-M	CHASSIS NETWORK	18.290 (08-..)	VDO Accelerator pedal calibration FFR STE
 TG-M	CHASSIS NETWORK	26.240 (08-..)	VDO Accelerator pedal calibration FFR STE
 TG-M	CHASSIS NETWORK	26.250 (08-..)	VDO Accelerator pedal calibration FFR STE
 TG-M	CHASSIS NETWORK	26.280 (08-..)	VDO Accelerator pedal calibration FFR STE
 TG-M	CHASSIS NETWORK	26.290 (08-..)	VDO Accelerator pedal calibration FFR STE
 TG-M	ENGINE MANAGEME	12.240 (08-..)	Bosch EDC 7 C32
 TG-M	ENGINE MANAGEME	12.250 (08-..)	Bosch EDC 7 C32
 TG-M	ENGINE MANAGEME	12.280 (08-..)	Bosch EDC 7 C32
 TG-M	ENGINE MANAGEME	12.290 (08-..)	Bosch EDC 7 C32
 TG-M	ENGINE MANAGEME	15.240 (08-..)	Bosch EDC 7 C32
 TG-M	ENGINE MANAGEME	15.250 (08-..)	Bosch EDC 7 C32
 TG-M	ENGINE MANAGEME	15.280 (08-..)	Bosch EDC 7 C32
 TG-M	ENGINE MANAGEME	15.290 (08-..)	Bosch EDC 7 C32
 TG-M	ENGINE MANAGEME	18.240 (08-..)	Bosch EDC 7 C32
 TG-M	ENGINE MANAGEME	18.250 (08-..)	Bosch EDC 7 C32
 TG-M	ENGINE MANAGEME	18.280 (08-..)	Bosch EDC 7 C32
 TG-M	ENGINE MANAGEME	18.290 (08-..)	Bosch EDC 7 C32
 TG-M	ENGINE MANAGEME	26.240 (08-..)	Bosch EDC 7 C32
 TG-M	ENGINE MANAGEME	26.250 (08-..)	Bosch EDC 7 C32
 TG-M	ENGINE MANAGEME	26.280 (08-..)	Bosch EDC 7 C32
 TG-M	ENGINE MANAGEME	26.290 (08-..)	Bosch EDC 7 C32

## Systems supported by ECReader (up to V4,90)

### TRUCKS




























**MAN**

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 TG-S	BRAKE SYS. MANAG	18.320 (08-..)	Knorr EBS 5
 TG-S	BRAKE SYS. MANAG	18.360 (08-..)	Knorr EBS 5
 TG-S	BRAKE SYS. MANAG	18.400 (08-..)	Knorr EBS 5
 TG-S	BRAKE SYS. MANAG	18.440 (08-..)	Knorr EBS 5
 TG-S	BRAKE SYS. MANAG	18.480 (08-..)	Knorr EBS 5
 TG-S	BRAKE SYS. MANAG	24.320 (08-..)	Knorr EBS 5
 TG-S	BRAKE SYS. MANAG	24.360 (08-..)	Knorr EBS 5
 TG-S	BRAKE SYS. MANAG	24.400 (08-..)	Knorr EBS 5
 TG-S	BRAKE SYS. MANAG	24.440 (08-..)	Knorr EBS 5
 TG-S	BRAKE SYS. MANAG	24.480 (08-..)	Knorr EBS 5
 TG-S	BRAKE SYS. MANAG	26.320 (08-..)	Knorr EBS 5
 TG-S	BRAKE SYS. MANAG	26.360 (08-..)	Knorr EBS 5
 TG-S	BRAKE SYS. MANAG	26.400 (08-..)	Knorr EBS 5
 TG-S	BRAKE SYS. MANAG	26.440 (08-..)	Knorr EBS 5
 TG-S	BRAKE SYS. MANAG	26.480 (08-..)	Knorr EBS 5
 TG-S	BRAKE SYS. MANAG	26.540 (08-..)	Knorr EBS 5
 TG-S	BRAKE SYS. MANAG	28.320 (08-..)	Knorr EBS 5
 TG-S	BRAKE SYS. MANAG	28.360 (08-..)	Knorr EBS 5
 TG-S	BRAKE SYS. MANAG	28.400 (08-..)	Knorr EBS 5
 TG-S	BRAKE SYS. MANAG	28.440 (08-..)	Knorr EBS 5
 TG-S	BRAKE SYS. MANAG	28.480 (08-..)	Knorr EBS 5
 TG-S	BRAKE SYS. MANAG	33.320 (08-..)	Knorr EBS 5
 TG-S	BRAKE SYS. MANAG	33.360 (08-..)	Knorr EBS 5
 TG-S	BRAKE SYS. MANAG	33.400 (08-..)	Knorr EBS 5
 TG-S	BRAKE SYS. MANAG	33.440 (08-..)	Knorr EBS 5
 TG-S	BRAKE SYS. MANAG	33.480 (08-..)	Knorr EBS 5
 TG-S	BRAKE SYS. MANAG	33.540 (08-..)	Knorr EBS 5

## Systems supported by ECReader (up to V4,90)

### TRUCKS




























**MAN**

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 TG-S	BRAKE SYS. MANAG	35.320 (08-..)	Knorr EBS 5
 TG-S	BRAKE SYS. MANAG	35.360 (08-..)	Knorr EBS 5
 TG-S	BRAKE SYS. MANAG	35.400 (08-..)	Knorr EBS 5
 TG-S	BRAKE SYS. MANAG	35.440 (08-..)	Knorr EBS 5
 TG-S	BRAKE SYS. MANAG	35.480 (08-..)	Knorr EBS 5
 TG-S	BRAKE SYS. MANAG	37.320 (08-..)	Knorr EBS 5
 TG-S	BRAKE SYS. MANAG	37.360 (08-..)	Knorr EBS 5
 TG-S	BRAKE SYS. MANAG	37.400 (08-..)	Knorr EBS 5
 TG-S	BRAKE SYS. MANAG	37.440 (08-..)	Knorr EBS 5
 TG-S	BRAKE SYS. MANAG	37.480 (08-..)	Knorr EBS 5
 TG-S	BRAKE SYS. MANAG	39.320 (08-..)	Knorr EBS 5
 TG-S	BRAKE SYS. MANAG	39.360 (08-..)	Knorr EBS 5
 TG-S	BRAKE SYS. MANAG	39.400 (08-..)	Knorr EBS 5
 TG-S	BRAKE SYS. MANAG	39.440 (08-..)	Knorr EBS 5
 TG-S	BRAKE SYS. MANAG	39.480 (08-..)	Knorr EBS 5
 TG-S	BRAKE SYS. MANAG	40.440 (08-..)	Knorr EBS 5
 TG-S	BRAKE SYS. MANAG	40.480 (08-..)	Knorr EBS 5
 TG-S	BRAKE SYS. MANAG	41.320 (08-..)	Knorr EBS 5
 TG-S	BRAKE SYS. MANAG	41.360 (08-..)	Knorr EBS 5
 TG-S	BRAKE SYS. MANAG	41.400 (08-..)	Knorr EBS 5
 TG-S	BRAKE SYS. MANAG	41.440 (08-..)	Knorr EBS 5
 TG-S	BRAKE SYS. MANAG	41.480 (08-..)	Knorr EBS 5
 TG-S	BRAKE SYS. MANAG	41.540 (08-..)	Knorr EBS 5
 TG-S	CHASSIS NETWORK	18.320 (08-..)	VDO Accelerator pedal calibration FFR STE
 TG-S	CHASSIS NETWORK	18.320 (08-..)	VDO Clutch Calibration FFR STEP 11
 TG-S	CHASSIS NETWORK	18.360 (08-..)	VDO Accelerator pedal calibration FFR STE
 TG-S	CHASSIS NETWORK	18.360 (08-..)	VDO Clutch Calibration FFR STEP 11

## Systems supported by ECReader (up to V4,90)

### TRUCKS




























**MAN**

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 TG-S	CHASSIS NETWORK	18.400 (08-..)	VDO Accelerator pedal calibration FFR STE
 TG-S	CHASSIS NETWORK	18.400 (08-..)	VDO Clutch Calibration FFR STEP 11
 TG-S	CHASSIS NETWORK	18.440 (08-..)	VDO Accelerator pedal calibration FFR STE
 TG-S	CHASSIS NETWORK	18.440 (08-..)	VDO Clutch Calibration FFR STEP 11
 TG-S	CHASSIS NETWORK	18.480 (08-..)	VDO Accelerator pedal calibration FFR STE
 TG-S	CHASSIS NETWORK	18.480 (08-..)	VDO Clutch Calibration FFR STEP 11
 TG-S	CHASSIS NETWORK	24.320 (08-..)	VDO Accelerator pedal calibration FFR STE
 TG-S	CHASSIS NETWORK	24.320 (08-..)	VDO Clutch Calibration FFR STEP 11
 TG-S	CHASSIS NETWORK	24.360 (08-..)	VDO Accelerator pedal calibration FFR STE
 TG-S	CHASSIS NETWORK	24.360 (08-..)	VDO Clutch Calibration FFR STEP 11
 TG-S	CHASSIS NETWORK	24.400 (08-..)	VDO Accelerator pedal calibration FFR STE
 TG-S	CHASSIS NETWORK	24.400 (08-..)	VDO Clutch Calibration FFR STEP 11
 TG-S	CHASSIS NETWORK	24.440 (08-..)	VDO Accelerator pedal calibration FFR STE
 TG-S	CHASSIS NETWORK	24.440 (08-..)	VDO Clutch Calibration FFR STEP 11
 TG-S	CHASSIS NETWORK	24.480 (08-..)	VDO Accelerator pedal calibration FFR STE
 TG-S	CHASSIS NETWORK	24.480 (08-..)	VDO Clutch Calibration FFR STEP 11
 TG-S	CHASSIS NETWORK	26.320 (08-..)	VDO Accelerator pedal calibration FFR STE
 TG-S	CHASSIS NETWORK	26.320 (08-..)	VDO Clutch Calibration FFR STEP 11
 TG-S	CHASSIS NETWORK	26.360 (08-..)	VDO Accelerator pedal calibration FFR STE
 TG-S	CHASSIS NETWORK	26.360 (08-..)	VDO Clutch Calibration FFR STEP 11
 TG-S	CHASSIS NETWORK	26.400 (08-..)	VDO Accelerator pedal calibration FFR STE
 TG-S	CHASSIS NETWORK	26.400 (08-..)	VDO Clutch Calibration FFR STEP 11
 TG-S	CHASSIS NETWORK	26.440 (08-..)	VDO Accelerator pedal calibration FFR STE
 TG-S	CHASSIS NETWORK	26.440 (08-..)	VDO Clutch Calibration FFR STEP 11
 TG-S	CHASSIS NETWORK	26.480 (08-..)	VDO Accelerator pedal calibration FFR STE
 TG-S	CHASSIS NETWORK	26.480 (08-..)	VDO Clutch Calibration FFR STEP 11
 TG-S	CHASSIS NETWORK	26.540 (08-..)	VDO Accelerator pedal calibration FFR STE

## Systems supported by ECReader (up to V4,90)

### TRUCKS




























**MAN**

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 TG-S	CHASSIS NETWORK	26.540 (08-..)	VDO Clutch Calibration FFR STEP 11
 TG-S	CHASSIS NETWORK	28.320 (08-..)	VDO Accelerator pedal calibration FFR STE
 TG-S	CHASSIS NETWORK	28.320 (08-..)	VDO Clutch Calibration FFR STEP 11
 TG-S	CHASSIS NETWORK	28.360 (08-..)	VDO Accelerator pedal calibration FFR STE
 TG-S	CHASSIS NETWORK	28.360 (08-..)	VDO Clutch Calibration FFR STEP 11
 TG-S	CHASSIS NETWORK	28.400 (08-..)	VDO Accelerator pedal calibration FFR STE
 TG-S	CHASSIS NETWORK	28.400 (08-..)	VDO Clutch Calibration FFR STEP 11
 TG-S	CHASSIS NETWORK	28.440 (08-..)	VDO Accelerator pedal calibration FFR STE
 TG-S	CHASSIS NETWORK	28.440 (08-..)	VDO Clutch Calibration FFR STEP 11
 TG-S	CHASSIS NETWORK	28.480 (08-..)	VDO Accelerator pedal calibration FFR STE
 TG-S	CHASSIS NETWORK	28.480 (08-..)	VDO Clutch Calibration FFR STEP 11
 TG-S	CHASSIS NETWORK	33.320 (08-..)	VDO Accelerator pedal calibration FFR STE
 TG-S	CHASSIS NETWORK	33.320 (08-..)	VDO Clutch Calibration FFR STEP 11
 TG-S	CHASSIS NETWORK	33.360 (08-..)	VDO Accelerator pedal calibration FFR STE
 TG-S	CHASSIS NETWORK	33.360 (08-..)	VDO Clutch Calibration FFR STEP 11
 TG-S	CHASSIS NETWORK	33.400 (08-..)	VDO Accelerator pedal calibration FFR STE
 TG-S	CHASSIS NETWORK	33.400 (08-..)	VDO Clutch Calibration FFR STEP 11
 TG-S	CHASSIS NETWORK	33.440 (08-..)	VDO Accelerator pedal calibration FFR STE
 TG-S	CHASSIS NETWORK	33.440 (08-..)	VDO Clutch Calibration FFR STEP 11
 TG-S	CHASSIS NETWORK	33.480 (08-..)	VDO Accelerator pedal calibration FFR STE
 TG-S	CHASSIS NETWORK	33.480 (08-..)	VDO Clutch Calibration FFR STEP 11
 TG-S	CHASSIS NETWORK	33.540 (08-..)	VDO Accelerator pedal calibration FFR STE
 TG-S	CHASSIS NETWORK	33.540 (08-..)	VDO Clutch Calibration FFR STEP 11
 TG-S	CHASSIS NETWORK	35.320 (08-..)	VDO Accelerator pedal calibration FFR STE
 TG-S	CHASSIS NETWORK	35.320 (08-..)	VDO Clutch Calibration FFR STEP 11
 TG-S	CHASSIS NETWORK	35.360 (08-..)	VDO Accelerator pedal calibration FFR STE
 TG-S	CHASSIS NETWORK	35.360 (08-..)	VDO Clutch Calibration FFR STEP 11

## Systems supported by ECReader (up to V4,90)

### TRUCKS




























**MAN**

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 TG-S	CHASSIS NETWORK	35.400 (08-..)	VDO Accelerator pedal calibration FFR STE
 TG-S	CHASSIS NETWORK	35.400 (08-..)	VDO Clutch Calibration FFR STEP 11
 TG-S	CHASSIS NETWORK	35.440 (08-..)	VDO Accelerator pedal calibration FFR STE
 TG-S	CHASSIS NETWORK	35.440 (08-..)	VDO Clutch Calibration FFR STEP 11
 TG-S	CHASSIS NETWORK	35.480 (08-..)	VDO Accelerator pedal calibration FFR STE
 TG-S	CHASSIS NETWORK	35.480 (08-..)	VDO Clutch Calibration FFR STEP 11
 TG-S	CHASSIS NETWORK	37.320 (08-..)	VDO Accelerator pedal calibration FFR STE
 TG-S	CHASSIS NETWORK	37.320 (08-..)	VDO Clutch Calibration FFR STEP 11
 TG-S	CHASSIS NETWORK	37.360 (08-..)	VDO Accelerator pedal calibration FFR STE
 TG-S	CHASSIS NETWORK	37.360 (08-..)	VDO Clutch Calibration FFR STEP 11
 TG-S	CHASSIS NETWORK	37.400 (08-..)	VDO Accelerator pedal calibration FFR STE
 TG-S	CHASSIS NETWORK	37.400 (08-..)	VDO Clutch Calibration FFR STEP 11
 TG-S	CHASSIS NETWORK	37.440 (08-..)	VDO Accelerator pedal calibration FFR STE
 TG-S	CHASSIS NETWORK	37.440 (08-..)	VDO Clutch Calibration FFR STEP 11
 TG-S	CHASSIS NETWORK	37.480 (08-..)	VDO Accelerator pedal calibration FFR STE
 TG-S	CHASSIS NETWORK	37.480 (08-..)	VDO Clutch Calibration FFR STEP 11
 TG-S	CHASSIS NETWORK	39.320 (08-..)	VDO Accelerator pedal calibration FFR STE
 TG-S	CHASSIS NETWORK	39.320 (08-..)	VDO Clutch Calibration FFR STEP 11
 TG-S	CHASSIS NETWORK	39.360 (08-..)	VDO Accelerator pedal calibration FFR STE
 TG-S	CHASSIS NETWORK	39.360 (08-..)	VDO Clutch Calibration FFR STEP 11
 TG-S	CHASSIS NETWORK	39.400 (08-..)	VDO Accelerator pedal calibration FFR STE
 TG-S	CHASSIS NETWORK	39.400 (08-..)	VDO Clutch Calibration FFR STEP 11
 TG-S	CHASSIS NETWORK	39.440 (08-..)	VDO Accelerator pedal calibration FFR STE
 TG-S	CHASSIS NETWORK	39.440 (08-..)	VDO Clutch Calibration FFR STEP 11
 TG-S	CHASSIS NETWORK	39.480 (08-..)	VDO Accelerator pedal calibration FFR STE
 TG-S	CHASSIS NETWORK	39.480 (08-..)	VDO Clutch Calibration FFR STEP 11
 TG-S	CHASSIS NETWORK	40.440 (08-..)	VDO Accelerator pedal calibration FFR STE

## Systems supported by ECUREADER (up to V4,90)

### TRUCKS




























**MAN**

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 TG-S	CHASSIS NETWORK	40.440 (08-..)	VDO Clutch Calibration FFR STEP 11
 TG-S	CHASSIS NETWORK	40.480 (08-..)	VDO Accelerator pedal calibration FFR STE
 TG-S	CHASSIS NETWORK	40.480 (08-..)	VDO Clutch Calibration FFR STEP 11
 TG-S	CHASSIS NETWORK	41.320 (08-..)	VDO Accelerator pedal calibration FFR STE
 TG-S	CHASSIS NETWORK	41.320 (08-..)	VDO Clutch Calibration FFR STEP 11
 TG-S	CHASSIS NETWORK	41.360 (08-..)	VDO Accelerator pedal calibration FFR STE
 TG-S	CHASSIS NETWORK	41.360 (08-..)	VDO Clutch Calibration FFR STEP 11
 TG-S	CHASSIS NETWORK	41.400 (08-..)	VDO Accelerator pedal calibration FFR STE
 TG-S	CHASSIS NETWORK	41.400 (08-..)	VDO Clutch Calibration FFR STEP 11
 TG-S	CHASSIS NETWORK	41.440 (08-..)	VDO Accelerator pedal calibration FFR STE
 TG-S	CHASSIS NETWORK	41.440 (08-..)	VDO Clutch Calibration FFR STEP 11
 TG-S	CHASSIS NETWORK	41.480 (08-..)	VDO Accelerator pedal calibration FFR STE
 TG-S	CHASSIS NETWORK	41.480 (08-..)	VDO Clutch Calibration FFR STEP 11
 TG-S	CHASSIS NETWORK	41.540 (08-..)	VDO Accelerator pedal calibration FFR STE
 TG-S	CHASSIS NETWORK	41.540 (08-..)	VDO Clutch Calibration FFR STEP 11
 TG-S	DASHBOARD	18.320 (08-..)	Stoneridge Electronics
 TG-S	DASHBOARD	18.360 (08-..)	Stoneridge Electronics
 TG-S	DASHBOARD	18.400 (08-..)	Stoneridge Electronics
 TG-S	DASHBOARD	18.440 (08-..)	Stoneridge Electronics
 TG-S	DASHBOARD	18.480 (08-..)	Stoneridge Electronics
 TG-S	DASHBOARD	24.320 (08-..)	Stoneridge Electronics
 TG-S	DASHBOARD	24.360 (08-..)	Stoneridge Electronics
 TG-S	DASHBOARD	24.400 (08-..)	Stoneridge Electronics
 TG-S	DASHBOARD	24.440 (08-..)	Stoneridge Electronics
 TG-S	DASHBOARD	24.480 (08-..)	Stoneridge Electronics
 TG-S	DASHBOARD	26.320 (08-..)	Stoneridge Electronics
 TG-S	DASHBOARD	26.360 (08-..)	Stoneridge Electronics

## Systems supported by ECReader (up to V4,90)

### TRUCKS




























**MAN**

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 TG-S	DASHBOARD	26.400 (08-..)	Stoneridge Electronics
 TG-S	DASHBOARD	26.440 (08-..)	Stoneridge Electronics
 TG-S	DASHBOARD	26.480 (08-..)	Stoneridge Electronics
 TG-S	DASHBOARD	26.540 (08-..)	Stoneridge Electronics
 TG-S	DASHBOARD	28.320 (08-..)	Stoneridge Electronics
 TG-S	DASHBOARD	28.360 (08-..)	Stoneridge Electronics
 TG-S	DASHBOARD	28.400 (08-..)	Stoneridge Electronics
 TG-S	DASHBOARD	28.440 (08-..)	Stoneridge Electronics
 TG-S	DASHBOARD	28.480 (08-..)	Stoneridge Electronics
 TG-S	DASHBOARD	33.320 (08-..)	Stoneridge Electronics
 TG-S	DASHBOARD	33.360 (08-..)	Stoneridge Electronics
 TG-S	DASHBOARD	33.400 (08-..)	Stoneridge Electronics
 TG-S	DASHBOARD	33.440 (08-..)	Stoneridge Electronics
 TG-S	DASHBOARD	33.480 (08-..)	Stoneridge Electronics
 TG-S	DASHBOARD	33.540 (08-..)	Stoneridge Electronics
 TG-S	DASHBOARD	35.320 (08-..)	Stoneridge Electronics
 TG-S	DASHBOARD	35.360 (08-..)	Stoneridge Electronics
 TG-S	DASHBOARD	35.400 (08-..)	Stoneridge Electronics
 TG-S	DASHBOARD	35.440 (08-..)	Stoneridge Electronics
 TG-S	DASHBOARD	35.480 (08-..)	Stoneridge Electronics
 TG-S	DASHBOARD	37.320 (08-..)	Stoneridge Electronics
 TG-S	DASHBOARD	37.360 (08-..)	Stoneridge Electronics
 TG-S	DASHBOARD	37.400 (08-..)	Stoneridge Electronics
 TG-S	DASHBOARD	37.440 (08-..)	Stoneridge Electronics
 TG-S	DASHBOARD	37.480 (08-..)	Stoneridge Electronics
 TG-S	DASHBOARD	39.320 (08-..)	Stoneridge Electronics
 TG-S	DASHBOARD	39.360 (08-..)	Stoneridge Electronics

## Systems supported by ECReader (up to V4,90)

### TRUCKS




























**MAN**

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 TG-S	DASHBOARD	39.400 (08-..)	Stoneridge Electronics
 TG-S	DASHBOARD	39.440 (08-..)	Stoneridge Electronics
 TG-S	DASHBOARD	39.480 (08-..)	Stoneridge Electronics
 TG-S	DASHBOARD	40.440 (08-..)	Stoneridge Electronics
 TG-S	DASHBOARD	40.480 (08-..)	Stoneridge Electronics
 TG-S	DASHBOARD	41.320 (08-..)	Stoneridge Electronics
 TG-S	DASHBOARD	41.360 (08-..)	Stoneridge Electronics
 TG-S	DASHBOARD	41.400 (08-..)	Stoneridge Electronics
 TG-S	DASHBOARD	41.440 (08-..)	Stoneridge Electronics
 TG-S	DASHBOARD	41.480 (08-..)	Stoneridge Electronics
 TG-S	DASHBOARD	41.540 (08-..)	Stoneridge Electronics
 TG-S	ENGINE MANAGEME	18.320 (08-..)	Bosch EDC 7 C32
 TG-S	ENGINE MANAGEME	18.360 (08-..)	Bosch EDC 7 C32
 TG-S	ENGINE MANAGEME	18.400 (08-..)	Bosch EDC 7 C32
 TG-S	ENGINE MANAGEME	18.440 (08-..)	Bosch EDC 7 C32
 TG-S	ENGINE MANAGEME	18.480 (08-..)	Bosch EDC 7 C32
 TG-S	ENGINE MANAGEME	24.320 (08-..)	Bosch EDC 7 C32
 TG-S	ENGINE MANAGEME	24.360 (08-..)	Bosch EDC 7 C32
 TG-S	ENGINE MANAGEME	24.400 (08-..)	Bosch EDC 7 C32
 TG-S	ENGINE MANAGEME	24.440 (08-..)	Bosch EDC 7 C32
 TG-S	ENGINE MANAGEME	24.480 (08-..)	Bosch EDC 7 C32
 TG-S	ENGINE MANAGEME	26.320 (08-..)	Bosch EDC 7 C32
 TG-S	ENGINE MANAGEME	26.360 (08-..)	Bosch EDC 7 C32
 TG-S	ENGINE MANAGEME	26.400 (08-..)	Bosch EDC 7 C32
 TG-S	ENGINE MANAGEME	26.440 (08-..)	Bosch EDC 7 C32
 TG-S	ENGINE MANAGEME	26.480 (08-..)	Bosch EDC 7 C32
 TG-S	ENGINE MANAGEME	26.540 (08-..)	Bosch EDC 7 C32

## Systems supported by ECReader (up to V4,90)

### TRUCKS



























**MAN**

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 TG-S	ENGINE MANAGEME	28.320 (08-..)	Bosch EDC 7 C32
 TG-S	ENGINE MANAGEME	28.360 (08-..)	Bosch EDC 7 C32
 TG-S	ENGINE MANAGEME	28.400 (08-..)	Bosch EDC 7 C32
 TG-S	ENGINE MANAGEME	28.440 (08-..)	Bosch EDC 7 C32
 TG-S	ENGINE MANAGEME	28.480 (08-..)	Bosch EDC 7 C32
 TG-S	ENGINE MANAGEME	33.320 (08-..)	Bosch EDC 7 C32
 TG-S	ENGINE MANAGEME	33.360 (08-..)	Bosch EDC 7 C32
 TG-S	ENGINE MANAGEME	33.400 (08-..)	Bosch EDC 7 C32
 TG-S	ENGINE MANAGEME	33.440 (08-..)	Bosch EDC 7 C32
 TG-S	ENGINE MANAGEME	33.480 (08-..)	Bosch EDC 7 C32
 TG-S	ENGINE MANAGEME	33.540 (08-..)	Bosch EDC 7 C32
 TG-S	ENGINE MANAGEME	35.320 (08-..)	Bosch EDC 7 C32
 TG-S	ENGINE MANAGEME	35.360 (08-..)	Bosch EDC 7 C32
 TG-S	ENGINE MANAGEME	35.400 (08-..)	Bosch EDC 7 C32
 TG-S	ENGINE MANAGEME	35.440 (08-..)	Bosch EDC 7 C32
 TG-S	ENGINE MANAGEME	35.480 (08-..)	Bosch EDC 7 C32
 TG-S	ENGINE MANAGEME	37.320 (08-..)	Bosch EDC 7 C32
 TG-S	ENGINE MANAGEME	37.360 (08-..)	Bosch EDC 7 C32
 TG-S	ENGINE MANAGEME	37.400 (08-..)	Bosch EDC 7 C32
 TG-S	ENGINE MANAGEME	37.440 (08-..)	Bosch EDC 7 C32
 TG-S	ENGINE MANAGEME	37.480 (08-..)	Bosch EDC 7 C32
 TG-S	ENGINE MANAGEME	39.320 (08-..)	Bosch EDC 7 C32
 TG-S	ENGINE MANAGEME	39.360 (08-..)	Bosch EDC 7 C32
 TG-S	ENGINE MANAGEME	39.400 (08-..)	Bosch EDC 7 C32
 TG-S	ENGINE MANAGEME	39.440 (08-..)	Bosch EDC 7 C32
 TG-S	ENGINE MANAGEME	39.480 (08-..)	Bosch EDC 7 C32
 TG-S	ENGINE MANAGEME	40.440 (08-..)	Bosch EDC 7 C32

## Systems supported by ECReader (up to V4,90)

### TRUCKS




























**MAN**

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 TG-S	ENGINE MANAGEME	40.480 (08-..)	Bosch EDC 7 C32
 TG-S	ENGINE MANAGEME	41.320 (08-..)	Bosch EDC 7 C32
 TG-S	ENGINE MANAGEME	41.360 (08-..)	Bosch EDC 7 C32
 TG-S	ENGINE MANAGEME	41.400 (08-..)	Bosch EDC 7 C32
 TG-S	ENGINE MANAGEME	41.440 (08-..)	Bosch EDC 7 C32
 TG-S	ENGINE MANAGEME	41.480 (08-..)	Bosch EDC 7 C32
 TG-S	ENGINE MANAGEME	41.540 (08-..)	Bosch EDC 7 C32
 TG-X	AUX. HEATING	18.360 (08-..)	Eberspacher Airtronic D2/D4
 TG-X	AUX. HEATING	18.400 (08-..)	Eberspacher Airtronic D2/D4
 TG-X	AUX. HEATING	18.440 (08-..)	Eberspacher Airtronic D2/D4
 TG-X	AUX. HEATING	18.480 (08-..)	Eberspacher Airtronic D2/D4
 TG-X	AUX. HEATING	18.540 (08-..)	Eberspacher Airtronic D2/D4
 TG-X	AUX. HEATING	18.680 (08-..)	Eberspacher Airtronic D2/D4
 TG-X	AUX. HEATING	24.360 (08-..)	Eberspacher Airtronic D2/D4
 TG-X	AUX. HEATING	24.400 (08-..)	Eberspacher Airtronic D2/D4
 TG-X	AUX. HEATING	24.440 (08-..)	Eberspacher Airtronic D2/D4
 TG-X	AUX. HEATING	24.480 (08-..)	Eberspacher Airtronic D2/D4
 TG-X	AUX. HEATING	24.540 (08-..)	Eberspacher Airtronic D2/D4
 TG-X	AUX. HEATING	26.360 (08-..)	Eberspacher Airtronic D2/D4
 TG-X	AUX. HEATING	26.400 (08-..)	Eberspacher Airtronic D2/D4
 TG-X	AUX. HEATING	26.440 (08-..)	Eberspacher Airtronic D2/D4
 TG-X	AUX. HEATING	26.480 (08-..)	Eberspacher Airtronic D2/D4
 TG-X	AUX. HEATING	26.540 (08-..)	Eberspacher Airtronic D2/D4
 TG-X	AUX. HEATING	28.360 (08-..)	Eberspacher Airtronic D2/D4
 TG-X	AUX. HEATING	28.400 (08-..)	Eberspacher Airtronic D2/D4
 TG-X	AUX. HEATING	28.440 (08-..)	Eberspacher Airtronic D2/D4

## Systems supported by ECUREADER (up to V4,90)

### TRUCKS



























**MAN**

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 TG-X	AUX. HEATING	28.480 (08-..)	Eberspacher Airtronic D2/D4
 TG-X	AUX. HEATING	28.540 (08-..)	Eberspacher Airtronic D2/D4
 TG-X	AUX. HEATING	33.360 (08-..)	Eberspacher Airtronic D2/D4
 TG-X	AUX. HEATING	33.400 (08-..)	Eberspacher Airtronic D2/D4
 TG-X	AUX. HEATING	33.440 (08-..)	Eberspacher Airtronic D2/D4
 TG-X	AUX. HEATING	33.480 (08-..)	Eberspacher Airtronic D2/D4
 TG-X	AUX. HEATING	33.680 (08-..)	Eberspacher Airtronic D2/D4
 TG-X	AUX. HEATING	41.540 (08-..)	Eberspacher Airtronic D2/D4
 TG-X	AUX. HEATING	41.680 (08-..)	Eberspacher Airtronic D2/D4
 TG-X	BRAKE POWER SUP	18.360 (08-..)	ZF Intarder
 TG-X	BRAKE POWER SUP	18.400 (08-..)	ZF Intarder
 TG-X	BRAKE POWER SUP	18.440 (08-..)	ZF Intarder
 TG-X	BRAKE POWER SUP	18.480 (08-..)	ZF Intarder
 TG-X	BRAKE POWER SUP	18.540 (08-..)	ZF Intarder
 TG-X	BRAKE POWER SUP	18.680 (08-..)	ZF Intarder
 TG-X	BRAKE POWER SUP	24.360 (08-..)	ZF Intarder
 TG-X	BRAKE POWER SUP	24.400 (08-..)	ZF Intarder
 TG-X	BRAKE POWER SUP	24.440 (08-..)	ZF Intarder
 TG-X	BRAKE POWER SUP	24.480 (08-..)	ZF Intarder
 TG-X	BRAKE POWER SUP	24.540 (08-..)	ZF Intarder
 TG-X	BRAKE POWER SUP	26.360 (08-..)	ZF Intarder
 TG-X	BRAKE POWER SUP	26.400 (08-..)	ZF Intarder
 TG-X	BRAKE POWER SUP	26.440 (08-..)	ZF Intarder
 TG-X	BRAKE POWER SUP	26.480 (08-..)	ZF Intarder
 TG-X	BRAKE POWER SUP	26.540 (08-..)	ZF Intarder
 TG-X	BRAKE POWER SUP	28.360 (08-..)	ZF Intarder
 TG-X	BRAKE POWER SUP	28.400 (08-..)	ZF Intarder

## Systems supported by ECUREADER (up to V4,90)

### TRUCKS




























**MAN**

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 TG-X	BRAKE POWER SUP	28.440 (08-..)	ZF Intarder
 TG-X	BRAKE POWER SUP	28.480 (08-..)	ZF Intarder
 TG-X	BRAKE POWER SUP	28.540 (08-..)	ZF Intarder
 TG-X	BRAKE POWER SUP	33.360 (08-..)	ZF Intarder
 TG-X	BRAKE POWER SUP	33.400 (08-..)	ZF Intarder
 TG-X	BRAKE POWER SUP	33.440 (08-..)	ZF Intarder
 TG-X	BRAKE POWER SUP	33.480 (08-..)	ZF Intarder
 TG-X	BRAKE POWER SUP	33.680 (08-..)	ZF Intarder
 TG-X	BRAKE POWER SUP	41.540 (08-..)	ZF Intarder
 TG-X	BRAKE POWER SUP	41.680 (08-..)	ZF Intarder
 TG-X	BRAKE SYS. MANAG	18.360 (08-..)	Knorr EBS 5
 TG-X	BRAKE SYS. MANAG	18.400 (08-..)	Knorr EBS 5
 TG-X	BRAKE SYS. MANAG	18.440 (08-..)	Knorr EBS 5
 TG-X	BRAKE SYS. MANAG	18.480 (08-..)	Knorr EBS 5
 TG-X	BRAKE SYS. MANAG	18.540 (08-..)	Knorr EBS 5
 TG-X	BRAKE SYS. MANAG	18.680 (08-..)	Knorr EBS 5
 TG-X	BRAKE SYS. MANAG	24.360 (08-..)	Knorr EBS 5
 TG-X	BRAKE SYS. MANAG	24.400 (08-..)	Knorr EBS 5
 TG-X	BRAKE SYS. MANAG	24.440 (08-..)	Knorr EBS 5
 TG-X	BRAKE SYS. MANAG	24.480 (08-..)	Knorr EBS 5
 TG-X	BRAKE SYS. MANAG	24.540 (08-..)	Knorr EBS 5
 TG-X	BRAKE SYS. MANAG	26.360 (08-..)	Knorr EBS 5
 TG-X	BRAKE SYS. MANAG	26.400 (08-..)	Knorr EBS 5
 TG-X	BRAKE SYS. MANAG	26.440 (08-..)	Knorr EBS 5
 TG-X	BRAKE SYS. MANAG	26.480 (08-..)	Knorr EBS 5
 TG-X	BRAKE SYS. MANAG	26.540 (08-..)	Knorr EBS 5
 TG-X	BRAKE SYS. MANAG	28.360 (08-..)	Knorr EBS 5

## Systems supported by ECReader (up to V4,90)

### TRUCKS




























**MAN**

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 TG-X	BRAKE SYS. MANAG	28.400 (08-..)	Knorr EBS 5
 TG-X	BRAKE SYS. MANAG	28.440 (08-..)	Knorr EBS 5
 TG-X	BRAKE SYS. MANAG	28.480 (08-..)	Knorr EBS 5
 TG-X	BRAKE SYS. MANAG	28.540 (08-..)	Knorr EBS 5
 TG-X	BRAKE SYS. MANAG	33.360 (08-..)	Knorr EBS 5
 TG-X	BRAKE SYS. MANAG	33.400 (08-..)	Knorr EBS 5
 TG-X	BRAKE SYS. MANAG	33.440 (08-..)	Knorr EBS 5
 TG-X	BRAKE SYS. MANAG	33.480 (08-..)	Knorr EBS 5
 TG-X	BRAKE SYS. MANAG	33.680 (08-..)	Knorr EBS 5
 TG-X	BRAKE SYS. MANAG	41.540 (08-..)	Knorr EBS 5
 TG-X	BRAKE SYS. MANAG	41.680 (08-..)	Knorr EBS 5
 TG-X	CHASSIS NETWORK	18.360 (08-..)	VDO Accelerator pedal calibration FFR STE
 TG-X	CHASSIS NETWORK	18.360 (08-..)	VDO Clutch Calibration FFR STEP 11
 TG-X	CHASSIS NETWORK	18.400 (08-..)	VDO Accelerator pedal calibration FFR STE
 TG-X	CHASSIS NETWORK	18.400 (08-..)	VDO Clutch Calibration FFR STEP 11
 TG-X	CHASSIS NETWORK	18.440 (08-..)	VDO Accelerator pedal calibration FFR STE
 TG-X	CHASSIS NETWORK	18.440 (08-..)	VDO Clutch Calibration FFR STEP 11
 TG-X	CHASSIS NETWORK	18.480 (08-..)	VDO Accelerator pedal calibration FFR STE
 TG-X	CHASSIS NETWORK	18.480 (08-..)	VDO Clutch Calibration FFR STEP 11
 TG-X	CHASSIS NETWORK	18.540 (08-..)	VDO Accelerator pedal calibration FFR STE
 TG-X	CHASSIS NETWORK	18.540 (08-..)	VDO Clutch Calibration FFR STEP 11
 TG-X	CHASSIS NETWORK	18.680 (08-..)	VDO Accelerator pedal calibration FFR STE
 TG-X	CHASSIS NETWORK	18.680 (08-..)	VDO Clutch Calibration FFR STEP 11
 TG-X	CHASSIS NETWORK	24.360 (08-..)	VDO Accelerator pedal calibration FFR STE
 TG-X	CHASSIS NETWORK	24.360 (08-..)	VDO Clutch Calibration FFR STEP 11
 TG-X	CHASSIS NETWORK	24.400 (08-..)	VDO Accelerator pedal calibration FFR STE
 TG-X	CHASSIS NETWORK	24.400 (08-..)	VDO Clutch Calibration FFR STEP 11

## Systems supported by ECReader (up to V4,90)

### TRUCKS




























**MAN**

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 TG-X	CHASSIS NETWORK	24.440 (08-..)	VDO Accelerator pedal calibration FFR STE
 TG-X	CHASSIS NETWORK	24.440 (08-..)	VDO Clutch Calibration FFR STEP 11
 TG-X	CHASSIS NETWORK	24.480 (08-..)	VDO Accelerator pedal calibration FFR STE
 TG-X	CHASSIS NETWORK	24.480 (08-..)	VDO Clutch Calibration FFR STEP 11
 TG-X	CHASSIS NETWORK	24.540 (08-..)	VDO Accelerator pedal calibration FFR STE
 TG-X	CHASSIS NETWORK	24.540 (08-..)	VDO Clutch Calibration FFR STEP 11
 TG-X	CHASSIS NETWORK	26.360 (08-..)	VDO Accelerator pedal calibration FFR STE
 TG-X	CHASSIS NETWORK	26.360 (08-..)	VDO Clutch Calibration FFR STEP 11
 TG-X	CHASSIS NETWORK	26.400 (08-..)	VDO Accelerator pedal calibration FFR STE
 TG-X	CHASSIS NETWORK	26.400 (08-..)	VDO Clutch Calibration FFR STEP 11
 TG-X	CHASSIS NETWORK	26.440 (08-..)	VDO Accelerator pedal calibration FFR STE
 TG-X	CHASSIS NETWORK	26.440 (08-..)	VDO Clutch Calibration FFR STEP 11
 TG-X	CHASSIS NETWORK	26.480 (08-..)	VDO Accelerator pedal calibration FFR STE
 TG-X	CHASSIS NETWORK	26.480 (08-..)	VDO Clutch Calibration FFR STEP 11
 TG-X	CHASSIS NETWORK	26.540 (08-..)	VDO Accelerator pedal calibration FFR STE
 TG-X	CHASSIS NETWORK	26.540 (08-..)	VDO Clutch Calibration FFR STEP 11
 TG-X	CHASSIS NETWORK	28.360 (08-..)	VDO Accelerator pedal calibration FFR STE
 TG-X	CHASSIS NETWORK	28.360 (08-..)	VDO Clutch Calibration FFR STEP 11
 TG-X	CHASSIS NETWORK	28.400 (08-..)	VDO Accelerator pedal calibration FFR STE
 TG-X	CHASSIS NETWORK	28.400 (08-..)	VDO Clutch Calibration FFR STEP 11
 TG-X	CHASSIS NETWORK	28.440 (08-..)	VDO Accelerator pedal calibration FFR STE
 TG-X	CHASSIS NETWORK	28.440 (08-..)	VDO Clutch Calibration FFR STEP 11
 TG-X	CHASSIS NETWORK	28.480 (08-..)	VDO Accelerator pedal calibration FFR STE
 TG-X	CHASSIS NETWORK	28.480 (08-..)	VDO Clutch Calibration FFR STEP 11
 TG-X	CHASSIS NETWORK	28.540 (08-..)	VDO Accelerator pedal calibration FFR STE
 TG-X	CHASSIS NETWORK	28.540 (08-..)	VDO Clutch Calibration FFR STEP 11
 TG-X	CHASSIS NETWORK	33.360 (08-..)	VDO Accelerator pedal calibration FFR STE

## Systems supported by ECUREADER (up to V4,90)

### TRUCKS




























**MAN**

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 TG-X	CHASSIS NETWORK	33.360 (08-..)	VDO Clutch Calibration FFR STEP 11
 TG-X	CHASSIS NETWORK	33.400 (08-..)	VDO Accelerator pedal calibration FFR STE
 TG-X	CHASSIS NETWORK	33.400 (08-..)	VDO Clutch Calibration FFR STEP 11
 TG-X	CHASSIS NETWORK	33.440 (08-..)	VDO Accelerator pedal calibration FFR STE
 TG-X	CHASSIS NETWORK	33.440 (08-..)	VDO Clutch Calibration FFR STEP 11
 TG-X	CHASSIS NETWORK	33.480 (08-..)	VDO Accelerator pedal calibration FFR STE
 TG-X	CHASSIS NETWORK	33.480 (08-..)	VDO Clutch Calibration FFR STEP 11
 TG-X	CHASSIS NETWORK	33.680 (08-..)	VDO Accelerator pedal calibration FFR STE
 TG-X	CHASSIS NETWORK	33.680 (08-..)	VDO Clutch Calibration FFR STEP 11
 TG-X	CHASSIS NETWORK	41.540 (08-..)	VDO Accelerator pedal calibration FFR STE
 TG-X	CHASSIS NETWORK	41.540 (08-..)	VDO Clutch Calibration FFR STEP 11
 TG-X	CHASSIS NETWORK	41.680 (08-..)	VDO Accelerator pedal calibration FFR STE
 TG-X	CHASSIS NETWORK	41.680 (08-..)	VDO Clutch Calibration FFR STEP 11
 TG-X	DASHBOARD	18.360 (08-..)	Stoneridge Electronics
 TG-X	DASHBOARD	18.400 (08-..)	Stoneridge Electronics
 TG-X	DASHBOARD	18.440 (08-..)	Stoneridge Electronics
 TG-X	DASHBOARD	18.480 (08-..)	Stoneridge Electronics
 TG-X	DASHBOARD	18.540 (08-..)	Stoneridge Electronics
 TG-X	DASHBOARD	18.680 (08-..)	Stoneridge Electronics
 TG-X	DASHBOARD	24.360 (08-..)	Stoneridge Electronics
 TG-X	DASHBOARD	24.400 (08-..)	Stoneridge Electronics
 TG-X	DASHBOARD	24.440 (08-..)	Stoneridge Electronics
 TG-X	DASHBOARD	24.480 (08-..)	Stoneridge Electronics
 TG-X	DASHBOARD	24.540 (08-..)	Stoneridge Electronics
 TG-X	DASHBOARD	26.360 (08-..)	Stoneridge Electronics
 TG-X	DASHBOARD	26.400 (08-..)	Stoneridge Electronics
 TG-X	DASHBOARD	26.440 (08-..)	Stoneridge Electronics

## Systems supported by ECReader (up to V4,90)

### TRUCKS




























**MAN**

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 TG-X	DASHBOARD	26.480 (08-..)	Stoneridge Electronics
 TG-X	DASHBOARD	26.540 (08-..)	Stoneridge Electronics
 TG-X	DASHBOARD	28.360 (08-..)	Stoneridge Electronics
 TG-X	DASHBOARD	28.400 (08-..)	Stoneridge Electronics
 TG-X	DASHBOARD	28.440 (08-..)	Stoneridge Electronics
 TG-X	DASHBOARD	28.480 (08-..)	Stoneridge Electronics
 TG-X	DASHBOARD	28.540 (08-..)	Stoneridge Electronics
 TG-X	DASHBOARD	33.360 (08-..)	Stoneridge Electronics
 TG-X	DASHBOARD	33.400 (08-..)	Stoneridge Electronics
 TG-X	DASHBOARD	33.440 (08-..)	Stoneridge Electronics
 TG-X	DASHBOARD	33.480 (08-..)	Stoneridge Electronics
 TG-X	DASHBOARD	33.680 (08-..)	Stoneridge Electronics
 TG-X	DASHBOARD	41.540 (08-..)	Stoneridge Electronics
 TG-X	DASHBOARD	41.680 (08-..)	Stoneridge Electronics
 TG-X	ENGINE MANAGEME	18.360 (08-..)	Bosch EDC 7 C32
 TG-X	ENGINE MANAGEME	18.400 (08-..)	Bosch EDC 7 C32
 TG-X	ENGINE MANAGEME	18.440 (08-..)	Bosch EDC 7 C32
 TG-X	ENGINE MANAGEME	18.480 (08-..)	Bosch EDC 7 C32
 TG-X	ENGINE MANAGEME	18.540 (08-..)	Bosch EDC 7 C32
 TG-X	ENGINE MANAGEME	18.680 (08-..)	Bosch EDC 7 C32
 TG-X	ENGINE MANAGEME	24.360 (08-..)	Bosch EDC 7 C32
 TG-X	ENGINE MANAGEME	24.400 (08-..)	Bosch EDC 7 C32
 TG-X	ENGINE MANAGEME	24.440 (08-..)	Bosch EDC 7 C32
 TG-X	ENGINE MANAGEME	24.480 (08-..)	Bosch EDC 7 C32
 TG-X	ENGINE MANAGEME	24.540 (08-..)	Bosch EDC 7 C32
 TG-X	ENGINE MANAGEME	26.360 (08-..)	Bosch EDC 7 C32
 TG-X	ENGINE MANAGEME	26.400 (08-..)	Bosch EDC 7 C32

## Systems supported by ECUreader (up to V4,90)

### TRUCKS




























**MAN**

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 TG-X	ENGINE MANAGEME	26.440 (08-..)	Bosch EDC 7 C32
 TG-X	ENGINE MANAGEME	26.480 (08-..)	Bosch EDC 7 C32
 TG-X	ENGINE MANAGEME	26.540 (08-..)	Bosch EDC 7 C32
 TG-X	ENGINE MANAGEME	28.360 (08-..)	Bosch EDC 7 C32
 TG-X	ENGINE MANAGEME	28.400 (08-..)	Bosch EDC 7 C32
 TG-X	ENGINE MANAGEME	28.440 (08-..)	Bosch EDC 7 C32
 TG-X	ENGINE MANAGEME	28.480 (08-..)	Bosch EDC 7 C32
 TG-X	ENGINE MANAGEME	28.540 (08-..)	Bosch EDC 7 C32
 TG-X	ENGINE MANAGEME	33.360 (08-..)	Bosch EDC 7 C32
 TG-X	ENGINE MANAGEME	33.400 (08-..)	Bosch EDC 7 C32
 TG-X	ENGINE MANAGEME	33.440 (08-..)	Bosch EDC 7 C32
 TG-X	ENGINE MANAGEME	33.480 (08-..)	Bosch EDC 7 C32
 TG-X	ENGINE MANAGEME	33.680 (08-..)	Bosch EDC 7 C32
 TG-X	ENGINE MANAGEME	41.540 (08-..)	Bosch EDC 7 C32
 TG-X	ENGINE MANAGEME	41.680 (08-..)	Bosch EDC 7 C32
 TG-X	MAINTENANCE SYST	18.360 (08-..)	
 TG-X	MAINTENANCE SYST	18.400 (08-..)	
 TG-X	MAINTENANCE SYST	18.440 (08-..)	
 TG-X	MAINTENANCE SYST	18.480 (08-..)	
 TG-X	MAINTENANCE SYST	18.540 (08-..)	
 TG-X	MAINTENANCE SYST	18.680 (08-..)	
 TG-X	MAINTENANCE SYST	24.360 (08-..)	
 TG-X	MAINTENANCE SYST	24.400 (08-..)	
 TG-X	MAINTENANCE SYST	24.440 (08-..)	
 TG-X	MAINTENANCE SYST	24.480 (08-..)	
 TG-X	MAINTENANCE SYST	24.540 (08-..)	
 TG-X	MAINTENANCE SYST	26.360 (08-..)	

## Systems supported by ECUreader (up to V4,90)

### TRUCKS

























**MAN**

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 TG-X	MAINTENANCE SYST	26.400 (08-..)	
 TG-X	MAINTENANCE SYST	26.440 (08-..)	
 TG-X	MAINTENANCE SYST	26.480 (08-..)	
 TG-X	MAINTENANCE SYST	26.540 (08-..)	
 TG-X	MAINTENANCE SYST	28.360 (08-..)	
 TG-X	MAINTENANCE SYST	28.400 (08-..)	
 TG-X	MAINTENANCE SYST	28.440 (08-..)	
 TG-X	MAINTENANCE SYST	28.480 (08-..)	
 TG-X	MAINTENANCE SYST	28.540 (08-..)	
 TG-X	MAINTENANCE SYST	33.360 (08-..)	
 TG-X	MAINTENANCE SYST	33.400 (08-..)	
 TG-X	MAINTENANCE SYST	33.440 (08-..)	
 TG-X	MAINTENANCE SYST	33.480 (08-..)	
 TG-X	MAINTENANCE SYST	33.680 (08-..)	
 TG-X	MAINTENANCE SYST	41.540 (08-..)	
 TG-X	MAINTENANCE SYST	41.680 (08-..)	
 TG-X	SUSPENSION CONTR	18.360 (08-..)	Wabco ECAS 2
 TG-X	SUSPENSION CONTR	18.400 (08-..)	Wabco ECAS 2
 TG-X	SUSPENSION CONTR	18.440 (08-..)	Wabco ECAS 2
 TG-X	SUSPENSION CONTR	18.480 (08-..)	Wabco ECAS 2
 TG-X	SUSPENSION CONTR	18.540 (08-..)	Wabco ECAS 2
 TG-X	SUSPENSION CONTR	18.680 (08-..)	Wabco ECAS 2
 TG-X	SUSPENSION CONTR	24.360 (08-..)	Wabco ECAS 2
 TG-X	SUSPENSION CONTR	24.400 (08-..)	Wabco ECAS 2
 TG-X	SUSPENSION CONTR	24.440 (08-..)	Wabco ECAS 2
 TG-X	SUSPENSION CONTR	24.480 (08-..)	Wabco ECAS 2
 TG-X	SUSPENSION CONTR	24.540 (08-..)	Wabco ECAS 2

## Systems supported by ECUreader (up to V4,90)

### TRUCKS





**MAN**

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 TG-X	SUSPENSION CONTR	26.360 (08-..)	Wabco ECAS 2
 TG-X	SUSPENSION CONTR	26.400 (08-..)	Wabco ECAS 2
 TG-X	SUSPENSION CONTR	26.440 (08-..)	Wabco ECAS 2
 TG-X	SUSPENSION CONTR	26.480 (08-..)	Wabco ECAS 2
 TG-X	SUSPENSION CONTR	26.540 (08-..)	Wabco ECAS 2
 TG-X	SUSPENSION CONTR	28.360 (08-..)	Wabco ECAS 2
 TG-X	SUSPENSION CONTR	28.400 (08-..)	Wabco ECAS 2
 TG-X	SUSPENSION CONTR	28.440 (08-..)	Wabco ECAS 2
 TG-X	SUSPENSION CONTR	28.480 (08-..)	Wabco ECAS 2
 TG-X	SUSPENSION CONTR	28.540 (08-..)	Wabco ECAS 2
 TG-X	SUSPENSION CONTR	33.360 (08-..)	Wabco ECAS 2
 TG-X	SUSPENSION CONTR	33.400 (08-..)	Wabco ECAS 2
 TG-X	SUSPENSION CONTR	33.440 (08-..)	Wabco ECAS 2
 TG-X	SUSPENSION CONTR	33.480 (08-..)	Wabco ECAS 2
 TG-X	SUSPENSION CONTR	33.680 (08-..)	Wabco ECAS 2
 TG-X	SUSPENSION CONTR	41.540 (08-..)	Wabco ECAS 2
 TG-X	SUSPENSION CONTR	41.680 (08-..)	Wabco ECAS 2
 U90	ABS		BOSCH ABS/ASR 2E
 U90	ABS		BOSCH ABS/ASR 2M Stufe 1
 U90	ABS		BOSCH ABS/ASR 3E
 U90	ABS		BOSCH/KNORR ABS Ci 12
 U90	ABS		KNORR ABS
 U90	CLIMA		Konvekta
 U90	CLIMA		WABCO ATC

## Systems supported by ECUreader (up to V4,90)

### TRUCKS



























### MAN Bus

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 EM220	ABS		BOSCH ABS Ci 12
 EM220	ABS		BOSCH ABS/ASR 2E
 EM220	ABS		BOSCH ABS/ASR 2M
 EM220	ABS		BOSCH ABS/ASR 2M Stufe 1
 EM220	ABS		BOSCH ABS/ASR 3E
 EM220	ABS		KNORR ABS
 EM220	ABS		KNORR ABS KB3AL
 EM220	CLIMA		Konvekta
 EM220	CLIMA		WABCO ATC
 EM222	ABS		BOSCH ABS Ci 12
 EM222	ABS		BOSCH ABS/ASR 2E
 EM222	ABS		BOSCH ABS/ASR 2M
 EM222	ABS		BOSCH ABS/ASR 2M Stufe 1
 EM222	ABS		BOSCH ABS/ASR 3E
 EM222	ABS		KNORR ABS
 EM222	ABS		KNORR ABS KB3AL
 EM222	CLIMA		Konvekta
 EM222	CLIMA		WABCO ATC
 EM223	ABS		BOSCH ABS Ci 12
 EM223	ABS		BOSCH ABS/ASR 2E
 EM223	ABS		BOSCH ABS/ASR 2M
 EM223	ABS		BOSCH ABS/ASR 2M Stufe 1
 EM223	ABS		BOSCH ABS/ASR 3E
 EM223	ABS		KNORR ABS
 EM223	ABS		KNORR ABS KB3AL
 EM223	CLIMA		Konvekta

## Systems supported by ECUREADER (up to V4,90)

### TRUCKS



























### MAN Bus

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 EM223	CLIMA		WABCO ATC
 ND222	ABS		BOSCH ABS Ci 12
 ND222	ABS		BOSCH ABS/ASR 2E
 ND222	ABS		BOSCH ABS/ASR 2M
 ND222	ABS		BOSCH ABS/ASR 2M Stufe 1
 ND222	ABS		BOSCH ABS/ASR 3E
 ND222	ABS		KNORR ABS
 ND222	ABS		KNORR ABS KB3AL
 ND222	CLIMA		Konvekta
 ND222	CLIMA		WABCO ATC
 NG/SG 263 Lion's Classic	ABS		BOSCH ABS Ci 12
 NG/SG 263 Lion's Classic	ABS		BOSCH ABS/ASR 2E
 NG/SG 263 Lion's Classic	ABS		BOSCH ABS/ASR 2M
 NG/SG 263 Lion's Classic	ABS		BOSCH ABS/ASR 2M Stufe 1
 NG/SG 263 Lion's Classic	ABS		BOSCH ABS/ASR 3E
 NG/SG 263 Lion's Classic	ABS		KNORR ABS
 NG/SG 263 Lion's Classic	ABS		KNORR ABS KB3AL
 NG/SG 263 Lion's Classic	CLIMA		Konvekta
 NG/SG 263 Lion's Classic	CLIMA		WABCO ATC
 NG/SG 313 Lion's Classic	ABS		BOSCH ABS Ci 12
 NG/SG 313 Lion's Classic	ABS		BOSCH ABS/ASR 2E
 NG/SG 313 Lion's Classic	ABS		BOSCH ABS/ASR 2M
 NG/SG 313 Lion's Classic	ABS		BOSCH ABS/ASR 2M Stufe 1
 NG/SG 313 Lion's Classic	ABS		BOSCH ABS/ASR 3E
 NG/SG 313 Lion's Classic	ABS		KNORR ABS
 NG/SG 313 Lion's Classic	ABS		KNORR ABS KB3AL

## Systems supported by ECUreader (up to V4,90)

### TRUCKS



























### MAN Bus

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 NG/SG 313 Lion's Classic	CLIMA		Konvekta
 NG/SG 313 Lion's Classic	CLIMA		WABCO ATC
 NG262	ABS		BOSCH ABS Ci 12
 NG262	ABS		BOSCH ABS/ASR 2E
 NG262	ABS		BOSCH ABS/ASR 2M
 NG262	ABS		BOSCH ABS/ASR 2M Stufe 1
 NG262	ABS		BOSCH ABS/ASR 3E
 NG262	ABS		KNORR ABS
 NG262	ABS		KNORR ABS KB3AL
 NG262	CLIMA		Konvekta
 NG262	CLIMA		WABCO ATC
 NL 223 Lion's Classic	ABS		BOSCH ABS Ci 12
 NL 223 Lion's Classic	ABS		BOSCH ABS/ASR 2E
 NL 223 Lion's Classic	ABS		BOSCH ABS/ASR 2M
 NL 223 Lion's Classic	ABS		BOSCH ABS/ASR 2M Stufe 1
 NL 223 Lion's Classic	ABS		BOSCH ABS/ASR 3E
 NL 223 Lion's Classic	ABS		KNORR ABS
 NL 223 Lion's Classic	ABS		KNORR ABS KB3AL
 NL 223 Lion's Classic	CLIMA		Konvekta
 NL 223 Lion's Classic	CLIMA		WABCO ATC
 NL 243 Lion's Classic	ABS		BOSCH ABS Ci 12
 NL 243 Lion's Classic	ABS		BOSCH ABS/ASR 2E
 NL 243 Lion's Classic	ABS		BOSCH ABS/ASR 2M
 NL 243 Lion's Classic	ABS		BOSCH ABS/ASR 2M Stufe 1
 NL 243 Lion's Classic	ABS		BOSCH ABS/ASR 3E
 NL 243 Lion's Classic	ABS		KNORR ABS

## Systems supported by ECUREADER (up to V4,90)

### TRUCKS



























### MAN Bus

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 NL 243 Lion's Classic	ABS		KNORR ABS KB3AL
 NL 243 Lion's Classic	CLIMA		Konvekta
 NL 243 Lion's Classic	CLIMA		WABCO ATC
 NL 263 Lion's Classic	ABS		BOSCH ABS Ci 12
 NL 263 Lion's Classic	ABS		BOSCH ABS/ASR 2E
 NL 263 Lion's Classic	ABS		BOSCH ABS/ASR 2M
 NL 263 Lion's Classic	ABS		BOSCH ABS/ASR 2M Stufe 1
 NL 263 Lion's Classic	ABS		BOSCH ABS/ASR 3E
 NL 263 Lion's Classic	ABS		KNORR ABS
 NL 263 Lion's Classic	ABS		KNORR ABS KB3AL
 NL 263 Lion's Classic	CLIMA		Konvekta
 NL 263 Lion's Classic	CLIMA		WABCO ATC
 NL 283 Lion's Classic	ABS		BOSCH ABS Ci 12
 NL 283 Lion's Classic	ABS		BOSCH ABS/ASR 2E
 NL 283 Lion's Classic	ABS		BOSCH ABS/ASR 2M
 NL 283 Lion's Classic	ABS		BOSCH ABS/ASR 2M Stufe 1
 NL 283 Lion's Classic	ABS		BOSCH ABS/ASR 3E
 NL 283 Lion's Classic	ABS		KNORR ABS
 NL 283 Lion's Classic	ABS		KNORR ABS KB3AL
 NL 283 Lion's Classic	CLIMA		Konvekta
 NL 283 Lion's Classic	CLIMA		WABCO ATC
 NL 313 Lion's Classic	ABS		BOSCH ABS Ci 12
 NL 313 Lion's Classic	ABS		BOSCH ABS/ASR 2E
 NL 313 Lion's Classic	ABS		BOSCH ABS/ASR 2M
 NL 313 Lion's Classic	ABS		BOSCH ABS/ASR 2M Stufe 1
 NL 313 Lion's Classic	ABS		BOSCH ABS/ASR 3E

## Systems supported by ECReader (up to V4,90)

### TRUCKS

























### MAN Bus

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 NL 313 Lion's Classic	ABS		KNORR ABS
 NL 313 Lion's Classic	ABS		KNORR ABS KB3AL
 NL 313 Lion's Classic	CLIMA		Konvekta
 NL 313 Lion's Classic	CLIMA		WABCO ATC
 NL 363 Lion's Classic	ABS		BOSCH ABS Ci 12
 NL 363 Lion's Classic	ABS		BOSCH ABS/ASR 2E
 NL 363 Lion's Classic	ABS		BOSCH ABS/ASR 2M
 NL 363 Lion's Classic	ABS		BOSCH ABS/ASR 2M Stufe 1
 NL 363 Lion's Classic	ABS		BOSCH ABS/ASR 3E
 NL 363 Lion's Classic	ABS		KNORR ABS
 NL 363 Lion's Classic	ABS		KNORR ABS KB3AL
 NL 363 Lion's Classic	CLIMA		Konvekta
 NL 363 Lion's Classic	CLIMA		WABCO ATC
 NM223	ABS		BOSCH ABS Ci 12
 NM223	ABS		BOSCH ABS/ASR 2E
 NM223	ABS		BOSCH ABS/ASR 2M
 NM223	ABS		BOSCH ABS/ASR 2M Stufe 1
 NM223	ABS		BOSCH ABS/ASR 3E
 NM223	ABS		KNORR ABS
 NM223	ABS		KNORR ABS KB3AL
 NM223	CLIMA		Konvekta
 NM223	CLIMA		WABCO ATC
 NM283	ABS		BOSCH ABS Ci 12
 NM283	ABS		BOSCH ABS/ASR 2E
 NM283	ABS		BOSCH ABS/ASR 2M
 NM283	ABS		BOSCH ABS/ASR 2M Stufe 1

## Systems supported by ECUREADER (up to V4,90)

### TRUCKS



























### MAN Bus

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 NM283	ABS		BOSCH ABS/ASR 3E
 NM283	ABS		KNORR ABS
 NM283	ABS		KNORR ABS KB3AL
 NM283	CLIMA		Konvekta
 NM283	CLIMA		WABCO ATC
 NU 263 Lion's Classic	ABS		BOSCH ABS Ci 12
 NU 263 Lion's Classic	ABS		BOSCH ABS/ASR 2E
 NU 263 Lion's Classic	ABS		BOSCH ABS/ASR 2M
 NU 263 Lion's Classic	ABS		BOSCH ABS/ASR 2M Stufe 1
 NU 263 Lion's Classic	ABS		BOSCH ABS/ASR 3E
 NU 263 Lion's Classic	ABS		KNORR ABS
 NU 263 Lion's Classic	ABS		KNORR ABS KB3AL
 NU 263 Lion's Classic	CLIMA		Konvekta
 NU 263 Lion's Classic	CLIMA		WABCO ATC
 NU 283 Lion's Classic	ABS		BOSCH ABS Ci 12
 NU 283 Lion's Classic	ABS		BOSCH ABS/ASR 2E
 NU 283 Lion's Classic	ABS		BOSCH ABS/ASR 2M
 NU 283 Lion's Classic	ABS		BOSCH ABS/ASR 2M Stufe 1
 NU 283 Lion's Classic	ABS		BOSCH ABS/ASR 3E
 NU 283 Lion's Classic	ABS		KNORR ABS
 NU 283 Lion's Classic	ABS		KNORR ABS KB3AL
 NU 283 Lion's Classic	CLIMA		Konvekta
 NU 283 Lion's Classic	CLIMA		WABCO ATC
 NU 313 Lion's Classic	ABS		BOSCH ABS Ci 12
 NU 313 Lion's Classic	ABS		BOSCH ABS/ASR 2E
 NU 313 Lion's Classic	ABS		BOSCH ABS/ASR 2M

## Systems supported by ECUREADER (up to V4,90)

### TRUCKS



























### MAN Bus

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 NU 313 Lion's Classic	ABS		BOSCH ABS/ASR 2M Stufe 1
 NU 313 Lion's Classic	ABS		BOSCH ABS/ASR 3E
 NU 313 Lion's Classic	ABS		KNORR ABS
 NU 313 Lion's Classic	ABS		KNORR ABS KB3AL
 NU 313 Lion's Classic	CLIMA		Konvekta
 NU 313 Lion's Classic	CLIMA		WABCO ATC
 NU 363 Lion's Classic	ABS		BOSCH ABS Ci 12
 NU 363 Lion's Classic	ABS		BOSCH ABS/ASR 2E
 NU 363 Lion's Classic	ABS		BOSCH ABS/ASR 2M
 NU 363 Lion's Classic	ABS		BOSCH ABS/ASR 2M Stufe 1
 NU 363 Lion's Classic	ABS		BOSCH ABS/ASR 3E
 NU 363 Lion's Classic	ABS		KNORR ABS
 NU 363 Lion's Classic	ABS		KNORR ABS KB3AL
 NU 363 Lion's Classic	CLIMA		Konvekta
 NU 363 Lion's Classic	CLIMA		WABCO ATC
 R 313 Lion's Comfort	ABS		BOSCH ABS Ci 12
 R 313 Lion's Comfort	ABS		BOSCH ABS/ASR 2E
 R 313 Lion's Comfort	ABS		BOSCH ABS/ASR 2M
 R 313 Lion's Comfort	ABS		BOSCH ABS/ASR 2M Stufe 1
 R 313 Lion's Comfort	ABS		BOSCH ABS/ASR 3E
 R 313 Lion's Comfort	ABS		KNORR ABS
 R 313 Lion's Comfort	ABS		KNORR ABS KB3AL
 R 313 Lion's Comfort	CLIMA		Konvekta
 R 313 Lion's Comfort	CLIMA		WABCO ATC
 R 363 Lion's Comfort	ABS		BOSCH ABS Ci 12
 R 363 Lion's Comfort	ABS		BOSCH ABS/ASR 2E

## Systems supported by ECUREADER (up to V4,90)

### TRUCKS



























### MAN Bus

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 R 363 Lion's Comfort	ABS		BOSCH ABS/ASR 2M
 R 363 Lion's Comfort	ABS		BOSCH ABS/ASR 2M Stufe 1
 R 363 Lion's Comfort	ABS		BOSCH ABS/ASR 3E
 R 363 Lion's Comfort	ABS		KNORR ABS
 R 363 Lion's Comfort	ABS		KNORR ABS KB3AL
 R 363 Lion's Comfort	CLIMA		Konvekta
 R 363 Lion's Comfort	CLIMA		WABCO ATC
 RH 352 Lion's Coach	ABS		BOSCH ABS Ci 12
 RH 352 Lion's Coach	ABS		BOSCH ABS/ASR 2E
 RH 352 Lion's Coach	ABS		BOSCH ABS/ASR 2M
 RH 352 Lion's Coach	ABS		BOSCH ABS/ASR 2M Stufe 1
 RH 352 Lion's Coach	ABS		BOSCH ABS/ASR 3E
 RH 352 Lion's Coach	ABS		KNORR ABS
 RH 352 Lion's Coach	ABS		KNORR ABS KB3AL
 RH 352 Lion's Coach	CLIMA		Konvekta
 RH 352 Lion's Coach	CLIMA		WABCO ATC
 RH 352 Lion's Star	ABS		BOSCH ABS Ci 12
 RH 352 Lion's Star	ABS		BOSCH ABS/ASR 2E
 RH 352 Lion's Star	ABS		BOSCH ABS/ASR 2M
 RH 352 Lion's Star	ABS		BOSCH ABS/ASR 2M Stufe 1
 RH 352 Lion's Star	ABS		BOSCH ABS/ASR 3E
 RH 352 Lion's Star	ABS		KNORR ABS
 RH 352 Lion's Star	ABS		KNORR ABS KB3AL
 RH 352 Lion's Star	CLIMA		Konvekta
 RH 352 Lion's Star	CLIMA		WABCO ATC
 RH 402 Lion's Coach	ABS		BOSCH ABS Ci 12

## Systems supported by ECUreader (up to V4,90)

### TRUCKS



























### MAN Bus

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 RH 402 Lion's Coach	ABS		BOSCH ABS/ASR 2E
 RH 402 Lion's Coach	ABS		BOSCH ABS/ASR 2M
 RH 402 Lion's Coach	ABS		BOSCH ABS/ASR 2M Stufe 1
 RH 402 Lion's Coach	ABS		BOSCH ABS/ASR 3E
 RH 402 Lion's Coach	ABS		KNORR ABS
 RH 402 Lion's Coach	ABS		KNORR ABS KB3AL
 RH 402 Lion's Coach	CLIMA		Konvekta
 RH 402 Lion's Coach	CLIMA		WABCO ATC
 RH 402 Lion's Star	ABS		BOSCH ABS Ci 12
 RH 402 Lion's Star	ABS		BOSCH ABS/ASR 2E
 RH 402 Lion's Star	ABS		BOSCH ABS/ASR 2M
 RH 402 Lion's Star	ABS		BOSCH ABS/ASR 2M Stufe 1
 RH 402 Lion's Star	ABS		BOSCH ABS/ASR 3E
 RH 402 Lion's Star	ABS		KNORR ABS
 RH 402 Lion's Star	ABS		KNORR ABS KB3AL
 RH 402 Lion's Star	CLIMA		Konvekta
 RH 402 Lion's Star	CLIMA		WABCO ATC
 RH 403 Lion's Top Coach	ABS		BOSCH ABS Ci 12
 RH 403 Lion's Top Coach	ABS		BOSCH ABS/ASR 2E
 RH 403 Lion's Top Coach	ABS		BOSCH ABS/ASR 2M
 RH 403 Lion's Top Coach	ABS		BOSCH ABS/ASR 2M Stufe 1
 RH 403 Lion's Top Coach	ABS		BOSCH ABS/ASR 3E
 RH 403 Lion's Top Coach	ABS		KNORR ABS
 RH 403 Lion's Top Coach	ABS		KNORR ABS KB3AL
 RH 403 Lion's Top Coach	CLIMA		Konvekta
 RH 403 Lion's Top Coach	CLIMA		WABCO ATC

## Systems supported by ECUreader (up to V4,90)

### TRUCKS



























### MAN Bus

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 RH 463 Lion's Star	ABS		BOSCH ABS Ci 12
 RH 463 Lion's Star	ABS		BOSCH ABS/ASR 2E
 RH 463 Lion's Star	ABS		BOSCH ABS/ASR 2M
 RH 463 Lion's Star	ABS		BOSCH ABS/ASR 2M Stufe 1
 RH 463 Lion's Star	ABS		BOSCH ABS/ASR 3E
 RH 463 Lion's Star	ABS		KNORR ABS
 RH 463 Lion's Star	ABS		KNORR ABS KB3AL
 RH 463 Lion's Star	CLIMA		Konvekta
 RH 463 Lion's Star	CLIMA		WABCO ATC
 RH 463 Lion's Top Coach	ABS		BOSCH ABS Ci 12
 RH 463 Lion's Top Coach	ABS		BOSCH ABS/ASR 2E
 RH 463 Lion's Top Coach	ABS		BOSCH ABS/ASR 2M
 RH 463 Lion's Top Coach	ABS		BOSCH ABS/ASR 2M Stufe 1
 RH 463 Lion's Top Coach	ABS		BOSCH ABS/ASR 3E
 RH 463 Lion's Top Coach	ABS		KNORR ABS
 RH 463 Lion's Top Coach	ABS		KNORR ABS KB3AL
 RH 463 Lion's Top Coach	CLIMA		Konvekta
 RH 463 Lion's Top Coach	CLIMA		WABCO ATC
 RHC 414 Lion's Coach	ABS		BOSCH ABS Ci 12
 RHC 414 Lion's Coach	ABS		BOSCH ABS/ASR 2E
 RHC 414 Lion's Coach	ABS		BOSCH ABS/ASR 2M
 RHC 414 Lion's Coach	ABS		BOSCH ABS/ASR 2M Stufe 1
 RHC 414 Lion's Coach	ABS		BOSCH ABS/ASR 3E
 RHC 414 Lion's Coach	ABS		KNORR ABS
 RHC 414 Lion's Coach	ABS		KNORR ABS KB3AL
 RHC 414 Lion's Coach	CLIMA		Konvekta

## Systems supported by ECUreader (up to V4,90)

### TRUCKS










### MAN Bus

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 RHC 414 Lion's Coach	CLIMA		WABCO ATC
 RHC 414 Lion's Top Coach	ABS		BOSCH ABS Ci 12
 RHC 414 Lion's Top Coach	ABS		BOSCH ABS/ASR 2E
 RHC 414 Lion's Top Coach	ABS		BOSCH ABS/ASR 2M
 RHC 414 Lion's Top Coach	ABS		BOSCH ABS/ASR 2M Stufe 1
 RHC 414 Lion's Top Coach	ABS		BOSCH ABS/ASR 3E
 RHC 414 Lion's Top Coach	ABS		KNORR ABS
 RHC 414 Lion's Top Coach	ABS		KNORR ABS KB3AL
 RHC 414 Lion's Top Coach	CLIMA		Konvekta
 RHC 414 Lion's Top Coach	CLIMA		WABCO ATC
 RHC 464 Lion's Coach	ABS		BOSCH ABS Ci 12
 RHC 464 Lion's Coach	ABS		BOSCH ABS/ASR 2E
 RHC 464 Lion's Coach	ABS		BOSCH ABS/ASR 2M
 RHC 464 Lion's Coach	ABS		BOSCH ABS/ASR 2M Stufe 1
 RHC 464 Lion's Coach	ABS		BOSCH ABS/ASR 3E
 RHC 464 Lion's Coach	ABS		KNORR ABS
 RHC 464 Lion's Coach	ABS		KNORR ABS KB3AL
 RHC 464 Lion's Coach	CLIMA		Konvekta
 RHC 464 Lion's Coach	CLIMA		WABCO ATC
 RHC 464 Lion's Top Coach	ABS		BOSCH ABS Ci 12
 RHC 464 Lion's Top Coach	ABS		BOSCH ABS/ASR 2E
 RHC 464 Lion's Top Coach	ABS		BOSCH ABS/ASR 2M
 RHC 464 Lion's Top Coach	ABS		BOSCH ABS/ASR 2M Stufe 1
 RHC 464 Lion's Top Coach	ABS		BOSCH ABS/ASR 3E
 RHC 464 Lion's Top Coach	ABS		KNORR ABS
 RHC 464 Lion's Top Coach	ABS		KNORR ABS KB3AL

## Systems supported by ECUREADER (up to V4,90)

### TRUCKS



























### MAN Bus

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 RHC 464 Lion's Top Coach	CLIMA		Konvekta
 RHC 464 Lion's Top Coach	CLIMA		WABCO ATC
 RHS 414 Lion's Star	ABS		BOSCH ABS Ci 12
 RHS 414 Lion's Star	ABS		BOSCH ABS/ASR 2E
 RHS 414 Lion's Star	ABS		BOSCH ABS/ASR 2M
 RHS 414 Lion's Star	ABS		BOSCH ABS/ASR 2M Stufe 1
 RHS 414 Lion's Star	ABS		BOSCH ABS/ASR 3E
 RHS 414 Lion's Star	ABS		KNORR ABS
 RHS 414 Lion's Star	ABS		KNORR ABS KB3AL
 RHS 414 Lion's Star	CLIMA		Konvekta
 RHS 414 Lion's Star	CLIMA		WABCO ATC
 RHS 414 Lion's Top Star	ABS		BOSCH ABS Ci 12
 RHS 414 Lion's Top Star	ABS		BOSCH ABS/ASR 2E
 RHS 414 Lion's Top Star	ABS		BOSCH ABS/ASR 2M
 RHS 414 Lion's Top Star	ABS		BOSCH ABS/ASR 2M Stufe 1
 RHS 414 Lion's Top Star	ABS		BOSCH ABS/ASR 3E
 RHS 414 Lion's Top Star	ABS		KNORR ABS
 RHS 414 Lion's Top Star	ABS		KNORR ABS KB3AL
 RHS 414 Lion's Top Star	CLIMA		Konvekta
 RHS 414 Lion's Top Star	CLIMA		WABCO ATC
 RHS 464 Lion's Star	ABS		BOSCH ABS Ci 12
 RHS 464 Lion's Star	ABS		BOSCH ABS/ASR 2E
 RHS 464 Lion's Star	ABS		BOSCH ABS/ASR 2M
 RHS 464 Lion's Star	ABS		BOSCH ABS/ASR 2M Stufe 1
 RHS 464 Lion's Star	ABS		BOSCH ABS/ASR 3E
 RHS 464 Lion's Star	ABS		KNORR ABS

## Systems supported by ECUreader (up to V4,90)

### TRUCKS



























### MAN Bus

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 RHS 464 Lion's Star	ABS		KNORR ABS KB3AL
 RHS 464 Lion's Star	CLIMA		Konvekta
 RHS 464 Lion's Star	CLIMA		WABCO ATC
 RHS 464 Lion's Top Star	ABS		BOSCH ABS Ci 12
 RHS 464 Lion's Top Star	ABS		BOSCH ABS/ASR 2E
 RHS 464 Lion's Top Star	ABS		BOSCH ABS/ASR 2M
 RHS 464 Lion's Top Star	ABS		BOSCH ABS/ASR 2M Stufe 1
 RHS 464 Lion's Top Star	ABS		BOSCH ABS/ASR 3E
 RHS 464 Lion's Top Star	ABS		KNORR ABS
 RHS 464 Lion's Top Star	ABS		KNORR ABS KB3AL
 RHS 464 Lion's Top Star	CLIMA		Konvekta
 RHS 464 Lion's Top Star	CLIMA		WABCO ATC
 SD202	ABS		BOSCH ABS Ci 12
 SD202	ABS		BOSCH ABS/ASR 2E
 SD202	ABS		BOSCH ABS/ASR 2M
 SD202	ABS		BOSCH ABS/ASR 2M Stufe 1
 SD202	ABS		BOSCH ABS/ASR 3E
 SD202	ABS		KNORR ABS
 SD202	ABS		KNORR ABS KB3AL
 SD202	CLIMA		Konvekta
 SD202	CLIMA		WABCO ATC
 SG 263 Lion's Classic G	ABS		BOSCH ABS Ci 12
 SG 263 Lion's Classic G	ABS		BOSCH ABS/ASR 2E
 SG 263 Lion's Classic G	ABS		BOSCH ABS/ASR 2M
 SG 263 Lion's Classic G	ABS		BOSCH ABS/ASR 2M Stufe 1
 SG 263 Lion's Classic G	ABS		BOSCH ABS/ASR 3E

## Systems supported by ECUREADER (up to V4,90)

### TRUCKS



























### MAN Bus

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 SG 263 Lion's Classic G	ABS		KNORR ABS
 SG 263 Lion's Classic G	ABS		KNORR ABS KB3AL
 SG 263 Lion's Classic G	CLIMA		Konvekta
 SG 263 Lion's Classic G	CLIMA		WABCO ATC
 SG 313 Lion's Classic G	ABS		BOSCH ABS Ci 12
 SG 313 Lion's Classic G	ABS		BOSCH ABS/ASR 2E
 SG 313 Lion's Classic G	ABS		BOSCH ABS/ASR 2M
 SG 313 Lion's Classic G	ABS		BOSCH ABS/ASR 2M Stufe 1
 SG 313 Lion's Classic G	ABS		BOSCH ABS/ASR 3E
 SG 313 Lion's Classic G	ABS		KNORR ABS
 SG 313 Lion's Classic G	ABS		KNORR ABS KB3AL
 SG 313 Lion's Classic G	CLIMA		Konvekta
 SG 313 Lion's Classic G	CLIMA		WABCO ATC
 SG292	ABS		BOSCH ABS Ci 12
 SG292	ABS		BOSCH ABS/ASR 2E
 SG292	ABS		BOSCH ABS/ASR 2M
 SG292	ABS		BOSCH ABS/ASR 2M Stufe 1
 SG292	ABS		BOSCH ABS/ASR 3E
 SG292	ABS		KNORR ABS
 SG292	ABS		KNORR ABS KB3AL
 SG292	CLIMA		Konvekta
 SG292	CLIMA		WABCO ATC
 SL 223 Lion's Classic	ABS		BOSCH ABS Ci 12
 SL 223 Lion's Classic	ABS		BOSCH ABS/ASR 2E
 SL 223 Lion's Classic	ABS		BOSCH ABS/ASR 2M
 SL 223 Lion's Classic	ABS		BOSCH ABS/ASR 2M Stufe 1

## Systems supported by ECUreader (up to V4,90)

### TRUCKS


























### MAN Bus

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 SL 223 Lion's Classic	ABS		BOSCH ABS/ASR 3E
 SL 223 Lion's Classic	ABS		KNORR ABS
 SL 223 Lion's Classic	ABS		KNORR ABS KB3AL
 SL 223 Lion's Classic	CLIMA		Konvekta
 SL 223 Lion's Classic	CLIMA		WABCO ATC
 SL 283 Lion's Classic	ABS		BOSCH ABS Ci 12
 SL 283 Lion's Classic	ABS		BOSCH ABS/ASR 2E
 SL 283 Lion's Classic	ABS		BOSCH ABS/ASR 2M
 SL 283 Lion's Classic	ABS		BOSCH ABS/ASR 2M Stufe 1
 SL 283 Lion's Classic	ABS		BOSCH ABS/ASR 3E
 SL 283 Lion's Classic	ABS		KNORR ABS
 SL 283 Lion's Classic	ABS		KNORR ABS KB3AL
 SL 283 Lion's Classic	CLIMA		Konvekta
 SL 283 Lion's Classic	CLIMA		WABCO ATC
 SU 223 Lion's Classic	ABS		BOSCH ABS Ci 12
 SU 223 Lion's Classic	ABS		BOSCH ABS/ASR 2E
 SU 223 Lion's Classic	ABS		BOSCH ABS/ASR 2M
 SU 223 Lion's Classic	ABS		BOSCH ABS/ASR 2M Stufe 1
 SU 223 Lion's Classic	ABS		BOSCH ABS/ASR 3E
 SU 223 Lion's Classic	ABS		KNORR ABS
 SU 223 Lion's Classic	ABS		KNORR ABS KB3AL
 SU 223 Lion's Classic	CLIMA		Konvekta
 SU 223 Lion's Classic	CLIMA		WABCO ATC
 SU 263 Lion's Classic	ABS		BOSCH ABS Ci 12
 SU 263 Lion's Classic	ABS		BOSCH ABS/ASR 2E
 SU 263 Lion's Classic	ABS		BOSCH ABS/ASR 2M

## Systems supported by ECUREADER (up to V4,90)

### TRUCKS


























### MAN Bus

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 SU 263 Lion's Classic	ABS		BOSCH ABS/ASR 2M Stufe 1
 SU 263 Lion's Classic	ABS		BOSCH ABS/ASR 3E
 SU 263 Lion's Classic	ABS		KNORR ABS
 SU 263 Lion's Classic	ABS		KNORR ABS KB3AL
 SU 263 Lion's Classic	CLIMA		Konvekta
 SU 263 Lion's Classic	CLIMA		WABCO ATC
 SU 313 Lion's Classic	ABS		BOSCH ABS Ci 12
 SU 313 Lion's Classic	ABS		BOSCH ABS/ASR 2E
 SU 313 Lion's Classic	ABS		BOSCH ABS/ASR 2M
 SU 313 Lion's Classic	ABS		BOSCH ABS/ASR 2M Stufe 1
 SU 313 Lion's Classic	ABS		BOSCH ABS/ASR 3E
 SU 313 Lion's Classic	ABS		KNORR ABS
 SU 313 Lion's Classic	ABS		KNORR ABS KB3AL
 SU 313 Lion's Classic	CLIMA		Konvekta
 SU 313 Lion's Classic	CLIMA		WABCO ATC
 SU 363 Lion's Classic	ABS		BOSCH ABS Ci 12
 SU 363 Lion's Classic	ABS		BOSCH ABS/ASR 2E
 SU 363 Lion's Classic	ABS		BOSCH ABS/ASR 2M
 SU 363 Lion's Classic	ABS		BOSCH ABS/ASR 2M Stufe 1
 SU 363 Lion's Classic	ABS		BOSCH ABS/ASR 3E
 SU 363 Lion's Classic	ABS		KNORR ABS
 SU 363 Lion's Classic	ABS		KNORR ABS KB3AL
 SU 363 Lion's Classic	CLIMA		Konvekta
 SU 363 Lion's Classic	CLIMA		WABCO ATC
 UL 313 Lion's Classic	ABS		BOSCH ABS Ci 12
 UL 313 Lion's Classic	ABS		BOSCH ABS/ASR 2E

## Systems supported by ECUREADER (up to V4,90)

### TRUCKS





### MAN Bus

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 UL 313 Lion's Classic	ABS		BOSCH ABS/ASR 2M
 UL 313 Lion's Classic	ABS		BOSCH ABS/ASR 2M Stufe 1
 UL 313 Lion's Classic	ABS		BOSCH ABS/ASR 3E
 UL 313 Lion's Classic	ABS		KNORR ABS
 UL 313 Lion's Classic	ABS		KNORR ABS KB3AL
 UL 313 Lion's Comfort	CLIMA		Konvekta
 UL 313 Lion's Comfort	CLIMA		WABCO ATC
 UL 353 Lion's Classic	ABS		BOSCH ABS Ci 12
 UL 353 Lion's Classic	ABS		BOSCH ABS/ASR 2E
 UL 353 Lion's Classic	ABS		BOSCH ABS/ASR 2M
 UL 353 Lion's Classic	ABS		BOSCH ABS/ASR 2M Stufe 1
 UL 353 Lion's Classic	ABS		BOSCH ABS/ASR 3E
 UL 353 Lion's Classic	ABS		KNORR ABS
 UL 353 Lion's Classic	ABS		KNORR ABS KB3AL
 UL 353 Lion's Comfort	CLIMA		Konvekta
 UL 353 Lion's Comfort	CLIMA		WABCO ATC
 UL 363 Lion's Classic	ABS		BOSCH ABS Ci 12
 UL 363 Lion's Classic	ABS		BOSCH ABS/ASR 2E
 UL 363 Lion's Classic	ABS		BOSCH ABS/ASR 2M
 UL 363 Lion's Classic	ABS		BOSCH ABS/ASR 2M Stufe 1
 UL 363 Lion's Classic	ABS		BOSCH ABS/ASR 3E
 UL 363 Lion's Classic	ABS		KNORR ABS
 UL 363 Lion's Classic	ABS		KNORR ABS KB3AL
 UL 363 Lion's Comfort	CLIMA		Konvekta
 UL 363 Lion's Comfort	CLIMA		WABCO ATC

## Systems supported by ECUreader (up to V4,90)

### TRUCKS






**Meiller-Kipper**

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Trailers	BRAKE SYS. MANAG	Trailers	Wabco Trailers EBS
 Trailers	BRAKE SYS. MANAG	Trailers	Wabco Trailers EBS kw2000
 Trailers	BRAKE SYS. MANAG	Trailers Haldex	Haldex EBS EB+
 Trailers	BRAKE SYS. MANAG	Trailers Knorr	Knorr Trailer EBS

## Systems supported by ECUreader (up to V4,90)

### TRUCKS




























Menci

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Trailers	BRAKE SYS. MANAG	Trailers	Wabco Trailer EBS
 Trailers	BRAKE SYS. MANAG	Trailers	Wabco Trailer VCS II
 Trailers	BRAKE SYS. MANAG	Trailers	Wabco Trailers EBS kw2000
 Trailers	BRAKE SYS. MANAG	Trailers Haldex	Haldex EBS EB+
 Trailers	BRAKE SYS. MANAG	Trailers Knorr	Knorr Trailer EBS

## Systems supported by ECUREADER (up to V4,90)

### TRUCKS




























### Mercedes Benz

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Sprinter	ABS	208 CDI (...-06)	ABS
 Sprinter	ABS	211 CDI (...-06)	ABS
 Sprinter	ABS	213 CDI (...-06)	ABS
 Sprinter	ABS	216 CDI (...-06)	ABS
 Sprinter	ABS	308 CDI (...-06)	ABS
 Sprinter	ABS	311 CDI (...-06)	ABS
 Sprinter	ABS	313 CDI (...-06)	ABS
 Sprinter	ABS	316 CDI (...-06)	ABS
 Sprinter	ABS	408 CDI (...-06)	ABS
 Sprinter	ABS	411 CDI (...-06)	ABS
 Sprinter	ABS	413 CDI (...-06)	ABS
 Sprinter	ABS	416 CDI (...-06)	ABS
 Sprinter	ABS	616 CDI (...-06)	ABS
 Sprinter	ABS + TRACT. CONT	215 CDI (07-..)	BOSCH ESP ABS ESP 906
 Sprinter	ABS + TRACT. CONT	218 CDI (07-..)	BOSCH ESP ABS ESP 906
 Sprinter	ABS + TRACT. CONT	315 CDI (07-..)	BOSCH ESP ABS ESP 906
 Sprinter	ABS + TRACT. CONT	318 CDI (07-..)	BOSCH ESP ABS ESP 906
 Sprinter	ABS + TRACT. CONT	415 CDI (07-..)	BOSCH ESP ABS ESP 906
 Sprinter	ABS + TRACT. CONT	418 CDI (07-..)	BOSCH ESP ABS ESP 906
 Sprinter	ABS + TRACT. CONT	518 CDI (07-..)	BOSCH ESP ABS ESP 906
 Sprinter	AIRBAG	215 CDI (07-..)	BOSCH SRS ARCADE 906
 Sprinter	AIRBAG	218 CDI (07-..)	BOSCH SRS ARCADE 906
 Sprinter	AIRBAG	315 CDI (07-..)	BOSCH SRS ARCADE 906
 Sprinter	AIRBAG	318 CDI (07-..)	BOSCH SRS ARCADE 906
 Sprinter	AIRBAG	415 CDI (07-..)	BOSCH SRS ARCADE 906
 Sprinter	AIRBAG	418 CDI (07-..)	BOSCH SRS ARCADE 906
 Sprinter	AIRBAG	518 CDI (07-..)	BOSCH SRS ARCADE 906

## Systems supported by ECUreader (up to V4,90)

### TRUCKS




























### Mercedes Benz

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Sprinter	AUTOM. TRANSMISSI	(..-06)	MB SSG Sprintshift
 Sprinter	AUTOM. TRANSMISSI	215 CDI (07-..)	SIEMENS EGS
 Sprinter	AUTOM. TRANSMISSI	218 CDI (07-..)	SIEMENS EGS
 Sprinter	AUTOM. TRANSMISSI	315 CDI (07-..)	SIEMENS EGS
 Sprinter	AUTOM. TRANSMISSI	318 CDI (07-..)	SIEMENS EGS
 Sprinter	AUTOM. TRANSMISSI	415 CDI (07-..)	SIEMENS EGS
 Sprinter	AUTOM. TRANSMISSI	418 CDI (07-..)	SIEMENS EGS
 Sprinter	AUTOM. TRANSMISSI	518 CDI (07-..)	SIEMENS EGS
 Sprinter	CHASSIS NETWORK	215 CDI (07-..)	MARQUARDT OBF Upper Switches Panel
 Sprinter	CHASSIS NETWORK	215 CDI (07-..)	TEMIC SAM
 Sprinter	CHASSIS NETWORK	218 CDI (07-..)	MARQUARDT OBF Upper Switches Panel
 Sprinter	CHASSIS NETWORK	218 CDI (07-..)	TEMIC SAM
 Sprinter	CHASSIS NETWORK	315 CDI (07-..)	MARQUARDT OBF Upper Switches Panel
 Sprinter	CHASSIS NETWORK	315 CDI (07-..)	TEMIC SAM
 Sprinter	CHASSIS NETWORK	318 CDI (07-..)	MARQUARDT OBF Upper Switches Panel
 Sprinter	CHASSIS NETWORK	318 CDI (07-..)	TEMIC SAM
 Sprinter	CHASSIS NETWORK	415 CDI (07-..)	MARQUARDT OBF Upper Switches Panel
 Sprinter	CHASSIS NETWORK	415 CDI (07-..)	TEMIC SAM
 Sprinter	CHASSIS NETWORK	418 CDI (07-..)	MARQUARDT OBF Upper Switches Panel
 Sprinter	CHASSIS NETWORK	418 CDI (07-..)	TEMIC SAM
 Sprinter	CHASSIS NETWORK	518 CDI (07-..)	MARQUARDT OBF Upper Switches Panel
 Sprinter	CHASSIS NETWORK	518 CDI (07-..)	TEMIC SAM
 Sprinter	CLIMA	215 CDI (07-..)	HELLA KLA
 Sprinter	CLIMA	218 CDI (07-..)	HELLA KLA
 Sprinter	CLIMA	315 CDI (07-..)	HELLA KLA
 Sprinter	CLIMA	318 CDI (07-..)	HELLA KLA
 Sprinter	CLIMA	415 CDI (07-..)	HELLA KLA

## Systems supported by ECReader (up to V4,90)

### TRUCKS




























### Mercedes Benz

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Sprinter	CLIMA	418 CDI (07-..)	HELLA KLA
 Sprinter	CLIMA	518 CDI (07-..)	HELLA KLA
 Sprinter	DASHBOARD	(..-06)	VDO KOMBI
 Sprinter	DASHBOARD	215 CDI (07-..)	BORG Kombi Instrument KI 906
 Sprinter	DASHBOARD	218 CDI (07-..)	BORG Kombi Instrument KI 906
 Sprinter	DASHBOARD	315 CDI (07-..)	BORG Kombi Instrument KI 906
 Sprinter	DASHBOARD	318 CDI (07-..)	BORG Kombi Instrument KI 906
 Sprinter	DASHBOARD	415 CDI (07-..)	BORG Kombi Instrument KI 906
 Sprinter	DASHBOARD	418 CDI (07-..)	BORG Kombi Instrument KI 906
 Sprinter	DASHBOARD	518 CDI (07-..)	BORG Kombi Instrument KI 906
 Sprinter	DIESEL MANAGEMEN	312 D 2.9 D 602980 (96-..)	BOSCH EVE
 Sprinter	DRIVER SIDE DOOR	215 CDI (07-..)	TEMIC TSG
 Sprinter	DRIVER SIDE DOOR	218 CDI (07-..)	TEMIC TSG
 Sprinter	DRIVER SIDE DOOR	315 CDI (07-..)	TEMIC TSG
 Sprinter	DRIVER SIDE DOOR	318 CDI (07-..)	TEMIC TSG
 Sprinter	DRIVER SIDE DOOR	415 CDI (07-..)	TEMIC TSG
 Sprinter	DRIVER SIDE DOOR	418 CDI (07-..)	TEMIC TSG
 Sprinter	DRIVER SIDE DOOR	518 CDI (07-..)	TEMIC TSG
 Sprinter	ENGINE MANAGEME	208 CDI (..-06)	BOSCH EDC Common Rail
 Sprinter	ENGINE MANAGEME	211 CDI (..-06)	BOSCH EDC Common Rail
 Sprinter	ENGINE MANAGEME	213 CDI (..-06)	BOSCH EDC Common Rail
 Sprinter	ENGINE MANAGEME	215 CDI (07-..)	BOSCH EDC CDI 4 Common Rail
 Sprinter	ENGINE MANAGEME	216 CDI (..-06)	BOSCH EDC Common Rail
 Sprinter	ENGINE MANAGEME	218 CDI (07-..)	BOSCH EDC CDI 4 Common Rail
 Sprinter	ENGINE MANAGEME	308 CDI (..-06)	BOSCH EDC Common Rail
 Sprinter	ENGINE MANAGEME	311 CDI (..-06)	BOSCH EDC Common Rail
 Sprinter	ENGINE MANAGEME	313 CDI (..-06)	BOSCH EDC Common Rail

## Systems supported by ECReader (up to V4,90)

### TRUCKS



























### Mercedes Benz

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Sprinter	ENGINE MANAGEME	315 CDI (07-..)	BOSCH EDC CDI 4 Common Rail
 Sprinter	ENGINE MANAGEME	316 CDI (...06)	BOSCH EDC Common Rail
 Sprinter	ENGINE MANAGEME	318 CDI (07-..)	BOSCH EDC CDI 4 Common Rail
 Sprinter	ENGINE MANAGEME	408 CDI (...06)	BOSCH EDC Common Rail
 Sprinter	ENGINE MANAGEME	411 CDI (...06)	BOSCH EDC Common Rail
 Sprinter	ENGINE MANAGEME	413 CDI (...06)	BOSCH EDC Common Rail
 Sprinter	ENGINE MANAGEME	415 CDI (07-..)	BOSCH EDC CDI 4 Common Rail
 Sprinter	ENGINE MANAGEME	416 CDI (...06)	BOSCH EDC Common Rail
 Sprinter	ENGINE MANAGEME	418 CDI (07-..)	BOSCH EDC CDI 4 Common Rail
 Sprinter	ENGINE MANAGEME	518 CDI (07-..)	BOSCH EDC CDI 4 Common Rail
 Sprinter	ENGINE MANAGEME	616 CDI (...06)	BOSCH EDC Common Rail
 Sprinter	IMMOBILIZER	(...06)	
 Sprinter	RATIO SEL. MANAGE	215 CDI (07-..)	DAIMLERCHRYSLER EWS Selector Lever
 Sprinter	RATIO SEL. MANAGE	218 CDI (07-..)	DAIMLERCHRYSLER EWS Selector Lever
 Sprinter	RATIO SEL. MANAGE	315 CDI (07-..)	DAIMLERCHRYSLER EWS Selector Lever
 Sprinter	RATIO SEL. MANAGE	318 CDI (07-..)	DAIMLERCHRYSLER EWS Selector Lever
 Sprinter	RATIO SEL. MANAGE	415 CDI (07-..)	DAIMLERCHRYSLER EWS Selector Lever
 Sprinter	RATIO SEL. MANAGE	418 CDI (07-..)	DAIMLERCHRYSLER EWS Selector Lever
 Sprinter	RATIO SEL. MANAGE	518 CDI (07-..)	DAIMLERCHRYSLER EWS Selector Lever
 Sprinter	SERVICE LIGHT RES	(99-03)	VDO/MARELLI
 Sprinter	SERVICE LIGHT RES	215 CDI (07-..)	
 Sprinter	SERVICE LIGHT RES	218 CDI (07-..)	
 Sprinter	SERVICE LIGHT RES	315 CDI (07-..)	
 Sprinter	SERVICE LIGHT RES	318 CDI (07-..)	
 Sprinter	SERVICE LIGHT RES	415 CDI (07-..)	
 Sprinter	SERVICE LIGHT RES	418 CDI (07-..)	
 Sprinter	SERVICE LIGHT RES	518 CDI (07-..)	

## Systems supported by ECUreader (up to V4,90)

### TRUCKS




















### Mercedes Benz

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Sprinter	STEERING COLUMN	215 CDI (07-..)	MARQUARDT EZS
 Sprinter	STEERING COLUMN	218 CDI (07-..)	MARQUARDT EZS
 Sprinter	STEERING COLUMN	315 CDI (07-..)	MARQUARDT EZS
 Sprinter	STEERING COLUMN	318 CDI (07-..)	MARQUARDT EZS
 Sprinter	STEERING COLUMN	415 CDI (07-..)	MARQUARDT EZS
 Sprinter	STEERING COLUMN	418 CDI (07-..)	MARQUARDT EZS
 Sprinter	STEERING COLUMN	518 CDI (07-..)	MARQUARDT EZS
 Sprinter	SWITCHLIGHT MODU	215 CDI (07-..)	VALEO MRM
 Sprinter	SWITCHLIGHT MODU	218 CDI (07-..)	VALEO MRM
 Sprinter	SWITCHLIGHT MODU	315 CDI (07-..)	VALEO MRM
 Sprinter	SWITCHLIGHT MODU	318 CDI (07-..)	VALEO MRM
 Sprinter	SWITCHLIGHT MODU	415 CDI (07-..)	VALEO MRM
 Sprinter	SWITCHLIGHT MODU	418 CDI (07-..)	VALEO MRM
 Sprinter	SWITCHLIGHT MODU	518 CDI (07-..)	VALEO MRM
 V-Class & VITO	ABS + TRACT. CONT	V 200 CDI	BOSCH ETS 5
 V-Class & VITO	ABS + TRACT. CONT	V 200 CDI (...99)	BOSCH ASR / ABD BAS / ETS
 V-Class & VITO	ABS + TRACT. CONT	V 220 CDI	BOSCH ETS 5
 V-Class & VITO	ABS + TRACT. CONT	V 220 CDI (...99)	BOSCH ASR / ABD BAS / ETS
 V-Class & VITO	ABS + TRACT. CONT	V 230	BOSCH ETS 5
 V-Class & VITO	ABS + TRACT. CONT	V 230 (...99)	BOSCH ASR / ABD BAS / ETS
 V-Class & VITO	ABS + TRACT. CONT	V 280	BOSCH ETS 5
 V-Class & VITO	ABS + TRACT. CONT	V 280 (...99)	BOSCH ASR / ABD BAS / ETS
 V-Class & VITO	ABS + TRACT. CONT	Vito F 108 CDI	BOSCH ETS 5
 V-Class & VITO	ABS + TRACT. CONT	Vito F 108 CDI (...99)	BOSCH ASR / ABD BAS / ETS
 V-Class & VITO	ABS + TRACT. CONT	Vito F 108 D	BOSCH ETS 5
 V-Class & VITO	ABS + TRACT. CONT	Vito F 108 D (...99)	BOSCH ASR / ABD BAS / ETS

## Systems supported by ECReader (up to V4,90)

### TRUCKS



























### Mercedes Benz

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 V-Class & VITO	ABS + TRACT. CONT	Vito F 110 CDI	BOSCH ETS 5
 V-Class & VITO	ABS + TRACT. CONT	Vito F 110 CDI (...99)	BOSCH ASR / ABD BAS / ETS
 V-Class & VITO	ABS + TRACT. CONT	Vito F 110 TD	BOSCH ETS 5
 V-Class & VITO	ABS + TRACT. CONT	Vito F 110 TD (...99)	BOSCH ASR / ABD BAS / ETS
 V-Class & VITO	ABS + TRACT. CONT	Vito F 112 CDI	BOSCH ETS 5
 V-Class & VITO	ABS + TRACT. CONT	Vito F 112 CDI (...99)	BOSCH ASR / ABD BAS / ETS
 V-Class & VITO	ABS + TRACT. CONT	Vito F 113 CDI	BOSCH ETS 5
 V-Class & VITO	ABS + TRACT. CONT	Vito F 113 CDI (...99)	BOSCH ASR / ABD BAS / ETS
 V-Class & VITO	ABS + TRACT. CONT	Vito F 114 CDI	BOSCH ETS 5
 V-Class & VITO	ABS + TRACT. CONT	Vito F 114 CDI (...99)	BOSCH ASR / ABD BAS / ETS
 V-Class & VITO	ABS + TRACT. CONT	Vito L 108 CDI	BOSCH ETS 5
 V-Class & VITO	ABS + TRACT. CONT	Vito L 108 CDI (...99)	BOSCH ASR / ABD BAS / ETS
 V-Class & VITO	ABS + TRACT. CONT	Vito L 108 D	BOSCH ETS 5
 V-Class & VITO	ABS + TRACT. CONT	Vito L 108 D (...99)	BOSCH ASR / ABD BAS / ETS
 V-Class & VITO	ABS + TRACT. CONT	Vito L 110 CDI	BOSCH ETS 5
 V-Class & VITO	ABS + TRACT. CONT	Vito L 110 CDI (...99)	BOSCH ASR / ABD BAS / ETS
 V-Class & VITO	ABS + TRACT. CONT	Vito L 110 TD	BOSCH ETS 5
 V-Class & VITO	ABS + TRACT. CONT	Vito L 110 TD (...99)	BOSCH ASR / ABD BAS / ETS
 V-Class & VITO	ABS + TRACT. CONT	Vito L 112 CDI	BOSCH ETS 5
 V-Class & VITO	ABS + TRACT. CONT	Vito L 112 CDI (...99)	BOSCH ASR / ABD BAS / ETS
 V-Class & VITO	ABS + TRACT. CONT	Vito L 113 CDI	BOSCH ETS 5
 V-Class & VITO	ABS + TRACT. CONT	Vito L 113 CDI (...99)	BOSCH ASR / ABD BAS / ETS
 V-Class & VITO	ABS + TRACT. CONT	Vito L 114 CDI	BOSCH ETS 5
 V-Class & VITO	ABS + TRACT. CONT	Vito L 114 CDI (...99)	BOSCH ASR / ABD BAS / ETS
 V-Class & VITO	AUTOM. TRANSMISSI	V 200 CDI (...99)	BOSCH ETC 6
 V-Class & VITO	AUTOM. TRANSMISSI	V 220 CDI (...99)	BOSCH ETC 6
 V-Class & VITO	AUTOM. TRANSMISSI	V 230 (...99)	BOSCH ETC 6

## Systems supported by ECReader (up to V4,90)

### TRUCKS




























### Mercedes Benz

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 V-Class & VITO	AUTOM. TRANSMISSI	V 280 (...99)	BOSCH ETC 6
 V-Class & VITO	AUTOM. TRANSMISSI	Vito F 108 CDI (...99)	BOSCH ETC 6
 V-Class & VITO	AUTOM. TRANSMISSI	Vito F 108 D (...99)	BOSCH ETC 6
 V-Class & VITO	AUTOM. TRANSMISSI	Vito F 110 CDI (...99)	BOSCH ETC 6
 V-Class & VITO	AUTOM. TRANSMISSI	Vito F 110 TD (...99)	BOSCH ETC 6
 V-Class & VITO	AUTOM. TRANSMISSI	Vito F 112 CDI (...99)	BOSCH ETC 6
 V-Class & VITO	AUTOM. TRANSMISSI	Vito F 113 CDI (...99)	BOSCH ETC 6
 V-Class & VITO	AUTOM. TRANSMISSI	Vito F 114 CDI (...99)	BOSCH ETC 6
 V-Class & VITO	AUTOM. TRANSMISSI	Vito L 108 CDI (...99)	BOSCH ETC 6
 V-Class & VITO	AUTOM. TRANSMISSI	Vito L 108 D (...99)	BOSCH ETC 6
 V-Class & VITO	AUTOM. TRANSMISSI	Vito L 110 CDI (...99)	BOSCH ETC 6
 V-Class & VITO	AUTOM. TRANSMISSI	Vito L 110 TD (...99)	BOSCH ETC 6
 V-Class & VITO	AUTOM. TRANSMISSI	Vito L 112 CDI (...99)	BOSCH ETC 6
 V-Class & VITO	AUTOM. TRANSMISSI	Vito L 113 CDI (...99)	BOSCH ETC 6
 V-Class & VITO	AUTOM. TRANSMISSI	Vito L 114 CDI (...99)	BOSCH ETC 6
 V-Class & VITO	ENGINE MANAGEME	V 114 111 (...99)	BOSCH Motronic ME 2.0
 V-Class & VITO	ENGINE MANAGEME	V 200 CDI 611 (98-00)	BOSCH EDC 15 C4 Common Rail
 V-Class & VITO	ENGINE MANAGEME	V 200 CDI 611 (98-00)	BOSCH EDC 15 C6 Common Rail
 V-Class & VITO	ENGINE MANAGEME	V 220 CDI 611 (98-00)	BOSCH EDC 15 C4 Common Rail
 V-Class & VITO	ENGINE MANAGEME	V 220 CDI 611 (98-00)	BOSCH EDC 15 C6 Common Rail
 V-Class & VITO	ENGINE MANAGEME	V 230 111 (...99)	BOSCH Motronic ME 2.0
 V-Class & VITO	ENGINE MANAGEME	Vito F 108 CDI 611 (98-00)	BOSCH EDC 15 C4 Common Rail
 V-Class & VITO	ENGINE MANAGEME	Vito F 108 CDI 611 (98-00)	BOSCH EDC 15 C6 Common Rail
 V-Class & VITO	ENGINE MANAGEME	Vito L 108 CDI 611 (98-00)	BOSCH EDC 15 C4 Common Rail
 V-Class & VITO	ENGINE MANAGEME	Vito L 108 CDI 611 (98-00)	BOSCH EDC 15 C6 Common Rail
 V-Class & VITO	SERVICE LIGHT RES	(99-03)	VDO/MARELLI

## Systems supported by ECReader (up to V4,90)

### TRUCKS




























### Mercedes Benz

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Vito	ABS + TRACT. CONT	109 CDI (07-..)	BOSCH ESP ABS
 Vito	ABS + TRACT. CONT	111 CDI (07-..)	BOSCH ESP ABS
 Vito	ABS + TRACT. CONT	111 CDI 4X4 (07-..)	BOSCH ESP ABS
 Vito	ABS + TRACT. CONT	115 CDI (07-..)	BOSCH ESP ABS
 Vito	ABS + TRACT. CONT	115 CDI 4X4 (07-..)	BOSCH ESP ABS
 Vito	ABS + TRACT. CONT	119 (07-..)	BOSCH ESP ABS
 Vito	ABS + TRACT. CONT	120 CDI (07-..)	BOSCH ESP ABS
 Vito	ABS + TRACT. CONT	123 (07-..)	BOSCH ESP ABS
 Vito	AIRBAG	109 CDI (07-..)	BOSCH SRS ARCADE 639
 Vito	AIRBAG	111 CDI (07-..)	BOSCH SRS ARCADE 639
 Vito	AIRBAG	111 CDI 4X4 (07-..)	BOSCH SRS ARCADE 639
 Vito	AIRBAG	115 CDI (07-..)	BOSCH SRS ARCADE 639
 Vito	AIRBAG	115 CDI 4X4 (07-..)	BOSCH SRS ARCADE 639
 Vito	AIRBAG	119 (07-..)	BOSCH SRS ARCADE 639
 Vito	AIRBAG	120 CDI (07-..)	BOSCH SRS ARCADE 639
 Vito	AIRBAG	123 (07-..)	BOSCH SRS ARCADE 639
 Vito	AUTOM. TRANSMISSI	109 CDI (07-..)	SIEMENS EGS
 Vito	AUTOM. TRANSMISSI	111 CDI (07-..)	SIEMENS EGS
 Vito	AUTOM. TRANSMISSI	111 CDI 4X4 (07-..)	SIEMENS EGS
 Vito	AUTOM. TRANSMISSI	115 CDI (07-..)	SIEMENS EGS
 Vito	AUTOM. TRANSMISSI	115 CDI 4X4 (07-..)	SIEMENS EGS
 Vito	AUTOM. TRANSMISSI	119 (07-..)	SIEMENS EGS
 Vito	AUTOM. TRANSMISSI	120 CDI (07-..)	SIEMENS EGS
 Vito	AUTOM. TRANSMISSI	123 (07-..)	SIEMENS EGS
 Vito	CHASSIS NETWORK	109 CDI (07-..)	Body Computer
 Vito	CHASSIS NETWORK	109 CDI (07-..)	Marquardt OBF Upper Switches Panel
 Vito	CHASSIS NETWORK	111 CDI (07-..)	Body Computer

## Systems supported by ECUREADER (up to V4,90)

### TRUCKS




























### Mercedes Benz

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Vito	CHASSIS NETWORK	111 CDI (07-..)	Marquardt OBF Upper Switches Panel
 Vito	CHASSIS NETWORK	111 CDI 4X4 (07-..)	Body Computer
 Vito	CHASSIS NETWORK	111 CDI 4X4 (07-..)	Marquardt OBF Upper Switches Panel
 Vito	CHASSIS NETWORK	115 CDI (07-..)	Body Computer
 Vito	CHASSIS NETWORK	115 CDI (07-..)	Marquardt OBF Upper Switches Panel
 Vito	CHASSIS NETWORK	115 CDI 4X4 (07-..)	Body Computer
 Vito	CHASSIS NETWORK	115 CDI 4X4 (07-..)	Marquardt OBF Upper Switches Panel
 Vito	CHASSIS NETWORK	119 (07-..)	Body Computer
 Vito	CHASSIS NETWORK	119 (07-..)	Marquardt OBF Upper Switches Panel
 Vito	CHASSIS NETWORK	120 CDI (07-..)	Body Computer
 Vito	CHASSIS NETWORK	120 CDI (07-..)	Marquardt OBF Upper Switches Panel
 Vito	CHASSIS NETWORK	123 (07-..)	Body Computer
 Vito	CHASSIS NETWORK	123 (07-..)	Marquardt OBF Upper Switches Panel
 Vito	DASHBOARD	109 CDI (07-..)	BORG Kombi Instrument 639 M
 Vito	DASHBOARD	111 CDI (07-..)	BORG Kombi Instrument 639 M
 Vito	DASHBOARD	111 CDI 4X4 (07-..)	BORG Kombi Instrument 639 M
 Vito	DASHBOARD	115 CDI (07-..)	BORG Kombi Instrument 639 M
 Vito	DASHBOARD	115 CDI 4X4 (07-..)	BORG Kombi Instrument 639 M
 Vito	DASHBOARD	119 (07-..)	BORG Kombi Instrument 639 M
 Vito	DASHBOARD	120 CDI (07-..)	BORG Kombi Instrument 639 M
 Vito	DASHBOARD	123 (07-..)	BORG Kombi Instrument 639 M
 Vito	ENGINE MANAGEME	111 CDI (07-..)	BOSCH EDC
 Vito	LEFT FRONT DOOR	109 CDI (07-..)	TEMIC TSG-VL
 Vito	LEFT FRONT DOOR	111 CDI (07-..)	TEMIC TSG-VL
 Vito	LEFT FRONT DOOR	111 CDI 4X4 (07-..)	TEMIC TSG-VL
 Vito	LEFT FRONT DOOR	115 CDI (07-..)	TEMIC TSG-VL
 Vito	LEFT FRONT DOOR	115 CDI 4X4 (07-..)	TEMIC TSG-VL

## Systems supported by ECReader (up to V4,90)

### TRUCKS









### Mercedes Benz

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Vito	LEFT FRONT DOOR	119 (07-..)	TEMIC TSG-VL
 Vito	LEFT FRONT DOOR	120 CDI (07-..)	TEMIC TSG-VL
 Vito	LEFT FRONT DOOR	123 (07-..)	TEMIC TSG-VL
 Vito	RATIO SEL. MANAGE	109 CDI (07-..)	EWM
 Vito	RATIO SEL. MANAGE	111 CDI (07-..)	EWM
 Vito	RATIO SEL. MANAGE	111 CDI 4X4 (07-..)	EWM
 Vito	RATIO SEL. MANAGE	115 CDI (07-..)	EWM
 Vito	RATIO SEL. MANAGE	115 CDI 4X4 (07-..)	EWM
 Vito	RATIO SEL. MANAGE	119 (07-..)	EWM
 Vito	RATIO SEL. MANAGE	120 CDI (07-..)	EWM
 Vito	RATIO SEL. MANAGE	123 (07-..)	EWM
 Vito	RIGHT FRONT DOOR	109 CDI (07-..)	TEMIC TSG-VR
 Vito	RIGHT FRONT DOOR	111 CDI (07-..)	TEMIC TSG-VR
 Vito	RIGHT FRONT DOOR	111 CDI 4X4 (07-..)	TEMIC TSG-VR
 Vito	RIGHT FRONT DOOR	115 CDI (07-..)	TEMIC TSG-VR
 Vito	RIGHT FRONT DOOR	115 CDI 4X4 (07-..)	TEMIC TSG-VR
 Vito	RIGHT FRONT DOOR	119 (07-..)	TEMIC TSG-VR
 Vito	RIGHT FRONT DOOR	120 CDI (07-..)	TEMIC TSG-VR
 Vito	RIGHT FRONT DOOR	123 (07-..)	TEMIC TSG-VR
 Vito	STEERING COLUMN	109 CDI (07-..)	EZS
 Vito	STEERING COLUMN	111 CDI (07-..)	EZS
 Vito	STEERING COLUMN	111 CDI 4X4 (07-..)	EZS
 Vito	STEERING COLUMN	115 CDI (07-..)	EZS
 Vito	STEERING COLUMN	115 CDI 4X4 (07-..)	EZS
 Vito	STEERING COLUMN	119 (07-..)	EZS
 Vito	STEERING COLUMN	120 CDI (07-..)	EZS
 Vito	STEERING COLUMN	123 (07-..)	EZS

## Systems supported by ECReader (up to V4,90)

### TRUCKS




























### Mercedes Benz

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Vito	SUSPENSION CONTR	109 CDI (07-..)	WEHRLE ENR
 Vito	SUSPENSION CONTR	111 CDI (07-..)	WEHRLE ENR
 Vito	SUSPENSION CONTR	111 CDI 4X4 (07-..)	WEHRLE ENR
 Vito	SUSPENSION CONTR	115 CDI (07-..)	WEHRLE ENR
 Vito	SUSPENSION CONTR	115 CDI 4X4 (07-..)	WEHRLE ENR
 Vito	SUSPENSION CONTR	119 (07-..)	WEHRLE ENR
 Vito	SUSPENSION CONTR	120 CDI (07-..)	WEHRLE ENR
 Vito	SUSPENSION CONTR	123 (07-..)	WEHRLE ENR

## Systems supported by ECReader (up to V4,90)

### TRUCKS




























### Mercedes Trucks

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Actros (...00)	ABS	1831 (...00)	MB ABS
 Actros (...00)	ABS	1831 K (...00)	MB ABS
 Actros (...00)	ABS	1831 L (...00)	MB ABS
 Actros (...00)	ABS	1831 L nR (...00)	MB ABS
 Actros (...00)	ABS	1835 L (...00)	MB ABS
 Actros (...00)	ABS	1835 L nR (...00)	MB ABS
 Actros (...00)	ABS	1840 (...00)	MB ABS
 Actros (...00)	ABS	1840 K (...00)	MB ABS
 Actros (...00)	ABS	1840 L (...00)	MB ABS
 Actros (...00)	ABS	1840 L nR (...00)	MB ABS
 Actros (...00)	ABS	1843 (...00)	MB ABS
 Actros (...00)	ABS	1843 K (...00)	MB ABS
 Actros (...00)	ABS	1843 L (...00)	MB ABS
 Actros (...00)	ABS	1843 L nR (...00)	MB ABS
 Actros (...00)	ABS	1846 (...00)	MB ABS
 Actros (...00)	ABS	1846 L (...00)	MB ABS
 Actros (...00)	ABS	1848 (...00)	MB ABS
 Actros (...00)	ABS	1848 L (...00)	MB ABS
 Actros (...00)	ABS	1853 L (...00)	MB ABS
 Actros (...00)	ABS	1857 L (...00)	MB ABS
 Actros (...00)	ABS	2031 AK (...00)	MB ABS
 Actros (...00)	ABS	2531 L (...00)	MB ABS
 Actros (...00)	ABS	2535 L (...00)	MB ABS
 Actros (...00)	ABS	2540 L (...00)	MB ABS
 Actros (...00)	ABS	2543 L (...00)	MB ABS
 Actros (...00)	ABS	2546 L (...00)	MB ABS
 Actros (...00)	ABS	2548 L (...00)	MB ABS

## Systems supported by ECReader (up to V4,90)

### TRUCKS




























### Mercedes Trucks

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Actros (...00)	ABS	2553 L (...00)	MB ABS
 Actros (...00)	ABS	2557 L (...00)	MB ABS
 Actros (...00)	ABS	3243 (...00)	MB ABS
 Actros (...00)	ABS	3335 B (...00)	MB ABS
 Actros (...00)	ABS	3335 K (...00)	MB ABS
 Actros (...00)	ABS	3340 AK (...00)	MB ABS
 Actros (...00)	ABS	3340 B (...00)	MB ABS
 Actros (...00)	ABS	3340 K (...00)	MB ABS
 Actros (...00)	ABS	3343 K (...00)	MB ABS
 Actros (...00)	ABS	3346 K (...00)	MB ABS
 Actros (...00)	ABS	3348 K (...00)	MB ABS
 Actros (...00)	ABS	4140 B (...00)	MB ABS
 Actros (...00)	ABS	4140 K (...00)	MB ABS
 Actros (...00)	ABS	4143 K (...00)	MB ABS
 Actros (...00)	ABS	4146 K (...00)	MB ABS
 Actros (...00)	ABS	4148 K (...00)	MB ABS
 Actros (...00)	BRAKE POWER SUP	1831 (...00)	MB RS Retarder
 Actros (...00)	BRAKE POWER SUP	1831 K (...00)	MB RS Retarder
 Actros (...00)	BRAKE POWER SUP	1831 L (...00)	MB RS Retarder
 Actros (...00)	BRAKE POWER SUP	1831 L nR (...00)	MB RS Retarder
 Actros (...00)	BRAKE POWER SUP	1835 L (...00)	MB RS Retarder
 Actros (...00)	BRAKE POWER SUP	1835 L nR (...00)	MB RS Retarder
 Actros (...00)	BRAKE POWER SUP	1840 (...00)	MB RS Retarder
 Actros (...00)	BRAKE POWER SUP	1840 K (...00)	MB RS Retarder
 Actros (...00)	BRAKE POWER SUP	1840 L (...00)	MB RS Retarder
 Actros (...00)	BRAKE POWER SUP	1840 L nR (...00)	MB RS Retarder
 Actros (...00)	BRAKE POWER SUP	1843 (...00)	MB RS Retarder

## Systems supported by ECUREADER (up to V4,90)

### TRUCKS




























### Mercedes Trucks

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Actros (...00)	BRAKE POWER SUP	1843 K (...00)	MB RS Retarder
 Actros (...00)	BRAKE POWER SUP	1843 L (...00)	MB RS Retarder
 Actros (...00)	BRAKE POWER SUP	1843 L nR (...00)	MB RS Retarder
 Actros (...00)	BRAKE POWER SUP	1846 (...00)	MB RS Retarder
 Actros (...00)	BRAKE POWER SUP	1846 L (...00)	MB RS Retarder
 Actros (...00)	BRAKE POWER SUP	1848 (...00)	MB RS Retarder
 Actros (...00)	BRAKE POWER SUP	1848 L (...00)	MB RS Retarder
 Actros (...00)	BRAKE POWER SUP	1853 L (...00)	MB RS Retarder
 Actros (...00)	BRAKE POWER SUP	1857 L (...00)	MB RS Retarder
 Actros (...00)	BRAKE POWER SUP	2031 AK (...00)	MB RS Retarder
 Actros (...00)	BRAKE POWER SUP	2531 L (...00)	MB RS Retarder
 Actros (...00)	BRAKE POWER SUP	2535 L (...00)	MB RS Retarder
 Actros (...00)	BRAKE POWER SUP	2540 L (...00)	MB RS Retarder
 Actros (...00)	BRAKE POWER SUP	2543 L (...00)	MB RS Retarder
 Actros (...00)	BRAKE POWER SUP	2546 L (...00)	MB RS Retarder
 Actros (...00)	BRAKE POWER SUP	2548 L (...00)	MB RS Retarder
 Actros (...00)	BRAKE POWER SUP	2553 L (...00)	MB RS Retarder
 Actros (...00)	BRAKE POWER SUP	2557 L (...00)	MB RS Retarder
 Actros (...00)	BRAKE POWER SUP	3243 (...00)	MB RS Retarder
 Actros (...00)	BRAKE POWER SUP	3335 B (...00)	MB RS Retarder
 Actros (...00)	BRAKE POWER SUP	3335 K (...00)	MB RS Retarder
 Actros (...00)	BRAKE POWER SUP	3340 AK (...00)	MB RS Retarder
 Actros (...00)	BRAKE POWER SUP	3340 B (...00)	MB RS Retarder
 Actros (...00)	BRAKE POWER SUP	3340 K (...00)	MB RS Retarder
 Actros (...00)	BRAKE POWER SUP	3343 K (...00)	MB RS Retarder
 Actros (...00)	BRAKE POWER SUP	3346 K (...00)	MB RS Retarder
 Actros (...00)	BRAKE POWER SUP	3348 K (...00)	MB RS Retarder

## Systems supported by ECReader (up to V4,90)

### TRUCKS




























### Mercedes Trucks

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Actros (...00)	BRAKE POWER SUP	4140 B (...00)	MB RS Retarder
 Actros (...00)	BRAKE POWER SUP	4140 K (...00)	MB RS Retarder
 Actros (...00)	BRAKE POWER SUP	4143 K (...00)	MB RS Retarder
 Actros (...00)	BRAKE POWER SUP	4146 K (...00)	MB RS Retarder
 Actros (...00)	BRAKE POWER SUP	4148 K (...00)	MB RS Retarder
 Actros (...00)	BRAKE SYS. MANAG	1831 (...00)	MB BS EPB
 Actros (...00)	BRAKE SYS. MANAG	1831 K (...00)	MB BS EPB
 Actros (...00)	BRAKE SYS. MANAG	1831 L (...00)	MB BS EPB
 Actros (...00)	BRAKE SYS. MANAG	1831 L nR (...00)	MB BS EPB
 Actros (...00)	BRAKE SYS. MANAG	1835 L (...00)	MB BS EPB
 Actros (...00)	BRAKE SYS. MANAG	1835 L nR (...00)	MB BS EPB
 Actros (...00)	BRAKE SYS. MANAG	1840 (...00)	MB BS EPB
 Actros (...00)	BRAKE SYS. MANAG	1840 K (...00)	MB BS EPB
 Actros (...00)	BRAKE SYS. MANAG	1840 L (...00)	MB BS EPB
 Actros (...00)	BRAKE SYS. MANAG	1840 L nR (...00)	MB BS EPB
 Actros (...00)	BRAKE SYS. MANAG	1843 (...00)	MB BS EPB
 Actros (...00)	BRAKE SYS. MANAG	1843 K (...00)	MB BS EPB
 Actros (...00)	BRAKE SYS. MANAG	1843 L (...00)	MB BS EPB
 Actros (...00)	BRAKE SYS. MANAG	1843 L nR (...00)	MB BS EPB
 Actros (...00)	BRAKE SYS. MANAG	1846 (...00)	MB BS EPB
 Actros (...00)	BRAKE SYS. MANAG	1846 L (...00)	MB BS EPB
 Actros (...00)	BRAKE SYS. MANAG	1848 (...00)	MB BS EPB
 Actros (...00)	BRAKE SYS. MANAG	1848 L (...00)	MB BS EPB
 Actros (...00)	BRAKE SYS. MANAG	1853 L (...00)	MB BS EPB
 Actros (...00)	BRAKE SYS. MANAG	1857 L (...00)	MB BS EPB
 Actros (...00)	BRAKE SYS. MANAG	2031 AK (...00)	MB BS EPB
 Actros (...00)	BRAKE SYS. MANAG	2531 L (...00)	MB BS EPB

## Systems supported by ECReader (up to V4,90)

### TRUCKS




























### Mercedes Trucks

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Actros (...00)	BRAKE SYS. MANAG	2535 L (...00)	MB BS EPB
 Actros (...00)	BRAKE SYS. MANAG	2540 L (...00)	MB BS EPB
 Actros (...00)	BRAKE SYS. MANAG	2543 L (...00)	MB BS EPB
 Actros (...00)	BRAKE SYS. MANAG	2546 L (...00)	MB BS EPB
 Actros (...00)	BRAKE SYS. MANAG	2548 L (...00)	MB BS EPB
 Actros (...00)	BRAKE SYS. MANAG	2553 L (...00)	MB BS EPB
 Actros (...00)	BRAKE SYS. MANAG	2557 L (...00)	MB BS EPB
 Actros (...00)	BRAKE SYS. MANAG	3243 (...00)	MB BS EPB
 Actros (...00)	BRAKE SYS. MANAG	3335 B (...00)	MB BS EPB
 Actros (...00)	BRAKE SYS. MANAG	3335 K (...00)	MB BS EPB
 Actros (...00)	BRAKE SYS. MANAG	3340 AK (...00)	MB BS EPB
 Actros (...00)	BRAKE SYS. MANAG	3340 B (...00)	MB BS EPB
 Actros (...00)	BRAKE SYS. MANAG	3340 K (...00)	MB BS EPB
 Actros (...00)	BRAKE SYS. MANAG	3343 K (...00)	MB BS EPB
 Actros (...00)	BRAKE SYS. MANAG	3346 K (...00)	MB BS EPB
 Actros (...00)	BRAKE SYS. MANAG	3348 K (...00)	MB BS EPB
 Actros (...00)	BRAKE SYS. MANAG	4140 B (...00)	MB BS EPB
 Actros (...00)	BRAKE SYS. MANAG	4140 K (...00)	MB BS EPB
 Actros (...00)	BRAKE SYS. MANAG	4143 K (...00)	MB BS EPB
 Actros (...00)	BRAKE SYS. MANAG	4146 K (...00)	MB BS EPB
 Actros (...00)	BRAKE SYS. MANAG	4148 K (...00)	MB BS EPB
 Actros (...00)	CLIMA	1831 (...00)	MB HZR
 Actros (...00)	CLIMA	1831 K (...00)	MB HZR
 Actros (...00)	CLIMA	1831 L (...00)	MB HZR
 Actros (...00)	CLIMA	1831 L nR (...00)	MB HZR
 Actros (...00)	CLIMA	1835 L (...00)	MB HZR
 Actros (...00)	CLIMA	1835 L nR (...00)	MB HZR

## Systems supported by ECUREADER (up to V4,90)

### TRUCKS




























### Mercedes Trucks

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Actros (...00)	CLIMA	1840 (...00)	MB HZR
 Actros (...00)	CLIMA	1840 K (...00)	MB HZR
 Actros (...00)	CLIMA	1840 L (...00)	MB HZR
 Actros (...00)	CLIMA	1840 L nR (...00)	MB HZR
 Actros (...00)	CLIMA	1843 (...00)	MB HZR
 Actros (...00)	CLIMA	1843 K (...00)	MB HZR
 Actros (...00)	CLIMA	1843 L (...00)	MB HZR
 Actros (...00)	CLIMA	1843 L nR (...00)	MB HZR
 Actros (...00)	CLIMA	1846 (...00)	MB HZR
 Actros (...00)	CLIMA	1846 L (...00)	MB HZR
 Actros (...00)	CLIMA	1848 (...00)	MB HZR
 Actros (...00)	CLIMA	1848 L (...00)	MB HZR
 Actros (...00)	CLIMA	1853 L (...00)	MB HZR
 Actros (...00)	CLIMA	1857 L (...00)	MB HZR
 Actros (...00)	CLIMA	2031 AK (...00)	MB HZR
 Actros (...00)	CLIMA	2531 L (...00)	MB HZR
 Actros (...00)	CLIMA	2535 L (...00)	MB HZR
 Actros (...00)	CLIMA	2540 L (...00)	MB HZR
 Actros (...00)	CLIMA	2543 L (...00)	MB HZR
 Actros (...00)	CLIMA	2546 L (...00)	MB HZR
 Actros (...00)	CLIMA	2548 L (...00)	MB HZR
 Actros (...00)	CLIMA	2553 L (...00)	MB HZR
 Actros (...00)	CLIMA	2557 L (...00)	MB HZR
 Actros (...00)	CLIMA	3243 (...00)	MB HZR
 Actros (...00)	CLIMA	3335 B (...00)	MB HZR
 Actros (...00)	CLIMA	3335 K (...00)	MB HZR
 Actros (...00)	CLIMA	3340 AK (...00)	MB HZR

## Systems supported by ECUREADER (up to V4,90)

### TRUCKS




























### Mercedes Trucks

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Actros (...00)	CLIMA	3340 B (...00)	MB HZR
 Actros (...00)	CLIMA	3340 K (...00)	MB HZR
 Actros (...00)	CLIMA	3343 K (...00)	MB HZR
 Actros (...00)	CLIMA	3346 K (...00)	MB HZR
 Actros (...00)	CLIMA	3348 K (...00)	MB HZR
 Actros (...00)	CLIMA	4140 B (...00)	MB HZR
 Actros (...00)	CLIMA	4140 K (...00)	MB HZR
 Actros (...00)	CLIMA	4143 K (...00)	MB HZR
 Actros (...00)	CLIMA	4146 K (...00)	MB HZR
 Actros (...00)	CLIMA	4148 K (...00)	MB HZR
 Actros (...00)	CLUTCH ELECTRONI	1831 (...00)	MB KS MKR
 Actros (...00)	CLUTCH ELECTRONI	1831 K (...00)	MB KS MKR
 Actros (...00)	CLUTCH ELECTRONI	1831 L (...00)	MB KS MKR
 Actros (...00)	CLUTCH ELECTRONI	1831 L nR (...00)	MB KS MKR
 Actros (...00)	CLUTCH ELECTRONI	1835 L (...00)	MB KS MKR
 Actros (...00)	CLUTCH ELECTRONI	1835 L nR (...00)	MB KS MKR
 Actros (...00)	CLUTCH ELECTRONI	1840 (...00)	MB KS MKR
 Actros (...00)	CLUTCH ELECTRONI	1840 K (...00)	MB KS MKR
 Actros (...00)	CLUTCH ELECTRONI	1840 L (...00)	MB KS MKR
 Actros (...00)	CLUTCH ELECTRONI	1840 L nR (...00)	MB KS MKR
 Actros (...00)	CLUTCH ELECTRONI	1843 (...00)	MB KS MKR
 Actros (...00)	CLUTCH ELECTRONI	1843 K (...00)	MB KS MKR
 Actros (...00)	CLUTCH ELECTRONI	1843 L (...00)	MB KS MKR
 Actros (...00)	CLUTCH ELECTRONI	1843 L nR (...00)	MB KS MKR
 Actros (...00)	CLUTCH ELECTRONI	1846 (...00)	MB KS MKR
 Actros (...00)	CLUTCH ELECTRONI	1846 L (...00)	MB KS MKR
 Actros (...00)	CLUTCH ELECTRONI	1848 (...00)	MB KS MKR

## Systems supported by ECUREADER (up to V4,90)

### TRUCKS




























### Mercedes Trucks

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Actros (...00)	CLUTCH ELECTRONI	1848 L (...00)	MB KS MKR
 Actros (...00)	CLUTCH ELECTRONI	1853 L (...00)	MB KS MKR
 Actros (...00)	CLUTCH ELECTRONI	1857 L (...00)	MB KS MKR
 Actros (...00)	CLUTCH ELECTRONI	2031 AK (...00)	MB KS MKR
 Actros (...00)	CLUTCH ELECTRONI	2531 L (...00)	MB KS MKR
 Actros (...00)	CLUTCH ELECTRONI	2535 L (...00)	MB KS MKR
 Actros (...00)	CLUTCH ELECTRONI	2540 L (...00)	MB KS MKR
 Actros (...00)	CLUTCH ELECTRONI	2543 L (...00)	MB KS MKR
 Actros (...00)	CLUTCH ELECTRONI	2546 L (...00)	MB KS MKR
 Actros (...00)	CLUTCH ELECTRONI	2548 L (...00)	MB KS MKR
 Actros (...00)	CLUTCH ELECTRONI	2553 L (...00)	MB KS MKR
 Actros (...00)	CLUTCH ELECTRONI	2557 L (...00)	MB KS MKR
 Actros (...00)	CLUTCH ELECTRONI	3243 (...00)	MB KS MKR
 Actros (...00)	CLUTCH ELECTRONI	3335 B (...00)	MB KS MKR
 Actros (...00)	CLUTCH ELECTRONI	3335 K (...00)	MB KS MKR
 Actros (...00)	CLUTCH ELECTRONI	3340 AK (...00)	MB KS MKR
 Actros (...00)	CLUTCH ELECTRONI	3340 B (...00)	MB KS MKR
 Actros (...00)	CLUTCH ELECTRONI	3340 K (...00)	MB KS MKR
 Actros (...00)	CLUTCH ELECTRONI	3343 K (...00)	MB KS MKR
 Actros (...00)	CLUTCH ELECTRONI	3346 K (...00)	MB KS MKR
 Actros (...00)	CLUTCH ELECTRONI	3348 K (...00)	MB KS MKR
 Actros (...00)	CLUTCH ELECTRONI	4140 B (...00)	MB KS MKR
 Actros (...00)	CLUTCH ELECTRONI	4140 K (...00)	MB KS MKR
 Actros (...00)	CLUTCH ELECTRONI	4143 K (...00)	MB KS MKR
 Actros (...00)	CLUTCH ELECTRONI	4146 K (...00)	MB KS MKR
 Actros (...00)	CLUTCH ELECTRONI	4148 K (...00)	MB KS MKR
 Actros (...00)	CRUISE MANAGEME	1831 (...00)	FR FMR

## Systems supported by ECReader (up to V4,90)

### TRUCKS




























### Mercedes Trucks

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Actros (...00)	CRUISE MANAGEME	1831 K (...00)	FR FMR
 Actros (...00)	CRUISE MANAGEME	1831 L (...00)	FR FMR
 Actros (...00)	CRUISE MANAGEME	1831 L nR (...00)	FR FMR
 Actros (...00)	CRUISE MANAGEME	1835 L (...00)	FR FMR
 Actros (...00)	CRUISE MANAGEME	1835 L nR (...00)	FR FMR
 Actros (...00)	CRUISE MANAGEME	1840 (...00)	FR FMR
 Actros (...00)	CRUISE MANAGEME	1840 K (...00)	FR FMR
 Actros (...00)	CRUISE MANAGEME	1840 L (...00)	FR FMR
 Actros (...00)	CRUISE MANAGEME	1840 L nR (...00)	FR FMR
 Actros (...00)	CRUISE MANAGEME	1843 (...00)	FR FMR
 Actros (...00)	CRUISE MANAGEME	1843 K (...00)	FR FMR
 Actros (...00)	CRUISE MANAGEME	1843 L (...00)	FR FMR
 Actros (...00)	CRUISE MANAGEME	1843 L nR (...00)	FR FMR
 Actros (...00)	CRUISE MANAGEME	1846 (...00)	FR FMR
 Actros (...00)	CRUISE MANAGEME	1846 L (...00)	FR FMR
 Actros (...00)	CRUISE MANAGEME	1848 (...00)	FR FMR
 Actros (...00)	CRUISE MANAGEME	1848 L (...00)	FR FMR
 Actros (...00)	CRUISE MANAGEME	1853 L (...00)	FR FMR
 Actros (...00)	CRUISE MANAGEME	1857 L (...00)	FR FMR
 Actros (...00)	CRUISE MANAGEME	2031 AK (...00)	FR FMR
 Actros (...00)	CRUISE MANAGEME	2531 L (...00)	FR FMR
 Actros (...00)	CRUISE MANAGEME	2535 L (...00)	FR FMR
 Actros (...00)	CRUISE MANAGEME	2540 L (...00)	FR FMR
 Actros (...00)	CRUISE MANAGEME	2543 L (...00)	FR FMR
 Actros (...00)	CRUISE MANAGEME	2546 L (...00)	FR FMR
 Actros (...00)	CRUISE MANAGEME	2548 L (...00)	FR FMR
 Actros (...00)	CRUISE MANAGEME	2553 L (...00)	FR FMR

## Systems supported by ECReader (up to V4,90)

### TRUCKS




























### Mercedes Trucks

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Actros (...00)	CRUISE MANAGEME	2557 L (...00)	FR FMR
 Actros (...00)	CRUISE MANAGEME	3243 (...00)	FR FMR
 Actros (...00)	CRUISE MANAGEME	3335 B (...00)	FR FMR
 Actros (...00)	CRUISE MANAGEME	3335 K (...00)	FR FMR
 Actros (...00)	CRUISE MANAGEME	3340 AK (...00)	FR FMR
 Actros (...00)	CRUISE MANAGEME	3340 B (...00)	FR FMR
 Actros (...00)	CRUISE MANAGEME	3340 K (...00)	FR FMR
 Actros (...00)	CRUISE MANAGEME	3343 K (...00)	FR FMR
 Actros (...00)	CRUISE MANAGEME	3346 K (...00)	FR FMR
 Actros (...00)	CRUISE MANAGEME	3348 K (...00)	FR FMR
 Actros (...00)	CRUISE MANAGEME	4140 B (...00)	FR FMR
 Actros (...00)	CRUISE MANAGEME	4140 K (...00)	FR FMR
 Actros (...00)	CRUISE MANAGEME	4143 K (...00)	FR FMR
 Actros (...00)	CRUISE MANAGEME	4146 K (...00)	FR FMR
 Actros (...00)	CRUISE MANAGEME	4148 K (...00)	FR FMR
 Actros (...00)	DASHBOARD	1831 (...00)	MB INS Comb. Instrument
 Actros (...00)	DASHBOARD	1831 K (...00)	MB INS Comb. Instrument
 Actros (...00)	DASHBOARD	1831 L (...00)	MB INS Comb. Instrument
 Actros (...00)	DASHBOARD	1831 L nR (...00)	MB INS Comb. Instrument
 Actros (...00)	DASHBOARD	1835 L (...00)	MB INS Comb. Instrument
 Actros (...00)	DASHBOARD	1835 L nR (...00)	MB INS Comb. Instrument
 Actros (...00)	DASHBOARD	1840 (...00)	MB INS Comb. Instrument
 Actros (...00)	DASHBOARD	1840 K (...00)	MB INS Comb. Instrument
 Actros (...00)	DASHBOARD	1840 L (...00)	MB INS Comb. Instrument
 Actros (...00)	DASHBOARD	1840 L nR (...00)	MB INS Comb. Instrument
 Actros (...00)	DASHBOARD	1843 (...00)	MB INS Comb. Instrument
 Actros (...00)	DASHBOARD	1843 K (...00)	MB INS Comb. Instrument

## Systems supported by ECUREADER (up to V4,90)

### TRUCKS




























### Mercedes Trucks

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Actros (...00)	DASHBOARD	1843 L (...00)	MB INS Comb. Instrument
 Actros (...00)	DASHBOARD	1843 L nR (...00)	MB INS Comb. Instrument
 Actros (...00)	DASHBOARD	1846 (...00)	MB INS Comb. Instrument
 Actros (...00)	DASHBOARD	1846 L (...00)	MB INS Comb. Instrument
 Actros (...00)	DASHBOARD	1848 (...00)	MB INS Comb. Instrument
 Actros (...00)	DASHBOARD	1848 L (...00)	MB INS Comb. Instrument
 Actros (...00)	DASHBOARD	1853 L (...00)	MB INS Comb. Instrument
 Actros (...00)	DASHBOARD	1857 L (...00)	MB INS Comb. Instrument
 Actros (...00)	DASHBOARD	2031 AK (...00)	MB INS Comb. Instrument
 Actros (...00)	DASHBOARD	2531 L (...00)	MB INS Comb. Instrument
 Actros (...00)	DASHBOARD	2535 L (...00)	MB INS Comb. Instrument
 Actros (...00)	DASHBOARD	2540 L (...00)	MB INS Comb. Instrument
 Actros (...00)	DASHBOARD	2543 L (...00)	MB INS Comb. Instrument
 Actros (...00)	DASHBOARD	2546 L (...00)	MB INS Comb. Instrument
 Actros (...00)	DASHBOARD	2548 L (...00)	MB INS Comb. Instrument
 Actros (...00)	DASHBOARD	2553 L (...00)	MB INS Comb. Instrument
 Actros (...00)	DASHBOARD	2557 L (...00)	MB INS Comb. Instrument
 Actros (...00)	DASHBOARD	3243 (...00)	MB INS Comb. Instrument
 Actros (...00)	DASHBOARD	3335 B (...00)	MB INS Comb. Instrument
 Actros (...00)	DASHBOARD	3335 K (...00)	MB INS Comb. Instrument
 Actros (...00)	DASHBOARD	3340 AK (...00)	MB INS Comb. Instrument
 Actros (...00)	DASHBOARD	3340 B (...00)	MB INS Comb. Instrument
 Actros (...00)	DASHBOARD	3340 K (...00)	MB INS Comb. Instrument
 Actros (...00)	DASHBOARD	3343 K (...00)	MB INS Comb. Instrument
 Actros (...00)	DASHBOARD	3346 K (...00)	MB INS Comb. Instrument
 Actros (...00)	DASHBOARD	3348 K (...00)	MB INS Comb. Instrument
 Actros (...00)	DASHBOARD	4140 B (...00)	MB INS Comb. Instrument

## Systems supported by ECUREADER (up to V4,90)

### TRUCKS




























### Mercedes Trucks

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Actros (...00)	DASHBOARD	4140 K (...00)	MB INS Comb. Instrument
 Actros (...00)	DASHBOARD	4143 K (...00)	MB INS Comb. Instrument
 Actros (...00)	DASHBOARD	4146 K (...00)	MB INS Comb. Instrument
 Actros (...00)	DASHBOARD	4148 K (...00)	MB INS Comb. Instrument
 Actros (...00)	ENGINE MANAGEME	1831 (...00)	MB MR PLD (EDC)
 Actros (...00)	ENGINE MANAGEME	1831 K (...00)	MB MR PLD (EDC)
 Actros (...00)	ENGINE MANAGEME	1831 L (...00)	MB MR PLD (EDC)
 Actros (...00)	ENGINE MANAGEME	1831 L nR (...00)	MB MR PLD (EDC)
 Actros (...00)	ENGINE MANAGEME	1835 L (...00)	MB MR PLD (EDC)
 Actros (...00)	ENGINE MANAGEME	1835 L nR (...00)	MB MR PLD (EDC)
 Actros (...00)	ENGINE MANAGEME	1840 (...00)	MB MR PLD (EDC)
 Actros (...00)	ENGINE MANAGEME	1840 K (...00)	MB MR PLD (EDC)
 Actros (...00)	ENGINE MANAGEME	1840 L (...00)	MB MR PLD (EDC)
 Actros (...00)	ENGINE MANAGEME	1840 L nR (...00)	MB MR PLD (EDC)
 Actros (...00)	ENGINE MANAGEME	1843 (...00)	MB MR PLD (EDC)
 Actros (...00)	ENGINE MANAGEME	1843 K (...00)	MB MR PLD (EDC)
 Actros (...00)	ENGINE MANAGEME	1843 L (...00)	MB MR PLD (EDC)
 Actros (...00)	ENGINE MANAGEME	1843 L nR (...00)	MB MR PLD (EDC)
 Actros (...00)	ENGINE MANAGEME	1846 (...00)	MB MR PLD (EDC)
 Actros (...00)	ENGINE MANAGEME	1846 L (...00)	MB MR PLD (EDC)
 Actros (...00)	ENGINE MANAGEME	1848 (...00)	MB MR PLD (EDC)
 Actros (...00)	ENGINE MANAGEME	1848 L (...00)	MB MR PLD (EDC)
 Actros (...00)	ENGINE MANAGEME	1853 L (...00)	MB MR PLD (EDC)
 Actros (...00)	ENGINE MANAGEME	1857 L (...00)	MB MR PLD (EDC)
 Actros (...00)	ENGINE MANAGEME	2031 AK (...00)	MB MR PLD (EDC)
 Actros (...00)	ENGINE MANAGEME	2531 L (...00)	MB MR PLD (EDC)
 Actros (...00)	ENGINE MANAGEME	2535 L (...00)	MB MR PLD (EDC)

## Systems supported by ECReader (up to V4,90)

### TRUCKS




























### Mercedes Trucks

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Actros (...00)	ENGINE MANAGEME	2540 L (...00)	MB MR PLD (EDC)
 Actros (...00)	ENGINE MANAGEME	2543 L (...00)	MB MR PLD (EDC)
 Actros (...00)	ENGINE MANAGEME	2546 L (...00)	MB MR PLD (EDC)
 Actros (...00)	ENGINE MANAGEME	2548 L (...00)	MB MR PLD (EDC)
 Actros (...00)	ENGINE MANAGEME	2553 L (...00)	MB MR PLD (EDC)
 Actros (...00)	ENGINE MANAGEME	2557 L (...00)	MB MR PLD (EDC)
 Actros (...00)	ENGINE MANAGEME	3243 (...00)	MB MR PLD (EDC)
 Actros (...00)	ENGINE MANAGEME	3335 B (...00)	MB MR PLD (EDC)
 Actros (...00)	ENGINE MANAGEME	3335 K (...00)	MB MR PLD (EDC)
 Actros (...00)	ENGINE MANAGEME	3340 AK (...00)	MB MR PLD (EDC)
 Actros (...00)	ENGINE MANAGEME	3340 B (...00)	MB MR PLD (EDC)
 Actros (...00)	ENGINE MANAGEME	3340 K (...00)	MB MR PLD (EDC)
 Actros (...00)	ENGINE MANAGEME	3343 K (...00)	MB MR PLD (EDC)
 Actros (...00)	ENGINE MANAGEME	3346 K (...00)	MB MR PLD (EDC)
 Actros (...00)	ENGINE MANAGEME	3348 K (...00)	MB MR PLD (EDC)
 Actros (...00)	ENGINE MANAGEME	4140 B (...00)	MB MR PLD (EDC)
 Actros (...00)	ENGINE MANAGEME	4140 K (...00)	MB MR PLD (EDC)
 Actros (...00)	ENGINE MANAGEME	4143 K (...00)	MB MR PLD (EDC)
 Actros (...00)	ENGINE MANAGEME	4146 K (...00)	MB MR PLD (EDC)
 Actros (...00)	ENGINE MANAGEME	4148 K (...00)	MB MR PLD (EDC)
 Actros (...00)	GEARBOX MANAGEM	1831 (...00)	MB GS EPS
 Actros (...00)	GEARBOX MANAGEM	1831 K (...00)	MB GS EPS
 Actros (...00)	GEARBOX MANAGEM	1831 L (...00)	MB GS EPS
 Actros (...00)	GEARBOX MANAGEM	1831 L nR (...00)	MB GS EPS
 Actros (...00)	GEARBOX MANAGEM	1835 L (...00)	MB GS EPS
 Actros (...00)	GEARBOX MANAGEM	1835 L nR (...00)	MB GS EPS
 Actros (...00)	GEARBOX MANAGEM	1840 (...00)	MB GS EPS

## Systems supported by ECReader (up to V4,90)

### TRUCKS




























### Mercedes Trucks

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Actros (...00)	GEARBOX MANAGEM	1840 K (...00)	MB GS EPS
 Actros (...00)	GEARBOX MANAGEM	1840 L (...00)	MB GS EPS
 Actros (...00)	GEARBOX MANAGEM	1840 L nR (...00)	MB GS EPS
 Actros (...00)	GEARBOX MANAGEM	1843 (...00)	MB GS EPS
 Actros (...00)	GEARBOX MANAGEM	1843 K (...00)	MB GS EPS
 Actros (...00)	GEARBOX MANAGEM	1843 L (...00)	MB GS EPS
 Actros (...00)	GEARBOX MANAGEM	1843 L nR (...00)	MB GS EPS
 Actros (...00)	GEARBOX MANAGEM	1846 (...00)	MB GS EPS
 Actros (...00)	GEARBOX MANAGEM	1846 L (...00)	MB GS EPS
 Actros (...00)	GEARBOX MANAGEM	1848 (...00)	MB GS EPS
 Actros (...00)	GEARBOX MANAGEM	1848 L (...00)	MB GS EPS
 Actros (...00)	GEARBOX MANAGEM	1853 L (...00)	MB GS EPS
 Actros (...00)	GEARBOX MANAGEM	1857 L (...00)	MB GS EPS
 Actros (...00)	GEARBOX MANAGEM	2031 AK (...00)	MB GS EPS
 Actros (...00)	GEARBOX MANAGEM	2531 L (...00)	MB GS EPS
 Actros (...00)	GEARBOX MANAGEM	2535 L (...00)	MB GS EPS
 Actros (...00)	GEARBOX MANAGEM	2540 L (...00)	MB GS EPS
 Actros (...00)	GEARBOX MANAGEM	2543 L (...00)	MB GS EPS
 Actros (...00)	GEARBOX MANAGEM	2546 L (...00)	MB GS EPS
 Actros (...00)	GEARBOX MANAGEM	2548 L (...00)	MB GS EPS
 Actros (...00)	GEARBOX MANAGEM	2553 L (...00)	MB GS EPS
 Actros (...00)	GEARBOX MANAGEM	2557 L (...00)	MB GS EPS
 Actros (...00)	GEARBOX MANAGEM	3243 (...00)	MB GS EPS
 Actros (...00)	GEARBOX MANAGEM	3335 B (...00)	MB GS EPS
 Actros (...00)	GEARBOX MANAGEM	3335 K (...00)	MB GS EPS
 Actros (...00)	GEARBOX MANAGEM	3340 AK (...00)	MB GS EPS
 Actros (...00)	GEARBOX MANAGEM	3340 B (...00)	MB GS EPS

## Systems supported by ECReader (up to V4,90)

### TRUCKS




























### Mercedes Trucks

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Actros (...00)	GEARBOX MANAGEM	3340 K (...00)	MB GS EPS
 Actros (...00)	GEARBOX MANAGEM	3343 K (...00)	MB GS EPS
 Actros (...00)	GEARBOX MANAGEM	3346 K (...00)	MB GS EPS
 Actros (...00)	GEARBOX MANAGEM	3348 K (...00)	MB GS EPS
 Actros (...00)	GEARBOX MANAGEM	4140 B (...00)	MB GS EPS
 Actros (...00)	GEARBOX MANAGEM	4140 K (...00)	MB GS EPS
 Actros (...00)	GEARBOX MANAGEM	4143 K (...00)	MB GS EPS
 Actros (...00)	GEARBOX MANAGEM	4146 K (...00)	MB GS EPS
 Actros (...00)	GEARBOX MANAGEM	4148 K (...00)	MB GS EPS
 Actros (...00)	MAINTENANCE SYST	1831 (...00)	MB WS FSS
 Actros (...00)	MAINTENANCE SYST	1831 K (...00)	MB WS FSS
 Actros (...00)	MAINTENANCE SYST	1831 L (...00)	MB WS FSS
 Actros (...00)	MAINTENANCE SYST	1831 L nR (...00)	MB WS FSS
 Actros (...00)	MAINTENANCE SYST	1835 L (...00)	MB WS FSS
 Actros (...00)	MAINTENANCE SYST	1835 L nR (...00)	MB WS FSS
 Actros (...00)	MAINTENANCE SYST	1840 (...00)	MB WS FSS
 Actros (...00)	MAINTENANCE SYST	1840 K (...00)	MB WS FSS
 Actros (...00)	MAINTENANCE SYST	1840 L (...00)	MB WS FSS
 Actros (...00)	MAINTENANCE SYST	1840 L nR (...00)	MB WS FSS
 Actros (...00)	MAINTENANCE SYST	1843 (...00)	MB WS FSS
 Actros (...00)	MAINTENANCE SYST	1843 K (...00)	MB WS FSS
 Actros (...00)	MAINTENANCE SYST	1843 L (...00)	MB WS FSS
 Actros (...00)	MAINTENANCE SYST	1843 L nR (...00)	MB WS FSS
 Actros (...00)	MAINTENANCE SYST	1846 (...00)	MB WS FSS
 Actros (...00)	MAINTENANCE SYST	1846 L (...00)	MB WS FSS
 Actros (...00)	MAINTENANCE SYST	1848 (...00)	MB WS FSS
 Actros (...00)	MAINTENANCE SYST	1848 L (...00)	MB WS FSS

## Systems supported by ECReader (up to V4,90)

### TRUCKS




























### Mercedes Trucks

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Actros (...00)	MAINTENANCE SYST	1853 L (...00)	MB WS FSS
 Actros (...00)	MAINTENANCE SYST	1857 L (...00)	MB WS FSS
 Actros (...00)	MAINTENANCE SYST	2031 AK (...00)	MB WS FSS
 Actros (...00)	MAINTENANCE SYST	2531 L (...00)	MB WS FSS
 Actros (...00)	MAINTENANCE SYST	2535 L (...00)	MB WS FSS
 Actros (...00)	MAINTENANCE SYST	2540 L (...00)	MB WS FSS
 Actros (...00)	MAINTENANCE SYST	2543 L (...00)	MB WS FSS
 Actros (...00)	MAINTENANCE SYST	2546 L (...00)	MB WS FSS
 Actros (...00)	MAINTENANCE SYST	2548 L (...00)	MB WS FSS
 Actros (...00)	MAINTENANCE SYST	2553 L (...00)	MB WS FSS
 Actros (...00)	MAINTENANCE SYST	2557 L (...00)	MB WS FSS
 Actros (...00)	MAINTENANCE SYST	3243 (...00)	MB WS FSS
 Actros (...00)	MAINTENANCE SYST	3335 B (...00)	MB WS FSS
 Actros (...00)	MAINTENANCE SYST	3335 K (...00)	MB WS FSS
 Actros (...00)	MAINTENANCE SYST	3340 AK (...00)	MB WS FSS
 Actros (...00)	MAINTENANCE SYST	3340 B (...00)	MB WS FSS
 Actros (...00)	MAINTENANCE SYST	3340 K (...00)	MB WS FSS
 Actros (...00)	MAINTENANCE SYST	3343 K (...00)	MB WS FSS
 Actros (...00)	MAINTENANCE SYST	3346 K (...00)	MB WS FSS
 Actros (...00)	MAINTENANCE SYST	3348 K (...00)	MB WS FSS
 Actros (...00)	MAINTENANCE SYST	4140 B (...00)	MB WS FSS
 Actros (...00)	MAINTENANCE SYST	4140 K (...00)	MB WS FSS
 Actros (...00)	MAINTENANCE SYST	4143 K (...00)	MB WS FSS
 Actros (...00)	MAINTENANCE SYST	4146 K (...00)	MB WS FSS
 Actros (...00)	MAINTENANCE SYST	4148 K (...00)	MB WS FSS
 Actros (...00)	PRELIMINARY HEATI	1831 (...00)	MB FLA Termostart.
 Actros (...00)	PRELIMINARY HEATI	1831 K (...00)	MB FLA Termostart.

## Systems supported by ECReader (up to V4,90)

### TRUCKS




























### Mercedes Trucks

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Actros (...00)	PRELIMINARY HEATI	1831 L (...00)	MB FLA Termostart.
 Actros (...00)	PRELIMINARY HEATI	1831 L nR (...00)	MB FLA Termostart.
 Actros (...00)	PRELIMINARY HEATI	1835 L (...00)	MB FLA Termostart.
 Actros (...00)	PRELIMINARY HEATI	1835 L nR (...00)	MB FLA Termostart.
 Actros (...00)	PRELIMINARY HEATI	1840 (...00)	MB FLA Termostart.
 Actros (...00)	PRELIMINARY HEATI	1840 K (...00)	MB FLA Termostart.
 Actros (...00)	PRELIMINARY HEATI	1840 L (...00)	MB FLA Termostart.
 Actros (...00)	PRELIMINARY HEATI	1840 L nR (...00)	MB FLA Termostart.
 Actros (...00)	PRELIMINARY HEATI	1843 (...00)	MB FLA Termostart.
 Actros (...00)	PRELIMINARY HEATI	1843 K (...00)	MB FLA Termostart.
 Actros (...00)	PRELIMINARY HEATI	1843 L (...00)	MB FLA Termostart.
 Actros (...00)	PRELIMINARY HEATI	1843 L nR (...00)	MB FLA Termostart.
 Actros (...00)	PRELIMINARY HEATI	1846 (...00)	MB FLA Termostart.
 Actros (...00)	PRELIMINARY HEATI	1846 L (...00)	MB FLA Termostart.
 Actros (...00)	PRELIMINARY HEATI	1848 (...00)	MB FLA Termostart.
 Actros (...00)	PRELIMINARY HEATI	1848 L (...00)	MB FLA Termostart.
 Actros (...00)	PRELIMINARY HEATI	1853 L (...00)	MB FLA Termostart.
 Actros (...00)	PRELIMINARY HEATI	1857 L (...00)	MB FLA Termostart.
 Actros (...00)	PRELIMINARY HEATI	2031 AK (...00)	MB FLA Termostart.
 Actros (...00)	PRELIMINARY HEATI	2531 L (...00)	MB FLA Termostart.
 Actros (...00)	PRELIMINARY HEATI	2535 L (...00)	MB FLA Termostart.
 Actros (...00)	PRELIMINARY HEATI	2540 L (...00)	MB FLA Termostart.
 Actros (...00)	PRELIMINARY HEATI	2543 L (...00)	MB FLA Termostart.
 Actros (...00)	PRELIMINARY HEATI	2546 L (...00)	MB FLA Termostart.
 Actros (...00)	PRELIMINARY HEATI	2548 L (...00)	MB FLA Termostart.
 Actros (...00)	PRELIMINARY HEATI	2553 L (...00)	MB FLA Termostart.
 Actros (...00)	PRELIMINARY HEATI	2557 L (...00)	MB FLA Termostart.

## Systems supported by ECReader (up to V4,90)

### TRUCKS
























### Mercedes Trucks

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Actros (...00)	PRELIMINARY HEATI	3243 (...00)	MB FLA Termostart.
 Actros (...00)	PRELIMINARY HEATI	3335 B (...00)	MB FLA Termostart.
 Actros (...00)	PRELIMINARY HEATI	3335 K (...00)	MB FLA Termostart.
 Actros (...00)	PRELIMINARY HEATI	3340 AK (...00)	MB FLA Termostart.
 Actros (...00)	PRELIMINARY HEATI	3340 B (...00)	MB FLA Termostart.
 Actros (...00)	PRELIMINARY HEATI	3340 K (...00)	MB FLA Termostart.
 Actros (...00)	PRELIMINARY HEATI	3343 K (...00)	MB FLA Termostart.
 Actros (...00)	PRELIMINARY HEATI	3346 K (...00)	MB FLA Termostart.
 Actros (...00)	PRELIMINARY HEATI	3348 K (...00)	MB FLA Termostart.
 Actros (...00)	PRELIMINARY HEATI	4140 B (...00)	MB FLA Termostart.
 Actros (...00)	PRELIMINARY HEATI	4140 K (...00)	MB FLA Termostart.
 Actros (...00)	PRELIMINARY HEATI	4143 K (...00)	MB FLA Termostart.
 Actros (...00)	PRELIMINARY HEATI	4146 K (...00)	MB FLA Termostart.
 Actros (...00)	PRELIMINARY HEATI	4148 K (...00)	MB FLA Termostart.
 Actros (...00)	RATIO SEL. MANAGE	1831 (...00)	MB AG AGE
 Actros (...00)	RATIO SEL. MANAGE	1831 K (...00)	MB AG AGE
 Actros (...00)	RATIO SEL. MANAGE	1831 L (...00)	MB AG AGE
 Actros (...00)	RATIO SEL. MANAGE	1831 L nR (...00)	MB AG AGE
 Actros (...00)	RATIO SEL. MANAGE	1835 L (...00)	MB AG AGE
 Actros (...00)	RATIO SEL. MANAGE	1835 L nR (...00)	MB AG AGE
 Actros (...00)	RATIO SEL. MANAGE	1840 (...00)	MB AG AGE
 Actros (...00)	RATIO SEL. MANAGE	1840 K (...00)	MB AG AGE
 Actros (...00)	RATIO SEL. MANAGE	1840 L (...00)	MB AG AGE
 Actros (...00)	RATIO SEL. MANAGE	1840 L nR (...00)	MB AG AGE
 Actros (...00)	RATIO SEL. MANAGE	1843 (...00)	MB AG AGE
 Actros (...00)	RATIO SEL. MANAGE	1843 K (...00)	MB AG AGE
 Actros (...00)	RATIO SEL. MANAGE	1843 L (...00)	MB AG AGE

## Systems supported by ECReader (up to V4,90)

### TRUCKS







### Mercedes Trucks

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Actros (...00)	RATIO SEL. MANAGE	1843 L nR (...00)	MB AG AGE
 Actros (...00)	RATIO SEL. MANAGE	1846 (...00)	MB AG AGE
 Actros (...00)	RATIO SEL. MANAGE	1846 L (...00)	MB AG AGE
 Actros (...00)	RATIO SEL. MANAGE	1848 (...00)	MB AG AGE
 Actros (...00)	RATIO SEL. MANAGE	1848 L (...00)	MB AG AGE
 Actros (...00)	RATIO SEL. MANAGE	1853 L (...00)	MB AG AGE
 Actros (...00)	RATIO SEL. MANAGE	1857 L (...00)	MB AG AGE
 Actros (...00)	RATIO SEL. MANAGE	2031 AK (...00)	MB AG AGE
 Actros (...00)	RATIO SEL. MANAGE	2531 L (...00)	MB AG AGE
 Actros (...00)	RATIO SEL. MANAGE	2535 L (...00)	MB AG AGE
 Actros (...00)	RATIO SEL. MANAGE	2540 L (...00)	MB AG AGE
 Actros (...00)	RATIO SEL. MANAGE	2543 L (...00)	MB AG AGE
 Actros (...00)	RATIO SEL. MANAGE	2546 L (...00)	MB AG AGE
 Actros (...00)	RATIO SEL. MANAGE	2548 L (...00)	MB AG AGE
 Actros (...00)	RATIO SEL. MANAGE	2553 L (...00)	MB AG AGE
 Actros (...00)	RATIO SEL. MANAGE	2557 L (...00)	MB AG AGE
 Actros (...00)	RATIO SEL. MANAGE	3243 (...00)	MB AG AGE
 Actros (...00)	RATIO SEL. MANAGE	3335 B (...00)	MB AG AGE
 Actros (...00)	RATIO SEL. MANAGE	3335 K (...00)	MB AG AGE
 Actros (...00)	RATIO SEL. MANAGE	3340 AK (...00)	MB AG AGE
 Actros (...00)	RATIO SEL. MANAGE	3340 B (...00)	MB AG AGE
 Actros (...00)	RATIO SEL. MANAGE	3340 K (...00)	MB AG AGE
 Actros (...00)	RATIO SEL. MANAGE	3343 K (...00)	MB AG AGE
 Actros (...00)	RATIO SEL. MANAGE	3346 K (...00)	MB AG AGE
 Actros (...00)	RATIO SEL. MANAGE	3348 K (...00)	MB AG AGE
 Actros (...00)	RATIO SEL. MANAGE	4140 B (...00)	MB AG AGE
 Actros (...00)	RATIO SEL. MANAGE	4140 K (...00)	MB AG AGE

## Systems supported by ECUREADER (up to V4,90)

### TRUCKS




























### Mercedes Trucks

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Actros (...00)	RATIO SEL. MANAGE	4143 K (...00)	MB AG AGE
 Actros (...00)	RATIO SEL. MANAGE	4146 K (...00)	MB AG AGE
 Actros (...00)	RATIO SEL. MANAGE	4148 K (...00)	MB AG AGE
 Actros (...00)	SERVICE LIGHT RES	1831 (...00)	MB WS FSS
 Actros (...00)	SERVICE LIGHT RES	1831 K (...00)	MB WS FSS
 Actros (...00)	SERVICE LIGHT RES	1831 L (...00)	MB WS FSS
 Actros (...00)	SERVICE LIGHT RES	1831 L nR (...00)	MB WS FSS
 Actros (...00)	SERVICE LIGHT RES	1835 L (...00)	MB WS FSS
 Actros (...00)	SERVICE LIGHT RES	1835 L nR (...00)	MB WS FSS
 Actros (...00)	SERVICE LIGHT RES	1840 (...00)	MB WS FSS
 Actros (...00)	SERVICE LIGHT RES	1840 K (...00)	MB WS FSS
 Actros (...00)	SERVICE LIGHT RES	1840 L (...00)	MB WS FSS
 Actros (...00)	SERVICE LIGHT RES	1840 L nR (...00)	MB WS FSS
 Actros (...00)	SERVICE LIGHT RES	1843 (...00)	MB WS FSS
 Actros (...00)	SERVICE LIGHT RES	1843 K (...00)	MB WS FSS
 Actros (...00)	SERVICE LIGHT RES	1843 L (...00)	MB WS FSS
 Actros (...00)	SERVICE LIGHT RES	1843 L nR (...00)	MB WS FSS
 Actros (...00)	SERVICE LIGHT RES	1846 (...00)	MB WS FSS
 Actros (...00)	SERVICE LIGHT RES	1846 L (...00)	MB WS FSS
 Actros (...00)	SERVICE LIGHT RES	1848 (...00)	MB WS FSS
 Actros (...00)	SERVICE LIGHT RES	1848 L (...00)	MB WS FSS
 Actros (...00)	SERVICE LIGHT RES	1853 L (...00)	MB WS FSS
 Actros (...00)	SERVICE LIGHT RES	1857 L (...00)	MB WS FSS
 Actros (...00)	SERVICE LIGHT RES	2031 AK (...00)	MB WS FSS
 Actros (...00)	SERVICE LIGHT RES	2531 L (...00)	MB WS FSS
 Actros (...00)	SERVICE LIGHT RES	2535 L (...00)	MB WS FSS
 Actros (...00)	SERVICE LIGHT RES	2540 L (...00)	MB WS FSS

## Systems supported by ECReader (up to V4,90)

### TRUCKS




























### Mercedes Trucks

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Actros (...00)	SERVICE LIGHT RES	2543 L (...00)	MB WS FSS
 Actros (...00)	SERVICE LIGHT RES	2546 L (...00)	MB WS FSS
 Actros (...00)	SERVICE LIGHT RES	2548 L (...00)	MB WS FSS
 Actros (...00)	SERVICE LIGHT RES	2553 L (...00)	MB WS FSS
 Actros (...00)	SERVICE LIGHT RES	2557 L (...00)	MB WS FSS
 Actros (...00)	SERVICE LIGHT RES	3243 (...00)	MB WS FSS
 Actros (...00)	SERVICE LIGHT RES	3335 B (...00)	MB WS FSS
 Actros (...00)	SERVICE LIGHT RES	3335 K (...00)	MB WS FSS
 Actros (...00)	SERVICE LIGHT RES	3340 AK (...00)	MB WS FSS
 Actros (...00)	SERVICE LIGHT RES	3340 B (...00)	MB WS FSS
 Actros (...00)	SERVICE LIGHT RES	3340 K (...00)	MB WS FSS
 Actros (...00)	SERVICE LIGHT RES	3343 K (...00)	MB WS FSS
 Actros (...00)	SERVICE LIGHT RES	3346 K (...00)	MB WS FSS
 Actros (...00)	SERVICE LIGHT RES	3348 K (...00)	MB WS FSS
 Actros (...00)	SERVICE LIGHT RES	4140 K (...00)	MB WS FSS
 Actros (...00)	SERVICE LIGHT RES	4143 K (...00)	MB WS FSS
 Actros (...00)	SERVICE LIGHT RES	4146 K (...00)	MB WS FSS
 Actros (...00)	SERVICE LIGHT RES	4148 K (...00)	MB WS FSS
 Actros (...00)	SUSPENSION CONTR	1831 (...00)	Wabco NR ECAS
 Actros (...00)	SUSPENSION CONTR	1831 K (...00)	Wabco NR ECAS
 Actros (...00)	SUSPENSION CONTR	1831 L (...00)	Wabco NR ECAS
 Actros (...00)	SUSPENSION CONTR	1831 L nR (...00)	Wabco NR ECAS
 Actros (...00)	SUSPENSION CONTR	1835 L (...00)	Wabco NR ECAS
 Actros (...00)	SUSPENSION CONTR	1835 L nR (...00)	Wabco NR ECAS
 Actros (...00)	SUSPENSION CONTR	1840 (...00)	Wabco NR ECAS
 Actros (...00)	SUSPENSION CONTR	1840 K (...00)	Wabco NR ECAS
 Actros (...00)	SUSPENSION CONTR	1840 L (...00)	Wabco NR ECAS

## Systems supported by ECReader (up to V4,90)

### TRUCKS



























### Mercedes Trucks

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Actros (...00)	SUSPENSION CONTR	1840 L nR (...00)	Wabco NR ECAS
 Actros (...00)	SUSPENSION CONTR	1843 (...00)	Wabco NR ECAS
 Actros (...00)	SUSPENSION CONTR	1843 K (...00)	Wabco NR ECAS
 Actros (...00)	SUSPENSION CONTR	1843 L (...00)	Wabco NR ECAS
 Actros (...00)	SUSPENSION CONTR	1843 L nR (...00)	Wabco NR ECAS
 Actros (...00)	SUSPENSION CONTR	1846 (...00)	Wabco NR ECAS
 Actros (...00)	SUSPENSION CONTR	1846 L (...00)	Wabco NR ECAS
 Actros (...00)	SUSPENSION CONTR	1848 (...00)	Wabco NR ECAS
 Actros (...00)	SUSPENSION CONTR	1848 L (...00)	Wabco NR ECAS
 Actros (...00)	SUSPENSION CONTR	1853 L (...00)	Wabco NR ECAS
 Actros (...00)	SUSPENSION CONTR	1857 L (...00)	Wabco NR ECAS
 Actros (...00)	SUSPENSION CONTR	2031 AK (...00)	Wabco NR ECAS
 Actros (...00)	SUSPENSION CONTR	2531 L (...00)	Wabco NR ECAS
 Actros (...00)	SUSPENSION CONTR	2535 L (...00)	Wabco NR ECAS
 Actros (...00)	SUSPENSION CONTR	2540 L (...00)	Wabco NR ECAS
 Actros (...00)	SUSPENSION CONTR	2543 L (...00)	Wabco NR ECAS
 Actros (...00)	SUSPENSION CONTR	2546 L (...00)	Wabco NR ECAS
 Actros (...00)	SUSPENSION CONTR	2548 L (...00)	Wabco NR ECAS
 Actros (...00)	SUSPENSION CONTR	2553 L (...00)	Wabco NR ECAS
 Actros (...00)	SUSPENSION CONTR	2557 L (...00)	Wabco NR ECAS
 Actros (...00)	SUSPENSION CONTR	3243 (...00)	Wabco NR ECAS
 Actros (...00)	SUSPENSION CONTR	3335 B (...00)	Wabco NR ECAS
 Actros (...00)	SUSPENSION CONTR	3335 K (...00)	Wabco NR ECAS
 Actros (...00)	SUSPENSION CONTR	3340 AK (...00)	Wabco NR ECAS
 Actros (...00)	SUSPENSION CONTR	3340 B (...00)	Wabco NR ECAS
 Actros (...00)	SUSPENSION CONTR	3340 K (...00)	Wabco NR ECAS
 Actros (...00)	SUSPENSION CONTR	3343 K (...00)	Wabco NR ECAS

## Systems supported by ECReader (up to V4,90)

### TRUCKS




























### Mercedes Trucks

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Actros (...00)	SUSPENSION CONTR	3346 K (...00)	Wabco NR ECAS
 Actros (...00)	SUSPENSION CONTR	3348 K (...00)	Wabco NR ECAS
 Actros (...00)	SUSPENSION CONTR	4140 B (...00)	Wabco NR ECAS
 Actros (...00)	SUSPENSION CONTR	4140 K (...00)	Wabco NR ECAS
 Actros (...00)	SUSPENSION CONTR	4143 K (...00)	Wabco NR ECAS
 Actros (...00)	SUSPENSION CONTR	4146 K (...00)	Wabco NR ECAS
 Actros (...00)	SUSPENSION CONTR	4148 K (...00)	Wabco NR ECAS
 Actros (01-02)	ABS	1831 (01-02)	MB ABS
 Actros (01-02)	ABS	1831 K (01-02)	MB ABS
 Actros (01-02)	ABS	1831 L (01-02)	MB ABS
 Actros (01-02)	ABS	1831 L nR (01-02)	MB ABS
 Actros (01-02)	ABS	1835 L (01-02)	MB ABS
 Actros (01-02)	ABS	1835 L nR (01-02)	MB ABS
 Actros (01-02)	ABS	1840 (01-02)	MB ABS
 Actros (01-02)	ABS	1840 K (01-02)	MB ABS
 Actros (01-02)	ABS	1840 L (01-02)	MB ABS
 Actros (01-02)	ABS	1840 L nR (01-02)	MB ABS
 Actros (01-02)	ABS	1843 (01-02)	MB ABS
 Actros (01-02)	ABS	1843 K (01-02)	MB ABS
 Actros (01-02)	ABS	1843 L (01-02)	MB ABS
 Actros (01-02)	ABS	1843 L nR (01-02)	MB ABS
 Actros (01-02)	ABS	1846 (01-02)	MB ABS
 Actros (01-02)	ABS	1846 L (01-02)	MB ABS
 Actros (01-02)	ABS	1848 (01-02)	MB ABS
 Actros (01-02)	ABS	1848 L (01-02)	MB ABS
 Actros (01-02)	ABS	1853 L (01-02)	MB ABS

## Systems supported by ECReader (up to V4,90)

### TRUCKS



























### Mercedes Trucks

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Actros (01-02)	ABS	1857 L (01-02)	MB ABS
 Actros (01-02)	ABS	2031 AK (01-02)	MB ABS
 Actros (01-02)	ABS	2531 L (01-02)	MB ABS
 Actros (01-02)	ABS	2535 L (01-02)	MB ABS
 Actros (01-02)	ABS	2540 L (01-02)	MB ABS
 Actros (01-02)	ABS	2543 L (01-02)	MB ABS
 Actros (01-02)	ABS	2546 L (01-02)	MB ABS
 Actros (01-02)	ABS	2548 L (01-02)	MB ABS
 Actros (01-02)	ABS	2553 L (01-02)	MB ABS
 Actros (01-02)	ABS	2557 L (01-02)	MB ABS
 Actros (01-02)	ABS	3243 (01-02)	MB ABS
 Actros (01-02)	ABS	3335 B (01-02)	MB ABS
 Actros (01-02)	ABS	3335 K (01-02)	MB ABS
 Actros (01-02)	ABS	3340 AK (01-02)	MB ABS
 Actros (01-02)	ABS	3340 B (01-02)	MB ABS
 Actros (01-02)	ABS	3340 K (01-02)	MB ABS
 Actros (01-02)	ABS	3343 K (01-02)	MB ABS
 Actros (01-02)	ABS	3346 K (01-02)	MB ABS
 Actros (01-02)	ABS	3348 K (01-02)	MB ABS
 Actros (01-02)	ABS	4140 B (01-02)	MB ABS
 Actros (01-02)	ABS	4140 K (01-02)	MB ABS
 Actros (01-02)	ABS	4143 K (01-02)	MB ABS
 Actros (01-02)	ABS	4146 K (01-02)	MB ABS
 Actros (01-02)	ABS	4148 K (01-02)	MB ABS
 Actros (01-02)	BRAKE POWER SUP	1831 (01-02)	MB RS Retarder
 Actros (01-02)	BRAKE POWER SUP	1831 K (01-02)	MB RS Retarder
 Actros (01-02)	BRAKE POWER SUP	1831 L (01-02)	MB RS Retarder

## Systems supported by ECReader (up to V4,90)

### TRUCKS




























### Mercedes Trucks

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Actros (01-02)	BRAKE POWER SUP	1831 L nR (01-02)	MB RS Retarder
 Actros (01-02)	BRAKE POWER SUP	1835 L (01-02)	MB RS Retarder
 Actros (01-02)	BRAKE POWER SUP	1835 L nR (01-02)	MB RS Retarder
 Actros (01-02)	BRAKE POWER SUP	1840 (01-02)	MB RS Retarder
 Actros (01-02)	BRAKE POWER SUP	1840 K (01-02)	MB RS Retarder
 Actros (01-02)	BRAKE POWER SUP	1840 L (01-02)	MB RS Retarder
 Actros (01-02)	BRAKE POWER SUP	1840 L nR (01-02)	MB RS Retarder
 Actros (01-02)	BRAKE POWER SUP	1843 (01-02)	MB RS Retarder
 Actros (01-02)	BRAKE POWER SUP	1843 K (01-02)	MB RS Retarder
 Actros (01-02)	BRAKE POWER SUP	1843 L (01-02)	MB RS Retarder
 Actros (01-02)	BRAKE POWER SUP	1843 L nR (01-02)	MB RS Retarder
 Actros (01-02)	BRAKE POWER SUP	1846 (01-02)	MB RS Retarder
 Actros (01-02)	BRAKE POWER SUP	1846 L (01-02)	MB RS Retarder
 Actros (01-02)	BRAKE POWER SUP	1848 (01-02)	MB RS Retarder
 Actros (01-02)	BRAKE POWER SUP	1848 L (01-02)	MB RS Retarder
 Actros (01-02)	BRAKE POWER SUP	1853 L (01-02)	MB RS Retarder
 Actros (01-02)	BRAKE POWER SUP	1857 L (01-02)	MB RS Retarder
 Actros (01-02)	BRAKE POWER SUP	2031 AK (01-02)	MB RS Retarder
 Actros (01-02)	BRAKE POWER SUP	2531 L (01-02)	MB RS Retarder
 Actros (01-02)	BRAKE POWER SUP	2535 L (01-02)	MB RS Retarder
 Actros (01-02)	BRAKE POWER SUP	2540 L (01-02)	MB RS Retarder
 Actros (01-02)	BRAKE POWER SUP	2543 L (01-02)	MB RS Retarder
 Actros (01-02)	BRAKE POWER SUP	2546 L (01-02)	MB RS Retarder
 Actros (01-02)	BRAKE POWER SUP	2548 L (01-02)	MB RS Retarder
 Actros (01-02)	BRAKE POWER SUP	2553 L (01-02)	MB RS Retarder
 Actros (01-02)	BRAKE POWER SUP	2557 L (01-02)	MB RS Retarder
 Actros (01-02)	BRAKE POWER SUP	3243 (01-02)	MB RS Retarder

## Systems supported by ECUREADER (up to V4,90)

### TRUCKS




























### Mercedes Trucks

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Actros (01-02)	BRAKE POWER SUP	3335 B (01-02)	MB RS Retarder
 Actros (01-02)	BRAKE POWER SUP	3335 K (01-02)	MB RS Retarder
 Actros (01-02)	BRAKE POWER SUP	3340 AK (01-02)	MB RS Retarder
 Actros (01-02)	BRAKE POWER SUP	3340 B (01-02)	MB RS Retarder
 Actros (01-02)	BRAKE POWER SUP	3340 K (01-02)	MB RS Retarder
 Actros (01-02)	BRAKE POWER SUP	3343 K (01-02)	MB RS Retarder
 Actros (01-02)	BRAKE POWER SUP	3346 K (01-02)	MB RS Retarder
 Actros (01-02)	BRAKE POWER SUP	3348 K (01-02)	MB RS Retarder
 Actros (01-02)	BRAKE POWER SUP	4140 B (01-02)	MB RS Retarder
 Actros (01-02)	BRAKE POWER SUP	4140 K (01-02)	MB RS Retarder
 Actros (01-02)	BRAKE POWER SUP	4143 K (01-02)	MB RS Retarder
 Actros (01-02)	BRAKE POWER SUP	4146 K (01-02)	MB RS Retarder
 Actros (01-02)	BRAKE POWER SUP	4148 K (01-02)	MB RS Retarder
 Actros (01-02)	BRAKE SYS. MANAG	1831 (01-02)	MB BS EPB
 Actros (01-02)	BRAKE SYS. MANAG	1831 K (01-02)	MB BS EPB
 Actros (01-02)	BRAKE SYS. MANAG	1831 L (01-02)	MB BS EPB
 Actros (01-02)	BRAKE SYS. MANAG	1831 L nR (01-02)	MB BS EPB
 Actros (01-02)	BRAKE SYS. MANAG	1835 L (01-02)	MB BS EPB
 Actros (01-02)	BRAKE SYS. MANAG	1835 L nR (01-02)	MB BS EPB
 Actros (01-02)	BRAKE SYS. MANAG	1840 (01-02)	MB BS EPB
 Actros (01-02)	BRAKE SYS. MANAG	1840 K (01-02)	MB BS EPB
 Actros (01-02)	BRAKE SYS. MANAG	1840 L (01-02)	MB BS EPB
 Actros (01-02)	BRAKE SYS. MANAG	1840 L nR (01-02)	MB BS EPB
 Actros (01-02)	BRAKE SYS. MANAG	1843 (01-02)	MB BS EPB
 Actros (01-02)	BRAKE SYS. MANAG	1843 K (01-02)	MB BS EPB
 Actros (01-02)	BRAKE SYS. MANAG	1843 L (01-02)	MB BS EPB
 Actros (01-02)	BRAKE SYS. MANAG	1843 L nR (01-02)	MB BS EPB

## Systems supported by ECReader (up to V4,90)

### TRUCKS




























### Mercedes Trucks

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Actros (01-02)	BRAKE SYS. MANAG	1846 (01-02)	MB BS EPB
 Actros (01-02)	BRAKE SYS. MANAG	1846 L (01-02)	MB BS EPB
 Actros (01-02)	BRAKE SYS. MANAG	1848 (01-02)	MB BS EPB
 Actros (01-02)	BRAKE SYS. MANAG	1848 L (01-02)	MB BS EPB
 Actros (01-02)	BRAKE SYS. MANAG	1853 L (01-02)	MB BS EPB
 Actros (01-02)	BRAKE SYS. MANAG	1857 L (01-02)	MB BS EPB
 Actros (01-02)	BRAKE SYS. MANAG	2031 AK (01-02)	MB BS EPB
 Actros (01-02)	BRAKE SYS. MANAG	2531 L (01-02)	MB BS EPB
 Actros (01-02)	BRAKE SYS. MANAG	2535 L (01-02)	MB BS EPB
 Actros (01-02)	BRAKE SYS. MANAG	2540 L (01-02)	MB BS EPB
 Actros (01-02)	BRAKE SYS. MANAG	2543 L (01-02)	MB BS EPB
 Actros (01-02)	BRAKE SYS. MANAG	2546 L (01-02)	MB BS EPB
 Actros (01-02)	BRAKE SYS. MANAG	2548 L (01-02)	MB BS EPB
 Actros (01-02)	BRAKE SYS. MANAG	2553 L (01-02)	MB BS EPB
 Actros (01-02)	BRAKE SYS. MANAG	2557 L (01-02)	MB BS EPB
 Actros (01-02)	BRAKE SYS. MANAG	3243 (01-02)	MB BS EPB
 Actros (01-02)	BRAKE SYS. MANAG	3335 B (01-02)	MB BS EPB
 Actros (01-02)	BRAKE SYS. MANAG	3335 K (01-02)	MB BS EPB
 Actros (01-02)	BRAKE SYS. MANAG	3340 AK (01-02)	MB BS EPB
 Actros (01-02)	BRAKE SYS. MANAG	3340 B (01-02)	MB BS EPB
 Actros (01-02)	BRAKE SYS. MANAG	3340 K (01-02)	MB BS EPB
 Actros (01-02)	BRAKE SYS. MANAG	3343 K (01-02)	MB BS EPB
 Actros (01-02)	BRAKE SYS. MANAG	3346 K (01-02)	MB BS EPB
 Actros (01-02)	BRAKE SYS. MANAG	3348 K (01-02)	MB BS EPB
 Actros (01-02)	BRAKE SYS. MANAG	4140 B (01-02)	MB BS EPB
 Actros (01-02)	BRAKE SYS. MANAG	4140 K (01-02)	MB BS EPB
 Actros (01-02)	BRAKE SYS. MANAG	4143 K (01-02)	MB BS EPB

## Systems supported by ECReader (up to V4,90)

### TRUCKS




























### Mercedes Trucks

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Actros (01-02)	BRAKE SYS. MANAG	4146 K (01-02)	MB BS EPB
 Actros (01-02)	BRAKE SYS. MANAG	4148 K (01-02)	MB BS EPB
 Actros (01-02)	CLIMA	1831 (01-02)	MB HZR
 Actros (01-02)	CLIMA	1831 K (01-02)	MB HZR
 Actros (01-02)	CLIMA	1831 L (01-02)	MB HZR
 Actros (01-02)	CLIMA	1831 L nR (01-02)	MB HZR
 Actros (01-02)	CLIMA	1835 L (01-02)	MB HZR
 Actros (01-02)	CLIMA	1835 L nR (01-02)	MB HZR
 Actros (01-02)	CLIMA	1840 (01-02)	MB HZR
 Actros (01-02)	CLIMA	1840 K (01-02)	MB HZR
 Actros (01-02)	CLIMA	1840 L (01-02)	MB HZR
 Actros (01-02)	CLIMA	1840 L nR (01-02)	MB HZR
 Actros (01-02)	CLIMA	1843 (01-02)	MB HZR
 Actros (01-02)	CLIMA	1843 K (01-02)	MB HZR
 Actros (01-02)	CLIMA	1843 L (01-02)	MB HZR
 Actros (01-02)	CLIMA	1843 L nR (01-02)	MB HZR
 Actros (01-02)	CLIMA	1846 (01-02)	MB HZR
 Actros (01-02)	CLIMA	1846 L (01-02)	MB HZR
 Actros (01-02)	CLIMA	1848 (01-02)	MB HZR
 Actros (01-02)	CLIMA	1848 L (01-02)	MB HZR
 Actros (01-02)	CLIMA	1853 L (01-02)	MB HZR
 Actros (01-02)	CLIMA	1857 L (01-02)	MB HZR
 Actros (01-02)	CLIMA	2031 AK (01-02)	MB HZR
 Actros (01-02)	CLIMA	2531 L (01-02)	MB HZR
 Actros (01-02)	CLIMA	2535 L (01-02)	MB HZR
 Actros (01-02)	CLIMA	2540 L (01-02)	MB HZR
 Actros (01-02)	CLIMA	2543 L (01-02)	MB HZR

## Systems supported by ECReader (up to V4,90)

### TRUCKS




























### Mercedes Trucks

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Actros (01-02)	CLIMA	2546 L (01-02)	MB HZR
 Actros (01-02)	CLIMA	2548 L (01-02)	MB HZR
 Actros (01-02)	CLIMA	2553 L (01-02)	MB HZR
 Actros (01-02)	CLIMA	2557 L (01-02)	MB HZR
 Actros (01-02)	CLIMA	3243 (01-02)	MB HZR
 Actros (01-02)	CLIMA	3335 B (01-02)	MB HZR
 Actros (01-02)	CLIMA	3335 K (01-02)	MB HZR
 Actros (01-02)	CLIMA	3340 AK (01-02)	MB HZR
 Actros (01-02)	CLIMA	3340 B (01-02)	MB HZR
 Actros (01-02)	CLIMA	3340 K (01-02)	MB HZR
 Actros (01-02)	CLIMA	3343 K (01-02)	MB HZR
 Actros (01-02)	CLIMA	3346 K (01-02)	MB HZR
 Actros (01-02)	CLIMA	3348 K (01-02)	MB HZR
 Actros (01-02)	CLIMA	4140 B (01-02)	MB HZR
 Actros (01-02)	CLIMA	4140 K (01-02)	MB HZR
 Actros (01-02)	CLIMA	4143 K (01-02)	MB HZR
 Actros (01-02)	CLIMA	4146 K (01-02)	MB HZR
 Actros (01-02)	CLIMA	4148 K (01-02)	MB HZR
 Actros (01-02)	CLUTCH ELECTRONI	1831 (01-02)	MB KS MKR
 Actros (01-02)	CLUTCH ELECTRONI	1831 K (01-02)	MB KS MKR
 Actros (01-02)	CLUTCH ELECTRONI	1831 L (01-02)	MB KS MKR
 Actros (01-02)	CLUTCH ELECTRONI	1831 L nR (01-02)	MB KS MKR
 Actros (01-02)	CLUTCH ELECTRONI	1835 L (01-02)	MB KS MKR
 Actros (01-02)	CLUTCH ELECTRONI	1835 L nR (01-02)	MB KS MKR
 Actros (01-02)	CLUTCH ELECTRONI	1840 (01-02)	MB KS MKR
 Actros (01-02)	CLUTCH ELECTRONI	1840 K (01-02)	MB KS MKR
 Actros (01-02)	CLUTCH ELECTRONI	1840 L (01-02)	MB KS MKR

## Systems supported by ECUREADER (up to V4,90)

### TRUCKS



























### Mercedes Trucks

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Actros (01-02)	CLUTCH ELECTRONI	1840 L nR (01-02)	MB KS MKR
 Actros (01-02)	CLUTCH ELECTRONI	1843 (01-02)	MB KS MKR
 Actros (01-02)	CLUTCH ELECTRONI	1843 K (01-02)	MB KS MKR
 Actros (01-02)	CLUTCH ELECTRONI	1843 L (01-02)	MB KS MKR
 Actros (01-02)	CLUTCH ELECTRONI	1843 L nR (01-02)	MB KS MKR
 Actros (01-02)	CLUTCH ELECTRONI	1846 (01-02)	MB KS MKR
 Actros (01-02)	CLUTCH ELECTRONI	1846 L (01-02)	MB KS MKR
 Actros (01-02)	CLUTCH ELECTRONI	1848 (01-02)	MB KS MKR
 Actros (01-02)	CLUTCH ELECTRONI	1848 L (01-02)	MB KS MKR
 Actros (01-02)	CLUTCH ELECTRONI	1853 L (01-02)	MB KS MKR
 Actros (01-02)	CLUTCH ELECTRONI	1857 L (01-02)	MB KS MKR
 Actros (01-02)	CLUTCH ELECTRONI	2031 AK (01-02)	MB KS MKR
 Actros (01-02)	CLUTCH ELECTRONI	2531 L (01-02)	MB KS MKR
 Actros (01-02)	CLUTCH ELECTRONI	2535 L (01-02)	MB KS MKR
 Actros (01-02)	CLUTCH ELECTRONI	2540 L (01-02)	MB KS MKR
 Actros (01-02)	CLUTCH ELECTRONI	2543 L (01-02)	MB KS MKR
 Actros (01-02)	CLUTCH ELECTRONI	2546 L (01-02)	MB KS MKR
 Actros (01-02)	CLUTCH ELECTRONI	2548 L (01-02)	MB KS MKR
 Actros (01-02)	CLUTCH ELECTRONI	2553 L (01-02)	MB KS MKR
 Actros (01-02)	CLUTCH ELECTRONI	2557 L (01-02)	MB KS MKR
 Actros (01-02)	CLUTCH ELECTRONI	3243 (01-02)	MB KS MKR
 Actros (01-02)	CLUTCH ELECTRONI	3335 B (01-02)	MB KS MKR
 Actros (01-02)	CLUTCH ELECTRONI	3335 K (01-02)	MB KS MKR
 Actros (01-02)	CLUTCH ELECTRONI	3340 AK (01-02)	MB KS MKR
 Actros (01-02)	CLUTCH ELECTRONI	3340 B (01-02)	MB KS MKR
 Actros (01-02)	CLUTCH ELECTRONI	3340 K (01-02)	MB KS MKR
 Actros (01-02)	CLUTCH ELECTRONI	3343 K (01-02)	MB KS MKR

## Systems supported by ECReader (up to V4,90)

### TRUCKS




























### Mercedes Trucks

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Actros (01-02)	CLUTCH ELECTRONI	3346 K (01-02)	MB KS MKR
 Actros (01-02)	CLUTCH ELECTRONI	3348 K (01-02)	MB KS MKR
 Actros (01-02)	CLUTCH ELECTRONI	4140 B (01-02)	MB KS MKR
 Actros (01-02)	CLUTCH ELECTRONI	4140 K (01-02)	MB KS MKR
 Actros (01-02)	CLUTCH ELECTRONI	4143 K (01-02)	MB KS MKR
 Actros (01-02)	CLUTCH ELECTRONI	4146 K (01-02)	MB KS MKR
 Actros (01-02)	CLUTCH ELECTRONI	4148 K (01-02)	MB KS MKR
 Actros (01-02)	CRUISE MANAGEME	1831 (01-02)	FR FMR
 Actros (01-02)	CRUISE MANAGEME	1831 K (01-02)	FR FMR
 Actros (01-02)	CRUISE MANAGEME	1831 L (01-02)	FR FMR
 Actros (01-02)	CRUISE MANAGEME	1831 L nR (01-02)	FR FMR
 Actros (01-02)	CRUISE MANAGEME	1835 L (01-02)	FR FMR
 Actros (01-02)	CRUISE MANAGEME	1835 L nR (01-02)	FR FMR
 Actros (01-02)	CRUISE MANAGEME	1840 (01-02)	FR FMR
 Actros (01-02)	CRUISE MANAGEME	1840 K (01-02)	FR FMR
 Actros (01-02)	CRUISE MANAGEME	1840 L (01-02)	FR FMR
 Actros (01-02)	CRUISE MANAGEME	1840 L nR (01-02)	FR FMR
 Actros (01-02)	CRUISE MANAGEME	1843 (01-02)	FR FMR
 Actros (01-02)	CRUISE MANAGEME	1843 K (01-02)	FR FMR
 Actros (01-02)	CRUISE MANAGEME	1843 L (01-02)	FR FMR
 Actros (01-02)	CRUISE MANAGEME	1843 L nR (01-02)	FR FMR
 Actros (01-02)	CRUISE MANAGEME	1846 (01-02)	FR FMR
 Actros (01-02)	CRUISE MANAGEME	1846 L (01-02)	FR FMR
 Actros (01-02)	CRUISE MANAGEME	1848 (01-02)	FR FMR
 Actros (01-02)	CRUISE MANAGEME	1848 L (01-02)	FR FMR
 Actros (01-02)	CRUISE MANAGEME	1853 L (01-02)	FR FMR
 Actros (01-02)	CRUISE MANAGEME	1857 L (01-02)	FR FMR

## Systems supported by ECReader (up to V4,90)

### TRUCKS




























### Mercedes Trucks

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Actros (01-02)	CRUISE MANAGEME	2031 AK (01-02)	FR FMR
 Actros (01-02)	CRUISE MANAGEME	2531 L (01-02)	FR FMR
 Actros (01-02)	CRUISE MANAGEME	2535 L (01-02)	FR FMR
 Actros (01-02)	CRUISE MANAGEME	2540 L (01-02)	FR FMR
 Actros (01-02)	CRUISE MANAGEME	2543 L (01-02)	FR FMR
 Actros (01-02)	CRUISE MANAGEME	2546 L (01-02)	FR FMR
 Actros (01-02)	CRUISE MANAGEME	2548 L (01-02)	FR FMR
 Actros (01-02)	CRUISE MANAGEME	2553 L (01-02)	FR FMR
 Actros (01-02)	CRUISE MANAGEME	2557 L (01-02)	FR FMR
 Actros (01-02)	CRUISE MANAGEME	3243 (01-02)	FR FMR
 Actros (01-02)	CRUISE MANAGEME	3335 B (01-02)	FR FMR
 Actros (01-02)	CRUISE MANAGEME	3335 K (01-02)	FR FMR
 Actros (01-02)	CRUISE MANAGEME	3340 AK (01-02)	FR FMR
 Actros (01-02)	CRUISE MANAGEME	3340 B (01-02)	FR FMR
 Actros (01-02)	CRUISE MANAGEME	3340 K (01-02)	FR FMR
 Actros (01-02)	CRUISE MANAGEME	3343 K (01-02)	FR FMR
 Actros (01-02)	CRUISE MANAGEME	3346 K (01-02)	FR FMR
 Actros (01-02)	CRUISE MANAGEME	3348 K (01-02)	FR FMR
 Actros (01-02)	CRUISE MANAGEME	4140 B (01-02)	FR FMR
 Actros (01-02)	CRUISE MANAGEME	4140 K (01-02)	FR FMR
 Actros (01-02)	CRUISE MANAGEME	4143 K (01-02)	FR FMR
 Actros (01-02)	CRUISE MANAGEME	4146 K (01-02)	FR FMR
 Actros (01-02)	CRUISE MANAGEME	4148 K (01-02)	FR FMR
 Actros (01-02)	DASHBOARD	1831 (01-02)	MB INS Comb. Instrument
 Actros (01-02)	DASHBOARD	1831 K (01-02)	MB INS Comb. Instrument
 Actros (01-02)	DASHBOARD	1831 L (01-02)	MB INS Comb. Instrument
 Actros (01-02)	DASHBOARD	1831 L nR (01-02)	MB INS Comb. Instrument

## Systems supported by ECUREADER (up to V4,90)

### TRUCKS




























### Mercedes Trucks

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Actros (01-02)	DASHBOARD	1835 L (01-02)	MB INS Comb. Instrument
 Actros (01-02)	DASHBOARD	1835 L nR (01-02)	MB INS Comb. Instrument
 Actros (01-02)	DASHBOARD	1840 (01-02)	MB INS Comb. Instrument
 Actros (01-02)	DASHBOARD	1840 K (01-02)	MB INS Comb. Instrument
 Actros (01-02)	DASHBOARD	1840 L (01-02)	MB INS Comb. Instrument
 Actros (01-02)	DASHBOARD	1840 L nR (01-02)	MB INS Comb. Instrument
 Actros (01-02)	DASHBOARD	1843 (01-02)	MB INS Comb. Instrument
 Actros (01-02)	DASHBOARD	1843 K (01-02)	MB INS Comb. Instrument
 Actros (01-02)	DASHBOARD	1843 L (01-02)	MB INS Comb. Instrument
 Actros (01-02)	DASHBOARD	1843 L nR (01-02)	MB INS Comb. Instrument
 Actros (01-02)	DASHBOARD	1846 (01-02)	MB INS Comb. Instrument
 Actros (01-02)	DASHBOARD	1846 L (01-02)	MB INS Comb. Instrument
 Actros (01-02)	DASHBOARD	1848 (01-02)	MB INS Comb. Instrument
 Actros (01-02)	DASHBOARD	1848 L (01-02)	MB INS Comb. Instrument
 Actros (01-02)	DASHBOARD	1853 L (01-02)	MB INS Comb. Instrument
 Actros (01-02)	DASHBOARD	1857 L (01-02)	MB INS Comb. Instrument
 Actros (01-02)	DASHBOARD	2031 AK (01-02)	MB INS Comb. Instrument
 Actros (01-02)	DASHBOARD	2531 L (01-02)	MB INS Comb. Instrument
 Actros (01-02)	DASHBOARD	2535 L (01-02)	MB INS Comb. Instrument
 Actros (01-02)	DASHBOARD	2540 L (01-02)	MB INS Comb. Instrument
 Actros (01-02)	DASHBOARD	2543 L (01-02)	MB INS Comb. Instrument
 Actros (01-02)	DASHBOARD	2546 L (01-02)	MB INS Comb. Instrument
 Actros (01-02)	DASHBOARD	2548 L (01-02)	MB INS Comb. Instrument
 Actros (01-02)	DASHBOARD	2553 L (01-02)	MB INS Comb. Instrument
 Actros (01-02)	DASHBOARD	2557 L (01-02)	MB INS Comb. Instrument
 Actros (01-02)	DASHBOARD	3243 (01-02)	MB INS Comb. Instrument
 Actros (01-02)	DASHBOARD	3335 B (01-02)	MB INS Comb. Instrument

## Systems supported by ECUREADER (up to V4,90)

### TRUCKS




























### Mercedes Trucks

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Actros (01-02)	DASHBOARD	3335 K (01-02)	MB INS Comb. Instrument
 Actros (01-02)	DASHBOARD	3340 AK (01-02)	MB INS Comb. Instrument
 Actros (01-02)	DASHBOARD	3340 B (01-02)	MB INS Comb. Instrument
 Actros (01-02)	DASHBOARD	3340 K (01-02)	MB INS Comb. Instrument
 Actros (01-02)	DASHBOARD	3343 K (01-02)	MB INS Comb. Instrument
 Actros (01-02)	DASHBOARD	3346 K (01-02)	MB INS Comb. Instrument
 Actros (01-02)	DASHBOARD	3348 K (01-02)	MB INS Comb. Instrument
 Actros (01-02)	DASHBOARD	4140 B (01-02)	MB INS Comb. Instrument
 Actros (01-02)	DASHBOARD	4140 K (01-02)	MB INS Comb. Instrument
 Actros (01-02)	DASHBOARD	4143 K (01-02)	MB INS Comb. Instrument
 Actros (01-02)	DASHBOARD	4146 K (01-02)	MB INS Comb. Instrument
 Actros (01-02)	DASHBOARD	4148 K (01-02)	MB INS Comb. Instrument
 Actros (01-02)	ENGINE MANAGEME	1831 (01-02)	MB MR PLD (EDC)
 Actros (01-02)	ENGINE MANAGEME	1831 K (01-02)	MB MR PLD (EDC)
 Actros (01-02)	ENGINE MANAGEME	1831 L (01-02)	MB MR PLD (EDC)
 Actros (01-02)	ENGINE MANAGEME	1831 L nR (01-02)	MB MR PLD (EDC)
 Actros (01-02)	ENGINE MANAGEME	1835 L (01-02)	MB MR PLD (EDC)
 Actros (01-02)	ENGINE MANAGEME	1835 L nR (01-02)	MB MR PLD (EDC)
 Actros (01-02)	ENGINE MANAGEME	1840 (01-02)	MB MR PLD (EDC)
 Actros (01-02)	ENGINE MANAGEME	1840 K (01-02)	MB MR PLD (EDC)
 Actros (01-02)	ENGINE MANAGEME	1840 L (01-02)	MB MR PLD (EDC)
 Actros (01-02)	ENGINE MANAGEME	1840 L nR (01-02)	MB MR PLD (EDC)
 Actros (01-02)	ENGINE MANAGEME	1843 (01-02)	MB MR PLD (EDC)
 Actros (01-02)	ENGINE MANAGEME	1843 K (01-02)	MB MR PLD (EDC)
 Actros (01-02)	ENGINE MANAGEME	1843 L (01-02)	MB MR PLD (EDC)
 Actros (01-02)	ENGINE MANAGEME	1843 L nR (01-02)	MB MR PLD (EDC)
 Actros (01-02)	ENGINE MANAGEME	1846 (01-02)	MB MR PLD (EDC)

## Systems supported by ECReader (up to V4,90)

### TRUCKS




























### Mercedes Trucks

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Actros (01-02)	ENGINE MANAGEME	1846 L (01-02)	MB MR PLD (EDC)
 Actros (01-02)	ENGINE MANAGEME	1848 (01-02)	MB MR PLD (EDC)
 Actros (01-02)	ENGINE MANAGEME	1848 L (01-02)	MB MR PLD (EDC)
 Actros (01-02)	ENGINE MANAGEME	1853 L (01-02)	MB MR PLD (EDC)
 Actros (01-02)	ENGINE MANAGEME	1857 L (01-02)	MB MR PLD (EDC)
 Actros (01-02)	ENGINE MANAGEME	2031 AK (01-02)	MB MR PLD (EDC)
 Actros (01-02)	ENGINE MANAGEME	2531 L (01-02)	MB MR PLD (EDC)
 Actros (01-02)	ENGINE MANAGEME	2535 L (01-02)	MB MR PLD (EDC)
 Actros (01-02)	ENGINE MANAGEME	2540 L (01-02)	MB MR PLD (EDC)
 Actros (01-02)	ENGINE MANAGEME	2543 L (01-02)	MB MR PLD (EDC)
 Actros (01-02)	ENGINE MANAGEME	2546 L (01-02)	MB MR PLD (EDC)
 Actros (01-02)	ENGINE MANAGEME	2548 L (01-02)	MB MR PLD (EDC)
 Actros (01-02)	ENGINE MANAGEME	2553 L (01-02)	MB MR PLD (EDC)
 Actros (01-02)	ENGINE MANAGEME	2557 L (01-02)	MB MR PLD (EDC)
 Actros (01-02)	ENGINE MANAGEME	3243 (01-02)	MB MR PLD (EDC)
 Actros (01-02)	ENGINE MANAGEME	3335 B (01-02)	MB MR PLD (EDC)
 Actros (01-02)	ENGINE MANAGEME	3335 K (01-02)	MB MR PLD (EDC)
 Actros (01-02)	ENGINE MANAGEME	3340 AK (01-02)	MB MR PLD (EDC)
 Actros (01-02)	ENGINE MANAGEME	3340 B (01-02)	MB MR PLD (EDC)
 Actros (01-02)	ENGINE MANAGEME	3340 K (01-02)	MB MR PLD (EDC)
 Actros (01-02)	ENGINE MANAGEME	3343 K (01-02)	MB MR PLD (EDC)
 Actros (01-02)	ENGINE MANAGEME	3346 K (01-02)	MB MR PLD (EDC)
 Actros (01-02)	ENGINE MANAGEME	3348 K (01-02)	MB MR PLD (EDC)
 Actros (01-02)	ENGINE MANAGEME	4140 B (01-02)	MB MR PLD (EDC)
 Actros (01-02)	ENGINE MANAGEME	4140 K (01-02)	MB MR PLD (EDC)
 Actros (01-02)	ENGINE MANAGEME	4143 K (01-02)	MB MR PLD (EDC)
 Actros (01-02)	ENGINE MANAGEME	4146 K (01-02)	MB MR PLD (EDC)

## Systems supported by ECReader (up to V4,90)

### TRUCKS




























### Mercedes Trucks

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Actros (01-02)	ENGINE MANAGEME	4148 K (01-02)	MB MR PLD (EDC)
 Actros (01-02)	GEARBOX MANAGEM	1831 (01-02)	MB GS EPS
 Actros (01-02)	GEARBOX MANAGEM	1831 K (01-02)	MB GS EPS
 Actros (01-02)	GEARBOX MANAGEM	1831 L (01-02)	MB GS EPS
 Actros (01-02)	GEARBOX MANAGEM	1831 L nR (01-02)	MB GS EPS
 Actros (01-02)	GEARBOX MANAGEM	1835 L (01-02)	MB GS EPS
 Actros (01-02)	GEARBOX MANAGEM	1835 L nR (01-02)	MB GS EPS
 Actros (01-02)	GEARBOX MANAGEM	1840 (01-02)	MB GS EPS
 Actros (01-02)	GEARBOX MANAGEM	1840 K (01-02)	MB GS EPS
 Actros (01-02)	GEARBOX MANAGEM	1840 L (01-02)	MB GS EPS
 Actros (01-02)	GEARBOX MANAGEM	1840 L nR (01-02)	MB GS EPS
 Actros (01-02)	GEARBOX MANAGEM	1843 (01-02)	MB GS EPS
 Actros (01-02)	GEARBOX MANAGEM	1843 K (01-02)	MB GS EPS
 Actros (01-02)	GEARBOX MANAGEM	1843 L (01-02)	MB GS EPS
 Actros (01-02)	GEARBOX MANAGEM	1843 L nR (01-02)	MB GS EPS
 Actros (01-02)	GEARBOX MANAGEM	1846 (01-02)	MB GS EPS
 Actros (01-02)	GEARBOX MANAGEM	1846 L (01-02)	MB GS EPS
 Actros (01-02)	GEARBOX MANAGEM	1848 (01-02)	MB GS EPS
 Actros (01-02)	GEARBOX MANAGEM	1848 L (01-02)	MB GS EPS
 Actros (01-02)	GEARBOX MANAGEM	1853 L (01-02)	MB GS EPS
 Actros (01-02)	GEARBOX MANAGEM	1857 L (01-02)	MB GS EPS
 Actros (01-02)	GEARBOX MANAGEM	2031 AK (01-02)	MB GS EPS
 Actros (01-02)	GEARBOX MANAGEM	2531 L (01-02)	MB GS EPS
 Actros (01-02)	GEARBOX MANAGEM	2535 L (01-02)	MB GS EPS
 Actros (01-02)	GEARBOX MANAGEM	2540 L (01-02)	MB GS EPS
 Actros (01-02)	GEARBOX MANAGEM	2543 L (01-02)	MB GS EPS
 Actros (01-02)	GEARBOX MANAGEM	2546 L (01-02)	MB GS EPS

## Systems supported by ECReader (up to V4,90)

### TRUCKS




























### Mercedes Trucks

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Actros (01-02)	GEARBOX MANAGEM	2548 L (01-02)	MB GS EPS
 Actros (01-02)	GEARBOX MANAGEM	2553 L (01-02)	MB GS EPS
 Actros (01-02)	GEARBOX MANAGEM	2557 L (01-02)	MB GS EPS
 Actros (01-02)	GEARBOX MANAGEM	3243 (01-02)	MB GS EPS
 Actros (01-02)	GEARBOX MANAGEM	3335 B (01-02)	MB GS EPS
 Actros (01-02)	GEARBOX MANAGEM	3335 K (01-02)	MB GS EPS
 Actros (01-02)	GEARBOX MANAGEM	3340 AK (01-02)	MB GS EPS
 Actros (01-02)	GEARBOX MANAGEM	3340 B (01-02)	MB GS EPS
 Actros (01-02)	GEARBOX MANAGEM	3340 K (01-02)	MB GS EPS
 Actros (01-02)	GEARBOX MANAGEM	3343 K (01-02)	MB GS EPS
 Actros (01-02)	GEARBOX MANAGEM	3346 K (01-02)	MB GS EPS
 Actros (01-02)	GEARBOX MANAGEM	3348 K (01-02)	MB GS EPS
 Actros (01-02)	GEARBOX MANAGEM	4140 B (01-02)	MB GS EPS
 Actros (01-02)	GEARBOX MANAGEM	4140 K (01-02)	MB GS EPS
 Actros (01-02)	GEARBOX MANAGEM	4143 K (01-02)	MB GS EPS
 Actros (01-02)	GEARBOX MANAGEM	4146 K (01-02)	MB GS EPS
 Actros (01-02)	GEARBOX MANAGEM	4148 K (01-02)	MB GS EPS
 Actros (01-02)	MAINTENANCE SYST	1831 (01-02)	MB WS FSS
 Actros (01-02)	MAINTENANCE SYST	1831 K (01-02)	MB WS FSS
 Actros (01-02)	MAINTENANCE SYST	1831 L (01-02)	MB WS FSS
 Actros (01-02)	MAINTENANCE SYST	1831 L nR (01-02)	MB WS FSS
 Actros (01-02)	MAINTENANCE SYST	1835 L (01-02)	MB WS FSS
 Actros (01-02)	MAINTENANCE SYST	1835 L nR (01-02)	MB WS FSS
 Actros (01-02)	MAINTENANCE SYST	1840 (01-02)	MB WS FSS
 Actros (01-02)	MAINTENANCE SYST	1840 K (01-02)	MB WS FSS
 Actros (01-02)	MAINTENANCE SYST	1840 L (01-02)	MB WS FSS
 Actros (01-02)	MAINTENANCE SYST	1840 L nR (01-02)	MB WS FSS

## Systems supported by ECReader (up to V4,90)

### TRUCKS




























### Mercedes Trucks

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Actros (01-02)	MAINTENANCE SYST	1843 (01-02)	MB WS FSS
 Actros (01-02)	MAINTENANCE SYST	1843 K (01-02)	MB WS FSS
 Actros (01-02)	MAINTENANCE SYST	1843 L (01-02)	MB WS FSS
 Actros (01-02)	MAINTENANCE SYST	1843 L nR (01-02)	MB WS FSS
 Actros (01-02)	MAINTENANCE SYST	1846 (01-02)	MB WS FSS
 Actros (01-02)	MAINTENANCE SYST	1846 L (01-02)	MB WS FSS
 Actros (01-02)	MAINTENANCE SYST	1848 (01-02)	MB WS FSS
 Actros (01-02)	MAINTENANCE SYST	1848 L (01-02)	MB WS FSS
 Actros (01-02)	MAINTENANCE SYST	1853 L (01-02)	MB WS FSS
 Actros (01-02)	MAINTENANCE SYST	1857 L (01-02)	MB WS FSS
 Actros (01-02)	MAINTENANCE SYST	2031 AK (01-02)	MB WS FSS
 Actros (01-02)	MAINTENANCE SYST	2531 L (01-02)	MB WS FSS
 Actros (01-02)	MAINTENANCE SYST	2535 L (01-02)	MB WS FSS
 Actros (01-02)	MAINTENANCE SYST	2540 L (01-02)	MB WS FSS
 Actros (01-02)	MAINTENANCE SYST	2543 L (01-02)	MB WS FSS
 Actros (01-02)	MAINTENANCE SYST	2546 L (01-02)	MB WS FSS
 Actros (01-02)	MAINTENANCE SYST	2548 L (01-02)	MB WS FSS
 Actros (01-02)	MAINTENANCE SYST	2553 L (01-02)	MB WS FSS
 Actros (01-02)	MAINTENANCE SYST	2557 L (01-02)	MB WS FSS
 Actros (01-02)	MAINTENANCE SYST	3243 (01-02)	MB WS FSS
 Actros (01-02)	MAINTENANCE SYST	3335 B (01-02)	MB WS FSS
 Actros (01-02)	MAINTENANCE SYST	3335 K (01-02)	MB WS FSS
 Actros (01-02)	MAINTENANCE SYST	3340 AK (01-02)	MB WS FSS
 Actros (01-02)	MAINTENANCE SYST	3340 B (01-02)	MB WS FSS
 Actros (01-02)	MAINTENANCE SYST	3340 K (01-02)	MB WS FSS
 Actros (01-02)	MAINTENANCE SYST	3343 K (01-02)	MB WS FSS
 Actros (01-02)	MAINTENANCE SYST	3346 K (01-02)	MB WS FSS

## Systems supported by ECReader (up to V4,90)

### TRUCKS




























### Mercedes Trucks

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Actros (01-02)	MAINTENANCE SYST	3348 K (01-02)	MB WS FSS
 Actros (01-02)	MAINTENANCE SYST	4140 B (01-02)	MB WS FSS
 Actros (01-02)	MAINTENANCE SYST	4140 K (01-02)	MB WS FSS
 Actros (01-02)	MAINTENANCE SYST	4143 K (01-02)	MB WS FSS
 Actros (01-02)	MAINTENANCE SYST	4146 K (01-02)	MB WS FSS
 Actros (01-02)	MAINTENANCE SYST	4148 K (01-02)	MB WS FSS
 Actros (01-02)	PRELIMINARY HEATI	1831 (01-02)	MB FLA Termostart.
 Actros (01-02)	PRELIMINARY HEATI	1831 K (01-02)	MB FLA Termostart.
 Actros (01-02)	PRELIMINARY HEATI	1831 L (01-02)	MB FLA Termostart.
 Actros (01-02)	PRELIMINARY HEATI	1831 L nR (01-02)	MB FLA Termostart.
 Actros (01-02)	PRELIMINARY HEATI	1835 L (01-02)	MB FLA Termostart.
 Actros (01-02)	PRELIMINARY HEATI	1835 L nR (01-02)	MB FLA Termostart.
 Actros (01-02)	PRELIMINARY HEATI	1840 (01-02)	MB FLA Termostart.
 Actros (01-02)	PRELIMINARY HEATI	1840 K (01-02)	MB FLA Termostart.
 Actros (01-02)	PRELIMINARY HEATI	1840 L (01-02)	MB FLA Termostart.
 Actros (01-02)	PRELIMINARY HEATI	1840 L nR (01-02)	MB FLA Termostart.
 Actros (01-02)	PRELIMINARY HEATI	1843 (01-02)	MB FLA Termostart.
 Actros (01-02)	PRELIMINARY HEATI	1843 K (01-02)	MB FLA Termostart.
 Actros (01-02)	PRELIMINARY HEATI	1843 L (01-02)	MB FLA Termostart.
 Actros (01-02)	PRELIMINARY HEATI	1843 L nR (01-02)	MB FLA Termostart.
 Actros (01-02)	PRELIMINARY HEATI	1846 (01-02)	MB FLA Termostart.
 Actros (01-02)	PRELIMINARY HEATI	1846 L (01-02)	MB FLA Termostart.
 Actros (01-02)	PRELIMINARY HEATI	1848 (01-02)	MB FLA Termostart.
 Actros (01-02)	PRELIMINARY HEATI	1848 L (01-02)	MB FLA Termostart.
 Actros (01-02)	PRELIMINARY HEATI	1853 L (01-02)	MB FLA Termostart.
 Actros (01-02)	PRELIMINARY HEATI	1857 L (01-02)	MB FLA Termostart.
 Actros (01-02)	PRELIMINARY HEATI	2031 AK (01-02)	MB FLA Termostart.

## Systems supported by ECReader (up to V4,90)

### TRUCKS




























### Mercedes Trucks

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Actros (01-02)	PRELIMINARY HEATI	2531 L (01-02)	MB FLA Termostart.
 Actros (01-02)	PRELIMINARY HEATI	2535 L (01-02)	MB FLA Termostart.
 Actros (01-02)	PRELIMINARY HEATI	2540 L (01-02)	MB FLA Termostart.
 Actros (01-02)	PRELIMINARY HEATI	2543 L (01-02)	MB FLA Termostart.
 Actros (01-02)	PRELIMINARY HEATI	2546 L (01-02)	MB FLA Termostart.
 Actros (01-02)	PRELIMINARY HEATI	2548 L (01-02)	MB FLA Termostart.
 Actros (01-02)	PRELIMINARY HEATI	2553 L (01-02)	MB FLA Termostart.
 Actros (01-02)	PRELIMINARY HEATI	2557 L (01-02)	MB FLA Termostart.
 Actros (01-02)	PRELIMINARY HEATI	3243 (01-02)	MB FLA Termostart.
 Actros (01-02)	PRELIMINARY HEATI	3335 B (01-02)	MB FLA Termostart.
 Actros (01-02)	PRELIMINARY HEATI	3335 K (01-02)	MB FLA Termostart.
 Actros (01-02)	PRELIMINARY HEATI	3340 AK (01-02)	MB FLA Termostart.
 Actros (01-02)	PRELIMINARY HEATI	3340 B (01-02)	MB FLA Termostart.
 Actros (01-02)	PRELIMINARY HEATI	3340 K (01-02)	MB FLA Termostart.
 Actros (01-02)	PRELIMINARY HEATI	3343 K (01-02)	MB FLA Termostart.
 Actros (01-02)	PRELIMINARY HEATI	3346 K (01-02)	MB FLA Termostart.
 Actros (01-02)	PRELIMINARY HEATI	3348 K (01-02)	MB FLA Termostart.
 Actros (01-02)	PRELIMINARY HEATI	4140 B (01-02)	MB FLA Termostart.
 Actros (01-02)	PRELIMINARY HEATI	4140 K (01-02)	MB FLA Termostart.
 Actros (01-02)	PRELIMINARY HEATI	4143 K (01-02)	MB FLA Termostart.
 Actros (01-02)	PRELIMINARY HEATI	4146 K (01-02)	MB FLA Termostart.
 Actros (01-02)	PRELIMINARY HEATI	4148 K (01-02)	MB FLA Termostart.
 Actros (01-02)	RATIO SEL. MANAGE	1831 (01-02)	MB AG AGE
 Actros (01-02)	RATIO SEL. MANAGE	1831 K (01-02)	MB AG AGE
 Actros (01-02)	RATIO SEL. MANAGE	1831 L (01-02)	MB AG AGE
 Actros (01-02)	RATIO SEL. MANAGE	1831 L nR (01-02)	MB AG AGE
 Actros (01-02)	RATIO SEL. MANAGE	1835 L (01-02)	MB AG AGE

## Systems supported by ECReader (up to V4,90)

### TRUCKS

### Mercedes Trucks

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Actros (01-02)	RATIO SEL. MANAGE	1835 L nR (01-02)	MB AG AGE
 Actros (01-02)	RATIO SEL. MANAGE	1840 (01-02)	MB AG AGE
 Actros (01-02)	RATIO SEL. MANAGE	1840 K (01-02)	MB AG AGE
 Actros (01-02)	RATIO SEL. MANAGE	1840 L (01-02)	MB AG AGE
 Actros (01-02)	RATIO SEL. MANAGE	1840 L nR (01-02)	MB AG AGE
 Actros (01-02)	RATIO SEL. MANAGE	1843 (01-02)	MB AG AGE
 Actros (01-02)	RATIO SEL. MANAGE	1843 K (01-02)	MB AG AGE
 Actros (01-02)	RATIO SEL. MANAGE	1843 L (01-02)	MB AG AGE
 Actros (01-02)	RATIO SEL. MANAGE	1843 L nR (01-02)	MB AG AGE
 Actros (01-02)	RATIO SEL. MANAGE	1846 (01-02)	MB AG AGE
 Actros (01-02)	RATIO SEL. MANAGE	1846 L (01-02)	MB AG AGE
 Actros (01-02)	RATIO SEL. MANAGE	1848 (01-02)	MB AG AGE
 Actros (01-02)	RATIO SEL. MANAGE	1848 L (01-02)	MB AG AGE
 Actros (01-02)	RATIO SEL. MANAGE	1853 L (01-02)	MB AG AGE
 Actros (01-02)	RATIO SEL. MANAGE	1857 L (01-02)	MB AG AGE
 Actros (01-02)	RATIO SEL. MANAGE	2031 AK (01-02)	MB AG AGE
 Actros (01-02)	RATIO SEL. MANAGE	2531 L (01-02)	MB AG AGE
 Actros (01-02)	RATIO SEL. MANAGE	2535 L (01-02)	MB AG AGE
 Actros (01-02)	RATIO SEL. MANAGE	2540 L (01-02)	MB AG AGE
 Actros (01-02)	RATIO SEL. MANAGE	2543 L (01-02)	MB AG AGE
 Actros (01-02)	RATIO SEL. MANAGE	2546 L (01-02)	MB AG AGE
 Actros (01-02)	RATIO SEL. MANAGE	2548 L (01-02)	MB AG AGE
 Actros (01-02)	RATIO SEL. MANAGE	2553 L (01-02)	MB AG AGE
 Actros (01-02)	RATIO SEL. MANAGE	2557 L (01-02)	MB AG AGE
 Actros (01-02)	RATIO SEL. MANAGE	3243 (01-02)	MB AG AGE
 Actros (01-02)	RATIO SEL. MANAGE	3335 B (01-02)	MB AG AGE
 Actros (01-02)	RATIO SEL. MANAGE	3335 K (01-02)	MB AG AGE

## Systems supported by ECReader (up to V4,90)

### TRUCKS




























### Mercedes Trucks

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Actros (01-02)	RATIO SEL. MANAGE	3340 AK (01-02)	MB AG AGE
 Actros (01-02)	RATIO SEL. MANAGE	3340 B (01-02)	MB AG AGE
 Actros (01-02)	RATIO SEL. MANAGE	3340 K (01-02)	MB AG AGE
 Actros (01-02)	RATIO SEL. MANAGE	3343 K (01-02)	MB AG AGE
 Actros (01-02)	RATIO SEL. MANAGE	3346 K (01-02)	MB AG AGE
 Actros (01-02)	RATIO SEL. MANAGE	3348 K (01-02)	MB AG AGE
 Actros (01-02)	RATIO SEL. MANAGE	4140 B (01-02)	MB AG AGE
 Actros (01-02)	RATIO SEL. MANAGE	4140 K (01-02)	MB AG AGE
 Actros (01-02)	RATIO SEL. MANAGE	4143 K (01-02)	MB AG AGE
 Actros (01-02)	RATIO SEL. MANAGE	4146 K (01-02)	MB AG AGE
 Actros (01-02)	RATIO SEL. MANAGE	4148 K (01-02)	MB AG AGE
 Actros (01-02)	SERVICE LIGHT RES	1831 (01-02)	MB WS FSS
 Actros (01-02)	SERVICE LIGHT RES	1831 K (01-02)	MB WS FSS
 Actros (01-02)	SERVICE LIGHT RES	1831 L (01-02)	MB WS FSS
 Actros (01-02)	SERVICE LIGHT RES	1831 L nR (01-02)	MB WS FSS
 Actros (01-02)	SERVICE LIGHT RES	1835 L (01-02)	MB WS FSS
 Actros (01-02)	SERVICE LIGHT RES	1835 L nR (01-02)	MB WS FSS
 Actros (01-02)	SERVICE LIGHT RES	1840 (01-02)	MB WS FSS
 Actros (01-02)	SERVICE LIGHT RES	1840 K (01-02)	MB WS FSS
 Actros (01-02)	SERVICE LIGHT RES	1840 L (01-02)	MB WS FSS
 Actros (01-02)	SERVICE LIGHT RES	1840 L nR (01-02)	MB WS FSS
 Actros (01-02)	SERVICE LIGHT RES	1843 (01-02)	MB WS FSS
 Actros (01-02)	SERVICE LIGHT RES	1843 K (01-02)	MB WS FSS
 Actros (01-02)	SERVICE LIGHT RES	1843 L (01-02)	MB WS FSS
 Actros (01-02)	SERVICE LIGHT RES	1843 L nR (01-02)	MB WS FSS
 Actros (01-02)	SERVICE LIGHT RES	1846 (01-02)	MB WS FSS
 Actros (01-02)	SERVICE LIGHT RES	1846 L (01-02)	MB WS FSS

## Systems supported by ECReader (up to V4,90)

### TRUCKS




























### Mercedes Trucks

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Actros (01-02)	SERVICE LIGHT RES	1848 (01-02)	MB WS FSS
 Actros (01-02)	SERVICE LIGHT RES	1848 L (01-02)	MB WS FSS
 Actros (01-02)	SERVICE LIGHT RES	1853 L (01-02)	MB WS FSS
 Actros (01-02)	SERVICE LIGHT RES	1857 L (01-02)	MB WS FSS
 Actros (01-02)	SERVICE LIGHT RES	2031 AK (01-02)	MB WS FSS
 Actros (01-02)	SERVICE LIGHT RES	2531 L (01-02)	MB WS FSS
 Actros (01-02)	SERVICE LIGHT RES	2535 L (01-02)	MB WS FSS
 Actros (01-02)	SERVICE LIGHT RES	2540 L (01-02)	MB WS FSS
 Actros (01-02)	SERVICE LIGHT RES	2543 L (01-02)	MB WS FSS
 Actros (01-02)	SERVICE LIGHT RES	2546 L (01-02)	MB WS FSS
 Actros (01-02)	SERVICE LIGHT RES	2548 L (01-02)	MB WS FSS
 Actros (01-02)	SERVICE LIGHT RES	2553 L (01-02)	MB WS FSS
 Actros (01-02)	SERVICE LIGHT RES	2557 L (01-02)	MB WS FSS
 Actros (01-02)	SERVICE LIGHT RES	3243 (01-02)	MB WS FSS
 Actros (01-02)	SERVICE LIGHT RES	3335 B (01-02)	MB WS FSS
 Actros (01-02)	SERVICE LIGHT RES	3335 K (01-02)	MB WS FSS
 Actros (01-02)	SERVICE LIGHT RES	3340 AK (01-02)	MB WS FSS
 Actros (01-02)	SERVICE LIGHT RES	3340 B (01-02)	MB WS FSS
 Actros (01-02)	SERVICE LIGHT RES	3340 K (01-02)	MB WS FSS
 Actros (01-02)	SERVICE LIGHT RES	3343 K (01-02)	MB WS FSS
 Actros (01-02)	SERVICE LIGHT RES	3346 K (01-02)	MB WS FSS
 Actros (01-02)	SERVICE LIGHT RES	3348 K (01-02)	MB WS FSS
 Actros (01-02)	SERVICE LIGHT RES	4140 K (01-02)	MB WS FSS
 Actros (01-02)	SERVICE LIGHT RES	4143 K (01-02)	MB WS FSS
 Actros (01-02)	SERVICE LIGHT RES	4146 K (01-02)	MB WS FSS
 Actros (01-02)	SERVICE LIGHT RES	4148 K (01-02)	MB WS FSS
 Actros (01-02)	SUSPENSION CONTR	1831 (01-02)	Wabco NR ECAS

## Systems supported by ECReader (up to V4,90)

### TRUCKS



























### Mercedes Trucks

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Actros (01-02)	SUSPENSION CONTR	1831 K (01-02)	Wabco NR ECAS
 Actros (01-02)	SUSPENSION CONTR	1831 L (01-02)	Wabco NR ECAS
 Actros (01-02)	SUSPENSION CONTR	1831 L nR (01-02)	Wabco NR ECAS
 Actros (01-02)	SUSPENSION CONTR	1835 L (01-02)	Wabco NR ECAS
 Actros (01-02)	SUSPENSION CONTR	1835 L nR (01-02)	Wabco NR ECAS
 Actros (01-02)	SUSPENSION CONTR	1840 (01-02)	Wabco NR ECAS
 Actros (01-02)	SUSPENSION CONTR	1840 K (01-02)	Wabco NR ECAS
 Actros (01-02)	SUSPENSION CONTR	1840 L (01-02)	Wabco NR ECAS
 Actros (01-02)	SUSPENSION CONTR	1840 L nR (01-02)	Wabco NR ECAS
 Actros (01-02)	SUSPENSION CONTR	1843 (01-02)	Wabco NR ECAS
 Actros (01-02)	SUSPENSION CONTR	1843 K (01-02)	Wabco NR ECAS
 Actros (01-02)	SUSPENSION CONTR	1843 L (01-02)	Wabco NR ECAS
 Actros (01-02)	SUSPENSION CONTR	1843 L nR (01-02)	Wabco NR ECAS
 Actros (01-02)	SUSPENSION CONTR	1846 (01-02)	Wabco NR ECAS
 Actros (01-02)	SUSPENSION CONTR	1846 L (01-02)	Wabco NR ECAS
 Actros (01-02)	SUSPENSION CONTR	1848 (01-02)	Wabco NR ECAS
 Actros (01-02)	SUSPENSION CONTR	1848 L (01-02)	Wabco NR ECAS
 Actros (01-02)	SUSPENSION CONTR	1853 L (01-02)	Wabco NR ECAS
 Actros (01-02)	SUSPENSION CONTR	1857 L (01-02)	Wabco NR ECAS
 Actros (01-02)	SUSPENSION CONTR	2031 AK (01-02)	Wabco NR ECAS
 Actros (01-02)	SUSPENSION CONTR	2531 L (01-02)	Wabco NR ECAS
 Actros (01-02)	SUSPENSION CONTR	2535 L (01-02)	Wabco NR ECAS
 Actros (01-02)	SUSPENSION CONTR	2540 L (01-02)	Wabco NR ECAS
 Actros (01-02)	SUSPENSION CONTR	2543 L (01-02)	Wabco NR ECAS
 Actros (01-02)	SUSPENSION CONTR	2546 L (01-02)	Wabco NR ECAS
 Actros (01-02)	SUSPENSION CONTR	2548 L (01-02)	Wabco NR ECAS
 Actros (01-02)	SUSPENSION CONTR	2553 L (01-02)	Wabco NR ECAS

## Systems supported by ECReader (up to V4,90)

### TRUCKS



















### Mercedes Trucks

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Actros (01-02)	SUSPENSION CONTR	2557 L (01-02)	Wabco NR ECAS
 Actros (01-02)	SUSPENSION CONTR	3243 (01-02)	Wabco NR ECAS
 Actros (01-02)	SUSPENSION CONTR	3335 B (01-02)	Wabco NR ECAS
 Actros (01-02)	SUSPENSION CONTR	3335 K (01-02)	Wabco NR ECAS
 Actros (01-02)	SUSPENSION CONTR	3340 AK (01-02)	Wabco NR ECAS
 Actros (01-02)	SUSPENSION CONTR	3340 B (01-02)	Wabco NR ECAS
 Actros (01-02)	SUSPENSION CONTR	3340 K (01-02)	Wabco NR ECAS
 Actros (01-02)	SUSPENSION CONTR	3343 K (01-02)	Wabco NR ECAS
 Actros (01-02)	SUSPENSION CONTR	3346 K (01-02)	Wabco NR ECAS
 Actros (01-02)	SUSPENSION CONTR	3348 K (01-02)	Wabco NR ECAS
 Actros (01-02)	SUSPENSION CONTR	4140 B (01-02)	Wabco NR ECAS
 Actros (01-02)	SUSPENSION CONTR	4140 K (01-02)	Wabco NR ECAS
 Actros (01-02)	SUSPENSION CONTR	4143 K (01-02)	Wabco NR ECAS
 Actros (01-02)	SUSPENSION CONTR	4146 K (01-02)	Wabco NR ECAS
 Actros (01-02)	SUSPENSION CONTR	4148 K (01-02)	Wabco NR ECAS
 Actros MPII (03-05)	AIRBAG	1832 (03-05)	MB SRS AirBag
 Actros MPII (03-05)	AIRBAG	1832 K (03-05)	MB SRS AirBag
 Actros MPII (03-05)	AIRBAG	1836 (03-05)	MB SRS AirBag
 Actros MPII (03-05)	AIRBAG	1841 (03-05)	MB SRS AirBag
 Actros MPII (03-05)	AIRBAG	1841 K (03-05)	MB SRS AirBag
 Actros MPII (03-05)	AIRBAG	1844 (03-05)	MB SRS AirBag
 Actros MPII (03-05)	AIRBAG	1844 K (03-05)	MB SRS AirBag
 Actros MPII (03-05)	AIRBAG	1846 (03-05)	MB SRS AirBag
 Actros MPII (03-05)	AIRBAG	1850 (03-05)	MB SRS AirBag
 Actros MPII (03-05)	AIRBAG	1854 (03-05)	MB SRS AirBag
 Actros MPII (03-05)	AIRBAG	1858 (03-05)	MB SRS AirBag

## Systems supported by ECReader (up to V4,90)

### TRUCKS




























### Mercedes Trucks

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Actros MPlI (03-05)	AIRBAG	2032 (03-05)	MB SRS AirBag
 Actros MPlI (03-05)	AIRBAG	2041 (03-05)	MB SRS AirBag
 Actros MPlI (03-05)	AIRBAG	2044 (03-05)	MB SRS AirBag
 Actros MPlI (03-05)	AIRBAG	2532 (03-05)	MB SRS AirBag
 Actros MPlI (03-05)	AIRBAG	2536 (03-05)	MB SRS AirBag
 Actros MPlI (03-05)	AIRBAG	2541 (03-05)	MB SRS AirBag
 Actros MPlI (03-05)	AIRBAG	2544 (03-05)	MB SRS AirBag
 Actros MPlI (03-05)	AIRBAG	2546 (03-05)	MB SRS AirBag
 Actros MPlI (03-05)	AIRBAG	2550 (03-05)	MB SRS AirBag
 Actros MPlI (03-05)	AIRBAG	2554 (03-05)	MB SRS AirBag
 Actros MPlI (03-05)	AIRBAG	2558 (03-05)	MB SRS AirBag
 Actros MPlI (03-05)	AIRBAG	4141 (03-05)	MB SRS AirBag
 Actros MPlI (03-05)	AIRBAG	4144 (03-05)	MB SRS AirBag
 Actros MPlI (03-05)	AIRBAG	4146 (03-05)	MB SRS AirBag
 Actros MPlI (03-05)	AIRBAG	4150 (03-05)	MB SRS AirBag
 Actros MPlI (03-05)	AUTOM. TRANSMISSI	1832 (03-05)	MB GS EPS
 Actros MPlI (03-05)	AUTOM. TRANSMISSI	1832 K (03-05)	MB GS EPS
 Actros MPlI (03-05)	AUTOM. TRANSMISSI	1836 (03-05)	MB GS EPS
 Actros MPlI (03-05)	AUTOM. TRANSMISSI	1841 (03-05)	MB GS EPS
 Actros MPlI (03-05)	AUTOM. TRANSMISSI	1841 K (03-05)	MB GS EPS
 Actros MPlI (03-05)	AUTOM. TRANSMISSI	1844 (03-05)	MB GS EPS
 Actros MPlI (03-05)	AUTOM. TRANSMISSI	1844 K (03-05)	MB GS EPS
 Actros MPlI (03-05)	AUTOM. TRANSMISSI	1846 (03-05)	MB GS EPS
 Actros MPlI (03-05)	AUTOM. TRANSMISSI	1850 (03-05)	MB GS EPS
 Actros MPlI (03-05)	AUTOM. TRANSMISSI	1854 (03-05)	MB GS EPS
 Actros MPlI (03-05)	AUTOM. TRANSMISSI	1858 (03-05)	MB GS EPS
 Actros MPlI (03-05)	AUTOM. TRANSMISSI	2032 (03-05)	MB GS EPS

## Systems supported by ECReader (up to V4,90)

### TRUCKS




























### Mercedes Trucks

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Actros MPlI (03-05)	AUTOM. TRANSMISSI	2041 (03-05)	MB GS EPS
 Actros MPlI (03-05)	AUTOM. TRANSMISSI	2044 (03-05)	MB GS EPS
 Actros MPlI (03-05)	AUTOM. TRANSMISSI	2532 (03-05)	MB GS EPS
 Actros MPlI (03-05)	AUTOM. TRANSMISSI	2536 (03-05)	MB GS EPS
 Actros MPlI (03-05)	AUTOM. TRANSMISSI	2541 (03-05)	MB GS EPS
 Actros MPlI (03-05)	AUTOM. TRANSMISSI	2544 (03-05)	MB GS EPS
 Actros MPlI (03-05)	AUTOM. TRANSMISSI	2546 (03-05)	MB GS EPS
 Actros MPlI (03-05)	AUTOM. TRANSMISSI	2550 (03-05)	MB GS EPS
 Actros MPlI (03-05)	AUTOM. TRANSMISSI	2554 (03-05)	MB GS EPS
 Actros MPlI (03-05)	AUTOM. TRANSMISSI	2558 (03-05)	MB GS EPS
 Actros MPlI (03-05)	AUTOM. TRANSMISSI	4141 (03-05)	MB GS EPS
 Actros MPlI (03-05)	AUTOM. TRANSMISSI	4144 (03-05)	MB GS EPS
 Actros MPlI (03-05)	AUTOM. TRANSMISSI	4146 (03-05)	MB GS EPS
 Actros MPlI (03-05)	AUTOM. TRANSMISSI	4150 (03-05)	MB GS EPS
 Actros MPlI (03-05)	BRAKE POWER SUP	1832 (03-05)	MB RS RETARDER
 Actros MPlI (03-05)	BRAKE POWER SUP	1832 K (03-05)	MB RS RETARDER
 Actros MPlI (03-05)	BRAKE POWER SUP	1836 (03-05)	MB RS RETARDER
 Actros MPlI (03-05)	BRAKE POWER SUP	1841 (03-05)	MB RS RETARDER
 Actros MPlI (03-05)	BRAKE POWER SUP	1841 K (03-05)	MB RS RETARDER
 Actros MPlI (03-05)	BRAKE POWER SUP	1844 (03-05)	MB RS RETARDER
 Actros MPlI (03-05)	BRAKE POWER SUP	1844 K (03-05)	MB RS RETARDER
 Actros MPlI (03-05)	BRAKE POWER SUP	1846 (03-05)	MB RS RETARDER
 Actros MPlI (03-05)	BRAKE POWER SUP	1850 (03-05)	MB RS RETARDER
 Actros MPlI (03-05)	BRAKE POWER SUP	1854 (03-05)	MB RS RETARDER
 Actros MPlI (03-05)	BRAKE POWER SUP	1858 (03-05)	MB RS RETARDER
 Actros MPlI (03-05)	BRAKE POWER SUP	2032 (03-05)	MB RS RETARDER
 Actros MPlI (03-05)	BRAKE POWER SUP	2041 (03-05)	MB RS RETARDER

## Systems supported by ECReader (up to V4,90)

### TRUCKS




























### Mercedes Trucks

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Actros MPII (03-05)	BRAKE POWER SUP	2044 (03-05)	MB RS RETARDER
 Actros MPII (03-05)	BRAKE POWER SUP	2532 (03-05)	MB RS RETARDER
 Actros MPII (03-05)	BRAKE POWER SUP	2536 (03-05)	MB RS RETARDER
 Actros MPII (03-05)	BRAKE POWER SUP	2541 (03-05)	MB RS RETARDER
 Actros MPII (03-05)	BRAKE POWER SUP	2544 (03-05)	MB RS RETARDER
 Actros MPII (03-05)	BRAKE POWER SUP	2546 (03-05)	MB RS RETARDER
 Actros MPII (03-05)	BRAKE POWER SUP	2550 (03-05)	MB RS RETARDER
 Actros MPII (03-05)	BRAKE POWER SUP	2554 (03-05)	MB RS RETARDER
 Actros MPII (03-05)	BRAKE POWER SUP	2558 (03-05)	MB RS RETARDER
 Actros MPII (03-05)	BRAKE POWER SUP	4141 (03-05)	MB RS RETARDER
 Actros MPII (03-05)	BRAKE POWER SUP	4144 (03-05)	MB RS RETARDER
 Actros MPII (03-05)	BRAKE POWER SUP	4146 (03-05)	MB RS RETARDER
 Actros MPII (03-05)	BRAKE POWER SUP	4150 (03-05)	MB RS RETARDER
 Actros MPII (03-05)	BRAKE SYS. MANAG	1832 (03-05)	MB BS EPB
 Actros MPII (03-05)	BRAKE SYS. MANAG	1832 K (03-05)	MB BS EPB
 Actros MPII (03-05)	BRAKE SYS. MANAG	1836 (03-05)	MB BS EPB
 Actros MPII (03-05)	BRAKE SYS. MANAG	1841 (03-05)	MB BS EPB
 Actros MPII (03-05)	BRAKE SYS. MANAG	1841 K (03-05)	MB BS EPB
 Actros MPII (03-05)	BRAKE SYS. MANAG	1844 (03-05)	MB BS EPB
 Actros MPII (03-05)	BRAKE SYS. MANAG	1844 K (03-05)	MB BS EPB
 Actros MPII (03-05)	BRAKE SYS. MANAG	1846 (03-05)	MB BS EPB
 Actros MPII (03-05)	BRAKE SYS. MANAG	1850 (03-05)	MB BS EPB
 Actros MPII (03-05)	BRAKE SYS. MANAG	1854 (03-05)	MB BS EPB
 Actros MPII (03-05)	BRAKE SYS. MANAG	1858 (03-05)	MB BS EPB
 Actros MPII (03-05)	BRAKE SYS. MANAG	2032 (03-05)	MB BS EPB
 Actros MPII (03-05)	BRAKE SYS. MANAG	2041 (03-05)	MB BS EPB
 Actros MPII (03-05)	BRAKE SYS. MANAG	2044 (03-05)	MB BS EPB

## Systems supported by ECReader (up to V4,90)

### TRUCKS




























### Mercedes Trucks

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Actros MPII (03-05)	BRAKE SYS. MANAG	2532 (03-05)	MB BS EPB
 Actros MPII (03-05)	BRAKE SYS. MANAG	2536 (03-05)	MB BS EPB
 Actros MPII (03-05)	BRAKE SYS. MANAG	2541 (03-05)	MB BS EPB
 Actros MPII (03-05)	BRAKE SYS. MANAG	2544 (03-05)	MB BS EPB
 Actros MPII (03-05)	BRAKE SYS. MANAG	2546 (03-05)	MB BS EPB
 Actros MPII (03-05)	BRAKE SYS. MANAG	2550 (03-05)	MB BS EPB
 Actros MPII (03-05)	BRAKE SYS. MANAG	2554 (03-05)	MB BS EPB
 Actros MPII (03-05)	BRAKE SYS. MANAG	2558 (03-05)	MB BS EPB
 Actros MPII (03-05)	BRAKE SYS. MANAG	4141 (03-05)	MB BS EPB
 Actros MPII (03-05)	BRAKE SYS. MANAG	4144 (03-05)	MB BS EPB
 Actros MPII (03-05)	BRAKE SYS. MANAG	4146 (03-05)	MB BS EPB
 Actros MPII (03-05)	BRAKE SYS. MANAG	4150 (03-05)	MB BS EPB
 Actros MPII (03-05)	CHASSIS NETWORK	1832 (03-05)	MB Base Module
 Actros MPII (03-05)	CHASSIS NETWORK	1832 (03-05)	MB Front Module
 Actros MPII (03-05)	CHASSIS NETWORK	1832 (03-05)	MB Rear Module
 Actros MPII (03-05)	CHASSIS NETWORK	1832 K (03-05)	MB Base Module
 Actros MPII (03-05)	CHASSIS NETWORK	1832 K (03-05)	MB Front Module
 Actros MPII (03-05)	CHASSIS NETWORK	1832 K (03-05)	MB Rear Module
 Actros MPII (03-05)	CHASSIS NETWORK	1836 (03-05)	MB Base Module
 Actros MPII (03-05)	CHASSIS NETWORK	1836 (03-05)	MB Front Module
 Actros MPII (03-05)	CHASSIS NETWORK	1836 (03-05)	MB Rear Module
 Actros MPII (03-05)	CHASSIS NETWORK	1841 (03-05)	MB Base Module
 Actros MPII (03-05)	CHASSIS NETWORK	1841 (03-05)	MB Front Module
 Actros MPII (03-05)	CHASSIS NETWORK	1841 (03-05)	MB Rear Module
 Actros MPII (03-05)	CHASSIS NETWORK	1841 K (03-05)	MB Base Module
 Actros MPII (03-05)	CHASSIS NETWORK	1841 K (03-05)	MB Front Module
 Actros MPII (03-05)	CHASSIS NETWORK	1841 K (03-05)	MB Rear Module

## Systems supported by ECReader (up to V4,90)

### TRUCKS




























### Mercedes Trucks

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Actros MPII (03-05)	CHASSIS NETWORK	1844 (03-05)	MB Base Module
 Actros MPII (03-05)	CHASSIS NETWORK	1844 (03-05)	MB Front Module
 Actros MPII (03-05)	CHASSIS NETWORK	1844 (03-05)	MB Rear Module
 Actros MPII (03-05)	CHASSIS NETWORK	1844 K (03-05)	MB Base Module
 Actros MPII (03-05)	CHASSIS NETWORK	1844 K (03-05)	MB Front Module
 Actros MPII (03-05)	CHASSIS NETWORK	1844 K (03-05)	MB Rear Module
 Actros MPII (03-05)	CHASSIS NETWORK	1846 (03-05)	MB Base Module
 Actros MPII (03-05)	CHASSIS NETWORK	1846 (03-05)	MB Front Module
 Actros MPII (03-05)	CHASSIS NETWORK	1846 (03-05)	MB Rear Module
 Actros MPII (03-05)	CHASSIS NETWORK	1850 (03-05)	MB Base Module
 Actros MPII (03-05)	CHASSIS NETWORK	1850 (03-05)	MB Front Module
 Actros MPII (03-05)	CHASSIS NETWORK	1850 (03-05)	MB Rear Module
 Actros MPII (03-05)	CHASSIS NETWORK	1854 (03-05)	MB Base Module
 Actros MPII (03-05)	CHASSIS NETWORK	1854 (03-05)	MB Front Module
 Actros MPII (03-05)	CHASSIS NETWORK	1854 (03-05)	MB Rear Module
 Actros MPII (03-05)	CHASSIS NETWORK	1858 (03-05)	MB Base Module
 Actros MPII (03-05)	CHASSIS NETWORK	1858 (03-05)	MB Front Module
 Actros MPII (03-05)	CHASSIS NETWORK	1858 (03-05)	MB Rear Module
 Actros MPII (03-05)	CHASSIS NETWORK	2032 (03-05)	MB Base Module
 Actros MPII (03-05)	CHASSIS NETWORK	2032 (03-05)	MB Front Module
 Actros MPII (03-05)	CHASSIS NETWORK	2032 (03-05)	MB Rear Module
 Actros MPII (03-05)	CHASSIS NETWORK	2041 (03-05)	MB Base Module
 Actros MPII (03-05)	CHASSIS NETWORK	2041 (03-05)	MB Front Module
 Actros MPII (03-05)	CHASSIS NETWORK	2041 (03-05)	MB Rear Module
 Actros MPII (03-05)	CHASSIS NETWORK	2044 (03-05)	MB Base Module
 Actros MPII (03-05)	CHASSIS NETWORK	2044 (03-05)	MB Front Module
 Actros MPII (03-05)	CHASSIS NETWORK	2044 (03-05)	MB Rear Module

## Systems supported by ECReader (up to V4,90)

### TRUCKS





### Mercedes Trucks

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Actros MPlI (03-05)	CHASSIS NETWORK	2532 (03-05)	MB Base Module
 Actros MPlI (03-05)	CHASSIS NETWORK	2532 (03-05)	MB Rear Module
 Actros MPlI (03-05)	CHASSIS NETWORK	2536 (03-05)	MB Base Module
 Actros MPlI (03-05)	CHASSIS NETWORK	2536 (03-05)	MB Rear Module
 Actros MPlI (03-05)	CHASSIS NETWORK	2541 (03-05)	MB Base Module
 Actros MPlI (03-05)	CHASSIS NETWORK	2541 (03-05)	MB Front Module
 Actros MPlI (03-05)	CHASSIS NETWORK	2541 (03-05)	MB Rear Module
 Actros MPlI (03-05)	CHASSIS NETWORK	2544 (03-05)	MB Base Module
 Actros MPlI (03-05)	CHASSIS NETWORK	2544 (03-05)	MB Front Module
 Actros MPlI (03-05)	CHASSIS NETWORK	2544 (03-05)	MB Rear Module
 Actros MPlI (03-05)	CHASSIS NETWORK	2546 (03-05)	MB Base Module
 Actros MPlI (03-05)	CHASSIS NETWORK	2546 (03-05)	MB Front Module
 Actros MPlI (03-05)	CHASSIS NETWORK	2546 (03-05)	MB Rear Module
 Actros MPlI (03-05)	CHASSIS NETWORK	2550 (03-05)	MB Base Module
 Actros MPlI (03-05)	CHASSIS NETWORK	2550 (03-05)	MB Front Module
 Actros MPlI (03-05)	CHASSIS NETWORK	2550 (03-05)	MB Rear Module
 Actros MPlI (03-05)	CHASSIS NETWORK	2554 (03-05)	MB Base Module
 Actros MPlI (03-05)	CHASSIS NETWORK	2554 (03-05)	MB Rear Module
 Actros MPlI (03-05)	CHASSIS NETWORK	2558 (03-05)	MB Base Module
 Actros MPlI (03-05)	CHASSIS NETWORK	2558 (03-05)	MB Front Module
 Actros MPlI (03-05)	CHASSIS NETWORK	2558 (03-05)	MB Rear Module
 Actros MPlI (03-05)	CHASSIS NETWORK	4141 (03-05)	MB Base Module
 Actros MPlI (03-05)	CHASSIS NETWORK	4141 (03-05)	MB Front Module
 Actros MPlI (03-05)	CHASSIS NETWORK	4141 (03-05)	MB Rear Module
 Actros MPlI (03-05)	CHASSIS NETWORK	4144 (03-05)	MB Base Module
 Actros MPlI (03-05)	CHASSIS NETWORK	4144 (03-05)	MB Front Module
 Actros MPlI (03-05)	CHASSIS NETWORK	4144 (03-05)	MB Rear Module

## Systems supported by ECReader (up to V4,90)

### TRUCKS




























### Mercedes Trucks

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Actros MPlI (03-05)	CHASSIS NETWORK	4146 (03-05)	MB Base Module
 Actros MPlI (03-05)	CHASSIS NETWORK	4146 (03-05)	MB Front Module
 Actros MPlI (03-05)	CHASSIS NETWORK	4146 (03-05)	MB Rear Module
 Actros MPlI (03-05)	CHASSIS NETWORK	4150 (03-05)	MB Base Module
 Actros MPlI (03-05)	CHASSIS NETWORK	4150 (03-05)	MB Front Module
 Actros MPlI (03-05)	CHASSIS NETWORK	4150 (03-05)	MB Rear Module
 Actros MPlI (03-05)	CHRONOTACHOGRA	1832 (03-05)	MB TACHOGRAPH
 Actros MPlI (03-05)	CHRONOTACHOGRA	1832 K (03-05)	MB TACHOGRAPH
 Actros MPlI (03-05)	CHRONOTACHOGRA	1836 (03-05)	MB TACHOGRAPH
 Actros MPlI (03-05)	CHRONOTACHOGRA	1841 (03-05)	MB TACHOGRAPH
 Actros MPlI (03-05)	CHRONOTACHOGRA	1841 K (03-05)	MB TACHOGRAPH
 Actros MPlI (03-05)	CHRONOTACHOGRA	1844 (03-05)	MB TACHOGRAPH
 Actros MPlI (03-05)	CHRONOTACHOGRA	1844 K (03-05)	MB TACHOGRAPH
 Actros MPlI (03-05)	CHRONOTACHOGRA	1846 (03-05)	MB TACHOGRAPH
 Actros MPlI (03-05)	CHRONOTACHOGRA	1850 (03-05)	MB TACHOGRAPH
 Actros MPlI (03-05)	CHRONOTACHOGRA	1854 (03-05)	MB TACHOGRAPH
 Actros MPlI (03-05)	CHRONOTACHOGRA	1858 (03-05)	MB TACHOGRAPH
 Actros MPlI (03-05)	CHRONOTACHOGRA	2032 (03-05)	MB TACHOGRAPH
 Actros MPlI (03-05)	CHRONOTACHOGRA	2041 (03-05)	MB TACHOGRAPH
 Actros MPlI (03-05)	CHRONOTACHOGRA	2044 (03-05)	MB TACHOGRAPH
 Actros MPlI (03-05)	CHRONOTACHOGRA	2532 (03-05)	MB TACHOGRAPH
 Actros MPlI (03-05)	CHRONOTACHOGRA	2536 (03-05)	MB TACHOGRAPH
 Actros MPlI (03-05)	CHRONOTACHOGRA	2541 (03-05)	MB TACHOGRAPH
 Actros MPlI (03-05)	CHRONOTACHOGRA	2544 (03-05)	MB TACHOGRAPH
 Actros MPlI (03-05)	CHRONOTACHOGRA	2546 (03-05)	MB TACHOGRAPH
 Actros MPlI (03-05)	CHRONOTACHOGRA	2550 (03-05)	MB TACHOGRAPH
 Actros MPlI (03-05)	CHRONOTACHOGRA	2554 (03-05)	MB TACHOGRAPH

## Systems supported by ECUREADER (up to V4,90)

### TRUCKS




























### Mercedes Trucks

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Actros MPlI (03-05)	CHRONOTACHOGRA	2558 (03-05)	MB TACHOGRAPH
 Actros MPlI (03-05)	CHRONOTACHOGRA	4141 (03-05)	MB TACHOGRAPH
 Actros MPlI (03-05)	CHRONOTACHOGRA	4144 (03-05)	MB TACHOGRAPH
 Actros MPlI (03-05)	CHRONOTACHOGRA	4146 (03-05)	MB TACHOGRAPH
 Actros MPlI (03-05)	CHRONOTACHOGRA	4150 (03-05)	MB TACHOGRAPH
 Actros MPlI (03-05)	CRUISE MANAGEME	1832 (03-05)	FR FMR
 Actros MPlI (03-05)	CRUISE MANAGEME	1832 K (03-05)	FR FMR
 Actros MPlI (03-05)	CRUISE MANAGEME	1836 (03-05)	FR FMR
 Actros MPlI (03-05)	CRUISE MANAGEME	1841 (03-05)	FR FMR
 Actros MPlI (03-05)	CRUISE MANAGEME	1841 K (03-05)	FR FMR
 Actros MPlI (03-05)	CRUISE MANAGEME	1844 (03-05)	FR FMR
 Actros MPlI (03-05)	CRUISE MANAGEME	1844 K (03-05)	FR FMR
 Actros MPlI (03-05)	CRUISE MANAGEME	1846 (03-05)	FR FMR
 Actros MPlI (03-05)	CRUISE MANAGEME	1850 (03-05)	FR FMR
 Actros MPlI (03-05)	CRUISE MANAGEME	1854 (03-05)	FR FMR
 Actros MPlI (03-05)	CRUISE MANAGEME	1858 (03-05)	FR FMR
 Actros MPlI (03-05)	CRUISE MANAGEME	2032 (03-05)	FR FMR
 Actros MPlI (03-05)	CRUISE MANAGEME	2041 (03-05)	FR FMR
 Actros MPlI (03-05)	CRUISE MANAGEME	2044 (03-05)	FR FMR
 Actros MPlI (03-05)	CRUISE MANAGEME	2532 (03-05)	FR FMR
 Actros MPlI (03-05)	CRUISE MANAGEME	2536 (03-05)	FR FMR
 Actros MPlI (03-05)	CRUISE MANAGEME	2541 (03-05)	FR FMR
 Actros MPlI (03-05)	CRUISE MANAGEME	2544 (03-05)	FR FMR
 Actros MPlI (03-05)	CRUISE MANAGEME	2546 (03-05)	FR FMR
 Actros MPlI (03-05)	CRUISE MANAGEME	2550 (03-05)	FR FMR
 Actros MPlI (03-05)	CRUISE MANAGEME	2554 (03-05)	FR FMR
 Actros MPlI (03-05)	CRUISE MANAGEME	2558 (03-05)	FR FMR

## Systems supported by ECReader (up to V4,90)

### TRUCKS


























### Mercedes Trucks

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Actros MPlI (03-05)	CRUISE MANAGEME	4141 (03-05)	FR FMR
 Actros MPlI (03-05)	CRUISE MANAGEME	4144 (03-05)	FR FMR
 Actros MPlI (03-05)	CRUISE MANAGEME	4146 (03-05)	FR FMR
 Actros MPlI (03-05)	CRUISE MANAGEME	4150 (03-05)	FR FMR
 Actros MPlI (03-05)	DASHBOARD	1832 (03-05)	MB INS
 Actros MPlI (03-05)	DASHBOARD	1832 K (03-05)	MB INS
 Actros MPlI (03-05)	DASHBOARD	1836 (03-05)	MB INS
 Actros MPlI (03-05)	DASHBOARD	1841 (03-05)	MB INS
 Actros MPlI (03-05)	DASHBOARD	1841 K (03-05)	MB INS
 Actros MPlI (03-05)	DASHBOARD	1844 (03-05)	MB INS
 Actros MPlI (03-05)	DASHBOARD	1844 K (03-05)	MB INS
 Actros MPlI (03-05)	DASHBOARD	1846 (03-05)	MB INS
 Actros MPlI (03-05)	DASHBOARD	1850 (03-05)	MB INS
 Actros MPlI (03-05)	DASHBOARD	1854 (03-05)	MB INS
 Actros MPlI (03-05)	DASHBOARD	1858 (03-05)	MB INS
 Actros MPlI (03-05)	DASHBOARD	2032 (03-05)	MB INS
 Actros MPlI (03-05)	DASHBOARD	2041 (03-05)	MB INS
 Actros MPlI (03-05)	DASHBOARD	2044 (03-05)	MB INS
 Actros MPlI (03-05)	DASHBOARD	2532 (03-05)	MB INS
 Actros MPlI (03-05)	DASHBOARD	2536 (03-05)	MB INS
 Actros MPlI (03-05)	DASHBOARD	2541 (03-05)	MB INS
 Actros MPlI (03-05)	DASHBOARD	2544 (03-05)	MB INS
 Actros MPlI (03-05)	DASHBOARD	2546 (03-05)	MB INS
 Actros MPlI (03-05)	DASHBOARD	2550 (03-05)	MB INS
 Actros MPlI (03-05)	DASHBOARD	2554 (03-05)	MB INS
 Actros MPlI (03-05)	DASHBOARD	2558 (03-05)	MB INS
 Actros MPlI (03-05)	DASHBOARD	4141 (03-05)	MB INS

## Systems supported by ECReader (up to V4,90)

### TRUCKS



























### Mercedes Trucks

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Actros MPlI (03-05)	DASHBOARD	4144 (03-05)	MB INS
 Actros MPlI (03-05)	DASHBOARD	4146 (03-05)	MB INS
 Actros MPlI (03-05)	DASHBOARD	4150 (03-05)	MB INS
 Actros MPlI (03-05)	ENGINE MANAGEME	1832 (03-05)	MB MR PLD (EDC)
 Actros MPlI (03-05)	ENGINE MANAGEME	1832 K (03-05)	MB MR PLD (EDC)
 Actros MPlI (03-05)	ENGINE MANAGEME	1836 (03-05)	MB MR PLD (EDC)
 Actros MPlI (03-05)	ENGINE MANAGEME	1841 (03-05)	MB MR PLD (EDC)
 Actros MPlI (03-05)	ENGINE MANAGEME	1841 K (03-05)	MB MR PLD (EDC)
 Actros MPlI (03-05)	ENGINE MANAGEME	1844 (03-05)	MB MR PLD (EDC)
 Actros MPlI (03-05)	ENGINE MANAGEME	1844 K (03-05)	MB MR PLD (EDC)
 Actros MPlI (03-05)	ENGINE MANAGEME	1846 (03-05)	MB MR PLD (EDC)
 Actros MPlI (03-05)	ENGINE MANAGEME	1850 (03-05)	MB MR PLD (EDC)
 Actros MPlI (03-05)	ENGINE MANAGEME	1854 (03-05)	MB MR PLD (EDC)
 Actros MPlI (03-05)	ENGINE MANAGEME	1858 (03-05)	MB MR PLD (EDC)
 Actros MPlI (03-05)	ENGINE MANAGEME	2032 (03-05)	MB MR PLD (EDC)
 Actros MPlI (03-05)	ENGINE MANAGEME	2041 (03-05)	MB MR PLD (EDC)
 Actros MPlI (03-05)	ENGINE MANAGEME	2044 (03-05)	MB MR PLD (EDC)
 Actros MPlI (03-05)	ENGINE MANAGEME	2532 (03-05)	MB MR PLD (EDC)
 Actros MPlI (03-05)	ENGINE MANAGEME	2536 (03-05)	MB MR PLD (EDC)
 Actros MPlI (03-05)	ENGINE MANAGEME	2541 (03-05)	MB MR PLD (EDC)
 Actros MPlI (03-05)	ENGINE MANAGEME	2544 (03-05)	MB MR PLD (EDC)
 Actros MPlI (03-05)	ENGINE MANAGEME	2546 (03-05)	MB MR PLD (EDC)
 Actros MPlI (03-05)	ENGINE MANAGEME	2550 (03-05)	MB MR PLD (EDC)
 Actros MPlI (03-05)	ENGINE MANAGEME	2554 (03-05)	MB MR PLD (EDC)
 Actros MPlI (03-05)	ENGINE MANAGEME	2558 (03-05)	MB MR PLD (EDC)
 Actros MPlI (03-05)	ENGINE MANAGEME	4141 (03-05)	MB MR PLD (EDC)
 Actros MPlI (03-05)	ENGINE MANAGEME	4144 (03-05)	MB MR PLD (EDC)

## Systems supported by ECReader (up to V4,90)

### TRUCKS



























### Mercedes Trucks

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Actros MPlI (03-05)	ENGINE MANAGEME	4146 (03-05)	MB MR PLD (EDC)
 Actros MPlI (03-05)	ENGINE MANAGEME	4150 (03-05)	MB MR PLD (EDC)
 Actros MPlI (03-05)	MAINTENANCE SYST	1832 (03-05)	MB WS
 Actros MPlI (03-05)	MAINTENANCE SYST	1832 K (03-05)	MB WS
 Actros MPlI (03-05)	MAINTENANCE SYST	1836 (03-05)	MB WS
 Actros MPlI (03-05)	MAINTENANCE SYST	1841 (03-05)	MB WS
 Actros MPlI (03-05)	MAINTENANCE SYST	1841 K (03-05)	MB WS
 Actros MPlI (03-05)	MAINTENANCE SYST	1844 (03-05)	MB WS
 Actros MPlI (03-05)	MAINTENANCE SYST	1844 K (03-05)	MB WS
 Actros MPlI (03-05)	MAINTENANCE SYST	1846 (03-05)	MB WS
 Actros MPlI (03-05)	MAINTENANCE SYST	1850 (03-05)	MB WS
 Actros MPlI (03-05)	MAINTENANCE SYST	1854 (03-05)	MB WS
 Actros MPlI (03-05)	MAINTENANCE SYST	1858 (03-05)	MB WS
 Actros MPlI (03-05)	MAINTENANCE SYST	2032 (03-05)	MB WS
 Actros MPlI (03-05)	MAINTENANCE SYST	2041 (03-05)	MB WS
 Actros MPlI (03-05)	MAINTENANCE SYST	2044 (03-05)	MB WS
 Actros MPlI (03-05)	MAINTENANCE SYST	2532 (03-05)	MB WS
 Actros MPlI (03-05)	MAINTENANCE SYST	2536 (03-05)	MB WS
 Actros MPlI (03-05)	MAINTENANCE SYST	2541 (03-05)	MB WS
 Actros MPlI (03-05)	MAINTENANCE SYST	2544 (03-05)	MB WS
 Actros MPlI (03-05)	MAINTENANCE SYST	2546 (03-05)	MB WS
 Actros MPlI (03-05)	MAINTENANCE SYST	2550 (03-05)	MB WS
 Actros MPlI (03-05)	MAINTENANCE SYST	2554 (03-05)	MB WS
 Actros MPlI (03-05)	MAINTENANCE SYST	2558 (03-05)	MB WS
 Actros MPlI (03-05)	MAINTENANCE SYST	4141 (03-05)	MB WS
 Actros MPlI (03-05)	MAINTENANCE SYST	4144 (03-05)	MB WS
 Actros MPlI (03-05)	MAINTENANCE SYST	4146 (03-05)	MB WS

## Systems supported by ECReader (up to V4,90)

### TRUCKS




























### Mercedes Trucks

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Actros MP11 (03-05)	MAINTENANCE SYST	4150 (03-05)	MB WS
 Actros MP11 (05-08)	AUTOM. TRANSMISSI	1832 BlueTec 4/5 (05-08)	GS II
 Actros MP11 (05-08)	AUTOM. TRANSMISSI	1836 BlueTec 4/5 (05-08)	GS II
 Actros MP11 (05-08)	AUTOM. TRANSMISSI	1841 BlueTec 4/5 (05-08)	GS II
 Actros MP11 (05-08)	AUTOM. TRANSMISSI	1844 BlueTec 4/5 (05-08)	GS II
 Actros MP11 (05-08)	AUTOM. TRANSMISSI	1846 BlueTec 4/5 (05-08)	GS II
 Actros MP11 (05-08)	AUTOM. TRANSMISSI	1848 BlueTec 4/5 (05-08)	GS II
 Actros MP11 (05-08)	AUTOM. TRANSMISSI	1851 BlueTec 4/5 (05-08)	GS II
 Actros MP11 (05-08)	AUTOM. TRANSMISSI	1855 BlueTec 4/5 (05-08)	GS II
 Actros MP11 (05-08)	AUTOM. TRANSMISSI	1860 BlueTec 4/5 (05-08)	GS II
 Actros MP11 (05-08)	AUTOM. TRANSMISSI	2532 BlueTec 4/5 (05-08)	GS II
 Actros MP11 (05-08)	AUTOM. TRANSMISSI	2536 BlueTec 4/5 (05-08)	GS II
 Actros MP11 (05-08)	AUTOM. TRANSMISSI	2541 BlueTec 4/5 (05-08)	GS II
 Actros MP11 (05-08)	AUTOM. TRANSMISSI	2544 BlueTec 4/5 (05-08)	GS II
 Actros MP11 (05-08)	AUTOM. TRANSMISSI	2546 BlueTec 4/5 (05-08)	GS II
 Actros MP11 (05-08)	AUTOM. TRANSMISSI	2548 BlueTec 4/5 (05-08)	GS II
 Actros MP11 (05-08)	AUTOM. TRANSMISSI	2551 BlueTec 4/5 (05-08)	GS II
 Actros MP11 (05-08)	AUTOM. TRANSMISSI	2555 BlueTec 4/5 (05-08)	GS II
 Actros MP11 (05-08)	AUTOM. TRANSMISSI	2560 BlueTec 4/5 (05-08)	GS II
 Actros MP11 (05-08)	BRAKE SYS. MANAG	1832 BlueTec 4/5 (05-08)	BS
 Actros MP11 (05-08)	BRAKE SYS. MANAG	1836 BlueTec 4/5 (05-08)	BS
 Actros MP11 (05-08)	BRAKE SYS. MANAG	1841 BlueTec 4/5 (05-08)	BS
 Actros MP11 (05-08)	BRAKE SYS. MANAG	1844 BlueTec 4/5 (05-08)	BS
 Actros MP11 (05-08)	BRAKE SYS. MANAG	1846 BlueTec 4/5 (05-08)	BS
 Actros MP11 (05-08)	BRAKE SYS. MANAG	1848 BlueTec 4/5 (05-08)	BS
 Actros MP11 (05-08)	BRAKE SYS. MANAG	1851 BlueTec 4/5 (05-08)	BS

## Systems supported by ECReader (up to V4,90)

### TRUCKS




























### Mercedes Trucks

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Actros MPlI (05-08)	BRAKE SYS. MANAG	1855 BlueTec 4/5 (05-08)	BS
 Actros MPlI (05-08)	BRAKE SYS. MANAG	1860 BlueTec 4/5 (05-08)	BS
 Actros MPlI (05-08)	BRAKE SYS. MANAG	2532 BlueTec 4/5 (05-08)	BS
 Actros MPlI (05-08)	BRAKE SYS. MANAG	2536 BlueTec 4/5 (05-08)	BS
 Actros MPlI (05-08)	BRAKE SYS. MANAG	2541 BlueTec 4/5 (05-08)	BS
 Actros MPlI (05-08)	BRAKE SYS. MANAG	2544 BlueTec 4/5 (05-08)	BS
 Actros MPlI (05-08)	BRAKE SYS. MANAG	2546 BlueTec 4/5 (05-08)	BS
 Actros MPlI (05-08)	BRAKE SYS. MANAG	2548 BlueTec 4/5 (05-08)	BS
 Actros MPlI (05-08)	BRAKE SYS. MANAG	2551 BlueTec 4/5 (05-08)	BS
 Actros MPlI (05-08)	BRAKE SYS. MANAG	2555 BlueTec 4/5 (05-08)	BS
 Actros MPlI (05-08)	BRAKE SYS. MANAG	2560 BlueTec 4/5 (05-08)	BS
 Actros MPlI (05-08)	CHASSIS NETWORK	1832 BlueTec 4/5 (05-08)	FM Front Module
 Actros MPlI (05-08)	CHASSIS NETWORK	1832 BlueTec 4/5 (05-08)	HM Rear Module
 Actros MPlI (05-08)	CHASSIS NETWORK	1832 BlueTec 4/5 (05-08)	MSF Modular Panel
 Actros MPlI (05-08)	CHASSIS NETWORK	1836 BlueTec 4/5 (05-08)	FM Front Module
 Actros MPlI (05-08)	CHASSIS NETWORK	1836 BlueTec 4/5 (05-08)	HM Rear Module
 Actros MPlI (05-08)	CHASSIS NETWORK	1836 BlueTec 4/5 (05-08)	MSF Modular Panel
 Actros MPlI (05-08)	CHASSIS NETWORK	1841 BlueTec 4/5 (05-08)	FM Front Module
 Actros MPlI (05-08)	CHASSIS NETWORK	1841 BlueTec 4/5 (05-08)	HM Rear Module
 Actros MPlI (05-08)	CHASSIS NETWORK	1841 BlueTec 4/5 (05-08)	MSF Modular Panel
 Actros MPlI (05-08)	CHASSIS NETWORK	1844 BlueTec 4/5 (05-08)	FM Front Module
 Actros MPlI (05-08)	CHASSIS NETWORK	1844 BlueTec 4/5 (05-08)	HM Rear Module
 Actros MPlI (05-08)	CHASSIS NETWORK	1844 BlueTec 4/5 (05-08)	MSF Modular Panel
 Actros MPlI (05-08)	CHASSIS NETWORK	1846 BlueTec 4/5 (05-08)	FM Front Module
 Actros MPlI (05-08)	CHASSIS NETWORK	1846 BlueTec 4/5 (05-08)	HM Rear Module
 Actros MPlI (05-08)	CHASSIS NETWORK	1846 BlueTec 4/5 (05-08)	MSF Modular Panel
 Actros MPlI (05-08)	CHASSIS NETWORK	1848 BlueTec 4/5 (05-08)	FM Front Module

## Systems supported by ECReader (up to V4,90)

### TRUCKS




















### Mercedes Trucks

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Actros MPlI (05-08)	CHASSIS NETWORK	1848 BlueTec 4/5 (05-08)	HM Rear Module
 Actros MPlI (05-08)	CHASSIS NETWORK	1848 BlueTec 4/5 (05-08)	MSF Modular Panel
 Actros MPlI (05-08)	CHASSIS NETWORK	1851 BlueTec 4/5 (05-08)	FM Front Module
 Actros MPlI (05-08)	CHASSIS NETWORK	1851 BlueTec 4/5 (05-08)	HM Rear Module
 Actros MPlI (05-08)	CHASSIS NETWORK	1851 BlueTec 4/5 (05-08)	MSF Modular Panel
 Actros MPlI (05-08)	CHASSIS NETWORK	1855 BlueTec 4/5 (05-08)	FM Front Module
 Actros MPlI (05-08)	CHASSIS NETWORK	1855 BlueTec 4/5 (05-08)	HM Rear Module
 Actros MPlI (05-08)	CHASSIS NETWORK	1855 BlueTec 4/5 (05-08)	MSF Modular Panel
 Actros MPlI (05-08)	CHASSIS NETWORK	1860 BlueTec 4/5 (05-08)	FM Front Module
 Actros MPlI (05-08)	CHASSIS NETWORK	1860 BlueTec 4/5 (05-08)	HM Rear Module
 Actros MPlI (05-08)	CHASSIS NETWORK	1860 BlueTec 4/5 (05-08)	MSF Modular Panel
 Actros MPlI (05-08)	CHASSIS NETWORK	2532 BlueTec 4/5 (05-08)	FM Front Module
 Actros MPlI (05-08)	CHASSIS NETWORK	2532 BlueTec 4/5 (05-08)	HM Rear Module
 Actros MPlI (05-08)	CHASSIS NETWORK	2532 BlueTec 4/5 (05-08)	MSF Modular Panel
 Actros MPlI (05-08)	CHASSIS NETWORK	2536 BlueTec 4/5 (05-08)	FM Front Module
 Actros MPlI (05-08)	CHASSIS NETWORK	2536 BlueTec 4/5 (05-08)	HM Rear Module
 Actros MPlI (05-08)	CHASSIS NETWORK	2536 BlueTec 4/5 (05-08)	MSF Modular Panel
 Actros MPlI (05-08)	CHASSIS NETWORK	2541 BlueTec 4/5 (05-08)	FM Front Module
 Actros MPlI (05-08)	CHASSIS NETWORK	2541 BlueTec 4/5 (05-08)	HM Rear Module
 Actros MPlI (05-08)	CHASSIS NETWORK	2541 BlueTec 4/5 (05-08)	MSF Modular Panel
 Actros MPlI (05-08)	CHASSIS NETWORK	2544 BlueTec 4/5 (05-08)	FM Front Module
 Actros MPlI (05-08)	CHASSIS NETWORK	2544 BlueTec 4/5 (05-08)	HM Rear Module
 Actros MPlI (05-08)	CHASSIS NETWORK	2544 BlueTec 4/5 (05-08)	MSF Modular Panel
 Actros MPlI (05-08)	CHASSIS NETWORK	2546 BlueTec 4/5 (05-08)	FM Front Module
 Actros MPlI (05-08)	CHASSIS NETWORK	2546 BlueTec 4/5 (05-08)	HM Rear Module
 Actros MPlI (05-08)	CHASSIS NETWORK	2546 BlueTec 4/5 (05-08)	MSF Modular Panel
 Actros MPlI (05-08)	CHASSIS NETWORK	2548 BlueTec 4/5 (05-08)	FM Front Module

## Systems supported by ECReader (up to V4,90)

### TRUCKS























### Mercedes Trucks

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Actros MPII (05-08)	CHASSIS NETWORK	2548 BlueTec 4/5 (05-08)	HM Rear Module
 Actros MPII (05-08)	CHASSIS NETWORK	2548 BlueTec 4/5 (05-08)	MSF Modular Panel
 Actros MPII (05-08)	CHASSIS NETWORK	2551 BlueTec 4/5 (05-08)	FM Front Module
 Actros MPII (05-08)	CHASSIS NETWORK	2551 BlueTec 4/5 (05-08)	HM Rear Module
 Actros MPII (05-08)	CHASSIS NETWORK	2551 BlueTec 4/5 (05-08)	MSF Modular Panel
 Actros MPII (05-08)	CHASSIS NETWORK	2555 BlueTec 4/5 (05-08)	FM Front Module
 Actros MPII (05-08)	CHASSIS NETWORK	2555 BlueTec 4/5 (05-08)	HM Rear Module
 Actros MPII (05-08)	CHASSIS NETWORK	2555 BlueTec 4/5 (05-08)	MSF Modular Panel
 Actros MPII (05-08)	CHASSIS NETWORK	2560 BlueTec 4/5 (05-08)	FM Front Module
 Actros MPII (05-08)	CHASSIS NETWORK	2560 BlueTec 4/5 (05-08)	HM Rear Module
 Actros MPII (05-08)	CHASSIS NETWORK	2560 BlueTec 4/5 (05-08)	MSF Modular Panel
 Actros MPII (05-08)	DASHBOARD	1832 BlueTec 4/5 (05-08)	INS Kombi instrument
 Actros MPII (05-08)	DASHBOARD	1836 BlueTec 4/5 (05-08)	INS Kombi instrument
 Actros MPII (05-08)	DASHBOARD	1841 BlueTec 4/5 (05-08)	INS Kombi instrument
 Actros MPII (05-08)	DASHBOARD	1844 BlueTec 4/5 (05-08)	INS Kombi instrument
 Actros MPII (05-08)	DASHBOARD	1846 BlueTec 4/5 (05-08)	INS Kombi instrument
 Actros MPII (05-08)	DASHBOARD	1848 BlueTec 4/5 (05-08)	INS Kombi instrument
 Actros MPII (05-08)	DASHBOARD	1851 BlueTec 4/5 (05-08)	INS Kombi instrument
 Actros MPII (05-08)	DASHBOARD	1855 BlueTec 4/5 (05-08)	INS Kombi instrument
 Actros MPII (05-08)	DASHBOARD	1860 BlueTec 4/5 (05-08)	INS Kombi instrument
 Actros MPII (05-08)	DASHBOARD	2532 BlueTec 4/5 (05-08)	INS Kombi instrument
 Actros MPII (05-08)	DASHBOARD	2536 BlueTec 4/5 (05-08)	INS Kombi instrument
 Actros MPII (05-08)	DASHBOARD	2541 BlueTec 4/5 (05-08)	INS Kombi instrument
 Actros MPII (05-08)	DASHBOARD	2544 BlueTec 4/5 (05-08)	INS Kombi instrument
 Actros MPII (05-08)	DASHBOARD	2546 BlueTec 4/5 (05-08)	INS Kombi instrument
 Actros MPII (05-08)	DASHBOARD	2548 BlueTec 4/5 (05-08)	INS Kombi instrument
 Actros MPII (05-08)	DASHBOARD	2551 BlueTec 4/5 (05-08)	INS Kombi instrument

## Systems supported by ECUreader (up to V4,90)

### TRUCKS




























### Mercedes Trucks

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Actros MPlI (05-08)	DASHBOARD	2555 BlueTec 4/5 (05-08)	INS Kombi instrument
 Actros MPlI (05-08)	DASHBOARD	2560 BlueTec 4/5 (05-08)	INS Kombi instrument
 Actros MPlI (05-08)	DRIVER SIDE DOOR	1832 BlueTec 4/5 (05-08)	TMF
 Actros MPlI (05-08)	DRIVER SIDE DOOR	1836 BlueTec 4/5 (05-08)	TMF
 Actros MPlI (05-08)	DRIVER SIDE DOOR	1841 BlueTec 4/5 (05-08)	TMF
 Actros MPlI (05-08)	DRIVER SIDE DOOR	1844 BlueTec 4/5 (05-08)	TMF
 Actros MPlI (05-08)	DRIVER SIDE DOOR	1846 BlueTec 4/5 (05-08)	TMF
 Actros MPlI (05-08)	DRIVER SIDE DOOR	1848 BlueTec 4/5 (05-08)	TMF
 Actros MPlI (05-08)	DRIVER SIDE DOOR	1851 BlueTec 4/5 (05-08)	TMF
 Actros MPlI (05-08)	DRIVER SIDE DOOR	1855 BlueTec 4/5 (05-08)	TMF
 Actros MPlI (05-08)	DRIVER SIDE DOOR	1860 BlueTec 4/5 (05-08)	TMF
 Actros MPlI (05-08)	DRIVER SIDE DOOR	2532 BlueTec 4/5 (05-08)	TMF
 Actros MPlI (05-08)	DRIVER SIDE DOOR	2536 BlueTec 4/5 (05-08)	TMF
 Actros MPlI (05-08)	DRIVER SIDE DOOR	2541 BlueTec 4/5 (05-08)	TMF
 Actros MPlI (05-08)	DRIVER SIDE DOOR	2544 BlueTec 4/5 (05-08)	TMF
 Actros MPlI (05-08)	DRIVER SIDE DOOR	2546 BlueTec 4/5 (05-08)	TMF
 Actros MPlI (05-08)	DRIVER SIDE DOOR	2548 BlueTec 4/5 (05-08)	TMF
 Actros MPlI (05-08)	DRIVER SIDE DOOR	2551 BlueTec 4/5 (05-08)	TMF
 Actros MPlI (05-08)	DRIVER SIDE DOOR	2555 BlueTec 4/5 (05-08)	TMF
 Actros MPlI (05-08)	DRIVER SIDE DOOR	2560 BlueTec 4/5 (05-08)	TMF
 Actros MPlI (05-08)	ENGINE MANAGEME	1832 BlueTec 4/5 (05-08)	MR
 Actros MPlI (05-08)	ENGINE MANAGEME	1836 BlueTec 4/5 (05-08)	MR
 Actros MPlI (05-08)	ENGINE MANAGEME	1841 BlueTec 4/5 (05-08)	MR
 Actros MPlI (05-08)	ENGINE MANAGEME	1844 BlueTec 4/5 (05-08)	MR
 Actros MPlI (05-08)	ENGINE MANAGEME	1846 BlueTec 4/5 (05-08)	MR
 Actros MPlI (05-08)	ENGINE MANAGEME	1848 BlueTec 4/5 (05-08)	MR
 Actros MPlI (05-08)	ENGINE MANAGEME	1851 BlueTec 4/5 (05-08)	MR

## Systems supported by ECReader (up to V4,90)

### TRUCKS




























### Mercedes Trucks

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Actros MPlI (05-08)	ENGINE MANAGEME	1855 BlueTec 4/5 (05-08)	MR
 Actros MPlI (05-08)	ENGINE MANAGEME	1860 BlueTec 4/5 (05-08)	MR
 Actros MPlI (05-08)	ENGINE MANAGEME	2532 BlueTec 4/5 (05-08)	MR
 Actros MPlI (05-08)	ENGINE MANAGEME	2536 BlueTec 4/5 (05-08)	MR
 Actros MPlI (05-08)	ENGINE MANAGEME	2541 BlueTec 4/5 (05-08)	MR
 Actros MPlI (05-08)	ENGINE MANAGEME	2544 BlueTec 4/5 (05-08)	MR
 Actros MPlI (05-08)	ENGINE MANAGEME	2546 BlueTec 4/5 (05-08)	MR
 Actros MPlI (05-08)	ENGINE MANAGEME	2548 BlueTec 4/5 (05-08)	MR
 Actros MPlI (05-08)	ENGINE MANAGEME	2551 BlueTec 4/5 (05-08)	MR
 Actros MPlI (05-08)	ENGINE MANAGEME	2555 BlueTec 4/5 (05-08)	MR
 Actros MPlI (05-08)	ENGINE MANAGEME	2560 BlueTec 4/5 (05-08)	MR
 Actros MPlI (05-08)	MAINTENANCE SYST	1832 BlueTec 4/5 (05-08)	WS
 Actros MPlI (05-08)	MAINTENANCE SYST	1836 BlueTec 4/5 (05-08)	WS
 Actros MPlI (05-08)	MAINTENANCE SYST	1841 BlueTec 4/5 (05-08)	WS
 Actros MPlI (05-08)	MAINTENANCE SYST	1844 BlueTec 4/5 (05-08)	WS
 Actros MPlI (05-08)	MAINTENANCE SYST	1846 BlueTec 4/5 (05-08)	WS
 Actros MPlI (05-08)	MAINTENANCE SYST	1848 BlueTec 4/5 (05-08)	WS
 Actros MPlI (05-08)	MAINTENANCE SYST	1851 BlueTec 4/5 (05-08)	WS
 Actros MPlI (05-08)	MAINTENANCE SYST	1855 BlueTec 4/5 (05-08)	WS
 Actros MPlI (05-08)	MAINTENANCE SYST	1860 BlueTec 4/5 (05-08)	WS
 Actros MPlI (05-08)	MAINTENANCE SYST	2532 BlueTec 4/5 (05-08)	WS
 Actros MPlI (05-08)	MAINTENANCE SYST	2536 BlueTec 4/5 (05-08)	WS
 Actros MPlI (05-08)	MAINTENANCE SYST	2541 BlueTec 4/5 (05-08)	WS
 Actros MPlI (05-08)	MAINTENANCE SYST	2544 BlueTec 4/5 (05-08)	WS
 Actros MPlI (05-08)	MAINTENANCE SYST	2546 BlueTec 4/5 (05-08)	WS
 Actros MPlI (05-08)	MAINTENANCE SYST	2548 BlueTec 4/5 (05-08)	WS
 Actros MPlI (05-08)	MAINTENANCE SYST	2551 BlueTec 4/5 (05-08)	WS

## Systems supported by ECUREADER (up to V4,90)

### TRUCKS



























### Mercedes Trucks

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Actros MPlI (05-08)	MAINTENANCE SYST	2555 BlueTec 4/5 (05-08)	WS
 Actros MPlI (05-08)	MAINTENANCE SYST	2560 BlueTec 4/5 (05-08)	WS
 Actros MPlI (05-08)	PASS. SIDE DOOR	1832 BlueTec 4/5 (05-08)	TMB
 Actros MPlI (05-08)	PASS. SIDE DOOR	1836 BlueTec 4/5 (05-08)	TMB
 Actros MPlI (05-08)	PASS. SIDE DOOR	1841 BlueTec 4/5 (05-08)	TMB
 Actros MPlI (05-08)	PASS. SIDE DOOR	1844 BlueTec 4/5 (05-08)	TMB
 Actros MPlI (05-08)	PASS. SIDE DOOR	1846 BlueTec 4/5 (05-08)	TMB
 Actros MPlI (05-08)	PASS. SIDE DOOR	1848 BlueTec 4/5 (05-08)	TMB
 Actros MPlI (05-08)	PASS. SIDE DOOR	1851 BlueTec 4/5 (05-08)	TMB
 Actros MPlI (05-08)	PASS. SIDE DOOR	1855 BlueTec 4/5 (05-08)	TMB
 Actros MPlI (05-08)	PASS. SIDE DOOR	1860 BlueTec 4/5 (05-08)	TMB
 Actros MPlI (05-08)	PASS. SIDE DOOR	2532 BlueTec 4/5 (05-08)	TMB
 Actros MPlI (05-08)	PASS. SIDE DOOR	2536 BlueTec 4/5 (05-08)	TMB
 Actros MPlI (05-08)	PASS. SIDE DOOR	2541 BlueTec 4/5 (05-08)	TMB
 Actros MPlI (05-08)	PASS. SIDE DOOR	2544 BlueTec 4/5 (05-08)	TMB
 Actros MPlI (05-08)	PASS. SIDE DOOR	2546 BlueTec 4/5 (05-08)	TMB
 Actros MPlI (05-08)	PASS. SIDE DOOR	2548 BlueTec 4/5 (05-08)	TMB
 Actros MPlI (05-08)	PASS. SIDE DOOR	2551 BlueTec 4/5 (05-08)	TMB
 Actros MPlI (05-08)	PASS. SIDE DOOR	2555 BlueTec 4/5 (05-08)	TMB
 Actros MPlI (05-08)	PASS. SIDE DOOR	2560 BlueTec 4/5 (05-08)	TMB
 Actros MPlI (05-08)	SUSPENSION CONTR	1832 BlueTec 4/5 (05-08)	NR
 Actros MPlI (05-08)	SUSPENSION CONTR	1836 BlueTec 4/5 (05-08)	NR
 Actros MPlI (05-08)	SUSPENSION CONTR	1841 BlueTec 4/5 (05-08)	NR
 Actros MPlI (05-08)	SUSPENSION CONTR	1844 BlueTec 4/5 (05-08)	NR
 Actros MPlI (05-08)	SUSPENSION CONTR	1846 BlueTec 4/5 (05-08)	NR
 Actros MPlI (05-08)	SUSPENSION CONTR	1848 BlueTec 4/5 (05-08)	NR
 Actros MPlI (05-08)	SUSPENSION CONTR	1851 BlueTec 4/5 (05-08)	NR

## Systems supported by ECReader (up to V4,90)

### TRUCKS




























### Mercedes Trucks

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Actros MPII (05-08)	SUSPENSION CONTR	1855 BlueTec 4/5 (05-08)	NR
 Actros MPII (05-08)	SUSPENSION CONTR	1860 BlueTec 4/5 (05-08)	NR
 Actros MPII (05-08)	SUSPENSION CONTR	2532 BlueTec 4/5 (05-08)	NR
 Actros MPII (05-08)	SUSPENSION CONTR	2536 BlueTec 4/5 (05-08)	NR
 Actros MPII (05-08)	SUSPENSION CONTR	2541 BlueTec 4/5 (05-08)	NR
 Actros MPII (05-08)	SUSPENSION CONTR	2544 BlueTec 4/5 (05-08)	NR
 Actros MPII (05-08)	SUSPENSION CONTR	2546 BlueTec 4/5 (05-08)	NR
 Actros MPII (05-08)	SUSPENSION CONTR	2548 BlueTec 4/5 (05-08)	NR
 Actros MPII (05-08)	SUSPENSION CONTR	2551 BlueTec 4/5 (05-08)	NR
 Actros MPII (05-08)	SUSPENSION CONTR	2555 BlueTec 4/5 (05-08)	NR
 Actros MPII (05-08)	SUSPENSION CONTR	2560 BlueTec 4/5 (05-08)	NR
 Actros MPIII (08-..)	AUTOM. TRANSMISSI	1832 BlueTec 4/5 (08-..)	GS II
 Actros MPIII (08-..)	AUTOM. TRANSMISSI	1836 BlueTec 4/5 (08-..)	GS II
 Actros MPIII (08-..)	AUTOM. TRANSMISSI	1841 BlueTec 4/5 (08-..)	GS II
 Actros MPIII (08-..)	AUTOM. TRANSMISSI	1844 BlueTec 4/5 (08-..)	GS II
 Actros MPIII (08-..)	AUTOM. TRANSMISSI	1846 BlueTec 4/5 (08-..)	GS II
 Actros MPIII (08-..)	AUTOM. TRANSMISSI	1848 BlueTec 4/5 (08-..)	GS II
 Actros MPIII (08-..)	AUTOM. TRANSMISSI	1851 BlueTec 4/5 (08-..)	GS II
 Actros MPIII (08-..)	AUTOM. TRANSMISSI	1855 BlueTec 4/5 (08-..)	GS II
 Actros MPIII (08-..)	AUTOM. TRANSMISSI	1860 BlueTec 4/5 (08-..)	GS II
 Actros MPIII (08-..)	AUTOM. TRANSMISSI	2532 BlueTec 4/5 (08-..)	GS II
 Actros MPIII (08-..)	AUTOM. TRANSMISSI	2536 BlueTec 4/5 (08-..)	GS II
 Actros MPIII (08-..)	AUTOM. TRANSMISSI	2541 BlueTec 4/5 (08-..)	GS II
 Actros MPIII (08-..)	AUTOM. TRANSMISSI	2544 BlueTec 4/5 (08-..)	GS II
 Actros MPIII (08-..)	AUTOM. TRANSMISSI	2546 BlueTec 4/5 (08-..)	GS II
 Actros MPIII (08-..)	AUTOM. TRANSMISSI	2548 BlueTec 4/5 (08-..)	GS II

## Systems supported by ECReader (up to V4,90)

### TRUCKS




























### Mercedes Trucks

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Actros MPIII (08-..)	AUTOM. TRANSMISSI	2551 BlueTec 4/5 (08-..)	GS II
 Actros MPIII (08-..)	AUTOM. TRANSMISSI	2555 BlueTec 4/5 (08-..)	GS II
 Actros MPIII (08-..)	AUTOM. TRANSMISSI	2560 BlueTec 4/5 (08-..)	GS II
 Actros MPIII (08-..)	BRAKE SYS. MANAG	1832 BlueTec 4/5 (08-..)	BS
 Actros MPIII (08-..)	BRAKE SYS. MANAG	1836 BlueTec 4/5 (08-..)	BS
 Actros MPIII (08-..)	BRAKE SYS. MANAG	1841 BlueTec 4/5 (08-..)	BS
 Actros MPIII (08-..)	BRAKE SYS. MANAG	1844 BlueTec 4/5 (08-..)	BS
 Actros MPIII (08-..)	BRAKE SYS. MANAG	1846 BlueTec 4/5 (08-..)	BS
 Actros MPIII (08-..)	BRAKE SYS. MANAG	1848 BlueTec 4/5 (08-..)	BS
 Actros MPIII (08-..)	BRAKE SYS. MANAG	1851 BlueTec 4/5 (08-..)	BS
 Actros MPIII (08-..)	BRAKE SYS. MANAG	1855 BlueTec 4/5 (08-..)	BS
 Actros MPIII (08-..)	BRAKE SYS. MANAG	1860 BlueTec 4/5 (08-..)	BS
 Actros MPIII (08-..)	BRAKE SYS. MANAG	2532 BlueTec 4/5 (08-..)	BS
 Actros MPIII (08-..)	BRAKE SYS. MANAG	2536 BlueTec 4/5 (08-..)	BS
 Actros MPIII (08-..)	BRAKE SYS. MANAG	2541 BlueTec 4/5 (08-..)	BS
 Actros MPIII (08-..)	BRAKE SYS. MANAG	2544 BlueTec 4/5 (08-..)	BS
 Actros MPIII (08-..)	BRAKE SYS. MANAG	2546 BlueTec 4/5 (08-..)	BS
 Actros MPIII (08-..)	BRAKE SYS. MANAG	2548 BlueTec 4/5 (08-..)	BS
 Actros MPIII (08-..)	BRAKE SYS. MANAG	2551 BlueTec 4/5 (08-..)	BS
 Actros MPIII (08-..)	BRAKE SYS. MANAG	2555 BlueTec 4/5 (08-..)	BS
 Actros MPIII (08-..)	BRAKE SYS. MANAG	2560 BlueTec 4/5 (08-..)	BS
 Actros MPIII (08-..)	CHASSIS NETWORK	1832 BlueTec 4/5 (08-..)	FM Front Module
 Actros MPIII (08-..)	CHASSIS NETWORK	1832 BlueTec 4/5 (08-..)	HM Rear Module
 Actros MPIII (08-..)	CHASSIS NETWORK	1832 BlueTec 4/5 (08-..)	MSF Modular Panel
 Actros MPIII (08-..)	CHASSIS NETWORK	1836 BlueTec 4/5 (08-..)	FM Front Module
 Actros MPIII (08-..)	CHASSIS NETWORK	1836 BlueTec 4/5 (08-..)	HM Rear Module
 Actros MPIII (08-..)	CHASSIS NETWORK	1836 BlueTec 4/5 (08-..)	MSF Modular Panel

## Systems supported by ECReader (up to V4,90)

### TRUCKS




























### Mercedes Trucks

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Actros MPIII (08-..)	CHASSIS NETWORK	1841 BlueTec 4/5 (08-..)	FM Front Module
 Actros MPIII (08-..)	CHASSIS NETWORK	1841 BlueTec 4/5 (08-..)	HM Rear Module
 Actros MPIII (08-..)	CHASSIS NETWORK	1841 BlueTec 4/5 (08-..)	MSF Modular Panel
 Actros MPIII (08-..)	CHASSIS NETWORK	1844 BlueTec 4/5 (08-..)	FM Front Module
 Actros MPIII (08-..)	CHASSIS NETWORK	1844 BlueTec 4/5 (08-..)	HM Rear Module
 Actros MPIII (08-..)	CHASSIS NETWORK	1844 BlueTec 4/5 (08-..)	MSF Modular Panel
 Actros MPIII (08-..)	CHASSIS NETWORK	1846 BlueTec 4/5 (08-..)	FM Front Module
 Actros MPIII (08-..)	CHASSIS NETWORK	1846 BlueTec 4/5 (08-..)	HM Rear Module
 Actros MPIII (08-..)	CHASSIS NETWORK	1846 BlueTec 4/5 (08-..)	MSF Modular Panel
 Actros MPIII (08-..)	CHASSIS NETWORK	1848 BlueTec 4/5 (08-..)	FM Front Module
 Actros MPIII (08-..)	CHASSIS NETWORK	1848 BlueTec 4/5 (08-..)	HM Rear Module
 Actros MPIII (08-..)	CHASSIS NETWORK	1848 BlueTec 4/5 (08-..)	MSF Modular Panel
 Actros MPIII (08-..)	CHASSIS NETWORK	1851 BlueTec 4/5 (08-..)	FM Front Module
 Actros MPIII (08-..)	CHASSIS NETWORK	1851 BlueTec 4/5 (08-..)	HM Rear Module
 Actros MPIII (08-..)	CHASSIS NETWORK	1851 BlueTec 4/5 (08-..)	MSF Modular Panel
 Actros MPIII (08-..)	CHASSIS NETWORK	1855 BlueTec 4/5 (08-..)	FM Front Module
 Actros MPIII (08-..)	CHASSIS NETWORK	1855 BlueTec 4/5 (08-..)	HM Rear Module
 Actros MPIII (08-..)	CHASSIS NETWORK	1855 BlueTec 4/5 (08-..)	MSF Modular Panel
 Actros MPIII (08-..)	CHASSIS NETWORK	1860 BlueTec 4/5 (08-..)	FM Front Module
 Actros MPIII (08-..)	CHASSIS NETWORK	1860 BlueTec 4/5 (08-..)	HM Rear Module
 Actros MPIII (08-..)	CHASSIS NETWORK	1860 BlueTec 4/5 (08-..)	MSF Modular Panel
 Actros MPIII (08-..)	CHASSIS NETWORK	2532 BlueTec 4/5 (08-..)	FM Front Module
 Actros MPIII (08-..)	CHASSIS NETWORK	2532 BlueTec 4/5 (08-..)	HM Rear Module
 Actros MPIII (08-..)	CHASSIS NETWORK	2532 BlueTec 4/5 (08-..)	MSF Modular Panel
 Actros MPIII (08-..)	CHASSIS NETWORK	2536 BlueTec 4/5 (08-..)	FM Front Module
 Actros MPIII (08-..)	CHASSIS NETWORK	2536 BlueTec 4/5 (08-..)	HM Rear Module
 Actros MPIII (08-..)	CHASSIS NETWORK	2536 BlueTec 4/5 (08-..)	MSF Modular Panel

## Systems supported by ECReader (up to V4,90)

### TRUCKS




























### Mercedes Trucks

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Actros MPIII (08-..)	CHASSIS NETWORK	2541 BlueTec 4/5 (08-..)	FM Front Module
 Actros MPIII (08-..)	CHASSIS NETWORK	2541 BlueTec 4/5 (08-..)	HM Rear Module
 Actros MPIII (08-..)	CHASSIS NETWORK	2541 BlueTec 4/5 (08-..)	MSF Modular Panel
 Actros MPIII (08-..)	CHASSIS NETWORK	2544 BlueTec 4/5 (08-..)	FM Front Module
 Actros MPIII (08-..)	CHASSIS NETWORK	2544 BlueTec 4/5 (08-..)	HM Rear Module
 Actros MPIII (08-..)	CHASSIS NETWORK	2544 BlueTec 4/5 (08-..)	MSF Modular Panel
 Actros MPIII (08-..)	CHASSIS NETWORK	2546 BlueTec 4/5 (08-..)	FM Front Module
 Actros MPIII (08-..)	CHASSIS NETWORK	2546 BlueTec 4/5 (08-..)	HM Rear Module
 Actros MPIII (08-..)	CHASSIS NETWORK	2546 BlueTec 4/5 (08-..)	MSF Modular Panel
 Actros MPIII (08-..)	CHASSIS NETWORK	2548 BlueTec 4/5 (08-..)	FM Front Module
 Actros MPIII (08-..)	CHASSIS NETWORK	2548 BlueTec 4/5 (08-..)	HM Rear Module
 Actros MPIII (08-..)	CHASSIS NETWORK	2548 BlueTec 4/5 (08-..)	MSF Modular Panel
 Actros MPIII (08-..)	CHASSIS NETWORK	2551 BlueTec 4/5 (08-..)	FM Front Module
 Actros MPIII (08-..)	CHASSIS NETWORK	2551 BlueTec 4/5 (08-..)	HM Rear Module
 Actros MPIII (08-..)	CHASSIS NETWORK	2551 BlueTec 4/5 (08-..)	MSF Modular Panel
 Actros MPIII (08-..)	CHASSIS NETWORK	2555 BlueTec 4/5 (08-..)	FM Front Module
 Actros MPIII (08-..)	CHASSIS NETWORK	2555 BlueTec 4/5 (08-..)	HM Rear Module
 Actros MPIII (08-..)	CHASSIS NETWORK	2555 BlueTec 4/5 (08-..)	MSF Modular Panel
 Actros MPIII (08-..)	CHASSIS NETWORK	2560 BlueTec 4/5 (08-..)	FM Front Module
 Actros MPIII (08-..)	CHASSIS NETWORK	2560 BlueTec 4/5 (08-..)	HM Rear Module
 Actros MPIII (08-..)	CHASSIS NETWORK	2560 BlueTec 4/5 (08-..)	MSF Modular Panel
 Actros MPIII (08-..)	DASHBOARD	1832 BlueTec 4/5 (08-..)	INS Kombi instrument
 Actros MPIII (08-..)	DASHBOARD	1836 BlueTec 4/5 (08-..)	INS Kombi instrument
 Actros MPIII (08-..)	DASHBOARD	1841 BlueTec 4/5 (08-..)	INS Kombi instrument
 Actros MPIII (08-..)	DASHBOARD	1844 BlueTec 4/5 (08-..)	INS Kombi instrument
 Actros MPIII (08-..)	DASHBOARD	1846 BlueTec 4/5 (08-..)	INS Kombi instrument
 Actros MPIII (08-..)	DASHBOARD	1848 BlueTec 4/5 (08-..)	INS Kombi instrument

## Systems supported by ECReader (up to V4,90)

### TRUCKS




























### Mercedes Trucks

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Actros MPIII (08-..)	DASHBOARD	1851 BlueTec 4/5 (08-..)	INS Kombi instrument
 Actros MPIII (08-..)	DASHBOARD	1855 BlueTec 4/5 (08-..)	INS Kombi instrument
 Actros MPIII (08-..)	DASHBOARD	1860 BlueTec 4/5 (08-..)	INS Kombi instrument
 Actros MPIII (08-..)	DASHBOARD	2532 BlueTec 4/5 (08-..)	INS Kombi instrument
 Actros MPIII (08-..)	DASHBOARD	2536 BlueTec 4/5 (08-..)	INS Kombi instrument
 Actros MPIII (08-..)	DASHBOARD	2541 BlueTec 4/5 (08-..)	INS Kombi instrument
 Actros MPIII (08-..)	DASHBOARD	2544 BlueTec 4/5 (08-..)	INS Kombi instrument
 Actros MPIII (08-..)	DASHBOARD	2546 BlueTec 4/5 (08-..)	INS Kombi instrument
 Actros MPIII (08-..)	DASHBOARD	2548 BlueTec 4/5 (08-..)	INS Kombi instrument
 Actros MPIII (08-..)	DASHBOARD	2551 BlueTec 4/5 (08-..)	INS Kombi instrument
 Actros MPIII (08-..)	DASHBOARD	2555 BlueTec 4/5 (08-..)	INS Kombi instrument
 Actros MPIII (08-..)	DASHBOARD	2560 BlueTec 4/5 (08-..)	INS Kombi instrument
 Actros MPIII (08-..)	DRIVER SIDE DOOR	1832 BlueTec 4/5 (08-..)	TMF
 Actros MPIII (08-..)	DRIVER SIDE DOOR	1836 BlueTec 4/5 (08-..)	TMF
 Actros MPIII (08-..)	DRIVER SIDE DOOR	1841 BlueTec 4/5 (08-..)	TMF
 Actros MPIII (08-..)	DRIVER SIDE DOOR	1844 BlueTec 4/5 (08-..)	TMF
 Actros MPIII (08-..)	DRIVER SIDE DOOR	1846 BlueTec 4/5 (08-..)	TMF
 Actros MPIII (08-..)	DRIVER SIDE DOOR	1848 BlueTec 4/5 (08-..)	TMF
 Actros MPIII (08-..)	DRIVER SIDE DOOR	1851 BlueTec 4/5 (08-..)	TMF
 Actros MPIII (08-..)	DRIVER SIDE DOOR	1855 BlueTec 4/5 (08-..)	TMF
 Actros MPIII (08-..)	DRIVER SIDE DOOR	1860 BlueTec 4/5 (08-..)	TMF
 Actros MPIII (08-..)	DRIVER SIDE DOOR	2532 BlueTec 4/5 (08-..)	TMF
 Actros MPIII (08-..)	DRIVER SIDE DOOR	2536 BlueTec 4/5 (08-..)	TMF
 Actros MPIII (08-..)	DRIVER SIDE DOOR	2541 BlueTec 4/5 (08-..)	TMF
 Actros MPIII (08-..)	DRIVER SIDE DOOR	2544 BlueTec 4/5 (08-..)	TMF
 Actros MPIII (08-..)	DRIVER SIDE DOOR	2546 BlueTec 4/5 (08-..)	TMF
 Actros MPIII (08-..)	DRIVER SIDE DOOR	2548 BlueTec 4/5 (08-..)	TMF

## Systems supported by ECReader (up to V4,90)

### TRUCKS




























### Mercedes Trucks

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Actros MP111 (08-..)	DRIVER SIDE DOOR	2551 BlueTec 4/5 (08-..)	TMF
 Actros MP111 (08-..)	DRIVER SIDE DOOR	2555 BlueTec 4/5 (08-..)	TMF
 Actros MP111 (08-..)	DRIVER SIDE DOOR	2560 BlueTec 4/5 (08-..)	TMF
 Actros MP111 (08-..)	ENGINE MANAGEME	1832 BlueTec 4/5 (08-..)	MR
 Actros MP111 (08-..)	ENGINE MANAGEME	1836 BlueTec 4/5 (08-..)	MR
 Actros MP111 (08-..)	ENGINE MANAGEME	1841 BlueTec 4/5 (08-..)	MR
 Actros MP111 (08-..)	ENGINE MANAGEME	1844 BlueTec 4/5 (08-..)	MR
 Actros MP111 (08-..)	ENGINE MANAGEME	1846 BlueTec 4/5 (08-..)	MR
 Actros MP111 (08-..)	ENGINE MANAGEME	1848 BlueTec 4/5 (08-..)	MR
 Actros MP111 (08-..)	ENGINE MANAGEME	1851 BlueTec 4/5 (08-..)	MR
 Actros MP111 (08-..)	ENGINE MANAGEME	1855 BlueTec 4/5 (08-..)	MR
 Actros MP111 (08-..)	ENGINE MANAGEME	1860 BlueTec 4/5 (08-..)	MR
 Actros MP111 (08-..)	ENGINE MANAGEME	2532 BlueTec 4/5 (08-..)	MR
 Actros MP111 (08-..)	ENGINE MANAGEME	2536 BlueTec 4/5 (08-..)	MR
 Actros MP111 (08-..)	ENGINE MANAGEME	2541 BlueTec 4/5 (08-..)	MR
 Actros MP111 (08-..)	ENGINE MANAGEME	2544 BlueTec 4/5 (08-..)	MR
 Actros MP111 (08-..)	ENGINE MANAGEME	2546 BlueTec 4/5 (08-..)	MR
 Actros MP111 (08-..)	ENGINE MANAGEME	2548 BlueTec 4/5 (08-..)	MR
 Actros MP111 (08-..)	ENGINE MANAGEME	2551 BlueTec 4/5 (08-..)	MR
 Actros MP111 (08-..)	ENGINE MANAGEME	2555 BlueTec 4/5 (08-..)	MR
 Actros MP111 (08-..)	ENGINE MANAGEME	2560 BlueTec 4/5 (08-..)	MR
 Actros MP111 (08-..)	PASS. SIDE DOOR	1832 BlueTec 4/5 (08-..)	TMB
 Actros MP111 (08-..)	PASS. SIDE DOOR	1836 BlueTec 4/5 (08-..)	TMB
 Actros MP111 (08-..)	PASS. SIDE DOOR	1841 BlueTec 4/5 (08-..)	TMB
 Actros MP111 (08-..)	PASS. SIDE DOOR	1844 BlueTec 4/5 (08-..)	TMB
 Actros MP111 (08-..)	PASS. SIDE DOOR	1846 BlueTec 4/5 (08-..)	TMB
 Actros MP111 (08-..)	PASS. SIDE DOOR	1848 BlueTec 4/5 (08-..)	TMB

## Systems supported by ECReader (up to V4,90)

### TRUCKS



























### Mercedes Trucks

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Actros MPIII (08-..)	PASS. SIDE DOOR	1851 BlueTec 4/5 (08-..)	TMB
 Actros MPIII (08-..)	PASS. SIDE DOOR	1855 BlueTec 4/5 (08-..)	TMB
 Actros MPIII (08-..)	PASS. SIDE DOOR	1860 BlueTec 4/5 (08-..)	TMB
 Actros MPIII (08-..)	PASS. SIDE DOOR	2532 BlueTec 4/5 (08-..)	TMB
 Actros MPIII (08-..)	PASS. SIDE DOOR	2536 BlueTec 4/5 (08-..)	TMB
 Actros MPIII (08-..)	PASS. SIDE DOOR	2541 BlueTec 4/5 (08-..)	TMB
 Actros MPIII (08-..)	PASS. SIDE DOOR	2544 BlueTec 4/5 (08-..)	TMB
 Actros MPIII (08-..)	PASS. SIDE DOOR	2546 BlueTec 4/5 (08-..)	TMB
 Actros MPIII (08-..)	PASS. SIDE DOOR	2548 BlueTec 4/5 (08-..)	TMB
 Actros MPIII (08-..)	PASS. SIDE DOOR	2551 BlueTec 4/5 (08-..)	TMB
 Actros MPIII (08-..)	PASS. SIDE DOOR	2555 BlueTec 4/5 (08-..)	TMB
 Actros MPIII (08-..)	PASS. SIDE DOOR	2560 BlueTec 4/5 (08-..)	TMB
 Actros MPIII (08-..)	SUSPENSION CONTR	1832 BlueTec 4/5 (08-..)	NR
 Actros MPIII (08-..)	SUSPENSION CONTR	1836 BlueTec 4/5 (08-..)	NR
 Actros MPIII (08-..)	SUSPENSION CONTR	1841 BlueTec 4/5 (08-..)	NR
 Actros MPIII (08-..)	SUSPENSION CONTR	1844 BlueTec 4/5 (08-..)	NR
 Actros MPIII (08-..)	SUSPENSION CONTR	1846 BlueTec 4/5 (08-..)	NR
 Actros MPIII (08-..)	SUSPENSION CONTR	1848 BlueTec 4/5 (08-..)	NR
 Actros MPIII (08-..)	SUSPENSION CONTR	1851 BlueTec 4/5 (08-..)	NR
 Actros MPIII (08-..)	SUSPENSION CONTR	1855 BlueTec 4/5 (08-..)	NR
 Actros MPIII (08-..)	SUSPENSION CONTR	1860 BlueTec 4/5 (08-..)	NR
 Actros MPIII (08-..)	SUSPENSION CONTR	2532 BlueTec 4/5 (08-..)	NR
 Actros MPIII (08-..)	SUSPENSION CONTR	2536 BlueTec 4/5 (08-..)	NR
 Actros MPIII (08-..)	SUSPENSION CONTR	2541 BlueTec 4/5 (08-..)	NR
 Actros MPIII (08-..)	SUSPENSION CONTR	2544 BlueTec 4/5 (08-..)	NR
 Actros MPIII (08-..)	SUSPENSION CONTR	2546 BlueTec 4/5 (08-..)	NR
 Actros MPIII (08-..)	SUSPENSION CONTR	2548 BlueTec 4/5 (08-..)	NR

## Systems supported by ECReader (up to V4,90)

### TRUCKS




























### Mercedes Trucks

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Actros MPIII (08-..)	SUSPENSION CONTR	2551 BlueTec 4/5 (08-..)	NR
 Actros MPIII (08-..)	SUSPENSION CONTR	2555 BlueTec 4/5 (08-..)	NR
 Actros MPIII (08-..)	SUSPENSION CONTR	2560 BlueTec 4/5 (08-..)	NR
 Atego	ABS	1017 (98-02)	MB ABS
 Atego	ABS	1018 (98-02)	MB ABS
 Atego	ABS	1018 (99-00)	MB ABS
 Atego	ABS	1018 AK (98-02)	MB ABS
 Atego	ABS	1018 AK (99-00)	MB ABS
 Atego	ABS	1018 Bluetec4 (05-07)	MB
 Atego	ABS	1018 Bluetec5 (06-08)	MB
 Atego	ABS	1018 L (98-02)	MB ABS
 Atego	ABS	1018 L (99-00)	MB ABS
 Atego	ABS	1022 Bluetec4 (05-07)	MB
 Atego	ABS	1022 Bluetec5 (06-08)	MB
 Atego	ABS	1024 Bluetec4 (05-07)	MB
 Atego	ABS	1024 Bluetec5 (06-08)	MB
 Atego	ABS	1217 (98-02)	MB ABS
 Atego	ABS	1218 (98-02)	MB ABS
 Atego	ABS	1218 (99-00)	MB ABS
 Atego	ABS	1218 Bluetec4 (05-07)	MB
 Atego	ABS	1218 Bluetec5 (06-08)	MB
 Atego	ABS	1218 K (98-02)	MB ABS
 Atego	ABS	1218 K (99-00)	MB ABS
 Atego	ABS	1218 L (98-02)	MB ABS
 Atego	ABS	1218 L (99-00)	MB ABS
 Atego	ABS	1222 Bluetec4 (05-07)	MB

## Systems supported by ECUreader (up to V4,90)

### TRUCKS




























### Mercedes Trucks

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Atego	ABS	1222 Bluetec5 (06-08)	MB
 Atego	ABS	1223 (98-02)	MB ABS
 Atego	ABS	1223 (99-00)	MB ABS
 Atego	ABS	1223 L (98-02)	MB ABS
 Atego	ABS	1223 L (99-00)	MB ABS
 Atego	ABS	1224 Bluetec4 (05-07)	MB
 Atego	ABS	1224 Bluetec5 (06-08)	MB
 Atego	ABS	1228 (98-02)	MB ABS
 Atego	ABS	1228 (99-00)	MB ABS
 Atego	ABS	1228 L (98-02)	MB ABS
 Atego	ABS	1228 L (99-00)	MB ABS
 Atego	ABS	1229 Bluetec4 (05-07)	MB
 Atego	ABS	1229 Bluetec5 (06-08)	MB
 Atego	ABS	1324 Bluetec4 (05-07)	MB
 Atego	ABS	1324 Bluetec5 (06-08)	MB
 Atego	ABS	1329 Bluetec4 (05-07)	MB
 Atego	ABS	1329 Bluetec5 (06-08)	MB
 Atego	ABS	1517 (98-02)	MB ABS
 Atego	ABS	1518 (98-02)	MB ABS
 Atego	ABS	1518 (99-00)	MB ABS
 Atego	ABS	1518 K (98-02)	MB ABS
 Atego	ABS	1518 K (99-00)	MB ABS
 Atego	ABS	1518 L (98-02)	MB ABS
 Atego	ABS	1518 L (99-00)	MB ABS
 Atego	ABS	1523 (98-02)	MB ABS
 Atego	ABS	1523 (99-00)	MB ABS
 Atego	ABS	1524 Bluetec4 (05-07)	MB

## Systems supported by ECUreader (up to V4,90)

### TRUCKS




























### Mercedes Trucks

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Atego	ABS	1524 Bluetec5 (06-08)	MB
 Atego	ABS	1529 Bluetec4 (05-07)	MB
 Atego	ABS	1529 Bluetec5 (06-08)	MB
 Atego	ABS	1823 (98-02)	MB ABS
 Atego	ABS	1828 (98-02)	MB ABS
 Atego	ABS	2528 (98-02)	MB ABS
 Atego	ABS	2528 (99-00)	MB ABS
 Atego	ABS	715 (98-02)	MB ABS
 Atego	ABS	715 (99-00)	MB ABS
 Atego	ABS	715 L (98-02)	MB ABS
 Atego	ABS	715 L (99-00)	MB ABS
 Atego	ABS	716 Bluetec4 (05-07)	MB
 Atego	ABS	716 Bluetec5 (06-08)	MB
 Atego	ABS	815 (98-02)	MB ABS
 Atego	ABS	815 (99-00)	MB ABS
 Atego	ABS	815 Eco (98-02)	MB ABS
 Atego	ABS	815 Eco (99-00)	MB ABS
 Atego	ABS	815 L (98-02)	MB ABS
 Atego	ABS	815 L (99-00)	MB ABS
 Atego	ABS	816 Bluetec4 (05-07)	MB
 Atego	ABS	816 Bluetec5 (06-08)	MB
 Atego	ABS	818 (98-02)	MB ABS
 Atego	ABS	818 (99-00)	MB ABS
 Atego	ABS	818 Bluetec4 (05-07)	MB
 Atego	ABS	818 Bluetec5 (06-08)	MB
 Atego	ABS	818 K (98-02)	MB ABS
 Atego	ABS	818 K (99-00)	MB ABS

## Systems supported by ECUREADER (up to V4,90)

### TRUCKS




























### Mercedes Trucks

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Atego	ABS	818 L (98-02)	MB ABS
 Atego	ABS	818 L (99-00)	MB ABS
 Atego	ABS	822 Bluetec4 (05-07)	MB
 Atego	ABS	822 Bluetec5 (06-08)	MB
 Atego	AUTOM. TRANSMISSI	1018 Bluetec4 (05-07)	MB GS AGS
 Atego	AUTOM. TRANSMISSI	1022 Bluetec4 (05-07)	MB GS AGS
 Atego	AUTOM. TRANSMISSI	1024 Bluetec4 (05-07)	MB GS AGS
 Atego	AUTOM. TRANSMISSI	1218 Bluetec4 (05-07)	MB GS AGS
 Atego	AUTOM. TRANSMISSI	1222 Bluetec4 (05-07)	MB GS AGS
 Atego	AUTOM. TRANSMISSI	1224 Bluetec4 (05-07)	MB GS AGS
 Atego	AUTOM. TRANSMISSI	1229 Bluetec4 (05-07)	MB GS AGS
 Atego	AUTOM. TRANSMISSI	1324 Bluetec4 (05-07)	MB GS AGS
 Atego	AUTOM. TRANSMISSI	1329 Bluetec4 (05-07)	MB GS AGS
 Atego	AUTOM. TRANSMISSI	1524 Bluetec4 (05-07)	MB GS AGS
 Atego	AUTOM. TRANSMISSI	1529 Bluetec4 (05-07)	MB GS AGS
 Atego	AUTOM. TRANSMISSI	716 Bluetec4 (05-07)	MB GS AGS
 Atego	AUTOM. TRANSMISSI	816 Bluetec4 (05-07)	MB GS AGS
 Atego	AUTOM. TRANSMISSI	818 Bluetec4 (05-07)	MB GS AGS
 Atego	AUTOM. TRANSMISSI	822 Bluetec4 (05-07)	MB GS AGS
 Atego	BRAKE POWER SUP	1018 Bluetec5 (06-08)	MB Intarder FR
 Atego	BRAKE POWER SUP	1022 Bluetec5 (06-08)	MB Intarder FR
 Atego	BRAKE POWER SUP	1024 Bluetec5 (06-08)	MB Intarder FR
 Atego	BRAKE POWER SUP	1218 Bluetec5 (06-08)	MB Intarder FR
 Atego	BRAKE POWER SUP	1222 Bluetec5 (06-08)	MB Intarder FR
 Atego	BRAKE POWER SUP	1224 Bluetec5 (06-08)	MB Intarder FR
 Atego	BRAKE POWER SUP	1229 Bluetec5 (06-08)	MB Intarder FR
 Atego	BRAKE POWER SUP	1324 Bluetec5 (06-08)	MB Intarder FR

## Systems supported by ECReader (up to V4,90)

### TRUCKS




























### Mercedes Trucks

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Atego	BRAKE POWER SUP	1329 Bluetec5 (06-08)	MB Intarder FR
 Atego	BRAKE POWER SUP	1524 Bluetec5 (06-08)	MB Intarder FR
 Atego	BRAKE POWER SUP	1529 Bluetec5 (06-08)	MB Intarder FR
 Atego	BRAKE POWER SUP	716 Bluetec5 (06-08)	MB Intarder FR
 Atego	BRAKE POWER SUP	816 Bluetec5 (06-08)	MB Intarder FR
 Atego	BRAKE POWER SUP	818 Bluetec5 (06-08)	MB Intarder FR
 Atego	BRAKE POWER SUP	822 Bluetec5 (06-08)	MB Intarder FR
 Atego	BRAKE SYS. MANAG	1018 (98-02)	MB BS EPB
 Atego	BRAKE SYS. MANAG	1018 AK (98-02)	MB BS EPB
 Atego	BRAKE SYS. MANAG	1018 L (98-02)	MB BS EPB
 Atego	BRAKE SYS. MANAG	1218 (98-02)	MB BS EPB
 Atego	BRAKE SYS. MANAG	1218 K (98-02)	MB BS EPB
 Atego	BRAKE SYS. MANAG	1218 L (98-02)	MB BS EPB
 Atego	BRAKE SYS. MANAG	1223 (98-02)	MB BS EPB
 Atego	BRAKE SYS. MANAG	1223 L (98-02)	MB BS EPB
 Atego	BRAKE SYS. MANAG	1228 (98-02)	MB BS EPB
 Atego	BRAKE SYS. MANAG	1228 L (98-02)	MB BS EPB
 Atego	BRAKE SYS. MANAG	1518 (98-02)	MB BS EPB
 Atego	BRAKE SYS. MANAG	1518 K (98-02)	MB BS EPB
 Atego	BRAKE SYS. MANAG	1518 L (98-02)	MB BS EPB
 Atego	BRAKE SYS. MANAG	1523 (98-02)	MB BS EPB
 Atego	BRAKE SYS. MANAG	2528 (00-00)	MB BS EPB
 Atego	BRAKE SYS. MANAG	2528 (98-02)	MB BS EPB
 Atego	CENTRAL LOCKING	1018 Bluetec4 (05-07)	MB FFB
 Atego	CENTRAL LOCKING	1018 Bluetec4 (05-07)	MB ZV
 Atego	CENTRAL LOCKING	1018 Bluetec5 (06-08)	MB FFB
 Atego	CENTRAL LOCKING	1018 Bluetec5 (06-08)	MB ZV

## Systems supported by ECReader (up to V4,90)

### TRUCKS




























### Mercedes Trucks

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Atego	CENTRAL LOCKING	1022 Bluetec4 (05-07)	MB FFB
 Atego	CENTRAL LOCKING	1022 Bluetec4 (05-07)	MB ZV
 Atego	CENTRAL LOCKING	1022 Bluetec5 (06-08)	MB FFB
 Atego	CENTRAL LOCKING	1022 Bluetec5 (06-08)	MB ZV
 Atego	CENTRAL LOCKING	1024 Bluetec4 (05-07)	MB FFB
 Atego	CENTRAL LOCKING	1024 Bluetec4 (05-07)	MB ZV
 Atego	CENTRAL LOCKING	1024 Bluetec5 (06-08)	MB FFB
 Atego	CENTRAL LOCKING	1024 Bluetec5 (06-08)	MB ZV
 Atego	CENTRAL LOCKING	1218 Bluetec4 (05-07)	MB FFB
 Atego	CENTRAL LOCKING	1218 Bluetec4 (05-07)	MB ZV
 Atego	CENTRAL LOCKING	1218 Bluetec5 (06-08)	MB FFB
 Atego	CENTRAL LOCKING	1218 Bluetec5 (06-08)	MB ZV
 Atego	CENTRAL LOCKING	1222 Bluetec4 (05-07)	MB FFB
 Atego	CENTRAL LOCKING	1222 Bluetec4 (05-07)	MB ZV
 Atego	CENTRAL LOCKING	1222 Bluetec5 (06-08)	MB FFB
 Atego	CENTRAL LOCKING	1222 Bluetec5 (06-08)	MB ZV
 Atego	CENTRAL LOCKING	1224 Bluetec4 (05-07)	MB FFB
 Atego	CENTRAL LOCKING	1224 Bluetec4 (05-07)	MB ZV
 Atego	CENTRAL LOCKING	1224 Bluetec5 (06-08)	MB FFB
 Atego	CENTRAL LOCKING	1224 Bluetec5 (06-08)	MB ZV
 Atego	CENTRAL LOCKING	1229 Bluetec4 (05-07)	MB FFB
 Atego	CENTRAL LOCKING	1229 Bluetec4 (05-07)	MB ZV
 Atego	CENTRAL LOCKING	1229 Bluetec5 (06-08)	MB FFB
 Atego	CENTRAL LOCKING	1229 Bluetec5 (06-08)	MB ZV
 Atego	CENTRAL LOCKING	1324 Bluetec4 (05-07)	MB FFB
 Atego	CENTRAL LOCKING	1324 Bluetec4 (05-07)	MB ZV
 Atego	CENTRAL LOCKING	1324 Bluetec5 (06-08)	MB FFB

## Systems supported by ECReader (up to V4,90)

### TRUCKS




























### Mercedes Trucks

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Atego	CENTRAL LOCKING	1324 Bluetec5 (06-08)	MB ZV
 Atego	CENTRAL LOCKING	1329 Bluetec4 (05-07)	MB FFB
 Atego	CENTRAL LOCKING	1329 Bluetec4 (05-07)	MB ZV
 Atego	CENTRAL LOCKING	1329 Bluetec5 (06-08)	MB FFB
 Atego	CENTRAL LOCKING	1329 Bluetec5 (06-08)	MB ZV
 Atego	CENTRAL LOCKING	1524 Bluetec4 (05-07)	MB FFB
 Atego	CENTRAL LOCKING	1524 Bluetec4 (05-07)	MB ZV
 Atego	CENTRAL LOCKING	1524 Bluetec5 (06-08)	MB FFB
 Atego	CENTRAL LOCKING	1524 Bluetec5 (06-08)	MB ZV
 Atego	CENTRAL LOCKING	1529 Bluetec4 (05-07)	MB FFB
 Atego	CENTRAL LOCKING	1529 Bluetec4 (05-07)	MB ZV
 Atego	CENTRAL LOCKING	1529 Bluetec5 (06-08)	MB FFB
 Atego	CENTRAL LOCKING	1529 Bluetec5 (06-08)	MB ZV
 Atego	CENTRAL LOCKING	716 Bluetec4 (05-07)	MB FFB
 Atego	CENTRAL LOCKING	716 Bluetec4 (05-07)	MB ZV
 Atego	CENTRAL LOCKING	716 Bluetec5 (06-08)	MB FFB
 Atego	CENTRAL LOCKING	716 Bluetec5 (06-08)	MB ZV
 Atego	CENTRAL LOCKING	816 Bluetec4 (05-07)	MB FFB
 Atego	CENTRAL LOCKING	816 Bluetec4 (05-07)	MB ZV
 Atego	CENTRAL LOCKING	816 Bluetec5 (06-08)	MB FFB
 Atego	CENTRAL LOCKING	816 Bluetec5 (06-08)	MB ZV
 Atego	CENTRAL LOCKING	818 Bluetec4 (05-07)	MB FFB
 Atego	CENTRAL LOCKING	818 Bluetec4 (05-07)	MB ZV
 Atego	CENTRAL LOCKING	818 Bluetec5 (06-08)	MB FFB
 Atego	CENTRAL LOCKING	818 Bluetec5 (06-08)	MB ZV
 Atego	CENTRAL LOCKING	822 Bluetec4 (05-07)	MB FFB
 Atego	CENTRAL LOCKING	822 Bluetec4 (05-07)	MB ZV

## Systems supported by ECReader (up to V4,90)

### TRUCKS




























### Mercedes Trucks

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Atego	CENTRAL LOCKING	822 Bluetec5 (06-08)	MB FFB
 Atego	CENTRAL LOCKING	822 Bluetec5 (06-08)	MB ZV
 Atego	CHRONOTACHOGRA	1017 (98-02)	TCO
 Atego	CHRONOTACHOGRA	1018 (98-02)	TCO
 Atego	CHRONOTACHOGRA	1018 Bluetec4 (05-07)	MB DTCO
 Atego	CHRONOTACHOGRA	1018 Bluetec5 (06-08)	Stoneridge Electronics DTCO
 Atego	CHRONOTACHOGRA	1018 K (98-02)	TCO
 Atego	CHRONOTACHOGRA	1018 L (98-02)	TCO
 Atego	CHRONOTACHOGRA	1022 Bluetec4 (05-07)	MB DTCO
 Atego	CHRONOTACHOGRA	1022 Bluetec5 (06-08)	Stoneridge Electronics DTCO
 Atego	CHRONOTACHOGRA	1024 Bluetec4 (05-07)	MB DTCO
 Atego	CHRONOTACHOGRA	1024 Bluetec5 (06-08)	Stoneridge Electronics DTCO
 Atego	CHRONOTACHOGRA	1217 (98-02)	TCO
 Atego	CHRONOTACHOGRA	1218 (98-02)	TCO
 Atego	CHRONOTACHOGRA	1218 Bluetec4 (05-07)	MB DTCO
 Atego	CHRONOTACHOGRA	1218 Bluetec5 (06-08)	Stoneridge Electronics DTCO
 Atego	CHRONOTACHOGRA	1218 K (98-02)	TCO
 Atego	CHRONOTACHOGRA	1218 L (98-02)	TCO
 Atego	CHRONOTACHOGRA	1222 Bluetec4 (05-07)	MB DTCO
 Atego	CHRONOTACHOGRA	1222 Bluetec5 (06-08)	Stoneridge Electronics DTCO
 Atego	CHRONOTACHOGRA	1223 (98-02)	TCO
 Atego	CHRONOTACHOGRA	1223 K (98-02)	TCO
 Atego	CHRONOTACHOGRA	1223 L (98-02)	TCO
 Atego	CHRONOTACHOGRA	1224 Bluetec4 (05-07)	MB DTCO
 Atego	CHRONOTACHOGRA	1224 Bluetec5 (06-08)	Stoneridge Electronics DTCO
 Atego	CHRONOTACHOGRA	1228 (98-02)	TCO
 Atego	CHRONOTACHOGRA	1228 K (98-02)	TCO

## Systems supported by ECReader (up to V4,90)

### TRUCKS




























### Mercedes Trucks

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Atego	CHRONOTACHOGRA	1228 L (98-02)	TCO
 Atego	CHRONOTACHOGRA	1229 Bluetec4 (05-07)	MB DTCO
 Atego	CHRONOTACHOGRA	1229 Bluetec5 (06-08)	Stoneridge Electronics DTCO
 Atego	CHRONOTACHOGRA	1324 Bluetec4 (05-07)	MB DTCO
 Atego	CHRONOTACHOGRA	1324 Bluetec5 (06-08)	Stoneridge Electronics DTCO
 Atego	CHRONOTACHOGRA	1329 Bluetec4 (05-07)	MB DTCO
 Atego	CHRONOTACHOGRA	1329 Bluetec5 (06-08)	Stoneridge Electronics DTCO
 Atego	CHRONOTACHOGRA	1517 (98-02)	TCO
 Atego	CHRONOTACHOGRA	1518 (98-02)	TCO
 Atego	CHRONOTACHOGRA	1518 K (98-02)	TCO
 Atego	CHRONOTACHOGRA	1518 L (98-02)	TCO
 Atego	CHRONOTACHOGRA	1523 (98-02)	TCO
 Atego	CHRONOTACHOGRA	1523 K (98-02)	TCO
 Atego	CHRONOTACHOGRA	1523 L (98-02)	TCO
 Atego	CHRONOTACHOGRA	1524 Bluetec4 (05-07)	MB DTCO
 Atego	CHRONOTACHOGRA	1524 Bluetec5 (06-08)	Stoneridge Electronics DTCO
 Atego	CHRONOTACHOGRA	1529 Bluetec4 (05-07)	MB DTCO
 Atego	CHRONOTACHOGRA	1529 Bluetec5 (06-08)	Stoneridge Electronics DTCO
 Atego	CHRONOTACHOGRA	1818 (98-02)	TCO
 Atego	CHRONOTACHOGRA	1823 (98-02)	TCO
 Atego	CHRONOTACHOGRA	1828 (98-02)	TCO
 Atego	CHRONOTACHOGRA	715 (98-02)	TCO
 Atego	CHRONOTACHOGRA	715 L (98-02)	TCO
 Atego	CHRONOTACHOGRA	716 Bluetec4 (05-07)	MB DTCO
 Atego	CHRONOTACHOGRA	716 Bluetec5 (06-08)	Stoneridge Electronics DTCO
 Atego	CHRONOTACHOGRA	815 (98-02)	TCO
 Atego	CHRONOTACHOGRA	815 L (98-02)	TCO

## Systems supported by ECReader (up to V4,90)

### TRUCKS

### Mercedes Trucks

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Atego	CHRONOTACHOGRA	816 Bluetec4 (05-07)	MB DTCO
 Atego	CHRONOTACHOGRA	816 Bluetec5 (06-08)	Stoneridge Electronics DTCO
 Atego	CHRONOTACHOGRA	818 (98-02)	TCO
 Atego	CHRONOTACHOGRA	818 Bluetec4 (05-07)	MB DTCO
 Atego	CHRONOTACHOGRA	818 Bluetec5 (06-08)	Stoneridge Electronics DTCO
 Atego	CHRONOTACHOGRA	818 K (98-02)	TCO
 Atego	CHRONOTACHOGRA	818 L (98-02)	TCO
 Atego	CHRONOTACHOGRA	822 Bluetec4 (05-07)	MB DTCO
 Atego	CHRONOTACHOGRA	822 Bluetec5 (06-08)	Stoneridge Electronics DTCO
 Atego	CLIMA	1018 (98-02)	MB HZR
 Atego	CLIMA	1018 AK (98-02)	MB HZR
 Atego	CLIMA	1018 L (98-02)	MB HZR
 Atego	CLIMA	1218 (98-02)	MB HZR
 Atego	CLIMA	1218 K (98-02)	MB HZR
 Atego	CLIMA	1218 L (98-02)	MB HZR
 Atego	CLIMA	1223 (98-02)	MB HZR
 Atego	CLIMA	1223 L (98-02)	MB HZR
 Atego	CLIMA	1228 (98-02)	MB HZR
 Atego	CLIMA	1228 L (98-02)	MB HZR
 Atego	CLIMA	1518 (98-02)	MB HZR
 Atego	CLIMA	1518 K (98-02)	MB HZR
 Atego	CLIMA	1518 L (98-02)	MB HZR
 Atego	CLIMA	1523 (98-02)	MB HZR
 Atego	CLIMA	2528 (98-02)	MB HZR
 Atego	CLIMA	715 (98-02)	MB HZR
 Atego	CLIMA	715 L (98-02)	MB HZR
 Atego	CLIMA	815 (98-02)	MB HZR

## Systems supported by ECReader (up to V4,90)

### TRUCKS

### Mercedes Trucks

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Atego	CLIMA	815 Eco (98-02)	MB HZR
 Atego	CLIMA	815 L (98-02)	MB HZR
 Atego	CLIMA	818 (98-02)	MB HZR
 Atego	CLIMA	818 K (98-02)	MB HZR
 Atego	CLIMA	818 L (98-02)	MB HZR
 Atego	CRUISE MANAGEME	1017 (98-02)	MB FR FMR
 Atego	CRUISE MANAGEME	1018 (00-00)	MB FR FMR
 Atego	CRUISE MANAGEME	1018 (98-02)	MB FR FMR
 Atego	CRUISE MANAGEME	1018 AK (00-00)	MB FR FMR
 Atego	CRUISE MANAGEME	1018 AK (98-02)	MB FR FMR
 Atego	CRUISE MANAGEME	1018 L (00-00)	MB FR FMR
 Atego	CRUISE MANAGEME	1018 L (98-02)	MB FR FMR
 Atego	CRUISE MANAGEME	1217 (98-02)	MB FR FMR
 Atego	CRUISE MANAGEME	1218 (00-00)	MB FR FMR
 Atego	CRUISE MANAGEME	1218 (98-02)	MB FR FMR
 Atego	CRUISE MANAGEME	1218 K (00-00)	MB FR FMR
 Atego	CRUISE MANAGEME	1218 K (98-02)	MB FR FMR
 Atego	CRUISE MANAGEME	1218 L (00-00)	MB FR FMR
 Atego	CRUISE MANAGEME	1218 L (98-02)	MB FR FMR
 Atego	CRUISE MANAGEME	1223 (00-00)	MB FR FMR
 Atego	CRUISE MANAGEME	1223 (98-02)	MB FR FMR
 Atego	CRUISE MANAGEME	1223 L (00-00)	MB FR FMR
 Atego	CRUISE MANAGEME	1223 L (98-02)	MB FR FMR
 Atego	CRUISE MANAGEME	1228 (00-00)	MB FR FMR
 Atego	CRUISE MANAGEME	1228 (98-02)	MB FR FMR
 Atego	CRUISE MANAGEME	1228 L (00-00)	MB FR FMR
 Atego	CRUISE MANAGEME	1228 L (98-02)	MB FR FMR

## Systems supported by ECReader (up to V4,90)

### TRUCKS












### Mercedes Trucks

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Atego	CRUISE MANAGEME	1517 (98-02)	MB FR FMR
 Atego	CRUISE MANAGEME	1518 (00-00)	MB FR FMR
 Atego	CRUISE MANAGEME	1518 (98-02)	MB FR FMR
 Atego	CRUISE MANAGEME	1518 K (00-00)	MB FR FMR
 Atego	CRUISE MANAGEME	1518 K (98-02)	MB FR FMR
 Atego	CRUISE MANAGEME	1518 L (00-00)	MB FR FMR
 Atego	CRUISE MANAGEME	1518 L (98-02)	MB FR FMR
 Atego	CRUISE MANAGEME	1523 (00-00)	MB FR FMR
 Atego	CRUISE MANAGEME	1523 (98-02)	MB FR FMR
 Atego	CRUISE MANAGEME	1818 (98-02)	MB FR FMR
 Atego	CRUISE MANAGEME	1823 (98-02)	MB FR FMR
 Atego	CRUISE MANAGEME	1828 (98-02)	MB FR FMR
 Atego	CRUISE MANAGEME	2528 (00-00)	MB FR FMR
 Atego	CRUISE MANAGEME	2528 (98-02)	MB FR FMR
 Atego	CRUISE MANAGEME	715 (00-00)	MB FR FMR
 Atego	CRUISE MANAGEME	715 (98-02)	MB FR FMR
 Atego	CRUISE MANAGEME	715 L (00-00)	MB FR FMR
 Atego	CRUISE MANAGEME	715 L (98-02)	MB FR FMR
 Atego	CRUISE MANAGEME	815 (00-00)	MB FR FMR
 Atego	CRUISE MANAGEME	815 (98-02)	MB FR FMR
 Atego	CRUISE MANAGEME	815 Eco (00-00)	MB FR FMR
 Atego	CRUISE MANAGEME	815 Eco (98-02)	MB FR FMR
 Atego	CRUISE MANAGEME	815 L (00-00)	MB FR FMR
 Atego	CRUISE MANAGEME	815 L (98-02)	MB FR FMR
 Atego	CRUISE MANAGEME	818 (00-00)	MB FR FMR
 Atego	CRUISE MANAGEME	818 (98-02)	MB FR FMR
 Atego	CRUISE MANAGEME	818 K (00-00)	MB FR FMR

## Systems supported by ECReader (up to V4,90)

### TRUCKS




























### Mercedes Trucks

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Atego	CRUISE MANAGEME	818 K (98-02)	MB FR FMR
 Atego	CRUISE MANAGEME	818 L (00-00)	MB FR FMR
 Atego	CRUISE MANAGEME	818 L (98-02)	MB FR FMR
 Atego	DASHBOARD	1017 (98-02)	MB INS Comb. Instrument
 Atego	DASHBOARD	1018 (00-00)	MB INS Comb. Instrument
 Atego	DASHBOARD	1018 (05-07)	MB
 Atego	DASHBOARD	1018 (98-02)	MB INS Comb. Instrument
 Atego	DASHBOARD	1018 AK (00-00)	MB INS Comb. Instrument
 Atego	DASHBOARD	1018 AK (98-02)	MB INS Comb. Instrument
 Atego	DASHBOARD	1018 L (00-00)	MB INS Comb. Instrument
 Atego	DASHBOARD	1018 L (98-02)	MB INS Comb. Instrument
 Atego	DASHBOARD	1022 (05-07)	MB
 Atego	DASHBOARD	1024 (05-07)	MB
 Atego	DASHBOARD	1217 (98-02)	MB INS Comb. Instrument
 Atego	DASHBOARD	1218 (00-00)	MB INS Comb. Instrument
 Atego	DASHBOARD	1218 (05-07)	MB
 Atego	DASHBOARD	1218 (98-02)	MB INS Comb. Instrument
 Atego	DASHBOARD	1218 K (00-00)	MB INS Comb. Instrument
 Atego	DASHBOARD	1218 K (98-02)	MB INS Comb. Instrument
 Atego	DASHBOARD	1218 L (00-00)	MB INS Comb. Instrument
 Atego	DASHBOARD	1218 L (98-02)	MB INS Comb. Instrument
 Atego	DASHBOARD	1222 (05-07)	MB
 Atego	DASHBOARD	1223 (00-00)	MB INS Comb. Instrument
 Atego	DASHBOARD	1223 (98-02)	MB INS Comb. Instrument
 Atego	DASHBOARD	1223 L (00-00)	MB INS Comb. Instrument
 Atego	DASHBOARD	1223 L (98-02)	MB INS Comb. Instrument
 Atego	DASHBOARD	1224 (05-07)	MB

## Systems supported by ECReader (up to V4,90)

### TRUCKS




























### Mercedes Trucks

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Atego	DASHBOARD	1228 (00-00)	MB INS Comb. Instrument
 Atego	DASHBOARD	1228 (98-02)	MB INS Comb. Instrument
 Atego	DASHBOARD	1228 L (00-00)	MB INS Comb. Instrument
 Atego	DASHBOARD	1228 L (98-02)	MB INS Comb. Instrument
 Atego	DASHBOARD	1229 (05-07)	MB
 Atego	DASHBOARD	1324 (05-07)	MB
 Atego	DASHBOARD	1329 (05-07)	MB
 Atego	DASHBOARD	1517 (98-02)	MB INS Comb. Instrument
 Atego	DASHBOARD	1518 (00-00)	MB INS Comb. Instrument
 Atego	DASHBOARD	1518 (98-02)	MB INS Comb. Instrument
 Atego	DASHBOARD	1518 K (00-00)	MB INS Comb. Instrument
 Atego	DASHBOARD	1518 K (98-02)	MB INS Comb. Instrument
 Atego	DASHBOARD	1518 L (98-02)	MB INS Comb. Instrument
 Atego	DASHBOARD	1523 (98-02)	MB INS Comb. Instrument
 Atego	DASHBOARD	1524 (05-07)	MB
 Atego	DASHBOARD	1529 (05-07)	MB
 Atego	DASHBOARD	1818 (98-02)	MB INS Comb. Instrument
 Atego	DASHBOARD	1823 (98-02)	MB INS Comb. Instrument
 Atego	DASHBOARD	1828 (98-02)	MB INS Comb. Instrument
 Atego	DASHBOARD	2528 (98-02)	MB INS Comb. Instrument
 Atego	DASHBOARD	715 (98-02)	MB INS Comb. Instrument
 Atego	DASHBOARD	715 L (98-02)	MB INS Comb. Instrument
 Atego	DASHBOARD	716 (05-07)	MB
 Atego	DASHBOARD	815 (98-02)	MB INS Comb. Instrument
 Atego	DASHBOARD	815 Eco (98-02)	MB INS Comb. Instrument
 Atego	DASHBOARD	815 L (98-02)	MB INS Comb. Instrument
 Atego	DASHBOARD	816 (05-07)	MB

## Systems supported by ECReader (up to V4,90)

### TRUCKS




























### Mercedes Trucks

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Atego	DASHBOARD	818 (05-07)	MB
 Atego	DASHBOARD	818 (98-02)	MB INS Comb. Instrument
 Atego	DASHBOARD	818 K (98-02)	MB INS Comb. Instrument
 Atego	DASHBOARD	818 L (98-02)	MB INS Comb. Instrument
 Atego	DASHBOARD	822 (05-07)	MB
 Atego	ENGINE MANAGEME	1017 (98-02)	MB MR PLD
 Atego	ENGINE MANAGEME	1018 (00-00)	MB MR PLD
 Atego	ENGINE MANAGEME	1018 (05-07)	MB MR PLD Bluetec 4
 Atego	ENGINE MANAGEME	1018 (98-02)	MB MR PLD
 Atego	ENGINE MANAGEME	1018 AK (00-00)	MB MR PLD
 Atego	ENGINE MANAGEME	1018 AK (98-02)	MB MR PLD
 Atego	ENGINE MANAGEME	1018 Bluetec 5 (06-08)	MB MR PLD
 Atego	ENGINE MANAGEME	1018 L (00-00)	MB MR PLD
 Atego	ENGINE MANAGEME	1018 L (98-02)	MB MR PLD
 Atego	ENGINE MANAGEME	1022 (05-07)	MB MR PLD Bluetec 4
 Atego	ENGINE MANAGEME	1022 Bluetec 5 (06-08)	MB MR PLD
 Atego	ENGINE MANAGEME	1024 (05-07)	MB MR PLD Bluetec 4
 Atego	ENGINE MANAGEME	1024 Bluetec 5 (06-08)	MB MR PLD
 Atego	ENGINE MANAGEME	1217 (98-02)	MB MR PLD
 Atego	ENGINE MANAGEME	1218 (00-00)	MB MR PLD
 Atego	ENGINE MANAGEME	1218 (05-07)	MB MR PLD Bluetec 4
 Atego	ENGINE MANAGEME	1218 (98-02)	MB MR PLD
 Atego	ENGINE MANAGEME	1218 Bluetec 5 (06-08)	MB MR PLD
 Atego	ENGINE MANAGEME	1218 K (00-00)	MB MR PLD
 Atego	ENGINE MANAGEME	1218 K (98-02)	MB MR PLD
 Atego	ENGINE MANAGEME	1218 L (00-00)	MB MR PLD
 Atego	ENGINE MANAGEME	1218 L (98-02)	MB MR PLD

## Systems supported by ECReader (up to V4,90)

### TRUCKS




























### Mercedes Trucks

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Atego	ENGINE MANAGEME	1222 (05-07)	MB MR PLD Bluetec 4
 Atego	ENGINE MANAGEME	1222 Bluetec 5 (06-08)	MB MR PLD
 Atego	ENGINE MANAGEME	1223 (00-00)	MB MR PLD
 Atego	ENGINE MANAGEME	1223 (98-02)	MB MR PLD
 Atego	ENGINE MANAGEME	1223 L (00-00)	MB MR PLD
 Atego	ENGINE MANAGEME	1223 L (98-02)	MB MR PLD
 Atego	ENGINE MANAGEME	1224 (05-07)	MB MR PLD Bluetec 4
 Atego	ENGINE MANAGEME	1224 Bluetec 5 (06-08)	MB MR PLD
 Atego	ENGINE MANAGEME	1228 (00-00)	MB MR PLD
 Atego	ENGINE MANAGEME	1228 (98-02)	MB MR PLD
 Atego	ENGINE MANAGEME	1228 L (00-00)	MB MR PLD
 Atego	ENGINE MANAGEME	1228 L (98-02)	MB MR PLD
 Atego	ENGINE MANAGEME	1229 (05-07)	MB MR PLD Bluetec 4
 Atego	ENGINE MANAGEME	1229 Bluetec 5 (06-08)	MB MR PLD
 Atego	ENGINE MANAGEME	1324 (05-07)	MB MR PLD Bluetec 4
 Atego	ENGINE MANAGEME	1324 Bluetec 5 (06-08)	MB MR PLD
 Atego	ENGINE MANAGEME	1329 (05-07)	MB MR PLD Bluetec 4
 Atego	ENGINE MANAGEME	1329 Bluetec 5 (06-08)	MB MR PLD
 Atego	ENGINE MANAGEME	1517 (98-02)	MB MR PLD
 Atego	ENGINE MANAGEME	1518 (00-00)	MB MR PLD
 Atego	ENGINE MANAGEME	1518 (98-02)	MB MR PLD
 Atego	ENGINE MANAGEME	1518 K (00-00)	MB MR PLD
 Atego	ENGINE MANAGEME	1518 K (98-02)	MB MR PLD
 Atego	ENGINE MANAGEME	1518 L (00-00)	MB MR PLD
 Atego	ENGINE MANAGEME	1518 L (98-02)	MB MR PLD
 Atego	ENGINE MANAGEME	1523 (00-00)	MB MR PLD
 Atego	ENGINE MANAGEME	1523 (98-02)	MB MR PLD

## Systems supported by ECReader (up to V4,90)

### TRUCKS




























### Mercedes Trucks

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Atego	ENGINE MANAGEME	1524 (05-07)	MB MR PLD Bluetec 4
 Atego	ENGINE MANAGEME	1524 Bluetec 5 (06-08)	MB MR PLD
 Atego	ENGINE MANAGEME	1529 (05-07)	MB MR PLD Bluetec 4
 Atego	ENGINE MANAGEME	1529 Bluetec 5 (06-08)	MB MR PLD
 Atego	ENGINE MANAGEME	1818 (98-02)	MB MR PLD
 Atego	ENGINE MANAGEME	1823 (98-02)	MB MR PLD
 Atego	ENGINE MANAGEME	1828 (98-02)	MB MR PLD
 Atego	ENGINE MANAGEME	2528 (00-00)	MB MR PLD
 Atego	ENGINE MANAGEME	2528 (98-02)	MB MR PLD
 Atego	ENGINE MANAGEME	715 (00-00)	MB MR PLD
 Atego	ENGINE MANAGEME	715 (98-02)	MB MR PLD
 Atego	ENGINE MANAGEME	715 L (00-00)	MB MR PLD
 Atego	ENGINE MANAGEME	715 L (98-02)	MB MR PLD
 Atego	ENGINE MANAGEME	716 (05-07)	MB MR PLD Bluetec 4
 Atego	ENGINE MANAGEME	716 Bluetec 5 (06-08)	MB MR PLD
 Atego	ENGINE MANAGEME	815 (00-00)	MB MR PLD
 Atego	ENGINE MANAGEME	815 (98-02)	MB MR PLD
 Atego	ENGINE MANAGEME	815 Eco (00-00)	MB MR PLD
 Atego	ENGINE MANAGEME	815 Eco (98-02)	MB MR PLD
 Atego	ENGINE MANAGEME	815 L (00-00)	MB MR PLD
 Atego	ENGINE MANAGEME	815 L (98-02)	MB MR PLD
 Atego	ENGINE MANAGEME	816 (05-07)	MB MR PLD Bluetec 4
 Atego	ENGINE MANAGEME	816 Bluetec 5 (06-08)	MB MR PLD
 Atego	ENGINE MANAGEME	818 (00-00)	MB MR PLD
 Atego	ENGINE MANAGEME	818 (05-07)	MB MR PLD Bluetec 4
 Atego	ENGINE MANAGEME	818 (98-02)	MB MR PLD
 Atego	ENGINE MANAGEME	818 Bluetec 5 (06-08)	MB MR PLD

## Systems supported by ECReader (up to V4,90)

### TRUCKS




























### Mercedes Trucks

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Atego	ENGINE MANAGEME	818 K (00-00)	MB MR PLD
 Atego	ENGINE MANAGEME	818 K (98-02)	MB MR PLD
 Atego	ENGINE MANAGEME	818 L (00-00)	MB MR PLD
 Atego	ENGINE MANAGEME	818 L (98-02)	MB MR PLD
 Atego	ENGINE MANAGEME	822 (05-07)	MB MR PLD Bluetec 4
 Atego	ENGINE MANAGEME	822 Bluetec 5 (06-08)	MB MR PLD
 Atego	GEARBOX MANAGEM	1018 Bluetec5 (06-08)	MB HPS
 Atego	GEARBOX MANAGEM	1022 Bluetec5 (06-08)	MB HPS
 Atego	GEARBOX MANAGEM	1024 Bluetec5 (06-08)	MB HPS
 Atego	GEARBOX MANAGEM	1218 Bluetec5 (06-08)	MB HPS
 Atego	GEARBOX MANAGEM	1222 Bluetec5 (06-08)	MB HPS
 Atego	GEARBOX MANAGEM	1224 Bluetec5 (06-08)	MB HPS
 Atego	GEARBOX MANAGEM	1229 Bluetec5 (06-08)	MB HPS
 Atego	GEARBOX MANAGEM	1324 Bluetec5 (06-08)	MB HPS
 Atego	GEARBOX MANAGEM	1329 Bluetec5 (06-08)	MB HPS
 Atego	GEARBOX MANAGEM	1524 Bluetec5 (06-08)	MB HPS
 Atego	GEARBOX MANAGEM	1529 Bluetec5 (06-08)	MB HPS
 Atego	GEARBOX MANAGEM	716 Bluetec5 (06-08)	MB HPS
 Atego	GEARBOX MANAGEM	816 Bluetec5 (06-08)	MB HPS
 Atego	GEARBOX MANAGEM	818 Bluetec5 (06-08)	MB HPS
 Atego	GEARBOX MANAGEM	822 Bluetec5 (06-08)	MB HPS
 Atego	MAINTENANCE SYST	1017 (98-02)	WS FSS
 Atego	MAINTENANCE SYST	1018 (98-02)	MB WS FSS
 Atego	MAINTENANCE SYST	1018 (98-02)	WS FSS
 Atego	MAINTENANCE SYST	1018 AK (98-02)	MB WS FSS
 Atego	MAINTENANCE SYST	1018 K (98-02)	WS FSS
 Atego	MAINTENANCE SYST	1018 L (98-02)	MB WS FSS

## Systems supported by ECReader (up to V4,90)

### TRUCKS




























### Mercedes Trucks

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Atego	MAINTENANCE SYST	1018 L (98-02)	WS FSS
 Atego	MAINTENANCE SYST	1217 (98-02)	WS FSS
 Atego	MAINTENANCE SYST	1218 (98-02)	MB WS FSS
 Atego	MAINTENANCE SYST	1218 (98-02)	WS FSS
 Atego	MAINTENANCE SYST	1218 K (98-02)	MB WS FSS
 Atego	MAINTENANCE SYST	1218 K (98-02)	WS FSS
 Atego	MAINTENANCE SYST	1218 L (98-02)	MB WS FSS
 Atego	MAINTENANCE SYST	1218 L (98-02)	WS FSS
 Atego	MAINTENANCE SYST	1223 (98-02)	MB WS FSS
 Atego	MAINTENANCE SYST	1223 (98-02)	WS FSS
 Atego	MAINTENANCE SYST	1223 K (98-02)	WS FSS
 Atego	MAINTENANCE SYST	1223 L (98-02)	MB WS FSS
 Atego	MAINTENANCE SYST	1223 L (98-02)	WS FSS
 Atego	MAINTENANCE SYST	1228 (98-02)	MB WS FSS
 Atego	MAINTENANCE SYST	1228 (98-02)	WS FSS
 Atego	MAINTENANCE SYST	1228 K (98-02)	WS FSS
 Atego	MAINTENANCE SYST	1228 L (98-02)	MB WS FSS
 Atego	MAINTENANCE SYST	1228 L (98-02)	WS FSS
 Atego	MAINTENANCE SYST	1517 (98-02)	WS FSS
 Atego	MAINTENANCE SYST	1518 (98-02)	MB WS FSS
 Atego	MAINTENANCE SYST	1518 (98-02)	WS FSS
 Atego	MAINTENANCE SYST	1518 K (98-02)	MB WS FSS
 Atego	MAINTENANCE SYST	1518 K (98-02)	WS FSS
 Atego	MAINTENANCE SYST	1518 L (98-02)	MB WS FSS
 Atego	MAINTENANCE SYST	1518 L (98-02)	WS FSS
 Atego	MAINTENANCE SYST	1523 (98-02)	MB WS FSS
 Atego	MAINTENANCE SYST	1523 (98-02)	WS FSS

## Systems supported by ECReader (up to V4,90)

### TRUCKS




























### Mercedes Trucks

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Atego	MAINTENANCE SYST	1523 K (98-02)	WS FSS
 Atego	MAINTENANCE SYST	1523 L (98-02)	WS FSS
 Atego	MAINTENANCE SYST	1818 (98-02)	WS FSS
 Atego	MAINTENANCE SYST	1823 (98-02)	WS FSS
 Atego	MAINTENANCE SYST	1828 (98-02)	WS FSS
 Atego	MAINTENANCE SYST	715 (98-02)	MB WS FSS
 Atego	MAINTENANCE SYST	715 (98-02)	WS FSS
 Atego	MAINTENANCE SYST	715 L (98-02)	MB WS FSS
 Atego	MAINTENANCE SYST	715 L (98-02)	WS FSS
 Atego	MAINTENANCE SYST	815 (98-02)	MB WS FSS
 Atego	MAINTENANCE SYST	815 (98-02)	WS FSS
 Atego	MAINTENANCE SYST	815 Eco (98-02)	MB WS FSS
 Atego	MAINTENANCE SYST	815 L (98-02)	MB WS FSS
 Atego	MAINTENANCE SYST	815 L (98-02)	WS FSS
 Atego	MAINTENANCE SYST	818 (98-02)	MB WS FSS
 Atego	MAINTENANCE SYST	818 (98-02)	WS FSS
 Atego	MAINTENANCE SYST	818 K (98-02)	MB WS FSS
 Atego	MAINTENANCE SYST	818 K (98-02)	WS FSS
 Atego	MAINTENANCE SYST	818 L (98-02)	MB WS FSS
 Atego	MAINTENANCE SYST	818 L (98-02)	WS FSS
 Atego	SUSPENSION CONTR	1017 (98-02)	WABCO NR ECAS
 Atego	SUSPENSION CONTR	1018 (98-02)	WABCO NR ECAS
 Atego	SUSPENSION CONTR	1018 AK (98-02)	WABCO NR ECAS
 Atego	SUSPENSION CONTR	1018 Bluetec4 (05-07)	MB
 Atego	SUSPENSION CONTR	1018 Bluetec5 (06-08)	MB NR
 Atego	SUSPENSION CONTR	1018 L (98-02)	WABCO NR ECAS
 Atego	SUSPENSION CONTR	1022 Bluetec4 (05-07)	MB

## Systems supported by ECReader (up to V4,90)

### TRUCKS



























### Mercedes Trucks

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Atego	SUSPENSION CONTR	1022 Bluetec5 (06-08)	MB NR
 Atego	SUSPENSION CONTR	1024 Bluetec4 (05-07)	MB
 Atego	SUSPENSION CONTR	1024 Bluetec5 (06-08)	MB NR
 Atego	SUSPENSION CONTR	1217 (98-02)	WABCO NR ECAS
 Atego	SUSPENSION CONTR	1218 (98-02)	WABCO NR ECAS
 Atego	SUSPENSION CONTR	1218 Bluetec4 (05-07)	MB
 Atego	SUSPENSION CONTR	1218 Bluetec5 (06-08)	MB NR
 Atego	SUSPENSION CONTR	1218 K (98-02)	WABCO NR ECAS
 Atego	SUSPENSION CONTR	1218 L (98-02)	WABCO NR ECAS
 Atego	SUSPENSION CONTR	1222 Bluetec4 (05-07)	MB
 Atego	SUSPENSION CONTR	1222 Bluetec5 (06-08)	MB NR
 Atego	SUSPENSION CONTR	1223 (98-02)	WABCO NR ECAS
 Atego	SUSPENSION CONTR	1223 L (98-02)	WABCO NR ECAS
 Atego	SUSPENSION CONTR	1224 Bluetec4 (05-07)	MB
 Atego	SUSPENSION CONTR	1224 Bluetec5 (06-08)	MB NR
 Atego	SUSPENSION CONTR	1228 (98-02)	WABCO NR ECAS
 Atego	SUSPENSION CONTR	1228 L (98-02)	WABCO NR ECAS
 Atego	SUSPENSION CONTR	1229 Bluetec4 (05-07)	MB
 Atego	SUSPENSION CONTR	1229 Bluetec5 (06-08)	MB NR
 Atego	SUSPENSION CONTR	1324 Bluetec4 (05-07)	MB
 Atego	SUSPENSION CONTR	1324 Bluetec5 (06-08)	MB NR
 Atego	SUSPENSION CONTR	1329 Bluetec4 (05-07)	MB
 Atego	SUSPENSION CONTR	1329 Bluetec5 (06-08)	MB NR
 Atego	SUSPENSION CONTR	1517 (98-02)	WABCO NR ECAS
 Atego	SUSPENSION CONTR	1518 (98-02)	WABCO NR ECAS
 Atego	SUSPENSION CONTR	1518 K (98-02)	WABCO NR ECAS
 Atego	SUSPENSION CONTR	1518 L (98-02)	WABCO NR ECAS

## Systems supported by ECUreader (up to V4,90)

### TRUCKS



























### Mercedes Trucks

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Atego	SUSPENSION CONTR	1523 (98-02)	WABCO NR ECAS
 Atego	SUSPENSION CONTR	1524 Bluetec4 (05-07)	MB
 Atego	SUSPENSION CONTR	1524 Bluetec5 (06-08)	MB NR
 Atego	SUSPENSION CONTR	1529 Bluetec4 (05-07)	MB
 Atego	SUSPENSION CONTR	1529 Bluetec5 (06-08)	MB NR
 Atego	SUSPENSION CONTR	1818 (98-02)	WABCO NR ECAS
 Atego	SUSPENSION CONTR	1823 (98-02)	WABCO NR ECAS
 Atego	SUSPENSION CONTR	1828 (98-02)	WABCO NR ECAS
 Atego	SUSPENSION CONTR	2528 (98-02)	WABCO NR ECAS
 Atego	SUSPENSION CONTR	715 (98-02)	WABCO NR ECAS
 Atego	SUSPENSION CONTR	715 L (98-02)	WABCO NR ECAS
 Atego	SUSPENSION CONTR	716 Bluetec4 (05-07)	MB
 Atego	SUSPENSION CONTR	716 Bluetec5 (06-08)	MB NR
 Atego	SUSPENSION CONTR	815 (98-02)	WABCO NR ECAS
 Atego	SUSPENSION CONTR	815 Eco (98-02)	WABCO NR ECAS
 Atego	SUSPENSION CONTR	815 L (98-02)	WABCO NR ECAS
 Atego	SUSPENSION CONTR	816 Bluetec4 (05-07)	MB
 Atego	SUSPENSION CONTR	816 Bluetec5 (06-08)	MB NR
 Atego	SUSPENSION CONTR	818 (98-02)	WABCO NR ECAS
 Atego	SUSPENSION CONTR	818 Bluetec4 (05-07)	MB
 Atego	SUSPENSION CONTR	818 Bluetec5 (06-08)	MB NR
 Atego	SUSPENSION CONTR	818 K (98-02)	WABCO NR ECAS
 Atego	SUSPENSION CONTR	818 L (98-02)	WABCO NR ECAS
 Atego	SUSPENSION CONTR	822 Bluetec4 (05-07)	MB
 Atego	SUSPENSION CONTR	822 Bluetec5 (06-08)	MB NR
 Axor SKN/C	ENGINE MANAGEME	1835 LS (...02)	MR PLD

## Systems supported by ECReader (up to V4,90)

### TRUCKS




























### Mercedes Trucks

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Axor SKN/C	ENGINE MANAGEME	1840 LS (...-02)	MR PLD
 Axor SKN/C	ENGINE MANAGEME	1843 LS (...-02)	MR PLD
 Axor SKT	CRUISE MANAGEME	1835 LS (...-99)	FR FMR
 Axor SKT	CRUISE MANAGEME	1835 LS (00-02)	FR FMR
 Axor SKT	CRUISE MANAGEME	1840 LS (...-99)	FR FMR
 Axor SKT	CRUISE MANAGEME	1840 LS (00-02)	FR FMR
 Axor SKT	CRUISE MANAGEME	1843 LS (...-99)	FR FMR
 Axor SKT	CRUISE MANAGEME	1843 LS (00-02)	FR FMR
 Axor SKT	ENGINE MANAGEME	1835 LS (...-02)	MR PLD
 Axor SKT	ENGINE MANAGEME	1840 LS (...-02)	MR PLD
 Axor SKT	ENGINE MANAGEME	1843 LS (...-02)	MR PLD
 Axor	ABS	1829 (05-07)	MB
 Axor	ABS	1833 (05-07)	MB
 Axor	ABS	1840 (05-07)	MB
 Axor	ABS	1843 (05-07)	MB
 Axor	ABS	2529 (05-07)	MB
 Axor	ABS	2533 (05-07)	MB
 Axor	ABS	2536 (05-07)	MB
 Axor	ABS	2540 (05-07)	MB
 Axor	ABS	2543 (05-07)	MB
 Axor	AUTOM. TRANSMISSI	1829 (05-07)	MB GS
 Axor	AUTOM. TRANSMISSI	1833 (05-07)	MB GS
 Axor	AUTOM. TRANSMISSI	1840 (05-07)	MB GS
 Axor	AUTOM. TRANSMISSI	1843 (05-07)	MB GS
 Axor	AUTOM. TRANSMISSI	2529 (05-07)	MB GS
 Axor	AUTOM. TRANSMISSI	2533 (05-07)	MB GS

## Systems supported by ECUreader (up to V4,90)

### TRUCKS




























### Mercedes Trucks

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Axor	AUTOM. TRANSMISSI	2536 (05-07)	MB GS
 Axor	AUTOM. TRANSMISSI	2540 (05-07)	MB GS
 Axor	AUTOM. TRANSMISSI	2543 (05-07)	MB GS
 Axor	BRAKE POWER SUP	1829 (05-07)	MB Intarder FR
 Axor	BRAKE POWER SUP	1829 (05-07)	MB Retarder RS
 Axor	BRAKE POWER SUP	1833 (05-07)	MB Intarder FR
 Axor	BRAKE POWER SUP	1833 (05-07)	MB Retarder RS
 Axor	BRAKE POWER SUP	1840 (05-07)	MB Intarder FR
 Axor	BRAKE POWER SUP	1840 (05-07)	MB Retarder RS
 Axor	BRAKE POWER SUP	1843 (05-07)	MB Intarder FR
 Axor	BRAKE POWER SUP	1843 (05-07)	MB Retarder RS
 Axor	BRAKE POWER SUP	2529 (05-07)	MB Intarder FR
 Axor	BRAKE POWER SUP	2529 (05-07)	MB Retarder RS
 Axor	BRAKE POWER SUP	2533 (05-07)	MB Intarder FR
 Axor	BRAKE POWER SUP	2533 (05-07)	MB Retarder RS
 Axor	BRAKE POWER SUP	2536 (05-07)	MB Intarder FR
 Axor	BRAKE POWER SUP	2536 (05-07)	MB Retarder RS
 Axor	BRAKE POWER SUP	2540 (05-07)	MB Intarder FR
 Axor	BRAKE POWER SUP	2540 (05-07)	MB Retarder RS
 Axor	BRAKE POWER SUP	2543 (05-07)	MB Intarder FR
 Axor	BRAKE POWER SUP	2543 (05-07)	MB Retarder RS
 Axor	CHRONOTACHOGRA	1829 (05-07)	MB DTCO Tachpgraph
 Axor	CHRONOTACHOGRA	1833 (05-07)	MB DTCO Tachpgraph
 Axor	CHRONOTACHOGRA	1840 (05-07)	MB DTCO Tachpgraph
 Axor	CHRONOTACHOGRA	1843 (05-07)	MB DTCO Tachpgraph
 Axor	CHRONOTACHOGRA	2529 (05-07)	MB DTCO Tachpgraph
 Axor	CHRONOTACHOGRA	2533 (05-07)	MB DTCO Tachpgraph

## Systems supported by ECUreader (up to V4,90)

### TRUCKS



























### Mercedes Trucks

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Axor	CHRONOTACHOGRA	2536 (05-07)	MB DTCO Tachpgraph
 Axor	CHRONOTACHOGRA	2540 (05-07)	MB DTCO Tachpgraph
 Axor	CHRONOTACHOGRA	2543 (05-07)	MB DTCO Tachpgraph
 Axor	DASHBOARD	1829 (05-07)	MB
 Axor	DASHBOARD	1833 (05-07)	MB
 Axor	DASHBOARD	1840 (05-07)	MB
 Axor	DASHBOARD	1843 (05-07)	MB
 Axor	DASHBOARD	2529 (05-07)	MB
 Axor	DASHBOARD	2533 (05-07)	MB
 Axor	DASHBOARD	2536 (05-07)	MB
 Axor	DASHBOARD	2540 (05-07)	MB
 Axor	DASHBOARD	2543 (05-07)	MB
 Axor	ENGINE MANAGEME	1829 (05-07)	MB
 Axor	ENGINE MANAGEME	1833 (05-07)	MB
 Axor	ENGINE MANAGEME	1840 (05-07)	MB
 Axor	ENGINE MANAGEME	1843 (05-07)	MB
 Axor	ENGINE MANAGEME	2529 (05-07)	MB
 Axor	ENGINE MANAGEME	2533 (05-07)	MB
 Axor	ENGINE MANAGEME	2536 (05-07)	MB
 Axor	ENGINE MANAGEME	2540 (05-07)	MB
 Axor	ENGINE MANAGEME	2543 (05-07)	MB
 Axor	SUSPENSION CONTR	1829 (05-07)	MB NR ECAS
 Axor	SUSPENSION CONTR	1833 (05-07)	MB NR ECAS
 Axor	SUSPENSION CONTR	1840 (05-07)	MB NR ECAS
 Axor	SUSPENSION CONTR	1843 (05-07)	MB NR ECAS
 Axor	SUSPENSION CONTR	2529 (05-07)	MB NR ECAS
 Axor	SUSPENSION CONTR	2533 (05-07)	MB NR ECAS

## Systems supported by ECReader (up to V4,90)

### TRUCKS




















### Mercedes Trucks

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Axor	SUSPENSION CONTR	2536 (05-07)	MB NR ECAS
 Axor	SUSPENSION CONTR	2540 (05-07)	MB NR ECAS
 Axor	SUSPENSION CONTR	2543 (05-07)	MB NR ECAS
 Econic	DASHBOARD	1824 LL (05-07)	MB INS
 Econic	DASHBOARD	1829 LL (05-07)	MB INS
 Econic	DASHBOARD	1833 LL (05-07)	MB INS
 Econic	DASHBOARD	2629 LL (05-07)	MB INS
 Econic	DASHBOARD	2633 LL (05-07)	MB INS
 Econic	ENGINE MANAGEME	1823 LL	MR PLD
 Econic	ENGINE MANAGEME	1824 LL (05-07)	MB
 Econic	ENGINE MANAGEME	1828 LL	MR PLD
 Econic	ENGINE MANAGEME	1829 LL (05-07)	MB
 Econic	ENGINE MANAGEME	1833 LL (05-07)	MB
 Econic	ENGINE MANAGEME	2628 LLc	MR PLD
 Econic	ENGINE MANAGEME	2628 LLp	MR PLD
 Econic	ENGINE MANAGEME	2629 LL (05-07)	MB
 Econic	ENGINE MANAGEME	2633 LL (05-07)	MB
 Econic	SUSPENSION CONTR	1824 LL (05-07)	MB NR
 Econic	SUSPENSION CONTR	1829 LL (05-07)	MB NR
 Econic	SUSPENSION CONTR	1833 LL (05-07)	MB NR
 Econic	SUSPENSION CONTR	2629 LL (05-07)	MB NR
 Econic	SUSPENSION CONTR	2633 LL (05-07)	MB NR
 Econic	ABS	1824 LL (05-07)	MB
 Econic	ABS	1829 LL (05-07)	MB
 Econic	ABS	1833 LL (05-07)	MB
 Econic	ABS	2629 LL (05-07)	MB

## Systems supported by ECUREADER (up to V4,90)

### TRUCKS



### Mercedes Trucks

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Econic	ABS	2633 LL (05-07)	MB
 Econic	BRAKE POWER SUP	1824 LL (05-07)	MB Intarder FR
 Econic	BRAKE POWER SUP	1829 LL (05-07)	MB Intarder FR
 Econic	BRAKE POWER SUP	1833 LL (05-07)	MB Intarder FR
 Econic	BRAKE POWER SUP	2629 LL (05-07)	MB Intarder FR
 Econic	BRAKE POWER SUP	2633 LL (05-07)	MB Intarder FR
 Unimog	ENGINE MANAGEME	(..-02)	BOSCH EVE
 Vario	ABS	614 D	MB ABS
 Vario	ABS	714 D	MB ABS
 Vario	ABS	815 D	MB ABS
 Vario	ABS	818 D	MB ABS
 Vario	ABS	O 815	MB ABS
 Vario	ABS	O 818	MB ABS
 Vario	DASHBOARD	614 D	MB INS
 Vario	DASHBOARD	714 D	MB INS
 Vario	DASHBOARD	815 D	MB INS
 Vario	DASHBOARD	818 D	MB INS
 Vario	DASHBOARD	O 815	MB INS
 Vario	DASHBOARD	O 818	MB INS

## Systems supported by ECUREADER (up to V4,90)

### TRUCKS



Mergul

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Trailers	BRAKE SYS. MANAG	Trailers	Wabco Trailer EBS
 Trailers	BRAKE SYS. MANAG	Trailers	Wabco Trailer VCS II

## Systems supported by ECUREADER (up to V4,90)

### TRUCKS



Mifroret

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Trailers	BRAKE SYS. MANAG	Trailers	Wabco Trailer EBS
 Trailers	BRAKE SYS. MANAG	Trailers	Wabco Trailer VCS II

## Systems supported by ECUREADER (up to V4,90)

### TRUCKS






Montalban

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Trailers	BRAKE SYS. MANAG	Trailers	Wabco Trailer EBS
 Trailers	BRAKE SYS. MANAG	Trailers	Wabco Trailer VCS II

## Systems supported by ECUREADER (up to V4,90)

### TRUCKS



### Montenegro

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Trailers	BRAKE SYS. MANAG	Trailers	Wabco Trailer EBS
 Trailers	BRAKE SYS. MANAG	Trailers	Wabco Trailer VCS II
 Trailers	BRAKE SYS. MANAG	Trailers	Wabco Trailers EBS kw2000
 Trailers	BRAKE SYS. MANAG	Trailers Haldex	Haldex EBS EB+
 Trailers	BRAKE SYS. MANAG	Trailers Knorr	Knorr Trailer EBS

## Systems supported by ECUREADER (up to V4,90)

### TRUCKS



Montull

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Trailers	BRAKE SYS. MANAG	Trailers	Wabco Trailer EBS
 Trailers	BRAKE SYS. MANAG	Trailers	Wabco Trailer VCS II

## Systems supported by ECUreader (up to V4,90)

### TRUCKS






Multicar

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 M26	ENGINE MANAGEME	8140	BOSCH EDC MS 6.3 CR
 M30	ENGINE MANAGEME	8140	BOSCH EDC MS 6.3 CR

## Systems supported by ECUREADER (up to V4,90)

### TRUCKS






### Multitrailer

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Trailers	BRAKE SYS. MANAG	Trailers	Wabco Trailer EBS
 Trailers	BRAKE SYS. MANAG	Trailers	Wabco Trailer VCS II
 Trailers	BRAKE SYS. MANAG	Trailers	Wabco Trailers EBS kw2000
 Trailers	BRAKE SYS. MANAG	Trailers Haldex	Haldex EBS EB+
 Trailers	BRAKE SYS. MANAG	Trailers Knorr	Knorr Trailer EBS

## Systems supported by ECUreader (up to V4,90)

### TRUCKS












Nardi

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Trailers	BRAKE SYS. MANAG	Trailers	Wabco Trailer EBS
 Trailers	BRAKE SYS. MANAG	Trailers	Wabco Trailer VCS II
 Trailers	BRAKE SYS. MANAG	Trailers	Wabco Trailers EBS kw2000
 Trailers	BRAKE SYS. MANAG	Trailers Haldex	Haldex EBS EB+
 Trailers	BRAKE SYS. MANAG	Trailers Knorr	Knorr Trailer EBS

## Systems supported by ECUreader (up to V4,90)

### TRUCKS






**Nissan**

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Atleon	ENGINE MANAGEME	3.0 TD	BOSCH EDC MSA 15
 Atleon	IMMOBILIZER	3.0 TD	NATS
 Cabstar	ENGINE MANAGEME	3.0 TD	BOSCH EDC MSA 15
 Cabstar	IMMOBILIZER	3.0 TD	NATS
 Navara	ENGINE MANAGEME	2.4 88kW (01-..)	EOBD
 Navara	ENGINE MANAGEME	2.5 D (04-..)	EOBD
 Navara	ENGINE MANAGEME	2.5 TD (04-..)	EOBD
 Pick-Up	ENGINE MANAGEME	2.4 88kW (01-..)	EOBD
 Pick-Up	ENGINE MANAGEME	2.5 D (04-..)	EOBD
 Pick-Up	ENGINE MANAGEME	2.5 TD (01-..)	EOBD
 Primastar	ENGINE MANAGEME	1.9 dCi F9Q	BOSCH EDC 15 C3 Common Rail

## Systems supported by ECUreader (up to V4,90)

### TRUCKS





















O.M.E.P.S.

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Trailers	BRAKE SYS. MANAG	Trailers	Wabco Trailer EBS
 Trailers	BRAKE SYS. MANAG	Trailers	Wabco Trailer VCS II
 Trailers	BRAKE SYS. MANAG	Trailers	Wabco Trailers EBS kw2000
 Trailers	BRAKE SYS. MANAG	Trailers Haldex	Haldex EBS EB+
 Trailers	BRAKE SYS. MANAG	Trailers Knorr	Knorr Trailer EBS

## Systems supported by ECUreader (up to V4,90)

### TRUCKS






Opel

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Combo	ABS		BOSCH ABS 5.3/5.4(+TC)
 Combo	ABS	1.3 CDTI (...03)	BOSCH ABS 5.3/5.4(+TC)
 Combo	ABS	1.3 CDTI (04-..)	BOSCH ABS 8
 Combo	AIRBAG	1.3 CDTI	SIEMENS AirBag SAB8x
 Combo	AIRBAG	1.3 CDTI (01-..)	TEMIC AirBag 07
 Combo	CHASSIS NETWORK	1.3 CDTI	SIEMENS Body computer
 Combo	DASHBOARD	1.3 CDTI (02-..)	SIEMENS Dashboard
 Combo	ELECTRIC STEERING	1.3 CDTI	EPS
 Combo	ENGINE MANAGEME	1.3 CDTI Z13DT (03-..)	MARELLI 6JF CF3 Common Rail
 Combo	ENGINE MANAGEME	1.4 X14SZ (97-00)	GM Multec S (F)
 Combo	IMMOBILIZER	1.3 CDTI	SIEMENS
 Movano	SERVICE LIGHT RES	2.5 CDTI 100 (07-..)	
 Movano	SERVICE LIGHT RES	2.5 CDTI 120 (07-..)	
 Movano	SERVICE LIGHT RES	2.5 CDTI 150 FAP (07-..)	
 Vivaro	AIRBAG	(02-..)	SAGEM - Autoliv AirBag ACU x.x
 Vivaro	ENGINE MANAGEME	1.9 dCi 100cv F9Q U7	BOSCH EDC 15 C3 Common Rail
 Vivaro	SERVICE LIGHT RES	2.0 16v 120 (07-..)	
 Vivaro	SERVICE LIGHT RES	2.0 CDTI 120 (07-..)	
 Vivaro	SERVICE LIGHT RES	2.0 CDTI 90 (07-..)	
 Vivaro	SERVICE LIGHT RES	2.5 CDTI 150 (07-..)	

## Systems supported by ECUREADER (up to V4,90)

### TRUCKS





Pacton

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Trailers	BRAKE SYS. MANAG	Trailers	Wabco Trailer EBS
 Trailers	BRAKE SYS. MANAG	Trailers	Wabco Trailer EBS kw2000
 Trailers	BRAKE SYS. MANAG	Trailers	Wabco Trailer VCS II
 Trailers	BRAKE SYS. MANAG	Trailers Haldex	Haldex EBS EB+
 Trailers	BRAKE SYS. MANAG	Trailers Knorr	Knorr Trailer EBS

## Systems supported by ECUREADER (up to V4,90)

### TRUCKS



Paganini

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Trailers	BRAKE SYS. MANAG	Trailers	Wabco Trailer EBS
 Trailers	BRAKE SYS. MANAG	Trailers	Wabco Trailers EBS kw2000
 Trailers	BRAKE SYS. MANAG	Trailers Haldex	Haldex EBS EB+
 Trailers	BRAKE SYS. MANAG	Trailers Knorr	Knorr Trailer EBS

## Systems supported by ECUREADER (up to V4,90)

### TRUCKS



Parcisa

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Trailers	BRAKE SYS. MANAG	Trailers	Wabco Trailer EBS
 Trailers	BRAKE SYS. MANAG	Trailers	Wabco Trailer VCS II

## Systems supported by ECUREADER (up to V4,90)

### TRUCKS



























**Pepin**

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Trailers	BRAKE SYS. MANAG	Trailers	Wabco Trailer EBS
 Trailers	BRAKE SYS. MANAG	Trailers	Wabco Trailer VCS II

## Systems supported by ECUREADER (up to V4,90)

### TRUCKS



























Peugeot

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Bipper	ABS + TRACT. CONT	1.3 Multijet 75cv	Bosch ESP 8
 Bipper	ABS + TRACT. CONT	1.4 8v	Bosch ESP 8
 Bipper	AIRBAG	1.3 Multijet 75cv	TRW SRS EP
 Bipper	AIRBAG	1.4 8v	TRW SRS EP
 Bipper	CHASSIS NETWORK	1.3 Multijet 75cv	DELPHI Body Computer
 Bipper	CHASSIS NETWORK	1.3 Multijet 75cv	DELPHI Body Computer CAN Info
 Bipper	CHASSIS NETWORK	1.3 Multijet 75cv	DELPHI EP
 Bipper	CHASSIS NETWORK	1.4 8v	DELPHI Body Computer
 Bipper	CHASSIS NETWORK	1.4 8v	DELPHI Body Computer CAN Info
 Bipper	CHASSIS NETWORK	1.4 8v	DELPHI EP
 Bipper	DASHBOARD	1.3 Multijet 75cv	MARELLI Dashboard Modale
 Bipper	DASHBOARD	1.4 8v	MARELLI Dashboard Modale
 Bipper	ENGINE MANAGEME	1.3 Multijet 75cv	MARELLI IAW 6F3
 Boxer	ABS		BOSCH ABS 5.3
 Boxer	AIRBAG		SIEMENS AirBag
 Boxer	ENGINE MANAGEME	2.0 HDI (02-06)	BOSCH EDC 15 Common Rail (JTD '99)
 Boxer	ENGINE MANAGEME	2.3 HDI (02-06)	BOSCH EDC 15 Common Rail (JTD '99)
 Boxer	ENGINE MANAGEME	2.8 HDI (02-06)	BOSCH EDC 15 Common Rail (JTD '99)
 Boxer	IMMOBILIZER		Delphi Code 2
 Expert	ABS	1.9 TD	BOSCH ABS ABR 5.3
 Expert	ABS	2.0 HDI	BOSCH ABS ABR 5.3
 Expert	DIESEL MANAGEMEN	1.9 D WJY	LUCAS Diesel DCN2
 Expert	DIESEL MANAGEMEN	1.9 TD DHX	BOSCH AS3 VP20
 Expert	ENGINE MANAGEME	2.0 HDI RHT	BOSCH EDC 15 C2 Common Rail
 Expert	ENGINE MANAGEME	2.0 HDI RHX	BOSCH EDC 15 C2 Common Rail
 Expert	ENGINE MANAGEME	2.0 HDI RHZ (.-00)	BOSCH EDC 15 C2 Common Rail

## Systems supported by ECUREADER (up to V4,90)

### TRUCKS



























Peugeot

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Expert	ENGINE MANAGEME	2.0 HDI RHZ (03-..)	BOSCH EDC 15 C2 Common Rail
 Partner	ABS	1.1	BOSCH ABS ABR 5.3
 Partner	ABS	1.4	BOSCH ABS ABR 5.3
 Partner	ABS	1.6 16v (08-..)	BOSCH ABS 8.1
 Partner	ABS	1.6 HDI 75cv (08-..)	BOSCH ABS 8.1
 Partner	ABS	1.6 HDI 90cv (08-..)	BOSCH ABS 8.1
 Partner	ABS	1.9 D	BOSCH ABS ABR 5.3
 Partner	ABS	2.0 HDI	BOSCH ABS ABR 5.3
 Partner	AIRBAG	1.6 16v (08-..)	Autoliv
 Partner	AIRBAG	1.6 HDI 75cv (08-..)	Autoliv
 Partner	AIRBAG	1.6 HDI 90cv (08-..)	Autoliv
 Partner	CHASSIS NETWORK	1.6 16v (08-..)	Delphi BSM
 Partner	CHASSIS NETWORK	1.6 16v (08-..)	JCAE BSI 5.20
 Partner	CHASSIS NETWORK	1.6 HDI 75cv (08-..)	Delphi BSM
 Partner	CHASSIS NETWORK	1.6 HDI 75cv (08-..)	JCAE BSI 5.20
 Partner	CHASSIS NETWORK	1.6 HDI 90cv (08-..)	Delphi BSM
 Partner	CHASSIS NETWORK	1.6 HDI 90cv (08-..)	JCAE BSI 5.20
 Partner	DASHBOARD	1.6 16v (08-..)	MARELLI
 Partner	DASHBOARD	1.6 HDI 75cv (08-..)	MARELLI
 Partner	DASHBOARD	1.6 HDI 90cv (08-..)	MARELLI
 Partner	DIESEL MANAGEMEN	1.9 D WJY	LUCAS Diesel DCN2
 Partner	ENGINE MANAGEME	1.1 HDY	BOSCH MonoMotronic MA3.1
 Partner	ENGINE MANAGEME	1.1 HDZ	BOSCH MonoMotronic MA3.1
 Partner	ENGINE MANAGEME	1.4 KFX	MARELLI MM 1AP.81
 Partner	ENGINE MANAGEME	1.4 KFX	SAGEM SL 96
 Partner	ENGINE MANAGEME	1.6 16v NFR (08-..)	BOSCH Motronic ME 7.4.5

## Systems supported by ECUREADER (up to V4,90)

### TRUCKS


























Peugeot

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Partner	ENGINE MANAGEME	2.0 HDI RHY	SIEMENS Diesel SID 801 Common Rail
 Partner	ENGINE MANAGEME	2.0 HDI RHY (..-00)	BOSCH EDC 15 C2 Common Rail
 Partner	ENGINE MANAGEME	2.0 HDI RHY (03-..)	BOSCH EDC 15 C2 Common Rail
 Partner	ENGINE MANAGEME	2.0 HDI RHZ (..-00)	BOSCH EDC 15 C2 Common Rail
 Partner	KEY ENCODE		Valeo/Siemens
 Partner	KEY ENCODE	(03-..)	VALEO Body Siemens
 Partner	SWITCHLIGHT MODU	1.6 16v (08-..)	Delphi
 Partner	SWITCHLIGHT MODU	1.6 HDI 75cv (08-..)	Delphi
 Partner	SWITCHLIGHT MODU	1.6 HDI 90cv (08-..)	Delphi
 Ranch	ABS	1.1	BOSCH ABS ABR 5.3
 Ranch	ABS	1.4	BOSCH ABS ABR 5.3
 Ranch	ABS	1.9 D	BOSCH ABS ABR 5.3
 Ranch	ABS	2.0 HDI	BOSCH ABS ABR 5.3
 Ranch	AIRBAG	1.1 (97-00)	AKF- Autoliv AirBag no SIDE AB
 Ranch	AIRBAG	1.4 (97-00)	AKF- Autoliv AirBag no SIDE AB
 Ranch	AIRBAG	1.9 D (97-00)	AKF- Autoliv AirBag no SIDE AB
 Ranch	AIRBAG	2.0 HDI (97-00)	AKF- Autoliv AirBag no SIDE AB
 Ranch	CHASSIS NETWORK	1.1 (..-01)	VALEO Body Computer
 Ranch	CHASSIS NETWORK	1.4 (..-01)	VALEO Body Computer
 Ranch	CHASSIS NETWORK	1.9 D (..-01)	VALEO Body Computer
 Ranch	CHASSIS NETWORK	2.0 HDI (..-01)	VALEO Body Computer
 Ranch	DIESEL MANAGEMEN	1.9 D WJY	LUCAS Diesel DCN2
 Ranch	ENGINE MANAGEME	1.1 HDY	BOSCH MonoMotronic MA3.1
 Ranch	ENGINE MANAGEME	1.1 HDZ	BOSCH MonoMotronic MA3.1
 Ranch	ENGINE MANAGEME	1.4 KFW	SAGEM S2000
 Ranch	ENGINE MANAGEME	1.4 KFX	MARELLI MM 1AP.40

## Systems supported by ECReader (up to V4,90)

### TRUCKS






Peugeot

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Ranch	ENGINE MANAGEME	1.6 16v NFU	BOSCH Motronic ME7.4.4
 Ranch	ENGINE MANAGEME	2.0 HDI RHY	SIEMENS Diesel SID 801 Common Rail
 Ranch	ENGINE MANAGEME	2.0 HDI RHY (..-00)	BOSCH EDC 15 C2 Common Rail
 Ranch	ENGINE MANAGEME	2.0 HDI RHZ (..-99)	BOSCH EDC 15 C2 Common Rail
 Ranch	RADIO / CD	1.1	CLARION AudioSystem
 Ranch	RADIO / CD	1.1	PHILIPS AudioSystem
 Ranch	RADIO / CD	1.1	VDO AudioSystem
 Ranch	RADIO / CD	1.4	CLARION AudioSystem
 Ranch	RADIO / CD	1.4	PHILIPS AudioSystem
 Ranch	RADIO / CD	1.4	VDO AudioSystem
 Ranch	RADIO / CD	1.9 D	CLARION AudioSystem
 Ranch	RADIO / CD	1.9 D	PHILIPS AudioSystem
 Ranch	RADIO / CD	1.9 D	VDO AudioSystem
 Ranch	RADIO / CD	2.0 HDI	CLARION AudioSystem
 Ranch	RADIO / CD	2.0 HDI	PHILIPS AudioSystem
 Ranch	RADIO / CD	2.0 HDI	VDO AudioSystem
 Ranch	SERVICE LIGHT RES	(98-00)	VDO
 Ranch	SWITCHLIGHT MODU	1.1	EATON
 Ranch	SWITCHLIGHT MODU	1.4	EATON
 Ranch	SWITCHLIGHT MODU	1.9 D	EATON
 Ranch	SWITCHLIGHT MODU	2.0 HDI	EATON
 Ranch	VISUAL./TELEMATICS	1.1	SAGEM
 Ranch	VISUAL./TELEMATICS	1.4	SAGEM
 Ranch	VISUAL./TELEMATICS	1.9 D	SAGEM
 Ranch	VISUAL./TELEMATICS	2.0 HDI	SAGEM

## Systems supported by ECUreader (up to V4,90)

### TRUCKS



Piacenza

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Trailers	ABS	Trailers Wabco	Wabco VARIO C1-C2-C plus
 Trailers	BRAKE SYS. MANAG	Trailers	Wabco Trailer EBS
 Trailers	BRAKE SYS. MANAG	Trailers	Wabco Trailers EBS kw2000
 Trailers	BRAKE SYS. MANAG	Trailers Haldex	Haldex EBS EB+
 Trailers	BRAKE SYS. MANAG	Trailers Knorr	Knorr Trailer EBS

## Systems supported by ECUREADER (up to V4,90)

### TRUCKS



























**Primball**

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Trailers	BRAKE SYS. MANAG	Trailers	Wabco Trailer EBS
 Trailers	BRAKE SYS. MANAG	Trailers	Wabco Trailer VCS II

## Systems supported by ECReader (up to V4,90)

### TRUCKS



























**Renault**

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Express	AIRBAG		SIEMENS - Autoliv AirBag AC4
 Express	AIRBAG		SIEMENS - Autoliv AirBag EC5
 Express	ENGINE MANAGEME	1.2 C3G - 702	MARELLI IAW 6R
 Express	ENGINE MANAGEME	1.2 C3G - 710	MARELLI IAW 6R
 Express	ENGINE MANAGEME	1.2 C3G - 710	MARELLI IAW 6R
 Express	ENGINE MANAGEME	1.2 C3G - 710	MARELLI IAW 6R
 Express	ENGINE MANAGEME	1.2 C3G - 710	MARELLI IAW 6R
 Express	ENGINE MANAGEME	1.2 C3G - 710	MARELLI IAW 6R
 Express	ENGINE MANAGEME	1.2 C3G - 710	MARELLI IAW 6R
 Express	ENGINE MANAGEME	1.4 C3J - 702	SIEMENS RENIX Monopoint
 Express	ENGINE MANAGEME	1.4 C3J - 760	SIEMENS RENIX Monopoint
 Express	ENGINE MANAGEME	1.4 C3J - 762	SIEMENS RENIX Monopoint
 Express	ENGINE MANAGEME	1.4 E7J - 720	SIEMENS BOSCH Monopoint
 Express	ENGINE MANAGEME	1.4 E7J - 720	SIEMENS BOSCH Monopoint
 Express	ENGINE MANAGEME	1.4 E7J - 720	SIEMENS BOSCH Monopoint
 Express	ENGINE MANAGEME	1.4 E7J - 720	SIEMENS BOSCH Monopoint
 Express	ENGINE MANAGEME	1.4 E7J - 720	SIEMENS BOSCH Monopoint
 Express	ENGINE MANAGEME	1.4 E7J - 720	SIEMENS BOSCH Monopoint
 Express	ENGINE MANAGEME	1.4 E7J - 724	SIEMENS BOSCH Monopoint
 Express	ENGINE MANAGEME	1.4 E7J - 724	SIEMENS BOSCH Monopoint
 Express	ENGINE MANAGEME	1.4 E7J - 724	SIEMENS BOSCH Monopoint
 Express	ENGINE MANAGEME	1.4 E7J - 724	SIEMENS BOSCH Monopoint
 Express	ENGINE MANAGEME	1.4 E7J - 724	SIEMENS BOSCH Monopoint
 Express	ENGINE MANAGEME	1.4 E7J - 728	SIEMENS BOSCH Monopoint
 Express	ENGINE MANAGEME	1.4 E7J - 728	SIEMENS BOSCH Monopoint
 Express	ENGINE MANAGEME	1.4 E7J - 728	SIEMENS BOSCH Monopoint
 Express	ENGINE MANAGEME	1.4 E7J - 728	SIEMENS BOSCH Monopoint
 Express	ENGINE MANAGEME	1.4 E7J - 728	SIEMENS BOSCH Monopoint

## Systems supported by ECReader (up to V4,90)

### TRUCKS



























**Renault**

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Express	ENGINE MANAGEME	1.4 E7J - 770	SIEMENS BOSCH Monopoint
 Express	ENGINE MANAGEME	1.4 E7J - 773	SIEMENS BOSCH Monopoint
 Express	ENGINE MANAGEME	1.4 E7J - 773	SIEMENS BOSCH Monopoint
 Express	ENGINE MANAGEME	1.4 E7J - 773	SIEMENS BOSCH Monopoint
 Kangoo II	ABS	1.5 dCi 105cv (08-..)	BOSCH ABS 8.0
 Kangoo II	ABS	1.5 dCi 105cv FAP (08-..)	BOSCH ABS 8.0
 Kangoo II	ABS	1.5 dCi 68cv (08-..)	BOSCH ABS 8.0
 Kangoo II	ABS	1.5 dCi 86cv (08-..)	BOSCH ABS 8.0
 Kangoo II	ABS	1.6 16v (08-..)	BOSCH ABS 8.0
 Kangoo II	AIRBAG	1.5 dCi 105cv (08-..)	BOSCH AirBag AB9
 Kangoo II	AIRBAG	1.5 dCi 105cv FAP (08-..)	BOSCH AirBag AB9
 Kangoo II	AIRBAG	1.5 dCi 68cv (08-..)	BOSCH AirBag AB9
 Kangoo II	AIRBAG	1.5 dCi 86cv (08-..)	BOSCH AirBag AB9
 Kangoo II	AIRBAG	1.6 16v (08-..)	BOSCH AirBag AB9
 Kangoo II	CHASSIS NETWORK	1.5 dCi 105cv (08-..)	Body Computer UCH
 Kangoo II	CHASSIS NETWORK	1.5 dCi 105cv (08-..)	Body Computer UPC
 Kangoo II	CHASSIS NETWORK	1.5 dCi 105cv FAP (08-..)	Body Computer UCH
 Kangoo II	CHASSIS NETWORK	1.5 dCi 105cv FAP (08-..)	Body Computer UPC
 Kangoo II	CHASSIS NETWORK	1.5 dCi 68cv (08-..)	Body Computer UCH
 Kangoo II	CHASSIS NETWORK	1.5 dCi 68cv (08-..)	Body Computer UPC
 Kangoo II	CHASSIS NETWORK	1.5 dCi 86cv (08-..)	Body Computer UCH
 Kangoo II	CHASSIS NETWORK	1.5 dCi 86cv (08-..)	Body Computer UPC
 Kangoo II	CHASSIS NETWORK	1.6 16v (08-..)	Body Computer UCH
 Kangoo II	CHASSIS NETWORK	1.6 16v (08-..)	Body Computer UPC
 Kangoo II	DASHBOARD	1.5 dCi 105cv (08-..)	SAGEM Kombi
 Kangoo II	DASHBOARD	1.5 dCi 105cv FAP (08-..)	SAGEM Kombi

## Systems supported by ECUREADER (up to V4,90)

### TRUCKS




























Renault

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Kangoo II	DASHBOARD	1.5 dCi 68cv (08-..)	SAGEM Kombi
 Kangoo II	DASHBOARD	1.5 dCi 86cv (08-..)	SAGEM Kombi
 Kangoo II	DASHBOARD	1.6 16v (08-..)	SAGEM Kombi
 Kangoo II	ELECTRIC STEERING	1.5 dCi 105cv (08-..)	KOYO EPS
 Kangoo II	ELECTRIC STEERING	1.5 dCi 105cv FAP (08-..)	KOYO EPS
 Kangoo II	ELECTRIC STEERING	1.5 dCi 68cv (08-..)	KOYO EPS
 Kangoo II	ELECTRIC STEERING	1.5 dCi 86cv (08-..)	KOYO EPS
 Kangoo II	ELECTRIC STEERING	1.6 16v (08-..)	KOYO EPS
 Kangoo II	ENGINE MANAGEME	1.5 dCi 105cv K4M (08-..)	DELPHI EDC Common Rail
 Kangoo II	SERVICE LIGHT RES	(08-..)	
 Kangoo	ABS	1.2	BOSCH ABS 5.3
 Kangoo	ABS	1.2	BOSCH ABS 5.3 T
 Kangoo	ABS	1.2 16v	BOSCH ABS 5.3
 Kangoo	ABS	1.2 16v	BOSCH ABS 5.3 T
 Kangoo	ABS	1.4	BOSCH ABS 5.3
 Kangoo	ABS	1.4	BOSCH ABS 5.3 T
 Kangoo	ABS	1.5 dCi 65cv	BOSCH ABS 5.3
 Kangoo	ABS	1.5 dCi 65cv	BOSCH ABS 5.3 T
 Kangoo	ABS	1.5 dCi 80cv	BOSCH ABS 5.3
 Kangoo	ABS	1.5 dCi 80cv	BOSCH ABS 5.3 T
 Kangoo	ABS	1.6 16v	BOSCH ABS 5.3
 Kangoo	ABS	1.6 16v	BOSCH ABS 5.3 T
 Kangoo	ABS	1.9 D	BOSCH ABS 5.3
 Kangoo	ABS	1.9 D	BOSCH ABS 5.3 T
 Kangoo	ABS	1.9 dCi	BOSCH ABS 5.3
 Kangoo	ABS	1.9 dCi	BOSCH ABS 5.3 T

## Systems supported by ECUreader (up to V4,90)

### TRUCKS




























Renault

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Kangoo	ABS	1.9 dTi	BOSCH ABS 5.3
 Kangoo	ABS	1.9 dTi	BOSCH ABS 5.3 T
 Kangoo	AIRBAG	1.2	SIEMENS - Autoliv AirBag AC4
 Kangoo	AIRBAG	1.2	SIEMENS - Autoliv AirBag AC6
 Kangoo	AIRBAG	1.2	SIEMENS - Autoliv AirBag EC5
 Kangoo	AIRBAG	1.2 16v	SIEMENS - Autoliv AirBag AC4
 Kangoo	AIRBAG	1.2 16v	SIEMENS - Autoliv AirBag AC6
 Kangoo	AIRBAG	1.2 16v	SIEMENS - Autoliv AirBag EC5
 Kangoo	AIRBAG	1.4	SIEMENS - Autoliv AirBag AC4
 Kangoo	AIRBAG	1.4	SIEMENS - Autoliv AirBag AC6
 Kangoo	AIRBAG	1.4	SIEMENS - Autoliv AirBag EC5
 Kangoo	AIRBAG	1.5 dCi 65cv	SIEMENS - Autoliv AirBag AC4
 Kangoo	AIRBAG	1.5 dCi 65cv	SIEMENS - Autoliv AirBag AC6
 Kangoo	AIRBAG	1.5 dCi 65cv	SIEMENS - Autoliv AirBag EC5
 Kangoo	AIRBAG	1.5 dCi 80cv	SIEMENS - Autoliv AirBag AC4
 Kangoo	AIRBAG	1.5 dCi 80cv	SIEMENS - Autoliv AirBag AC6
 Kangoo	AIRBAG	1.5 dCi 80cv	SIEMENS - Autoliv AirBag EC5
 Kangoo	AIRBAG	1.6 16v	SIEMENS - Autoliv AirBag AC4
 Kangoo	AIRBAG	1.6 16v	SIEMENS - Autoliv AirBag AC6
 Kangoo	AIRBAG	1.6 16v	SIEMENS - Autoliv AirBag EC5
 Kangoo	AIRBAG	1.9 D	SIEMENS - Autoliv AirBag AC4
 Kangoo	AIRBAG	1.9 D	SIEMENS - Autoliv AirBag AC6
 Kangoo	AIRBAG	1.9 D	SIEMENS - Autoliv AirBag EC5
 Kangoo	AIRBAG	1.9 dCi	SIEMENS - Autoliv AirBag AC4
 Kangoo	AIRBAG	1.9 dCi	SIEMENS - Autoliv AirBag AC6
 Kangoo	AIRBAG	1.9 dCi	SIEMENS - Autoliv AirBag EC5
 Kangoo	AIRBAG	1.9 dTi	SIEMENS - Autoliv AirBag AC4

## Systems supported by ECReader (up to V4,90)

### TRUCKS



























**Renault**

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Kangoo	AIRBAG	1.9 dTi	SIEMENS - Autoliv AirBag AC6
 Kangoo	AIRBAG	1.9 dTi	SIEMENS - Autoliv AirBag EC5
 Kangoo	DIESEL MANAGEMEN	1.9 D F8Q	SIEMENS Diesel DCU3R
 Kangoo	DIESEL MANAGEMEN	1.9 D F8Q (55Kw) (...99)	LUCAS Diesel DPCN1
 Kangoo	DIESEL MANAGEMEN	1.9 dTi F9Q	BOSCH MSA 15
 Kangoo	ELECTRONIC INJECTI	AUTODETECT	
 Kangoo	ENGINE MANAGEME	1.2 D7F - 730	SAGEM SAFIR Multipoint
 Kangoo	ENGINE MANAGEME	1.2 D7F - 730	SAGEM SAFIR Multipoint
 Kangoo	ENGINE MANAGEME	1.2 D7F - 730	SAGEM SAFIR Multipoint
 Kangoo	ENGINE MANAGEME	1.2 D7F - 730	SAGEM SAFIR Multipoint
 Kangoo	ENGINE MANAGEME	1.2 D7F - 730	SAGEM SAFIR Multipoint
 Kangoo	ENGINE MANAGEME	1.2 D7F - 730	SAGEM SAFIR Multipoint
 Kangoo	ENGINE MANAGEME	1.2 D7F - 730	SAGEM SAFIR Multipoint
 Kangoo	ENGINE MANAGEME	1.2 D7F - 730	SAGEM SAFIR Multipoint
 Kangoo	ENGINE MANAGEME	1.2 D7F - G7	SIEMENS Sirius 32
 Kangoo	ENGINE MANAGEME	1.4 (01-..)	EOBD
 Kangoo	ENGINE MANAGEME	1.4 16v K4J	SIEMENS Sirius 32
 Kangoo	ENGINE MANAGEME	1.4 E7J	SIEMENS FENIX 5
 Kangoo	ENGINE MANAGEME	1.4 E7J	SIEMENS Sirius 32
 Kangoo	ENGINE MANAGEME	1.5 dCi (05-..)	SIEMENS EDC SID
 Kangoo	ENGINE MANAGEME	1.5 dCi (06-..)	SIEMENS EDC SID 301 Common Rail
 Kangoo	ENGINE MANAGEME	1.5 dCi 65cv K9K	DELPHI LUCAS LVCR Common Rail
 Kangoo	ENGINE MANAGEME	1.5 dCi 82cv (04-..)	SIEMENS EDC SID
 Kangoo	ENGINE MANAGEME	1.6 16v K4M	SIEMENS Sirius 32
 Kangoo	ENGINE MANAGEME	1.9 D F8Q	LUCAS Diesel DCU3R
 Kangoo	ENGINE MANAGEME	1.9 dCi F9Q - 740 (...00)	BOSCH EDC 15 C3 Common Rail
 Kangoo	ENGINE MANAGEME	1.9 dCi F9Q (01-..)	BOSCH EDC 15 C3 Common Rail

## Systems supported by ECReader (up to V4,90)

### TRUCKS




























**Renault**

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Kangoo	ENGINE MANAGEME	AUTODETECT	
 Kangoo	IMMOBILIZER	1.2	Immobilizer Body Computer
 Kangoo	IMMOBILIZER	1.2 16v	Immobilizer Body Computer
 Kangoo	IMMOBILIZER	1.4	Immobilizer Body Computer
 Kangoo	IMMOBILIZER	1.5 dCi 65cv	Immobilizer Body Computer
 Kangoo	IMMOBILIZER	1.5 dCi 80cv	Immobilizer Body Computer
 Kangoo	IMMOBILIZER	1.6 16v	Immobilizer Body Computer
 Kangoo	IMMOBILIZER	1.9 D	Immobilizer Body Computer
 Kangoo	IMMOBILIZER	1.9 dCi	Immobilizer Body Computer
 Kangoo	IMMOBILIZER	1.9 dTi	Immobilizer Body Computer
 Master	ABS		TEVES ABS MK20T
 Master	ABS	(01-..)	TEVES ABS Mk60
 Master	AIRBAG		SAGEM - Autoliv AirBag ACU 3
 Master	AIRBAG		SIEMENS - Autoliv AirBag AC4
 Master	AIRBAG		SIEMENS - Autoliv AirBag EC5
 Master	ENGINE MANAGEME	2.2 16v dCi G9T D7 (01-..)	BOSCH EDC 15 C3 Common Rail
 Master	ENGINE MANAGEME	2.2 J7T - 782	SIEMENS Multipoint
 Master	ENGINE MANAGEME	2.2 J7T - 788	SIEMENS Multipoint
 Megane	DIESEL MANAGEMEN	1.9 D F8Q	SIEMENS Diesel DCU3R
 Trafic	AIRBAG		SIEMENS - Autoliv AirBag AC4
 Trafic	AIRBAG		SIEMENS - Autoliv AirBag EC5
 Trafic	AIRBAG	1.9 dCi (..-02)	SAGEM - Autoliv AirBag ACU x.x
 Trafic	ENGINE MANAGEME	1.9 dCi F9Q	BOSCH EDC 15 C3 Common Rail
 Trafic	ENGINE MANAGEME	2.2 J7T	SIEMENS BENDIX-FENIX Multipoint
 Trafic	ENGINE MANAGEME	2.2 J7T	SIEMENS BENDIX-FENIX Multipoint
 Trafic	ENGINE MANAGEME	2.2 J7T	SIEMENS BENDIX-FENIX Multipoint

## Systems supported by ECUreader (up to V4,90)

### TRUCKS

### Renault Trucks

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Kerax	ABS	260	Bosch ABS 24
 Kerax	ABS	260	Bosch ABS I8
 Kerax	ABS	260	WABCO ABS D-E
 Kerax	ABS	270	Bosch ABS 24
 Kerax	ABS	270	Bosch ABS I8
 Kerax	ABS	270	WABCO ABS D-E
 Kerax	ABS	300	Bosch ABS 24
 Kerax	ABS	300	Bosch ABS I8
 Kerax	ABS	300	WABCO ABS D-E
 Kerax	ABS	320	Bosch ABS 24
 Kerax	ABS	320	Bosch ABS I8
 Kerax	ABS	320	WABCO ABS D-E
 Kerax	ABS	340	Bosch ABS 24
 Kerax	ABS	340	Bosch ABS I8
 Kerax	ABS	340	WABCO ABS D-E
 Kerax	ABS	370	Bosch ABS 24
 Kerax	ABS	370	Bosch ABS I8
 Kerax	ABS	370	WABCO ABS D-E
 Kerax	ABS	385	Bosch ABS 24
 Kerax	ABS	385	Bosch ABS I8
 Kerax	ABS	385	WABCO ABS D-E
 Kerax	ABS	400	Bosch ABS 24
 Kerax	ABS	400	Bosch ABS I8
 Kerax	ABS	400	WABCO ABS D-E
 Kerax	ABS	420	Bosch ABS 24
 Kerax	ABS	420	Bosch ABS I8
 Kerax	ABS	420	WABCO ABS D-E

## Systems supported by ECReader (up to V4,90)

### TRUCKS




























### Renault Trucks

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Kerax	AUTOM. TRANSMISSI	260	ZF ASTRONIC
 Kerax	AUTOM. TRANSMISSI	270	ZF ASTRONIC
 Kerax	AUTOM. TRANSMISSI	300	ZF ASTRONIC
 Kerax	AUTOM. TRANSMISSI	320	ZF ASTRONIC
 Kerax	AUTOM. TRANSMISSI	340	ZF ASTRONIC
 Kerax	AUTOM. TRANSMISSI	370	ZF ASTRONIC
 Kerax	AUTOM. TRANSMISSI	385	ZF ASTRONIC
 Kerax	AUTOM. TRANSMISSI	400	ZF ASTRONIC
 Kerax	AUTOM. TRANSMISSI	420	ZF ASTRONIC
 Kerax	BRAKE POWER SUP	260	ZF Intarder
 Kerax	BRAKE POWER SUP	270	ZF Intarder
 Kerax	BRAKE POWER SUP	300	ZF Intarder
 Kerax	BRAKE POWER SUP	320	ZF Intarder
 Kerax	BRAKE POWER SUP	340	ZF Intarder
 Kerax	BRAKE POWER SUP	370	ZF Intarder
 Kerax	BRAKE POWER SUP	385	ZF Intarder
 Kerax	BRAKE POWER SUP	400	ZF Intarder
 Kerax	BRAKE POWER SUP	420	ZF Intarder
 Kerax	BRAKE SYS. MANAG	260	EBS
 Kerax	BRAKE SYS. MANAG	270	EBS
 Kerax	BRAKE SYS. MANAG	300	EBS
 Kerax	BRAKE SYS. MANAG	320	EBS
 Kerax	BRAKE SYS. MANAG	340	EBS
 Kerax	BRAKE SYS. MANAG	370	EBS
 Kerax	BRAKE SYS. MANAG	385	EBS
 Kerax	BRAKE SYS. MANAG	400	EBS
 Kerax	BRAKE SYS. MANAG	420	EBS

## Systems supported by ECReader (up to V4,90)

### TRUCKS




























### Renault Trucks

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Kerax	CHASSIS NETWORK	260	VECU 3 Body Computer Euro3
 Kerax	CHASSIS NETWORK	270	VECU 3 Body Computer Euro3
 Kerax	CHASSIS NETWORK	300	VECU 3 Body Computer Euro3
 Kerax	CHASSIS NETWORK	320	VECU 3 Body Computer Euro3
 Kerax	CHASSIS NETWORK	340	VECU 3 Body Computer Euro3
 Kerax	CHASSIS NETWORK	370	VECU 3 Body Computer Euro3
 Kerax	CHASSIS NETWORK	385	VECU 3 Body Computer Euro3
 Kerax	CHASSIS NETWORK	400	VECU 3 Body Computer Euro3
 Kerax	CHASSIS NETWORK	420	VECU 3 Body Computer Euro3
 Kerax	DASHBOARD	260	AFFI COMBISTRUM 2000
 Kerax	DASHBOARD	270	AFFI COMBISTRUM 2000
 Kerax	DASHBOARD	300	AFFI COMBISTRUM 2000
 Kerax	DASHBOARD	320	AFFI COMBISTRUM 2000
 Kerax	DASHBOARD	340	AFFI COMBISTRUM 2000
 Kerax	DASHBOARD	370	AFFI COMBISTRUM 2000
 Kerax	DASHBOARD	385	AFFI COMBISTRUM 2000
 Kerax	DASHBOARD	400	AFFI COMBISTRUM 2000
 Kerax	DASHBOARD	420	AFFI COMBISTRUM 2000
 Kerax	ENGINE MANAGEME	260	DENSO ITC
 Kerax	ENGINE MANAGEME	260	E-Tech 3
 Kerax	ENGINE MANAGEME	270	DENSO ITC
 Kerax	ENGINE MANAGEME	270	E-Tech 3
 Kerax	ENGINE MANAGEME	300	DENSO ITC
 Kerax	ENGINE MANAGEME	300	E-Tech 3
 Kerax	ENGINE MANAGEME	320	DENSO ITC
 Kerax	ENGINE MANAGEME	340	DENSO ITC
 Kerax	ENGINE MANAGEME	340	E-Tech 3

## Systems supported by ECUreader (up to V4,90)

### TRUCKS



























### Renault Trucks

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Kerax	ENGINE MANAGEME	370	DENSO ITC
 Kerax	ENGINE MANAGEME	370	E-Tech 3
 Kerax	ENGINE MANAGEME	385	DENSO ITC
 Kerax	ENGINE MANAGEME	385	E-Tech 3
 Kerax	ENGINE MANAGEME	400	DENSO ITC
 Kerax	ENGINE MANAGEME	400	E-Tech 3
 Kerax	ENGINE MANAGEME	420	DENSO ITC
 Kerax	ENGINE MANAGEME	420	E-Tech 3
 Kerax	SPEED LIMITER	260	ACTIA LIVASR
 Kerax	SPEED LIMITER	270	ACTIA LIVASR
 Kerax	SPEED LIMITER	300	ACTIA LIVASR
 Kerax	SPEED LIMITER	320	ACTIA LIVASR
 Kerax	SPEED LIMITER	340	ACTIA LIVASR
 Kerax	SPEED LIMITER	370	ACTIA LIVASR
 Kerax	SPEED LIMITER	385	ACTIA LIVASR
 Kerax	SPEED LIMITER	400	ACTIA LIVASR
 Kerax	SPEED LIMITER	420	ACTIA LIVASR
 Kerax	SUSPENSION CONTR	260	WABCO ECAS
 Kerax	SUSPENSION CONTR	260	WABCO ECAS JED
 Kerax	SUSPENSION CONTR	270	WABCO ECAS
 Kerax	SUSPENSION CONTR	270	WABCO ECAS JED
 Kerax	SUSPENSION CONTR	300	WABCO ECAS
 Kerax	SUSPENSION CONTR	300	WABCO ECAS JED
 Kerax	SUSPENSION CONTR	320	WABCO ECAS
 Kerax	SUSPENSION CONTR	320	WABCO ECAS JED
 Kerax	SUSPENSION CONTR	340	WABCO ECAS
 Kerax	SUSPENSION CONTR	340	WABCO ECAS JED

## Systems supported by ECUreader (up to V4,90)



























### TRUCKS

### Renault Trucks

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Kerax	SUSPENSION CONTR	370	WABCO ECAS
 Kerax	SUSPENSION CONTR	370	WABCO ECAS JED
 Kerax	SUSPENSION CONTR	385	WABCO ECAS
 Kerax	SUSPENSION CONTR	385	WABCO ECAS JED
 Kerax	SUSPENSION CONTR	400	WABCO ECAS
 Kerax	SUSPENSION CONTR	400	WABCO ECAS JED
 Kerax	SUSPENSION CONTR	420	WABCO ECAS
 Kerax	SUSPENSION CONTR	420	WABCO ECAS JED
 Kerax	ENGINE MANAGEME	180	dCi Euro 3
 Kerax	ENGINE MANAGEME	220	dCi Euro 3
 Kerax	ENGINE MANAGEME	260	dCi Euro 3
 Kerax	ENGINE MANAGEME	270	dCi Euro 3
 Kerax	ENGINE MANAGEME	300	dCi Euro 3
 Kerax	ENGINE MANAGEME	340	dCi Euro 3
 Kerax	ENGINE MANAGEME	370	dCi Euro 3
 Kerax	ENGINE MANAGEME	385	dCi Euro 3
 Kerax	ENGINE MANAGEME	400	dCi Euro 3
 Kerax	ENGINE MANAGEME	420	dCi Euro 3
 Magnum Dxi	BRAKE SYS. MANAG	460 (07-..)	Knorr EBS
 Magnum Dxi	BRAKE SYS. MANAG	500 (07-..)	Knorr EBS
 Magnum Dxi	DASHBOARD	460 (07-..)	Dashboard
 Magnum Dxi	DASHBOARD	500 (07-..)	Dashboard
 Magnum Dxi	ENGINE MANAGEME	460 (07-..)	EDC Euro 5
 Magnum Dxi	ENGINE MANAGEME	500 (07-..)	EDC Euro 5
 Magnum Dxi	ENGINE MANAGEME	460 (07-..)	
 Magnum Dxi	ENGINE MANAGEME	500 (07-..)	

## Systems supported by ECUREADER (up to V4,90)



























### TRUCKS Renault Trucks

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Magnum Dxi	IMMOBILIZER	460 (07-..)	
 Magnum Dxi	IMMOBILIZER	500 (07-..)	
 Magnum Dxi	SUSPENSION CONTR	460 (07-..)	Knorr
 Magnum Dxi	SUSPENSION CONTR	500 (07-..)	Knorr
 Magnum Dxi	BRAKE SYS. MANAG	460 (07-..)	Knorr EBS
 Magnum Dxi	BRAKE SYS. MANAG	500 (07-..)	Knorr EBS
 Magnum Dxi	DASHBOARD	460 (07-..)	Dashboard
 Magnum Dxi	DASHBOARD	500 (07-..)	Dashboard
 Magnum Dxi	ENGINE MANAGEME	460 (07-..)	EDC Euro 5
 Magnum Dxi	ENGINE MANAGEME	500 (07-..)	EDC Euro 5
 Magnum Dxi	ENGINE MANAGEME	460 (07-..)	
 Magnum Dxi	ENGINE MANAGEME	500 (07-..)	
 Magnum Dxi	IMMOBILIZER	460 (07-..)	
 Magnum Dxi	IMMOBILIZER	500 (07-..)	
 Magnum Dxi	SUSPENSION CONTR	460 (07-..)	Knorr
 Magnum Dxi	SUSPENSION CONTR	500 (07-..)	Knorr
 Magnum	ABS	440	Bosch ABS 24
 Magnum	ABS	440	Bosch ABS I8
 Magnum	ABS	440	WABCO ABS D-E
 Magnum	ABS	480	Bosch ABS 24
 Magnum	ABS	480	Bosch ABS I8
 Magnum	ABS	480	WABCO ABS D-E
 Magnum	AUTOM. TRANSMISSI	440	ZF ASTRONIC
 Magnum	AUTOM. TRANSMISSI	480	ZF ASTRONIC
 Magnum	BRAKE POWER SUP	440	ZF Intarder
 Magnum	BRAKE POWER SUP	480	ZF Intarder

## Systems supported by ECUreader (up to V4,90)

### TRUCKS



























### Renault Trucks

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Magnum	BRAKE SYS. MANAG	440	EBS
 Magnum	BRAKE SYS. MANAG	480	EBS
 Magnum	CHASSIS NETWORK	440	VECU 3 Body Computer Euro3
 Magnum	CHASSIS NETWORK	480	VECU 3 Body Computer Euro3
 Magnum	DASHBOARD	440	AFFI COMBISTRUM 2000
 Magnum	DASHBOARD	480	AFFI COMBISTRUM 2000
 Magnum	ENGINE MANAGEME	440	DENSO ITC
 Magnum	ENGINE MANAGEME	440	E-Tech 3
 Magnum	ENGINE MANAGEME	480	DENSO ITC
 Magnum	ENGINE MANAGEME	480	E-Tech 3
 Magnum	SPEED LIMITER	440	ACTIA LIVASR
 Magnum	SPEED LIMITER	480	ACTIA LIVASR
 Magnum	SUSPENSION CONTR	440	WABCO ECAS JED
 Magnum	SUSPENSION CONTR	480	WABCO ECAS
 Magnum	ABS	420	Bosch ABS 24
 Magnum	ABS	420	Bosch ABS I8
 Magnum	ABS	440	WABCO ABS D-E
 Magnum	ABS	480	Bosch ABS 24
 Magnum	ABS	480	Bosch ABS I8
 Magnum	ABS	480	WABCO ABS D-E
 Magnum	AUTOM. TRANSMISSI	440	ZF ASTRONIC
 Magnum	AUTOM. TRANSMISSI	480	ZF ASTRONIC
 Magnum	BRAKE POWER SUP	440	ZF Intarder
 Magnum	BRAKE POWER SUP	480	ZF Intarder
 Magnum	BRAKE SYS. MANAG	440	EBS
 Magnum	BRAKE SYS. MANAG	480	EBS

## Systems supported by ECUreader (up to V4,90)

### TRUCKS




























### Renault Trucks

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Magnum	CHASSIS NETWORK	440	VECU 3 Body Computer Euro3
 Magnum	CHASSIS NETWORK	480	VECU 3 Body Computer Euro3
 Magnum	DASHBOARD	440	AFFI COMBISTRUM 2000
 Magnum	DASHBOARD	480	AFFI COMBISTRUM 2000
 Magnum	ENGINE MANAGEME	420	DENSO ITC
 Magnum	ENGINE MANAGEME	440	dCi Euro 3
 Magnum	ENGINE MANAGEME	440	E-Tech 3
 Magnum	ENGINE MANAGEME	480	dCi Euro 3
 Magnum	ENGINE MANAGEME	480	DENSO ITC
 Magnum	ENGINE MANAGEME	480	E-Tech 3
 Magnum	SPEED LIMITER	440	ACTIA LIVASR
 Magnum	SPEED LIMITER	480	ACTIA LIVASR
 Magnum	SUSPENSION CONTR	440	WABCO ECAS
 Magnum	SUSPENSION CONTR	480	WABCO ECAS JED
 Maxter	ENGINE MANAGEME	300	DENSO ITC
 Maxter	ENGINE MANAGEME	340	DENSO ITC
 Maxter	ENGINE MANAGEME	385	DENSO ITC
 Maxter	ENGINE MANAGEME	400	DENSO ITC
 Midliner M	ENGINE MANAGEME	250	DENSO ITC
 Midlum	ABS	150	Bosch ABS 24
 Midlum	ABS	150	Bosch ABS I8
 Midlum	ABS	150	WABCO ABS D-E
 Midlum	ABS	180	Bosch ABS 24
 Midlum	ABS	180	Bosch ABS I8
 Midlum	ABS	180	WABCO ABS D-E
 Midlum	ABS	220	Bosch ABS 24

## Systems supported by ECUreader (up to V4,90)

### TRUCKS



























### Renault Trucks

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Midlum	ABS	220	Bosch ABS I8
 Midlum	ABS	220	WABCO ABS D-E
 Midlum	ABS	270	Bosch ABS 24
 Midlum	ABS	270	Bosch ABS I8
 Midlum	ABS	270	WABCO ABS D-E
 Midlum	AUTOM. TRANSMISSI	150	ZF ASTRONIC
 Midlum	AUTOM. TRANSMISSI	180	ZF ASTRONIC
 Midlum	AUTOM. TRANSMISSI	220	ZF ASTRONIC
 Midlum	AUTOM. TRANSMISSI	270	ZF ASTRONIC
 Midlum	BRAKE POWER SUP	150	ZF Intarder
 Midlum	BRAKE POWER SUP	180	ZF Intarder
 Midlum	BRAKE POWER SUP	220	ZF Intarder
 Midlum	BRAKE POWER SUP	270	ZF Intarder
 Midlum	BRAKE SYS. MANAG	150	EBS
 Midlum	BRAKE SYS. MANAG	180	EBS
 Midlum	BRAKE SYS. MANAG	220	EBS
 Midlum	BRAKE SYS. MANAG	270	EBS
 Midlum	CHASSIS NETWORK	150	VECU 3 Body Computer Euro3
 Midlum	CHASSIS NETWORK	180	VECU 3 Body Computer Euro3
 Midlum	CHASSIS NETWORK	220	VECU 3 Body Computer Euro3
 Midlum	CHASSIS NETWORK	270	VECU 3 Body Computer Euro3
 Midlum	DASHBOARD	150	AFFI COMBINSTRUM 2000
 Midlum	DASHBOARD	180	AFFI COMBINSTRUM 2000
 Midlum	DASHBOARD	220	AFFI COMBINSTRUM 2000
 Midlum	DASHBOARD	270	AFFI COMBINSTRUM 2000
 Midlum	ENGINE MANAGEME	150	DENSO ITC
 Midlum	ENGINE MANAGEME	150	E-Tech 3

## Systems supported by ECUreader (up to V4,90)

### TRUCKS



























### Renault Trucks

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Midlum	ENGINE MANAGEME	180	DENSO ITC
 Midlum	ENGINE MANAGEME	180	E-Tech 3
 Midlum	ENGINE MANAGEME	220	DENSO ITC
 Midlum	ENGINE MANAGEME	220	E-Tech 3
 Midlum	ENGINE MANAGEME	270	DENSO ITC
 Midlum	ENGINE MANAGEME	270	E-Tech 3
 Midlum	SPEED LIMITER	150	ACTIA LIVASR
 Midlum	SPEED LIMITER	180	ACTIA LIVASR
 Midlum	SPEED LIMITER	220	ACTIA LIVASR
 Midlum	SPEED LIMITER	270	ACTIA LIVASR
 Midlum	SUSPENSION CONTR	150	WABCO ECAS
 Midlum	SUSPENSION CONTR	150	Wabco ECAS JED
 Midlum	SUSPENSION CONTR	180	WABCO ECAS
 Midlum	SUSPENSION CONTR	180	Wabco ECAS JED
 Midlum	SUSPENSION CONTR	220	WABCO ECAS
 Midlum	SUSPENSION CONTR	220	Wabco ECAS JED
 Midlum	SUSPENSION CONTR	270	WABCO ECAS
 Midlum	SUSPENSION CONTR	270	Wabco ECAS JED
 Midlum	ENGINE MANAGEME	150	dCi Euro 3
 Premium Dxi	BRAKE SYS. MANAG	370 (07-..)	Knorr EBS
 Premium Dxi	BRAKE SYS. MANAG	410 (07-..)	Knorr EBS
 Premium Dxi	BRAKE SYS. MANAG	450 (07-..)	Knorr EBS
 Premium Dxi	DASHBOARD	370 (07-..)	Dashboard
 Premium Dxi	DASHBOARD	410 (07-..)	Dashboard
 Premium Dxi	DASHBOARD	450 (07-..)	Dashboard
 Premium Dxi	ENGINE MANAGEME	370 (07-..)	EDC Euro 5

## Systems supported by ECReader (up to V4,90)

### TRUCKS



























### Renault Trucks

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Premium Dxi	ENGINE MANAGEME	410 (07-..)	EDC Euro 5
 Premium Dxi	ENGINE MANAGEME	450 (07-..)	EDC Euro 5
 Premium Dxi	ENGINE MANAGEME	370 (07-..)	
 Premium Dxi	ENGINE MANAGEME	410 (07-..)	
 Premium Dxi	ENGINE MANAGEME	450 (07-..)	
 Premium Dxi	IMMOBILIZER	370 (07-..)	
 Premium Dxi	IMMOBILIZER	410 (07-..)	
 Premium Dxi	IMMOBILIZER	450 (07-..)	
 Premium Dxi	SUSPENSION CONTR	370 (07-..)	Knorr
 Premium Dxi	SUSPENSION CONTR	410 (07-..)	Knorr
 Premium Dxi	SUSPENSION CONTR	450 (07-..)	Knorr
 Premium Dxi	BRAKE SYS. MANAG	370 (07-..)	Knorr EBS
 Premium Dxi	BRAKE SYS. MANAG	410 (07-..)	Knorr EBS
 Premium Dxi	BRAKE SYS. MANAG	450 (07-..)	Knorr EBS
 Premium Dxi	DASHBOARD	370 (07-..)	Dashboard
 Premium Dxi	DASHBOARD	410 (07-..)	Dashboard
 Premium Dxi	DASHBOARD	450 (07-..)	Dashboard
 Premium Dxi	ENGINE MANAGEME	370 (07-..)	EDC Euro 5
 Premium Dxi	ENGINE MANAGEME	410 (07-..)	EDC Euro 5
 Premium Dxi	ENGINE MANAGEME	450 (07-..)	EDC Euro 5
 Premium Dxi	ENGINE MANAGEME	370 (07-..)	
 Premium Dxi	ENGINE MANAGEME	410 (07-..)	
 Premium Dxi	ENGINE MANAGEME	450 (07-..)	
 Premium Dxi	IMMOBILIZER	370 (07-..)	
 Premium Dxi	IMMOBILIZER	410 (07-..)	
 Premium Dxi	IMMOBILIZER	450 (07-..)	

## Systems supported by ECUreader (up to V4,90)

### TRUCKS




























### Renault Trucks

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Premium Dxi	SUSPENSION CONTR	370 (07-..)	Knorr
 Premium Dxi	SUSPENSION CONTR	410 (07-..)	Knorr
 Premium Dxi	SUSPENSION CONTR	450 (07-..)	Knorr
 Premium	ABS	220	BOSCH ABS 24
 Premium	ABS	220	BOSCH ABS I8
 Premium	ABS	220	WABCO ABS D-E
 Premium	ABS	260	BOSCH ABS 24
 Premium	ABS	260	BOSCH ABS I8
 Premium	ABS	260	WABCO ABS D-E
 Premium	ABS	270	BOSCH ABS 24
 Premium	ABS	270	BOSCH ABS I8
 Premium	ABS	270	WABCO ABS D-E
 Premium	ABS	300	BOSCH ABS 24
 Premium	ABS	300	BOSCH ABS I8
 Premium	ABS	300	WABCO ABS D-E
 Premium	ABS	320	BOSCH ABS 24
 Premium	ABS	320	BOSCH ABS I8
 Premium	ABS	320	WABCO ABS D-E
 Premium	ABS	340	BOSCH ABS 24
 Premium	ABS	340	BOSCH ABS I8
 Premium	ABS	340	WABCO ABS D-E
 Premium	ABS	370	BOSCH ABS 24
 Premium	ABS	370	BOSCH ABS I8
 Premium	ABS	370	WABCO ABS D-E
 Premium	ABS	385	BOSCH ABS 24
 Premium	ABS	385	BOSCH ABS I8

## Systems supported by ECUREADER (up to V4,90)

### TRUCKS




























### Renault Trucks

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Premium	ABS	400	BOSCH ABS 24
 Premium	ABS	400	BOSCH ABS I8
 Premium	ABS	400	WABCO ABS D-E
 Premium	ABS	420	BOSCH ABS 24
 Premium	ABS	420	BOSCH ABS I8
 Premium	ABS	420	WABCO ABS D-E
 Premium	AUTOM. TRANSMISSI	220	ZF ASTRONIC
 Premium	AUTOM. TRANSMISSI	260	ZF ASTRONIC
 Premium	AUTOM. TRANSMISSI	270	ZF ASTRONIC
 Premium	AUTOM. TRANSMISSI	300	ZF ASTRONIC
 Premium	AUTOM. TRANSMISSI	320	ZF ASTRONIC
 Premium	AUTOM. TRANSMISSI	340	ZF ASTRONIC
 Premium	AUTOM. TRANSMISSI	370	ZF ASTRONIC
 Premium	AUTOM. TRANSMISSI	385	ZF ASTRONIC
 Premium	AUTOM. TRANSMISSI	400	ZF ASTRONIC
 Premium	AUTOM. TRANSMISSI	420	ZF ASTRONIC
 Premium	BRAKE POWER SUP	220	ZF Intarder
 Premium	BRAKE POWER SUP	260	ZF Intarder
 Premium	BRAKE POWER SUP	270	ZF Intarder
 Premium	BRAKE POWER SUP	300	ZF Intarder
 Premium	BRAKE POWER SUP	320	ZF Intarder
 Premium	BRAKE POWER SUP	340	ZF Intarder
 Premium	BRAKE POWER SUP	370	ZF Intarder
 Premium	BRAKE POWER SUP	385	ZF Intarder
 Premium	BRAKE POWER SUP	400	ZF Intarder
 Premium	BRAKE POWER SUP	420	ZF Intarder
 Premium	BRAKE SYS. MANAG	220	EBS

## Systems supported by ECReader (up to V4,90)

























### TRUCKS

### Renault Trucks

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Premium	BRAKE SYS. MANAG	260	EBS
 Premium	BRAKE SYS. MANAG	270	EBS
 Premium	BRAKE SYS. MANAG	300	EBS
 Premium	BRAKE SYS. MANAG	320	EBS
 Premium	BRAKE SYS. MANAG	340	EBS
 Premium	BRAKE SYS. MANAG	370	EBS
 Premium	BRAKE SYS. MANAG	385	EBS
 Premium	BRAKE SYS. MANAG	400	EBS
 Premium	BRAKE SYS. MANAG	420	EBS
 Premium	CHASSIS NETWORK	220	VECU 3 Body Computer Euro3
 Premium	CHASSIS NETWORK	260	VECU 3 Body Computer Euro3
 Premium	CHASSIS NETWORK	270	VECU 3 Body Computer Euro3
 Premium	CHASSIS NETWORK	300	VECU 3 Body Computer Euro3
 Premium	CHASSIS NETWORK	320	VECU 3 Body Computer Euro3
 Premium	CHASSIS NETWORK	340	VECU 3 Body Computer Euro3
 Premium	CHASSIS NETWORK	370	VECU 3 Body Computer Euro3
 Premium	CHASSIS NETWORK	385	VECU 3 Body Computer Euro3
 Premium	CHASSIS NETWORK	400	VECU 3 Body Computer Euro3
 Premium	CHASSIS NETWORK	420	VECU 3 Body Computer Euro3
 Premium	DASHBOARD	220	AFFI COMBINSTRUM 2000
 Premium	DASHBOARD	260	AFFI COMBINSTRUM 2000
 Premium	DASHBOARD	270	AFFI COMBINSTRUM 2000
 Premium	DASHBOARD	300	AFFI COMBINSTRUM 2000
 Premium	DASHBOARD	320	AFFI COMBINSTRUM 2000
 Premium	DASHBOARD	340	AFFI COMBINSTRUM 2000
 Premium	DASHBOARD	370	AFFI COMBINSTRUM 2000
 Premium	DASHBOARD	385	AFFI COMBINSTRUM 2000

## Systems supported by ECUreader (up to V4,90)




























### TRUCKS Renault Trucks

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Premium	DASHBOARD	400	AFFI COMBINSTRUM 2000
 Premium	DASHBOARD	420	AFFI COMBINSTRUM 2000
 Premium	ENGINE MANAGEME	220	dCi Euro 3
 Premium	ENGINE MANAGEME	220	DENSO ITC
 Premium	ENGINE MANAGEME	220	E-Tech 3
 Premium	ENGINE MANAGEME	250	dCi Euro 3
 Premium	ENGINE MANAGEME	250	DENSO ITC
 Premium	ENGINE MANAGEME	250	E-Tech 3
 Premium	ENGINE MANAGEME	270	dCi Euro 3
 Premium	ENGINE MANAGEME	270	DENSO ITC
 Premium	ENGINE MANAGEME	270	E-Tech 3
 Premium	ENGINE MANAGEME	300	dCi Euro 3
 Premium	ENGINE MANAGEME	300	DENSO ITC
 Premium	ENGINE MANAGEME	300	E-Tech 3
 Premium	ENGINE MANAGEME	320	dCi Euro 3
 Premium	ENGINE MANAGEME	320	DENSO ITC
 Premium	ENGINE MANAGEME	320	E-Tech 3
 Premium	ENGINE MANAGEME	340	dCi Euro 3
 Premium	ENGINE MANAGEME	340	DENSO ITC
 Premium	ENGINE MANAGEME	340	E-Tech 3
 Premium	ENGINE MANAGEME	370	dCi Euro 3
 Premium	ENGINE MANAGEME	370	DENSO ITC
 Premium	ENGINE MANAGEME	370	E-Tech 3
 Premium	ENGINE MANAGEME	385	DENSO ITC
 Premium	ENGINE MANAGEME	400	dCi Euro 3
 Premium	ENGINE MANAGEME	400	DENSO ITC
 Premium	ENGINE MANAGEME	400	E-Tech 3

## Systems supported by ECUreader (up to V4,90)

### TRUCKS







### Renault Trucks

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Premium	ENGINE MANAGEME	420	dCi Euro 3
 Premium	ENGINE MANAGEME	420	DENSO ITC
 Premium	ENGINE MANAGEME	420	E-Tech 3
 Premium	SPEED LIMITER	220	ACTIA LIVASR
 Premium	SPEED LIMITER	260	ACTIA LIVASR
 Premium	SPEED LIMITER	270	ACTIA LIVASR
 Premium	SPEED LIMITER	300	ACTIA LIVASR
 Premium	SPEED LIMITER	320	ACTIA LIVASR
 Premium	SPEED LIMITER	340	ACTIA LIVASR
 Premium	SPEED LIMITER	370	ACTIA LIVASR
 Premium	SPEED LIMITER	385	ACTIA LIVASR
 Premium	SPEED LIMITER	400	ACTIA LIVASR
 Premium	SPEED LIMITER	420	ACTIA LIVASR
 Premium	SUSPENSION CONTR	220	WABCO ECAS
 Premium	SUSPENSION CONTR	220	WABCO ECAS JED
 Premium	SUSPENSION CONTR	260	WABCO ECAS
 Premium	SUSPENSION CONTR	260	WABCO ECAS JED
 Premium	SUSPENSION CONTR	270	WABCO ECAS
 Premium	SUSPENSION CONTR	270	WABCO ECAS JED
 Premium	SUSPENSION CONTR	300	WABCO ECAS
 Premium	SUSPENSION CONTR	300	WABCO ECAS JED
 Premium	SUSPENSION CONTR	320	WABCO ECAS
 Premium	SUSPENSION CONTR	320	WABCO ECAS JED
 Premium	SUSPENSION CONTR	340	WABCO ECAS
 Premium	SUSPENSION CONTR	340	WABCO ECAS JED
 Premium	SUSPENSION CONTR	370	WABCO ECAS
 Premium	SUSPENSION CONTR	370	WABCO ECAS JED

## Systems supported by ECUreader (up to V4,90)

### TRUCKS



### Renault Trucks

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Premium	SUSPENSION CONTR	385	WABCO ECAS
 Premium	SUSPENSION CONTR	385	WABCO ECAS JED
 Premium	SUSPENSION CONTR	400	WABCO ECAS
 Premium	SUSPENSION CONTR	400	WABCO ECAS JED
 Premium	SUSPENSION CONTR	420	WABCO ECAS
 Premium	SUSPENSION CONTR	420	WABCO ECAS JED

## Systems supported by ECUREADER (up to V4,90)

### TRUCKS



### Reparafrota

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Trailers	BRAKE SYS. MANAG	Trailers	Wabco Trailer EBS
 Trailers	BRAKE SYS. MANAG	Trailers	Wabco Trailer VCS II

## Systems supported by ECUREADER (up to V4,90)

### TRUCKS



























### Ros Roca Index

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Trailers	BRAKE SYS. MANAG	Trailers	Wabco Trailer EBS
 Trailers	BRAKE SYS. MANAG	Trailers	Wabco Trailer VCS II

## Systems supported by ECUreader (up to V4,90)

### TRUCKS




























Scania

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 L-series	ABS	L124-420 (...-99)	BOSCH ABS I8
 L-series	ABS	L144-530 (...-99)	BOSCH ABS I8
 L-series	ABS	L164-480 (...-99)	BOSCH ABS I8
 P-series	ABS	P113-400 (...-99)	BOSCH ABS I8
 P-series	ABS	P114-340 (...-99)	BOSCH ABS I8
 P-series	ABS	P114-380 (...-99)	BOSCH ABS I8
 P-series	ABS	P124-420 (...-99)	BOSCH ABS I8
 P-series	ABS	P164-580 (...-99)	BOSCH ABS I8
 P-series	ABS	P94-230 (...-99)	BOSCH ABS I8
 P-series	ABS	P94-260 (...-99)	BOSCH ABS I8
 P-series	ABS	P94-300 (...-99)	BOSCH ABS I8
 P-series	AIR BRAKE MANAGE	P230 (07-08)	VIS
 P-series	AIR BRAKE MANAGE	P270 (07-08)	VIS
 P-series	AIR BRAKE MANAGE	P310 (07-08)	VIS
 P-series	AIR BRAKE MANAGE	P340 (07-08)	VIS
 P-series	AIR BRAKE MANAGE	P380 (07-08)	VIS
 P-series	AIR BRAKE MANAGE	P420 Euro 4 (07-08)	VIS
 P-series	AIR BRAKE MANAGE	P420 Euro 5 (08-..)	VIS
 P-series	AIRBAG	P230 (07-08)	CSS
 P-series	AIRBAG	P270 (07-08)	CSS
 P-series	AIRBAG	P310 (07-08)	CSS
 P-series	AIRBAG	P340 (07-08)	CSS
 P-series	AIRBAG	P380 (07-08)	CSS
 P-series	AIRBAG	P420 Euro 4 (07-08)	CSS
 P-series	AIRBAG	P420 Euro 5 (08-..)	CSS
 P-series	ANTITHEFT	P230 (07-08)	LAS

## Systems supported by ECReader (up to V4,90)

### TRUCKS

Scania

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 P-series	ANTITHEFT	P270 (07-08)	LAS
 P-series	ANTITHEFT	P310 (07-08)	LAS
 P-series	ANTITHEFT	P340 (07-08)	LAS
 P-series	ANTITHEFT	P380 (07-08)	LAS
 P-series	ANTITHEFT	P420 Euro 4 (07-08)	LAS
 P-series	ANTITHEFT	P420 Euro 5 (08-..)	LAS
 P-series	AUTOM. TRANSMISSI	P230 (07-08)	GMS Opticruise
 P-series	AUTOM. TRANSMISSI	P270 (07-08)	GMS Opticruise
 P-series	AUTOM. TRANSMISSI	P310 (07-08)	GMS Opticruise
 P-series	AUTOM. TRANSMISSI	P340 (07-08)	GMS Opticruise
 P-series	AUTOM. TRANSMISSI	P380 (07-08)	GMS Opticruise
 P-series	AUTOM. TRANSMISSI	P420 Euro 4 (07-08)	GMS Opticruise
 P-series	AUTOM. TRANSMISSI	P420 Euro 5 (08-..)	GMS Opticruise
 P-series	BRAKE SYS. MANAG	P230 (07-08)	Brake management system
 P-series	BRAKE SYS. MANAG	P270 (07-08)	Brake management system
 P-series	BRAKE SYS. MANAG	P310 (07-08)	Brake management system
 P-series	BRAKE SYS. MANAG	P340 (07-08)	Brake management system
 P-series	BRAKE SYS. MANAG	P380 (07-08)	Brake management system
 P-series	BRAKE SYS. MANAG	P420 Euro 4 (07-08)	Brake management system
 P-series	BRAKE SYS. MANAG	P420 Euro 5 (08-..)	Brake management system
 P-series	CHASSIS NETWORK	P230 (07-08)	Body Computer
 P-series	CHASSIS NETWORK	P270 (07-08)	Body Computer
 P-series	CHASSIS NETWORK	P310 (07-08)	Body Computer
 P-series	CHASSIS NETWORK	P340 (07-08)	Body Computer
 P-series	CHASSIS NETWORK	P380 (07-08)	Body Computer
 P-series	CHASSIS NETWORK	P420 Euro 4 (07-08)	Body Computer
 P-series	CHASSIS NETWORK	P420 Euro 5 (08-..)	Body Computer

## Systems supported by ECUREADER (up to V4,90)

### TRUCKS



























Scania

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 P-series	CLIMA	P230 (07-08)	CCS
 P-series	CLIMA	P270 (07-08)	CCS
 P-series	CLIMA	P310 (07-08)	CCS
 P-series	CLIMA	P340 (07-08)	CCS
 P-series	CLIMA	P380 (07-08)	CCS
 P-series	CLIMA	P420 Euro 4 (07-08)	CCS
 P-series	CLIMA	P420 Euro 5 (08-..)	CCS
 P-series	DASHBOARD	P230 (07-08)	Dashboard
 P-series	DASHBOARD	P270 (07-08)	Dashboard
 P-series	DASHBOARD	P310 (07-08)	Dashboard
 P-series	DASHBOARD	P340 (07-08)	Dashboard
 P-series	DASHBOARD	P380 (07-08)	Dashboard
 P-series	DASHBOARD	P420 Euro 4 (07-08)	Dashboard
 P-series	DASHBOARD	P420 Euro 5 (08-..)	Dashboard
 P-series	ENGINE MANAGEME	P230 (07-08)	EMS
 P-series	ENGINE MANAGEME	P270 (07-08)	EMS
 P-series	ENGINE MANAGEME	P310 (07-08)	EMS
 P-series	ENGINE MANAGEME	P340 (07-08)	EMS
 P-series	ENGINE MANAGEME	P380 (07-08)	EMS
 P-series	ENGINE MANAGEME	P420 Euro 4 (07-08)	EMS
 P-series	ENGINE MANAGEME	P420 Euro 5 (08-..)	EMS
 P-series	HEADLIGHT LEVEL	P230 (07-08)	VIS
 P-series	HEADLIGHT LEVEL	P270 (07-08)	VIS
 P-series	HEADLIGHT LEVEL	P310 (07-08)	VIS
 P-series	HEADLIGHT LEVEL	P340 (07-08)	VIS
 P-series	HEADLIGHT LEVEL	P380 (07-08)	VIS
 P-series	HEADLIGHT LEVEL	P420 Euro 4 (07-08)	VIS

## Systems supported by ECReader (up to V4,90)

### TRUCKS




























Scania

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 P-series	HEADLIGHT LEVEL	P420 Euro 5 (08-..)	VIS
 P-series	SUSPENSION CONTR	P230 (07-08)	SMS ECAS
 P-series	SUSPENSION CONTR	P270 (07-08)	SMS ECAS
 P-series	SUSPENSION CONTR	P310 (07-08)	SMS ECAS
 P-series	SUSPENSION CONTR	P340 (07-08)	SMS ECAS
 P-series	SUSPENSION CONTR	P380 (07-08)	SMS ECAS
 P-series	SUSPENSION CONTR	P420 Euro 4 (07-08)	SMS ECAS
 P-series	SUSPENSION CONTR	P420 Euro 5 (08-..)	SMS ECAS
 P-series	AIR BRAKE MANAGE	P230 (07-08)	VIS
 P-series	AIR BRAKE MANAGE	P270 (07-08)	VIS
 P-series	AIR BRAKE MANAGE	P310 (07-08)	VIS
 P-series	AIR BRAKE MANAGE	P340 (07-08)	VIS
 P-series	AIR BRAKE MANAGE	P380 (07-08)	VIS
 P-series	AIR BRAKE MANAGE	P420 Euro 4 (07-08)	VIS
 P-series	AIR BRAKE MANAGE	P420 Euro 5 (08-..)	VIS
 P-series	AIRBAG	P230 (07-08)	CSS
 P-series	AIRBAG	P270 (07-08)	CSS
 P-series	AIRBAG	P310 (07-08)	CSS
 P-series	AIRBAG	P340 (07-08)	CSS
 P-series	AIRBAG	P380 (07-08)	CSS
 P-series	AIRBAG	P420 Euro 4 (07-08)	CSS
 P-series	AIRBAG	P420 Euro 5 (08-..)	CSS
 P-series	ANTITHEFT	P230 (07-08)	LAS
 P-series	ANTITHEFT	P270 (07-08)	LAS
 P-series	ANTITHEFT	P310 (07-08)	LAS
 P-series	ANTITHEFT	P340 (07-08)	LAS

## Systems supported by ECReader (up to V4,90)

### TRUCKS




























Scania

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 P-series	ANTITHEFT	P380 (07-08)	LAS
 P-series	ANTITHEFT	P420 Euro 4 (07-08)	LAS
 P-series	ANTITHEFT	P420 Euro 5 (08-..)	LAS
 P-series	AUTOM. TRANSMISSI	P230 (07-08)	GMS Opticruise
 P-series	AUTOM. TRANSMISSI	P270 (07-08)	GMS Opticruise
 P-series	AUTOM. TRANSMISSI	P310 (07-08)	GMS Opticruise
 P-series	AUTOM. TRANSMISSI	P340 (07-08)	GMS Opticruise
 P-series	AUTOM. TRANSMISSI	P380 (07-08)	GMS Opticruise
 P-series	AUTOM. TRANSMISSI	P420 Euro 4 (07-08)	GMS Opticruise
 P-series	AUTOM. TRANSMISSI	P420 Euro 5 (08-..)	GMS Opticruise
 P-series	BRAKE SYS. MANAG	P230 (07-08)	Brake management system
 P-series	BRAKE SYS. MANAG	P270 (07-08)	Brake management system
 P-series	BRAKE SYS. MANAG	P310 (07-08)	Brake management system
 P-series	BRAKE SYS. MANAG	P340 (07-08)	Brake management system
 P-series	BRAKE SYS. MANAG	P380 (07-08)	Brake management system
 P-series	BRAKE SYS. MANAG	P420 Euro 4 (07-08)	Brake management system
 P-series	BRAKE SYS. MANAG	P420 Euro 5 (08-..)	Brake management system
 P-series	CHASSIS NETWORK	P230 (07-08)	Body Computer
 P-series	CHASSIS NETWORK	P270 (07-08)	Body Computer
 P-series	CHASSIS NETWORK	P310 (07-08)	Body Computer
 P-series	CHASSIS NETWORK	P340 (07-08)	Body Computer
 P-series	CHASSIS NETWORK	P380 (07-08)	Body Computer
 P-series	CHASSIS NETWORK	P420 Euro 4 (07-08)	Body Computer
 P-series	CHASSIS NETWORK	P420 Euro 5 (08-..)	Body Computer
 P-series	CLIMA	P230 (07-08)	CCS
 P-series	CLIMA	P270 (07-08)	CCS
 P-series	CLIMA	P310 (07-08)	CCS

## Systems supported by ECUreader (up to V4,90)

### TRUCKS



























Scania

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 P-series	CLIMA	P340 (07-08)	CCS
 P-series	CLIMA	P380 (07-08)	CCS
 P-series	CLIMA	P420 Euro 4 (07-08)	CCS
 P-series	CLIMA	P420 Euro 5 (08-..)	CCS
 P-series	DASHBOARD	P230 (07-08)	Dashboard
 P-series	DASHBOARD	P270 (07-08)	Dashboard
 P-series	DASHBOARD	P310 (07-08)	Dashboard
 P-series	DASHBOARD	P340 (07-08)	Dashboard
 P-series	DASHBOARD	P380 (07-08)	Dashboard
 P-series	DASHBOARD	P420 Euro 4 (07-08)	Dashboard
 P-series	DASHBOARD	P420 Euro 5 (08-..)	Dashboard
 P-series	ENGINE MANAGEME	P113-400 (92-97)	BOSCH EDC M7
 P-series	ENGINE MANAGEME	P114-340 (96-99)	BOSCH EDC
 P-series	ENGINE MANAGEME	P114-380 (96-99)	BOSCH EDC
 P-series	ENGINE MANAGEME	P124-420 (96-99)	BOSCH EDC
 P-series	ENGINE MANAGEME	P230 (07-08)	EMS
 P-series	ENGINE MANAGEME	P270 (07-08)	EMS
 P-series	ENGINE MANAGEME	P310 (07-08)	EMS
 P-series	ENGINE MANAGEME	P340 (07-08)	EMS
 P-series	ENGINE MANAGEME	P380 (07-08)	EMS
 P-series	ENGINE MANAGEME	P420 Euro 4 (07-08)	EMS
 P-series	ENGINE MANAGEME	P420 Euro 5 (08-..)	EMS
 P-series	HEADLIGHT LEVEL	P230 (07-08)	VIS
 P-series	HEADLIGHT LEVEL	P270 (07-08)	VIS
 P-series	HEADLIGHT LEVEL	P310 (07-08)	VIS
 P-series	HEADLIGHT LEVEL	P340 (07-08)	VIS
 P-series	HEADLIGHT LEVEL	P380 (07-08)	VIS

## Systems supported by ECUreader (up to V4,90)

### TRUCKS




























Scania

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 P-series	HEADLIGHT LEVEL	P420 Euro 4 (07-08)	VIS
 P-series	HEADLIGHT LEVEL	P420 Euro 5 (08-..)	VIS
 P-series	SUSPENSION CONTR	P230 (07-08)	SMS ECAS
 P-series	SUSPENSION CONTR	P270 (07-08)	SMS ECAS
 P-series	SUSPENSION CONTR	P310 (07-08)	SMS ECAS
 P-series	SUSPENSION CONTR	P340 (07-08)	SMS ECAS
 P-series	SUSPENSION CONTR	P380 (07-08)	SMS ECAS
 P-series	SUSPENSION CONTR	P420 Euro 4 (07-08)	SMS ECAS
 P-series	SUSPENSION CONTR	P420 Euro 5 (08-..)	SMS ECAS
 R-series	ABS	R113-380 (...-99)	BOSCH ABS I8
 R-series	AIR BRAKE MANAGE	R230 (07-08)	VIS
 R-series	AIR BRAKE MANAGE	R270 (07-08)	VIS
 R-series	AIR BRAKE MANAGE	R310 (07-08)	VIS
 R-series	AIR BRAKE MANAGE	R340 (07-08)	VIS
 R-series	AIR BRAKE MANAGE	R380 (07-08)	VIS
 R-series	AIR BRAKE MANAGE	R420 Euro 4 (07-08)	VIS
 R-series	AIR BRAKE MANAGE	R420 Euro 5 (08-..)	VIS
 R-series	AIR BRAKE MANAGE	R470 (07-08)	VIS
 R-series	AIR BRAKE MANAGE	R500 (07-08)	VIS
 R-series	AIR BRAKE MANAGE	R560 (07-08)	VIS
 R-series	AIR BRAKE MANAGE	R580 (07-08)	VIS
 R-series	AIR BRAKE MANAGE	R620 (07-08)	VIS
 R-series	AIRBAG	R230 (07-08)	CSS
 R-series	AIRBAG	R270 (07-08)	CSS
 R-series	AIRBAG	R310 (07-08)	CSS
 R-series	AIRBAG	R340 (07-08)	CSS

## Systems supported by ECReader (up to V4,90)

### TRUCKS




























Scania

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 R-series	AIRBAG	R380 (07-08)	CSS
 R-series	AIRBAG	R420 Euro 4 (07-08)	CSS
 R-series	AIRBAG	R420 Euro 5 (08-..)	CSS
 R-series	AIRBAG	R470 (07-08)	CSS
 R-series	AIRBAG	R500 (07-08)	CSS
 R-series	AIRBAG	R560 (07-08)	CSS
 R-series	AIRBAG	R580 (07-08)	CSS
 R-series	AIRBAG	R620 (07-08)	CSS
 R-series	ANTITHEFT	R230 (07-08)	LAS
 R-series	ANTITHEFT	R270 (07-08)	LAS
 R-series	ANTITHEFT	R310 (07-08)	LAS
 R-series	ANTITHEFT	R340 (07-08)	LAS
 R-series	ANTITHEFT	R380 (07-08)	LAS
 R-series	ANTITHEFT	R420 Euro 4 (07-08)	LAS
 R-series	ANTITHEFT	R420 Euro 5 (08-..)	LAS
 R-series	ANTITHEFT	R470 (07-08)	LAS
 R-series	ANTITHEFT	R500 (07-08)	LAS
 R-series	ANTITHEFT	R560 (07-08)	LAS
 R-series	ANTITHEFT	R580 (07-08)	LAS
 R-series	ANTITHEFT	R620 (07-08)	LAS
 R-series	AUTOM. TRANSMISSI	R230 (07-08)	GMS Opticruise
 R-series	AUTOM. TRANSMISSI	R270 (07-08)	GMS Opticruise
 R-series	AUTOM. TRANSMISSI	R310 (07-08)	GMS Opticruise
 R-series	AUTOM. TRANSMISSI	R340 (07-08)	GMS Opticruise
 R-series	AUTOM. TRANSMISSI	R380 (07-08)	GMS Opticruise
 R-series	AUTOM. TRANSMISSI	R420 Euro 4 (07-08)	GMS Opticruise
 R-series	AUTOM. TRANSMISSI	R420 Euro 5 (08-..)	GMS Opticruise

## Systems supported by ECUreader (up to V4,90)

### TRUCKS




























Scania

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 R-series	AUTOM. TRANSMISSI	R470 (07-08)	GMS Opticruise
 R-series	AUTOM. TRANSMISSI	R500 (07-08)	GMS Opticruise
 R-series	AUTOM. TRANSMISSI	R560 (07-08)	GMS Opticruise
 R-series	AUTOM. TRANSMISSI	R580 (07-08)	GMS Opticruise
 R-series	AUTOM. TRANSMISSI	R620 (07-08)	GMS Opticruise
 R-series	BRAKE SYS. MANAG	R230 (07-08)	Brake management system
 R-series	BRAKE SYS. MANAG	R270 (07-08)	Brake management system
 R-series	BRAKE SYS. MANAG	R310 (07-08)	Brake management system
 R-series	BRAKE SYS. MANAG	R340 (07-08)	Brake management system
 R-series	BRAKE SYS. MANAG	R380 (07-08)	Brake management system
 R-series	BRAKE SYS. MANAG	R420 Euro 4 (07-08)	Brake management system
 R-series	BRAKE SYS. MANAG	R420 Euro 5 (08-..)	Brake management system
 R-series	BRAKE SYS. MANAG	R470 (07-08)	Brake management system
 R-series	BRAKE SYS. MANAG	R500 (07-08)	Brake management system
 R-series	BRAKE SYS. MANAG	R560 (07-08)	Brake management system
 R-series	BRAKE SYS. MANAG	R580 (07-08)	Brake management system
 R-series	BRAKE SYS. MANAG	R620 (07-08)	Brake management system
 R-series	CHASSIS NETWORK	R230 (07-08)	Body Computer
 R-series	CHASSIS NETWORK	R270 (07-08)	Body Computer
 R-series	CHASSIS NETWORK	R310 (07-08)	Body Computer
 R-series	CHASSIS NETWORK	R340 (07-08)	Body Computer
 R-series	CHASSIS NETWORK	R380 (07-08)	Body Computer
 R-series	CHASSIS NETWORK	R420 Euro 4 (07-08)	Body Computer
 R-series	CHASSIS NETWORK	R420 Euro 5 (08-..)	Body Computer
 R-series	CHASSIS NETWORK	R470 (07-08)	Body Computer
 R-series	CHASSIS NETWORK	R500 (07-08)	Body Computer
 R-series	CHASSIS NETWORK	R560 (07-08)	Body Computer

## Systems supported by ECUreader (up to V4,90)

### TRUCKS

Scania

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 R-series	CHASSIS NETWORK	R580 (07-08)	Body Computer
 R-series	CHASSIS NETWORK	R620 (07-08)	Body Computer
 R-series	CLIMA	R230 (07-08)	CCS
 R-series	CLIMA	R270 (07-08)	CCS
 R-series	CLIMA	R310 (07-08)	CCS
 R-series	CLIMA	R340 (07-08)	CCS
 R-series	CLIMA	R380 (07-08)	CCS
 R-series	CLIMA	R420 Euro 4 (07-08)	CCS
 R-series	CLIMA	R420 Euro 5 (08-..)	CCS
 R-series	CLIMA	R470 (07-08)	CCS
 R-series	CLIMA	R500 (07-08)	CCS
 R-series	CLIMA	R560 (07-08)	CCS
 R-series	CLIMA	R580 (07-08)	CCS
 R-series	CLIMA	R620 (07-08)	CCS
 R-series	DASHBOARD	R230 (07-08)	Dashboard
 R-series	DASHBOARD	R270 (07-08)	Dashboard
 R-series	DASHBOARD	R310 (07-08)	Dashboard
 R-series	DASHBOARD	R340 (07-08)	Dashboard
 R-series	DASHBOARD	R380 (07-08)	Dashboard
 R-series	DASHBOARD	R420 Euro 4 (07-08)	Dashboard
 R-series	DASHBOARD	R420 Euro 5 (08-..)	Dashboard
 R-series	DASHBOARD	R470 (07-08)	Dashboard
 R-series	DASHBOARD	R500 (07-08)	Dashboard
 R-series	DASHBOARD	R560 (07-08)	Dashboard
 R-series	DASHBOARD	R580 (07-08)	Dashboard
 R-series	DASHBOARD	R620 (07-08)	Dashboard
 R-series	ENGINE MANAGEME	R230 (07-08)	EMS

## Systems supported by ECUreader (up to V4,90)

### TRUCKS



























Scania

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 R-series	ENGINE MANAGEME	R270 (07-08)	EMS
 R-series	ENGINE MANAGEME	R310 (07-08)	EMS
 R-series	ENGINE MANAGEME	R340 (07-08)	EMS
 R-series	ENGINE MANAGEME	R380 (07-08)	EMS
 R-series	ENGINE MANAGEME	R420 Euro 4 (07-08)	EMS
 R-series	ENGINE MANAGEME	R420 Euro 5 (08-..)	EMS
 R-series	ENGINE MANAGEME	R470 (07-08)	EMS
 R-series	ENGINE MANAGEME	R500 (07-08)	EMS
 R-series	ENGINE MANAGEME	R560 (07-08)	EMS
 R-series	ENGINE MANAGEME	R580 (07-08)	EMS
 R-series	ENGINE MANAGEME	R620 (07-08)	EMS
 R-series	HEADLIGHT LEVEL	R230 (07-08)	VIS
 R-series	HEADLIGHT LEVEL	R270 (07-08)	VIS
 R-series	HEADLIGHT LEVEL	R310 (07-08)	VIS
 R-series	HEADLIGHT LEVEL	R340 (07-08)	VIS
 R-series	HEADLIGHT LEVEL	R380 (07-08)	VIS
 R-series	HEADLIGHT LEVEL	R420 Euro 4 (07-08)	VIS
 R-series	HEADLIGHT LEVEL	R420 Euro 5 (08-..)	VIS
 R-series	HEADLIGHT LEVEL	R470 (07-08)	VIS
 R-series	HEADLIGHT LEVEL	R500 (07-08)	VIS
 R-series	HEADLIGHT LEVEL	R560 (07-08)	VIS
 R-series	HEADLIGHT LEVEL	R580 (07-08)	VIS
 R-series	HEADLIGHT LEVEL	R620 (07-08)	VIS
 R-series	SUSPENSION CONTR	R230 (07-08)	SMS ECAS
 R-series	SUSPENSION CONTR	R270 (07-08)	SMS ECAS
 R-series	SUSPENSION CONTR	R310 (07-08)	SMS ECAS
 R-series	SUSPENSION CONTR	R340 (07-08)	SMS ECAS

## Systems supported by ECUreader (up to V4,90)

### TRUCKS

Scania

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 R-series	SUSPENSION CONTR	R380 (07-08)	SMS ECAS
 R-series	SUSPENSION CONTR	R420 Euro 4 (07-08)	SMS ECAS
 R-series	SUSPENSION CONTR	R420 Euro 5 (08-..)	SMS ECAS
 R-series	SUSPENSION CONTR	R470 (07-08)	SMS ECAS
 R-series	SUSPENSION CONTR	R500 (07-08)	SMS ECAS
 R-series	SUSPENSION CONTR	R560 (07-08)	SMS ECAS
 R-series	SUSPENSION CONTR	R580 (07-08)	SMS ECAS
 R-series	SUSPENSION CONTR	R620 (07-08)	SMS ECAS
 R-series	ABS	R114-340 (..-99)	BOSCH ABS I8
 R-series	ABS	R114-380 (..-99)	BOSCH ABS I8
 R-series	ABS	R124-420 (..-99)	BOSCH ABS I8
 R-series	ABS	R124-440 (..-99)	BOSCH ABS I8
 R-series	ABS	R124-470 (..-99)	BOSCH ABS I8
 R-series	ABS	R143-470 (..-99)	BOSCH ABS I8
 R-series	ABS	R143-500 (..-99)	BOSCH ABS I8
 R-series	ABS	R144-530 (..-99)	BOSCH ABS I8
 R-series	ABS	R164-480 (..-99)	BOSCH ABS I8
 R-series	ABS	R164-580 (..-99)	BOSCH ABS I8
 R-series	AIR BRAKE MANAGE	R230 (07-08)	VIS
 R-series	AIR BRAKE MANAGE	R270 (07-08)	VIS
 R-series	AIR BRAKE MANAGE	R310 (07-08)	VIS
 R-series	AIR BRAKE MANAGE	R340 (07-08)	VIS
 R-series	AIR BRAKE MANAGE	R380 (07-08)	VIS
 R-series	AIR BRAKE MANAGE	R420 Euro 4 (07-08)	VIS
 R-series	AIR BRAKE MANAGE	R420 Euro 5 (08-..)	VIS
 R-series	AIR BRAKE MANAGE	R470 (07-08)	VIS

## Systems supported by ECReader (up to V4,90)

### TRUCKS




























Scania

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 R-series	AIR BRAKE MANAGE	R500 (07-08)	VIS
 R-series	AIR BRAKE MANAGE	R560 (07-08)	VIS
 R-series	AIR BRAKE MANAGE	R580 (07-08)	VIS
 R-series	AIR BRAKE MANAGE	R620 (07-08)	VIS
 R-series	AIRBAG	R230 (07-08)	CSS
 R-series	AIRBAG	R270 (07-08)	CSS
 R-series	AIRBAG	R310 (07-08)	CSS
 R-series	AIRBAG	R340 (07-08)	CSS
 R-series	AIRBAG	R380 (07-08)	CSS
 R-series	AIRBAG	R420 Euro 4 (07-08)	CSS
 R-series	AIRBAG	R420 Euro 5 (08-..)	CSS
 R-series	AIRBAG	R470 (07-08)	CSS
 R-series	AIRBAG	R500 (07-08)	CSS
 R-series	AIRBAG	R560 (07-08)	CSS
 R-series	AIRBAG	R580 (07-08)	CSS
 R-series	AIRBAG	R620 (07-08)	CSS
 R-series	ANTITHEFT	R230 (07-08)	LAS
 R-series	ANTITHEFT	R270 (07-08)	LAS
 R-series	ANTITHEFT	R310 (07-08)	LAS
 R-series	ANTITHEFT	R340 (07-08)	LAS
 R-series	ANTITHEFT	R380 (07-08)	LAS
 R-series	ANTITHEFT	R420 Euro 4 (07-08)	LAS
 R-series	ANTITHEFT	R420 Euro 5 (08-..)	LAS
 R-series	ANTITHEFT	R470 (07-08)	LAS
 R-series	ANTITHEFT	R500 (07-08)	LAS
 R-series	ANTITHEFT	R560 (07-08)	LAS
 R-series	ANTITHEFT	R580 (07-08)	LAS

## Systems supported by ECUREADER (up to V4,90)

### TRUCKS

Scania

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 R-series	ANTITHEFT	R620 (07-08)	LAS
 R-series	AUTOM. TRANSMISSI	R230 (07-08)	GMS Opticruise
 R-series	AUTOM. TRANSMISSI	R270 (07-08)	GMS Opticruise
 R-series	AUTOM. TRANSMISSI	R310 (07-08)	GMS Opticruise
 R-series	AUTOM. TRANSMISSI	R340 (07-08)	GMS Opticruise
 R-series	AUTOM. TRANSMISSI	R380 (07-08)	GMS Opticruise
 R-series	AUTOM. TRANSMISSI	R420 Euro 4 (07-08)	GMS Opticruise
 R-series	AUTOM. TRANSMISSI	R420 Euro 5 (08-..)	GMS Opticruise
 R-series	AUTOM. TRANSMISSI	R470 (07-08)	GMS Opticruise
 R-series	AUTOM. TRANSMISSI	R500 (07-08)	GMS Opticruise
 R-series	AUTOM. TRANSMISSI	R560 (07-08)	GMS Opticruise
 R-series	AUTOM. TRANSMISSI	R580 (07-08)	GMS Opticruise
 R-series	AUTOM. TRANSMISSI	R620 (07-08)	GMS Opticruise
 R-series	BRAKE SYS. MANAG	R230 (07-08)	Brake management system
 R-series	BRAKE SYS. MANAG	R270 (07-08)	Brake management system
 R-series	BRAKE SYS. MANAG	R310 (07-08)	Brake management system
 R-series	BRAKE SYS. MANAG	R340 (07-08)	Brake management system
 R-series	BRAKE SYS. MANAG	R380 (07-08)	Brake management system
 R-series	BRAKE SYS. MANAG	R420 Euro 4 (07-08)	Brake management system
 R-series	BRAKE SYS. MANAG	R420 Euro 5 (08-..)	Brake management system
 R-series	BRAKE SYS. MANAG	R470 (07-08)	Brake management system
 R-series	BRAKE SYS. MANAG	R500 (07-08)	Brake management system
 R-series	BRAKE SYS. MANAG	R560 (07-08)	Brake management system
 R-series	BRAKE SYS. MANAG	R580 (07-08)	Brake management system
 R-series	BRAKE SYS. MANAG	R620 (07-08)	Brake management system
 R-series	CHASSIS NETWORK	R230 (07-08)	Body Computer
 R-series	CHASSIS NETWORK	R270 (07-08)	Body Computer

## Systems supported by ECUREADER (up to V4,90)

### TRUCKS
























Scania

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 R-series	CHASSIS NETWORK	R310 (07-08)	Body Computer
 R-series	CHASSIS NETWORK	R340 (07-08)	Body Computer
 R-series	CHASSIS NETWORK	R380 (07-08)	Body Computer
 R-series	CHASSIS NETWORK	R420 Euro 4 (07-08)	Body Computer
 R-series	CHASSIS NETWORK	R420 Euro 5 (08-..)	Body Computer
 R-series	CHASSIS NETWORK	R470 (07-08)	Body Computer
 R-series	CHASSIS NETWORK	R500 (07-08)	Body Computer
 R-series	CHASSIS NETWORK	R560 (07-08)	Body Computer
 R-series	CHASSIS NETWORK	R580 (07-08)	Body Computer
 R-series	CHASSIS NETWORK	R620 (07-08)	Body Computer
 R-series	CLIMA	R230 (07-08)	CCS
 R-series	CLIMA	R270 (07-08)	CCS
 R-series	CLIMA	R310 (07-08)	CCS
 R-series	CLIMA	R340 (07-08)	CCS
 R-series	CLIMA	R380 (07-08)	CCS
 R-series	CLIMA	R420 Euro 4 (07-08)	CCS
 R-series	CLIMA	R420 Euro 5 (08-..)	CCS
 R-series	CLIMA	R470 (07-08)	CCS
 R-series	CLIMA	R500 (07-08)	CCS
 R-series	CLIMA	R560 (07-08)	CCS
 R-series	CLIMA	R580 (07-08)	CCS
 R-series	CLIMA	R620 (07-08)	CCS
 R-series	DASHBOARD	R230 (07-08)	Dashboard
 R-series	DASHBOARD	R270 (07-08)	Dashboard
 R-series	DASHBOARD	R310 (07-08)	Dashboard
 R-series	DASHBOARD	R340 (07-08)	Dashboard
 R-series	DASHBOARD	R380 (07-08)	Dashboard

## Systems supported by ECReader (up to V4,90)

### TRUCKS



























Scania

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 R-series	DASHBOARD	R420 Euro 4 (07-08)	Dashboard
 R-series	DASHBOARD	R420 Euro 5 (08-..)	Dashboard
 R-series	DASHBOARD	R470 (07-08)	Dashboard
 R-series	DASHBOARD	R500 (07-08)	Dashboard
 R-series	DASHBOARD	R560 (07-08)	Dashboard
 R-series	DASHBOARD	R580 (07-08)	Dashboard
 R-series	DASHBOARD	R620 (07-08)	Dashboard
 R-series	ENGINE MANAGEME	R113-380 (92-97)	BOSCH EDC M7
 R-series	ENGINE MANAGEME	R114-340 (96-99)	BOSCH EDC
 R-series	ENGINE MANAGEME	R114-380 (96-99)	BOSCH EDC
 R-series	ENGINE MANAGEME	R124-420 (96-99)	BOSCH EDC
 R-series	ENGINE MANAGEME	R143-470 (88-91)	BOSCH EDC M7
 R-series	ENGINE MANAGEME	R143-500 (91-96)	BOSCH EDC M7
 R-series	ENGINE MANAGEME	R144-530 (96-99)	BOSCH EDC
 R-series	ENGINE MANAGEME	R230 (07-08)	EMS
 R-series	ENGINE MANAGEME	R270 (07-08)	EMS
 R-series	ENGINE MANAGEME	R310 (07-08)	EMS
 R-series	ENGINE MANAGEME	R340 (07-08)	EMS
 R-series	ENGINE MANAGEME	R380 (07-08)	EMS
 R-series	ENGINE MANAGEME	R420 Euro 4 (07-08)	EMS
 R-series	ENGINE MANAGEME	R420 Euro 5 (08-..)	EMS
 R-series	ENGINE MANAGEME	R470 (07-08)	EMS
 R-series	ENGINE MANAGEME	R500 (07-08)	EMS
 R-series	ENGINE MANAGEME	R560 (07-08)	EMS
 R-series	ENGINE MANAGEME	R580 (07-08)	EMS
 R-series	ENGINE MANAGEME	R620 (07-08)	EMS
 R-series	HEADLIGHT LEVEL	R230 (07-08)	VIS

## Systems supported by ECUreader (up to V4,90)

### TRUCKS











Scania

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 R-series	HEADLIGHT LEVEL	R270 (07-08)	VIS
 R-series	HEADLIGHT LEVEL	R310 (07-08)	VIS
 R-series	HEADLIGHT LEVEL	R340 (07-08)	VIS
 R-series	HEADLIGHT LEVEL	R380 (07-08)	VIS
 R-series	HEADLIGHT LEVEL	R420 Euro 4 (07-08)	VIS
 R-series	HEADLIGHT LEVEL	R420 Euro 5 (08-..)	VIS
 R-series	HEADLIGHT LEVEL	R470 (07-08)	VIS
 R-series	HEADLIGHT LEVEL	R500 (07-08)	VIS
 R-series	HEADLIGHT LEVEL	R560 (07-08)	VIS
 R-series	HEADLIGHT LEVEL	R580 (07-08)	VIS
 R-series	HEADLIGHT LEVEL	R620 (07-08)	VIS
 R-series	SUSPENSION CONTR	R230 (07-08)	SMS ECAS
 R-series	SUSPENSION CONTR	R270 (07-08)	SMS ECAS
 R-series	SUSPENSION CONTR	R310 (07-08)	SMS ECAS
 R-series	SUSPENSION CONTR	R340 (07-08)	SMS ECAS
 R-series	SUSPENSION CONTR	R380 (07-08)	SMS ECAS
 R-series	SUSPENSION CONTR	R420 Euro 4 (07-08)	SMS ECAS
 R-series	SUSPENSION CONTR	R420 Euro 5 (08-..)	SMS ECAS
 R-series	SUSPENSION CONTR	R470 (07-08)	SMS ECAS
 R-series	SUSPENSION CONTR	R500 (07-08)	SMS ECAS
 R-series	SUSPENSION CONTR	R560 (07-08)	SMS ECAS
 R-series	SUSPENSION CONTR	R580 (07-08)	SMS ECAS
 R-series	SUSPENSION CONTR	R620 (07-08)	SMS ECAS
 T-series	ABS	T114-380 (.-99)	BOSCH ABS I8
 T-series	ABS	T124-400 (.-99)	BOSCH ABS I8
 T-series	ABS	T124-420 (.-99)	BOSCH ABS I8

## Systems supported by ECUREADER (up to V4,90)

### TRUCKS











**Scania**

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 T-series	ABS	T143-500 (...-99)	BOSCH ABS I8
 T-series	ABS	T144-500 (...-99)	BOSCH ABS I8
 T-series	ABS	T146-480 (...-99)	BOSCH ABS I8
 T-series	ABS	T146-580 (...-99)	BOSCH ABS I8
 T-series	ENGINE MANAGEME	T114-340 (96-99)	BOSCH EDC
 T-series	ENGINE MANAGEME	T114-380 (96-99)	BOSCH EDC
 T-series	ENGINE MANAGEME	T124-400 (95-99)	BOSCH EDC
 T-series	ENGINE MANAGEME	T124-420 (95-99)	BOSCH EDC
 T-series	ENGINE MANAGEME	T143-500 (88-96)	BOSCH EDC M7
 T-series	ENGINE MANAGEME	T144-530 (96-99)	BOSCH EDC

## Systems supported by ECUreader (up to V4,90)

### TRUCKS






### Scania Bus

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 BN113	ENGINE MANAGEME	180 (90-98)	BOSCH EDC M7
 BN113	ENGINE MANAGEME	260 (90-98)	BOSCH EDC M7
 K113	ENGINE MANAGEME	380 (90-..)	BOSCH EDC M7
 K124	ENGINE MANAGEME	360 (97-..)	BOSCH EDC M7
 K124	ENGINE MANAGEME	420 (97-..)	BOSCH EDC
 K124	ENGINE MANAGEME	420 (97-..)	BOSCH EDC Lucas
 K124	ENGINE MANAGEME	420 (97-..)	BOSCH EDC M7
 L113	ENGINE MANAGEME	(93-98)	BOSCH EDC M7
 L113	ENGINE MANAGEME	250 (92-98)	BOSCH EDC M7
 N113	ENGINE MANAGEME	250 (91-98)	BOSCH EDC M7

## Systems supported by ECUreader (up to V4,90)

### TRUCKS






**Schmitz**

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Trailers	ABS	Trailers Wabco	Wabco VARIO C1-C2-C plus
 Trailers	BRAKE SYS. MANAG	Trailers	Wabco Trailer EBS
 Trailers	BRAKE SYS. MANAG	Trailers	Wabco Trailers EBS kw2000
 Trailers	BRAKE SYS. MANAG	Trailers Haldex	Haldex EBS EB+
 Trailers	BRAKE SYS. MANAG	Trailers Knorr	Knorr Trailer EBS

## Systems supported by ECUREADER (up to V4,90)

### TRUCKS












Schwartz

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Trailers	BRAKE SYS. MANAG	Trailers	Wabco Trailer EBS
 Trailers	BRAKE SYS. MANAG	Trailers	Wabco Trailer VCS II
 Trailers	BRAKE SYS. MANAG	Trailers	Wabco Trailers EBS kw2000
 Trailers	BRAKE SYS. MANAG	Trailers Haldex	Haldex EBS EB+
 Trailers	BRAKE SYS. MANAG	Trailers Knorr	Knorr Trailer EBS

## Systems supported by ECUREADER (up to V4,90)

### TRUCKS



### Seddon Atkinson

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Strato/Pacer	ENGINE MANAGEME	Cursor 10	BOSCH EDC 7
 Strato/Pacer	ENGINE MANAGEME	Cursor 13	BOSCH EDC 7
 Strato/Pacer	ENGINE MANAGEME	Cursor 8	BOSCH EDC 7
 Strato	CHASSIS NETWORK		VDO Body Controller
 Strato	DASHBOARD		VDO Instrument Cluster
 Strato	ENGINE MANAGEME	Cursor 10 F3AE0681A	BOSCH EDC MS 6.2
 Strato	ENGINE MANAGEME	Cursor 10 F3AE0681B	BOSCH EDC MS 6.2
 Strato	ENGINE MANAGEME	Cursor 10 F3AE0681D	BOSCH EDC MS 6.2
 Strato	ENGINE MANAGEME	Cursor 10 F3AE0681E	BOSCH EDC MS 6.2
 Strato	ENGINE MANAGEME	Cursor 10 F3AE0681H	BOSCH EDC MS 6.2
 Strato	GEARBOX MANAGEM		Eurotronic 2

## Systems supported by ECUREADER (up to V4,90)

### TRUCKS
















Serviplem Baryval

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Trailers	BRAKE SYS. MANAG	Trailers	Wabco Trailer EBS
 Trailers	BRAKE SYS. MANAG	Trailers	Wabco Trailer VCS II

## Systems supported by ECUREADER (up to V4,90)

### TRUCKS



Setra

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Top Class	BRAKE SYS. MANAG	S 411 HD	BS EBS ZF
 Top Class	BRAKE SYS. MANAG	S 415 HD	BS EBS ZF
 Top Class	BRAKE SYS. MANAG	S 415 HDH	BS EBS ZF
 Top Class	BRAKE SYS. MANAG	S 417 HDH	BS EBS ZF
 Top Class	BRAKE SYS. MANAG	S 431 DT	BS EBS ZF
 Top Class	CRUISE MANAGEME	S 411 HD	FR FMR
 Top Class	CRUISE MANAGEME	S 415 HD	FR FMR
 Top Class	CRUISE MANAGEME	S 415 HDH	FR FMR
 Top Class	CRUISE MANAGEME	S 417 HDH	FR FMR
 Top Class	CRUISE MANAGEME	S 431 DT	FR FMR
 Top Class	ENGINE MANAGEME	S 411 HD	MR PLD
 Top Class	ENGINE MANAGEME	S 415 HD	MR PLD
 Top Class	ENGINE MANAGEME	S 415 HDH	MR PLD
 Top Class	ENGINE MANAGEME	S 417 HDH	MR PLD
 Top Class	ENGINE MANAGEME	S 431 DT	MR PLD

## Systems supported by ECUreader (up to V4,90)

### TRUCKS



Sical

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Trailers	BRAKE SYS. MANAG	Trailers	Wabco Trailer EBS
 Trailers	BRAKE SYS. MANAG	Trailers	Wabco Trailer VCS II

## Systems supported by ECUreader (up to V4,90)

### TRUCKS















Silva

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Trailers	BRAKE SYS. MANAG	Trailers	Wabco Trailer EBS
 Trailers	BRAKE SYS. MANAG	Trailers	Wabco Trailer VCS II

## Systems supported by ECUREADER (up to V4,90)

### TRUCKS



Skoda

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Pick-up	ABS	(..-03)	
 Pick-up	AIRBAG	(..-03)	
 Pick-up	AUX. HEATING	(..-00)	
 Pick-up	CENTRAL LOCKING	(..-00)	
 Pick-up	CLUTCH ELECTRONI	(..-00)	
 Pick-up	DASHBOARD	(..-00)	
 Pick-up	DRIVER SEAT CONTR	(..-00)	
 Pick-up	ENGINE MANAGEME	(..-03)	
 Pick-up	ENGINE MANAGEME	(..-03)	
 Pick-up	ENGINE MANAGEME	(..-03)	
 Pick-up	IMMOBILIZER	(..-00)	
 Pick-up	PARKING HELP	(..-00)	
 Pick-up	RADIO / CD	(..-03)	
 Pick-up	SUSPENSION CONTR	(..-00)	

## Systems supported by ECUREADER (up to V4,90)

### TRUCKS





Tafyma

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Trailers	BRAKE SYS. MANAG	Trailers	Wabco Trailer EBS
 Trailers	BRAKE SYS. MANAG	Trailers	Wabco Trailer VCS II

## Systems supported by ECUreader (up to V4,90)

### TRUCKS



**Tecnokar**

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Trailers	BRAKE SYS. MANAG	Trailers	Wabco Trailer EBS
 Trailers	BRAKE SYS. MANAG	Trailers	Wabco Trailers EBS kw2000
 Trailers	BRAKE SYS. MANAG	Trailers Haldex	Haldex EBS EB+
 Trailers	BRAKE SYS. MANAG	Trailers Knorr	Knorr Trailer EBS

## Systems supported by ECUreader (up to V4,90)

### TRUCKS




Tisvol

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Trailers	BRAKE SYS. MANAG	Trailers	Wabco Trailer EBS
 Trailers	BRAKE SYS. MANAG	Trailers	Wabco Trailer VCS II

## Systems supported by ECUreader (up to V4,90)

### TRUCKS



Toyota

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 HiAce	ENGINE MANAGEME	2.5 D-4D 2KD-FTV (04-..)	EOBD
 HiAce	ENGINE MANAGEME	2.7 3RZ-FE (01-..)	EOBD
 HiLux	ENGINE MANAGEME	2.5 D-4D 2KD-FTV (04-..)	EOBD

## Systems supported by ECUreader (up to V4,90)

### TRUCKS



























### Voltrailer

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Trailers	BRAKE SYS. MANAG	Trailers	Wabco Trailer EBS
 Trailers	BRAKE SYS. MANAG	Trailers	Wabco Trailer VCS II

## Systems supported by ECReader (up to V4,90)

### TRUCKS

**Volvo**

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 F10	ENGINE MANAGEME	290 (91-94)	BOSCH EDC M7
 F12	ENGINE MANAGEME	370 (90-94)	BOSCH EDC M7
 F12	ENGINE MANAGEME	390 (87-94)	BOSCH EDC M7
 F16	ENGINE MANAGEME	370 (91-94)	BOSCH EDC M7
 FH12	AIR DRYER	380 (...-07)	Air Dryer
 FH12	AIR DRYER	420 (...-07)	Air Dryer
 FH12	AIR DRYER	460 (...-07)	Air Dryer
 FH12	AIR DRYER	500 (...-07)	Air Dryer
 FH12	AUX. HEATING	380 (03-07)	
 FH12	AUX. HEATING	420 (03-07)	
 FH12	AUX. HEATING	460 (03-07)	
 FH12	AUX. HEATING	500 (03-07)	
 FH12	BRAKE SYS. MANAG	(98-02)	ABS/ATC
 FH12	BRAKE SYS. MANAG	380 (03-07)	
 FH12	BRAKE SYS. MANAG	420 (03-07)	
 FH12	BRAKE SYS. MANAG	460 (03-07)	
 FH12	BRAKE SYS. MANAG	500 (03-07)	
 FH12	CHANGE BRAKE PAD	380 (03-07)	
 FH12	CHANGE BRAKE PAD	420 (03-07)	
 FH12	CHANGE BRAKE PAD	460 (03-07)	
 FH12	CHANGE BRAKE PAD	500 (03-07)	
 FH12	CHASSIS MANAGEME	380 (03-07)	
 FH12	CHASSIS MANAGEME	420 (03-07)	
 FH12	CHASSIS MANAGEME	460 (03-07)	
 FH12	CHASSIS MANAGEME	500 (03-07)	
 FH12	CHASSIS NETWORK	(98-02)	Vehicle ECU

## Systems supported by ECReader (up to V4,90)

### TRUCKS



























Volvo

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 FH12	CHASSIS NETWORK	380 (03-07)	Vehicle ECU
 FH12	CHASSIS NETWORK	420 (03-07)	Vehicle ECU
 FH12	CHASSIS NETWORK	460 (03-07)	Vehicle ECU
 FH12	CHASSIS NETWORK	500 (03-07)	Vehicle ECU
 FH12	CHRONOTACHOGRA	380 (03-07)	
 FH12	CHRONOTACHOGRA	420 (03-07)	
 FH12	CHRONOTACHOGRA	460 (03-07)	
 FH12	CHRONOTACHOGRA	500 (03-07)	
 FH12	DASHBOARD	(98-02)	Display
 FH12	DASHBOARD	380 (03-07)	
 FH12	DASHBOARD	420 (03-07)	
 FH12	DASHBOARD	460 (03-07)	
 FH12	DASHBOARD	500 (03-07)	
 FH12	ELECTRIC ACTUATIO	380 (03-07)	
 FH12	ELECTRIC ACTUATIO	420 (03-07)	
 FH12	ELECTRIC ACTUATIO	460 (03-07)	
 FH12	ELECTRIC ACTUATIO	500 (03-07)	
 FH12	ENGINE MANAGEME	(94-98)	D12
 FH12	ENGINE MANAGEME	340 (93-98)	BOSCH EDC
 FH12	ENGINE MANAGEME	380 (03-07)	
 FH12	ENGINE MANAGEME	380 (93-98)	BOSCH EDC
 FH12	ENGINE MANAGEME	420 (03-07)	
 FH12	ENGINE MANAGEME	420 (93-98)	BOSCH EDC
 FH12	ENGINE MANAGEME	460 (03-07)	
 FH12	ENGINE MANAGEME	500 (03-07)	
 FH12	HEADLIGHT LEVEL	380 (03-07)	
 FH12	HEADLIGHT LEVEL	420 (03-07)	

## Systems supported by ECReader (up to V4,90)

### TRUCKS















Volvo

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 FH12	HEADLIGHT LEVEL	460 (03-07)	
 FH12	HEADLIGHT LEVEL	500 (03-07)	
 FH12	SUSPENSION CONTR	(98-02)	ECAS
 FH12	SUSPENSION CONTR	380 (03-07)	
 FH12	SUSPENSION CONTR	420 (03-07)	
 FH12	SUSPENSION CONTR	460 (03-07)	
 FH12	SUSPENSION CONTR	500 (03-07)	
 FH16	AIR DRYER	540 (...-07)	Air Dryer
 FH16	AIR DRYER	580 (...-07)	Air Dryer
 FH16	AIR DRYER	610 (...-07)	Air Dryer
 FH16	AIR DRYER	660 (...-07)	Air Dryer
 FH16	AUX. HEATING	540 (03-07)	
 FH16	AUX. HEATING	580 (03-07)	
 FH16	AUX. HEATING	610 (03-07)	
 FH16	AUX. HEATING	660 (03-07)	
 FH16	BRAKE SYS. MANAG	540 (03-07)	
 FH16	BRAKE SYS. MANAG	580 (03-07)	
 FH16	BRAKE SYS. MANAG	610 (03-07)	
 FH16	BRAKE SYS. MANAG	660 (03-07)	
 FH16	CHANGE BRAKE PAD	540 (03-07)	
 FH16	CHANGE BRAKE PAD	580 (03-07)	
 FH16	CHANGE BRAKE PAD	610 (03-07)	
 FH16	CHANGE BRAKE PAD	660 (03-07)	
 FH16	CHASSIS MANAGEME	540 (03-07)	
 FH16	CHASSIS MANAGEME	580 (03-07)	
 FH16	CHASSIS MANAGEME	610 (03-07)	

## Systems supported by ECReader (up to V4,90)

### TRUCKS


























Volvo

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 FH16	CHASSIS MANAGEME	660 (03-07)	
 FH16	CHASSIS NETWORK	540 (03-07)	Vehicle ECU
 FH16	CHASSIS NETWORK	580 (03-07)	Vehicle ECU
 FH16	CHASSIS NETWORK	610 (03-07)	Vehicle ECU
 FH16	CHASSIS NETWORK	660 (03-07)	Vehicle ECU
 FH16	CHRONOTACHOGRA	540 (03-07)	
 FH16	CHRONOTACHOGRA	580 (03-07)	
 FH16	CHRONOTACHOGRA	610 (03-07)	
 FH16	CHRONOTACHOGRA	660 (03-07)	
 FH16	DASHBOARD	540 (03-07)	
 FH16	DASHBOARD	580 (03-07)	
 FH16	DASHBOARD	610 (03-07)	
 FH16	DASHBOARD	660 (03-07)	
 FH16	ELECTRIC ACTUATIO	540 (03-07)	
 FH16	ELECTRIC ACTUATIO	580 (03-07)	
 FH16	ELECTRIC ACTUATIO	610 (03-07)	
 FH16	ELECTRIC ACTUATIO	660 (03-07)	
 FH16	ENGINE MANAGEME	470 (93-98)	BOSCH EDC M7
 FH16	ENGINE MANAGEME	520 (93-98)	BOSCH EDC M7
 FH16	ENGINE MANAGEME	540 (03-07)	
 FH16	ENGINE MANAGEME	580 (03-07)	
 FH16	ENGINE MANAGEME	610 (03-07)	
 FH16	ENGINE MANAGEME	660 (03-07)	
 FH16	HEADLIGHT LEVEL	540 (03-07)	
 FH16	HEADLIGHT LEVEL	580 (03-07)	
 FH16	HEADLIGHT LEVEL	610 (03-07)	
 FH16	HEADLIGHT LEVEL	660 (03-07)	

## Systems supported by ECReader (up to V4,90)

### TRUCKS



























Volvo

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 FH16	SUSPENSION CONTR	540 (03-07)	
 FH16	SUSPENSION CONTR	580 (03-07)	
 FH16	SUSPENSION CONTR	610 (03-07)	
 FH16	SUSPENSION CONTR	660 (03-07)	
 FH16	AIR DRYER	540 (...-07)	Air Dryer
 FH16	AIR DRYER	580 (...-07)	Air Dryer
 FH16	AIR DRYER	610 (...-07)	Air Dryer
 FH16	AIR DRYER	660 (...-07)	Air Dryer
 FH16	AUX. HEATING	540 (03-07)	
 FH16	AUX. HEATING	580 (03-07)	
 FH16	AUX. HEATING	610 (03-07)	
 FH16	AUX. HEATING	660 (03-07)	
 FH16	BRAKE SYS. MANAG	540 (03-07)	
 FH16	BRAKE SYS. MANAG	580 (03-07)	
 FH16	BRAKE SYS. MANAG	610 (03-07)	
 FH16	BRAKE SYS. MANAG	660 (03-07)	
 FH16	CHANGE BRAKE PAD	540 (03-07)	
 FH16	CHANGE BRAKE PAD	580 (03-07)	
 FH16	CHANGE BRAKE PAD	610 (03-07)	
 FH16	CHANGE BRAKE PAD	660 (03-07)	
 FH16	CHASSIS MANAGEME	540 (03-07)	
 FH16	CHASSIS MANAGEME	580 (03-07)	
 FH16	CHASSIS MANAGEME	610 (03-07)	
 FH16	CHASSIS MANAGEME	660 (03-07)	
 FH16	CHASSIS NETWORK	540 (03-07)	Vehicle ECU
 FH16	CHASSIS NETWORK	580 (03-07)	Vehicle ECU

## Systems supported by ECUreader (up to V4,90)

### TRUCKS



























Volvo

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 FH16	CHASSIS NETWORK	610 (03-07)	Vehicle ECU
 FH16	CHASSIS NETWORK	660 (03-07)	Vehicle ECU
 FH16	CHRONOTACHOGRA	540 (03-07)	
 FH16	CHRONOTACHOGRA	580 (03-07)	
 FH16	CHRONOTACHOGRA	610 (03-07)	
 FH16	CHRONOTACHOGRA	660 (03-07)	
 FH16	DASHBOARD	540 (03-07)	
 FH16	DASHBOARD	580 (03-07)	
 FH16	DASHBOARD	610 (03-07)	
 FH16	DASHBOARD	660 (03-07)	
 FH16	ELECTRIC ACTUATIO	540 (03-07)	
 FH16	ELECTRIC ACTUATIO	580 (03-07)	
 FH16	ELECTRIC ACTUATIO	610 (03-07)	
 FH16	ELECTRIC ACTUATIO	660 (03-07)	
 FH16	ENGINE MANAGEME	540 (03-07)	
 FH16	ENGINE MANAGEME	580 (03-07)	
 FH16	ENGINE MANAGEME	610 (03-07)	
 FH16	ENGINE MANAGEME	660 (03-07)	
 FH16	HEADLIGHT LEVEL	540 (03-07)	
 FH16	HEADLIGHT LEVEL	580 (03-07)	
 FH16	HEADLIGHT LEVEL	610 (03-07)	
 FH16	HEADLIGHT LEVEL	660 (03-07)	
 FH16	SUSPENSION CONTR	540 (03-07)	
 FH16	SUSPENSION CONTR	580 (03-07)	
 FH16	SUSPENSION CONTR	610 (03-07)	
 FH16	SUSPENSION CONTR	660 (03-07)	

## Systems supported by ECReader (up to V4,90)

### TRUCKS



























Volvo

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 FH	AIR DRYER	400 (..-07)	Air Dryer
 FH	AIR DRYER	440 (..-07)	Air Dryer
 FH	AIR DRYER	480 (..-07)	Air Dryer
 FH	AIR DRYER	520 (..-07)	Air Dryer
 FH	AUX. HEATING	400 (07-..)	
 FH	AUX. HEATING	440 (07-..)	
 FH	AUX. HEATING	480 (07-..)	
 FH	AUX. HEATING	520 (07-..)	
 FH	BRAKE SYS. MANAG	400 (07-..)	
 FH	BRAKE SYS. MANAG	440 (07-..)	
 FH	BRAKE SYS. MANAG	480 (07-..)	
 FH	BRAKE SYS. MANAG	520 (07-..)	
 FH	CHANGE BRAKE PAD	400 (07-..)	
 FH	CHANGE BRAKE PAD	440 (07-..)	
 FH	CHANGE BRAKE PAD	480 (07-..)	
 FH	CHANGE BRAKE PAD	520 (07-..)	
 FH	CHASSIS MANAGEME	400 (07-..)	
 FH	CHASSIS MANAGEME	440 (07-..)	
 FH	CHASSIS MANAGEME	480 (07-..)	
 FH	CHASSIS MANAGEME	520 (07-..)	
 FH	CHASSIS NETWORK	400 (07-..)	Vehicle ECU
 FH	CHASSIS NETWORK	440 (07-..)	Vehicle ECU
 FH	CHASSIS NETWORK	480 (07-..)	Vehicle ECU
 FH	CHASSIS NETWORK	520 (07-..)	Vehicle ECU
 FH	CHRONOTACHOGRA	400 (07-..)	
 FH	CHRONOTACHOGRA	440 (07-..)	
 FH	CHRONOTACHOGRA	480 (07-..)	

## Systems supported by ECReader (up to V4,90)

### TRUCKS

Volvo

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 FH	CHRONOTACHOGRA	520 (07-..)	
 FH	DASHBOARD	400 (07-..)	
 FH	DASHBOARD	440 (07-..)	
 FH	DASHBOARD	480 (07-..)	
 FH	DASHBOARD	520 (07-..)	
 FH	ELECTRIC ACTUATIO	400 (07-..)	
 FH	ELECTRIC ACTUATIO	440 (07-..)	
 FH	ELECTRIC ACTUATIO	480 (07-..)	
 FH	ELECTRIC ACTUATIO	520 (07-..)	
 FH	ENGINE MANAGEME	400 (07-..)	
 FH	ENGINE MANAGEME	440 (07-..)	
 FH	ENGINE MANAGEME	480 (07-..)	
 FH	ENGINE MANAGEME	520 (07-..)	
 FH	HEADLIGHT LEVEL	400 (07-..)	
 FH	HEADLIGHT LEVEL	440 (07-..)	
 FH	HEADLIGHT LEVEL	480 (07-..)	
 FH	HEADLIGHT LEVEL	520 (07-..)	
 FH	SUSPENSION CONTR	400 (07-..)	
 FH	SUSPENSION CONTR	440 (07-..)	
 FH	SUSPENSION CONTR	480 (07-..)	
 FH	SUSPENSION CONTR	520 (07-..)	
 FL10	ENGINE MANAGEME	286 (92-94)	BOSCH EDC M7
 FL12	ENGINE MANAGEME	380 (95-..)	BOSCH EDC
 FL12	ENGINE MANAGEME	420 (95-..)	BOSCH EDC
 FM12	AUX. HEATING	360 (03-07)	
 FM12	AUX. HEATING	400 (03-07)	

## Systems supported by ECReader (up to V4,90)

### TRUCKS



























Volvo

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 FM12	AUX. HEATING	440 (03-07)	
 FM12	AUX. HEATING	480 (03-07)	
 FM12	BRAKE SYS. MANAG	(98-02)	ABS/ATC
 FM12	BRAKE SYS. MANAG	360 (03-07)	
 FM12	BRAKE SYS. MANAG	400 (03-07)	
 FM12	BRAKE SYS. MANAG	440 (03-07)	
 FM12	BRAKE SYS. MANAG	480 (03-07)	
 FM12	CHANGE BRAKE PAD	360 (03-07)	
 FM12	CHANGE BRAKE PAD	400 (03-07)	
 FM12	CHANGE BRAKE PAD	440 (03-07)	
 FM12	CHANGE BRAKE PAD	480 (03-07)	
 FM12	CHASSIS NETWORK	(98-02)	Vehicle ECU
 FM12	CHASSIS NETWORK	360 (03-07)	Vehicle ECU
 FM12	CHASSIS NETWORK	400 (03-07)	Vehicle ECU
 FM12	CHASSIS NETWORK	440 (03-07)	Vehicle ECU
 FM12	CHASSIS NETWORK	480 (03-07)	Vehicle ECU
 FM12	DASHBOARD	(98-02)	Display
 FM12	DASHBOARD	360 (03-07)	
 FM12	DASHBOARD	400 (03-07)	
 FM12	DASHBOARD	440 (03-07)	
 FM12	DASHBOARD	480 (03-07)	
 FM12	ENGINE MANAGEME	360 (03-07)	
 FM12	ENGINE MANAGEME	400 (03-07)	
 FM12	ENGINE MANAGEME	440 (03-07)	
 FM12	ENGINE MANAGEME	480 (03-07)	
 FM12	HEADLIGHT LEVEL	360 (03-07)	
 FM12	HEADLIGHT LEVEL	400 (03-07)	

## Systems supported by ECReader (up to V4,90)

### TRUCKS



























Volvo

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 FM12	HEADLIGHT LEVEL	440 (03-07)	
 FM12	HEADLIGHT LEVEL	480 (03-07)	
 FM12	SUSPENSION CONTR	(98-02)	ECAS
 FM12	SUSPENSION CONTR	360 (03-07)	
 FM12	SUSPENSION CONTR	400 (03-07)	
 FM12	SUSPENSION CONTR	440 (03-07)	
 FM12	SUSPENSION CONTR	480 (03-07)	
 FM12	AUX. HEATING	360 (03-07)	
 FM12	AUX. HEATING	400 (03-07)	
 FM12	AUX. HEATING	440 (03-07)	
 FM12	AUX. HEATING	480 (03-07)	
 FM12	BRAKE SYS. MANAG	360 (03-07)	
 FM12	BRAKE SYS. MANAG	400 (03-07)	
 FM12	BRAKE SYS. MANAG	440 (03-07)	
 FM12	BRAKE SYS. MANAG	480 (03-07)	
 FM12	CHANGE BRAKE PAD	360 (03-07)	
 FM12	CHANGE BRAKE PAD	400 (03-07)	
 FM12	CHANGE BRAKE PAD	440 (03-07)	
 FM12	CHANGE BRAKE PAD	480 (03-07)	
 FM12	CHASSIS MANAGEME	440 (03-07)	
 FM12	CHASSIS MANAGEME	480 (03-07)	
 FM12	CHASSIS NETWORK	360 (03-07)	Vehicle ECU
 FM12	CHASSIS NETWORK	400 (03-07)	Vehicle ECU
 FM12	CHASSIS NETWORK	440 (03-07)	Vehicle ECU
 FM12	CHASSIS NETWORK	480 (03-07)	Vehicle ECU
 FM12	DASHBOARD	360 (03-07)	

## Systems supported by ECReader (up to V4,90)

### TRUCKS



























Volvo

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 FM12	DASHBOARD	400 (03-07)	
 FM12	DASHBOARD	440 (03-07)	
 FM12	DASHBOARD	480 (03-07)	
 FM12	ENGINE MANAGEME	360 (03-07)	
 FM12	ENGINE MANAGEME	400 (03-07)	
 FM12	ENGINE MANAGEME	440 (03-07)	
 FM12	ENGINE MANAGEME	480 (03-07)	
 FM12	HEADLIGHT LEVEL	360 (03-07)	
 FM12	HEADLIGHT LEVEL	400 (03-07)	
 FM12	HEADLIGHT LEVEL	440 (03-07)	
 FM12	HEADLIGHT LEVEL	480 (03-07)	
 FM12	SUSPENSION CONTR	360 (03-07)	
 FM12	SUSPENSION CONTR	400 (03-07)	
 FM12	SUSPENSION CONTR	440 (03-07)	
 FM12	SUSPENSION CONTR	480 (03-07)	
 FM9	AUX. HEATING	260 (03-07)	
 FM9	AUX. HEATING	300 (03-07)	
 FM9	AUX. HEATING	340 (03-07)	
 FM9	AUX. HEATING	380 (03-07)	
 FM9	BRAKE SYS. MANAG	260 (03-07)	
 FM9	BRAKE SYS. MANAG	300 (03-07)	
 FM9	BRAKE SYS. MANAG	340 (03-07)	
 FM9	BRAKE SYS. MANAG	380 (03-07)	
 FM9	CHANGE BRAKE PAD	260 (03-07)	
 FM9	CHANGE BRAKE PAD	300 (03-07)	
 FM9	CHANGE BRAKE PAD	340 (03-07)	

## Systems supported by ECReader (up to V4,90)

### TRUCKS


Volvo

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 FM9	CHANGE BRAKE PAD	380 (03-07)	
 FM9	CHASSIS MANAGEME	260 (03-07)	
 FM9	CHASSIS MANAGEME	300 (03-07)	
 FM9	CHASSIS MANAGEME	340 (03-07)	
 FM9	CHASSIS MANAGEME	380 (03-07)	
 FM9	CHASSIS NETWORK	260 (03-07)	Vehicle ECU
 FM9	CHASSIS NETWORK	300 (03-07)	Vehicle ECU
 FM9	CHASSIS NETWORK	340 (03-07)	Vehicle ECU
 FM9	CHASSIS NETWORK	380 (03-07)	Vehicle ECU
 FM9	DASHBOARD	260 (03-07)	
 FM9	DASHBOARD	300 (03-07)	
 FM9	DASHBOARD	340 (03-07)	
 FM9	DASHBOARD	380 (03-07)	
 FM9	ENGINE MANAGEME	260 (03-07)	
 FM9	ENGINE MANAGEME	300 (03-07)	
 FM9	ENGINE MANAGEME	340 (03-07)	
 FM9	ENGINE MANAGEME	380 (03-07)	
 FM9	HEADLIGHT LEVEL	260 (03-07)	
 FM9	HEADLIGHT LEVEL	300 (03-07)	
 FM9	HEADLIGHT LEVEL	340 (03-07)	
 FM9	HEADLIGHT LEVEL	380 (03-07)	
 FM9	SUSPENSION CONTR	260 (03-07)	
 FM9	SUSPENSION CONTR	300 (03-07)	
 FM9	SUSPENSION CONTR	340 (03-07)	
 FM9	SUSPENSION CONTR	380 (03-07)	
 NL12	ENGINE MANAGEME	360 (96-...)	BOSCH EDC M7

## Systems supported by ECUREADER (up to V4,90)

### TRUCKS





Volvo

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 NL12	ENGINE MANAGEME	400 (96-..)	BOSCH EDC M7

## Systems supported by ECUreader (up to V4,90)

### TRUCKS



























### Volvo Bus

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 B12	ENGINE MANAGEME	340 (95-..)	BOSCH EDC
 B12	ENGINE MANAGEME	380 (95-..)	BOSCH EDC
 B12	ENGINE MANAGEME	400 (92-95)	BOSCH EDC M7
 B12	ENGINE MANAGEME	420 (95-..)	BOSCH EDC

## Systems supported by ECReader (up to V4,90)

### TRUCKS



























**VW**

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Caddy	ABS	(04-06)	
 Caddy	AIRBAG	(..-03)	
 Caddy	AIRBAG	(04-06)	
 Caddy	COMFORT SYSTEM	(04-06)	
 Caddy	DASHBOARD	(04-06)	
 Caddy	ELECTRIC STEERING	(04-06)	
 Caddy	ENGINE MANAGEME	(..-03)	
 Caddy	ENGINE MANAGEME	(..-03)	
 Caddy	ENGINE MANAGEME	(..-03)	
 Caddy	ENGINE MANAGEME	(04-06)	CAN
 Caddy	ENGINE MANAGEME	1.9 TDI BKC (04-06)	
 Caddy	IMMOBILIZER	(..-00)	
 Caddy	IMMOBILIZER	(04-06)	
 Caddy	RADIO / CD	(04-06)	
 Caddy	SERVICE LIGHT RES	(93-96)	MANUAL
 Caddy	SERVICE LIGHT RES	(97-98)	MANUAL
 Caddy	TRANSPORT MODALI	(04-06)	
<hr/>			
 Crafter	ABS + TRACT. CONT	2.5 TDI 109cv (06-..)	
 Crafter	ABS + TRACT. CONT	2.5 TDI 130cv (06-..)	
 Crafter	ABS + TRACT. CONT	2.5 TDI 164cv (06-..)	
 Crafter	ABS + TRACT. CONT	2.5 TDI 89cv (06-..)	
 Crafter	AIRBAG	2.5 TDI 109cv (06-..)	
 Crafter	AIRBAG	2.5 TDI 130cv (06-..)	
 Crafter	AIRBAG	2.5 TDI 164cv (06-..)	
 Crafter	AIRBAG	2.5 TDI 89cv (06-..)	
 Crafter	AUTOM. TRANSMISSI	2.5 TDI 109cv (06-..)	

## Systems supported by ECReader (up to V4,90)

### TRUCKS



























**VW**

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Crafter	AUTOM. TRANSMISSI	2.5 TDI 130cv (06-..)	
 Crafter	AUTOM. TRANSMISSI	2.5 TDI 164cv (06-..)	
 Crafter	AUTOM. TRANSMISSI	2.5 TDI 89cv (06-..)	
 Crafter	DASHBOARD	2.5 TDI 109cv (06-..)	
 Crafter	DASHBOARD	2.5 TDI 130cv (06-..)	
 Crafter	DASHBOARD	2.5 TDI 164cv (06-..)	
 Crafter	DASHBOARD	2.5 TDI 89cv (06-..)	
 Crafter	ENGINE MANAGEME	2.5 TDI 109cv (06-..)	
 Crafter	ENGINE MANAGEME	2.5 TDI 130cv (06-..)	
 Crafter	ENGINE MANAGEME	2.5 TDI 164cv (06-..)	
 Crafter	ENGINE MANAGEME	2.5 TDI 89cv (06-..)	
 Crafter	SERVICE LIGHT RES	2.5 TDI 109cv (06-..)	
 Crafter	SERVICE LIGHT RES	2.5 TDI 130cv (06-..)	
 Crafter	SERVICE LIGHT RES	2.5 TDI 164cv (06-..)	
 Crafter	SERVICE LIGHT RES	2.5 TDI 89cv (06-..)	
 LT 98	ENGINE MANAGEME	(..-01)	
 LT 98	IMMOBILIZER	(..-01)	
 LT 98	SERVICE LIGHT RES	(98-98)	MANUAL
 LT	ABS	(..-6/96)	
 LT	ENGINE MANAGEME	(..-6/96)	
 LT	ENGINE MANAGEME	(..-6/96)	
 LT	ENGINE MANAGEME	(..-6/96)	
 LT	IMMOBILIZER	(..-6/96)	
 LT	SERVICE LIGHT RES	(93-96)	MANUAL
 T4-Caravelle	ABS	(..-6/98)	
 T4-Caravelle	AIRBAG	(..-6/98)	

## Systems supported by ECReader (up to V4,90)

### TRUCKS


















**VW**

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 T4-Caravelle	CLIMA	(..-6/98)	
 T4-Caravelle	CONV. TOP/SUNROO	(..-6/98)	
 T4-Caravelle	ENGINE MANAGEME	(..-6/98)	
 T4-Caravelle	ENGINE MANAGEME	(..-6/98)	
 T4-Caravelle	ENGINE MANAGEME	(..-6/98)	
 T4-Caravelle	IMMOBILIZER	(..-6/98)	
 T4-Caravelle	SERVICE LIGHT RES	(93-96)	MANUAL
 T4-Caravelle	SERVICE LIGHT RES	(97-98)	MANUAL
 T4-Caravelle	SERVICE LIGHT RES	(99-02)	
 T4-Transporter	ABS	(..-6/98)	
 T4-Transporter	AIRBAG	(..-6/98)	
 T4-Transporter	CLIMA	(..-6/98)	
 T4-Transporter	CONV. TOP/SUNROO	(..-6/98)	
 T4-Transporter	ENGINE MANAGEME	(..-6/98)	
 T4-Transporter	ENGINE MANAGEME	(..-6/98)	
 T4-Transporter	ENGINE MANAGEME	(..-6/98)	
 T4-Transporter	IMMOBILIZER	(..-6/98)	
 T4-Transporter	SERVICE LIGHT RES	(93-96)	MANUAL
 T4-Transporter	SERVICE LIGHT RES	(97-98)	MANUAL
 T4-Transporter	SERVICE LIGHT RES	(99-02)	
 T5-Caravelle	ABS	(03-06)	
 T5-Caravelle	AIRBAG	(03-06)	
 T5-Caravelle	AUTOM. TRANSMISSI	(03-06)	
 T5-Caravelle	CLIMA	(03-06)	
 T5-Caravelle	COMFORT SYSTEM	(03-06)	
 T5-Caravelle	DASHBOARD	(03-06)	

## Systems supported by ECReader (up to V4,90)

### TRUCKS





**VW**

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 T5-Caravelle	ENGINE MANAGEME	(03-06)	
 T5-Caravelle	SERVICE LIGHT RES	(03-06)	
 T5-Transporter	ABS	(03-06)	
 T5-Transporter	AIRBAG	(03-06)	
 T5-Transporter	AUTOM. TRANSMISSI	(03-06)	
 T5-Transporter	CLIMA	(03-06)	
 T5-Transporter	COMFORT SYSTEM	(03-06)	
 T5-Transporter	DASHBOARD	(03-06)	
 T5-Transporter	ENGINE MANAGEME	(03-06)	
 T5-Transporter	SERVICE LIGHT RES	(03-06)	
 Taro	AIRBAG	(..-6/98)	
 Taro	ENGINE MANAGEME	(..-6/98)	
 Taro	ENGINE MANAGEME	(..-6/98)	
 Taro	ENGINE MANAGEME	(..-6/98)	
 Taro	IMMOBILIZER	(..-6/98)	
 Taro	SERVICE LIGHT RES	(93-96)	
 Taro	SERVICE LIGHT RES	(97-98)	

## Systems supported by ECUREADER (up to V4,90)

### TRUCKS



**WABCO**

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Trailers	ABS	Trailers	Wabco Trailer VCS II
 Trailers	ABS	Trailers Wabco	Wabco VARIO C1-C2-C plus
 Trailers	BRAKE SYS. MANAG	Trailers	Wabco Trailer EBS
 Trailers	BRAKE SYS. MANAG	Trailers	Wabco Trailer EBS Kw2000

## Systems supported by ECUreader (up to V4,90)

### TRUCKS

Zorzi

MODEL	SYSTEM TYPE	ENGINE / SYSTEM	ECU
 Trailers	BRAKE SYS. MANAG	Trailers	Wabco Trailer EBS
 Trailers	BRAKE SYS. MANAG	Trailers	Wabco Trailers EBS kw2000
 Trailers	BRAKE SYS. MANAG	Trailers Haldex	Haldex EBS EB+
 Trailers	BRAKE SYS. MANAG	Trailers Knorr	Knorr Trailer EBS
 Trailers	BRAKE SYS. MANAG	Trailers Wabco	Wabco VARIO C1-C2-C plus