

#	Brand	Model	System	Engine	ECU	Version
1	DAF	CF 65	ENGINE MANAGEMENT	XE 340 (02-05)	DAF UPEC	V4,2
2	DAF	CF 65	ENGINE MANAGEMENT	XE 380 (02-05)	DAF UPEC	V4,2
3	DAF	CF 65	ENGINE MANAGEMENT	XE 430 (02-05)	DAF UPEC	V4,2
4	DAF	CF 65	ENGINE MANAGEMENT	XE 480 (02-05)	DAF UPEC	V4,2
5	DAF	CF 65	AUTOM. TRANSMISSION	XE 340 (02-05)	ZF ASTRONIC	V4,2
6	DAF	CF 65	AUTOM. TRANSMISSION	XE 380 (02-05)	ZF ASTRONIC	V4,2
7	DAF	CF 65	AUTOM. TRANSMISSION	XE 430 (02-05)	ZF ASTRONIC	V4,2
8	DAF	CF 65	AUTOM. TRANSMISSION	XE 480 (02-05)	ZF ASTRONIC	V4,2
9	DAF	CF 65	SUSPENSION CONTROL	XE 340 (02-05)	WABCO ECAS 3	V4,2
10	DAF	CF 65	SUSPENSION CONTROL	XE 380 (02-05)	WABCO ECAS 3	V4,2
11	DAF	CF 65	SUSPENSION CONTROL	XE 430 (02-05)	WABCO ECAS 3	V4,2
12	DAF	CF 65	SUSPENSION CONTROL	XE 480 (02-05)	WABCO ECAS 3	V4,2
13	DAF	CF 65	DASHBOARD	XE 340 (02-05)		V4,2
14	DAF	CF 65	DASHBOARD	XE 380 (02-05)		V4,2
15	DAF	CF 65	DASHBOARD	XE 430 (02-05)		V4,2
16	DAF	CF 65	DASHBOARD	XE 480 (02-05)		V4,2
17	DAF	CF 65	BRAKE SYS. MANAGEMENT	XE 340 (02-05)	WABCO EBS	V4,2
18	DAF	CF 65	BRAKE SYS. MANAGEMENT	XE 380 (02-05)	WABCO EBS	V4,2
19	DAF	CF 65	BRAKE SYS. MANAGEMENT	XE 430 (02-05)	WABCO EBS	V4,2
20	DAF	CF 65	BRAKE SYS. MANAGEMENT	XE 480 (02-05)	WABCO EBS	V4,2
21	DAF	CF 75	ENGINE MANAGEMENT	XE 340 (02-05)	DAF UPEC	V4,2
22	DAF	CF 75	ENGINE MANAGEMENT	XE 380 (02-05)	DAF UPEC	V4,2
23	DAF	CF 75	ENGINE MANAGEMENT	XE 430 (02-05)	DAF UPEC	V4,2
24	DAF	CF 75	ENGINE MANAGEMENT	XE 480 (02-05)	DAF UPEC	V4,2
25	DAF	CF 75	AUTOM. TRANSMISSION	XE 340 (02-05)	ZF ASTRONIC	V4,2
26	DAF	CF 75	AUTOM. TRANSMISSION	XE 380 (02-05)	ZF ASTRONIC	V4,2
27	DAF	CF 75	AUTOM. TRANSMISSION	XE 430 (02-05)	ZF ASTRONIC	V4,2
28	DAF	CF 75	AUTOM. TRANSMISSION	XE 480 (02-05)	ZF ASTRONIC	V4,2
29	DAF	CF 75	SUSPENSION CONTROL	XE 340 (02-05)	WABCO ECAS 3	V4,2
30	DAF	CF 75	SUSPENSION CONTROL	XE 380 (02-05)	WABCO ECAS 3	V4,2
31	DAF	CF 75	SUSPENSION CONTROL	XE 430 (02-05)	WABCO ECAS 3	V4,2
32	DAF	CF 75	SUSPENSION CONTROL	XE 480 (02-05)	WABCO ECAS 3	V4,2
33	DAF	CF 75	DASHBOARD	XE 340 (02-05)		V4,2
34	DAF	CF 75	DASHBOARD	XE 380 (02-05)		V4,2
35	DAF	CF 75	DASHBOARD	XE 430 (02-05)		V4,2
36	DAF	CF 75	DASHBOARD	XE 480 (02-05)		V4,2
37	DAF	CF 75	BRAKE SYS. MANAGEMENT	XE 340 (02-05)	WABCO EBS	V4,2
38	DAF	CF 75	BRAKE SYS. MANAGEMENT	XE 380 (02-05)	WABCO EBS	V4,2

#	Brand	Model	System	Engine	ECU	Version
39	DAF	CF 75	BRAKE SYS. MANAGEMENT	XE 430 (02-05)	WABCO EBS	V4,2
40	DAF	CF 75	BRAKE SYS. MANAGEMENT	XE 480 (02-05)	WABCO EBS	V4,2
41	DAF	CF 85	ENGINE MANAGEMENT	XE 340 (02-05)	DAF UPEC	V4,2
42	DAF	CF 85	ENGINE MANAGEMENT	XE 380 (02-05)	DAF UPEC	V4,2
43	DAF	CF 85	ENGINE MANAGEMENT	XE 430 (02-05)	DAF UPEC	V4,2
44	DAF	CF 85	ENGINE MANAGEMENT	XE 480 (02-05)	DAF UPEC	V4,2
45	DAF	CF 85	AUTOM. TRANSMISSION	XE 340 (02-05)	ZF ASTRONIC	V4,2
46	DAF	CF 85	AUTOM. TRANSMISSION	XE 380 (02-05)	ZF ASTRONIC	V4,2
47	DAF	CF 85	AUTOM. TRANSMISSION	XE 430 (02-05)	ZF ASTRONIC	V4,2
48	DAF	CF 85	AUTOM. TRANSMISSION	XE 480 (02-05)	ZF ASTRONIC	V4,2
49	DAF	CF 85	SUSPENSION CONTROL	XE 340 (02-05)	WABCO ECAS 3	V4,2
50	DAF	CF 85	SUSPENSION CONTROL	XE 380 (02-05)	WABCO ECAS 3	V4,2
51	DAF	CF 85	SUSPENSION CONTROL	XE 430 (02-05)	WABCO ECAS 3	V4,2
52	DAF	CF 85	SUSPENSION CONTROL	XE 480 (02-05)	WABCO ECAS 3	V4,2
53	DAF	CF 85	DASHBOARD	XE 340 (02-05)		V4,2
54	DAF	CF 85	DASHBOARD	XE 380 (02-05)		V4,2
55	DAF	CF 85	DASHBOARD	XE 430 (02-05)		V4,2
56	DAF	CF 85	DASHBOARD	XE 480 (02-05)		V4,2
57	DAF	CF 85	BRAKE SYS. MANAGEMENT	XE 340 (02-05)	WABCO EBS	V4,2
58	DAF	CF 85	BRAKE SYS. MANAGEMENT	XE 380 (02-05)	WABCO EBS	V4,2
59	DAF	CF 85	BRAKE SYS. MANAGEMENT	XE 430 (02-05)	WABCO EBS	V4,2
60	DAF	CF 85	BRAKE SYS. MANAGEMENT	XE 480 (02-05)	WABCO EBS	V4,2
61	DAF	XF 95	ENGINE MANAGEMENT	XE 380 C (02-05)	DAF UPEC	V4,2
62	DAF	XF 95	ENGINE MANAGEMENT	XE 430 C (02-05)	DAF UPEC	V4,2
63	DAF	XF 95	ENGINE MANAGEMENT	XE 480 C (02-05)	DAF UPEC	V4,2
64	DAF	XF 95	ENGINE MANAGEMENT	XE 530 C (02-05)	DAF UPEC	V4,2
65	DAF	XF 95	AUTOM. TRANSMISSION	XE 380 C (02-05)	ZF ASTRONIC	V4,2
66	DAF	XF 95	AUTOM. TRANSMISSION	XE 430 C (02-05)	ZF ASTRONIC	V4,2
67	DAF	XF 95	AUTOM. TRANSMISSION	XE 480 C (02-05)	ZF ASTRONIC	V4,2
68	DAF	XF 95	AUTOM. TRANSMISSION	XE 530 C (02-05)	ZF ASTRONIC	V4,2
69	DAF	XF 95	SUSPENSION CONTROL	XE 380 C (02-05)	WABCO ECAS 3	V4,2
70	DAF	XF 95	SUSPENSION CONTROL	XE 430 C (02-05)	WABCO ECAS 3	V4,2
71	DAF	XF 95	SUSPENSION CONTROL	XE 480 C (02-05)	WABCO ECAS 3	V4,2
72	DAF	XF 95	SUSPENSION CONTROL	XE 530 C (02-05)	WABCO ECAS 3	V4,2
73	DAF	XF 95	DASHBOARD	XE 380 C (02-05)		V4,2
74	DAF	XF 95	DASHBOARD	XE 430 C (02-05)		V4,2
75	DAF	XF 95	DASHBOARD	XE 480 C (02-05)		V4,2
76	DAF	XF 95	DASHBOARD	XE 530 C (02-05)		V4,2

#	Brand	Model	System	Engine	ECU	Version
77	DAF	XF 95	BRAKE SYS. MANAGEMENT	XE 380 C (02-05)	WABCO EBS	V4,2
78	DAF	XF 95	BRAKE SYS. MANAGEMENT	XE 430 C (02-05)	WABCO EBS	V4,2
79	DAF	XF 95	BRAKE SYS. MANAGEMENT	XE 480 C (02-05)	WABCO EBS	V4,2
80	DAF	XF 95	BRAKE SYS. MANAGEMENT	XE 530 C (02-05)	WABCO EBS	V4,2
81	Iveco	Daily & TurboDaily	CHASSIS NETWORK	2.3 HPI 116 CV		V4,2
82	Iveco	Daily & TurboDaily	CHASSIS NETWORK	2.3 HPI 96 CV		V4,2
83	Iveco	Daily & TurboDaily	CHASSIS NETWORK	2.3 HPT		V4,2
84	Iveco	Daily & TurboDaily	CHASSIS NETWORK	2.8 HPI		V4,2
85	Iveco	Daily & TurboDaily	CHASSIS NETWORK	3.0 CNG		V4,2
86	Iveco	Daily & TurboDaily	CHASSIS NETWORK	3.0 HPI		V4,2
87	Iveco	Daily & TurboDaily	CHASSIS NETWORK	3.0 HPT		V4,2
88	Iveco	Trakker	IMMOBILIZER			V4,2
89	Iveco	Trakker	SUSPENSION CONTROL		WABCO ECAS + CAN	V4,2
90	MAN	F2000	ENGINE MANAGEMENT	19.414 (99-00)	EDC MS5	V4,2
91	MAN	F2000	ENGINE MANAGEMENT	19.463 (99-00)	EDC MS5	V4,2
92	MAN	F2000	ABS	19.414 (99-00)	BOSCH/KNORR ABS Ci 12	V4,2
93	MAN	F2000	ABS	19.463 (99-00)	BOSCH/KNORR ABS Ci 12	V4,2
94	MAN	F2000	SUSPENSION CONTROL	19.414 (99-00)	WABCO ECAS 4x2 6x4	V4,2
95	MAN	F2000	SUSPENSION CONTROL	19.463 (99-00)	WABCO ECAS 4x2 6x4	V4,2
96	MAN	F2000	AUX. HEATING	19.414 (99-00)	ZH Webasto AT2000	V4,2
97	MAN	F2000	AUX. HEATING	19.463 (99-00)	ZH Webasto AT2000	V4,2
98	MAN	F2000	BRAKE POWER SUPP.	19.414 (99-00)	ZF Intarder est 32	V4,2
99	MAN	F2000	BRAKE POWER SUPP.	19.463 (99-00)	ZF Intarder est 32	V4,2
100	Mercedes Benz		Sprinter	ABS	208 CDI	ABS V4,2
101	Mercedes Benz		Sprinter	ABS	211 CDI	ABS V4,2
102	Mercedes Benz		Sprinter	ABS	213 CDI	ABS V4,2
103	Mercedes Benz		Sprinter	ABS	216 CDI	ABS V4,2
104	Mercedes Benz		Sprinter	ABS	308 CDI	ABS V4,2
105	Mercedes Benz		Sprinter	ABS	311 CDI	ABS V4,2
106	Mercedes Benz		Sprinter	ABS	313 CDI	ABS V4,2
107	Mercedes Benz		Sprinter	ABS	316 CDI	ABS V4,2
108	Mercedes Benz		Sprinter	ABS	408 CDI	ABS V4,2
109	Mercedes Benz		Sprinter	ABS	411 CDI	ABS V4,2
110	Mercedes Benz		Sprinter	ABS	413 CDI	ABS V4,2
111	Mercedes Benz		Sprinter	ABS	416 CDI	ABS V4,2
112	Mercedes Benz		Sprinter	ABS	616 CDI	ABS V4,2
113	Volvo	FH16	SERVICE LIGHT RESET	540 (03-07)		V4,2
114	Volvo	FH16	SERVICE LIGHT RESET	580 (03-07)		V4,2

#	Brand	Model	System	Engine	ECU	Version
115	Volvo	FH16	SERVICE LIGHT RESET	610 (03-07)		V4,2
116	Volvo	FH16	SERVICE LIGHT RESET	660 (03-07)		V4,2
117	Volvo	FH16	ENGINE MANAGEMENT	540 (03-07)		V4,2
118	Volvo	FH16	ENGINE MANAGEMENT	580 (03-07)		V4,2
119	Volvo	FH16	ENGINE MANAGEMENT	610 (03-07)		V4,2
120	Volvo	FH16	ENGINE MANAGEMENT	660 (03-07)		V4,2
121	Volvo	FH16	CHASSIS NETWORK	540 (03-07)	Vehicle ECU	V4,2
122	Volvo	FH16	CHASSIS NETWORK	580 (03-07)	Vehicle ECU	V4,2
123	Volvo	FH16	CHASSIS NETWORK	610 (03-07)	Vehicle ECU	V4,2
124	Volvo	FH16	CHASSIS NETWORK	660 (03-07)	Vehicle ECU	V4,2
125	Volvo	FH16	SUSPENSION CONTROL	540 (03-07)		V4,2
126	Volvo	FH16	SUSPENSION CONTROL	580 (03-07)		V4,2
127	Volvo	FH16	SUSPENSION CONTROL	610 (03-07)		V4,2
128	Volvo	FH16	SUSPENSION CONTROL	660 (03-07)		V4,2
129	Volvo	FH16	HEADLIGHT LEVEL	540 (03-07)		V4,2
130	Volvo	FH16	HEADLIGHT LEVEL	580 (03-07)		V4,2
131	Volvo	FH16	HEADLIGHT LEVEL	610 (03-07)		V4,2
132	Volvo	FH16	HEADLIGHT LEVEL	660 (03-07)		V4,2
133	Volvo	FH16	DASHBOARD	540 (03-07)		V4,2
134	Volvo	FH16	DASHBOARD	580 (03-07)		V4,2
135	Volvo	FH16	DASHBOARD	610 (03-07)		V4,2
136	Volvo	FH16	DASHBOARD	660 (03-07)		V4,2
137	Volvo	FH16	AUX. HEATING	540 (03-07)		V4,2
138	Volvo	FH16	AUX. HEATING	580 (03-07)		V4,2
139	Volvo	FH16	AUX. HEATING	610 (03-07)		V4,2
140	Volvo	FH16	AUX. HEATING	660 (03-07)		V4,2
141	Volvo	FH16	ELECTRIC ACTUATION	540 (03-07)		V4,2
142	Volvo	FH16	ELECTRIC ACTUATION	580 (03-07)		V4,2
143	Volvo	FH16	ELECTRIC ACTUATION	610 (03-07)		V4,2
144	Volvo	FH16	ELECTRIC ACTUATION	660 (03-07)		V4,2
145	Volvo	FH16	BRAKE SYS. MANAGEMENT	540 (03-07)		V4,2
146	Volvo	FH16	BRAKE SYS. MANAGEMENT	580 (03-07)		V4,2
147	Volvo	FH16	BRAKE SYS. MANAGEMENT	610 (03-07)		V4,2
148	Volvo	FH16	BRAKE SYS. MANAGEMENT	660 (03-07)		V4,2
149	Volvo	FH16	CHRONOTACHOGRAPH	540 (03-07)		V4,2
150	Volvo	FH16	CHRONOTACHOGRAPH	580 (03-07)		V4,2
151	Volvo	FH16	CHRONOTACHOGRAPH	610 (03-07)		V4,2
152	Volvo	FH16	CHRONOTACHOGRAPH	660 (03-07)		V4,2

#	Brand	Model	System	Engine	ECU	Version
153	Volvo	FH16	CHASSIS MANAGEMENT	540 (03-07)		V4,2
154	Volvo	FH16	CHASSIS MANAGEMENT	580 (03-07)		V4,2
155	Volvo	FH16	CHASSIS MANAGEMENT	610 (03-07)		V4,2
156	Volvo	FH16	CHASSIS MANAGEMENT	660 (03-07)		V4,2
157	Volvo	FH16	SERVICE LIGHT RESET	540 (03-07)		V4,2
158	Volvo	FH16	SERVICE LIGHT RESET	580 (03-07)		V4,2
159	Volvo	FH16	SERVICE LIGHT RESET	610 (03-07)		V4,2
160	Volvo	FH16	SERVICE LIGHT RESET	660 (03-07)		V4,2
161	Volvo	FH16	ENGINE MANAGEMENT	540 (03-07)		V4,2
162	Volvo	FH16	ENGINE MANAGEMENT	580 (03-07)		V4,2
163	Volvo	FH16	ENGINE MANAGEMENT	610 (03-07)		V4,2
164	Volvo	FH16	ENGINE MANAGEMENT	660 (03-07)		V4,2
165	Volvo	FH16	CHASSIS NETWORK	540 (03-07)	Vehicle ECU	V4,2
166	Volvo	FH16	CHASSIS NETWORK	580 (03-07)	Vehicle ECU	V4,2
167	Volvo	FH16	CHASSIS NETWORK	610 (03-07)	Vehicle ECU	V4,2
168	Volvo	FH16	CHASSIS NETWORK	660 (03-07)	Vehicle ECU	V4,2
169	Volvo	FH16	SUSPENSION CONTROL	540 (03-07)		V4,2
170	Volvo	FH16	SUSPENSION CONTROL	580 (03-07)		V4,2
171	Volvo	FH16	SUSPENSION CONTROL	610 (03-07)		V4,2
172	Volvo	FH16	SUSPENSION CONTROL	660 (03-07)		V4,2
173	Volvo	FH16	HEADLIGHT LEVEL	540 (03-07)		V4,2
174	Volvo	FH16	HEADLIGHT LEVEL	580 (03-07)		V4,2
175	Volvo	FH16	HEADLIGHT LEVEL	610 (03-07)		V4,2
176	Volvo	FH16	HEADLIGHT LEVEL	660 (03-07)		V4,2
177	Volvo	FH16	DASHBOARD	540 (03-07)		V4,2
178	Volvo	FH16	DASHBOARD	580 (03-07)		V4,2
179	Volvo	FH16	DASHBOARD	610 (03-07)		V4,2
180	Volvo	FH16	DASHBOARD	660 (03-07)		V4,2
181	Volvo	FH16	AUX. HEATING	540 (03-07)		V4,2
182	Volvo	FH16	AUX. HEATING	580 (03-07)		V4,2
183	Volvo	FH16	AUX. HEATING	610 (03-07)		V4,2
184	Volvo	FH16	AUX. HEATING	660 (03-07)		V4,2
185	Volvo	FH16	ELECTRIC ACTUATION	540 (03-07)		V4,2
186	Volvo	FH16	ELECTRIC ACTUATION	580 (03-07)		V4,2
187	Volvo	FH16	ELECTRIC ACTUATION	610 (03-07)		V4,2
188	Volvo	FH16	ELECTRIC ACTUATION	660 (03-07)		V4,2
189	Volvo	FH16	BRAKE SYS. MANAGEMENT	540 (03-07)		V4,2
190	Volvo	FH16	BRAKE SYS. MANAGEMENT	580 (03-07)		V4,2

#	Brand	Model	System	Engine	ECU	Version
191	Volvo	FH16	BRAKE SYS. MANAGEMENT	610 (03-07)		V4,2
192	Volvo	FH16	BRAKE SYS. MANAGEMENT	660 (03-07)		V4,2
193	Volvo	FH16	CHRONOTACHOGRAPH	540 (03-07)		V4,2
194	Volvo	FH16	CHRONOTACHOGRAPH	580 (03-07)		V4,2
195	Volvo	FH16	CHRONOTACHOGRAPH	610 (03-07)		V4,2
196	Volvo	FH16	CHRONOTACHOGRAPH	660 (03-07)		V4,2
197	Volvo	FH16	CHASSIS MANAGEMENT	540 (03-07)		V4,2
198	Volvo	FH16	CHASSIS MANAGEMENT	580 (03-07)		V4,2
199	Volvo	FH16	CHASSIS MANAGEMENT	610 (03-07)		V4,2
200	Volvo	FH16	CHASSIS MANAGEMENT	660 (03-07)		V4,2
201	Volvo	FM12	SERVICE LIGHT RESET	360 (03-07)		V4,2
202	Volvo	FM12	SERVICE LIGHT RESET	400 (03-07)		V4,2
203	Volvo	FM12	SERVICE LIGHT RESET	440 (03-07)		V4,2
204	Volvo	FM12	SERVICE LIGHT RESET	480 (03-07)		V4,2
205	Volvo	FM12	ENGINE MANAGEMENT	360 (03-07)		V4,2
206	Volvo	FM12	ENGINE MANAGEMENT	400 (03-07)		V4,2
207	Volvo	FM12	ENGINE MANAGEMENT	440 (03-07)		V4,2
208	Volvo	FM12	ENGINE MANAGEMENT	480 (03-07)		V4,2
209	Volvo	FM12	CHASSIS NETWORK	360 (03-07)	Vehicle ECU	V4,2
210	Volvo	FM12	CHASSIS NETWORK	400 (03-07)	Vehicle ECU	V4,2
211	Volvo	FM12	CHASSIS NETWORK	440 (03-07)	Vehicle ECU	V4,2
212	Volvo	FM12	CHASSIS NETWORK	480 (03-07)	Vehicle ECU	V4,2
213	Volvo	FM12	SUSPENSION CONTROL	360 (03-07)		V4,2
214	Volvo	FM12	SUSPENSION CONTROL	400 (03-07)		V4,2
215	Volvo	FM12	SUSPENSION CONTROL	440 (03-07)		V4,2
216	Volvo	FM12	SUSPENSION CONTROL	480 (03-07)		V4,2
217	Volvo	FM12	HEADLIGHT LEVEL	360 (03-07)		V4,2
218	Volvo	FM12	HEADLIGHT LEVEL	400 (03-07)		V4,2
219	Volvo	FM12	HEADLIGHT LEVEL	440 (03-07)		V4,2
220	Volvo	FM12	HEADLIGHT LEVEL	480 (03-07)		V4,2
221	Volvo	FM12	DASHBOARD	360 (03-07)		V4,2
222	Volvo	FM12	DASHBOARD	400 (03-07)		V4,2
223	Volvo	FM12	DASHBOARD	440 (03-07)		V4,2
224	Volvo	FM12	DASHBOARD	480 (03-07)		V4,2
225	Volvo	FM12	AUX. HEATING	360 (03-07)		V4,2
226	Volvo	FM12	AUX. HEATING	400 (03-07)		V4,2
227	Volvo	FM12	AUX. HEATING	440 (03-07)		V4,2
228	Volvo	FM12	AUX. HEATING	480 (03-07)		V4,2

#	Brand	Model	System	Engine	ECU	Version
229	Volvo	FM12	BRAKE SYS. MANAGEMENT	360 (03-07)		V4,2
230	Volvo	FM12	BRAKE SYS. MANAGEMENT	400 (03-07)		V4,2
231	Volvo	FM12	BRAKE SYS. MANAGEMENT	440 (03-07)		V4,2
232	Volvo	FM12	BRAKE SYS. MANAGEMENT	480 (03-07)		V4,2
233	Volvo	FM12	SERVICE LIGHT RESET	360 (03-07)		V4,2
234	Volvo	FM12	SERVICE LIGHT RESET	400 (03-07)		V4,2
235	Volvo	FM12	SERVICE LIGHT RESET	440 (03-07)		V4,2
236	Volvo	FM12	SERVICE LIGHT RESET	480 (03-07)		V4,2
237	Volvo	FM12	ENGINE MANAGEMENT	360 (03-07)		V4,2
238	Volvo	FM12	ENGINE MANAGEMENT	400 (03-07)		V4,2
239	Volvo	FM12	ENGINE MANAGEMENT	440 (03-07)		V4,2
240	Volvo	FM12	ENGINE MANAGEMENT	480 (03-07)		V4,2
241	Volvo	FM12	CHASSIS NETWORK	360 (03-07)	Vehicle ECU	V4,2
242	Volvo	FM12	CHASSIS NETWORK	400 (03-07)	Vehicle ECU	V4,2
243	Volvo	FM12	CHASSIS NETWORK	440 (03-07)	Vehicle ECU	V4,2
244	Volvo	FM12	CHASSIS NETWORK	480 (03-07)	Vehicle ECU	V4,2
245	Volvo	FM12	SUSPENSION CONTROL	360 (03-07)		V4,2
246	Volvo	FM12	SUSPENSION CONTROL	400 (03-07)		V4,2
247	Volvo	FM12	SUSPENSION CONTROL	440 (03-07)		V4,2
248	Volvo	FM12	SUSPENSION CONTROL	480 (03-07)		V4,2
249	Volvo	FM12	HEADLIGHT LEVEL	360 (03-07)		V4,2
250	Volvo	FM12	HEADLIGHT LEVEL	400 (03-07)		V4,2
251	Volvo	FM12	HEADLIGHT LEVEL	440 (03-07)		V4,2
252	Volvo	FM12	HEADLIGHT LEVEL	480 (03-07)		V4,2
253	Volvo	FM12	DASHBOARD	360 (03-07)		V4,2
254	Volvo	FM12	DASHBOARD	400 (03-07)		V4,2
255	Volvo	FM12	DASHBOARD	440 (03-07)		V4,2
256	Volvo	FM12	DASHBOARD	480 (03-07)		V4,2
257	Volvo	FM12	AUX. HEATING	360 (03-07)		V4,2
258	Volvo	FM12	AUX. HEATING	400 (03-07)		V4,2
259	Volvo	FM12	AUX. HEATING	440 (03-07)		V4,2
260	Volvo	FM12	AUX. HEATING	480 (03-07)		V4,2
261	Volvo	FM12	ELECTRIC ACTUATION	360 (03-07)		V4,2
262	Volvo	FM12	ELECTRIC ACTUATION	400 (03-07)		V4,2
263	Volvo	FM12	ELECTRIC ACTUATION	440 (03-07)		V4,2
264	Volvo	FM12	ELECTRIC ACTUATION	480 (03-07)		V4,2
265	Volvo	FM12	BRAKE SYS. MANAGEMENT	360 (03-07)		V4,2
266	Volvo	FM12	BRAKE SYS. MANAGEMENT	400 (03-07)		V4,2

#	Brand	Model	System	Engine	ECU	Version
267	Volvo	FM12	BRAKE SYS. MANAGEMENT	440 (03-07)		V4,2
268	Volvo	FM12	BRAKE SYS. MANAGEMENT	480 (03-07)		V4,2
269	Volvo	FM12	CHRONOTACHOGRAPH	360 (03-07)		V4,2
270	Volvo	FM12	CHRONOTACHOGRAPH	400 (03-07)		V4,2
271	Volvo	FM12	CHRONOTACHOGRAPH	440 (03-07)		V4,2
272	Volvo	FM12	CHRONOTACHOGRAPH	480 (03-07)		V4,2
273	Volvo	FM12	CHASSIS MANAGEMENT	360 (03-07)		V4,2
274	Volvo	FM12	CHASSIS MANAGEMENT	400 (03-07)		V4,2
275	Volvo	FM12	CHASSIS MANAGEMENT	440 (03-07)		V4,2
276	Volvo	FM12	CHASSIS MANAGEMENT	480 (03-07)		V4,2
277	Volvo	FM9	SERVICE LIGHT RESET	260 (03-07)		V4,2
278	Volvo	FM9	SERVICE LIGHT RESET	300 (03-07)		V4,2
279	Volvo	FM9	SERVICE LIGHT RESET	340 (03-07)		V4,2
280	Volvo	FM9	SERVICE LIGHT RESET	380 (03-07)		V4,2
281	Volvo	FM9	ENGINE MANAGEMENT	260 (03-07)		V4,2
282	Volvo	FM9	ENGINE MANAGEMENT	300 (03-07)		V4,2
283	Volvo	FM9	ENGINE MANAGEMENT	340 (03-07)		V4,2
284	Volvo	FM9	ENGINE MANAGEMENT	380 (03-07)		V4,2
285	Volvo	FM9	CHASSIS NETWORK	260 (03-07)	Vehicle ECU	V4,2
286	Volvo	FM9	CHASSIS NETWORK	300 (03-07)	Vehicle ECU	V4,2
287	Volvo	FM9	CHASSIS NETWORK	340 (03-07)	Vehicle ECU	V4,2
288	Volvo	FM9	CHASSIS NETWORK	380 (03-07)	Vehicle ECU	V4,2
289	Volvo	FM9	SUSPENSION CONTROL	260 (03-07)		V4,2
290	Volvo	FM9	SUSPENSION CONTROL	300 (03-07)		V4,2
291	Volvo	FM9	SUSPENSION CONTROL	340 (03-07)		V4,2
292	Volvo	FM9	SUSPENSION CONTROL	380 (03-07)		V4,2
293	Volvo	FM9	HEADLIGHT LEVEL	260 (03-07)		V4,2
294	Volvo	FM9	HEADLIGHT LEVEL	300 (03-07)		V4,2
295	Volvo	FM9	HEADLIGHT LEVEL	340 (03-07)		V4,2
296	Volvo	FM9	HEADLIGHT LEVEL	380 (03-07)		V4,2
297	Volvo	FM9	DASHBOARD	260 (03-07)		V4,2
298	Volvo	FM9	DASHBOARD	300 (03-07)		V4,2
299	Volvo	FM9	DASHBOARD	340 (03-07)		V4,2
300	Volvo	FM9	DASHBOARD	380 (03-07)		V4,2
301	Volvo	FM9	AUX. HEATING	260 (03-07)		V4,2
302	Volvo	FM9	AUX. HEATING	300 (03-07)		V4,2
303	Volvo	FM9	AUX. HEATING	340 (03-07)		V4,2
304	Volvo	FM9	AUX. HEATING	380 (03-07)		V4,2

#	Brand	Model	System	Engine	ECU	Version
305	Volvo	FM9	ELECTRIC ACTUATION	260 (03-07)		V4,2
306	Volvo	FM9	ELECTRIC ACTUATION	300 (03-07)		V4,2
307	Volvo	FM9	ELECTRIC ACTUATION	340 (03-07)		V4,2
308	Volvo	FM9	ELECTRIC ACTUATION	380 (03-07)		V4,2
309	Volvo	FM9	BRAKE SYS. MANAGEMENT	260 (03-07)		V4,2
310	Volvo	FM9	BRAKE SYS. MANAGEMENT	300 (03-07)		V4,2
311	Volvo	FM9	BRAKE SYS. MANAGEMENT	340 (03-07)		V4,2
312	Volvo	FM9	BRAKE SYS. MANAGEMENT	380 (03-07)		V4,2
313	Volvo	FM9	CHRONOTACHOGRAPH	260 (03-07)		V4,2
314	Volvo	FM9	CHRONOTACHOGRAPH	300 (03-07)		V4,2
315	Volvo	FM9	CHRONOTACHOGRAPH	340 (03-07)		V4,2
316	Volvo	FM9	CHRONOTACHOGRAPH	380 (03-07)		V4,2
317	Volvo	FM9	CHASSIS MANAGEMENT	260 (03-07)		V4,2
318	Volvo	FM9	CHASSIS MANAGEMENT	300 (03-07)		V4,2
319	Volvo	FM9	CHASSIS MANAGEMENT	340 (03-07)		V4,2
320	Volvo	FM9	CHASSIS MANAGEMENT	380 (03-07)		V4,2